


Product Manual


Profibus DP TOS-S7-PB Gateway for TOSHIBA - Inverter VF- S7, S9, S11, A7, P7, nC1



ESCO EUGEN SCHMIDT UND CO
ANTRIEBSTECHNIK



Gateway PROFIBUS DP





Important Instruction

This manual has been compiled with great care. However, ESCO EUGEN SCHMIDT UND CO does not undertake any responsibility for incorrect representation or unmentioned technical correlations. Especially, any liability for the damages that result due to the use of this technical manual is not accepted.

The products and the functions described in this documentation can be modified to suit the latest technological development anytime. The information given in this manual cannot be held valid contractually.

Contents

| | |
|--|-----------|
| 1 Introduction | 3 |
| 1.1 Contents of Delivery-kit | 3 |
| 1.2 Application | 3 |
| 1.3 Valid Specifications | 3 |
| 2 Safety Instructions | 4 |
| 2.1 Safety Instruction Symbols | 5 |
| 3 Technical Data | 6 |
| 3.1 Mechanical Data | 6 |
| 3.2 Ambient Conditions | 6 |
| 3.3 Electrical Data | 6 |
| 3.4 Characteristics | 6 |
| 3.5 Power Supply | 7 |
| 3.6 Compliance with standards | 7 |
| 3.7 Communication Data | 7 |
| 4 Hardware Description | 9 |
| 4.1 Positioning of Addresses | 9 |
| 4.2 Profibus Connections | 9 |
| 4.3 Diagnostic Indicator on Profibus Module | 11 |
| 4.4 Diagnostics on Profibus | 11 |
| 4.5 Serial Interface TOSHIBA VF S7 inverter | |
| 5 Software Description | 14 |
| 5.1 Profibus- General | 14 |
| 5.2 Profibus-Control word object 6040H | 15 |
| 5.3 Profibus-Status word object 6041H | 16 |
| 5.4 Associated equipment TOSHIBA VF S7 inverter | |
| 6 Profibus Objects | 18 |
| 6.1 General | 18 |
| 6.2 Profibus Interface, Explanation of the objects | 18 |
| 7 Application of Profibus with TOSHIBA VF S7 inverter | 24 |
| Pre-Settings | 24 |

| | |
|--|-----------|
| 7 Commissioning | 25 |
| 7.3 Start up | 25 |
| 7.4 Hints for Commissioning/ operation | 25 |
| 7.5 Incompatibilities of functions | 27 |
| 8 Complete Access to all the variable of TOSHIBA VF S7 inverter | 28 |
| 8.0 Command Types, COM | 28 |
| 8.1 Status indications COM | 30 |
| 8.2 Examples | 31 |
| 9 List of Addressess for TOSHIBA VF S7 inverter | 33 |
| 9.1 Headings | 33 |
| 9.2 Parameter list | 33 |

VF S7 – Profibus - Module

1 Introduction

Following operational instructions are for the purpose of safe working TOSHIBA VF S7 series frequency converter (Inverter) with Profibus switching module TOS - S7 - PB , which is also referred below as “Profibus-module“.

All the safety instructions laid out here must be observed.

All the persons, who work with Profibus-Module, must have access to this operational instructions. All specifications are to be observed.

This documentation must be applied in complete form and unrestricted condition.

In order to ensure trouble free operation, please read the manual before using the module.

1.1 Delivery-Kit

Delivery-Kit contains:

- One Profibus-Modul TOS - S7 - PB with plug-in connector for the external 24V DC power supply.
- One connecting cable CAB - VF - BUS for connecting Profibus-Module to Inverter.
- One Diskette with GSD-data
- An Installation Advice

1.2 Application

Profibus-Module should be used only under the installation-requirements described in this technical documentation.

The Profibus-Module is an option for TOSHIBA Inverter VF S7. S7 series is fitted with serial interface(TTL). The Profibus-Module TOS - S7 – PB enables each module to be connected to up to four TOSHIBA Inverters VF S7 on to Profibus DP.

Via the Profibus, the VF S7 inverter with the connected module, can be programmed or controlled through Control Words or Objects described below. In addition to that, all the parameters and variables of VF S7 can be read and written without any restrictions.

The Profibus-Module should be installed and connected as per the specifications and in such a way that by orderly and correct use, no personnel danger should occur in the normal operation.

The safety instructions described here must be observed without fail.

It should be ensured through suitable measures that no personnel or equipment damage results due to failure of Profibus-Module.

Any other use is prohibited.

1.3 Valid Specifications:

The information, Data and instructions contained in this document is compiled very carefully as per the development and publishing of the latest- up to the version available at the time of compilation. From the hints, diagrams and descriptions contained in this documentation no claims can be made for the revisions of the Profibus-Module.

For the suitability of the indicated procedures and circuits, EUGEN SCHMIDT UND CO does not take any guarantee or liability.

Every liability and guarantee is invalid when damages occur due to :

- Inappropriate use of Technical Documentation
- Invalid application and installation
- Unauthorized modification of the Profibus-Module or its connection to the VF S7 inverter
- Requirement failure

2 Safety Instructions

2.1 Safety Instructions- General

These safety instructions do no claim for the completeness. For any queries on problems, please contact EUGEN SCHMIDT UND CO.

The Profibus-Module corresponds to the version available for the technology at the time of writing this manual and is considered as reliable.

From the Profibus-Module, dangers can occur if:

- an unqualified person works with the Profibus-Module
- the Profibus-Module is used incorrectly.

The hints given in this documentation are only suggestions and must be checked when applying to each application for their feasibility and functionality.

Hence, considerable care must be taken so that through any defect or fault in the Profibus-Module, no personnel or equipment damage can occur.

This total drive system must be put into operation only in trouble free condition.

Changes and modifications on the Profibus-Module are fundamentally denied. Any self modification or change without conformation from and in agreement with EUGEN SCHMIDT UND CO invalidates any guarantee and responsibility.

While installing this module, it is important to follow correct connections to all the active components(Profibus-Module, Inverter etc.) for avoiding possible EMC interference, all the general known wiring rules should be adopted (e.g correct voltage balance, flat surface earthing of screens, contractor switching with suitable RC-combination etc.) The module should be earthed through earthing connector.

2.2 Symbols of Safety Instructions



All the safety instructions in this technical book are depicted with common principle (Pictogramm)





Warning word

Instructions Text

- Depiction of the act of Danger through pictogramm
- Indication of Level of Danger through warning word.
- Description of the danger as well as advice for avoiding the danger through Instructions test

| Used Pitogram | Associated Warning Word | Explanation |
|--|-------------------------|--|
|  | Warning! | Warning for a possiblity of highly dangerous situation Possible consequences by mishandling: Death or sever injuries |
|  | Careful | Warning for possiblity of a highly dangerous situation Possible consequences by mishandling: Low or superficial injuries |

| Used Pitogram | Associated Warning Word | Explanation |
|---|-------------------------|--|
|  | Stop! | Warning for possible equipment damage Possible consequences by mishandling: Damage to Profibus-Module or its surroundings. |

| Used Pitogram | Associated Warning Word | Explanation |
|---|-------------------------|---|
|  | Tip! | Useful tips for easy dealing with Profibus-Module |

3 Technical Data

3.1 Mechanical Data

The Profibus-Module TOS - S7 - PB is mounted on a DIN rail

The Profibus-Module TOS - S7 – PB is constructed in IP31

Dimensions: (W.H.D): 90 x 125 x 42 mm aligned

3.2 Ambient Conditions

| | |
|-------------------------|--|
| Standards | EN, IEC |
| Limits of Vibrations: | 0.6g- range 10 to 50 Hz |
| Max. Ambient Dust Grade | Dust Grade2 as per IEC 664 |
| Max. Relative Humidity: | 93% without condensation. (not tropical) |
| Temperature: | |
| Storage | -25 to 65°C |
| Operation | -10 to 50°C |

3.3 Electrical Data

| | |
|---------------------|---|
| Power Supply | External 24V DC |
| Current Consumption | 150 mA |
| Communication | RS485 |
| Profibus Partner | Slave |
| Transmission Rate | Max. 12 MBaud |
| Galvanic Isolation | All 4 channel to Profibus with 600V among one another |

3.4 Characteristics:

- Up to max. FOUR Inverters can be connected to one Profibus-Module
- Simple connection of the inverter through Western connector
- Upto 126 partners on the Bus
- Access to all TOSHIBA VF S7 parameters
- Transmission medium: Two core twisted-pair cable, screened
- Automatically adjustable transmission rate
- Physical construction as per standard RS485
- Continuous Monitoring of the connection between Inverter/Profibus-Module
- Separate 24 V DC power supply
- Transmission security over Profibus: Hamming – Distance 5

VF S7 – Profibus - Module

3.5 Power Supply

Profibus-Module always requires a separate 24V DC supply (150mA), even with TOSHIBA VF S7 inverter switched off.

The internal + 24V power supply of the VF S7, available on the terminal of the serial interface and the inverter control terminals cannot be used as power supply for the Profibus module. The Profibus-Module must be additionally supplied with external + 24V DC.

In case VF S7 requires + 24V supply available at the terminal strip of the serial interface for creating galvanic isolation between VF S7 and the Profibus-Module, it should be kept in mind that this voltage can be loaded externally only upto 10mA. Otherwise the operation of the inverter is no more reliable.

3.6 Compliance with standards

| | |
|---|----------------------|
| CE Marking: | Existing (EN 50178) |
| Protections against electrostatic discharge (ESD) | IEC 1000-4-2-Level3 |
| Immunity against stray electromagnetic field over Radio frequency | IEC 1000-4-3 Level 3 |
| Stability against fast rising electrical impulse (Burst) | IEC 1000-4-4 Level 4 |
| Step Voltage Stability | IEC 1000-4-5 level 3 |
| Immunity against radio interface disturbances coupled with industrial wiring | IEC 1000-4-6 Level 3 |
| Stability against voltage spikes, short time power interruptions and voltage fluctuations | IEC 1000-4-11 |

3.7 Communication Data

3.7.1 Bus Times

The cycle time of the communication system is the time, in which the entire Control Word and Status Words are exchanged between the Master and the Field device(here: TOSHIBA VF S7). It depends on the data and the transmission rate of the communication system.

Thus :

T_{syn} = The synchronizing time, over which each partner must go through at least one pause before it can begin to accept a call (fixed with 3 bits).

T_{id1} = After the reception of the latest sign of a Telegram, the Initiator has to wait for this time, before it can send the next telegram . This times must be at least the time T_{syn} plus a safety margin.

T_{SDR} = The time, that a slave requires for answering.

min T_{SDR} = The time that a slave must wait for, before it can answer.

max T_{SDR} = The latest time within which a slave must respond.

The exact times are shown in following table:

| Transmission Rate [kBit/s] | 9,6 | 19,2 | 45,45 | 93,75 | 187,5 | 500 | 1500 | 3000 | 6000 | 12000 |
|----------------------------|-----|------|-------|-------|-------|-----|------|------|------|-------|
| min T_{SDR} in t_{Bit} | 11 | 11 | 11 | 11 | 11 | 11 | 11 | 11 | 11 | 11 |
| max T_{SDR} in t_{Bit} | 60 | 60 | 60 | 60 | 60 | 100 | 150 | 800 | 800 | 800 |

3.7.2 System Response Time

The system response time of Profibus system mainly depends on the following factors:

- The response time within which a partner can answer (T_{SDR})
- The transmission rate (Baudrate)
- Min_Slave_Interval (in Profibus-Module TOS - S7 - PB < 100µs)
- The agreed raw data length

Explanation of the used short-forms:

T_{MC} = Time cyclical message(Demand Telegram + T_{SDR} + Response from slave)

T_{BC} = Bus Cycle time; derived from the addition of message-cycles. For multi-master cases individual cycles are to be added.

T_{SDR} = 30 T_{Bit} at Baud rates greater than 1.5 Mband with Asic SPC3 used in Profibus-Module TOS-VF-PB

T_{Bit} = Time for transmission of a Bit.

In Data Exchange there exists a Telegram header of 9 Bytes. The pause time of the Bus results simultaneously from $T_{syn} = 33 T_{Bit}$ and $T_{ID1} = 75 T_{Bit}$.

The formula for calculation of the Messge Cycle time is given by:

$$T_{MC} = (2x \text{ length of the Headers in Bytes}) * 11 \text{ Bit} + T_{SDR} + T_{syn} + T_{ID1} \text{ (in Bit)}$$

3.7.3 Operational Time in TOSHIBA VF S7 inverter

The operational time in VF S7 inverter is given by addition of Bus Run Time. This operational time is decided with minimum tolerance and amounts to maximum 20 mSec. It is same for all the VF S7 inverters and is applicable for getting access to Profibus-Module on the VF S7 inverter. That means:

- 10 ms for giving information on VF S7 inverter and 10 ms for automatic responses.

That means, in summary:

- 20 ms for the exchange of Control Words and Status Words
- 20 ms for the reference value and actual value feedback
- 10 ms for accessing a parameter or a variable of an inverter.

3.7.4 Achievable Bus Lengths

As shown in the following table, the possible Bus lengths decrease rapidly with increasing transmission rates.

| Transmission Rate [kBit/s] | 9,6 | 19,2 | 45,45 | 93,75 | 187,5 | 500 | 1500 | 3000 | 6000 | 12000 |
|----------------------------|------|------|-------|-------|-------|-----|------|------|------|-------|
| Max. Bus length [m] | 1200 | 1200 | 1200 | 1200 | 1000 | 400 | 200 | 100 | 100 | 100 |

Hence care should be taken to keep the wiring from the Bus to individual participating units as short as possible in order to avoid unnecessary increase in total wiring length.

Tip!




Cable from Profibus to participating unit should not be longer than 6.6m for transmission speed of up to 1500 kbit/sec. For higher transmission speeds, the cable should not be used as reflections from this component negatively influence the transmission performance as well as achievable lengths. In that case connections should be made using plug-in connectors with built-in Bus cable.

4 Hardware Description

4.1 Setting of the Addresses

The addresses of Profibus-Module are set through two Hexadecimal coded rotating switches. The left is coded 16^1 , the right one is coded 16^0 . Any change of addresses is effective after the revised initialisation of the buses.

The transmission rate is adjusted automatically. The module supports transmission rate up to max 12 MBit/s.




Tip!



The addresses are readable only at the time of initialization.
Any subsequent change is not accepted and the communication to the corresponding participant is no longer possible unless restart command is given

4.2 Wiring of the Profibus

The Profibus accounts for the group of sequentially constructed buses. The wiring is terminated at the end with a 220 Ω Resistance. In addition to this the Bus wiring also has 390 Ω resistance connected to wires VP and DGND.




The above sketch can be considered as an example of building-up of Profibus System.

VF S7 - ProfiBus-Module

The terminating resistances are normally soldered inside the connector or otherwise realised through separate circuit at the end of the wiring.

The disposition of 9 Pin Sub-D connectors on the module corresponds the Profibus-Norm EN 50170:



Hint: The pins 3,5,6 and 8 marked with * are mandatory connections.

Tip!



Fault condition can arise if the 1st or the last participant on the Profibus becomes faulty. This fact should be considered carefully while doing the engineering.

Otherwise the regulations and wiring rules of the Profibus user organization are applicable.

4.3 Diagnostic Indication on the Profibus-Module

The Profibus-Module has LEDs for status indication. These LEDs have following meaning:

| Indication on the Profibus Module | Colour | Function |
|-----------------------------------|--------|---|
| + 5 V | Green | Supervision of the internal operating voltage of the Profibus Modules |
| Bus Error | Red | Supervision of the communications PB_Netwrok/ Fault Annunciation |

4.4 Diagnostic on the Profibus

There is internal supervision of the Profibus-system. In case of interruption on the bus, the Profibus-Module ensures that LED "Bus Error" on the Profibus-Module lights up and connected VF S7 inverter goes into control stop with fault indication *Err5* (Communications Fault).

In case of a break in wiring from a VF S7 inverter to the Profibus-Module, the inverter goes into the safety mode and goes into controlled stop with the fault indication *Err5* (Communications Fault). Other inverters connected to this Profibus-Module or other Profibus-Modules are not affected by this.

The separately fed Diagnostic-Byte of the Profibus-Module is always reset to the value of zero in healthy condition. In case of fault, following decimal indication of the values of the Diagnostic-Bytes result::

| Weightage | Meaning |
|-----------|---|
| 0 | No Fault |
| 1-5 | Profibus_module Internal Fault |
| 6 | Receiver Buffer Overload for the Profibus-Module. |
| 7- 10 | Profibus-Module Internal Fault. |
| 11 | Profibus Initialization Fault. |
| 12 | SPC3 Fault (User Asic) |


Tip!



A fault annunciation should be always reset from the Master so that Profibus-Module can be taken off Fault-status.

4.5 Serial Interface TOSHIBA VF S7

The internal drive addresses of the VF S7 set in the factory are not used. The ranking of the drives from 0 to 3 results from the respective push-in connectors through which the drives are connected with the Profibus-Module as per the following diagram.



For connecting the first inverter VF S7 to the push-in connector of the Profibus-Module TOS - VF - PB , the accompanying cable has to be used. For connecting additional inverters with the push-in connectors 1 to 3 of the Profibus-Module, there is a possibility to order a set of 3 cables (Order Type CAB-VF-BUS)

For self-constructed cable, following instructions should be observed.



- 1) The maximum length of the connecting cable is limited to 1 m.

Each signal receiving channel and transmitting channel (RXD, TXD) must be connected to 0 V.

- 2) The connecting cable must have eight- pin RJ 45 connecting plug on both the ends.
- 3) The pins 7 and 8 are not wired, however, Standard cables can be connected at these outputs over an additional Twisted pair.

The configuration of the overall system should be considered from the point of EMC regulations. The Profibus-Module must be correctly earthed.

VF S7 – Profibus - Module



5 Software Description

5.1 Profibus : General

Under the roof of the Profibus-User organisation (PNO/Karlsruhe), all the Profibus activities are brought together and coordinated. The Profibus protocol is finalized as per the European Norm EN 50170.

In order to meet the various requirements of the industrial communication for accountability, there are three Profibus solutions as per the task.

- Profibus DP For quick data exchange in the periphery. (DP = Decentralized Periphery)
Data Unit Byte/ Transmission Time : few 100 µs... 100ms/ Transmission Frequency 10... 100ms)
- Profibus FMS For the object oriented data exchange in cell range and field range (FMS= Fieldbus Message Specification; Data Unit KByte/ Transmission Time: Seconds /Transmission Frequency Std./ min)
- Profibus PA Fulfills the requirements of the process automation and in protected domain.(PA= Process Automation)

The protocol realised in the Profibus-Modul TOS - VF - PB is the Profibus-DP protocol. At layer 1 (physical layer) and layer 2 (safety layer) of the ISO/OSI modules, it is identical to the previous Profibus-FMS protocol. Simply in the layer 7, it differentiates itself from the similar FMS-Protocol. As the user layer is defined in the layer 7, one can view Profibus-DP as standardised application of the layer 2.

The Profibus-DP protocol is basically address oriented in a strict Master-Slave operation. It also allows the multi-master operation as well as mixed operation between Profibus DP and FMS participants.

Practically approx. 90% of all the Profibus-slave solutions realised up to now are DP solutions.

The transmission speeds of Profibus are definitely increased. The Profibus-module TOS - VF - PB supports the highest transmission speed of 12MBit/s specified up to now.

In the realisation of the working profiles of Profibus DP, essentially all the equally comparable profiles of Interbus-S (Drivecom) and CAN (CANopen-Specification) are referred. Hence, it is possible to drive a frequency converter (e.g. TOSHIBA VF S7) with unique control in control-word mode totally independent of the Bus system.

The main Profibus-Telegram construction with Profibus Module TOS - VF – PB is as follows: :

| Word 1 | Word 2 | Word 3 | Word 4 | Word 5 | Word 6 | Word 7 | Word 8 | Word 9 | Word 10 | Word 11 | Word 12 | Word 13 | Word 14 |
|----------------|--------------|----------------|--------------|----------------|--------------|----------------|--------------|-----------------------------|-----------------------|---------|---------|---------|---------|
| Control Word 0 | Ref. Value 0 | Control Word 1 | Ref. Value 1 | Control Word 2 | Ref. Value 2 | Control Word 3 | Ref. Value 3 | Connect or No. Command Type | Object No. or Address | Data | Data | Data | Data |

Tip!



The Profibus-Module breaks this data string as individual information for the respective inverter. The inverter would be coded as per the connection point (0-3) on the Profibus-Module. Simultaneously, the information on the inverter connected to the Module is passed on, whereby the Control Word has the priority.

With the start of the Profibus system, each Profibus slave module announces itself to the master. Via the GSD data of the module (included in delivery), the master has received the information at the time of configuration of the Profibus systems as to how many Bytes, Status and Control information is processed by the module

The Profibus recognises basically two forms of the data transmission between participants.

- Synchronous Operation
- Asynchronous Operation

In asynchronous operation, the data is sent from Master to the Profibus-Module and the Profibus-Module forwards the data after processing the information to the respective inverter.

In synchronous operation, the data are written and re-sent. They are stored in the Profibus-Module as long as Synchron-Telegram is sent. With that all the marked data on the inverter are given forward. This is suitable for, for example, the simultaneous reference value for many inverters.

In the Profibus-Module for the VF S7, the Profile 20-Standardized within Drivecom and supplemented by the „ Velocity Mode“ of the CANopen Profile, is implemented. With this, all the inverters are addressed as per the common principle and value domain, meanings and pre-settings (default values) for the parameters and functions are finalized.

VF S7 – Profibus - Module

VF S7 Profibus-Module

For all, the profiles of the operating system (Drivecom, CANopen, Velocity Mode Profibus), the characteristics within the “status mode“ are common. It is important here that the respective transitions can run through one another. The transition with the individual steps and the reactions of the inverter are described in the title 5.4 status Drive TOSHIBA VF S7.

The regulation of the inverter takes place over Control Word and the inverter response over the Status Words. The meaning of the Control Words and the Status Words is thus always the same.

- The Control Word 0 for the inverter at push-in connector 0 is converted into send command 1. The Control Words for the inverters at push-in connector 1-3 are transmitted in the send command 3,5 and 7.
- The Status Word 0 for the inverter at push-in connector 0 is converted into Receiving word 1. The Status Words of the inverters at the push-in connectors 1-3 are converted into receiving words 3,5 and 7.

Over the control word, the Master can issue transition within the status mode. The Profibus-Control Word is identical to its important functions of Drivecom- control word of Interbus-S and CANopen control word.

Through control words, the transition within the status mode and with that, the status of the inverter is signalled to the Master. The transition and status in Profibus-Status Word are mainly taken from Drivecom-statusmode of the Interbus-S and from CANopen-Status Word.

Over the send command 9-14, the individual Objects can be spoken to as per Profibus. The response takes place in Receive command 9-14. Further explanation of the Control and Status Words is given in the following titles.

5.2 Profibus-Control Word

The control word is composed of two Bytes, whose 16 bits have following meaning for the inverter VF S7:

| Bit 15 | Bit 14 | Bit 13 | Bit 12 | Bit 11 | Bit 10 | Bit 9 | Bit 8 |
|--|--|------------------------------|---|-----------------------|-----------|----------|-------------------------|
| Reference Value switching (1=Terminal strip 0= Profibus) | Direction Switching Right=0(+) Left=1(-) | Not used | VF S7 Enable, Command word Bit 15 | Not used | Reserved | Reserved | Stop Stop=1 Run=0 |
| Bit 7 | Bit 6 | Bit 5 | Bit 4 | Bit 3 | Bit 2 | Bit 1 | Bit 0 |
| Fault reset | Depends on operation mode | Depends on operation mode | Depends on operation mode | Operations Enabled | Quickstop | Voltage | Switch-ON |

The Bits marked with grey are pre-coded through drive profile of the Profibus DP (Mandatory)

5.2.1 Meaning of the Bits in Control Words

The Bits0-3 as well as 7 and 8 are used for running of the status mode.

Bit 2: Quickstop:

With the transition from 1 to 0 (Falling Edge) of this Bit, Quickstop results with the corresponding transition in the status Drive (ref.5.4 “Status Drive“)

Bit 7: Resetting After Fault:

With the transition for 0 to 1 (Rising Edge), all the inverter faults are reset.

Bit 8: Stop:

By resetting of this Bit, motors are commanded to stop with pre-set deceleration (ref: 5.4 “Status Drive“)

Bit 4-6, 9-11, 13

They must not be set. (Reserved or manufacturing specific Bits)

Bit 12:

This allows access to the internal Command Word (Address FAOOH) of the VF S7 inverter (ref. 10.2.2 “Parameters“). This is possibly only in the “Status Drive“ Enabled, state in order to restrict unauthorized start outside this state (0=Access not possible, 1= Access Enabled)

Bit 14 Switching:

Switching of the direction of rotation of the motors with reference command over the Profibus (ref 6.2.2“Speed Reference“)

Bit 15 Reference Value Input:

Switching of the Reference Command from either Terminal Strip of VFS7 or the bus.(Bus=0, Terminal Strip=1)

VF S7 - ProfiBus-Module

5.3 Profibus Status Word

The Profibus-Status Word is mainly identical to the Drivemom and CANopen Status Word. Over the Status Word, the drive regulation responds back its Operational Status. It is composed of two Bytes together whose 16 Bits have following disposition

| Bit 15 | Bit 14 | Bit 13 | Bit 12 | Bit 11 | Bit 10 | Bit 9 | Bit 8 |
|---------------------------------|--|----------|----------|-------------|----------------------------|--------|----------|
| Motor Status Run=1 Stop=0 | Direction of Rotation Right=0 Left =1 | Not used | Not used | Limit value | Reference value reached | Remote | Not used |

| Bit 7 | Bit 6 | Bit 5 | Bit 4 | Bit 3 | Bit 2 | Bit 1 | Bit 0 |
|---------|----------------------|------------|--------------------|-------|----------------------|-------------|------------------------|
| Warning | Switching Blocked | Quick Stop | Voltage Blocked | Fault | Operation Enabled | Switched ON | Ready for Switch ON |

The Bits with Grey background are pre-set from the Drive profile of the Profibus DP (Mandatory).

5.3.1 Meaning of the bits in Control Word

Bit 3: fault :

This Bit is set when the corresponding VF S7 comes up with a fault. (Transition 13, 14).

Bit 8,12-13 Free:

These Bits must always be 0.

Bit 9 Remote:

This Bit is set when a functional communications connection between the Profibus-Module and the connected inverter is established. The supervision of the Profibus_Systems must be from the Master.

Bit 10 Reference Value Reached :

Bit 10 is set as soon as the motor frequency is smaller or equal to the actual Reference Value ($\pm 2,5$ Hz Hysteresis). This Bit 10 is set also if motor is at standstill (and the Reference Value is zero).

Bit 11 Limit Value:


This Bit is directly influenced by the setting of speed-limit value (ref :6.2.4 „Speed limit-value (Object 6046H)“)

Bit 14 Direction of Rotation:

Signals direction of Motor Rotation (0:Clockwise, 1: anti-clockwise)

5.4 Bit 15 Motor Status: Run Indication: This Bit is set by either running motor or by active DC current switching.

5.4 Drive initialization (TOSHIBA Inverter VF S7, S9, A7, P7, nC1)



6 Profibus Objects

6.1 General

Profibus is basically address oriented. It is possible to change and re-adjust all the parameters and the variables of the connected inverter. These values are always stored in inverter's or Profibus-Module RAM whenever called upon via Objects. The procedure is described here very briefly.

The CANopen Profile „Velocity Mode“ regulates the control of drives as per the Interbus-S Drivecom-Profiles 20-22. The functions are copied whereby the important functions are copied as Duty Functions (Mandatory). The scope and the order of magnitude are given by Profile “Velocity Mode“. The operating profile of the Profibus DP takes over these Objects. It is described as follows:

The Profibus-Module participates as a slave in the communication over Profibus DP. The Bus information and control commands are shared with the Profibus-Module, which it passes on to the connected inverter as control words. On it's side, the Profibus-Module communicates further the feedback (status word) received from the inverter to the Bus-Master. The information contained in the Data words 1-8 of the data Strings can be foreseen such as Process Data Channels.

For the use of data words 9-14, the Object Parameters of the connected inverter described hereunder can be addressed and also the supporting functions can be activated, whereby all the parameters and variables of the VF S7 can be read and written. (e.g 9 “Complete Access of all the Variables of”). It can be seen as utilisation of Parameter data channel

The entire control information and status information must be programmed and managed from the Bus-Master.

Tip!



All objects (60 XXH) foreseen with an index can be addressed over the Data words 9-14. The coding of the plug-in connector (Hence the targeted response of an inverter) is realised in High-Byte from word 9. With the individual objects, the data lengths and units are specified, the words or the double-words are then to be described as appropriate.

6.2 Profibus-Interface, Explanation of Objects

Tip!




The specified values, which lie outside the adjustable limits of the VF S7 inverters can be adjusted at the respective limit values and are correspondingly displayed in the feedback.

By adjusting the values which are not specified over the objects but specified with the help of special functions over the words 9-14, the inverter generates Fault annunciation (e.g 9,3,4 “ Reception from Inverter, Faulty communication (“N”)“).

By accessing unknown or undefined objects, no fault is annunciated; in the Reception-DATA- Words 11-14 indicates OOH

Tip!



By establishing the connection of the inverter VF S7 to the Profibus-Module, the actual inverter data is read and accepted as setting it in the module.

VF S7 – Profibus - Module

6.2.1 Number of Pair of Poles (Object 604DH)

| | |
|----------------------------------|---|
| Meaning | Number of Pair of Poles of a motor |
| Object Nr. in Word 10: | 604DH |
| Data length from Word 11: | 1 Byte (Low Byte in Word11) |
| Value Domain: | 1 ... 255, pre adjusted on 2 (1 .. FFH) With the setting of 0 as number of pole-pairs, the module interpreters the setting for speeds as bipolar in Hz and assumes no calculation of 1/min in Hz. |
| Unit: | 1 |

The number of pole-pairs are required in order to calculate rotations (min^{-1}) from the Frequency (Hz). The formula for calculation of speed from frequency is:

$$n = f \times 60 / P$$

Where:

n = Motor speed in 1/min

f = Supply frequency in Hz (it is automatically read from VF S7 address 0007H)

p = Number of Poles-Pairs

The permissible range for p is from 1-255. By writing the values as 0, all the speeds are set in Hz.

Tip!



The pole-pairs are preset for commonly found 4-pole motors ($p=2$), which corresponds to operational speed of 1500 1/min with 50 Hz and 1800 1/min with 60 Hz frequency.

A change in the pole-pairs leads to consideration of other values, when they are accessed next. For example, a change in pole-pairs is first converted into new speed when it is accessed next.

6.2.2 Speed Setting (In Profibus-Data string transmitting word 2,4,6,8)

| | |
|----------------------------|--|
| Meaning | Speed set-point value for the inverter |
| In Word 2, 4, 6, 8: | |
| Data Length: | 1 Word (2 Byte) |
| Value Domain: | -32768 - +32768, 15 Bit + Sign (0000H to 7FFFH= positive, 0000H= 0; 7FFFH= 32767) (FFFFH to 8000H= negative, FFFFH= -1; 8000H= -32768) |
| Unit: | 1/min or 0,01Hz (as per the setting of pole-pairs) |

Tip!



Profibus writes a bipolar Reference value. That means, the setting value contains speed and the direction of rotation. This must also be kept in mind while setting the direction of rotation.


With clockwise directional setting, the positive speed values of a reference correspond to clockwise direction and the negative speed value of a reference correspond to anti-clockwise direction.

With anti-clockwise directional setting, positive speed value of a reference correspond to anti-clockwise direction and negative speed value of a reference corresponds to clockwise direction.

VF S7 - ProfiBus-Module

6.2.3 Maximum/Minimum Speed (Object 6056H)

| | |
|-------------------------------|---|
| Meaning | Maximum and Minimum speed for the inverter (ref: sketch in part 6.2.4 ("Speed-Limit settings")) |
| Object Nr. In Word 10: | 6056H |
| Word 11 & 12 | Minimum Speed |
| Word 13 & 14 | Maximum Speed |
| Data Length | Two Double words (total 8 Byte) |
| Value Domain: | Each Double word 0 - ($2^{32}-1$) |
| Unit: | 10^{-3} min^{-1} or (with pole-pair setting of 0) 0,01 Hz |




Example for unique setting of 35 1/min as minimum speed and 2,750 1/min as max. speed for the inverter with Address 1 (Occupancy of the Byte for the words 9-14: Byte 1= high-Byte of word 9, Byte 10= Low-Byte of word 9 etc.)

| Word 9 | | Word 10 | | Word 11 | | Word 12 | | Word 13 | | Word 14 | |
|-----------------|--------|------------|--------|---------------------------|--------|---------|--------|------------------------------|---------|---------|---------|
| Byte 1 | Byte 2 | Byte 3 | Byte 4 | Byte 5 | Byte 6 | Byte 7 | Byte 8 | Byte 9 | Byte 10 | Byte 11 | Byte 12 |
| ID und Üb.-Code | | Object Nr. | | min. speed (35.000 1/min) | | | | Max..speed (2.750.000 1/min) | | | |
| 01H | 57H | 60H | 48H | 00H | 00H | 88H | B8H | 00H | 29H | F6H | 30H |

6.2.4 Speed-Limit Setting (Object 6046H)

| | |
|-------------------------------|--|
| Meaing | Max. and mim. Speed limit value for both the directions |
| Object-Nr. In Word 10: | 6046H |
| Word 11 & 12 | Minimum Limit value |
| Word 13 & 14 | Maximum Limit value |
| Data Length: | Two Double words (Total8 Bytes) |
| Value Domain: | 0 - ($2^{32}-1$) |
| Unit: | 10^{-3} min^{-1} or (with pole-pair settingof 0) 0,01Hz |



These threshold values are proportional for the setting of Bit 11 (Limit value) in the status word of the respective interests. Here a minimum and maximum limit value is given to a Double-word, which is then valid for both the directions.

Tip!



The Bit 11 in Status Word (ref. 5.3, "Profibus Status Word") is set when the permissible range is over exceeded or under exceeded. The Parameter "LL"(Address 0013) and "UL" (Address 0012) from the inverter are read out as settings und and converted to the corresponding speeds.

VF S7 - ProfiBus-Module

6.2.5 Positive Acceleration (Object 6048H)

| | |
|-------------------------------|---|
| Meaning | Acceleration, Differential Speed |
| Profibus-Marking: | <i>positive Acceleration</i> |
| Objekt-Nr. In Word 10: | 6048H |
| Word 11 & 12 | Differential Speed |
| Meaning | pos. Acceleration, Differential Speed |
| Data Length | 1 Double-Word(4 Byte) |
| Value Domain: | 0- ($2^{32}-1$) |
| Unit: | min^{-1} or (with pole-pair setting of 0) 0,01Hz |
| Pre-setting: | Calculated from the VF S7 Parameters |
| Word 13 | <i>Differential Time</i> |
| Meaning | pos. Acceleration, Differential Time |
| Data Length: | 1 Word (2 Byte) |
| Value Domain: | 0...-65535 |
| Unit: | 0,1s |
| Pre-setting:: | Calculated from the VF S7 Parameter – ramp-up Time ACC |

The effective acceleration results as a quotient of Differential Speed and Differential Time. This value is calculated from the Profibus-Module and transmitted to the inverter VF S7. For the selection always the actual inverter values referred to the rated speed are picked and indicated.

VF S7 – Profibus - Module

6.2.6 Negative Acceleration (Object 6049H)

| | |
|-------------------------------|---|
| Meaning | Acceleration, Differential Speed |
| Profibus-Marking: | <i>negative</i> Acceleration |
| Object-Nr. In Word 10: | 6049H ¹ |
| Word 11 & 12 | Differential Speed |
| Meaning | neg. Acceleration, Differential Speed |
| Data Length: | 1 Double-Word (4 Byte) |
| Value Domain: | 0- ($2^{32}-1$) |
| Unit: | min ⁻¹ or in 0,01Hz |
| Pre-setting: | Calculated from VF S7 Parameters |
| Word 13 | <i>Differential Time</i> |
| Meaning | Acceleration, Differential Time |
| Data Length: | 1 Word (2 Byte) |
| Value Domain: | 0...-65535 |
| Unit: | 0,1 s |
| Pre-setting: | Calculated from VF S7 Parameters Ramp-down Time DEC |

The effective Acceleration results as a quotient of Differential Speed and Differential Time

Tip!



The parameters of the positive and negative Acceleration remain stored in RAM of the Profibus-Module. It suffices to change a value so that the new acceleration can be determined. Every selection of a value after that requires setting of both the data words.
The differential speed is calculated by the Profibus-Module always based on the rated speed and correspondingly displayed during feedback.

Example: An eight pole motor (four pole-pairs, Rated Speed 750 min⁻¹) is controlled by a VF S7 which is connected to the plug-in connector 1 of the Profibus-Module. The maximum speed of this motor is supposed to be 1500 min⁻¹, and the acceleration time for this speed to be 10 s. The unique writing for it is:

The Profibus-Module receives from Word 9 onwards following data:

| Wort 9 | | Wort 10 | | Wort 11 | | Wort 12 | | Wort 13 | |
|-----------------|--------|------------|--------|-------------------------|--------|---------|--------|-------------------|---------|
| Byte 1 | Byte 2 | Byte 3 | Byte 4 | Byte 5 | Byte 6 | Byte 7 | Byte 8 | Byte 9 | Byte 10 |
| ID and Üb.-Code | | Object-Nr. | | Pos. Differential Speed | | | | Differential Time | |
| 01H | 57H | 60H | 48H | 00H | 00H | 05H | DCH | 00H | 0AH |

Hint: The Acceleration Time ACC of the VF S7 is with reference to the supply frequency (Adress 0007). (Under the assumption that in „0007“ ,50Hz is entered), the Profibus-Module sends for this acceleration (0 to 100 Hz in 10 s) the value of 5 sec for the parameter ACC of the VF S7.

Note: The requirement for the motor to be driven at 1500 min⁻¹, is that the Object 6058H (Maximum/Minimum speed for the inverter at plug-in connector 1) is also correspondingly adjusted.

7 Application of Profibus with TOSHIBA VF S7

7.1 Construction of the Profibus DP Data Transmission

| Word Nr | Meaning |
|---------|---|
| 1 | Control Word and Status Word for the inverter at plug-in connector 0 |
| 2 | Speed –Reference and Actual Value the inverter at plug-in connector 0 |
| 3 | Control Word and Status Word for the inverter at plug-in connector 1 |
| 4 | Speed –Reference and Actual Value the inverter at plug-in connector 1 |
| 5 | Control Word and Status Word for the inverter at plug-in connector 2 |
| 6 | Speed –Reference and Actual Value the inverter at plug-in connector 2 |
| 7 | Control Word and Status Word for the inverter at plug-in connector 3 |
| 8 | Speed –Reference and Actual Value the inverter at plug-in connector 3 |
| 9- 14 | Reading and Writing of parameters of VF S7 (5 Words) |

As on the Profibus-Module up to four Vf S7 series inverters can be connected, there are also four separate Control Words and Status Words as well as four separate reference values and actual values for individual inverters.

Further, it is possible to read and write all the parameters of the connected inverter VF S7, via the words 9 – 14 (Ref. **Fehler! Verweisquelle konnte nicht gefunden werden.** Complete Access to all the variables of)

Construction of the Words 9- 14:

| Word-Nr. | Contents |
|----------|--|
| 9 | High-Value Byte (Byte 1): Plug-in Connector of the VF S7 on the Profibus-Modul and the method of evaluation Lower Half Byte : Address (0-3) Upper Halfbyte: Method of evaluation (0-singular, 8-Cyclical) Low-Value Byte (Byte 2): Order Type "R" = Read Data (52H) "W" = RAM-Write Data (57H) "P" = EEPROM-Write Data (50H) |
| 10 | Object-Number or Parameter-Address in Inverter (see 10 "Address list of the VF S7") |
| 11 - 14 | With Write Command: Data |

All other values are given by the objects defined by each Bus-participants.

7.2 Pre-settings

The Profibus-Module has a pre-setting which is shared over GSD-Data of the Profibus-Master. The adjustment decides 2 communications channels per Bus-participants : Two Sending Words and Two Receiving Words per inverter plug-in connector, as well as five Sending Words and Receiving Words which can be used alternately for all the inverters connected to the Module.

VF S7 – Profibus - Module


Commissioning

7.3 Switching ON

1. Prepare and load the Bus configuration with the help of GSD-Data. The GSD-Data for the Profibus-Modul TOS - VF - PB is supplied on the diskette with Module.
2. For the setting of undervoltage, set correct addresses on the Profibus-Modul with rotary switches 1 and 2. Profibus-Module recognises the transmission rate (max. up to 12 MBit/s) internally.
3. Connect the inverter VF S7 with the Profibus-Module.
4. Supply Auxiliary voltage to the Profibus-Module.
5. Start the Profibus.
6. With the connection, VF S7 automatically monitors it's communication to the Profibus-Module. Start of a motor is only possible when the Statusdrive can run . (ref. **Fehler! Verweisquelle konnte nicht gefunden werden.** "Statusdrive").
7. Set parameters for the inverter as per the application (Pole-pairs, maximum and minimum Speed, Limit Values as well as negative and positive Acceleration).
8. Start the inverter as per the application.
Hint: All the settings in the Profibus-Module are stored only in the RAM of the module.
9. Reset the faults on the inverter basically over the Profibus.

7.4 Hints for Commissioning / Operation

Warning!



Always have the 24 V supply for the Profibus-Module.

By not having this voltage on the Profibus-Module while starting of the inverter, the terminals of the inverter are enabled as per the circuit connection of digital / analogue inputs and the motor can start running.

If the 24 V voltage is interrupted, the inverter goes in to control stop mode with Fault annunciation "ErrS".

Tip!



If processing of a fault is set by the Master, The Profibus-Module ensures that, with interruption of the buses, the inverter goes into controlled stop mode with fault „ ErrS“. For re-starting, this fault must be be reset over Profibus.

Tip!



Faults should be reset over the Bus. Nevertheless, it is possible to reset a fault also by switching off and on the power supply of the inverter. In this case it is ensured further, that the starting of the inverter can take place only over the Profibus.

Tip!



The Profibus-Modul ensures that with the connection of an VF S7 inverter with the Profibus-Module Bus connection is established automatically. The inverter announces the status word "Remote" (Bit 9 = 1).

Tip!



The Profibus-Module ensures that the inverter VF S7 does not start running by itself immediately after the connection to the Profibus-Module. The Local operation via the terminal strip is blocked and it is enabled only when the Statusdrive runs up to the state „Operation Enabled“ and the Bits 14 and 15 are reset in the respective control words.

Tip!



The connection between the Profibus-Module and one or more inverters can be broken without any effect for the Profibus-Module or for the remaining inverters. In Status Word of the affected inverter, the annunciation „Remote“ (Bit 9) is set to 0 and the inverter goes into control stop mode with fault „ErrS“.

Tip!



Write and Read commands of an inverter that is not connected, does not influence the functions of the other connected inverters. In this case, response <N> (Communication Failure) results.

Caution!



The inverter is set for control over the Profibus. With this, the motor runs up when via the Profibus-Module the status “Operation Enabled” is reached in the Statusdrive, a Run-command is given at the terminal strip, the inverter is programmed for the terminal strip operation and the reference value is given over the Profibus. For the Run-command to be from the Profibus, it can be set in Profibus-Control Word of the inverter.

Tip!



All Parameters of the VF S7 can be displayed on the integrated operator terminal.

The display of a parameter on the integrated slave terminal of VF S7 is not automatically refreshed with the changes. To actualise the display, keep switching between the double-push on the DATA-button on the display of the parameter code and renewed numerical value.

Tip!



If nothing else is adjusted, all adjustments and settings are stored in the RAM of the inverter.

Many SPS- und PC- control systems exchange a series of High-Bytes and Low-Bytes during Word Transfer command. In such cases, High and Low Bytes can be exchanged, which should be kept in mind during programming.

7.5 Incompatibility of Functions

The following functions cannot be configured simultaneously. By losing the compatibility, the inverter sends back the fault message described in chapter 8 ("Complete Access of all Variables of")

| | Summing Reference-Value | PI-Control | JOG | Frequency Selection |
|-------------------------|-------------------------|------------|-----|---------------------|
| Summing Reference-Value | | ● | | |
| PI-Control | ● | | ● | ● |
| JOG | | ● | | |
| Frequency Selection | | ● | | |

●: Incompatible Functions

VF S7 - ProfiBus-Module

8 Complete Access To All Variables of TOSHIBA VF S7


To supplement the aforesaid description of Profibus-Objects on all variables and parameters of the inverter for access, Read and Write instructions can be undertaken over the words 9 –14 of the Profibus Telegram. Thus, the Profibus-Module takes over the control and standard data and reduces the required Data Protocol to it's basic utility data. This is possible by setting of Bits in the control word as per manufacturer's specification.

Command Type, COM

| COM [1 Byte] | DATA [1~4 Bytes] (Hexadecimal Range) |
|--|--------------------------------------|
| Command/ Hex/ Binary Value Meaning | |
| <R>:(52H) / 0101 0010: Command Type –Read Data | No Data |
| <W>:(57H) / 0101 0111: Command Type RAM –Write Data | Write Data (0H - FFFFH) |
| <P>:(50H)/ 0101 0000: Command Type EEPROM- Write Data | Write Data (0H - FFFFH) |

General Example:

Warning!



With the setting of the Bit 15 in Word 9, transition between singular and cyclical Information takes place. A combination of cyclical Write operation with with EEPROM-Write –Data is not recommended and can lead to destruction of EEPROM as a result of violation of the permissible Write cycles.

Tip!



In the following examples, examples are mentioned such as to how to access the extended functions in VF S7 via Words 9 – 14.: For this, in Byte 1 of Word 9, connection point of the respective VF S7 on the Profibus Module must be given, otherwise the Profibus-Module always accesses the 0 connection point.

Tip!



The response of the FU via the Profibus-Module with this form of instructions (over internal FU-Addresses) is maximum 1 Word (2 Bytes) long. The normal Receiver-DATA_Words (Words 12-14) are not over-written and hence can still have Data contents of the previous instructions.

General Example:

Defined Message from Profibus Receiver, singular (write command: "P" or "W")

| Byte 1 | Byte 2 | Byte 3 | Byte 4 | Byte 5 | Byte 6 |
|-------------------|---------|-------------------------|--------|-------------------------|--------|
| VF S7 - Nr. | COM | Logic address | | Data | |
| 0 00000 x x | xxxxxxx | xxxxxxxxxxxxxxxxxxx | | xxxxxxxxxxxxxxxxxxx | |
| 00H for Nr. 0 | "W" | 16 Bit binary | | 16 Bit binary | |
| 01H for Nr. 1 | "P" | 0000H - FFFFH | | 0000H - FFFFH | |
| 02H for Nr. 2 | | Byte 4:MSB, Byte 3: LSB | | Byte 6:MSB, Byte 5: LSB | |
| 03H for Nr. 3 | | | | | |

VF S7 – Profibus - Module

Defined Message from Profibus Receiver, cyclical (write command: "P" or "W")

| Byte 1 | Byte 2 | Byte 3 | Byte 4 | Byte 5 | Byte 6 |
|---|------------------------------|--|--------|---|--------|
| VF S7 - Nr. 1 0000 x x 80H for Nr. 0 81H for Nr. 1 82H for Nr. 2 83H for Nr. 3 | COM xxxxxxx "W" "P" | Logic address xxxxxxxxxxxxxxxxxx 16 Bit binary 0000H - FFFFH Byte 4:MSB, Byte 3: LSB | | Data xxxxxxxxxxxxxxxxxx 16 Bit binary 0000H - FFFFH Byte 6:MSB, Byte 5: LSB | |

Defined Message from Profibus Receiver, singular (Read Command: "R")

7 0 7 0 7 0

| Byte 1 | Byte 2 | Byte 3 | Byte 4 |
|---|-----------------------|---|--------|
| VF S7 - Nr. 0 0000 x x 00H for Nr. 0 01H for Nr. 1 02H for Nr. 2 03H for Nr. 3 | COM xxxxxxx "R" | Address xxxxxxxxxxxxxxxxxx 16 Bit binary 0000H - FFFFH Byte 4: MSB, Byte 3: LSB | |

Defined Message from Profibus Receiver, cyclical (Read Command: "R")

7 0 7 0 7 0

| Byte 1 | Byte 2 | Byte 3 | Byte 4 |
|---|-----------------------|---|--------|
| VF S7 - Nr. 1 0000 x x 80H for Nr. 0 81H for Nr. 1 82H for Nr. 2 83H for Nr. 3 | COM xxxxxxx "R" | Address xxxxxxxxxxxxxxxxxx 16 Bit binary 0000H - FFFFH Byte 4: MSB, Byte 3: LSB | |

Response on Write/ Read Commands

Defined Message on the Profibus singular sending

Normal Answer

7 0 7 0 7 0

| Byte 1 | Byte 2 | Byte 3 | Byte 4 | Byte 5 | Byte 6 |
|---|--|---|--------|--|--------|
| VF S7 - Nr. 0 0000 x x 00H for Nr. 0 01H for Nr. 1 02H for Nr. 2 03H for Nr. 3 | COM xxxxxxx "R" or "r" "W" or "w" "P" or "p" | Logic address xxxxxxxxxxxxxxxxxx 16 Bit binary 0000H - FFFFH Byte 3: MSB, Byte 4: LSB | | Data xxxxxxxxxxxxxxxxxx 16 Bit binary 0000H - FFFFH Byte 5: MSB, Byte 6: LSB | |

VF S7 - ProfiBus-Module

Defined Message on the Profibus cyclical sending

Normal Answer

7 0 7 0 7 0

| Byte 1 | Byte 2 | Byte 3 | Byte 4 | Byte 5 | Byte 6 |
|-------------------|------------|--------------------------|--------|--------------------------|--------|
| VF S7 - Nr. | COM | Logic address | | Data | |
| 1 00000 x x | xxxxxxx | xxxxxxxxxxxxxxxx | | xxxxxxxxxxxxxxxx | |
| 80H for Nr. 0 | "R" or "r" | 16 Bit binary | | 16 Bit binary | |
| 81H for Nr. 1 | "W" or "w" | 0000H - FFFFH | | 0000H - FFFFH | |
| 82H for Nr. 2 | "P" or "p" | Byte 3: MSB, Byte 4: LSB | | Byte 5: MSB, Byte 6: LSB | |
| 83H for Nr. 3 | | | | | |

Answer on a false Message Cyclical :

7 0 7 0 7 0

| Byte 1 | Byte 2 | Byte 3 | Byte 4 |
|-------------------|------------|--------------------------|--------|
| VF S7 - Nr. | COM | Address | |
| 1 00000 x x | xxxxxxx | xxxxxxxxxxxxxxxx | |
| 80H for Nr. 0 | "N" or "n" | 16 Bit binary | |
| 81H for Nr. 1 | | 0000H - FFFFH | |
| 82H for Nr. 2 | | Byte 3: MSB, Byte 4: LSB | |
| 83H for Nr. 3 | | | |

8.1 Status Annunciation COM

| COM [1 Byte] | DATA | | |
|--|-------|--------------|--------------|
| | Hex | Binary value | Data Range |
| <N>: Communication Fault Inverter Status Readable, Inverter is not in the Fault Status (e.g. Very high value is given) | (4EH) | 0100 1110 | |
| <n>: Communication Fault Inverter Status Readable, Inverter is in the Fault Status | (6EH) | 0110 1110 | |
| <P>: EEPROM-Data writing successful | (50H) | 0101 0000 | |
| <p>: EEPROM-Data writing not possible | (70H) | 0111 0000 | |
| <R>: Data reading successful | (52H) | 0101 0010 | (0H - FFFFH) |
| <r>: Data reading not possible | (72H) | 0111 0010 | |
| <W>: RAM - Data writing successful | (57H) | 0101 0111 | (0H - FFFFH) |
| <w>: RAM- Data writing not possible | (77H) | 0111 0111 | |

8.2 Examples

8.2.1 Read Command on inverter TOSHIBA VF S7 ("R")

For making up the examples, the Addresses and the Valuations of the variables of the address list of the VF S7 inverters are used as basis. Byte 1 is the higher value Byte of Word 9, Byte 2 the lower value and so on.

DC Link Voltage of the inverter at the connection point 3 cyclically reads out as:

7 0 7 0 7 0

| Byte 1 | Byte 2 | Byte 3 | Byte 4 |
|------------------|------------|---------------------|--------|
| VF S7 - Nr. 3 | COM "R" | Address | |
| 1 0000 1 1 | 0101 0010x | 1111 1110 0000 0100 | |
| 83H | 52H | FE04H | |

Ramp-up time of the inverter at connection point 2 singularly reads out as:

7 0 7 0 7 0

| Byte 1 | Byte 2 | Byte 3 | Byte 4 |
|------------------|------------|---------------------|--------|
| VF S7 - Nr. 2 | COM "R" | Address | |
| 0 0000 1 0 | 0101 0010x | 0000 0000 0000 1001 | |
| 02H | 52H | 0009H | |

8.2.2 Writing in RAM Memory of the inverter TOSHIBA VF S7 ("W")

Tip!



In order to accept the given reference value over the Profibus with words 9 – 14, the Bit 15 of the Profibus Control words must be set.

30 Hz Reference Value for the inverter at connection point 1 singular sending

7 0 7 0 7 0 7 0

| Byte 1 | Byte 2 | Byte 3 | Byte 4 | Byte 5 | Byte 6 |
|------------------|-----------|---------------------|--------|---------------------|--------|
| VF S7 - Nr. 1 | COM "W" | Adresse | | Daten | |
| 0 0000 0 1 | 0101 0111 | 1111 1010 0000 0001 | | 30Hz/ 0,01= 3000 | |
| 01H | 57H | FA01H | | 0000 1011 1011 1000 | |
| | | | | 0BB8H | |

50 s Ramp-up Time for the inverter at connection point 1 singular sending.

7 0 7 0 7 0 7 0

| Byte 1 | Byte 2 | Byte 3 | Byte 4 | Byte 5 | Byte 6 |
|------------------|-----------|---------------------|--------|---------------------|--------|
| VF S7 - Nr. 1 | COM "W" | Address | | Data | |
| 0 0000 0 1 | 0101 0111 | 0000 0000 0000 1001 | | 50s / 0,1= 500 | |
| 01H | 57H | 0009H | | 0000 0001 1111 0100 | |
| | | | | 01F4H | |

8.2.3 Reception From Inverter, Communication OK ("R")

Motor-Actual Frequency (30 Hz) from inverter at connection point 2 cyclically reads out as:

7 0 7 0 7 0 7 0

| Byte 1 | Byte 2 | Byte 3 | Byte 4 | Byte 5 | Byte 6 |
|-------------------|-----------|---------------------|--------|---------------------|--------|
| VF S7 - Nr. 2 | COM "R" | Address | | Data | |
| 1 00000 1 0 | 0101 0010 | 1111 1110 0000 0000 | | 3000 x 0,01= 30s | |
| 82H | 52H | FE00H | | 0000 1011 1011 1000 | |
| | | | | 0BB8H | |

8.2.4 Reception From Inverter, Faulty Communication ("N")

Response to given Reference Value at inverter 2 , Reference Value above that of UL

7 0 7 0 7 0


| Byte 1 | Byte 2 | Byte 3 | Byte 4 |
|------------------|------------|---------------------|--------|
| VF S7 - Nr. 2 | COM "N" | Address | |
| 1 0000 1 0 | 0101 0010x | 1111 1010 0000 0001 | |
| 82H | 4EH | FA01H | |

8.2.5 Configuration of the VF S7 with the Profibus-Module

The time monitoring of VF S7 is switched off at the factory. (VF S7 Parameter 0803H). In order to switch off the drive under broken connection to the Profibus-Module, set a value of >0 on this parameter.

If the operator of the drive prefers not to switch off in such cases, one of the measures for him is to set the Parameter 0803H on 0 so as to switch off the time monitoring.

Warning!



If the Time monitoring – so called Watchdog- of the inverter remains switched off, there exists the danger of undesirable start of the motors connected to the inverter.

Tip!



The transmission rate adjusted in the inverter must remain at 9600 Bit/s so that the Profibus-Module can establish the communication with the inverter

When the Profibus-Module receives no answer from the drive, the Profibus-Module sends back the Code 18H ("errS") to the Master, if the user defined query is a Read Command at the address FC90H (Fault Register). After more unsuccessful Read attempts between the Profibus-Module and the Vf S7, the Profibus-Module sets the VF S7 in „Start Block“ status in order to avoid automatic new Start of the Vf S7 inverter if communications connections is re-established.

9 List of Addresses of TOSHIBA VF S7

9.1 Headings in the Parameter list

| | |
|------------------------------|--|
| <i>Address HEX</i> | The four-tier number for the identification of the parameters is given as Hexadecimal values. In the binary mode, the Address is sent in the form of 2 Bytes with the higher valued Byte first and the lower valued Byte at the end, whereby the given Hexadecimal values are converted in Binary values. |
| <i>Display FU</i> | The sign that comes on the 7-segment LED display of the VF S7 Inverter. |
| <i>Parameter Description</i> | Description of the parameters |
| <i>Range of Adjustments</i> | Maximum and Minimum values permissible from VF-S7. Division by the multiplier gives the Word value to be sent |
| <i>Resolution</i> | Scale factor with unit. Multiplication with the raw data gives the actual value. After division of the actual values by the scale factor results the corresponding raw data. Some parameters are not scaled. One can select from many setting possibilities. |
| <i>Access</i> | <u>Read</u> -Parameter can only be read. <u>Stop</u> - Parameter can be written only with VF S7 in Stop mode (= Motor at stand-still) Always-Parameter can be read and written at any time. |

9.2 Parameter list

The parameter set of the S7 frequency converter consists of in all 91 different parameters which are theme-wise bound together in the 9 parameter groups and a user-parameter group. The dial-up and the changing of the parameters in general is described in chapter 6 .

In the following, various parameter groups are introduced and explained.

| | |
|---|---|
| BASIC PARAMETER #1: | This group contains all the parameters which are important for the basic settings of an inverter. (e.g. . Ramp settings, Method of control, electrical data of supply and motor). |
| TERMINAL FUNCTIONS: (Parameter F100 to F132) | In this group, the input and the output terminals can be programmed individually. |
| FREQUENCY PARAMETER: (Parameter F200 to F294) | This group contains the parameters for setting reference value and characteristics of the inverters in special situations. (e.g. DC Braking, Jump Frequency) |
| SPECIAL FUNCTIONS: (Parameter F300 to F363) | Parameters that decide the characteristics of the inverter in fault conditions, internal adjustments (carrier frequency) and auxiliary circuit for the inverters (Braking Resistance) . |
| MOTOR PARAMETES: (Parameter F400 to F405) | The parameters of this group are self-set by the so called Auto-tuning-run of the inverter and contain information on the connected motor and the drive. As a rule, these parameters should not be changed. |

BASIC PARAMETER #2:
(Parameter F500 to F505)

The parameters of this group offer second Ramp-up and ramp-down. Besides, further settings for ramp-up and Ramp-down are selectable.

PROTECTIVE FUNCTIONS:
(Parameter F600 to F618)

This group, protective functions such as emergency stop, Overload, and fault processing are set.

DISPLAY PARAMETERS
(Parameter F700 to F702)

These parameters decide the display of Current, Voltage, frequency , or frequency proportional values.

COMMUNICATION:
(Parameter F800 to F803)

In this parameter group, the settings for the integral interface are contained (e.g.. Baud rate, Parity).

USER PARAMETER:
(Gruppe Gr.U)

This group contains all the parameters which deviate from the factory settings. With this, finding of the modified parameters is quick and uncomplicated.

9.2.1 Standard parameters

On the basis of this parameter list it is explained how over the Profibus the parameters can be accessed.

For each parameter following information is given:

- Adresse, to be given in the message on the VF S7,
- Parameter display on the operator panel,
- Upper and Lower limit values,
- Internal scale factor (Multiplier) or List of the available options.
- Method of accessing each parameter.

For the parameters with the internal scale factors, the data in the transmitted message is scaled with the multiplication factor.

Example:

Setting of the Ramp-up (ACC) at 415,8 Sec. The scale factor of ACC parameter is 0,1 Sec.

The Data value in the message sent is $415,8 / 0,1 = 4158 = 103EH$.

VF S7 – Profibus - Module

| Address HEX | Display FU | Parameter description | Setting Range | Resolution | Access |
|----------------|---------------|---|---|------------|---------|
| 0000 | AU1 | Setting of the Ramp-up and ramp-down | 0: manual 1: automatic | - | always |
| 0001 | AU2 | Selection of the Method of Operation / Torque Control of the inverter At the dial-up, the parameter always remains on the setting of 0 | 0: Manual Setting 1: automatic voltage boost (corresp. Pt = 2) 2: Vector Control (SLV) (corresp. Pt = 3) 3: SLV with Auto-Tuning (corresp. F400 = 2 and Pt = 3) | - | In Stop |
| 0002 | AU3 | Setting of Operational Characteristics This parameter changes at values of 1 or 2 the following parameter contents: type Setting of Motor rated Frequency FH, UL, uL, F204, F213 (s. page 7.7) F301 Activation of Motor Capture function F302 Ride-over of supply failure. F307 Output Voltage compensation On F502 Ramp-up-/Braking form | 0: Manual Setting 1: type = 1 (50Hz) F301 = 1 F302 = 1 F307 = 1 F502 = 1 2: type = 2 (60Hz) F301 = 1 F302 = 1 F307 = 1 F502 = 1 | - | In Stop |
| 0003 | CMOD | Command over | 0: terminal Block 1: Push Buttons | - | Always |
| 0004 | FMOD | Frequency Set-point over | 0: terminal Block 1: Push Buttons 2: Potentiometer Button | - | Always |
| 0005 | FMSL | Finalising the magnitude for the FM Terminal | 0: Output Frequency 1: Output Current 2**: Freq. Set-point at FM, Level adjustable with arrow button , offline, 3**: FU-rated Current at FM, Level adjustable offline, | - | Always |
| 0006 | FM | Calibration function for the FM-Terminal: With connected measuring equipment this can be equalized Online to the selected value under parameter FMSL. | (see Section 7.3.3) | - | Always |
| 0007 | typ | Selection of the Basic Setting FH, uL, UL, F204, F213 (See Page 7-7) | 1: 50Hz-setting 2: 60Hz- setting 3: Factory setting (Caution: With Factory setting FH, UL, F204, F213 on <u>80 Hz</u> and uL on <u>60 Hz</u> set). | - | In Stop |
| 0008 | Fr | Selection of the Direction | 0: Forward 1: backward | - | Always |
| 0009 | ACC | Ramp-up time #1 The ramp-up time is measured from the standstill up to the maximum frequency FH run up. | 0,1s ... 3600s | 0,1s | Always |
| 0010 | DEC | Ramp-down Time #1 The ramp-down time is measured for deceleration from Maximum frequency FH up to still stand | 0,1s ... 3600s | 0,1s | Always |
| 0011 | FH | Maximum Output Frequency | 30,0Hz ... 320,0Hz | 0,1Hz | In Stop |
| 0012 | UL | Upper Frequency Limit | 0,5Hz ... FH | 0,1Hz | Always |

** above Version 121

VF S7 - ProfiBus-Module

| Address HEX | Display FU | Parameter description | Setting Range | Resolution | Access |
|----------------|---------------|---|--|------------|----------|
| 0013 | LL | Lower Frequency Limit | 0,0Hz ... UL | 0,1Hz | Always |
| 0014 | uL | Base Frequency At this frequency the full output voltage is reached. (= Rated freq. Of the connected motor) | 25,0Hz ... 320,0Hz | 0,1Hz | Always |
| 0015 | Pt | V/f-curve selection | 0: Linear V/f- Characteristics (Constant Torque) 1: quadratic V/f- Characteristics (variable torque) 2: Automatic Voltage Boost 3: Vector control 4: Automatic Voltage Boost With energy saving function* (ECN- Mode) | - | Bei Halt |
| 0016 | ub | Value at „Voltage Boost“, only correct when under Pt a value of 0 or 1 is given | 0,0% ... 30,0% | 0,1% | Always |
| 0017 | OLM | Finalization about the connected motor | <u>Self-cooled Motors:</u> 0: Motor Monitoring active, no „Soft-Stall“- control 1: Motor Monitoring active, „Soft-Stall“- control active 2: No Motor Monitoring active, no „Soft-Stall“- control 3: No Motor Monitoring active, „Soft-Stall“- control active <u>Force-cooled Motor:</u> 4: Motor Monitoring active, no „Soft-Stall“- control 5: Motor Monitoring active, „Soft-Stall“- control active 6: No Motor Monitoring active, no „Soft-Stall“- control 7: No Motor Monitoring active, „Soft-Stall“- control active | - | Always |
| 0018 | Sr1 | Fixed Frequency Nr. 1 | LL ... UL | 0,1Hz | Always |
| 0019 | Sr2 | Fixed Frequency Nr 2 | LL ... UL | 0,1Hz | Always |
| 0020 | Sr3 | Fixed Frequency Nr. 3 | LL ... UL | 0,1Hz | Always |
| 0021 | Sr4 | Fixed Frequency Nr. 4 | LL ... UL | 0,1Hz | Always |
| 0022 | Sr5 | Fixed Frequency Nr. 5 | LL ... UL | 0,1Hz | Always |
| 0023 | Sr6 | Fixed Frequency Nr. 6 | LL ... UL | 0,1Hz | Always |
| 0024 | Sr7 | Fixed Frequency Nr. 7 | LL ... UL | 0,1Hz | Always |

9.2.2 Extended Parameters

The parameters *0800H* and *0801H* can be written any time, but the modified values are accepted only after the initialisation (after the switch-on).

| Address HEX | Display FU | Parameter description | Setting Range | Resolution | Access |
|----------------|---------------|--|---|------------|--------|
| 0100 | F100 | Above this Output freq. „SPEED REACH“ is annunciated on the output terminal. | 0,0Hz ... UL | 0,1Hz | Always |
| 0101 | F101 | Combined with the Parameter F102 this middle freq. builds the freq. Range for the annunciation at the output terminal. | 0,0Hz ... UL | 0,1Hz | Always |
| 0102 | F102 | Freq. Deviation around the Parameter F101. Within this freq. range a signal appears at the corresponding output terminal. | 0,0Hz ... UL | 0,1Hz | Always |
| 0103 | F103 | Signal selection for the ST-Function (The ST-Function can be programmed at one of the input terminals . See also Parameter F110 to F115) If the reference value Enable is explicitly programmed (F103 = 0), one of the digital input terminals must be set for ST-Function. | 0: Reference Value Enable with connection ST-P24 1: Reference Value Enable Continuously active 2: Tie up with Directional input (Function F or R) | - | Always |
| 0104 | F104 | Signal selection for the RST-Function (The RST-Function can be programmed at one of the input terminals . See also Parameter F113.) | 0: Fault Reset („RESET“) with connection RST- P24 1: Fault Reset („RESET“) by opening the connection RST- P24 | - | Always |
| 0110 | F110 | Determination of a function which is continuously set as active. (Example: Often an explicit reference value is not necessary. In this case this parameter can be set, for example, at 1 in order to hold the reference value enabling continuously active. | (See table below) | 0 ... 37 | Always |
| 0111 | F111 | Fixing of function for input terminal F | (See table below) | 0 ... 37 | Always |
| 0112 | F112 | Fixing of function for input terminal R | (See table below) | 0 ... 37 | Always |
| 0113 | F113 | Fixing of function for input terminal RST | (See table below) | 0 ... 37 | Always |
| 0114 | F114 | Fixing of function for input terminal S1 | (See table below) | 0 ... 37 | Always |
| 0115 | F115 | Fixing of function for input terminal S2 | (See table below) | 0 ... 37 | Always |

VF S7 - ProfiBus-Module

Option Selection for the Parameter F110 to F115 :

| Value | Function | Value | Functional Combination |
|-------|--|-------|---|
| 0 | No Function | 23 | R + S1 |
| 1 | Reference Value Enable (ST) | 24 | F + S2 |
| 2 | Forward Run (F) | 25 | R + S2 |
| 3 | Reverse Run (R) | 26 | F + S3 |
| 4 | Intermittant Operation(JOG) | 27 | R + S3 |
| 5 | Switching to Ramp-up and Ramp-down # 2 (AD2) | 28 | F + S4 |
| | | 29 | R + S4 |
| 6 | Fixed Frequency Selection (S1) | 30 | F + AD2 + S1 |
| 7 | Fixed Frequency Selection (S2) | 31 | R + AD2 + S1 |
| 8 | Fixed Frequency Selection (S3) | 32 | F + AD2 + S2 |
| 9 | Fixed Frequency Selection (S4) | 33 | R + AD2 + S2 |
| 10 | Fault Reset (RST) | 34 | F + AD2 + S3 |
| 11 | Emergency Stop / External Fault (EMG) | 35 | R + AD2 + S3 |
| 12 | Switching between Push Buttons and Terminal control (PNL/TB) | 36 | F + AD2 + S4 |
| | | 37 | R + AD2 + S4 |
| 13 | DC Braking allowed /Blocked (DB) | 38** | It switches from VIA / II to VIB Caution: F200 must stay on „2“. |
| 14 | PI – Control out of action | | |
| 15 | Parameter changes allowed (PWREN) (For this earlier in F700 a „1“ (= Ssoftware Block) must be programmed | 39** | Motor Overload Characteristics #2 and Boost #2 |
| | | 40** | (programmed in F173, F172) effective. Motor Overload Characteristics #2 and Boost #2(programmiert in F173, F172) + AD2 |
| 16 | ST + RST | | |
| 17 | ST + PNL/TB | | |
| 18 | F + JOG | | |
| 19 | R + JOG | 41** | Motorised Potentiometer run up to FH |
| 20 | F + AD2 AD2=Acc/Dec. on #2 | 42** | Motorised Potentiometer run down to LL |
| 21 | R + AD2 Values for AD2 are set in | 43** | Motorised Potentiometer quickstop till LL |
| 22 | F + S1 F500, F501 | 44** | Motorised Potentiometer quickstart and Reset (Reset is effective only in fault condition, the quick stop is not active in fault case. |

**only after V.121

| Address HEX | Display FU | Parameter description | Setting Range | Resolution | Access |
|-------------|------------|---|-------------------|------------|--------|
| 0130 | F130 | Fixing of function for Output terminal OUT1 The output is switched through when the selected setting from the table below is encountered (see the chapter 3.3.2 also) | (See table below) | - | Always |
| 0131 | F131 | Fixing of function for Output terminal OUT2 The output is switched through when the selected setting from the table below is encountered (see the chapter 3.3.2 also) | (See table below) | - | Always |
| 0132 | F132 | Fixing of function for Output – Relay FLA, FLB, FLC The output is switched through when either a fault occurs or the selected setting from the table below is encountered (see the chapter 3.3.2 also) | (See table below) | - | Always |

VF S7 – Profibus - Module

Option Selection for the Parameter F130, F131 and F132 :

| Value | Function |
|-------|--|
| 0 | By reaching / exceeding the Lower Frequency Limit LL |
| 1 | By Output frequency under the Lower Frequency Limit LL (Function 0 inverted) |
| 2 | By reaching the Upper Frequency Limit UL |
| 3 | By Output frequency under the Upper Frequency Limit UL (Function 2 inverted) |
| 4 | By exceeding a Frequency Limit (see Parameter F100) |
| 5 | By remaining lower than a Frequency Limit (see Parameter F100 , Function 4 inverted) |
| 6 | By completing a ramp-up or Ramp-down process (Other than reaching 0 Hz) |
| 7 | During a ramp-up or Ramp-down process and at stand-still (Function 6 inverted), depending on Parameter F102 |
| 8 | By reaching a frequency range (see Parameter F101 and F102) |
| 9 | When the output frequency lies outside the range determined by Parameter F101 and F102 (Function 8 inverted) |
| 10** | Signal in case of Fault |
| 11** | Signal, when no Fault occurs (Function 10 inverted). |
| 12** | Signal at exceeding the over current limit (see F616 and F618) |
| 13** | Signal, when no overcurrent is detected (Function 12 inverted). |

**Only above V.121

All the terminals (F130, F131, F132) can be parametered with the same functional value.

| Address HEX | Display FU | Parameter description | Setting Range | Resolution | Access |
|-------------|------------|---|----------------|------------|--------|
| 0172 | F172** | Manual Voltage Boost #2 | 0.0 ... 25.0 | 0.1% | Always |
| 0173 | F173** | Characteristics Motor Load for FU – Rated Load #2 | 10 ... 100 (%) | 1 % | Always |

** Only above V.121

| Address HEX | Display FU | Parameter description | Setting Range | Resolution | Access |
|-------------|------------|--|---|------------|--------|
| 0200 | F200 | Priority Arrangement for the individual reference value inputs. | 0: VIA / II 1: VIB 2**: Selection for digital Input terminals between VIA / II and VIB 3**: Motorised Potentiometer 4**: Motorised Potentiometer with the memory of the last reference value. After the power supply interruption, this last reference value is actual. | - | Always |
| 0201 | F201 | VIA- or. II-Input: Reference Value #1 | 0 ... 100% | 1% | Always |
| 0202 | F202 | VIA- or. II-Input: Reference Frequency #1 assigned to Reference Value #1 (Parameter F201) | 0,0Hz ... 320,0Hz | 0,1Hz | Always |
| 0203 | F203 | VIA- or. II-Input: Reference Value #2 | 0 ... 100% | 1% | Always |
| 0204 | F204 | VIA- or. II-Input: Reference Frequency #2 assigned to Reference Value #2 (Parameter F203) | 0,0Hz ... 320,0Hz | 0,1Hz | Always |

VF S7 - ProfiBus-Module

| | | | | | |
|-------------|------|--|--|----------------|------------------|
| 0210 | F210 | VIB- Reference Value #1 at F200 = 0, 1, 2 **Motorised Potentiometer Reaction Time for ramp-up at F200 = 3, 4 | 0 ... 100% 0 ... 100s (1=0,1s) | 1% 1=0,1s | Always |
| 0211 | F211 | VIB- Reference Freq. #1 at F200 = 0, 1, 2 **Motorised Pot. Step width for Ramp-up at F200 = 3, 4 | 0,0Hz ... 320,0Hz 0,0Hz ... 320,0Hz | 0,1Hz 0,1Hz | Always Always |
| 0212 | F212 | VIB- Reference Value #2 at F200 = 0, 1, 2 ** Motorised Potentiometer Reaction Time for ramp-down at F200 = 3, 4 | 0 ... 100% 0 ... 100s (1=0,1s) | 1% 1=0,1s | Always Always |
| 0213 | F213 | VIB - - Reference Frequency #2 bei F200 = 0, 1, 2 ** Motorised Pot. Step width for Ramp-down at F200 = 3, 4 | 0,0Hz ... 320,0Hz 0,0Hz ... 320,0Hz | 0,1Hz 0,1Hz | Always Always |
| 0240 | F240 | Start frequency: In contrast to the lower limit frequency (Parameter LL), by application of Start Freq. , <u>immediately</u> this frequency is output, whereby during the acceleration up to the lower frequency limit, all the lower frequencies within the domain of ramp-up are also output. | 0,5Hz ... 10,0Hz | 0,1Hz | Always |
| 0241 | F241 | Middle Hysteresis Frequency (Parameter F242) | 0,0Hz ... FH | 0,1Hz | Always |
| 0242 | F242 | Half Hysteresis Width : With the parameters F241 und F242, programming of run-up hysteresis is possible. The ramp-up starts with a frequency which is given by the <u>summation</u> of Parameter F241 and F242 , the ramp-down process ends with a frequency given by the <u>difference</u> of the Parameter F241 and F242. This function is especially usefull for heavy run-up applications. | 0,0Hz ... FH | 0,1Hz | Always |
| 0250 | F250 | Frequency limit for DC Braking The DC Braking is sensible applied only at small frequencies. This parameter decides under which frequency limit, the DC Braking will be activated. | 0,0Hz ... FH | 0,1Hz | Always |
| 0251 | F251 | Braking DC Current (Referenced to the value of rated output current) | 0 ... 100% | 1% | Always |

****Only above V.121**

| Address HEX | Display FU | Parameter description | Setting Range | Resolution | Access |
|-------------|------------|---|--|------------|--------|
| 0252 | F252 | DC Braking Time | 0,0s ... 20,0s | 0,1s | Always |
| 0260 | F260 | Frequency in Intermittant Operation („JOG“-Mode) | 0,0Hz ... 20,0Hz | 0,1Hz | Always |
| 0261 | F261 | Method of Braking in Intermittant Operation („JOG“-Modus) | 0: Ramp-down 1: Free Motor Running 2: DC Braking | - | Always |
| 0270 | F270 | Jump Frequency #1 (see Parameter F271) | LL ... UL | 0,1Hz | Always |
| 0271 | F271 | Frequency Range for Jump Frequency #1 Parameter F270 and F271 determine the fading frequency range of (F270 - F271) to (F270 + F271) . | 0,0Hz ... 30,0Hz | 0,1Hz | Always |
| 0272 | F272 | Jump Frequency #2 | LL ... UL | 0,1Hz | Always |
| 0273 | F273 | Frequency Range for Jump Frequency #2 | 0,0Hz ... 30,0Hz | 0,1Hz | Always |
| 0274 | F274 | Jump Frequency #3 | LL ... UL | 0,1Hz | Always |
| 0275 | F275 | Frequency Range for Jump Frequency #3 | 0,0Hz ... 30,0Hz | 0,1Hz | Always |
| 0280 | F280 | Fixed Frequency Nr. 1 (identical to Parameter Sr1)* | LL ... UL | 0,1Hz | Always |
| 0281 | F281 | Fixed Frequency Nr. 2 (identical to Parameter Sr2)* | LL ... UL | 0,1Hz | Always |
| 0282 | F282 | Fixed Frequency Nr. 3 (identical to Parameter Sr3)* | LL ... UL | 0,1Hz | Always |
| 0283 | F283 | Fixed Frequency Nr. 4 (identical to Parameter Sr4)* | LL ... UL | 0,1Hz | Always |
| 0284 | F284 | Fixed Frequency Nr. 5 (identical to Parameter Sr5)* | LL ... UL | 0,1Hz | Always |
| 0285 | F285 | Fixed Frequency Nr. 6 (identical to Parameter Sr6)* | LL ... UL | 0,1Hz | Always |

VF S7 – Profibus - Module

| | | | | | |
|-------------|------|---|-----------|-------|--------|
| 0286 | F286 | Fixed Frequency Nr. 7 (identical to Parameter Sr7)* | LL ... UL | 0,1Hz | Always |
| 0287 | F287 | Fixed Frequency Nr. 8 | LL ... UL | 0,1Hz | Always |
| 0288 | F288 | Fixed Frequency Nr. 9 | LL ... UL | 0,1Hz | Always |
| 0289 | F289 | Fixed Frequency Nr. 10 | LL ... UL | 0,1Hz | Always |
| 0290 | F290 | Fixed Frequency Nr. 11 | LL ... UL | 0,1Hz | Always |
| 0291 | F291 | Fixed Frequency Nr. 12 | LL ... UL | 0,1Hz | Always |
| 0292 | F292 | Fixed Frequency Nr. 13 | LL ... UL | 0,1Hz | Always |
| 0293 | F293 | Fixed Frequency Nr. 14 | LL ... UL | 0,1Hz | Always |
| 0294 | F294 | Fixed Frequency Nr. 15 | LL ... UL | 0,1Hz | Always |

The parameters F280 to F286 are identical to the Parameters Sr1 to Sr7 . A change in one of the parameters results in the similar change in the corresponding parameter.

| Address HEX | Display FU | Parameter description | Setting Range | Resolution | Access |
|----------------|---------------|--|---|------------|---------|
| 0300 | F300 | Carrier Frequency for the Pulse Width Modulation | 2,2kHz ... 12,0kHz | 0,1kHz | Always |
| 0301 | F301 | Motor Capture Function | 0: Switched Off 1: by short time power interruptions 2: By short time Reference Value Block (ST-Signal) 3: Combination from function 1 and 2 | - | Always |
| 0302 | F302 | Characteristics during power supply failure | 0: Operation is interrupted 1: Operation is continued through the feedback energy from the motor circuit. | - | Always |
| 0303 | F303 | Number of Restarts after fault („Trip“) | 0 ... 10 | 1 | Always |
| 0304 | F304 | Connection of an external braking resistance (This is connected to PA und PB terminals of an inverter) | 0:No external braking resistance 1: External braking resistance Exists | - | Always |
| 0305 | F305 | „Soft Stall“-Control for ramp-down This control avoids the fault (Over Voltage), in which, by too high DC link voltage results in dynamic lengthening of ramp-down. | 0: Standard level 1: Switched Off 2**: High level | - | Always |
| 0306 | F306 | Output Voltage Level (maximum output voltage based on Input Voltage value) | 0 ... 120% | 1% | Always |
| 0307 | F307 | Supply Voltage Compensation (Fluctuations of the input voltages are not passed on to the output) | 0: Switched Off 1: Switched On | - | In Stop |
| 0308 | F308 | Thermal Overload Protection for the Braking This parameter determines the permissible switching time for the connected braking resistance. It is calculated from the ratio of Total Cycle Time (= Acceleration Time + Time Constant of the drive + Braking time) to the Braking time. This determines the reciprocal ED- value. Ensure that the connected braking resistance is calculated for the desired braking power. Your TOSHIBA sales representative can help you in the selection of the braking resistance. | 1 ... 255 255 ⇒ 100% 0 ⇒ 0% | 1 | Always |

VF S7 - ProfiBus-Module

| | | | | | |
|-------------|------|--|---|------|--------|
| 0360 | F360 | PI-Control With this parameter, PI-Control can be switched on. For operation with PI-Control, terminals VIA (0 ... 10V DC) or Klemme II (0(4) ... 20mA) serve as inputs for the feedback signal. Parameter F200 then has no function. | 0: Switched Off 1: Operation with PI-Control | - | Always |
| 0362 | F362 | P-Component The P-component has the influence on the reaction time of the controller. | 0,01 ... 100,0 | 0,01 | Always |
| 0363 | F363 | I-Component The I-component ensures that no deviation between the set value and the actual value exists. | 0,01 ... 100,0 | 0,01 | Always |

****Only above V.121**

| Address HEX | Display FU | Parameter description | Setting Range | Resolution | Access |
|----------------|---------------|--|--|------------|---------|
| 0400 | F400 | Automatic setting | 0: No effect 1: Result of the Auto-Tuning-Operation 2: Auto-Tuning-Operation | - | In Stop |
| 0401 | F401 | Motor Constant 1 (Slip) | 0 ... 255 | 1 | Always |
| 0402 | F402 | Motor Constant 2 (Stator Resistance) | 0 ... 255 | 1 | In Stop |
| 0403 | F403 | Motor Constant 3 (Rotor resistance) | 0 ... 255 | 1 | In Stop |
| 0404 | F404 | Motor Constant 4 (Main Inductance) | 0 ... 255 | 1 | In Stop |
| 0405 | F405 | Inertia (Referred to the Motor Shaft) | 0: Small 1: Medium 2: Large 3: Very Large | - | Always |

*** The Motor parameters F402 to F404 are determined from the inverter itself, when it carries out Auto-Tuning mode. For that, please select under the BASIC PARAMETERS #1 the value of 1 or 2 (as per the Motor frequency) for Parameter AU3 and for the Parameter AU2 , a value of 3 or for F400 a value of 2. After each Auto-Tuning run the parameter F400 jumps to the value of 1.**

| Address HEX | Display FU | Parameter description | Setting Range | Resolution | Access |
|----------------|---------------|--|---|------------|--------|
| 0500 | F500 | Ramp-up Time #2 The ramp-up time is referred as acceleration time from stand-still up to the maximum frequency FH | 0,1s ... 3600s | 0,1s | Always |
| 0501 | F501 | Ramp-down Time #2 The ramp-down time is referred as deceleration time from the maximum frequency FH to stand-still. | 0,1s ... 3600s | 0,1s | Always |
| 0502 | F502 | Ramp form for the Acceleration / Deceleration Times #1 | 0: Linear ramp-up (Constant Acceleration) 1: Ramp-up with increasing or decreasing acceleration at the beginning or end (S-Curve) 2: Ramp-up with sinking acceleration at the end (C-Curve) | - | Always |
| 0503 | F503 | Ramp form for the Acceleration / Deceleration Times #2 | (see Par. F502) | - | Always |

VF S7 – Profibus - Module

| | | | | | |
|-------------|------|---|--|-------|--------|
| 0504 | F504 | Selection of ramp-up / ramp-down parameter #1 or #2 | 0: ramp-up / ramp-down parameter #1 1: ramp-up / ramp-down parameter #2 | - | Always |
| 0505 | F505 | Switching Frequency between ramp-up / ramp-down #1 and #2 (The arrangement of the ramp-up / ramp-down times for the corresponding frequency ranges is determined via Parameter F504 or over the Input-terminals with AD2-Function. (see section 7.10). Standard arrangement is ramp-up / ramp-down #1 for the lower freq. Range and ramp-up / ramp-down #2 for the upper freq. Range | 0,0Hz ... UL | 0,1Hz | Always |

| Address HEX | Display FU | Parameter description | | Setting Range | Resolution | Access |
|----------------|---------------|---|--|--|------------|--------|
| 0600 | F600 | Ratio of Motor load to FU – Rated Load | This parameter determines how big the the motor rated current is with respect to the inverters's output current. By correct setting of this parameter, the thermal protection of the | 10% ... 100% | 1% | Always |
| 0601 | F601 | Threshold for the „Soft-Stall“-control Adjustment of the overload ratio of the motor rated current to the inverter rated current, above which the „Soft-Stall“-control is initiated. (see also Parameter OLM, basic parameter #1). | | 10% ... 199% (200% = Switched off) | 1% | Always |
| 0602 | F602 | Fault Mode | | 0: Fault is erased after the switch off of supply voltage 1: Fault is NOT erased after the switch off of supply voltage | - | Always |
| 0603 | F603 | Characteristics on Emergency Stop / External Fault | | 0: Free Run-down 1: Ramp-down 2: DC Braking | - | Always |
| 0604 | F604 | Time span of the Dc braking on Emergency Stop / External Fault | | 0,0s ... 20,0s | 0,1s | Always |
| 0605 | F605 | Monitoring of Output power terminals (Motor cables) for phase failure. | | 0: No Monitoring 1: By first switch on 2: By reference value Enable | - | Always |
| 0616 | F616** | Over current threshold value (Switching of the digital outputs Out 1, Out 2 and the output relay FLA, in case so programmed). | | 10 ... 200 (%) | 0,1% | Always |
| 0618 | F618** | Over current threshold Time (Switching of the digital outputs Out 1, Out 2 and the output relay FLA, in case so programmed). | | 0,0 ... 10 (s) | 0,1% | Always |

**Only above V.121

VF S7 - ProfiBus-Module

| Address HEX | Display FU | Parameter description | Setting Range | Resolution | Access |
|----------------|---------------|---|--|------------|--------|
| 0700 | F700 | Parameter Block With Blocked Parameters, only parameter F700 can be changed. All other parameters are readable but not changeable. | 0: Not Blocked (Parameter CMOD and FMOD not changeable in operation) 1: Blocked 2: Not Blocked (Parameter CMOD and FMOD changeable in operation) | - | Always |
| 0701 | F701 | Display of Current, Voltage and Frequency values. Voltage and current values can be displayed as referenced to rated values (in %) or as Absolute values (in V or A). Anstatt der Frequenz kann eine frequenz-proportionale Größe ausgegeben werden. Ein entsprechender Multiplikator ist unter Parameter F702 festzulegen. | 0: Frequency in [Hz]; Current, Voltage in [%] 1: Frequency in [Hz]; Current, Voltage as Absolute values 2: Frequency-proportional value : Current, Voltage in [%] 3: Frequency-proportional value ; Current, Voltage as Absolute values | 0,1s | Always |
| 0702 | F702 | Multiplier for frequency proportional Display | 0,01 ... 200,0 | 0,01 | Always |

| Address HEX | Display FU | Parameter description | Setting Range | Resolution | Access |
|----------------|---------------|--|--|------------|--------|
| 0800 | F800 | Data Transmission Rate over interface | 0: 1200 baud 1: 2400 baud 2: 4800 baud 3: 9600 baud | - | Always |
| 0801 | F801 | Parity | 0: None 1: Even 2: odd | - | Always |
| 0802 | F802 | Inverter Identification Number Up to 32 inverters can be addressed over the interface. In order to correctly address each inverter, for each unit that is connected to the Bus system, another identification number must be given. | 0 ... 31 | - | Always |
| 0803 | F803 | Time Delay on Communication Fault Time, after which a Fault annunciation is generated in case of communications failure over the interface. | 0 ... 100 | 1 | Always |

VF S7 – Profibus - Module

| Address HEX | Display FU | Parameter description | Setting Range | Resolution | Access |
|----------------|---------------|---|-----------------|------------|--------|
| FA00 | | Command Register | 00000 ... FFFFF | - | Always |
| FA01 | | Freq. –Reference Value Communication | 0,0Hz ... FH | 0.01 Hz | Always |
| FA02 | | Freq. –Reference Value Control Panel | 0,0Hz ... FH | 0.01 Hz | Always |

| Address HEX | Display FU | Parameter description | Setting Range | Resolution | Access |
|----------------|---------------|-----------------------|---------------|------------|--------|
| FC90 | | Aktueller Fehler | - | - | Read |

| Address HEX | Display FU | Parameter description | Setting Range | Resolution | Access |
|----------------|---------------|-------------------------------------|---------------|------------|--------|
| FD00 | | Freq. Actual Value | - | 0,01 Hz | Read |
| FE00 | | Freq. Actual Value – Fault Register | - | 0,01 Hz | Read |
| FE01 | | Status word (see 10.2.3 Tabel 2) | - | - | Read |
| FE02 | | Freq. –Reference Value | - | 0,01 Hz | Read |
| FE03 | | Motor Current | - | 0,01 % | Read |
| FE04 | | Input Voltage | - | 0,01 % | Read |
| FE05 | | Output Voltage | - | 0,01 % | Read |
| FE06 | | Status of the Digital Inputs | - | - | Read |
| FE07 | | Status of the Digital Outputs | - | - | Read |
| FE08 | | CPU – Version | - | - | Read |
| FE09 | | EEPROM – Version | - | - | Read |
| FE10 | | Fault Memory 1 | - | - | Read |
| FE11 | | Fault Memory 2 | - | - | Read |
| FE12 | | Fault Memory 3 | - | - | Read |
| FE13 | | Fault Memory 4 | - | - | Read |
| FE14 | | Operation Time | - | 0,01 / h | Read |

Hint :

The Parameters 0800H, 0801H, 0802H and 0803H remain untouched by the resetting of the adjustments. Changes in the settings of the transmission rate and parity of the serial interface are taken into account only after fresh initialization of the VF S7 (Switch off and re-Switch-on of the power supply of VF S7). Modify these parameters only when it is absolutely necessary.

After a fault condition, control allows read out of the fault code, responsible for switch of , from the Fault register of the inverter (FE10H - FE13H) . (the already stored „ Old-Fault Codes“ are pushed over by „ New- faults“ successively from FE10H nach FE13H.

VF S7 - ProfiBus-Module

9.2.3 Description of the Communication Commands and Status Parameters

9.2.4 Table 1: (FA00H) Bit-Structure of Command Words

| Bit | Funktion | 0 | 1 |
|-----|--|-----------|----------------|
| 15 | Command Word Valid (FA00H) ¹ | Invalid | Valid |
| 14 | Freq. Reference Value Valid (FA01H) ² | Invalid | Valid |
| 13 | Re-adjustment after Switch Off | OUT | Re-adjustment |
| 12 | Emergency Stop | OUT | Quickstop |
| 11 | Free Stop | OUT | Free Run |
| 10 | Operation/Stop | Stop | Operation |
| 9 | Clockwise/ Anti-clockwise Run | Clockwise | Anti-clockwise |
| 8 | Intermittant Operation (JOG) | OUT | JOG |
| 7 | DC Switching (dCI) | OUT | DCI |
| 6 | ACC / DEC #1/#2 – Switching | #1 | #2 |
| 5 | (reserved) | - | - |
| 4 | (reserved) | - | - |
| 3 | Fixed Frequency #4 | OUT | ON |
| 2 | Fixed Frequency #3 | OUT | ON |
| 1 | Fixed Frequency #2 | OUT | ON |
| 0 | Fixed Frequency #1 | OUT | ON |

¹ If this Bit 15 is set, the VF S7 is controlled over the serial interface and the signals applied to the logic inputs are eventually ignored.

² By setting of the Bit 14, the signals applied to Analogue inputs are eventually ignored and the the reference value transmitted over the serial interface takes priority.

Table 2: (FE01H) Bit-Structure of the internal VF S7-Status words

| Bit | Function | 0 | 1 |
|-----|---------------------------------|-----------|----------------|
| 15 | (reserved) | - | - |
| 14 | (reserved) | - | - |
| 13 | (reserved) | - | - |
| 12 | (reserved) | - | - |
| 11 | (reserved) | - | - |
| 10 | Operational Status ¹ | Stopped | Runs |
| 9 | Direction of Rotation | Clockwise | Anti-clockwise |
| 8 | Intermittant Operation (JOG) | - | JOG |
| 7 | DC Switching (dCI) (dCI) | - | dCI |
| 6 | ACC / DEC #1/#2 – Status | #1 | #2 |
| 5 | (reserved) | - | - |
| 4 | (reserved) | - | - |
| 3 | (reserved) | - | - |
| 2 | (reserved) | - | - |
| 1 | (reserved) | - | - |
| 0 | (reserved) | - | - |

¹ During the DC switching this Bit remains set (Signal: Drive Runs)

Hint: This S7-internal Status word is not identical to the Status word as per Profibus.

VF S7 – Profibus - Module

Table 3: (FE06H) Bit-Structure of the LI-Words

| Bit | Terminal | Function | Terminal ON-Data |
|------|----------|-----------------|---------------------|
| 0 | F | Digital Input 1 | 1 = Input Set (1h) |
| 1 | R | Digital Input 2 | 1 = Input Set (2h) |
| 2 | RST | Digital Input 3 | 1 = Input Set (4h) |
| 3 | S1 | Digital Input 4 | 1 = Input Set (8h) |
| 4-15 | S2 | Digital Input 5 | 1 = Input Set (10h) |

Example:

If the Inputs F and S1 are set, *FE06* has the Value: $01h + 08h = 0009h$.

Table 4: (FE07H) Bit-Structure of the LO-Words

| Bit | Terminal | Function | Terminal ON-Data |
|--------|----------|-------------------|---------------------|
| 0 | OUT1 | Output Terminal 1 | 1 = Output Set (1h) |
| 1 - 15 | OUT2 | Output Terminal 2 | 1 = Output Set (2h) |

Example:

If the Outputs 1 and 2 are set, *FE06* ha the Value : $01h + 02h = 0003h$.

VF S7 - ProfiBus-Module

9.2.5 Fault Messages

This table contains all the values, which the Fault Words *FC90H*, *FE10H*, *FE11H*, *FE12H* und *FE13H* can take.

The Fault Word 0023H contains in the fault-free status of the inverter the last occurring fault, in case of fault, this Fault Word has the Fault Code of the actual fault.

| Fault Code | Value | Fault Type |
|------------|-------------|--|
| nErr | 0000 | No fault |
| OC1 | 0001 | Over Current During Ramp-up |
| OC2 | 0002 | Over Current During Ramp-down |
| OC3 | 0003 | Over Current During Constant Speed |
| OCL | 0004 | External Phase Short Circuit (Load Side) |
| OCA | 0005 | Internal Phase Short Circuit (Power Circuit) |
| | 0006 | Reserved |
| | 0007 | Reserved |
| (EPH1) | 0008 | Reserved |
| EPHO | 0009 | Failed Output Phase |
| OP1 | 000A | Over Voltage During Ramp-up |
| OP2 | 000B | Over Voltage During Ramp-down |
| OP3 | 000C | Over Voltage During Constant Speed |
| OL1 | 000D | Inverter Overload |
| OL2 | 000E | Motor Overload |
| OLr | 000F | Brake resistor Overload |
| OH | 0010 | Overheating |
| E | 0011 | Emergency Stop |
| EEP1 | 0012 | EEPROM – Fault |
| | 0013 | Reserved |
| | 0014 | Reserved |
| Err2 | 0015 | RAM - Fault |
| Err3 | 0016 | ROM - Fault |
| Err4 | 0017 | CPU - Fault |
| Err5 | 0018 | Communications Fault |
| | 0019...0024 | Reserved |
| OCr | 0025 | Brake Resistor Fault |
| | 0026...0027 | Reserved |
| Etn | 0028 | Auto-Tuning - Fault |
| EtYP | 0029 | Inverter Initialization Fault |