


Installation Manual

Bently Nevada™ Asset Condition Monitoring



3300 System Installation

**Copyright © 1987. Bently Nevada LLC.
All rights reserved.**

The information contained in this document is subject to change without notice.

The following are trademarks of General Electric Company in the United States and other countries:

Bently Nevada Keyphasor, Proximitor

Contact Information

The following ways of contacting Bently Nevada are provided for those times when you cannot contact your local representative:

Mailing Address	1631 Bently Parkway South Minden, Nevada USA 89423 USA
Telephone	1.775.782.3611 1.800.227.5514
Fax	1.775.215.2873
Internet	www.ge-energy.com/bently

Additional Information

Notice:

This manual does not contain all the information required to operate and maintain the product. Refer to the following manuals for other required information.

3300 System Overview (Part Number 80171-01)

3300 System Troubleshooting (Part Number 80173-01)

The above two documents and 80172 are available as Part Number 80170-01 or -02.

3300/12 AC Power Supply (Part Number 89602-01)

3300/14 DC Power Supply (Part Number 101256-01)

3300/03 System Monitor (Part Number 89604-01)

3300 Internal Barrier Manual (Part Number 88837-01)

Product Disposal Statement


Customers and third parties, who are not member states of the European Union, who are in control of the product at the end of its life or at the end of its use, are solely responsible for the proper disposal of the product. No person, firm, corporation, association or agency that is in control of product shall dispose of it in a manner that is in violation of any applicable federal, state, local or international law. Bently Nevada LLC is not responsible for the disposal of the product at the end of its life or at the end of its use.

Symbols


Special symbols are used in the manual to illustrate specifics in the step-by-step processes. For example:




PRESS




FLASHING




CONNECT



DISCONNECT



OBSERVE




SCREWDRIVER

Contents

1.	RECEIVING INSPECTION	1
2.	HANDLING & STORING CONSIDERATIONS.....	2
3.	RACK ASSEMBLY OPTIONS.....	3
4.	RACK INSTALLATION [PANEL MOUNT].....	4
5.	RACK INSTALLATION [19-INCH EIA].....	5
6.	PANEL CUTOUT DIMENSIONS.....	6
7.	WEATHERPROOF HOUSING INSTALLATION	7
8.	POWER SUPPLY INSTALLATION	13
9.	SYSTEM MONITOR INSTALLATION	15
10.	MONITOR INSTALLATION [TYPICAL]	16
11.	POWER INPUT MODULE	17
12.	SIGNAL INPUT RELAY MODULES	18
13.	ALERT RELAY ACTUATION CIRCUITS	23
14.	DANGER RELAY ACTUATION CIRCUITS	26
15.	FIELD GROUNDING TECHNIQUE.....	28

1. RECEIVING INSPECTION

1. Visually inspect the exterior of rack assembly and components for obvious shipping damage.
2. Inspect interior of monitors and power supply. Loosen screws to pull each monitor and power supply out from rack.




DAMAGE CLAIMS

If shipping damage is apparent,
file a claim with the carrier and
submit a copy to Bently Nevada
Corporation.



2. HANDLING & STORING CONSIDERATIONS

Handling and storing of printed circuit boards is extremely critical. Circuit boards contain devices that are susceptible to damage when exposed to electrostatic charges. Damage caused by obvious mishandling of the board will void the warranty. To avoid damage, observe the following precautions in the order given.



- Prior to servicing, remove all power to the instrument.
- Do not discharge static electricity onto the circuit board. Avoid tools or procedures that would subject the circuit board to static damage. Some of the possible causes include ungrounded soldering irons and nonconductive plastics or similar materials.
- Personnel must be grounded with a suitable grounding strap (such as 3M Velostat No. 2060) prior to handling or performing maintenance on a printed circuit board.
- Transport and store circuit boards in electrically conductive bags or foil.
- Use extra caution during dry weather. Relative humidity less than 30% tends to multiply the accumulation of static charges on any surface.

3. RACK ASSEMBLY OPTIONS




EXTERNAL DIMENSIONS


	A	B
01,11,21,31 = 4 POSITIONS	11.00 IN. (279.4 mm)	8.00 IN. (203.2 mm)
02,12,22,32 = 6 POSITIONS	15.00 IN. (381.0 mm)	12.00 IN. (304.8 mm)
03,13,23,33 = 8 POSITIONS	19.00 IN. (482.6 mm)	16.00 IN. (406.4 mm)
04,14,24,34 = 10 POSITIONS	23.00 IN. (584.2 mm)	20.00 IN (508.0 mm)
05,15,25,35 = 12 POSITIONS	27.00 IN (685.8 mm)	24.00 IN. (609.0 mm)
06,16,26,36 = 14 POSITIONS	31.00 IN. (787.4 mm)	28.00 IN. (711.2 mm)
07,17,27,37 = 8 POSITIONS	19.00 IN. (482.6 mm)	16.00 IN (406.4 mm)

4. RACK INSTALLATION [PANEL MOUNT]

1. Slide rack through panel cutout.



5. RACK INSTALLATION [19-INCH EIA]



PART NO. 3300/05-


AA	
0	7

*

RACK SIZE
07 = 8 Position 19-Inch EIA Rack

* ALSO APPLICABLE TO AA OPTION 17, 27, AND 37.

6. PANEL CUTOUT DIMENSIONS



OPTIONS	RACK SIZE	A
01,11,21,31	4 POSITIONS	8.56 IN. (217.5 mm)
01,12,22,32	6 POSITIONS	12.57 IN (319.3mm)
03,13,23,33	8 POSITIONS	16.57 IN. (420.8mm)
04,14,24,34	10 POSITIONS	20.58 IN (522.7 mm)
05,15,25,35	12 POSITIONS	24.58 IN (624.3 mm)
06,16,26,36	14 POSITIONS	28.59 IN (726.2 mm)
07,17,27,37	8 POSITIONS	SEE SECTION 5

NOTE


The dimensions specified for "A" in the table above refer to the case where a panel is being cut out for the rack only and not for the weatherproof housing. The panel cutout dimensions for the weatherproof housing are specified in the "Tabulated Data" table in section 7 under the "E" column.


7. WEATHERPROOF HOUSING INSTALLATION


The next 5 pages contain the weatherproof housing installation drawing, 330006.

[illegible]












8. POWER SUPPLY INSTALLATION


For systems with the AC Power Supply, perform the following steps. For systems with the DC Power Supply, perform the steps on the following page.



1. Slide Power Supply into rack and fasten two screws.

2. Slide the transformer assembly into the rack. Fasten the screw that mounts the support plate to the rack side panel. Connect cables to backplane and Power Input Module as shown.

3. Connect cables from backplane to Power Input Module as shown.



4. Place Power Input Module in position at rear of rack. Fasten retaining screws.



For systems with the DC Power Supply, perform the following steps.



WARNING

High voltage present
could cause shock,
burns, or death.

Do not touch exposed wires
or terminals.




1. Slide Power Supply into rack and fasten two screws.

2. Insert filter board. Fasten screw that secures the filter board to the rack side panel. Connect cable from filter board to Power Input Module as shown.


3. Connect cables from backplane to Power Input Module as shown.

4. Place Power Input Module in position at rear of rack. Fasten retaining screws.




9. SYSTEM MONITOR INSTALLATION

1. Slide System Monitor panel to the right before inserting monitor. Slide System Monitor board into rack to engage connector on backplane.





2. Slide front panel to the left and fasten two screws.




10. MONITOR INSTALLATION [TYPICAL]

1. Slide monitor front panel to the right before inserting monitor. Slide monitor circuit board into rack to engage connector on backplane. If the monitor is a dual width monitor with two separate circuit boards, line the lower edges of both boards up with the slots in the rack and slide the boards in simultaneously. Make sure that the connectors on both boards are fully seated in the backplane. **NOTE:** For the 3300/30 and 3300/35 dual width six channel temperature monitors, the left of the two boards (when facing the rack) must be in an odd numbered rack position (numbered from left to right starting at one) to communicate with a TDIX or a TDXnet.



2. Slide front panel to the left and fasten to rack.




SIGNAL INPUT RELAY MODULE
(SEE 12)

3. Install Signal Input Relay Module in rear of rack and fasten screws.

11. POWER INPUT MODULE

For grounding technique see Section 15.



12. SIGNAL INPUT RELAY MODULES


WARNING

High voltage present
could cause shock,
burns, or death.
Do not touch exposed
wires or terminals.


CAUTION

The following information is not
applicable to the Velomitor. Refer to
the 3300/55 Maintenance Manual for
jumper configuration of the
Velomitor Relay Module.

SIGNAL INPUT RELAY MODULES




JUMPERS
W1 – W8




JUMPERS
W11, W12




RELAYS



CIRCUIT BOARD
DUAL RELAYS



FOR FIELD
WIRING
REFER TO
MONITOR
MANUAL



WITH DUAL RELAYS

WITHOUT RELAYS

ALERT RELAY	JUMPER *	
	IN	OUT
NORMALLY ENERGIZED	W3	W4, W11
NORMALLY DEENERGIZED	W4, W11	W3

DANGER RELAY	JUMPER *	
	IN	OUT
NORMALLY ENERGIZED	W2	W1, W12
NORMALLY DEENERGIZED	W1, W12	W2

* FOR MORE INFORMATION ON RELAY
CONFIGURATION REFER TO
SECTIONS 13 AND 14.



WARNING

High voltage present
could cause shock,
burns, or death.
Do not touch exposed
wires or terminals.


CAUTION

The following information is not
applicable to the Velomitor.
Refer to the 3300/55
Maintenance Manual for jumper
configuration of the Velomitor
Relay Module.

SIGNAL INPUT RELAY MODULES



WITH QUAD RELAYS



SIGNAL INPUT/QUAD RELAY CARD OPTION *		
RELAY OPTIONS	INSTALL	REMOVE
ALERT RELAYS NORMALLY DE-ENERGIZED	W2,3C W3D,4D	W3A,4C
ALERT RELAYS NORMALLY ENERGIZED	W3A,4C	W2,3C W3D,4D
DANGER RELAYS NORMALLY DE-ENERGIZED	W1,3B W4A,4E	W4B,4F
DANGER RELAYS NORMALLY ENERGIZED	W4B,4F	W1,3B W4A,4E

* For more information on relay configuration refer to Sections 13 and 14.

WARNING




High voltage present
could cause shock
burns or death

Do not touch exposed
wires or terminals

CAUTION

The following information is
not applicable to the
Velomitor. Refer to the
3300/55 Maintenance
Manual for jumper
configuration of the
Velomitor Relay Module.

SIGNAL INPUT RELAY MODULES



FOR FIELD
WIRING
REFER TO
INTERNAL
SAFETY
BARRIER
INSTALLATION
MANUAL


WITH DUAL RELAYS
AND INTERNAL BARRIERS

RELAY OPTIONS	JUMPER	
	INSTALL	REMOVE
ALERT RELAYS NORMALLY DE-ENERGIZED	W4,W9	W3
ALERT RELAYS NORMALLY ENERGIZED	W3	W4,W9
DANGER RELAYS NORMALLY DE-ENERGIZED	W1,W10	W2
DANGER RELAYS NORMALLY ENERGIZED	W2	W1,10

13. ALERT RELAY ACTUATION CIRCUITS

The following diagram shows the functional concept of jumper configurations for Alert relay bus actuation for the Dual Relay Module. For more detail refer to schematics in the applicable monitor manuals.

NOTE: The relay located directly behind a monitor is always driven by that monitor, and all other relay connected on the same bus will also be driven by that monitor.




CAUTION

The following information is not applicable to the Velomitor. Refer to the 3300/55 Maintenance Manual for jumper configuration of the Velomitor Relay Module.

FUNCTION	JUMPER	
	INSTALL	REMOVE
Set Alert relay for normally energized operation*	W3	W4,W11
Set Alert relay for normally de-energized operation*	W4,W11	W3
Select Alert bus 1	W6	W5
Select Alert bus 2	W5	W6


* REFER TO SECTION 12 FOR JUMPER CONFIGURATION OF RELAYS IN A SYSTEM WITH INTERNAL BARRIERS.

The following diagram shows the functional concept of jumper configurations for Alert relay actuation for the Quad Relay Module. **Note:** The jumper configuration shown is not applicable to the Velomitor Signal Input Relay Module. Refer to the Dual Velocity Monitor Maintenance Manual. For more details refer to schematics in the applicable monitor manuals.



CAUTION

The following information is not applicable to the Velomitor. Refer to the 3300/55 Maintenance Manual for jumper configuration of the Velomitor Relay Module.




FUNCTION	JUMPER	
	INSTALL	REMOVE
Set Alert relays for normally energized operation	W3A,4C	W2,3C,3D,4D
Set Alert relays for normally de-energized operation	W2,3C,3D,4D	W3A,4C

14. DANGER RELAY ACTUATION CIRCUITS

The following diagram shows the functional concept of jumper configurations for Danger relay bus actuation for the Dual Relay Module. **Note:** The jumper configuration shown is not applicable to the Velomitor Signal Input Relay Module. For more details refer to schematics in applicable monitor manuals.

NOTE: The relay located directly behind a monitor is always driven by that monitor, and all other relays connected on the same bus will also be driven by that monitor.



CAUTION

The following information is not applicable to the Velomitor. Refer to the 3300/55 Maintenance Manual for jumper configuration of the Velomitor Relay Module.


FUNCTION	JUMPER INSTALL REMOVE	
Set Danger relay for normally energized operation*	W2	W1,W12
Set Danger relay for normally de-energized operation*	W1,W12	W2
Select Danger bus 1 for operation	W8	W7
Select Danger bus 2 for operation	W7	W8

* REFER TO SECTION 12 FOR JUMPER CONFIGURATION OF RELAYS IN A SYSTEM WITH INTERNAL BARRIERS.

The following diagram shows the functional concept of jumper configurations for Danger Relay actuation for the Quad Relay Module. **Note:** The jumper configuration shown is not applicable to the Velomitor Signal Input Relay Module. For more details refer to schematics in the applicable monitor manuals.

CAUTION

The following information is not applicable to the Velomitor. Refer to the 3300/55 Maintenance Manual for jumper configuration of the Velomitor Relay Module.



FUNCTION	JUMPER	
	INSTALL	REMOVE
Set Danger relays for normally energized operation	W4B,4F	W1,3B,4A,4E
Set Danger relays for normally de- energized operation	W1,3B,4A,4E	W4B,4F

15. FIELD GROUNDING TECHNIQUE

1. Refer to the applicable monitor manual for monitor connections.
2. For single point ground on typical system installations, install a jumper wire between the terminals labeled "Single Point Ground" on the Power Input Module. For systems with external safety barriers, refer to the field wiring diagrams in the appropriate monitor maintenance manuals for grounding requirements. For systems with internal safety barriers, refer to the 3300 Internal Barriers Installation Manual for grounding requirements. **NOTE:** Keep in mind that when communicating with a host computer the communication and earth grounds inside the computer may be connected. Consider carefully when grounding to avoid ground loops and potential communication problems.

WARNING

High voltage present
could cause shock,
burns, or death.
Do not touch exposed
wires or terminals.

WARNING

DO NOT REMOVE JUMPER STRAPS UNLESS SYSTEM COMMON IS CONNECTED TO THE EARTH GROUND AT A DIFFERENT LOCATION. FAILURE TO HEED THIS WARNING COULD EXPOSE PERSONNEL TO DANGEROUSLY HIGH VOLTAGE LEVELS.

