

onn.™

6-DEVICE UNIVERSAL REMOTE



Model: 100008755

PRODUCT GUIDE

Need help?
We're here for you every day
7 a.m. – 9 p.m. CST.
Give us a call at 1-888-516-2630

We'd love to hear from you. Scan with your
walmart app and let us know what you think.



6 81131 31001 7

v1.8

TABLE OF CONTENTS

• GETTING STARTED (BATTERIES)	02
• GETTING STARTED (BUTTONS)	03
• PROGRAMMING YOUR REMOTE (DIRECT CODE ENTRY)	05
• PROGRAMMING YOUR REMOTE (AUTO CODE SEARCH)	08
• FAVORITE CHANNELS	09
• VOLUME LOCK	10
• CHANNEL LOCK	11
• CODE IDENTIFICATION	12
• RESET TO FACTORY DEFAULT SETTINGS	13
• TROUBLESHOOTING	14
• FCC INFORMATION	15

GETTING STARTED (BATTERIES)

Thank you for choosing the ONN Universal Remote Control. This remote control can operate a wide range of electronic devices, works across most brands and models, and comes pre-programmed to operate many Samsung TVs (see the *Programming Your Remote* sections if your device is not compatible). Your remote can control up to 6 devices and is remarkably easy to set up. To get started, please install two AA alkaline batteries (not included) as shown below.


Installing the Batteries

1. Remove the battery cover.
2. Insert the batteries as shown.
3. Snap the battery cover back into place.

Battery Precautions

- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc) or rechargeable (nickel-cadmium) batteries.
- Always remove old, weak or worn-out batteries promptly and recycle or dispose of them in accordance with local and national regulations.

Low Battery Indicator


If while using the remote, the  button's red indicator light flashes 3 times, this indicates the batteries need to be replaced. Please replace the batteries as soon as possible when this indication occurs.

Code Saver

When changing the batteries of your remote, please do so quickly. You have up to 20 minutes to change the batteries in your remote without losing the programmed codes.


Battery Saver

To conserve battery power, the remote will automatically turn off if any button is pressed for more than 60 seconds (except during programming). This feature is helpful in the event that the remote is stuck in a location where the buttons remain depressed, such as between sofa cushions.



Your remote control's model number can be found in the battery compartment

GETTING STARTED (BUTTONS)



NOTE: Some of the buttons on the remote may not support all of the functions of the original device remote.

GETTING STARTED (BUTTONS)



POWER

Turns your device On/Off and also serves as an indicator when the remote is being programmed



INPUT

Switches between the sources connected to your TV



DEVICE CATEGORIES

Use these buttons to select the device you want to control



GUIDE

Use to access the guide of satellite and cable set-top boxes



PROGRAM

Use to put your remote in programming mode



APPS

Use to access your smart TV's apps (if supported)



BACK

Return to the previous menu or screen



CUSTOM BUTTONS

Use to access device shortcuts for additional features or custom apps on your device (if supported)



INFO

Use to access on-screen content description and information

PROGRAMMING YOUR REMOTE (DIRECT CODE ENTRY)


Programming your remote is as easy as 1, 2, 3

Before beginning, please make sure that the device you want to control is powered on and follow these three simple steps.

NOTE: Press **PROGRAM** to exit at any time.

1.

Press and hold the **PROGRAM** button until the  button lights up red.

The  button's red indicator light remains on.



Red indicator light




NOTE: The ONN universal remote comes pre-programmed to operate many Samsung TVs.

PROGRAMMING YOUR REMOTE (DIRECT CODE ENTRY)

2.

Select the device you want to program from the **Device Categories**:



The  button's red indicator light blinks once and remains on.



Red indicator light

Device Categories




PROGRAMMING YOUR REMOTE (DIRECT CODE ENTRY)

3.

Enter the 4-digit code from the included list for the category and brand of your device.

The  button's red indicator light shuts off if a valid code was entered.

If the  button's red indicator light flashes and remains on after entering four digits, that means an invalid code was entered. In that case, check the list again and re-enter the code.




NOTE: Test the remote with the device to make sure all the buttons work as expected. If some of the buttons/features don't work, try a different code in the list. Repeat this process for each device you wish to control.



Enter the code

PROGRAMMING YOUR REMOTE (AUTO CODE SEARCH)





It's recommended to program your remote by using the **Direct Code Entry** method, however if with that method you were not able to find a code that is compatible with your device, you may try the **Auto Code Search** method below:


1. Power on the device that you want to control.
2. Press and hold the **PROGRAM** button until the  button lights up red. The  button's red indicator light remains on.
3. Select a device from **Device Categories** you would like to control. The  button's red indicator light blinks once and remains on.


Device Categories



NOTE: Please refer to the list below if you are unsure about the device category.







- **TV:** TV, TV/DVD and other TV combinations.
 - **SAT/CBL:** Satellite, Cable, DVR, and other set-top boxes.
 - **AUDIO:** Sound Bars, Audio Receivers, and other audio devices.
 - **B-RAY/DVD:** Blu-ray Players and DVD Players.
 - **STREAM:** Roku, Apple TV, Xbox, and other streaming media players.
 - **OTHER:** VCRs, Digital Frames, and devices not found on the code list.
4. Point the remote at the device you wish to control and then press and hold the  button until the device turns off. The  button's red indicator light will blink as the codes are being tested.
 5. When the device turns off, immediately release the  button to lock in the code. The  button's red indicator light will turn off. Test the remote with the device to make sure all the buttons work as expected. If some of the buttons/features don't work, repeat the process or try the **Direct Code Entry** method.

NOTE: It may take over 10 minutes to scan through all the possible codes for your device. If during the Auto Code Search you have either accidentally or deliberately released the  button, you may repeat steps 1 through 5 above to resume the code search where it left off.

After the Auto Code Search has exhausted all available codes for the selected category, the remote's  button's red indicator light blinks three times and turns off. If none of the codes worked with your device, try the Direct Code Entry method.



FAVORITE CHANNELS

For easy access to up to 10 of your favorite channels, follow the steps below.

1. Select a device from **Device Categories** that controls the channels. The  button's red indicator light will blink once.
2. Press and hold the **PROGRAM** button until the  button lights up red. The  button's red indicator light remains on.
3. Press the **FAV** button. The  button's red indicator light blinks once and remains on.
4. Select the button (0 – 9) that you will use for storing your favorite channel. The  button's red indicator light blinks once and remains on.
5. Enter the channel number you wish to program as a favorite channel.
6. Press the **FAV** button, the  button's red indicator light will turn off and the channel is saved.

NOTE: To change a stored favorite channel, repeat steps 1-6 above.






To Access Your Favorite Channels:

1. Press the **FAV** button. The  button's red indicator lights up and remains lit.
2. To access the favorite channel, press the programmed button for that channel (0-9). The  button's red indicator light blinks, then turns off as the command is sent.





VOLUME LOCK

Use this feature to lock a device to the remote's volume control. For example, the remote can be in TV mode while the volume buttons control your sound bar.

Enabling Volume Lock:

1. Press and hold the **PROGRAM** button until the  button lights up red. The  button's red indicator light remains on.
2. Select a device from **Device Categories** that you want to lock to the remote's volume control. The  button's red indicator light blinks once and remains on.
3. Press the **VOL+** button. The  button's red indicator light blinks once and remains on.
4. Press the **OK** button. The  button's red indicator light will blink twice and turn off.

Disabling Volume Lock:







1. Press and hold the **PROGRAM** button until the  button lights up red. The  button's red indicator light remains on.
2. Press the **VOL-** button. The  button's red indicator light blinks once and remains on.
3. Press the **OK** button. The  button's red indicator light will blink twice and turn off.

NOTE: On most newer HDMI-connected devices, the Volume Lock feature may be unnecessary as this feature is already built-in.






CHANNEL LOCK

Use this feature to lock a device to the remote's channel control. For example, the remote can be in TV mode while the channel buttons control your satellite or cable box.

Enabling Channel Lock:

1. Press and hold the **PROGRAM** button until the  button lights up red. The  button's red indicator light remains on.
2. Select a device from **Device Categories** that you want to lock to the remote's channel control. The  button's red indicator light blinks once and remains on.
3. Press the **CH+** button. The  button's red indicator light blinks once and remains on.
4. Press the  button. The  button's red indicator light will blink twice and turn off.













Disabling Channel Lock:

1. Press and hold the **PROGRAM** button until the  button lights up red. The  button's red indicator light remains on.
2. Press the **CH-** button. The  button's red indicator light blinks once and remains on.
3. Press the  button. The  button's red indicator light will blink twice and turn off.

NOTE: On most newer HDMI-connected devices, the Channel Lock feature may be unnecessary as this feature is already built-in.





CODE IDENTIFICATION

To identify any of your programmed codes, follow the steps below.

1. Press and hold the **PROGRAM** button until the  button lights up red. The  button's red indicator light remains on.
2. Select a device from **Device Categories** that you would like the code for. The  button's red indicator light blinks once and remains on.
3. Press the  button. The  button's red indicator light blinks once and remains on.
4. Press the  button. Count the number of times the  button's red indicator light flashes. This is the number corresponding to the first digit of the code. If the  button does not flash, the corresponding code number is 0. Repeat the process by pressing the ,  and  buttons for the remaining digits.
5. Press the  button to exit.

NOTE: Press  to exit at any time.

RESET TO FACTORY DEFAULT SETTINGS

1. Press and hold the **PROGRAM** button until the  button lights up red. The  button's red indicator light remains on.
2. Press the **INFO** button. The  button's red indicator light blinks once and remains on.
3. Press the **OK** button. The  button's red indicator light will flash twice and the remote will revert to factory settings.

TROUBLESHOOTING

The tips below can help you solve problems and answer questions you may have with your remote control. In general, always make sure:

- 1) The remote is in the correct device category mode (TV, SAT/CBL, AUDIO, B-RAY/DVD, STREAM, OTHER); this tells the remote which device to operate.
- 2) The batteries are fresh and properly installed.
- 3) To remove any obstacles between the remote and the device, and that you're aiming the remote at the device's IR sensor.

The remote can't be programmed to operate my device.

- If you're using the Direct Code Entry method to enter the codes for your brand and the device is still not functioning properly after trying all the code options, try the Auto Code Search method.
- To control combo devices like TV/VCRs or TV/DVDs, you must program the individual corresponding device buttons to control each part of the combo unit.

Some of the buttons of the remote are not supported or working properly on my device.

- It's possible the code that you programmed is not fully compatible with your device. Try selecting the next code from the options available for the category and brand of your device.
- There may be some buttons from your device's original remote that are not supported.
- You may have pressed an invalid button for the device category mode the remote is in.

The remote will not change the channels on my device.

- Make sure the remote is in the correct device category mode (TV, SAT/CBL, AUDIO, B-RAY/DVD, STREAM, OTHER) that controls the channels.
- Try pressing the ENTER button after you enter a channel number (a requirement with certain models and brands of TV and/or Cable/Satellite boxes).

The remote will not adjust the volume on my device.

- Make sure the remote is in the correct device category mode (TV, SAT/CBL, AUDIO, B-RAY/DVD, STREAM, OTHER) that controls the volume.

My device's menu or app hub does not appear.

- Menu and app hub access isn't supported for all brands. You may need to use your original remote control to access the menu functions and/or app hub for some devices.

My remote's light is blinking

- If while using the remote the indicator light flashes 3 times, this indicates the batteries need to be replaced.

For more information, please call the Customer Support Help Line: 1 (888) 516-2630

FCC INFORMATION

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

CAUTION: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.