

Basic's to decoding Inmarsat L-Band signals using the RSP

[CHECK YOUR LOCAL LAWS BEFORE DECODIING ANY SIGNALS FROM THE INMARSAT SYSTEM](#)



Hardware used

SDR: RSP1a SDR from SDRplay
<https://www.sdrplay.com/rsp1a/>



Antenna: Modified GPS patch antenna for L-Band from SDR-Kits, model A154.
<https://www.sdr-kits.net/L-Band-Receive%20Antenna>



Software used

SDRuno v1.32

<https://www.sdrplay.com/downloads/>

VBcable (Donationware) vPack43

<https://www.vb-audio.com/Cable/>

VAC (Paid for use) v4.60

<https://vac.muzychenko.net/en/>

JAERO (Free) v1.0.4.9

<https://github.com/jontio/JAERO/releases>

Tekmanoid STD-C Decoder (Paid for use) v1.5.1

Requires Java JRE, check your local laws before using this decoder.

<http://www.tekmanoid.com/egc.shtml>

<https://www.java.com/en/download/>

Introduction

(some text taken and edited from the RTL-SDR Blog website)

This document is not a definitive guide to Satcom, L-Band transmission or the Inmarsat system. This is a collection of information that I have found scatter throughout the internet and re-compiled into a document, this document. My aim is to help you get started and hopefully guide you in the right direction. **Expect typographical mistakes, inaccuracies, or omissions**

Inmarsat is a communications service provider with several geostationary satellites in orbit. Inmarsat provides services such as satellite phone communications, broadband internet, and short text and data messaging services. Geostationary means that the Inmarsat satellites are in a fixed position in the sky and do not move.

The Inmarsat 3-F(x) satellites have transponders transmitting data in L-Band (1.5 GHz) that can be decoded.

The modes we will cover in this document are Aeronautical (Classic Aero or ACARS) and Inmarsat-C (STD-C) using an RSP1a, RSP2/2pro or RSPduo connected to the SDR-Kits modified L-Band patch antenna. The Inmarsat system is not limited to only these types of networks. We are limited to the decoders available.

<https://en.wikipedia.org/wiki/Inmarsat>

Some regions that use the I-3 satellite services moved and migrated to the Inmarsat I-4 Satellites. See the following document. https://www.inmarsat.com/wp-content/uploads/2018/09/INM_C_I3_I4_migration_guide_V3.0.pdf

Two of the most popular decoding applications are JAERO used for ACARS and Tekmanoid STD-C Decoder used for decoding STD-C NCS transmissions on the Inmarsat 3-F(x) satellites

https://www.sigidwiki.com/wiki/Inmarsat_Aero


https://www.sigidwiki.com/wiki/Inmarsat-C_TDM

Software installation


Virtual Audio Cable: A virtual audio cable allows you to pipe audio from application (SDRuno) into another application (a decoder like JAERO) digitally. I will assume SDRuno is already installed with your device attached and functioning properly.

You can now download a virtual audio cable package. If you already have a virtual audio cable package installed, you can skip to the next section. If you don't have a virtual audio cable application installed, you only need to choose one and only install one of the two, either one works fine

Close any running apps, install the virtual audio cable and reboot your computer. When your computer boots back to your desktop, your computer will now have a virtual audio cable pair installed on the system.




You can verify by going to your Control Panel and double clicking the Sound icon. VB-Cable and Virtual Audio Cable will only install a single virtual audio cable pair, one is for the input (Recording) and one is for the output (Playback). A single pair is all that is needed (as shown below).



JAERO

(some text taken and edited from the JAERO website)



JAERO is a program that decodes ACARS (Aircraft Communications Addressing and Reporting System) messages sent by satellites (in this case Inmarsat) to Airplanes (SatCom ACARS). This is commonly used when airplanes are well beyond VHF range.

JAERO also allows for decoding and demodulation of voice calls, due to local laws and privacy, I will not show or discuss how to do this. You can find more information about that JAERO feature online.

JAERO can be downloaded from the link provided on the first page of this document. After downloading the installer, simply double click the setup file and install it on your primary drive.

Tekmanoid STD-C Decoder

(some text taken and edited from the USA-Satcoms website)


Inmarsat STD-C is a data or message-based system used mostly by maritime operators. An Inmarsat C terminal transmits and receives on L-Band to various geosynchronous satellites that service each major ocean region.

The Tekmanoid STD-C decoder will decode STD-C Inmarsat EGC (enhanced group call) and LES (land earth station) messages. Some of these messages contain private information. Reception of these messages may not be legal in your country; therefore, your local laws should be checked.

The Enhanced Group Call (EGC) service is a message broadcast service with global coverage (except the poles) within the Inmarsat-C communications system. Two of the services provided are:


FleetNET and SafetyNET

FleetNET is used to send commercial messages to individuals or groups of subscribers (for example, individual companies communicating with their own Mobile Earth Stations (MES)). SafetyNET is used for broadcasting Maritime Safety Information (MSI) such as Navigational warnings, meteorological warnings, meteorological forecasts and other safety related information (including Distress Alert Relays) from official sources.



The LES station acts as an interface (or gateway) between the Inmarsat space segment and the national/international telecommunications networks.

The Tekmanoid STD-C decoder requires Java JRE in order to run. The link for the Java runtime environment is on page 2 of this document. For information contact the developer direct admin@tekmanoid.com




There are alternatives to using the Tekmanoid STD-C decoder, but in my opinion the other decoders available do not perform as well on low end systems or even work without needing “helper” applications to be installed. Tekmanoid STD-C decoder is very easy to use and works great on my low-end system using minimal system resources.

Putting all the pieces together


ACARS and STD-C messages will transmit via the Inmarsat satellite deployed within your coverage area/region, you will need to choose the Inmarsat satellite that is closest to your coverage area.

Note that only different frequencies are used between ACARS transmissions and STD-C transmissions. You will only need to receive from one of the available 3-F(x) Inmarsat satellites. L-Band ACARS transmissions are in the 1.545 GHz range but STD-C messages are on fixed frequencies (shown on page 8)



Since STD-C transmissions are broadcasted on fixed frequencies, we want to monitor the TDM NCSC channel, again these are fixed for the following Ocean Regions. Choose the region closest to your location (page 9).

Again, some regions that use the I-3 satellite services moved and migrated to the Inmarsat I-4 Satellites. See the following document. https://www.inmarsat.com/wp-content/uploads/2018/09/INM_C_I3_I4_migration_guide_V3.0.pdf



STD-C transmissions are broadcasted on fixed frequencies, NCSC channel. The NCSC frequency per region is noted below.

Inmarsat satellite: Inmarsat-4 F3 (AOR-W)

Direction: 98° West

Frequency: 1.537.70 GHz

Inmarsat satellite: Inmarsat-3 F5 (AOR-E)

Direction: 54° West

Frequency: 1.541.45 GHz

Inmarsat satellite: Inmarsat-4 F1 (IOR)

Direction: 25° East

Frequency: 1.537.10 GHz

Inmarsat satellite: Inmarsat-4 F1 (POR)

Direction: 143.5° East


Frequency: 1.541.45 GHz

I will assume you have located the Inmarsat satellite that covers your region. I suggest using a compass on your mobile phone to pinpoint the general direction. The direction is in ° (degrees). I am referencing true north, not magnetitic north (traditional analog compass).

https://en.wikipedia.org/wiki/Magnetic_declination

You can also download an app for your smartphone called Satellite AR (Android and IOS). After you locate the correct direction of the Inmarsat satellite, you will want to place the L-Band patch on a flat metal surface. I have read that the receive pattern of this patch antenna is z (about 85-90°, straight up). Point the top of the antenna facing the Inmarsat satellite. Using the roof of my car worked just fine, just remember to point the front of the antenna at the satellite.

https://www.u-blox.com/sites/default/files/products/documents/GPS-Antenna_AppNote_%28GPS-X-08014%29.pdf



Launch SDRuno and click the PLAY button, remember that if the RSP(x) is in ZERO IF mode, give frequency separation between the VFO (top frequency) and LO (bottom frequency). In LOW IF mode this is not needed. I suggest running a sample rate of 2 MHz, larger bandwidths are not needed.



The SDR-Kits patch antenna requires that the RSP(x) Bias-T be enabled. The Bias-T option is enabled within the MAIN panel of SDRuno. See the SDRuno manual located here. https://www.sdrplay.com/docs/SDRplay_SDRuno_User_Manual.pdf view page 17.

With the Bias-T enabled. Set the RSP(x) RF GAIN to max. The RF GAIN slider is located on the MAIN panel. See the SDRuno manual located here. https://www.sdrplay.com/docs/SDRplay_SDRuno_User_Manual.pdf view page 17.

For more information about the RF GAIN settings of the RSP(x) https://www.sdrplay.com/wp-content/uploads/2018/06/Gain_and_AGC_in_SDRuno.pdf

Select the Virtual audio cable as the output in SDRuno, this is selected via the RX Control panel. SETT. button and clicking on the OUT tab.



Have SDRuno's Volume slider (RX Control) at about 35-40%




Upper sideband is recommended but I found the best mode to use for L-Band ACARS or L-Band STD-C decoding is DIGITAL with a filter width of 3k.



Be sure to set a proper step size (right click the RX Control frequency readout). The step size is not important for STD-C transmissions because these signals are only on one frequency for the satellite in your region but L-Band ACARS signals will be on many frequencies. Setting the proper step size will avoid issues when you point and click on signals you want to decode using the JAERO decoder.




You will want to center the signal with a little breathing room within the AUX SP filter passband. The filter slopes are very sharp. Keep the signal centered and away from the extreme edges (red markers).




Select your virtual audio cable within the decoder's audio input preferences.

The Tekmanoid STD-C decoder sound properties are located under Settings in the toolbar menu.




JAERO's sound settings is located under the Tools menu and Settings.



The screenshot displays the SDRplay software interface. At the top, there are controls for Volume, Signal, Quality, SYNC, and CRC. Below this is a 'Statistics' panel showing 'Good Frames' (10), 'Lost Frames' (0), and 'LESEGG Q' (0). A 'Tuner' panel shows a frequency range from 0 to 4 MHz. The main area is a list of detected signals with columns for Date, SigID, Rep, Prio, Service, Address, and P. The list includes various Inmarsat L-Band signals, such as 'NAVAREA I 059', 'NAVAREA I 058', and 'NAVAREA I 057'. A 'Map' panel on the right shows a satellite view of the United Kingdom with red pins indicating the locations of the detected signals.

For STD-C decoding use the frequency from page 8 of this document



For JAERO decoding, I suggest you start in the 1.545 GHz portion and observe the constellation in the JAERO decoder.

The signal to noise ratio (SNR) needed for successful decoding in these decoders will need to be greater than 7dB. When working with a weak satellite signals, try decimating the signal using SDRuno's decimation feature. (MAIN panel, DEC).

<https://youtu.be/zcs7qw1gEDI>

Additional resources

Videos

<https://youtu.be/NWyYVOdlkoU>

<https://youtu.be/uh7ZJDnORus>

<https://youtu.be/mRXWhk9Gf1g>

<https://youtu.be/pp0JxlpN4XA>

SDRuno L-band frequency bank

<https://mega.nz/#!jRFRiSaA!CcmRRRpjToxPzyGV9bf7MkDkKnqCYZCwwjC5curWj6g>

PDFs:

[https://www.inmarsat.com/wp-](https://www.inmarsat.com/wp-content/uploads/2018/08/Aero_Service_External_Com_Kit_I3_to_I4_Transition_21AUG2018.pdf)

[content/uploads/2018/08/Aero Service External Com Kit I3 to I4 Transition 21AUG2018.pdf](https://www.inmarsat.com/wp-content/uploads/2018/08/Aero_Service_External_Com_Kit_I3_to_I4_Transition_21AUG2018.pdf)

[http://seaworm.narod.ru/12/Inmarsat Maritime Handbook.pdf](http://seaworm.narod.ru/12/Inmarsat_Maritime_Handbook.pdf)

Websites

<https://usa-satcom.com/>

<https://uhf-satcom.com/>

I hope this document helps you get started in decoding Inmarsat L-Band transmissions from the I3-F(x) satellites. I am sure I missed some key features, remember this is only a primer/basics to decoding these types of transmissions.

Warmest of 73,
Mike-KD2KOG

SDRPlay modules use a Mirics chipset and software. The information supplied hereunder is provided to you by SDRPlay under license from Mirics. Mirics hereby grants you a perpetual, worldwide, royalty free license to use the information herein for the purpose of designing software that utilizes SDRPlay modules, under the following conditions:

There are no express or implied copyright licenses granted hereunder to design or fabricate any integrated circuits or integrated circuits based on the information in this document. Mirics reserves the right to make changes without further notice to any of its products. Mirics makes no warranty, representation or guarantee regarding the suitability of its products for any particular purpose, nor does Mirics assume any liability arising out of the application or use of any product or circuit, and specifically disclaims any and all liability, including without limitation consequential or incidental damages. Typical parameters that may be provided in Mirics data sheets and/or specifications can and do vary in different applications and actual performance may vary over time. All operating parameters must be validated for each customer application by the buyer's technical experts. SDRPlay and Mirics products are not designed, intended, or authorized for use as components in systems intended for surgical implant into the body, or other applications intended to support or sustain life, or for any other application in which the failure of the Mirics product could create a situation where personal injury or death may occur. Should Buyer purchase or use SDRPlay or Mirics products for any such unintended or unauthorized application, Buyer shall indemnify and hold both SDRPlay and Mirics and their officers, employees, subsidiaries, affiliates, and distributors harmless against all claims, costs, damages, and expenses, and reasonable attorney fees arising out of, directly or indirectly, any claim of personal injury or death associated with such unintended or unauthorized use, even if such claim alleges that either SDRPlay or Mirics were negligent regarding the design or manufacture of the part. Mirics FlexiRFTM, Mirics FlexiTVTM and MiricsTM are trademarks of Mirics .

SDRPlay is the trading name of SDRPlay Limited a company registered in England # 09035244.

Mirics is the trading name of Mirics Limited a company registered in England # 05046393