



BUZZ


BY CHEFMAN

BLUETOOTH ENABLED SINGLE SERVE COFFEE MAKER

USER GUIDE

Now that you have purchased a Chefman® product you can rest assured in the knowledge that as well as your 1-year parts and labor warranty you have the added peace of mind of dedicated helplines and web support.

AFTER SALES SUPPORT

 USA 888-315-6553


 customerservice@chefman.com

MODEL: RJ14-BUZZ-BLACK



READ ALL INSTRUCTIONS BEFORE USE

For your safety and continued enjoyment of this product, always read the instruction manual before using.



CONTENTS

- 1** Introduction
- 2** Safety Instructions
- 4** Features
- 5** Operating Instructions
- 10** User Maintenance
- 11** Terms and Conditions
- 12** Warranty Card

INTRODUCTION

Congratulations !

You have made an excellent choice with the purchase of this quality Chefman® product. By doing so you now have the assurance and peace of mind which comes from purchasing a product that has been manufactured to the highest standards of performance and safety, supported by the high quality standards of Chefman®.

We want you to be completely satisfied with your purchase so this Chefman® product is backed by a comprehensive manufacturer's 1-year warranty and an outstanding after sales service through our dedicated Helpline.

We hope you will enjoy using your purchase for many years to come.

If you require technical support or in the unlikely event that your purchase is faulty please telephone our Helpline for immediate assistance. Faulty product claims made within the 1-year warranty period will be repaired or replaced free of charge provided that you have satisfactory proof of purchase (keep your receipt). This guarantee is in addition to your statutory rights. Your statutory rights are not affected. This limited warranty does not apply in cases of damage caused by accident, improper use, abuse and force majeure.

This warranty gives you specific legal rights. You may have other legal rights that vary depending on where you live. Some states or provinces do not allow limitations on implied warranties or special, incidental, or consequential damages, so the foregoing limitations may not apply to you.

This limited warranty will be invalidated if the appliance is tampered with in any way whatsoever. In case of questions or technical problems please call the following toll-free help line number: 888-315-6553, Monday – Friday 9am to 5pm EST.

If the appliance has to be returned to us, it must be packed correctly as we cannot accept any responsibility for damage caused in transit. We recommend you use a traceable, insured delivery service.

IMPORTANT SAFEGUARDS

SAFETY INFORMATION

This appliance is for **HOUSEHOLD USE ONLY**.

WARNING: When using electrical appliances especially when children are present, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and/or injury to persons, including the following:

1. Read all instructions before use.
2. Do not touch hot surfaces. Use handles or knobs.
3. To protect against fire, electrical shock and injury to persons do not immerse cord, plugs, or the appliance in water or other liquids.
4. Close supervision is necessary when any appliance is used by or near children.
5. Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts and before cleaning the appliance.
6. Do not operate appliance with a damaged cord or plug, or after the appliance malfunctions or has been dropped or damaged in any manner. Call our toll- free customer assistance number for information on examination, repair, or adjustment.
7. The use of accessory attachments not recommended by the appliance manufacturer may result in fire, electric shock or injuries to persons.
8. Do not use outdoors or in a damp area.
9. Do not let cord hang over edge of table or counter, or touch hot surfaces.
10. Do not place on or near a hot gas or electric burner, or in a heated oven.
11. To disconnect the appliance, turn control to off , then remove plug from wall outlet.
12. Do not use this appliance for anything other than its intended use.
13. Scalding may occur if the lid is removed during the brewing cycles.

IMPORTANT SAFEGUARDS (CONT'D)

14. To reduce the risk of fire or electric shock, do not remove the bottom cover on the appliance. No user serviceable parts inside. Call our toll-free customer assistance number for repair.

Warning: Coffee maker is never to be used on a range top.

Warning: Hot steam.

Caution: To reduce the risk of scalding, do not open lid when coffee is brewing.

Warning: To reduce the risk of fire or electric shock, do not remove bottom cover.

No user-serviceable parts inside. Repair should be done by authorized service representative.



Warning: After brewing is finished turn off the appliance.

SAVE THESE INSTRUCTIONS

FEATURES



1. Coffee grounds filter
2. Capsule Receptacle for both K-Cups and Coffee Ground Filter
3. Lid
4. Water shower head
5. Water tank
6. Speaker
7. Volume buttons
8. Brew button
9. Bluetooth button
10. Power button




OPERATING INSTRUCTIONS

USING YOUR COFFEE MAKER

Remove packing materials and read all instructions carefully before use. Before first use, run the machine with water and no coffee to ensure the unit is clean. Do not immerse the unit in water.

Note: You do not need to press the power button to turn on the coffee maker. The power button is for the Bluetooth connectivity.



STEP 1: Place K-Cup or provided permanent coffee ground filter* into receptacle.

STEP 2: Add water to tank located behind capsule receptacle, under water shower head and close lid until you hear a clicking sound. **Important: The amount of water added to the tank is the amount brewed.** Do not fill the water tank above the 14oz marking along the back of the water tank.

STEP 3: Connect unit to power supply.

IMPORTANT: Do not plug in this unit before water is added to tank.

STEP 4: Firmly press the "BREW" button. The brew indicator light will blink while brewing.

*Fill provided coffee ground filter with ground coffee and close until it clicks. Place filter into the receptacle by aligning the "front" of the filter and receptacle facing the user. No filters may be used other than the one provided. May cause injury to persons and damage to the unit.

CAUTION: To avoid potential scalding, do not open the lid while the unit is in operation. We recommend not keeping your unit plugged in overnight or for long periods of time.

OPERATING INSTRUCTIONS [CONT'D]

CONNECTING TO YOUR COFFEE MAKER VIA BLUETOOTH WIRELESS TECHNOLOGY

You can set up the Bluetooth connectivity at any time.

The Buzz coffee maker will work with any device that has Bluetooth capability, including smartphones, tablets, laptops, and computers.

Note: Bluetooth function is completely separate from brewing function. This coffee maker does not brew coffee using Bluetooth and is not app controlled. Bluetooth does not need to be turned on in order to make coffee. See beginning of Operating Instructions on how to brew coffee.

CONNECTING YOUR COFFEE MAKER

STEP 1: Firmly press the Power button until you hear an audible: "Power on." The light underneath the Bluetooth symbol will flash blue while it works to establish a Bluetooth connection.

STEP 2: Open the Bluetooth settings on your device (phone/tablet/computer, etc.)

STEP 3: Make sure Bluetooth is enabled on your device.

STEP 4: Select Chefman Buzz on the Device list. Once the devices are paired, the coffee maker will say audibly: "Connected." The light will remain blue as long as the coffee maker and the device are paired and both devices are turned on.


OPERATING INSTRUCTIONS [CONT'D]

BLUETOOTH SETTINGS INSTRUCTIONS

USING BLUETOOTH ON YOUR COFFEE MAKER

Once connected, you will be able to play music and make/ receive phone calls from your coffee maker.

Press the Bluetooth button (3). Now that you have already set up and connected your device to your coffee maker (as per the direction above), it will automatically start playing music from your device through your coffee maker whenever you have the Bluetooth function working and the 2 devices are connected.



STEP 1: Press the Power button (4).

STEP 2: Press the Bluetooth button (3). It will automatically start playing music from your device through your coffee maker.

Decrease Volume – Firmly press and hold the Decrease Volume (1) button to lower the volume.

Increase Volume – Firmly press and hold the Increase Volume (2) button to turn up the volume.

Note: Volume can also be controlled by your device.

Replay a Song – Tap the Decrease Volume button to replay a track or to play the previous track.

Skip a Song – Tap the Increase Volume button to skip to the next track.

OPERATING INSTRUCTIONS (CONT'D)

MAKING AND RECEIVING CALLS FROM YOUR COFFEE MAKER

Note: You must be connected to Bluetooth to make and receive calls. You will need to remain close to the coffee maker for the duration of the call as it is similar to being on speaker phone – the further away you are from the coffee maker, the harder it will be for the caller to hear you.

Note: If your phone is charging using the USB port, you will still be able to quickly answer using the coffee maker. If you want to switch from Bluetooth to using your phone, we recommend stepping away from the coffee maker so that you don't have interference between the two devices.

RECEIVING PHONE CALLS

Your coffee maker will automatically start ringing when you receive a call (assuming your phone is connected via Bluetooth).

To answer the call, press the Bluetooth button

To end the call, press the Bluetooth button

Set the volume as needed using the Volume Increase/ Decrease buttons on the control panel.

MAKING PHONE CALLS

You will be able to place a call from your smartphone through your coffee maker.

STEP 1: Use your phone to select the contact or dial the number you want to call.

STEP 2: Choose Chefman Buzz from the options of ways to call.

The phone will then ring from your coffee maker directly.

OPERATING INSTRUCTIONS (CONT'D)

DISCONNECTING YOUR COFFEE MAKER

There are several ways to disconnect your Buzz coffee maker.

OPTION 1

Press and hold the Power Button until the coffee maker says, "Power off."

OPTION 2

Press and hold the Bluetooth Button until the coffee maker says "Disconnected."

OPTION 3

Disconnect from your Bluetooth device using the following instructions:

STEP 1: Open the Bluetooth settings on your device.

STEP 2: Find Chefman Buzz on the Device list and select.

STEP 3: Tap Disconnect.

CHARGING YOUR DEVICE USING THE USB PORT

On the right-hand side panel of the coffee maker, you will find a USB port for charging devices. This USB port is meant to charge devices only. It does not connect the device to the coffee maker speaker functions and plugging in the device via the USB port will not allow the device to play music or make/ receive phone calls through the coffee maker.

You do not need to connect the Bluetooth to charge your device.

USER MAINTENANCE

CLEANING YOUR COFFEE MAKER

Proper maintenance will ensure years of service from your appliance. Clean the appliance after every use. This appliance contains no user serviceable parts and requires little maintenance.

Warning: Unplug the appliance and let it cool down completely before cleaning.

Caution: Do not immerse the coffee maker, or the power cord with plug, into water or any liquids. Do not use abrasive pads or alcohol.

- Take out the permanent filter and receptacle from the coffee machine.
- Clean the housing with a clean, damp cloth.
- Use baking soda or a mild cleaning agent to remove stains in the receptacle. If stains are hard to remove, use a more powerful cleaning agent. Do not immerse the unit in water as it will damage the Bluetooth functionality.
- Make sure all parts are completely dry after washing and before use.
- After cleaning, reassemble the coffee maker.

Note: Do not dry the inside of the water tank with a cloth, as lint may remain.

TERMS AND CONDITIONS

LIMITED WARRANTY

CHEFMAN LLC warrants, subject to the conditions stated below, that from the date of purchase, this product will be free from mechanical defects for a period of ONE (1) year. CHEFMAN LLC, at its option, will repair or replace this product found to be defective during the warranty period. Should this product become defective by reason of improper workmanship or material defect during the specified warranty period, CHEFMAN LLC will repair or replace the same effecting all necessary parts replacements for a period of one year from the date of purchase. If product is no longer available we will replace it with a product of equal value. Transportation charges on parts, or products in whole, submitted for repair or replacement, under this warranty, must be borne by the purchaser. This warranty is void if the product is used for other than single-family household use or subjected to any voltage and waveform other than as specified on the rating label (e.g., 120V ~ 60 Hz).

This warranty is available to consumers only. You are a consumer if you own a CHEFMAN® product that was purchased at retail for personal, family or household use. Except as otherwise required under applicable law, this warranty is not available to retailers or other commercial purchasers or owners.

CONDITIONS: This warranty is valid for the original USA and Canada retail purchaser from the date of initial retail purchase and is not transferable. Keep the original sales receipt. Proof of purchase is required to obtain warranty service or replacement. Dealers, service centers, or retail stores do not have the right to alter, modify or in any way, change the terms and conditions of this warranty. Warranty registration is not necessary to obtain warranty on CHEFMAN LLC Products. Save your proof of purchase receipt.

ABOUT YOUR PRODUCT WARRANTY: Most warranty repairs are handled routinely, but sometimes requests for warranty service may not be appropriate. For example, warranty service would NOT apply if the product damage occurred because of misuse, lack of routine maintenance, shipping, handling, 3rd party warehousing or improper installation. Similarly, the warranty is void if the manufacturing date or the serial number on the product has been removed or the equipment has been altered or modified. During the warranty period, the authorized service dealer, at its option, will repair or replace any part that, upon examination, is found to be defective under normal use and service.

NORMAL WEAR: This warranty does not cover normal wear of parts or damage resulting from any of the following: negligent use or misuse of the product; improper voltage or current; use contrary to the operation instructions; deviation from instructions regarding storage and transportation; repair or alteration by anyone other than CHEFMAN LLC or an authorized service center. Further, the warranty does not cover Acts of God, such as fire, flood, hurricanes and tornadoes. CHEFMAN LLC shall not be liable for any incidental or consequential damages caused by the breach of any express or implied warranty. Except to the extent prohibited by applicable law, any implied warranty of merchantability or fitness for a particular purpose is limited in duration to the duration of the above warranty. Some states, provinces or jurisdictions do not allow the exclusion or limitation of incidental or consequential damages or limitations on how long an implied warranty lasts, so the above limitations or exclusion may not apply to you. This warranty gives you specific legal rights, and you may also have other rights that vary from state to state or province to province.

HOW TO OBTAIN WARRANTY SERVICE: If your CHEFMAN® product should prove to be defective within the warranty period, we will repair it, or if we think necessary, replace it. To obtain warranty service, simply email customerservice@chefman.com or call our toll-free number 1-888-315-6553 for additional information from our Customer Service Representatives, or send the defective product to Customer Service at Chefman, 1 Sharp Plaza, Mahwah, NJ 07495.

This warranty is effective for the time periods listed above and subject to the conditions provided for within this policy.

CALIFORNIA RESIDENTS ONLY:

California law provides that for In-Warranty Service, California residents have the option of returning a nonconforming product (A) to the store where it was purchased or (B) to another retail store which sells Chefman products of the same type. The retail store shall then, at its discretion, either repair the product, refer the consumer to an independent repair facility, replace the product, or refund the purchase price less the amount directly attributable to the consumer's prior usage of the product. If the above two options do not result in the appropriate relief to the consumer, the consumer may then take the product to an independent repair facility if service or repair can be economically accomplished. Chefman and not the consumer will be responsible for the reasonable cost of such service, repair, replacement, or refund for nonconforming products under warranty.

CHEFMAN is a registered trademark of PLUS ITS CHEAP, LLC.

WARRANTY CARD

CHEFMAN®

BUZZ SINGLE SERVE COFFEE MAKER

All data fields are required in order for us to process your request:

Model Number: _____

Full Name: _____

Address: _____



Email: (If applicable) _____

Date of Purchase*: _____

*We recommend you keep the receipt with this warranty card

Retail Store of Purchase: _____

Description of Malfunction:

Return your completed warranty card to:

RJ Brands
1 Sharp Plaza
Suite 207
Mahwah, NJ
07495

AFTER SALES SUPPORT



888-315-6553



customerservice@chefman.com

MODEL: RJ14-BUZZ-BLACK

Phone lines available Monday to Friday, 9am-5pm EST

1-YEAR LIMITED WARRANTY



TO LOG-IN TO CLUBCHEFMAN.COM FOLLOW THE BELOW STEPS:

1. Enter www.clubchefman.com into your web browser.
2. Click on "Sign Up Now".
3. Fill in the required information as prompted.
NOTE: "Place of Purchase" refers to the store at which you purchased your product.
4. Sign in using your User Name and Password.

CLUB CHEFMAN ACCESS CODE:

2131452

CHEFMAN®

Follow Us



RJBRANDS.COM | CLUBCHEFMAN.COM | CHEFMAN.COM