





# Compact<sup>™</sup> High Speed Counter Module

(Catalog Number 1769-HSC)

**User Manual** 



**Important User Information** Because of the variety of uses for the products described in this publication, those responsible for the application and use of this control equipment must satisfy themselves that all necessary steps have been taken to assure that each application and use meets all performance and safety requirements, including any applicable laws, regulations, codes and standards.

The illustrations, charts, sample programs and layout examples shown in this guide are intended solely for purposes of example. Since there are many variables and requirements associated with any particular installation, Allen-Bradley does not assume responsibility or liability (to include intellectual property liability) for actual use based upon the examples shown in this publication.

Allen-Bradley publication SGI-1.1, *Safety Guidelines for the Application, Installation and Maintenance of Solid-State Control* (available from your local Allen-Bradley office), describes some important differences between solid-state equipment and electromechanical devices that should be taken into consideration when applying products such as those described in this publication.

Reproduction of the contents of this copyrighted publication, in whole or part, without written permission of Rockwell Automation, is prohibited.

Throughout this manual we use notes to make you aware of safety considerations:

## ATTENTION



Identifies information about practices or circumstances that can lead to personal injury or death, property damage or economic loss

Attention statements help you to:

- identify a hazard
- avoid a hazard
- recognize the consequences



Identifies information that is critical for successful application and understanding of the product.

Allen-Bradley, Compact, MicroLogix, CompactLogix, RSLogix and RSNetworx are trademarks of Rockwell Automation. Belden is a trademark of Belden, Inc.

Preface	Who Should Use This ManualHow to Use This ManualConventions Used in This ManualRockwell Automation Support	P-1 P-1 P-2 P-3
Module Overview	Chapter 1 Module Overview	1-1 1-3
Module Operation	Chapter 2         Counter Defaults.         Module Operation Block Diagrams         Number of Counters         Summary of Available Counter Configurations         Input Filtering.         Operational Mode Selection.         Input Frequency         Counter Types         Modifying Count Value         Rate/Timer Functionality         Output Control	2-1 2-2 2-4 2-4 2-6 2-7 2-14 2-14 2-15 2-18 2-23
Installation and Wiring	Chapter 3         Compliance to European Union Directives         Power Requirements         General Considerations         System Assembly         Mounting         Replacing the Module within a System         Field Wiring Connections	3-1 3-2 3-6 3-7 3-10 3-11
Module Configuration, Output, and Input Data	Chapter 4 Configuring the Module. Configuration Array. Output Array Input Array.	4-1 4-2 4-21 4-31
Diagnostics and Troubleshooting	Chapter 5         Safety Considerations         Module Operation vs. Counter Operation.         Counter Defaults.         Module Diagnostics.         Non-Critical vs. Critical Module Errors         Module Error Definition         Error Codes         Contacting Rockwell Automation	5-1 5-3 5-4 5-5 5-5 5-8 5-14

## **Specifications**

1769-HSC Module with

1769-HSC Module with

MicroLogix 1500 Controllers and an Allen-Bradley 845F Encoder

**Programming Quick Reference** 

**CompactLogix Controllers and an** 

Allen-Bradley 845F Encoder

## **Appendix A**

General Specifications	A-1
Input Specifications	A-2
Output Specifications	A-2
Throughput and Timing	A-3
Rate Accuracy	A-3
Temperature Derating	A-4

# Appendix **B**

System Diagram	B-1
845F Encoder Wiring to the 1769-HSC	B-1
Purpose	B-2
Scope	B-2
Adding a 1769-HSC High Speed Counter Module into a	
CompactLogix System	B-2
Configuring Your 1769-HSC Module	B-6
Monitoring the Current Count Value and Verifying Output	
Operation H	3-10

# **Appendix C**

System Diagram	C-1
845F Encoder wiring to the 1/09-HSC	C-1
Purpose	C-2
	C-2
Adding a 1/69-HSC High Speed Counter Module into a	~ ~
MicroLogix 1500 System	C-2
Configuring Your 1769-HSC Module	C-5
Monitoring the Current Count and	
Verifying Output Operation	C-8

# **Appendix D**

••	
Configuration Array.	D-2
Output Array	D-4
Input Array	D-5

#### Index

Read this preface to familiarize yourself with the rest of the manual. This preface covers the following topics:

- who should use this manual
- how to use this manual
- related publications
- conventions used in this manual
- Rockwell Automation support

Who Should Use This<br/>ManualUse this manual if you are responsible for designing, installing,<br/>programming, or troubleshooting control systems that use<br/>Allen-Bradley Compact™ I/O and/or Micrologix™ 1500 or<br/>CompactLogix™ controllers.

**How to Use This Manual** As much as possible, we organized this manual to explain, in a task-by-task manner, how to install, configure, program, operate and troubleshoot a control system using the 1769 High Speed Counter modules.

## **Manual Contents**

If you want	See
An overview of the module	Chapter 1
A description of module operation, including counters, inputs, and outputs.	Chapter 2
Installation and wiring guidelines	Chapter 3
Module addressing, configuration and status information	Chapter 4
Information on module diagnostics and troubleshooting	Chapter 5
Specifications	Appendix A
Programming and Configuration for CompactLogix	Appendix B
Programming and Configuration for MicroLogix 1500	Appendix C
Programming Quick Reference	Appendix D

#### **Related Documentation**

The table below provides a listing of publications that contain important information about Compact I/O, CompactLogix, and MicroLogix 1500 systems.

For	Read this document	Document number
A user manual containing information on how to install, use and program your MicroLogix 1500 controller	MicroLogix™ 1500 User Manual	1764-UM001A-US-P
A user manual containing information on how to install, use, and program your CompactLogix processor.	CompactLogix™ User Manual	1769-UM007C-EN-P
A user manual containing information on how to install, and use your 1769-ADN DeviceNet Adapter.	DeviceNet Adapter User Manual	1769-UM001A-US-P
An overview of 1769 Compact Discrete I/O modules	1769 Compact Discrete Input/Output Modules Product Data	1769-2.1
An overview of the MicroLogix 1500 System, including 1769 Compact I/O.	MicroLogix™ 1500 System Overview	1764-SO001B-EN-P
In-depth information on grounding and wiring Allen-Bradley programmable controllers.	Allen-Bradley Programmable Controller Grounding and Wiring Guidelines	1770-4.1

If you would like a manual, you can:

- download a free electronic version from the internet at **www.theautomationbookstore.com**
- purchase a printed manual by:
  - contacting your local distributor or Rockwell Automation representative
  - visiting **www.theautomationbookstore.com** and placing your order
  - calling 1.800.963.9548 (USA/Canada) or 001.330.725.1574 (Outside USA/Canada)

# Conventions Used in This Manual

The following conventions are used throughout this manual:

- Bulleted lists (like this one) provide information not procedural steps.
- Numbered lists provide sequential steps or hierarchical information.
- *Italic* type is used for emphasis.
- Text in this font indicates words or phrases you should type.

# Rockwell Automation Support

Rockwell Automation offers support services worldwide, with over 75 Sales/Support Offices, 512 authorized distributors and 260 authorized Systems Integrators located throughout the United States alone, plus Rockwell Automation representatives in every major country in the world.

## **Local Product Support**

Contact your local Rockwell Automation representative for:

- sales and order support
- product technical training
- warranty support
- support service agreement

## **Technical Product Assistance**

If you need to contact Rockwell Automation for technical assistance, please review the information in Chapter 5, Diagnostics and Troubleshooting first. Then call your local Rockwell Automation representative.

#### Your Questions or Comments on the Manual

If you find a problem with this manual, please notify us. If you have any suggestions for how this manual could be made more useful to you, please contact us at the address below:

Rockwell Automation Automation Control and Information Group Technical Communication, Dept. A602V P.O. Box 2086 Milwaukee, WI 53201-2086

# **Module Overview**

This chapter contains the following:

- module overview
- hardware features

The 1769-HSC is an intelligent counter module with its own microprocessor and I/O that is capable of reacting to high speed input signals. The module can interface with up to 2 channels of quadrature or 4 channels of pulse/count inputs. The signals received at the inputs are filtered, decoded, and counted. They are also processed to generate rate and time-between-pulses (pulse interval) data. Count and rate values can then be used to activate outputs based on user-defined ranges.

The module counts pulses at up to 1 MHz from devices such as proximity switches, pulse generators, turbine flowmeters, and quadrature encoders. The module has four on-board high speed switching outputs. These outputs can be under user program or direct module control, based on the count value or frequency.

The module is compatible with MicroLogix<sup>TM</sup> 1500<sup>(1)</sup> packaged controllers, CompactLogix<sup>TM(2)</sup> modular PLCs, and the Series B<sup>(3)</sup> 1769-ADN DeviceNet Adapter.

# Counters

The module is capable of counting pulses in either direction (forward/reverse, up/down, etc.). A maximum of four pulse counters (or 2 quadrature counters) are available. Each 32-bit counter can count to  $\pm 2$  billion as a ring or linear counter. In addition to providing a count value, the module provides a rate value up to  $\pm 1$  MHz, dependent upon the type of input. The rate value (as modified by scalar) is the input frequency to the counter. When the count value is increasing, the rate value is positive. When the count value is decreasing, the rate value is negative.

- (1) 1764-LSP and 1764-LRP Series C, Firmware revision 6.0 and higher.
- (2) Firmware versions prior to 11.0 require the use of Generic Profiles.
- (3) Available Spring 2002.

# **Module Overview**

Counters can also be reset or preset to any value between user-defined minimum and maximum values. Preset can be accomplished from the user program or at a Z input event. The Z input can also generate a capture value and/or freeze (gate) the counters.

#### Inputs

The module features six high-speed differential inputs labeled  $\pm A0$ ,  $\pm B0$ ,  $\pm Z0$ ,  $\pm A1$ ,  $\pm B1$ , and  $\pm Z1$ . These inputs support 2 quadrature encoders with ABZ inputs and/or up to 4 discrete count inputs. In addition, x1, x2, and x4 encoder configurations are provided to fully use the capabilities of high resolution quadrature encoders. The inputs can be wired for standard differential line driver output devices, as well as single-ended devices such as limit switches, photo eyes, and proximity sensors. Inputs are optically isolated from the bus and from one another, and have an operational range of 2.6 to 30V dc.

#### Outputs

Sixteen outputs are available: four on-board (real) and twelve virtual bits. All 16 outputs can be individually controlled by the module or by the user control program.

The 4 on-board (real) outputs are dc sourcing, powered by a user-supplied (5 to 30V dc) power source. These outputs are electronically protected from current overloads and short circuit conditions. Overcurrent status is monitored and fed back to the user program. Output states are determined by a combination of output data, configuration data, ranges, and overcurrent status.

See Output Control on page 2-23 for a description of how the module determines output status.

# **Hardware Features**

The module's hardware features are illustrated below. Refer to Chapter 3 for detailed information on installation and wiring.

#### Figure 1.1 Hardware Features



ltem	Description
1	bus lever
2a	upper panel mounting tab
2b	lower panel mounting tab
3	module status LEDs (6 Input, 4 Output, 1 Fuse, 1 OK)
4	module door with terminal identification label
5a	movable bus connector (bus interface) with female pins
5b	stationary bus connector (bus interface) with male pins
6	nameplate label
7a	upper tongue-and-groove slots
7b	lower tongue-and-groove slots
8a	upper DIN rail latch
8b	lower DIN rail latch
9	write-on label for user identification tags
10	removable terminal block (RTB) with finger-safe cover
10a	RTB upper retaining screw
10b	RTB lower retaining screw

# LEDs

The front panel has a total of twelve indicator LEDs, as shown in Figure 1.1 on page 1-3.

+OUT	0 2 FUSE 1 3 OK	$\Big]$
	A0 B0 Z0 A1 B1 Z1 High Speed Counter	

#### Table 1.1 Diagnostic Indicators

LED	Color	Indicates
0 OUT	Amber	ON/OFF logic status of output 0
1 OUT	Amber	ON/OFF logic status of output 1
2 OUT	Amber	ON/OFF logic status of output 2
3 OUT	Amber	ON/OFF logic status of output 3
FUSE	Red	Overcurrent
OK Off		No power is applied.
	Red (briefly)	Performing self-test.
	Solid Green	OK, normal operating condition.
	Flashing Green	OK, module in Program or Fault mode.
	Solid Red or Amber	Hardware error. Cycle power to the module. If problem persists, replace the module.
	Flashing Red	Recoverable fault. Reconfigure, reset, or perform error recovery. See section on page 5-5, Non-Critical vs. Critical Module Errors. The OK LED flashes red for all of the error codes in Table 5.6.
A0	Amber	ON/OFF status of input A0
A1	Amber	ON/OFF status of input A1
BO	Amber	ON/OFF status of input B0
B1	Amber	ON/OFF status of input B1
Z0	Amber	ON/OFF status of input Z0
Z1	Amber ON/OFF status of input Z1	
ALL ON	<ul> <li>Possible causes for all LEDs to be on:</li> <li>Bus Error has occurred: Controller hard fault. Cycle power.</li> <li>During Flash Upgrade of Controller: Normal. Do not cycle power during the Flash Upgrade.</li> <li>All LEDs will flash on briefly during power up. This is permaled.</li> </ul>	

# **Module Operation**

This chapter contains information about:

- counter defaults
- module operation block diagrams
- number of counters
- input filtering
- input operational mode
- modifying count value or input signals
- counter types
- rate/timer functionality
- output control
- safe state control

# **Counter Defaults**

When the module powers-up, all Output Array and Configuration Array values are set to their default values (see Chapter 4 or Appendix D for default values). All Input Array values are cleared. None of the module data is retentive through a power cycle.

In effect, this means that power cycling clears the module:

- stored counts and configurations are lost
- faults and flags are cleared
- outputs are off

# Module Operation Block Diagrams

To provide an overview of the module operation, the block diagrams indicate relationships between module functions and configuration parameters.

## Inputs

The following diagram illustrates how the inputs function.



## **Outputs**

The following diagram illustrates how the outputs function.



# **Number of Counters**

The module has six input points: A0, B0, Z0, A1, B1, and Z1. Through these inputs, the module can function with 1, 2, 3, or 4 counters depending upon the number of counters and the operational mode configuration of the input points.

# Summary of Available Counter Configurations

The table below summarizes the input configurations available for all counters, based on the number of counters.

Number of Counters	Counter	Operational Mode	Gate or Preset Functionality
1 Counter	0	Any	All
I Counter	1 through 3	Not available	·
	0	Any	All
2 Counters	1	Any	All
	2 and 3	Not Available	
	0	Any	All
2 Countors	1	Pulse/Internal Direction	All
5 Counters	2	Pulse/Internal Direction	None
	3	Not available	•
4 Counters	0	Pulse/Internal Direction	All
	1	Pulse/Internal Direction	All
	2	Pulse/Internal Direction	None
	3	Pulse/Internal Direction	None

The counter options and operating modes are summarized in Figure 2.1.





(1) The number of counters is defined by the NumberOfCounters bits in word 0 of the Configuration Array.

# **Input Filtering**

In many industrial environments, high frequency noise can be inadvertently coupled to the sensor wires. The module can help reject some noise by means of built-in filters. Inputs are filtered by means of user-selectable, low-pass filters<sup>(1)</sup> set up during module configuration.

The available nominal pulse width filters are:

#### **Table 2.1 Available Filters**

Input	Filter
A0, A1, B0, B1, Z0, Z1	5 ms, 500 µs, 10 µs, no filter

The filters are selected for each input in the Filter Selection word of the Module Configuration Array.



The input state bits (InputStateA0 through InputStateZ1) reflect the filter's inputs, but are NOT affected by the signal inhibit or invert operations described on page 2-7.

#### **Table 2.2 Filter Pulse Width and Frequency**

Nominal Filter Settings		Maximum Guarante Width	ed Blocked Pulse	Minimum Guaranteed Pass Pulse Width			
Pulse Width	Equivalent Frequency <sup>(1)</sup>	Pulse Width	Equivalent Frequency <sup>(1)</sup>	Pulse Width	Equivalent Frequency <sup>(1)</sup>		
no filter	1 MHz	n/a	n/a	250 ns	2 MHz		
10 µs	50 kHz	7.4 µs	67.5 kHz	25 µs	20 kHz		
500 µs	1 kHz	370 µs	1.35 kHz	1.25 ms	400 Hz		
5 ms	100 Hz	3.7 ms	135 Hz	12.5 ms	40 Hz		

(1) Equivalent frequency assumes a perfect 50% duty cycle and are for reference purposes only. Hence, the no-filter setting is guaranteed to pass 4 MHz even though the module's maximum is 1 MHz. This allows the sensor and wiring to attenuate the pulse to 25% duty cycle while the module maintains pulse recognition.

IMPORTANT

The built-in filters are simple, averaging, low-pass filters. They are designed to block noise pulses of width equal to the values presented in Table 2.2. Applying full amplitude, 50% duty cycle signals that are of frequency above the selected filter's threshold frequency may result in an average value signal of sufficient amplitude to turn the input on. A transition from no input to the full amplitude, 50% duty cycle signal (or back to no signal) may result in inadvertent input transitions.

<sup>(1)</sup> Low-pass filters block frequencies above the threshold frequency.

# Operational Mode Selection

A count channel's operational mode configuration selection determines how the A and B inputs cause a counter channel to increment or decrement. The six available mode selections are:

- Pulse/External Direction Input
- Pulse/Internal Direction Input
- Up and Down Pulse Input
- X1 Quadrature Encoder Input
- X2 Quadrature Encoder Input
- X4 Quadrature Encoder Input

```
IMPORTANT The operational mode selection is limited by the number of counters selected.With 2 counters selected, Counters 0 and 1 can be assigned any operational mode.
```

- With 3 counters selected, Counter 0 can be assigned any mode, but Counters 1 and 2 can only be configured as pulse/internal direction.
- With 4 counters selected, all counters must be configured for the pulse/internal direction mode.

See the Figure 2.1 on page 2-5 for the operational modes available for the counters, based on the number of counters configured.

## **Direction Inhibit and Direction Invert Output Control Bits**

These bits apply to all of the counter modes.



When set, the Direction Inhibit bit disables any physical input from affecting count direction.

When set, the Direction Invert bit changes the direction of the counter in all operational modes.

When Direction Inhibit is set, then Direction Invert *is* the direction.

## **Pulse/External Direction Mode Selection**

In this mode, the B input controls the direction of the counter, as shown in Figure 2.2 on page 2-8. If the B input is low (0), the counter increments on the rising edges of input A. If the input B is high (1), the counter decrements on the rising edges of input A.



Two Output Control bits allow you to modify the operation of the B input from your control program or during configuration. The Direction Inhibit bit, when set (1), disables the operation of the B input.

The Direction Invert bit, when set (1), reverses the operation of the B input, but only if the Direction Inhibit bit is not set. If the Direction Inhibit bit is set, then the Direction Invert bit controls counter direction.

When the Direction Inhibit bit is set (1):

- and Direction Invert = 0, count direction is up (forward)
- and Direction Invert = 1, count direction is down (reversed)

#### Figure 2.2 Pulse/External Direction Mode (Direction Inhibit = 0, Direction Invert = 0)



Direction Inhibit Bit	Direction Invert Bit	Input A (Count)	Input B (Direction)	Change in Count Value
0	0	$\uparrow$	0 or open	+1
		$\uparrow$	1	-1
		0, 1, ↓	don't care	0
0	1	$\uparrow$	0 or open	-1
		$\uparrow$	1	+1
		0, 1, ↓	don't care	0
1	0	$\uparrow$	0 or open	+1
		$\uparrow$	1	+1
		0, 1, ↓	don't care	0
1	1	$\uparrow$	0 or open	-1
		$\uparrow$	1	-1
		0, 1, ↓	don't care	0

Table 2.3 Pulse External Direction Counting

See Direction Inhibit and Direction Invert Output Control Bits page 2-7 for more information.

# **Pulse/Internal Direction Mode Selection**

When the Pulse/Internal Direction mode is selected, the status of the Direction Invert bit, as controlled by the user program, determines the direction of the counter. The counter increments on the rising edge of the module's A input when the Direction Invert bit is reset (0). The counter decrements on the rising edge of the A input when the Direction Invert bit is set (1).

 Table 2.4 Pulse Internal Direction Counting - Counters 0 and 1

Direction Inhibit Bit	Direction Invert Bit	Input A (Count)	Input B	Change in Count Value
don't care	0	$\uparrow$	don't care	+1
		0, 1, ↓	don't care	0
don't care	1	$\uparrow$	don't care	-1
		0, 1, ↓	don't care	0

Direction Inhibit Bit	Direction Invert Bit	Input A	Input B (Count)	Change in Count Value
don't care	0	don't care	$\uparrow$	+1
		don't care	0, 1, ↓	0
don't care	1	don't care	$\uparrow$	-1
		don't care	0, 1, ↓	0

Table 2.5 Pulse Internal Direction Counting - Counters 2 and 3

# **Up and Down Pulses Mode Selection**

In this mode, the counter channel increments on the rising edge of pulses applied to input A and decrements on the rising edge of pulses applied to input B. When set, the Direction Inhibit bit causes both A and B to increment. When set, the Direction Invert bit causes B to increment and A to decrement. When the Direction Invert and Direction Inhibit bits are both set, both A and B decrement.



When both inputs transition simultaneously or near simultaneously, the net result is no change to the count value.

#### Figure 2.3 Up and Down Pulse Mode (Direction Inhibit = 0, Direction Invert = 0)



Direction Inhibit Bit	Direction Invert Bit	Input A (Count)	Input B (Direction)	Change in Count Value
0	0	$\uparrow$	0, 1, ↓	+1
		0, 1, ↓	↑	-1
		$\uparrow$	↑	0
0	1	$\uparrow$	0, 1, ↓	-1
		0, 1, ↓	↑	+1
		$\uparrow$	↑	0
1	0	$\uparrow$	0, 1, ↓	+1
		0, 1, ↓	1	+1
		$\uparrow$	1	0
1	1	$\uparrow$	0, 1, ↓	-1
		0, 1, ↓	$\uparrow$	-1
		$\uparrow$	1	0

Table 2.6 Up and Down Counting

## X1 Quadrature Encoder Mode Selection

In this mode, when a quadrature encoder is attached to inputs A and B, the count direction is determined by the phase relation of inputs A and B. If A leads B, the counter increments. If B leads A, the counter decrements. In other words, when B is low, the count increments on the rising edge of input A and decrements on the falling edge of input A. If B is high, all rising transitions on input A are ignored. The counter changes value *only* on one edge of input A as shown in Figure 2.4.



When both A and B transition at the same time, instead of in the defined 90° phase separation, the quadrature signal is invalid.

See also: Direction Inhibit and Direction Invert Output Control Bits on page 2-7 and their effect on Quadrature signals on page 2-13.



#### Figure 2.4 Quadrature Encoder Modes (Direction Inhibit = 0, Direction Invert = 0)

#### **X2 Quadrature Encoder Mode Selection**

The X2 Quadrature Encoder mode operates much like the X1 Quadrature Encoder except that the resolution is doubled as shown in Figure 2.4 on page 2-12.

## X4 Quadrature Encoder Mode Selection

The X4 Quadrature Encoder mode operates much like the X1 Quadrature Encoder except that the resolution is quadrupled as shown in Figure 2.4 on page 2-12.

The following diagram shows how Direction Inhibit and Direction Invert affect the counter.

								_			A	•		, ,	 Inpu	t A								
			[	Juac	Irati	ure					В				nput	t B		1 1 1						
				Enc	code	er					Z			-0 	npu	t Z		- - -						
	_													<u>-</u> 0 ·				1						
	-orv	ward	1 KO 	tatio	on A		]				]			Rev	erse	KO ]	tatio	n						]
A					1		   		1		   				_	Y		1	_	·		- - -	_	• •
В —			1 1 1		   		1 1 1		1 1 1		1 1 1			-		1 1 1		1 1 1		   		1 1 1		1 1
- - - -		1 1 1		1 1 1		1 1 1		i i	1 1	I I I	, 1 1	1 1 1			1 1 1		1		1		1		1	1 1 1
DirectionInhibit = 0;	Dire	ectic	inln <sup>ı</sup>	vert	= 0		   		   	1 1 1	   			1 1 1		   		 				   	· · · · · · · · · · · · · · · · · · ·	   
	1	, , ,	1 1 1	- - - -	'2 		1		'3 		1 1 1			1 1 1		2		r r r	- - - -	·1 	- - - -	1 1 1	- - - -	0
X1 Count Pulse –	1	   	2	   	3	   	4	   	5	   	6			5	   	4	1 1 1	3	   	2	   	<u>.</u> 1	   	0 1
X2 Count Pulse		1 1 1		1 1 1		1 1 1		1 1 1		1 1 1		1 1 1	     		1 1 1		1 1 1		1 1 1		1 1 1		1 1 1	
	1	2	3	4	5	6	7	8	9 	10 	11 	12 	11 	10 	'9 	8	7 	6	5	4	3 	2	¦1 	0
X4 Count Pulse										-		-					-				-			
DirectionInhibit = 0;	Dire	ectic	่ทไท ่	vert	= 1	   	- 	   		1 1 1	1		1 1 1	1		-	-	   	1		   	1 1 1	1 1 1	<b>r</b> 1
ĺ	0	     	1 1 1	- - -	) 		1 1 1		4		1 1 1		1 1 1	1 1 1	- - - -	5	- - -	1 1 1	- - - -		- - - -	1 1 1		Í
X1 Count Pulse	6	1 1 1	5	1 1 1	4	1 1 1	3	1 1 1	2	I I I	1	1 1 1	1 1 1	2	1 1 1	3	1 1 1	4	1 1 1	5	1 1 1	6	1	7
X2 Count Pulse		   		   		   		   		1 1 1		-	1 1 1		1		1		1 1		1 1 1	Ļ	1 1 +	
	6	5	- 4 	3	2	 	• 0 	-1 	'-2 	-3 	-4 	-;5 	-4	-3 	-2 	1 	¦0 	-1 	2	3	4	5 	6	'7 
X4 Count Pulse			_		-					-		-	1		-				-		-			-
DirectionInhibit = 1;	Dire 1	ctic	onlnı '	vert	0 ;2	1 1 1	1 1 1	1 1 1	3	1 1 1	, , , ,				1 1 1	4	1	     	1 1 1	5	1 1 1		1 1 1	6
		   	ı ı	, , ,		, , ,	1	, , ,			1			1	, , ,		, , ,	1 1 1				1 1	, , ,	
	1	1 1 1	2	1 1 1	3 	1 1 1	4 	1 1 1	5	1 1 1	6	1 1 1		7	1 1 1	8	1	9	1 1 1	10 I	1 1 1	11 1	1 1 - 1 1	12 
X2 Count Pulse	4									1		1	40		1		1 1 14 <b>7</b>		1		- -			
V4 Count Dulos	1		3	4	3		Ĺ	8	9		11		13		15	10	17	18	19	20	21		23	∠4 
		!	<u> </u>	-	   	-	<u> </u>	-	• 	-	• •	-	1		-	• 	1	• 	-	• •	-	+ 		+ 
DirectionInhibit = 1;	Dire 18	etic	inlm ¦	γert ¦	= 1   <b>17</b>	1 1 1	- - - -	1 1 1	16	1 1 1		- - -	1	- - - -	1 1 1	15	- - -	- - 	1 1 1	14	1 1 1 1	- - - -	1 1 1	13
X1 Count Pulse		   	1 1 1	1 1 1		1 1	1 1 1	1 1		1 1	1 1 1	1 1	1 1 1	1 1	1		1	1 1 1	1		1	1 1 1	1 1 1	
	16	1 1 1	15 	1 1 1	14 	1 1 1	13 	1 1 1	12 	I I I	11 	1 1 1	   	10 	1 1 1	9	1	8	1 1 1	7	1 1 1	6	1 1 1	5
X2 Count Pulse	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	  -1	-2	-3	-4	  -5	-6	 -7
X4 Count Pulse																								

#### Figure 2.5 Operation Using Various Direction Inhibit and Direction Invert Settings

# **Input Frequency**

Maximum input frequency is determined by the input configuration as shown in the table below.

Input Configuration	Input Frequency
X4 Quadrature Encoder	250 kHz
X2 Quadrature Encoder	500 kHz
All Other Configurations	1 MHz

See Table 2.2 for additional details.

# **Counter Types**

Each of the four possible counters can be configured to stop counting and set a flag at its limits (linear counter) or to roll over and set a flag at its limits (ring counter). A counter's limits are programmed by the Ctr*n*MaxCount and Ctr*n*MinCount words in the Module Configuration Array. Both types are described below.

# **Linear Counter**

The figure below describes linear counter operation. In linear operation, the current count (Ctr[n].CurrentCount) value remains between, or equal to, the user-programmed minimum count (CtrnMinCount) and maximum count (CtrnMaxCount) values. If the Ctr[n].CurrentCount value would go above (>) or below (<) these values, the counter stops counting, and an overflow/underflow bit is set. The overflow/underflow bits can be reset using the CtrnResetCounterOverflow and CtrnResetCounterUnderflow bits.

#### Figure 2.6 Linear Counter Diagram



Pulses are not accumulated in an overflow/underflow state. The counter begins counting again when pulses are applied in the proper direction. For example, if you exceed the maximum by 1,000 counts, you do not need to apply 1,000 counts in the opposite direction before the counter begins counting down. The first pulse in the opposite direction decrements the counter.

#### **Ring Counter**

Figure 2.7 demonstrates ring counter operation. In ring counter operation, the current count (Ctr[*n*].CurrentCount) value changes between user-programmable minimum count (Ctr*n*MinCount) and maximum count (Ctr*n*MaxCount) values. If, when counting up, the counter reaches the Ctr*n*MaxCount value, it rolls over to the Ctr*n*MinCount value upon receiving the next count and sets the overflow bit. If, when counting down, the counter reaches the Ctr*n*MinCount value, it rolls under to the Ctr*n*MaxCount value upon receiving the next count and sets the ctr*n*MinCount value, it rolls under to the Ctr*n*MaxCount value upon receiving the next count and sets the underflow bit. These bits can be reset using the Ctr*n*ResetCounterOverflow and Ctr*n*ResetCounterUnderflow bits.

#### Figure 2.7 Ring Counter Diagram



## **Modifying Count Value**

The count value (Ctr[*n*].CurrentCount) can be stored, reset, or preset using the Z input, CtrReset bit in the Configuration Array, control bits in the Output Array, or written over using a Direct Write command.

#### **Table 2.7 Available Z Functions**

Setting	For function
Store <sup>(1)</sup>	on rising edge of Z, store count in the Stored Count input word
Hold	while Z = 1, hold counter at its current value
Preset/Reset	on rising edge of Z, preset the count value to the value in the preset word

 If both a store and preset function are configured, the stored count is captured before the preset operation takes place.

#### IMPORTANT

Because only the Z inputs are used for external gating and presetting, these functions are not available for Counters 2 and 3, which do not have Z inputs. All options are always available for Counters 0 and 1, regardless of input operational mode.

## **Counter Enable/Disable**

The counter may be enabled or disabled using the Ctr*n*En control bit. Be aware that disabling the counter does not inhibit any current count loading functions (e.g. preset or direct write) or any Z function.

## **Z Input Functions**

#### Store

The Z input can be used to capture the current count value even when the counter is counting at full 1 MHz speed.

#### Gate

The Z inputs can be used to gate (hold) the counter at its current value regardless of incoming A or B inputs. A gating function is typically one that allows pulses to reach the counter (gate open) or not (gate closed).

#### Z Preset

Preset can be programmed to occur based on the actions of the Z input signal.

## **Inhibit and Invert**

The Z input signals may be inverted and/or inhibited, depending on the user configuration of the Ctr*n*ZInvert and Ctr*n*ZInhibit output control bits. If the signal is inhibited, the invert bit *is* the Z signal for the actions described above.

For an explanation of those bits, see Z Inv - Z Invert (CtrnZInvert) on page 4-25 and Z Inh - Z Inhibit (CtrnZInhibit) on page 4-25.

#### **Direct Write**

You can arbitrarily change the current count value (Ctr[*n*].CurrentCount) to the direct write control value (Range12To15[*n*].HiLimOrDirWr). This ability applies to ranges 12 through 15. The direct write value takes effect when the Load Direct Write bit (Range12To15[*n*].LoadDirectWrite) transitions from 0 to 1.

If you attempt to preset and load direct write to a counter at the same time, only the preset (Ctr*n*Preset) will take effect.

#### **Preset/Reset**

Preset sets the counter to a zero or non-zero value you define. Reset the counter by setting this value (Ctr nPreset) to zero.

#### Counter Reset

The CtrReset bit in the Configuration Array, when set, causes the following to occur when the system transitions to Run or the Inhibit Module bit transitions to 0:

- All counters are disabled and reset to zero.
- The Output Array is reset to default values until the ModConfig bit is set (1). The default value for the Output Array is all zeros.
- The Input Array counter Status Flags (Overflow, Underflow, RisingEdgeZ, RateValid, PresetWarning) are reset.
- The Input Array counter values (Current Count<sup>(1)</sup>, StoredCount, CurrentRate and PulseInterval) are also reset to zero.
- All counts are lost and all outputs are turned off.

IMPORTANT	For the most predictable results, you may want to clear the output image of the processor BEFORE performing a counter reset (CtrReset) to the 1769-HSC module.
	This is because CtrReset does not change the processor's output image. CtrReset sets the 1769-HSC module's Output Array to all zero's. If any bit is set to 1 in the processor's output image, when sent to the module, it will be seen as a state transition and be acted upon.

#### Soft Preset

Preset can be programmed to occur by setting the appropriate output control bits via your control program. Setting the CtrnSoftPreset bit in the Output Array causes the counter to be preset, changing the count to the value in CtrnPreset.

If zero is outside the MinCount and MaxCount limits set in the Configuration Array, then the Preset value is loaded into CurrentCount instead of zero. This also causes the PresetWarning bit to be set, which, in turn, sets the GenError bit.

#### Z Preset

Preset can be programmed to occur based on the actions of the Z input signal.

#### Autopreset

If the module is configured such that Ctr*n*MaxCount < Ctr[*n*].CurrentCount or Ctr*n*MinCount > Ctr[*n*].CurrentCount, then the module will automatically change Ctr[*n*].CurrentCount to the Ctr*n*Preset value and set the Ctr*n*PresetWarning bit.

## **Rate/Timer Functionality**

To ensure maximum accuracy, the module offers two different methods to calculate the rate:

- Per Pulse = 1/Pulse Interval
- Cyclic = Number of Pulses/User-Defined Time Interval

You select the method used, depending upon the pulse speed as defined below. These are continuously available regardless of input operational mode.

## **Pulse Interval Rate Calculation Method**



The pulse interval rate method is very accurate for slower rates, i.e. when the pulse interval (or time between pulses) is large compared to the system clock timer (1  $\mu$ s). A timer is used to measure the time between two successive pulses. The inverse of this value is the pulse interval rate. The pulse interval rate cannot be read directly from the module. It needs to be calculated. The calculation can be performed in the user control program.

This method is not as accurate for higher pulse rates. When the pulse interval shrinks, two factors can distort the per pulse calculation. If the pulse interval is close to the measuring timer's clock frequency, 1 MHz, the granularity of the time increments has a greater effect on rate inaccuracy. In addition, the rate may be calculated many times over the course of a single backplane scan. As a result, the rate data

obtained at a backplane scan is only that of the very last pair of pulses and disregards the other rate calculations that may have occurred during that interval. This can result in rate inaccuracy if the pulses are unevenly spaced.

## **Cyclic Rate Calculation Method (Current Rate)**

The module continuously calculates rates for each of its four possible counters, regardless of operational mode (e.g. up/down count). The 32-bit signed integer rate from each counter is reported in the Ctr[*n*].CurrentRate words of the Input Array.

In this method, the rates are calculated at the end of a counter's configured cycle time. This is configured via the CtrnCyclicRateUpdateTime configuration word/menu. Valid entries are +1 to 32767 milliseconds. The number of net counts, net change in Ctr[n].CurrentCount, during that period is converted into a rate value, providing an average pulse rate.

The generalized rate calculation is: Rate =  $\Delta$  count/  $\Delta$  time.

**IMPORTANT** The rate calculation is based on net counts. If a counter goes up 500 counts and down 300 counts, the net count is +200. Therefore, changes in direction and speed affect the Ctr[*n*].CurrentRate value.

The cyclic method is better suited to high pulse rates.

## **Hysteresis Detection and Configuration**

Because physical vibration can cause an encoder to generate pulses which you may not wish to consider as valid motion, a hysteresis value is used to eliminate a certain number of pulses in either direction as vibration-generated. These pulses are not used to calculate the Ctr[*n*].CurrentRate value. You program the minimum number of counts that are considered to be valid motion, using the Ctr*n*Hysteresis configuration word/menu. If the change in counts over the update time cycle is less than that minimum number of programmed counts, the Ctr[*n*].CurrentRate is reported as zero.

**NOTE:** This concept is not used to alter actual count values.

**IMPORTANT** Hysteresis does not depend on the direction(s) of the change in count. Therefore, creeping, a slow change in count in one direction only, can also be reported as zero frequency when it falls below the hysteresis threshold.

#### Scalar

You can configure the Ctr*n*Scalar value to scale or convert the raw rate value to application-specific information, such as RPM (Revolutions Per Minute). Setting Ctr*n*Scalar to 1 leaves the rate value in cycles per second (Hertz).

The actual rate equation is:

 $Current Rate = \frac{1000 \text{ x } \Delta \text{ count}}{CyclicRateUpdateTime \text{ x Scalar}}$ 

TIP

To configure the Ctr[*n*].CurrentRate value to show an RPM value, set Ctr*n*Scalar to (counts per revolution)/60.

For example, where Ctr0CyclicRateUpdateTime = 80, the encoder has 360 counts per revolution, and the change in Ctr[0].CurrentCount is 96:

Scalar = <u>360 counts/revolution</u> 60 sec/min

 

 RPM =

 <sup>1000</sup> Cyclic Rate Update Time/sec x 96 counts

 80 Cyclic Rate Update Time x 360 counts/revolution 60 sec/min

#### **Rate Valid**

The Ctr[n].RateValid bit indicates calculation integrity. When the bit is set, it indicates that the accompanying Ctr[n].CurrentRate value is accurate. The Ctr[n].RateValid bit is reset when the overflow or underflow events have occurred, i.e. at rising edges of Ctr[n].Overflow or Ctr[n].Underflow bits. It also happens when the count is abruptly modified via a preset (CtrnSoftPreset, CtrnCtrPresetWarning or Z based preset event) or direct write (Range12To15[n].LoadDirectWrite). When this occurs, the Ctr[n].CurrentRate value is frozen at the last known good value so that effects of erroneous rates will not propagate to range comparisons. The value remains frozen until the current cycle time plus one more cycle time are elapsed (this may be up to twice the CtrnCyclicRateUpdateTime). If the overflow/underflow occurrence lasts for more than one cycle times.

Ensure that another overflow/underflow, etc. does not happen during this recovery time. The rate will remain invalid until a full update time has occurred with no such events. If the Ctr[n].RateValid bit is seldom or never set, the CtrnMinCount and CtrnMaxCount values may be configured too close to each other.

### **Rate Method Selection**

By knowing when to use each method, an optimal rate determination can be made.



Fractional rates are not reported by the module, but can be calculated from Ctr[*n*].PulseInterval in your control program.

The following information is provided to assist you in choosing the appropriate calculation method. In general you should consider the effect of having the count off by  $\pm 1$  in each method at frequencies of interest to see if the resulting inaccuracy is acceptable.

#### Per Pulse Method Example

If the frequency of interest has 100 counts (of the 1 µs clock) between pulses, an error of 1 count results in a 1-in-100, or 1%, error. If there are 1000 counts between pulses, then the error is 1-in-1000, or 0.1%. Error for a variety of pulse values is shown below.

Table 2.8 Per Pulse Errors	
----------------------------	--

Actual 1 µs Internal Pulses <sup>(1)</sup>	Reported Pulses	Real Frequency	Reported Frequency	% Error
2	1	500 kHz	1 MHz	100%
9	10	111 kHz	100 kHz	11.1%
101	100	9.901 kHz	10.000 kHz	1.00%
1001	1000	999 Hz	1000 Hz	0.10%
9,999	10,000	100.01 Hz	100.00 Hz	0.010%
99,999	100,000	10.00010 Hz	10.00000 Hz	0.001%

(1) 1.9999 can be rounded to 2 and so on.

#### Cyclic Method

Since the update time is programmable, there is more flexibility in choosing the correct fit when using the Cyclic Method.

Error estimates are shown below for a variety of update times.

**Table 2.9 Maximum Cyclic Rate Errors** 

CyclicRate	Frequency										
Time x Scalar	100 Hz	1 kHz	10 kHz	100 kHz	1 MHz						
1	n/a	n/a	20.02%	2.011%	0.210%						
10	n/a	20.11%	2.020%	0.210%	0.030%						
100	20.01%	2.110%	0.220%	0.031%	0.012%						
1000	3.010%	0.310%	0.040%	0.013%	0.010%						
10,000	1.210%	0.130%	0.022%	0.011%	0.010%						

See also: Rate Accuracy graph on page A-3.

# **Output Control**

All 16 outputs can be controlled by any of the 4 counters or by the user's control program, via the output mask function. Output states are determined by count, rate, ranges, mask configuration data, overcurrent status, and safe state settings and conditions.

The 16 outputs are made up of 4 real (physical) outputs and 12 virtual outputs. The status of the real and virtual outputs is available to the user program. The real outputs are electronically protected from overloads.

**IMPORTANT** To turn outputs on, you must use both the Output On Mask and the Output Off Mask.

#### Masks

#### Output On Mask

Using the Output On Mask, all of the module's outputs can be turned on directly by the user control program, like discrete outputs. A bit which is set in the mask turns on the corresponding real or virtual output.

#### Output Off Mask

The Output Off Mask has veto power over any output. It can turn any or all of the module's outputs off. When a bit in this mask is set to 0, the output will be turned off. Each bit is logically ANDed with the Output On Mask and masks of active and enabled ranges. If the bit in this mask is set to 1, the output may be turned on or off by the ranges, or the Output On Mask. The final result is available as the Readback.n bit.

#### Ranges

Up to 16 dynamically configurable ranges are available. Ranges activate outputs based on the current count value or the current rate value. Each range is programmed with a type, counter number, two limit values, an invert bit, and an output mask.

Each range is programmed with high and low limits for the chosen value. The range's invert bit indicates whether the range is active between or outside the range limits. When the chosen value fulfills the configuration parameters, the range is active as indicated in the Input Array. When a range is active and enabled (RangeEn.n = 1), the range turns on all outputs indicated by the Range Output Mask except those that are prevented from being enabled by the other factors such as Output Off Mask or Overcurrent. The status of a range is provided by the range active status word, where 1 equals range active and zero equals inactive.



Ranges can be disabled while the module is running using the RangeEn.n bit in the output file. However, even a disabled range will report when it is active or not. For example, an unprogrammed range has limits of 0, and points to the Ctr[0].CurrentCount value. If this value is 0, that range is reported as active.
#### Count Range

In a non-inverted count range, the outputs are active if the count value is within the user-defined range. In an inverted count range, the outputs are active if the count value is outside the user-defined range. Valid limits for the range are -2 billion and +2 billion regardless of programmed minimum and maximum values.

The example shows all ranges referring to one counter. The module is capable of individually assigning each range to any counter. Each counter can also have a combination of count and rate ranges.

## Figure 2.8 Count Range Example



 Table 2.10 Count Range Example Values

6)	e Counter Number	e Type <sup>(1)</sup>	e Low Limit	e High Limit	e Invert Bit	Outputs <sup>(2)</sup> (Range[ <i>n</i> ].OutputControl word)													its Affected			
Rang	Rang	Rang	Rang	Rang	Rang	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	Outpu
1	01	0	-7000	-5000	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	1	0
2	01	0	-1000	+4500	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	1	0	1
3	01	0	-4000	+3000	0	0	0	0	0	0	0	0	0	0	0	0	0	0	1	0	0	2
4	01	0	-9000	+9000	1	0	0	0	0	0	0	0	0	0	0	0	0	1	0	0	1	0 and 3

(1) For Range Type, 0 = count range and 1 = rate range.

(2) Bits 0 through 3 are real outputs. Bits 4 through 15 are virtual outputs.

#### Rate Range

In a non-inverted rate range, the outputs are active if the rate measurement is within the user-defined range. In an inverted rate range, the outputs are active if the rate measurement is outside the user-defined range. The input rate can be up to 1 MHz in either direction.

The example shows all ranges referring to one counter. The module is capable of individually assigning each range to any counter. Each counter can also have a combination of count and rate ranges.



#### Figure 2.9 Rate Range Example

Table 2.11 Count Range Example Values

	e Counter Number	e Type <sup>(1)</sup>	e Low Limit	e High Limit	e Invert Bit		Outputs <sup>(2)</sup> (Range[ <i>n</i> ].OutputControl word)												ts Affected			
Range	Range	Range	Range	Range	Range	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	Outpu
1	00	1	-7000	-5000	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	1	0
2	00	1	-1000	+4500	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	1	0	1
3	00	1	-4000	+3000	0	0	0	0	0	0	0	0	0	0	0	0	0	0	1	0	0	2
4	00	1	-20000	+20000	1	0	0	0	0	0	0	0	0	0	0	0	0	1	0	0	1	0 and 3

(1) For Range Type, 0 = count range and 1 = rate range.

(2) Bits 0 through 3 are real outputs. Bits 4 through 15 are virtual outputs.

#### Overcurrent

If the module detects a real output point overcurrent condition, it reports it to the input file and turns off that output. You can also program the module to latch each of the four real outputs off, emulating a physical fuse, or to automatically reset. The 12 virtual outputs do not have this function.

When the OvercurrentLatchOff bit is set and an overcurrent situation occurs, even momentarily, the associated real output is latched off until the ResetBlownFuse bit transitions from 0 to 1.

If the OvercurrentLatchOff bit is reset and an overcurrent situation occurs, the output turns off for 1 second and is then retried (auto-reset). The module continues to attempt to turn the output back on until the overcurrent situation is no longer detected and the output is successfully turned back on.

**IMPORTANT** The outputs will be on momentarily while they are retried. The length of time they are on depends on the magnitude of the load.

## Safe State Control

The 1769-HSC module combines the Hold Last State and User-Defined Safe State options with a safe state run alternative that allows the module to continue to control outputs under program or fault states<sup>(1)</sup>. These options are described below.

Only the physical outputs are affected by safe state settings and conditions. Virtual outputs, inputs, and counting are not affected by program or fault states.

#### Hold Last State (HLS)

This condition applies depending on the mode of the controller. When the hold last state option is set, the module holds the outputs at the state they were at just before the control system transitioned from Run to Program or Run to Fault.

HLS sets the module according to the values configured for Program Mode (described on page 4-9) and Output Fault Mode (described on page 4-10).

The module continues to update the Input Array and count inputs in all modes. The operation of the outputs will vary according to mode and configuration and the capabilities of the controller or bus master.

#### User-Defined Safe State (UDSS)

In this configuration, the module sets the outputs to a user-defined safe state when the control system transitions from Run to Program or Run to Fault.

UDSS sets the module according to the values configured for Output Program Value (described on page 4-10) and Output Fault Value (described on page 4-11).

#### Program State Run (PSR)

Program State Run allows you to specify that the output should continue to be controlled by the module as if it were in the Run state. That is, events on the module or changes in the Output image will affect the physical outputs without regard to the Program\_HLS or UDSS state indicated. When this bit is set, the corresponding Out*n*ProgramMode and Out*n*ProgramValue bits are ignored.

PSR sets the module according to the value configured for Output Program State Run (described on page 4-9).



Selecting this option will allow outputs to change state while ladder logic is not running. You must take care to assure that this does not pose a risk of injury or equipment damage when selecting this option.

## IMPORTANT

The prescan initiated by some controllers could have an effect on the outputs. To overcome any changes in physical output states that may be caused by this, retentive output instructions (eg. latch, unlatch etc.) should be used when bit manipulations are done on the Output image of this module in ladder logic.

This applies to a wide range of bits when Program State Run is selected, since presetting a counter, enabling a range, changing a mask, and changing Module Configuration Array settings can cause ranges and outputs to change state.

#### Fault State Run (FSR)

Similar to Program State Run, Fault State Run allows you to specify, on a bit basis, that the output should continue to be controlled by the module as if it were Run state. That is, events on the module or changes in the Output image will affect the physical outputs without regard to the Program\_HLS or UDSS state indicated. When this bit is set, the corresponding Program Mode and Program Value bits are ignored.

FSR sets the module according to the value configured for Output Fault State Run (described on page 4-10).



Selecting this option will allow outputs to change state while ladder logic is not running. You must take care to assure that this does not pose a risk of injury or equipment damage when selecting this option.

#### IMPORTANT

The prescan initiated by some controllers could have an effect on the outputs. To overcome any changes in physical output states that may be caused by this, retentive output instructions (eg. latch, unlatch etc.) should be used when bit manipulations are done on the Output image of this module in ladder logic.

This applies to a wide range of bits when Fault State Run is selected, since presetting a counter, enabling a range, changing a mask, and changing Configuration Array settings can cause ranges and outputs to change state.

Program to Fault Enable (PFE)

The ProgToFaultEn bit allows you to select which data value (Program Value or Fault Value) to apply to the output when the Output State Logic state Prog\_HLS changes to indicate Fault\_HLS.

If PFE is 0, the module leaves the Program value applied. If PFE is set to 1, the Fault value is applied.



If the module is in a safe state such as Program or Fault which is configured to turn an output ON and excessive current is drawn from the output, the output will still turn off according to the programmed OverCurrentLatchOff bit configuration.

The module' s Default Safe State configuration is all zero's, resulting in the following:

- Program State = UDSS
- Program Value = OFF
- Program State Run = No
- Fault State = UDSS
- Fault Value = OFF
- Fault State Run = No
- PFE = leave program value applied.

## **Output Control Example**

The following example illustrates the module's output control flow. The following conditions are reflected in Table 2.12:

- Range 0 is enabled and active
- Range 1 is disabled
- Range 2 is enabled but not active
- an overcurrent condition exists on real output 3
- OvercurrentLatchOff is set
- the system is in Run mode

The table below illustrates the step-by-step logical operations that are performed to determine the final output state. For example, Range 1 values do not affect the output because Range 1 is disabled, and the Output Off Mask causes some of the outputs to change to zero because it takes priority over the range masks.

The output parameters shown in the table have been discussed in the previous sections.

Output Parameter	Mask Information	Logical Operation	Result <sup>(1)</sup>
Range O	0 0 0 1 0 1 1 0 1 1 0 1 0 0 0 1	OR	0 0 0 1 0 1 1 0 1 1 0 1 0 0 0 1
Range 1	0 0 1 0 1 1 1 1 1 1 1 1 0 0 1 0	OR	0 0 0 1 0 1 1 0 1 1 0 1 0 0 0 1
Range 2	0 1 0 0 0 0 0 0 0 0 0 1 1 0 0	OR	0 0 0 1 0 1 1 0 1 1 0 1 0 0 0 1
Output On Mask	0 1 0 0 1 0 1 0 1 0 1 0 1 0 0 0	OR	0 1 0 1 1 1 1 0 1 1 1 1 1 0 0 1
Output Overcurrent	1 0 0 0	AND	0 1 0 1 1 1 1 0 1 1 1 1 <b>0</b> 0 0 1
Output Off Mask	1 1 1 1 0 0 0 0 1 1 1 1 1 1 0 0	AND	0 1 0 1 0 0 0 0 1 1 1 1 0 0 0 0
Program State Values	1 1 1 1	Override	0 1 0 1 0 0 0 0 1 1 1 1 0 0 0 0
Fault State Values	1 1 1 1	Override	0 1 0 1 0 0 0 0 1 1 1 1 0 0 0 0
Final Output State			0 1 0 1 0 0 0 0 1 1 1 1 0 0 0 0

#### **Table 2.12 Output Control Example**

(1) Bolded text indicates that these values have changed.

## **Readback/Loopback**

The Readback/loopback function is the feedback of the module's outputs via its Input Array. This 16-bit image includes both real (4) and virtual (12) outputs.

If the module's output is OFF due to overcurrent, both the Overcurrent status flag and the Readback bit will indicate the condition being 1 and 0 respectively. Conversely, should the output be ON due to any module control (eg. UDSS), this will be indicated by Readback.

# **Installation and Wiring**

This chapter tells you how to:

- determine the power requirements for the modules
- avoid electrostatic damage
- install the module
- wire the module's terminal block
- wire input devices

## Compliance to European Union Directives

This product is approved for installation within the European Union and EEA regions. It has been designed and tested to meet the following directives.

## **EMC** Directive

The 1769-HSC module is tested to meet Council Directive 89/336/EEC Electromagnetic Compatibility (EMC) and the following standards, in whole or in part, documented in a technical construction file:

- EN 50081-2 EMC – Generic Emission Standard, Part 2 - Industrial Environment
- EN 50082-2 EMC – Generic Immunity Standard, Part 2 - Industrial Environment

This product is intended for use in an industrial environment.

## **Low Voltage Directive**

This product is tested to meet Council Directive 73/23/EEC Low Voltage, by applying the safety requirements of EN 61131-2 Programmable Controllers, Part 2 – Equipment Requirements and Tests.

For specific information required by EN61131-2, see the appropriate sections in this publication, as well as the following Allen-Bradley publications:

- Industrial Automation, Wiring and Grounding Guidelines for Noise Immunity, publication 1770-4.1
- Automation Systems Catalog, publication B113

## **Power Requirements**

The modules receive power through the Compact bus interface from the +5V dc/+24V dc system power supply. The maximum current drawn by the modules is shown in the table below.

Module Current Draw	at 5V dc	at 24V dc
	425 mA	0 mA

## **General Considerations**

Compact I/O is suitable for use in an industrial environment when installed in accordance with these instructions. Specifically, this equipment is intended for use in clean, dry environments (Pollution degree  $2^{(1)}$ ) and to circuits not exceeding Over Voltage Category II<sup>(2)</sup> (IEC 60664-1).<sup>(3)</sup>

- (1) Pollution Degree 2 is an environment where, normally, only non-conductive pollution occurs except that occasionally a temporary conductivity caused by condensation shall be expected.
- (2) Over Voltage Category II is the load level section of the electrical distribution system. At this level transient voltages are controlled and do not exceed the impulse voltage capability of the product's insulation.
- (3) Pollution Degree 2 and Over Voltage Category II are International Electrotechnical Commission (IEC) designations.

#### **Hazardous Location Considerations**

This equipment is suitable for use in Class I, Division 2, Groups A, B, C, D or non-hazardous locations only. The following WARNING statement applies to use in hazardous locations.



• All wiring must comply with N.E.C. article 501-4(b).

## **Prevent Electrostatic Discharge**



## **Remove Power**



Remove power before removing or inserting this module. When you remove or insert a module with power applied, an electrical arc may occur. An electrical arc can cause personal injury or property damage by:

- sending an erroneous signal to your system's field devices, causing unintended machine motion
- causing an explosion in a hazardous environment

Electrical arcing causes excessive wear to contacts on both the module and its mating connector and may lead to premature failure.

## **Selecting a Location**

#### Reducing Noise

Most applications require installation in an industrial enclosure to reduce the effects of electrical interference. The module is highly susceptible to electrical noise. Electrical noise coupled to the inputs will reduce the performance (accuracy) of the module.

Group your modules to minimize adverse effects from radiated electrical noise and heat. Consider the following conditions when selecting a location for the module. Position the module:

- away from sources of electrical noise such as hard-contact switches, relays, and AC motor drives
- away from modules which generate significant radiated heat, such as the 1769-IA16. Refer to the module's heat dissipation specification.

In addition, route shielded, twisted-pair analog input and output wiring away from any high voltage I/O wiring.

#### Protecting the Circuit Board from Contamination

The printed circuit boards of the modules must be protected from dirt, oil, moisture, and other airborne contaminants. To protect these boards, we recommend installing the system in an enclosure suitable for the environment. The interior of the enclosure should be kept clean and the enclosure door should be kept closed whenever possible.

#### Power Supply Distance

You can install as many modules as your power supply can support. However, the module has a power supply distance rating of 4, which means that it may not be located more than 4 modules away from the system power supply.

The illustration below provides an example showing how power supply distance is determined.



## System Assembly

The module can be attached to an adjacent controller, power supply, or I/O module. For mounting instructions, see Panel Mounting on page 3-7, or DIN Rail Mounting on page 3-9. To work with a system that is already mounted, see Replacing the Module within a System on page 3-10.

The following procedure shows you how to assemble the Compact I/O system.



- 1. Disconnect power.
- **2.** Check that the bus lever of the module (A) is in the unlocked (fully right) position.
- **3.** Use the upper and lower tongue-and-groove slots (B) to secure the modules together.
- **4.** Move the module back along the tongue-and-groove slots until the bus connectors (C) line up with each other.
- **5.** Use your fingers or a small screw driver to push the bus lever back slightly to clear the positioning tab (D).
- **6.** Move the module's bus lever fully to the left (E) until it clicks. Ensure it is locked firmly in place.



When attaching I/O modules, it is very important that the bus connectors are securely locked together to ensure proper electrical connection.

**7.** Attach an end cap terminator (F) to the last module in the system by using the tongue-and-groove slots as before.

**8.** Lock the end cap bus terminator (G).

IMPORTANT

A 1769-ECR or 1769-ECL right or left end cap must be used to terminate the end of the serial communication bus.

## Mounting



During panel or DIN rail mounting of all devices, be sure that all debris (metal chips, wire strands, etc.) is kept from falling into the module. Debris that falls into the module could cause damage at power up.

## **Minimum Spacing**

Maintain spacing from enclosure walls, wireways, adjacent equipment, etc. Allow 50 mm (2 in.) of space on all sides for adequate ventilation, as shown below:



## **Panel Mounting**

Mount the module to a panel using two screws per module. Use M4 or #8 panhead screws. Mounting screws are required on every module.

## Panel Mounting Using the Dimensional Drawing

NOTE: All dimensions are in mm (inches). Hole spacing tolerance: ±0.04 mm (0.016 in.).









#### Panel Mounting Procedure Using Modules as a Template

The following procedure allows you to use the assembled modules as a template for drilling holes in the panel. Due to module mounting hole tolerance, it is important to follow these procedures:

- 1. On a clean work surface, assemble no more than three modules.
- **2.** Using the assembled modules as a template, carefully mark the center of all module-mounting holes on the panel.
- **3.** Return the assembled modules to the clean work surface, including any previously mounted modules.
- **4.** Drill and tap the mounting holes for the recommended M4 or #8 screw.
- **5.** Place the modules back on the panel, and check for proper hole alignment.
- **6.** Attach the modules to the panel using the mounting screws.



If mounting more modules, mount only the last one of this group and put the others aside. This reduces remounting time during drilling and tapping of the next group.

7. Repeat steps 1 to 6 for any remaining modules.

## **DIN Rail Mounting**

The module can be mounted using the following DIN rails: 35 x 7.5 mm (EN 50 022 - 35 x 7.5) or 35 x 15 mm (EN 50 022 - 35 x 15).

Before mounting the module on a DIN rail, close the DIN rail latches. Press the DIN rail mounting area of the module against the DIN rail. The latches will momentarily open and lock into place. DIN rail mounting dimensions are shown below.



Dimension	Height
А	118 mm (4.65 in.)
В	59 mm (2.325 in.)
С	59 mm (2.325 in.)

# Replacing the Module within a System

The module can be replaced while the system is mounted to a panel (or DIN rail).

- 1. Remove power. See important note on page 3-4.
- **2.** Remove terminal block or disconnect input/output wiring from the module.
- **3.** Remove the upper and lower mounting screws from the module (or open the DIN latches using a flat-blade screwdriver).
- **4.** On the module to be replaced and the right-side adjacent module (or end cap if the module is the last module in the bank), move the bus levers to the right (unlock) to disconnect the module from the adjacent modules.
- **5.** Gently slide the disconnected module forward.

If you feel excessive resistance, make sure that you disconnected the module from the bus and that you removed both mounting screws (or opened the DIN latches).



It may be necessary to rock the module slightly from front to back to remove it, or, in a panel-mounted system, to loosen the screws of adjacent modules.

- **6.** Before installing the replacement module, be sure that the bus lever on the right-side adjacent module is in the unlocked (fully right) position.
- 7. Slide the replacement module into the open slot.
- **8.** Connect the modules together by locking (fully left) the bus levers on the replacement module and the right-side adjacent module or end cap.
- **9.** Replace the mounting screws (or snap the module onto the DIN rail).
- **10.** Replace the terminal block or connect input/output wiring to the module.

## **Field Wiring Connections**

## System Wiring Guidelines

Consider the following when wiring your system:

#### General

- Make sure the system is properly grounded.
- Input and output channels are isolated from the 1769 Compact bus. Input channels are isolated from one another; output channels are not.
- Shielded cable is required for high-speed input signals A, B, and Z. Use individually shielded, twisted-pair cable for lengths up to 300 meters (1000 feet).
- Group this module and other low voltage DC modules away from AC I/O or high voltage DC modules.
- Route field wiring away from any other wiring and as far as possible from sources of electrical noise, such as motors, transformers, contactors, and ac devices.
- Routing field wiring in a grounded conduit can reduce electrical noise.
- If field wiring must cross ac or power cables, ensure that they cross at right angles.

#### Terminal Block

- To ensures optimum accuracy, limit overall cable impedance by keeping cable as short as possible. Locate the module as close to input devices as the application permits.
- Tighten terminal screws with care. Excessive tightening can strip a screw.

#### Grounding

- This product is intended to be mounted to a well-grounded mounting surface such as a metal panel. Additional grounding connections from the module's mounting tabs or DIN rail (if used) are only required when the mounting surface is non-conductive and cannot be grounded.
- Keep shield connection to ground as short as possible.
- Ground the shield drain wire at the 1769-HSC input end only.
- Refer to *Industrial Automation Wiring and Grounding Guidelines*, Allen-Bradley publication 1770-4.1, for additional information.

## **Considerations for Reducing Noise**

In high noise environments, the 1769-HSC inputs may accept "false" pulses, particularly when using low frequency input signals with slowly sloping pulse edges. To minimize the effects of high frequency noise on low frequency signals, perform the following:

- Identify and remove noise sources.
- Route input cabling away from noise sources.
- Use your programming software to select low-pass filters on input signals. Filter values depend on the application and can be determined empirically.
- Use devices which output differential signals, such as differential encoders, to minimize the possibility that a noise source will cause a false input.

## **Removing and Replacing the Terminal Block**

When wiring the module, you do not have to remove the terminal block. If you remove the terminal block, use the write-on label located on the side of the terminal block to identify the module location and type.



To remove the terminal block, loosen the upper and lower retaining screws. The terminal block will back away from the module as you remove the screws. When replacing the terminal block, torque the retaining screws to 0.46 Nm (4.1 in-lbs).



## Wiring the Finger-Safe Terminal Block

When wiring the terminal block, keep the finger-safe cover in place.

- 1. Loosen the terminal screws to be wired.
- **2.** Route the wire under the terminal pressure plate. You can use the bare wire or a spade lug. The terminals accept a 6.35 mm (0.25 in.) spade lug.



The terminal screws are non-captive. Therefore, it is possible to use a ring lug [maximum 1/4 inch o.d. with a 0.139 inch minimum i.d. (M3.5)] with the module.

**3.** Tighten the terminal screw making sure the pressure plate secures the wire. Recommended torque when tightening terminal screws is 0.68 Nm (6 in-lbs).



If you need to remove the finger-safe cover, insert a screwdriver into one of the square, wiring holes and gently pry the cover off. If you wire the terminal block with the finger-safe cover removed, you will not be able to put it back on the terminal block because the wires will be in the way.

#### Wire Size and Terminal Screw Torque

Each terminal accepts up to two wires with the following restrictions:

N	/ire Type	Wire Size	Terminal Screw Torque	Retaining Screw Torque		
Solid	Cu-90°C (194°F)	#14 to #22 AWG	0.68 Nm (6 in-lbs)	0.46 Nm (4.1 in-lbs)		
Stranded	Cu-90°C (194°F)	#16 to #22 AWG	0.68 Nm (6 in-lbs)	0.46 Nm (4.1 in-lbs)		

## Wiring the Modules



To prevent shock hazard, care should be taken when wiring the module to signal sources. Before wiring any module, disconnect power from the system power supply and from any other source to the module.

After the module is properly installed, follow the wiring procedure below. To ensure proper operation and high immunity to electrical noise, always use shielded wire.



To wire your module follow these steps.

- **1.** At each end of the cable, strip some casing to expose the individual wires.
- Trim the signal wires to 2-in. (5 cm) lengths. Strip about 3/16 in.
   (5 mm) of insulation away to expose the end of the wire.



Be careful when stripping wires. Wire fragments that fall into a module could cause damage at power up.

- **3.** At the 1769-HSC input end of the cable, twist the drain wire and foil shield together, bend them away from the cable, and apply shrink wrap. Ground the shield at this end.
- **4.** At the other end of the cable, cut the drain wire and foil shield back to the cable and apply shrink wrap.
- **5.** Connect the signal wires to the terminal block. Connect the other end of the cable to the input device.
- 6. Repeat steps 1 through 5 for each channel on the module.

## **Terminal Door Label**

A removable, write-on label is provided with the module. Remove the label from the door, mark the identification of each terminal with permanent ink, and slide the label back into the door. Your markings (ID tag) will be visible when the module door is closed.

## **Terminal Block Wiring**

The input and output terminals are illustration in the figure below. Both inputs and outputs are isolated from the 1769 Compact bus.



## **Wiring Diagrams**

#### Inputs

The module utilizes differential inputs. Therefore, two input terminals are required for each input point. For example, the A0+ and A0- terminals are required for input point A0. Each input point is isolated from other input points, the 1769 Compact bus, and the entire output terminal group.

The inputs are compatible with standard differential line driver output devices as well as single-ended devices such as limit switches, photo-eyes, and proximity sensors. Examples of differential and single-ended circuits are shown in the following figures.

#### **Figure 3.3 Differential Encoder Wiring**



(1) Refer to your encoder manual for proper cable type. The type of cable used should be twisted pair, individually shielded cable with a maximum length of 300m (1000 ft.).

#### Figure 3.4 Single-Ended Encoder Wiring



- Refer to your encoder manual for proper cable type. The type of cable used should be twisted-pair, individually shielded cable with a maximum length of 300m (1000 ft.).
- (2) External resistors are required if they are not internal to the encoder. The pull-up resistor (R) value depends on the power supply value. The table below shows the maximum resistor values for typical supply voltages. To calculate the maximum resistor value, use the following formula:

$$R = \frac{(Vdc - Vmin)}{Imin}$$

where:

 $\label{eq:resonance} \begin{array}{l} R = maximum \ pull-up \ resistor \ value \\ Vdc = power \ supply \ voltage \\ Vmin = 2.6V \ dc \\ Imin = 6.8 \ mA \end{array}$ 

Power Supply Voltage (Vdc)	Maximum Pull-up Resistor Value (R) <sup>(1)</sup>
5V dc	352 Ω
12V dc	1382 <b>Ω</b>
24V dc	3147 Ω

(1) Resistance values may change, depending upon your application.

The minimum resistor (R) value depends on the current sinking capability of the encoder. Refer to your encoder's documentation.

#### **Figure 3.5 Discrete Device Wiring**



(1) External resistors are required if they are not internal to the sensor. The pull-up resistor (R) value depends on the power supply value. The table below shows the maximum resistor values for typical supply voltages. To calculate the maximum resistor value, use the following formula:

$$R=\frac{(Vdc-Vmin)}{Imin}$$

where:

 $\label{eq:R} \begin{array}{l} \mathsf{R} = \mathsf{maximum pull-up resistor value} \\ \mathsf{Vdc} = \mathsf{power supply voltage} \\ \mathsf{Vmin} = 2.6\mathsf{V} \; \mathsf{dc} \\ \mathsf{Imin} = 6.8 \; \mathsf{mA} \end{array}$ 

Power Supply Voltage (Vdc)	Maximum Pull-up Resistor Value (R) <sup>(1)</sup>
5V dc	352 Ω
12V dc	1382 <b>Ω</b>
24V dc	3147 Ω

(1) Resistance values may change, depending upon your application.

The minimum resistor (R) value depends on the current sinking capability of the sensor. Refer to your sensor's documentation.

#### Outputs

The four output terminals must be powered by a user-supplied external source. User Power range is from +5 to +30V dc. See Output Specifications on page A-2 for voltage and current levels. There is no isolation between the outputs, but the outputs are isolated from the inputs and the 1769 Compact bus.

#### **Electronic Protection**

The electronic protection of the 1769-HSC has been designed to provide protection for current overload and short circuit conditions. The protection is based on a thermal cut-out principle. In the event of a short circuit or current overload condition on an output channel, that channel will turn off within milliseconds after the thermal cut-out temperature has been reached.

#### **Overcurrent Autoreset Operation**

The module detects overcurrent situations and reports them to the backplane in the Out*n*OverCurrent bits of the Input Array. When the overcurrent condition is detected, the outputs are turned off.

The module can latch outputs off in order to emulate the behavior of a physical fuse. Use the OvercurrentLatchOff bit to enable or disable this feature. When the OvercurrentLatchOff bit is set and an overcurrent situation occurs (even momentarily) the physical output will be latched off until the ResetBlownFuse bit is cycled from off to on (rising edge triggered). During the latched off time, the Readback.*n* bit in the Input Array also shows that the output is off.

If the OvercurrentLatchOff bit is not set, the output will be turned off for 1 second and then be retried (if still directed to be on). Retries will repeat until the overcurrent situation is corrected.

Only the 4 physical outputs can be latched off. The virtual outputs are not affected.

IMPORTANT	During the retry period, the physical output and the Readback. <i>n</i> bits will be on briefly (until the overcurrent causes them to shut off again). Take this into consideration and configure your system accordingly.
TIP	Short-circuits and overload conditions should be corrected as soon as possible. Damage may occur if

corrected as soon as possible. Damage may occur if short-circuits or overload conditions are allowed for extended periods.

#### **Transistor Output Transient Pulses**

The maximum duration of the transient pulse occurs when minimum load is connected to the output. However, for most applications, the energy of the transient pulse is not sufficient to energize the load.



A transient pulse occurs in transistor outputs when the external DC supply voltage is applied to the output common terminals (e.g. via the master control relay). The sudden application of voltage creates this transient pulse. This condition is inherent in transistor outputs and is common to solid state devices. A transient pulse can occur regardless of the controller having power or not. Refer to your controller's user manual to reduce inadvertent operation.

The graph below illustrates that the duration of the transient is proportional to the load current. Therefore, as the on-state load current increases, the transient pulse decreases. Power-up transients do not exceed the time duration shown below, for the amount of loading indicated, at 60°C (140°F).





Output wiring is illustrated in the following diagram.

#### Figure 3.7 Output Wiring

Basic wiring<sup>(1)</sup> of output devices<sup>(2)</sup> to the module is shown below.



- Miswiring of the module to an AC power source or applying reverse polarity will damage the module.
- Be careful when stripping wires. Wire fragments that fall into a module could cause damage at power up. Once wiring is complete, ensure the module is free of all metal fragments.



- (1) Recommended Surge Suppression The module has built-in suppression which is sufficient for most applications, however, for high-noise applications, use a 1N4004 diode reverse-wired across the load for transistor outputs switching 24V dc inductive loads. For additional details, refer to Industrial Automation Wiring and Grounding Guidelines, Allen-Bradley publication 1770-4.1.
- (2) Sourcing Output Source describes the current flow between the I/O module and the field device. Sourcing output circuits supply (source) current to sinking field devices. Field devices connected to the negative side (DC Common) of the field power supply are sinking field devices. Field devices connected to the positive side (+V) of the field supply are sourcing field devices. *Europe:* DC sinking input and sourcing output module circuits are the commonly used options.

# **Module Configuration, Output, and Input Data**

After installation of the 1769-HSC module, you must configure it for operation, using the programming software compatible with the controller (for example, RSLogix 500 or RSLogix 5000).



Normal counter configuration is done using programming software. In that case, it is not necessary to know the meaning of the bit location. However, some systems allow configuration to be changed by the control program. Refer to your controller's documentation for details.

Information on programming the module using specific controllers and software is contained in the following Appendices.

Appendix	Controller	Software
Appendix B	CompactLogix Controller	RSLogix 5000
Appendix C	MicroLogix 1500 Controller	RSLogix 500

## **Configuring the Module**

The module uses three arrays: Configuration Array, Output Array, and Input Array. You configure the module by establishing settings in the Configuration and Output Arrays. The Input Array shows the data that the module sends to the controller.

**IMPORTANT** Both the Configuration Array and Output Array settings affect the module configuration. Changing certain configuration parameters from defaults may necessitate changing other values to avoid configuration errors.

## **Configuration Array**

The Configuration Array, which consists of 118 words, allows you to specify how the module's counters will function. The default value is all zeros with the exception of:

- NumberofCounters (see page 4-8)
- Ctr*n*MaxCount (see page 4-11)
- Ctr*n*MinCount (see page 4-12)
- Ctr*n*Scalar (see page 4-14)
- CtrnCyclicUpdateTime (see page 4-14)



Normal counter configuration is done using programming software. In that case, it is not necessary to know the bit location. However, some systems allow configuration to be changed by the control program. Refer to your controller's documentation for details.

**IMPORTANT** When changing configuration values, verify that only valid configurations are created for the module. For example, changing NumberofCounters from its default of 1 to 0 requires that Ctr1MinCount and Ctr1MaxCount also be set to 0, etc.

See Table 5.6 "Configuration Error Codes" on page 5-9 if you encounter configuration errors.

Word 0 contains general configuration bits. Word 1 contains the filter settings. Words 2 through 5 refer to the physical outputs. Words 6 through 45 are counter configuration words. Words 46 through 117 are range configuration words. More detailed descriptions of the configuration words and bits follow the Configuration Array below.

**IMPORTANT** Certain values (noted below) cannot be changed while a counter(s) or range(s) is enabled. Attempting to do so will cause a configuration error and the entire Configuration Array will be rejected until the error is eliminated.

Word	15 14 13 12	11 1	0 09 08	07	06	05	04	03	02	01	00	Function
0	Not Used		NumberOf Counters	I	Not Use	d	PFE	Not	Used	Ctr Rst	OCLO	General Configuration Bits
1	Filter_Z1 Not Used Fil	ter_B1 Us	ot ed Filter_A1	Filte	er_ZO	Not Used	Filte	r_B0	Not Used	Filte	r_A0	Filter Selection
2	Nc	it Used		Out3 PSR	Out2 PSR	Out1 PSR	Out0 PSR	Out3 PM	Out2 PM	Out1 PM	Out0 PM	Output Program Mode and Output Program State Run
3		Output Program Value										
4	No	it Used	Out0 FSR	Out3 FM	Out2 FM	Out1 FM	Out0 FM	Output Fault Mode and Output Fault State Run				
5		Out0 FV	Output Fault Value									
6 7			Ctr0Ma	axCount	t							Counter 0 Maximum Count
8 9		Counter 0 Minimum Count										
10 11		Counter O Preset										
12		Counter 0 Hysteresis										
13		Counter 0 Scalar										
14		Counter O Cyclic Rate Update Time										
15	Not Used Lin- ear	Not Used	Storage Mode		1	Not Use	d		Opera	ational	Mode	Counter O Configuration Flags
16 17			Ctr1Ma	axCount	t							Counter 1 Maximum Count
18 19			Ctr1Mi	inCount								Counter 1 Minimum Count
20 21			Ctr1F	Preset								Counter 1 Preset
22			Ctr1Hy	steresis	3							Counter 1 Hysteresis
23			Ctr15	Scalar								Counter 1 Scalar
24			Ctr1CyclicRat	teUpdat	teTime							Counter 1 Cyclic Rate Update Time
25	Not Used Lin- ear	Counter 1 Configuration Flags										
26 27		Counter 2 Maximum Count										
28 29		Counter 2 Minimum Count										
30 31		Counter 2 Preset										
32			Ctr2Hy	steresis	8							Counter 2 Hysteresis
33			Ctr2S	Scalar								Counter 2 Scalar
34			Ctr2CyclicRat	teUpdat	teTime							Counter 2 Cyclic Rate Update Time

Word	15	1/	12	12	11	10	00	B	it 07	06	05	0/	02	02	01	00	Function
35	13	lot Use	d	Lin- ear		10	00			Not	Used		00	02	01	00	Counter 2 Configuration
36 37								Ctr3Ma	axCount								Counter 3 Maximum Count
38 39								Ctr3Mi	nCount								Counter 3 Minimum Count
40 41								Ctr3F	reset								Counter 3 Preset
42								Ctr3Hy:	steresis								Counter 3 Hysteresis
43	Ctr3Scalar														Counter 3 Scalar		
44	Ctr3CyclicRateUpdateTime														Counter 3 Cyclic Rate Update Time		
45	Not Used Lin- ear Not Used														Counter 3 Configuration Flags		
46 47	- RangeOTo11[0].HighLimit													Range O High Limit			
48 49	- Range0To11[0].LowLimit														Range O Low Limit		
50	Out 15	Out 14	Out 13	Out 12	Out 11	Out 10	Out 09	Out 8	Out 7	Out 6	Out 5	Out 4	Out 3	Out 2	Out 1	Out 0	Range 0 Output Control
51			۱۱	lot Use	d	<u> </u>	<u> </u>	Inv	١	Not Use	d	Туре	Not	Used	ToTh	isCtr	Range O Configuration Flags
52 53							Rang	je0To11	(1).High	Limit							Range 1 High Limit
54 55							Ranç	geOTo11	[1].Low	Limit							Range 1 Low Limit
56	Out 15	Out 14	Out 13	Out 12	Out 11	Out 10	Out 09	Out 8	Out 7	Out 6	Out 5	Out 4	Out 3	Out 2	Out 1	Out O	Range 1 Output Control
57			١	lot Use	d			Inv	١	Not Use	d	Туре	Not	Used	ToTh	isCtr	Range 1 Configuration Flags
58 59							Rang	je0To11	[2].High	Limit							Range 2 High Limit
60 61							Ranç	geOTo11	[2].Low	Limit							Range 2 Low Limit
62	Out 15	Out 14	Out 13	Out 12	Out 11	Out 10	Out 09	Out 8	Out 7	Out 6	Out 5	Out 4	Out 3	Out 2	Out 1	Out 0	Range 2 Output Control
63			١	lot Use	d	•		Inv	١	Not Use	d	Туре	Not	Used	ToTh	isCtr	Range 2 Configuration Flags
64 65	Range0To11[3].HighLimit												Range 3 High Limit				
66 67	RangeOTo11[3].LowLimit													Range 3 Low Limit			
68	Out 15	Out 14	Out 13	Out 12	Out 11	Out 10	Out 09	Out 8	Out 7	Out 6	Out 5	Out 4	Out 3	Out 2	Out 1	Out 0	Range 3 Output Control
69			N	lot Use	d	I	I	Inv	Ν	Not Use	d	Туре	Not	Used	ToTh	isCtr	Range 3 Configuration Flags
70 71							Rang	je0To11	[4].High	Limit							Range 4 High Limit

								В	it										
Word	15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00	Function		
72							Rang	jeOTo11	[4].Low	Limit							Range 4 Low Limit		
73 74	Out	Out 14	Out	Out	Out	Out	Out	Out 8	Out 7	Out 6	Out 5	Out 4	Out 3	Out 2	Out 1	Out 0	Range 4 Output Control		
75	Not Used								v Not Used			Туре	Not	Used	ToThisCtr		Range 4 Configuration		
76 77							Rang	eOTo11	[5].High	Limit		Range 5 High Limit							
78 79							Ranç	jeOTo11	[5].Low	Limit	Range 5 Low Limit								
80	Out	Out	Out	Out	Out	Out	Out	Out 8 Out 7 Out 6 Out 5 Out 4 Out 3 Out 2 Out 1 Out 0					Range 5 Output Control						
81	15     14     13     12     11     10     09     54100     54100     5410     5410 <th>nisCtr</th> <th colspan="3">Range 5 Configuration</th>										nisCtr	Range 5 Configuration							
82	Bange(To11/6) Highlimit												Bange 6 High Limit						
83 84																			
85	- Range0To11[6].LowLimit											Range 6 Low Limit							
86	Out 15	Out 14	Out 13	Out 12	Out 11	Out 10	Out 09	Out 8	Out 7	Out 6	Out 5	Out 4	Out 3	Out 2	Out 1	Out 0	Range 6 Output Control		
87	Not Used Inv Not Used Type Not Used ToThisCtr									isCtr	Range 6 Configuration Flags								
88 89	RangeOTo11[7].HighLimit												Range 7 High Limit						
90 91							Ranç	je0To11	[7].Low	Limit							Range 7 Low Limit		
92	Out         Out <th>Out 0</th> <th colspan="2">Range 7 Output Control</th>									Out 0	Range 7 Output Control								
93	Not Used								Inv Not Used				Not	Used	ToTh	nisCtr	Range 7 Configuration Flags		
94 95	RangeOTo11[8].HighLimit													Range 8 High Limit					
96 97							Ranç	jeOTo11	[8].Low	Limit							Range 8 Low Limit		
98	Out 15	Out 14	Out 13	Out 12	Out 11	Out 10	Out 09	Out 8	Out 7	Out 6	Out 5	Out 4	ut 4 Out 3 Out 2 Out 1 Out 0			Range 8 Output Control			
99	Not Used         Inv         Not Used         Type         Not Used         ToThisCtr								nisCtr	Range 8 Configuration Flags									
100 101	Range0To11[9].HighLimit										Range 9 High Limit								
102 103	RangeOTo11[9].LowLimit											Range 9 Low Limit							
104	Out 15	Out 14	Out 13	Out 12	Out 11	Out 10	Out 09	Out 8	Out 7	Out 6	Out 5	Out 4	Out 3	Out 2	Out 1	Out 0	Range 9 Output Control		
105	Not Used         Inv         Not Used         Type         Not Used         ToThisCtr											nisCtr	Range 9 Configuration Flags						
106 107	RangeOTo11[10].HighLimit											Range 10 High Limit							
108 109	Range0To11[10].LowLimit									Range 10 Low Limit									

	Bit												<b>F</b>					
Word	15	14	13	3 12 11 10 09 08 07 06 05 04 03 02 01 00		00	Function											
110	Out 15	Out 14	Out 13	Out 12	Out 11	Out 10	Out 09	Out 8	Out 7	Out 6	Out 5	Out 4	Out 3	Out 2	Out 1	Out 0	Range 10 Output Control	
111	Not Used							Inv Not Used Ty					Not	Used	ToThisCtr		Range 10 Configuration Flags	
112	Bango()To11[11] HighLimit											Bange 11 High Limit						
113																		
114	BangaDTo11[11] LowLimit											Bange 11 Low Limit						
115	nuigooron (m).cowLinit																	
116	Out         Out 0         Out 8         Out 7         Out 6         Out 5         Out 4         Out 3         Out 2         Out 1         Out 0								Out 0	Range 11 Output Control								
117	Not Used						Inv Not Used				Туре	Not Used ToThisCtr			isCtr	Range 11 Configuration Flags		

## **General Configuration Bits**

Configuration Array Word 0	15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00
General Configuration Bits			Not	Used			Numbero	f Counters	N	ot Us	ed	PFE	Not l	Jsed	Ctr Reset	OCLO

OCLO - Overcurrent Latch Off (OverCurrentLatchOff)

When set, this bit causes the module to make any overcurrent activity latch the corresponding output off, simulating a physical fuse. When OCLO = 0, it automatically resets. The rising edge of RBF resets the output.

IMPORTANT	Do not set this bit while a counter or range is enabled (Ctr0En, Ctr1En, Ctr2En, Ctr3En, or RangeEn set to 1). Attempting to do so will result in a BadModConfigUpdate error. See page 5-13 for a full list of prohibited settings
	list of prohibited settings.
#### Counter Reset (CtrReset)

The CtrReset bit in the Configuration Array, when set, causes the following to occur when the system transitions to Run or the Inhibit Module bit transitions to 0:

- All counters are disabled and reset to zero.
- The Output Array is reset to default values until the ModConfig bit is set (1). The default value for the Output Array is all zeros.
- The Input Array counter Status Flags (Overflow, Underflow, RisingEdgeZ, RateValid, PresetWarning) are reset.
- The Input Array counter values (Current Count<sup>(1)</sup>, StoredCount, CurrentRate and PulseInterval) are also reset to zero.
- All counts are lost and all outputs are turned off.

IMPORTANTFor most predictable results, you may want to clear<br/>the output image of the processor BEFORE<br/>performing a counter reset (CtrReset) to the 1769-HSC<br/>module.This is because CtrReset does not change the<br/>processor's output image. CtrReset sets the 1769-HSC<br/>module's Output Array to all zero's. If any bit is set to<br/>1 in the processor's output image, when sent to the<br/>module, it will be seen as a state transition and be<br/>acted upon.

#### PFE - Program to Fault Enable (ProgToFaultEn)

This bit indicates what should happen when the bus controller indicates a change from one condition (Program mode) to another (Fault mode). If this bit is set (1), the safe state operation of all 4 real outputs changes to that identified by the Fault State and Fault Value words. If this bit is reset (0), the module continues with the operation identified by the Program State and Program Value words.

If zero is outside the MinCount and MaxCount limits set in the Configuration Array, then the Preset value is loaded into CurrentCount instead of zero. This also causes the PresetWarning bit to be set, which, in turn, sets the GenError bit.

#### Number of Counters (NumberOfCounters)

This 2-bit value indicates whether the module uses 1 counter, 2 counters, 3 counters, or 4 counters. The default value is 1 (2 counters).

**Table 4.2 Number of Counters Determination** 

Bit 01	Bit 00	Counters
0	0	1
0	1	2
1	0	3
1	1	4

IMPORTANT

Do not set this value while a counter or range is enabled (Ctr0En, Ctr1En, Ctr2En, Ctr3En, or RangeEn set to 1). Attempting to do so will result in a BadModConfigUpdate error. See page 5-13 for a full list of prohibited settings.

# **Filter Selection**

Configuration Array Word 1	15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00
Filter Selection	Filte	r_Z1	Not Used	Filte	erB1	Not Used	Filte	erA1	Filte	erZ0	Not Used	Filte	erB0	Not Used	Filte	erA0

This value indicates the nominal filter frequency as shown in the table below.

#### **Table 4.3 Filter Selection Settings**

ţ	FilterA0	Bit 1 - FilterA0_1	Bit 0 - FilterA0_0
d g Bit	FilterB0	Bit 4 - FilterB0_1	Bit 3 - FilterB0_0
s an Idin	FilterZ0	Bit 7 - FilterZ0_1	Bit 6 - FilterZO_0
ilter spor	FilterA1	Bit 9 - FilterA1_1	Bit 8 - FilterA1_0
Fi	FilterB1	Bit 12 - FilterB1_1	Bit 11 - FilterB1_0
ŭ	FilterZ1	Bit 15 - FilterZ1_1	Bit 14 - FilterZ1_0
y	None	0	0
inal enc ings	0.01 ms minimum pulse width	0	1
Nom requ Setti	0.5 ms minimum pulse width	1	0
- £ •	5 ms minimum pulse width	1	1

#### IMPORTANT

Do not set these bits while certain counters or ranges are enabled. Attempting to do so will result in a BadModConfigUpdate error. See page 5-13 for a full list of prohibited settings.

# **Program Mode and Program State Run**

Configuration Array Word 2	15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00
Output Program Mode and Output Program State Run				Not	Jsed				Out3 PSR	Out2 PSR	Out1 PSR	Out0 PSR	Out3 PM	Out2 PM	Out1 PM	Out0 PM

#### Program Mode (OutOProgramMode through Out3ProgramMode)

The program mode bits configure the output for Hold Last State (HLS) or User-Defined Safe State (UDSS) during Program State.

- 1 = Hold Last State
- 0 = User-Defined Safe State

IMPORTANT

Program Mode and Program State Run only apply to certain controllers. Refer to your controller's documentation for more information.

#### Program State Run (OutOProgramStateRun through Out3ProgramStateRun)

Program State Run allows you to specify, on a bit basis, that the output should continue to be controlled by the module as if it were in the Run state. That is, events on the module or changes in the Output image will affect the physical outputs without regard to the Program\_HLS or UDSS state indicated. When this bit is set, the corresponding Program Mode and Program Value bits are ignored.

# ATTENTION

Selecting this option will allow outputs to change state while ladder logic is not running. You must take care to assure that this does not pose a risk of injury or equipment damage when selecting this option.

#### IMPORTANT

The prescan initiated by some controllers could have an effect on the outputs. To overcome any changes in physical output states that may be caused by this, retentive output instructions (eg. latch, unlatch etc.) should be used when bit manipulations are done on the Output image of this module in ladder logic.

This applies to a wide range of bits when Program State Run is selected, since presetting a counter, enabling a range, changing a mask, and changing Configuration Array settings can cause ranges and outputs to change state.

# Output Program Value (Out0ProgramValue through Out3ProgramValue)

Configuration Array Word 3	15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00
Output Program Value						Not	Used						Out3 PV	Out2 PV	Out1 PV	Out0 PV

These bits are the values that will be applied to each of the real outputs when User-Defined Safe State (UDSS) is set as described above and the module is in Program state.

# **Output Fault Mode and Output Fault State Run**

Configuration Array Word 4	15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00
Output Fault Mode and Output Fault State Run				Not l	Jsed				Out3 FSR	Out2 FSR	Out1 FSR	OutO FSR	Out3 FM	Out2 FM	Out1 FM	Out0 FM

#### Output Fault Mode (Out0FaultMode through Out3FaultMode)

These bits configure the output for Hold Last State or User-Defined Safe State during a Fault state.

- 1 = Hold Last State
- 0 = User-Defined Safe State

#### Output Fault State Run (OutOFaultStateRun through Out3FaultStateRun)

Similar to Program State Run, Fault State Run allows you to specify, on a bit basis, that the output should continue to be controlled by the module as if it were Run state. That is, events on the module or changes in the Output image will affect the physical outputs without regard to the Program\_HLS or UDSS state indicated. When this bit is set, the corresponding Program Mode and Program Value bits are ignored.

#### ATTENTION



Selecting this option will allow outputs to change state while ladder logic is not running. You must take care to assure that this does not pose a risk of injury or equipment damage when selecting this option.

# IMPORTANTThe prescan initiated by some controllers could have<br/>an effect on the outputs. To overcome any changes in<br/>physical output states that may be caused by this,<br/>retentive output instructions (eg. latch, unlatch etc.)<br/>should be used when bit manipulations are done on<br/>the Output image of this module in ladder logic.This applies to a wide range of bits when Fault State<br/>Run is selected, since presetting a counter, enabling a<br/>range, changing a mask, and changing Configuration<br/>Array settings can cause ranges and outputs to<br/>change state.

# Output Fault Value (OutOFaultValue through Out3FaultValue)

Configu	ration Array Word 5	15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00
5	Output Fault Value						Not	Used						Out3 FV	Out2 FV	Out1 FV	Out0 FV

These bits are the values that will be applied to each of the real outputs when User-Defined Safe State is set as described above and the module is in Fault state.



Outputs are also affected by PFT above.



# Counter Maximum Count (CtrnMaxCount)

Configu	ration Array Words	15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00
6 7	Counter 0 Maximum Count								CtrOMa	xCount							
16 17	Counter 1 Maximum Count								Ctr1Ma	xCount							
26 27	Counter 2 Maximum Count								Ctr2Ma	xCount							
36 37	Counter 3 Maximum Count								Ctr3Ma	xCount							

This is the maximum count value allowed for counter (*n*). The count value cannot exceed this value. Allowable values are Ctr nMinCount + 1 through 2,147,483,647 (decimal).

The default value is +2,147,483,647 decimal for counters 0 and 1. The default value is 0 for counters 2 and 3.

**IMPORTANT** Do not change this value while the counter is enabled. Attempting to do so will result in a BadModConfigUpdate error. See page 5-13 for a full list of prohibited settings.

#### Counter Minimum Count (CtrnMinCount)

Configu	ration Array Words	15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00
8	Counter 0 Minimum Count								CtrOMi	nCount							
9									GUUIVII	noouni							
18	Counter 1 Minimum Count								C+r1Mi	nCount							
19									GUTIVII	ncount							
28	Countor 2 Minimum Count								C+r2Mi	nCount							
29									GUZIVII	nouni							
38	Counter 3 Minimum Count								Ctr3Mi	nCount							
39									GUJIVII	noouni							

This is the minimum count value allowed for counter (n). The count value cannot fall below this value. This value must be less than CtrnMaxCount or a configuration error occurs. Allowable values are from -2,147,483,648 to CtrnMaxCount - 1.

The default value is -2,147,483,648 decimal for counters 0 and 1. The default value is 0 for counters 2 and 3.

**IMPORTANT** Do not change this value while the counter is enabled. Attempting to do so will result in a BadModConfigUpdate error. See page 5-13 for a full list of prohibited settings.

### Counter Preset (CtrnPreset)

Configu	ration Array Words	15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00
10	Counter O Preset								CtrOP	Preset							
11									01101	10301							
20	Counter 1 Preset								Ctr1P	Procot							
21	oounter i rieset								0111	16361							
30	Counter 2 Preset								Ctr2P	Preset							
31									00121	10301							
40	Counter 3 Preset								Ctr3P	reset							
41									01101	10301							

This value can be used to change the current count value of countern on certain gate (Zn) events and when CtrnSoftPreset is used.

Ctr*n*Preset must be greater than or equal to Ctr*n*MinCount and less than Ctr*n*MaxCount. The default value is zero.

#### Counter Hysteresis (CtrnHysteresis)

Configu	uration Array Words	15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00
12	Counter 0 Hysteresis								CtrOHys	steresis							
22	Counter 1 Hysteresis								Ctr1Hy	steresis							
32	Counter 2 Hysteresis								Ctr2Hy	steresis							
42	Counter 3 Hysteresis								Ctr3Hy	steresis							

The hysteresis value is the number of counts that should be disregarded in the calculation of the cyclic rate. If the count value changes by less than the hysteresis value, the rate is reported as zero, regardless of the actual rate at which the pulses are counted.

**IMPORTANT** Do not change this value while the counter is enabled. Attempting to do so will result in a BadModConfigUpdate error. See page 5-13 for a full list of prohibited settings.

# Counter Scalar (CtrnScalar)

Configu	ration Array Words	15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00
13	Counter 0 Scalar					-	-	-	CtrOS	Scalar	-		-			-	-
23	Counter 1 Scalar								Ctr1S	Scalar							
33	Counter 2 Scalar								Ctr2S	Scalar							
43	Counter 3 Scalar								Ctr3S	Scalar							

This value is used to scale the Rate value. The Rate value is divided by the Scalar value. The default value is 1 for counters 0 and 1. The default value is 0 for counters 2 and 3.

CtrnScalar may be used to determine RPM. To configure the Ctr[n].CurrentRate value to show an RPM value, set CtrnScalar to (counts per revolution)/60. See page 2-20 for more information.

IMPORTANT	For any counter being used, do not set Scalar to a value less than one or a configuration error will occur.
IMPORTANT	Do not change this value while the counter is enabled. Attempting to do so will result in a BadModConfigUpdate error. See page 5-13 for a full

# Cyclic Rate Update Time (Ctr*n*CyclicRateUpdateTime)

list of prohibited settings.

Confi	iguration Array Words	15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00
14	Counter 0 Cyclic Rate Update Time		Ctr0CyclicRateUpdateTime														
24	Counter 1 Cyclic Rate Update Time		Ctr1CyclicRateUpdateTime														
34	Counter 2 Cyclic Rate Update Time		Ctr2CyclicRateUpdateTime														
44	Counter 3 Cyclic Rate Update Time	Ctr3CyclicRateUpdateTime															

This value is used to set the cyclic rate update time for the CurrentRate calculation. The value indicates the time in milliseconds from 1 to 32767. An invalid number causes a configuration error. The default value is 10 for counters 0 and 1. The default value is 0 for counters 2 and 3.

IMPORTANT	Do not change this value while the counter is
	enabled. Attempting to do so will result in a
	BadModConfigUpdate error. See page 5-13 for a full
	list of prohibited settings.

See page 2-19 for more information on cyclic rate.

# **Configuration Flags**

Con	Configuration Array Words		14	13	12	11	10	09	08	07	06	05	04	03	02	01	00	
15	Counter O Configuration Flags	ſ	Not Use	d	Linear	Not Used	Sto	rage M	ode		Ν	lot Use		Operational Mode				
25	Counter 1 Configuration Flags	I	Not Use	d	Linear	Not Used Storage Mode				Ν	lot Use		Opera	ational I	Mode			
35	Counter 2 Configuration Flags	1	Not Use	d	Linear	Not Used												
45	Counter 3 Configuration Flags	1	Not Use	d	Linear	ar Not Used												

*Operational Mode (CtrnConfig.OperationalMode\_0 through CtrnConfig.OperationalMode\_2)* 

These bits apply to Counters 0 and 1 only.

This value determines how the A0 or A1 and B0 or B1 inputs are decoded when assigned to counter 0 or counter 1. See the following table.

#### **Table 4.4 Operational Mode Settings**

	Set bit		For function
Ctr <i>n</i> Config.OperationalMode_2	Ctr <i>n</i> Config.OperationalMode_1	Ctr <i>n</i> Config.OperationalMode_0	
0	0	0	Pulse internal direction
0	0	1	Pulse external direction
1	0	0	Quadrature encoder X1
1	0	1	Quadrature encoder X2
1	1	0	Quadrature encoder X4
0	1	0	Up/Down Pulses
0	1	1	reserved
1	1	1	reserved



The Ctr1Config.OperationalMode bits are reserved if the Number of Counters equals 1. Attempting to set reserved bits will result in a configuration error.

# IMPORTANT

Do not change this value while the counter is enabled. Attempting to do so will result in a BadModConfigUpdate error. See page 5-13 for a full list of prohibited settings.

# Storage Mode (CtrnConfig.StorageMode\_0 through CtrnConfig.StorageMode\_2)

These three bits apply to Counters 0 and 1 only. They define how the module interprets the Z input, as shown below. Each bit works independently. If bit 0 and bit 2 are set simultaneously, a Z event causes the Current Count Value to be stored and then preset.

#### **Table 4.5 Storage Mode Settings**

Set bit	For function
Ctr <i>n</i> Config.StorageMode_0	Stores the Current Count Value on the rising edge of Z to Ctr[n].StoredCount in the input file.
CtrnConfig.StorageMode_1	Holds the counter at its Current Count Value while Z = 1.
CtrnConfig.StorageMode_2	Presets the Current Count Value on the rising edge of Z.

IMPORTANT

TIP

Z = internal Z. Internal Z is the version of the Z input pin as modified by the Output Array control bits Z Invert and Z Inhibit.

 The Ctr1Config.StorageMode bits are reserved if NumberofCounters\_1 and NumberofCounters\_0 are set to 00 (one counter). Attempting to set reserved bits will result in a configuration error.

**IMPORTANT** Do not change this value while the counter is enabled. Attempting to do so will result in a BadModConfigUpdate error. See page 5-13 for a full list of prohibited settings.

Linear (Ctr0Config.Linear through Ctr3Config.Linear)

This bit indicates how the counter operates upon reaching a Ctr*n*MinCount or Ctr*n*MaxCount.

- 0 = Ring Counter
- 1 = Linear Counter

See page 2-14 for a description of ring and linear counter operation.

**IMPORTANT** Do not change this value while the counter is enabled. Attempting to do so will result in a BadModConfigUpdate error. See page 5-13 for a full list of prohibited settings.

Configuration	Array Words	15 14 13 12 11 10 09 08 07 06 05 04 03 02 01									00				
46 and 47	Range 0 High Limit							Range	eOTo11	[0].Higl	hLimit				-
48 and 49	Range 0 Low Limit							Range	eOTo11	[0].Lov	/Limit				
52 and 53	Range 1 High Limit							Range	eOTo11	[1].Higl	hLimit				
54 and 55	Range 1 Low Limit							Range	eOTo11	[1].Lov	/Limit				
58and 59	Range 2 High Limit							Range	eOTo11	[2].Higl	hLimit				
60 and 61	Range 2 Low Limit							Range	eOTo11	[2].Lov	/Limit				
64 and 65	Range 3 High Limit							Range	eOTo11	[3].Higl	hLimit				
66 and 67	Range 3 Low Limit							Range	eOTo11	[3].Lov	/Limit				
70 and 71	Range 4 High Limit		RangeOTo11[4].HighLimit												
72 and 73	Range 4 Low Limit		Range0To11[4].LowLimit												
76 and 77	Range 5 High Limit		RangeOTo11[5].HighLimit												
78 and 79	Range 5 Low Limit		Range0To11[5].LowLimit												
82 and 83	Range 6 High Limit							Range	eOTo11	[6].Higl	hLimit				
84 and 85	Range 6 Low Limit							Range	eOTo11	[6].Lov	/Limit				
88 and 89	Range 7 High Limit							Range	eOTo11	[7].Higl	hLimit				
90 and 91	Range 7 Low Limit							Range	eOTo11	[7].Lov	/Limit				
94 and 95	Range 8 High Limit							Range	eOTo11	[8].Higl	hLimit				
96 and 97	Range 8 Low Limit							Range	eOTo11	[8].Lov	/Limit				
100 and 101	Range 9 High Limit	Range0To11[9].HighLimit													
102 and 103	Range 9 Low Limit	RangeOTo11[9].LowLimit													
106 and 107	Range 10 High Limit							Range	OTo11[	10].Hig	hLimit				
108 and 109	Range 10 Low Limit							Range	0To11[	10].Lov	wLimit				
112 and 113	Range 11 High Limit							Range	0To11[	11].Hig	hLimit				
114 and 115	Range 11 Low Limit	RangeOTo11[11].LowLimit													

# Range High Limit (RangeOTo11[*n*].HighLimit) and Range Low Limit (RangeOTo11[*n*].LowLimit)

These values, which represent a count value or rate value, depending upon the programed Type, are used for range comparison. When the rate value is equal to Range0To11[*n*].HighLimit or Range0To11[*n*].LowLimit, Range*n* changes state, becoming either active or inactive, depending upon the setting of the Range0To11[*n*].Invert bit.



#### **Object Value (Current Count or Current Rate)**



Range0To11[*n*].HighLimit must be greater than Range0To11[*n*].LowLimit or a configuration error results.

# Range Output Control (RangeOTo11[n].OutputControl)

Configu	ration Array Words	15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00
50	Range 0 Output Control	Out 15	Out 14	Out 13	Out 12	Out 11	Out 10	Out 9	Out 8	Out 7	Out 6	Out 5	Out 4	Out 3	Out 2	Out 1	Out 0
56	Range 1 Output Control	Out 15	Out 14	Out 13	Out 12	Out 11	Out 10	Out 9	Out 8	Out 7	Out 6	Out 5	Out 4	Out 3	Out 2	Out 1	Out 0
62	Range 2 Output Control	Out 15	Out 14	Out 13	Out 12	Out 11	Out 10	Out 9	Out 8	Out 7	Out 6	Out 5	Out 4	Out 3	Out 2	Out 1	Out 0
68	Range 3 Output Control	Out 15	Out 14	Out 13	Out 12	Out 11	Out 10	Out 9	Out 8	Out 7	Out 6	Out 5	Out 4	Out 3	Out 2	Out 1	Out 0
74	Range 4 Output Control	Out 15	Out 14	Out 13	Out 12	Out 11	Out 10	Out 9	Out 8	Out 7	Out 6	Out 5	Out 4	Out 3	Out 2	Out 1	Out 0
80	Range 5 Output Control	Out 15	Out 14	Out 13	Out 12	Out 11	Out 10	Out 9	Out 8	Out 7	Out 6	Out 5	Out 4	Out 3	Out 2	Out 1	Out 0
86	Range 6 Output Control	Out 15	Out 14	Out 13	Out 12	Out 11	Out 10	Out 9	Out 8	Out 7	Out 6	Out 5	Out 4	Out 3	Out 2	Out 1	Out 0
92	Range 7 Output Control	Out 15	Out 14	Out 13	Out 12	Out 11	Out 10	Out 9	Out 8	Out 7	Out 6	Out 5	Out 4	Out 3	Out 2	Out 1	Out 0
98	Range 8 Output Control	Out 15	Out 14	Out 13	Out 12	Out 11	Out 10	Out 9	Out 8	Out 7	Out 6	Out 5	Out 4	Out 3	Out 2	Out 1	Out 0
104	Range 9 Output Control	Out 15	Out 14	Out 13	Out 12	Out 11	Out 10	Out 9	Out 8	Out 7	Out 6	Out 5	Out 4	Out 3	Out 2	Out 1	Out 0
110	Range 10 Output Control	Out 15	Out 14	Out 13	Out 12	Out 11	Out 10	Out 9	Out 8	Out 7	Out 6	Out 5	Out 4	Out 3	Out 2	Out 1	Out O
116	Range 11 Output Control	Out 15	Out 14	Out 13	Out 12	Out 11	Out 10	Out 9	Out 8	Out 7	Out 6	Out 5	Out 4	Out 3	Out 2	Out 1	Out O

These 16-bit words indicate which outputs should be enabled when a range is active. When range n is enabled, this word is combined with the other range output masks as described in Output Off Mask (OutputOffMask.0 through OutputOffMask.15) on page 4-23 and Output On Mask (OutputOnMask.0 through OutputOnMask.15) on page 4-22.

Range Co	nfigurat	tion Flags
----------	----------	------------

Config	Configuration Array Words 15 14				12	11	10	09	08	07	06	05	04	03	02	01	00
51	Range 0 Configuration Flags		Not Used						Inv	Not Used			Туре	Not	Not Used		isCtr
57	Range 1 Configuration Flags				Not Use	d			Inv	١	lot Use	d	Туре	Not Used		ToTh	isCtr
63	Range 2 Configuration Flags				Not Use	d			Inv	١	lot Use	d	Туре	Not	Jsed	ToTh	isCtr
69	Range 3 Configuration Flags				Not Use	d			Inv	Ν	lot Use	d	Туре	Not	Jsed	ToThisCtr	
75	Range 4 Configuration Flags		Not Used					Inv	Not Used			Туре	Not	Jsed	isCtr		
81	Range 5 Configuration Flags		Not Used				Inv	Ν	lot Use	d	Туре	Not	Jsed	ToTh	isCtr		
87	Range 6 Configuration Flags				Not Use	d			Inv	Not Used			Туре	Not	Jsed	ToTh	isCtr
93	Range 7 Configuration Flags				Not Use	d			Inv	Not Used			Туре	Not	Jsed	ToTh	isCtr
99	Range 8 Configuration Flags				Not Use	d			Inv	Not Used			Туре	Not	Jsed	ToTh	isCtr
105	Range 9 Configuration Flags	Not Used				Inv	Not Used			Туре	Not	Jsed	ToTh	isCtr			
111	Range 10 Configuration Flags		Not Used					Inv	Not Used			Туре	Not	Jsed	ToTh	isCtr	
117	Range 11 Configuration Flags		Not Used				Inv	Not Used			Туре	Not	Jsed	ToTh	isCtr		

ToThisCtr (RangeOTo11[n].ToThisCounter)

This 2-bit value indicates which counter is used in the range comparison for range n, as shown in the table below.

**Table 4.6 Range Counter Number Determination** 

Bit 01	Bit 00	Counter
0	0	0
0	1	1
1	0	2
1	1	3

IMPORTANT

If this value is greater than NumberOfCounters, a configuration error occurs.

Type (RangeOTo11[n].Type)

This bit indicates which type of value to use for the range comparison in range n. This value and Range0To11[n].ToThisCounter determine the current value that is used in range comparison as the rate or count value.

Range0To11[ <i>n</i> ].Type	Range Type
0	Count Value
1	Rate Value

#### Inv (RangeOTo11[n].Invert)

This bit indicates whether the range n should be active inside or outside the Range0To11[n].Low Limit and Range0To11[n].HighLimit window.

- 0 = The range *n* is active when the rate or count value is at or between Range0To11[*n*].Low Limit and Range0To11[*n*].HighLimit. When the range is active, the RangeActive.*n* bit is set. When the range is active and enabled, the outputs indicated in the Range Output Control word are activated.
- 1 = The range *n* is active when the rate or count value is lower than or equal to Range0To11[*n*].LowLimit or higher than or equal to Range0To11[*n*].HighLimit. When the range is active, the RangeActive.*n* bit is set. When the range is active and enabled, the outputs indicated in the Range Output Control word are applied.



Ranges can be active in overflow, underflow, and rollover situations.

# **Output Array**

The Output Array, which consists of 34 words, allows you to access the module's real-time output data to control the module. The default value is all zeros.

**IMPORTANT** The Output Array contains dynamic configuration data. The settings in the Output Array must be compatible with the settings in the Configuration Array.

For example, do not attempt to set Counter Control Bits for a given counter in the Output Array unless NumberOfCounters in the Configuration Array indicates that the counter is declared to be used.

IMPORTANT

All *Not Used* bits (shaded in Table 4.7) must be set to 0 or the InvalidOutput bit in the Input Array will be set. When the InvalidOutput bit is set, the entire Output Array is rejected until an Output Array that does not have this error is sent.

#### Table 4.7 Output Array

								В	it								<b>F</b>
vvora	15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00	Function
0	Out 15	Out 14	Out 13	Out 12	Out 11	Out 10	Out 9	Out 8	Out 7	Out 6	Out 5	Out 4	Out 3	Out 2	Out 1	Out O	Output On Mask
1	Out 15	Out 14	Out 13	Out 12	Out 11	Out 10	Out 9	Out 8	Out 7	Out 6	Out 5	Out 4	Out 3	Out 2	Out 1	Out O	Output Off Mask
2	R15	R14	R13	R12	R11	R10	R9	R8	R7	R6	R5	R4	R3	R2	R1	RO	Range Enable
3								Not l	Jsed								Not Used
4				Not	Used				RBF			١	Vot Use	d			Reset Blown Fuse
5			Not	Used			RPW	RREZ	Z Inh	Z Inv	D Inh	D Inv	RU	RO	SP	En	Counter 0 Control Bits
6			Not	Used			RPW	RREZ	Z Inh	Z Inv	D Inh	D Inv	RU	RO	SP	En	Counter 1 Control Bits
7			Not	Used			RPW		Not	Used		D Inv	RU	RO	SP	En	Counter 2 Control Bits
8			Not	Used			RPW		Not	Used		D Inv	RU	RO	SP	En	Counter 3 Control Bits
9								Not l	Jsed								Not Used
10 11						I	Range12	2To15[0	].HiLim	OrDirW	r						Range High Limit or Direct Write Value
12 13							Rang	e12To15	5[0].Lov	/Limit							Range Low Limit
14							Range12	2To15[0	].Outpu	tContro							Range Output Control
15			١	lot Use	d			lnv	Not	Used	LDW	Туре	Not	Used	ToTh	nisCtr	Range Configuration Flags
16 17	Rang								].HiLim	OrDirW	r				•		Range High Limit or Direct Write Value
18 19							Rang	e12To15	ō[1].Lov	<i>v</i> Limit							Range Low Limit
20						ŀ	Range12	2To15[1	].Outpu	tContro							Range Output Control
21			Ν	lot Use	d			Inv	Not	Used	LDW	Туре	Not	Used	ToTh	nisCtr	Range Configuration Flags

#### Table 4.7 Output Array

								В	lit								
Word	15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00	Function
22 23			•				Range1	2To15[2	?].HiLim	OrDirW	r						Range High Limit or Direct Write Value
24 25							Rang	e12To1	5[2].Lov	vLimit							Range Low Limit
26							Range1	2To15[2	?].Outpu	tContro							Range Output Control
27			1	Not Use	d			lnv	Not	Used	LDW	Туре	Not	Used	ToTh	iisCtr	Range Configuration Flags
28 29		Range12To				2To15[3	I].HiLim	OrDirW	r						Range High Limit or Direct Write Value		
30 31							Rang	e12To1!	5[3].Lov	vLimit							Range Low Limit
32							Range1	2To15[3	].Outpu	tContro							Range Output Control
33			1	Not Use	d			lnv	Not	Used	LDW	Туре	Not	Used	ToTh	iisCtr	Range Configuration Flags

# Output On Mask (OutputOnMask.0 through OutputOnMask.15)

Output Array Word 0	15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00
Output On Mask	Out 15	Out 14	Out 13	Out 12	Out 11	Out 10	Out 9	Out 8	Out 7	Out 6	Out 5	Out 4	Out 3	Out 2	Out 1	Out O

This word allows you to turn on any output, real or virtual, when the corresponding bit is set. This mask is logically OR'ed with the range masks but logically AND'ed with the Output Off Mask Word described on page 4-23.

Using the Output On Mask, all of the module's outputs can be turned on directly by the user control program, like discrete outputs. A bit which is set in the mask turns on the corresponding real or virtual output.

See "Output Control" on page 2-23 and "Output Control Example" on page 2-30 for more information about output determination.



The corresponding Output Off Mask bit must be set to enable this bit.



# Output Off Mask (OutputOffMask.0 through OutputOffMask.15)

Output Array Word 1	15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00
Output Off Mask	Out 15	Out 14	Out 13	Out 12	Out 11	Out 10	Out 9	Out 8	Out 7	Out 6	Out 5	Out 4	Out 3	Out 2	Out 1	Out O

This word turns OFF any output, real or virtual, when the corresponding bit is reset. This mask has veto power over all the Range masks and the Output On Mask described above. It is logically AND'ed with the results of those masks. See "Output Control" on page 2-23 and "Output Control Example" on page 2-30 for more information about output determination.



This mask can be overridden when a safe state is indicated.

# Range Enable (RangeEn.0 through RangeEn.15)

Output Array Word 2	15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00
Range Enable	R15	R14	R13	R12	R11	R10	R9	R8	R7	R6	R5	R4	R3	R2	R1	RO

When the bit corresponding to the range number is set, Range[n].OutputControl is applied whenever the range is active.

# **RBF - Reset Blown Fuse (ResetBlownFuse)**

Output Array Word 4	15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00
Reset Blown Fuse				Not	Used				RBF			Ν	lot Use	d		

When the OvercurrentLatchOff bit is set and an overcurrent condition has occurred, the real output remains off until this bit is cycled from 0 to 1 (rising edge).

#### **Control Bits**

Output Array Words 5 to 8	15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00
Counter 0 Control Bits (Word 5)		Not Used					RPW	RREZ	Z Inh	Z Inv	D Inh	D Inv	RU	RO	SP	En
Counter 1 Control Bits (Word 6)			Not	Jsed			RPW	RREZ	Z Inh	Z Inv	D Inh	D Inv	RU	RO	SP	En
Counter 2 Control Bits (Word 7)		Not Used					RPW		Not	Used		D Inv	RU	RO	SP	En
Counter 3 Control Bits (Word 8)			Not	Jsed			RPW		Not	Used		D Inv	RU	RO	SP	En

The control bits for counter (n) are described below.



#### En - Enable Counter (CtrnEn)

This bit, when set (1), enables the inputs to be counted. When reset (0), this bit inhibits any activity of the A or B inputs from affecting the count, pulse interval, and rate values.

#### SP - Soft Preset (CtrnSoftPreset)

A 0 to 1 transition of this bit causes counter (n) to be preset, changing the count to the value in Ctr*n*Preset.

RCO - Reset Counter Overflow (CtrnResetCounterOverflow)

A 0 to 1 transition of this bit causes the corresponding Ctr[n]Overflow bit to be reset.

*RCU - Reset Counter Underflow (CtrnResetCounterUnderflow)* 

A 0 to 1 transition of this bit causes the corresponding Ctr[n]Underflow bit to be reset.

#### D Inv - Direction Invert (Ctrn DirectionInvert)

This bit, when set, inverts the direction of the counter (n). If the Ctr*n*DirectionInhibit bit is set when this bit is:

- 0 the resulting direction is up, increasing counts
- 1 the resulting direction is down, decreasing counts

#### D Inh - Direction Inhibit (CtrnDirectionInhibit)

This bit, when set, inhibits the direction of the input signal from being used by the module.

#### Z Inv - Z Invert (CtrnZInvert)

When set, this bit inverts the Zn value. The Zn value is also affected by the CtrnZInhibit bit. If the CtrnZInhibit is set, the module uses CtrnZInvert for all internal Z activities, preset, hold and store. Input state Zn is not affected by this bit.

#### Z Inh - Z Inhibit (CtrnZInhibit)

When set, this bit inhibits the Zn state from being used by the module.

RREZ - Reset Rising Edge Z (CtrnResetRisingEdgeZ)

A 0 to 1 transition causes the Ctr[n].RisingEdgeZ bit to be reset.

*RPW - Reset Counter Preset Warning (CtrnResetCtrPresetWarning)* 

A 0 to 1 transition causes the Ctr[n]PresetWarning bit to be reset.

# Range High Limit or Direct Write Value (Range12To15[*n*].HiLimOrDirWr)

	Output Array Words	15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00
10 and 11	Range 12 High Limit Direct Write Value						Ra	nge12	To15[0	)].HiLir	nOrDir	Wr					
16 and 17	Range 13 High Limit Direct Write Value						Ra	nge12	To15[1	].HiLir	nOrDir	Wr					
22 and 23	Range 14 High Limit Direct Write Value	ue Range12To15[2].HiLimOrDirWr															
28 and 29	Range 15 High Limit Direct Write Value						Ra	nge12	To15[3	8].HiLir	nOrDir	Wr					

This value may be used in one of two ways, depending on the setting of the Load Direct Write (Range12To15[*n*].LoadDirectWrite) bit.

#### When Load Direct Write = 0

When Range12To15[n].LoadDirectWrite = 0, then Range12To15[n].HiLimOrDirWr is used in the range comparison (range represents a count value or a rate value according to the programmed range type, Range12To15[n].Type).

When the range value is equal to Range12To15[*n*].HiLimOrDirWr, Range*n* will change state. The range will become active or inactive depending on the Range12To15[*n*].Invert bit.







Range12To15[n].HiLimOrDirWr must be higher than the Range12To15[n].LowLimit or the InvalidRangeLimitn error flag in the Input Array will be set.

TIP

Range12To15[*n*].HiLimOrDirWr may be higher than the maximum rate or count value. For example, when the object value is a rate, Range12To15[*n*].HiLimOrDirWr may be programmed

in excess of 1,000,000 with no configuration error.

When Load Direct Write = 1

When Range12To15[*n*].LoadDirectWrite = 1, then Range12To15[*n*].HiLimOrDirWr is used to change the Ctr[*n*].CurrentCount to Range12To15[*n*].HiLimOrDirWr.

When the Range12To15[*n*].LoadDirectWrite bit transitions from 0 to 1, then Range12To15[*n*].HiLimOrDirWr is loaded into Ctr[n].CurrentCount (where *n* is the counter indicated in Range12To15[*n*].ToThisCounter).



When Ctr*n*SoftPreset and a Range12To15[*n*].LoadDirectWrite to counter *n* are indicated at the same time, only the Ctr*n*SoftPreset

will occur. When more than one range indicates a Range12To15[n].LoadDirectWrite to a single counter, only the one from the lowest designated range will take effect.

### Range Low Limit (Range12To15[n].LowLimit)

	Output Array Words	15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00
12 and 13	Range 12 Low Limit							Range	12To1	5[0].Lo	wLimit	t					
18 and 19	Range 13 Low Limit	Range12To15[1].LowLimit															
24 and 25	Range 14 Low Limit	Range12To15[2].LowLimit															
30 and 31	Range 15 Low Limit							Range	12To1	5[3].Lo	wLimit	t					

This value is used in the range comparison. It is the complement of the Range12To15[n].HiLimOrDirWr value in setting the compare window.

When the rate or count value is equal to Range12To15[n].LowLimit, the range will change state – opposite of the action at Range12To15[n].HiLimOrDirWr. The range will become active or inactive depending on the Range12To15[n].Invert bit.



Range12To15[*n*].LowLimit must be lower than the Range12To15[*n*].HiLimOrDirWr or the InvalidRangeLimit*n* error flag in the Input Array will be set.



# Range Output Control (Range12To15[n].OutputControl)

	Output Array Words	15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00
14	Range 12 Output Control						R	ange12	2To15[0	].Outpi	utContr	ol					
20	Range 13 Output Control	Range12To15[1].OutputControl															
26	Range 14 Output Control	Range12To15[2].OutputControl															
32	Range 15 Output Control						R	ange12	2To15[3	].Outpi	utContr	ol					

This 16-bit word indicates which outputs should be on (corresponding bit set in this word) when a range is active. When Range*n* is enabled and active, Range12To15[*n*].OutputControl will be logically OR'ed with other Range12To15[*n*].OutputControl masks and the OutputOnMask.*n* etc., as described on page 4-22.

When Range12To15[*n*].LoadDirectWrite is set, Range12To15[*n*].OutputControl is ignored.

# **Range Configuration Flags (12 through 15)**

	Output Array Words	15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00
15	Range 12 Configuration Flags		Not Used						Inv	Not	Used	LDW	Туре	Not l	Jsed	ToTh	isCtr
21	Range 13 Configuration Flags		Not Used						Inv	Not	Used	LDW	Туре	Not l	Jsed	ToTh	isCtr
27	Range 14 Configuration Flags		Not Used						Inv	Not	Used	LDW	Туре	Not l	Jsed	ToTh	isCtr
33	Range 15 Configuration Flags		Not Used						Inv	Not	Used	LDW	Туре	Not l	Jsed	ToTh	isCtr

#### ToThisCtr - Range Counter Number (Range12To15[n].ToThisCounter)

This 2-bit value indicates which counter will be used in the range comparison or Range12To15[n].LoadDirectWrite. The counter is indicated as follows:

#### **Table 4.8 Range Counter Number Determination**

Bit 01	Bit 00	Counter
0	0	0
0	1	1
1	0	2
1	1	3

If Range12To15[*n*].ToThisCounter is set to a number larger than NumberOfCounters in the Configuration Array, then the InvalidCtrAssignToRange*n* error bit in the Input Array will be set.

#### *Type - RangeType (Range12To15[n].Type)*

This bit value indicates which type of value to use for the range comparison in Range. That is, the Range12To15[n].ToThisCounter, from above, and this Range12To15[n].Type value determine the rate or count value, the current value which is compared to, for the range comparison. The type of value is indicated as follows:

- 0 = Count Value
- 1 = Rate Value

When Range12To15[*n*].LoadDirectWrite is set Range12To15[*n*].Type is ignored.

LDW - Load Direct Write (Range12To15[n].LoadDirectWrite)

A 0 to 1 transition of this bit causes counter (n)'s current count value to change to the value of Range12To15[n].HiLimOrDirWr.

IMPORTANT	The write occurs according to the internal timings of the module and the system. For the most predictable results, the counter should be disabled or stopped while performing this action.
IMPORTANT	If both Ctr <i>n</i> SoftPreset and Range12To15[ <i>n</i> ].HiLimOrDirWr transition to 1 during the same Output Array update, only the Ctr <i>n</i> SoftPreset occurs. Range12To15[ <i>n</i> ].HiLimOrDirWr is ignored.

#### Inv - Range Invert (Range12To15[n].Invert)

Indicates the active portion of Range*n*. When Range12To15[*n*].Invert = 0, the outputs are activated when the range value is at or between the Range12To15[*n*].LowLimit and Range12To15[*n*].HiLimOrDirWr. When Range12To15[*n*].Invert = 1, the outputs are activated when the range is at or outside the range limits.



#### **Object Value (Current Count or Current Rate)**

# **Input Array**

The Input Array, which consists of 35 words, allows read-only access to the module's input data via word and bit access. The Input Array is described below. The functions are described in more detail in the sections following the table.

IMPORTANT	During the non-run states (program and fault), the module continues to update the Input Array (continues counting, etc). Depending on the bus master, you may not see this.
TIP	Status bits for a particular counter reflect the



status bits for a particular counter reflect the configuration settings for that counter. To receive valid status, the counter must be enabled and the module must have stored a valid configuration for that counter.

### Table 4.9 Input Array

									Bi	t							
Word	15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00	Function
0						Not Use	ed				Z1	B1	A1	Z0	BO	A0	Input State
1							R	eadbacl	k.0 throu	gh Readb	ack.15	•					Readback
2	Inva Inva	lidRar thrc lidRar	ngeLim ough ngeLim	nit12 nit15	Invalid Invalid	CtrAssi thro CtrAssi	gnToRa ugh gnToRa	ange12 ange15	Gen Error	Invalid Output	Mod Config	Not Used	Out	00verc Out30	urrent th vercurre	irough nt	Status Flags
3							Ranç	geActive	e.0 throu	gh Range	Active.1	5					Range Active
4								Ct	r[0] Curr	entCount							Counter O Current Count
5								01	.[o].ou.i	oncoount							
6								Ct	tr[0].Stor	edCount							Counter 0 Stored Count
7																	
8								C	tr[0].Cur	rentRate							Counter 0 Current Rate
9																	
10								Ct	r[0].Puls	elnterval							Counter 0 Pulse Interval
12					Not I	lsed				COPW	RV	Not Used	IDW	RF7	CUdf	COvf	Counter O Status Flags
13									NotL	lsed							Not Used
14																	
15								Ct	r[1].Curr	entCount							Counter 1 Current Count
16		Ctr[1].StoredCount															
17		Ctr[1].StoredCount															Counter 1 Stored Count
18		Ctr[1] CurrentBate														Counter 1 Current Bate	
19								0	u[1].0ui	Iontituto							
20								Ct	r[1].Puls	elnterval							Counter 1 Pulse Interval
21										0.1511.1	514						
22					Not l	Jsed			NL	C1PW	RV	IC	IDW	REZ	CUdf	COvt	Counter 1 Status Flags
23									NOT L	Jsea							Not Used
24								Ct	r[2].Curr	entCount							Counter 2 Current Count
25																	
27								С	tr[2].Cur	rentRate							Counter 2 Current Rate
28					Not l	Jsed				C2PW	RV	IC	IDW	Not	CUdf	COvf	Countor 2 Status Flags
20									NL					Used			
29									Not L	lsed							Not Used
30								Ct	r[3].Curr	entCount							Counter 3 Current Count
32																	
33								C	tr[3].Cur	rentRate							Counter 3 Current Rate
34					Not	Jsed				C3PW	RV	IC	IDW	Not Used	CUdf	COvf	Counter 3 Status Flags
														1		·	I

# Input State (InputStateA0 through InputStateZ1)

Input Array Word 0	15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00
Input State					Not	Jsed					Z1	B1	A1	ZO	BO	A0

This word indicates the state of the real (physical) inputs after filtering.

• 1 = On

• 0 = Off

# Readback (Readback.0 through Readback.15)

Input Array Word 1	15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00
Readback						F	Readbac	k.0 throu	ugh Rea	dback.15	ō					

This input word reflects counter's module-directed status of all sixteen outputs, real and virtual.

• 1 = On

• 0 = Off

# **Status Flags**

Input Array Word 2	15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00
Status Flags	Inv Inv	validRar thro validRar	ngeLimit ngeLimit ngeLimit	t12 t15	Inval Inval	idCtrAssi thro idCtrAssi	ignToRan ough ignToRan	ge12 ge15	Gen Error	Invalid Output	Mod Config	Not Used	0) 0)	ut00ve thro ut30ve	ercurre ugh ercurre	nt nt

Output Overcurrent (OutOOvercurrent to Out3OverCurrent)

The output overcurrent bits are set (1) when the module is in an overcurrent condition. These bits also show whether the output is latched off, because the output(s) remain in the off state and these bits remain on until the ResetBlownFuse bit is used.

#### Module Configured (ModConfig)

Word 2, bit 5 is set by the module after it has accepted all of the configuration data. When set (1), this bit confirms that the module received and accepted valid configuration data. When reset (0), this bit indicates that the module is still checking for errors or contains errors and the old configuration is still being used.



#### Invalid Output (InvalidOutput)

- 1 = an unused bit in the Output Array is set
- 0 = no unused bits in the Output Array are set

When this error occurs, the entire Output Array is rejected until an Output Array that does not have this error is sent.

#### Error (GenError)

When this bit is set (1), it indicates one or more of the following errors for the Input Array:

- Out*n*Overcurrent
- InvalidRangeLimitn
- InvalidCtrAssignToRangen
- InvalidOutput
- Ctr[n].Overflow
- Ctr[n].Underflow
- Ctr[*n*].InvalidDirectWrite
- Ctr[n].InvalidCounter
- Ctr[n].PresetWarning

where n indicates the counter number.

To determine which error has set the GenError bit, identify which bit is set. This could be done by using a subroutine to examine these bits in the Input Array.



Ctr[n].RateValid does not set the GenError bit.

Invalid Counter Assigned to Range (InvalidCtrAssignToRange12 through InvalidCtrAssignToRange15)

InvalidCtrAssignToRange12 is set when the indicated range in the Output Array refers to a non-existent counter.

- It is set (1) when Range12To15[*n*].ToThisCounter > NumberOfCounters.
- It is cleared (0) when Range12To15[*n*].ToThisCounter ≤ NumberOfCounters.

When this error occurs, the entire Output Array is rejected until a valid configuration is detected.

Invalid Range Limit (InvalidRangeLimit12 through InvalidRangeLimit15)

This bit is set when the range limits are invalid according to the limitations indicated in Range12To15[n].HiLimOrDirWr and Range12To15[n].LowLimit in the Output Array.

- 1 = Range limits are invalid.
- 0 = no error

When this error occurs, the entire Output Array is rejected until a valid configuration is detected.

# Range Active (RangeActive.0 through RangeActive.15)

Input Array Word 3	15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00
Range Active						Rar	igeActiv	e.0 throi	ugh Ran	geActiv	e.15					

This word reflects the status of all of the ranges. When a count or rate meets the criteria programmed for a given range, the range is active.

- 1 = active
- 0 = inactive/false



When the range is enabled and active, the output mask for that range is applied.

# Current Count (Ctr[n].CurrentCount)

	Input Array Words	15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00
4	Counter 0 Current Count		•	•			-	•	Ct	r[0] Curr	entCount						
5									01	ilo].cuii	entoount						
14	Counter 1 Current Count								Ct	r[1] Curr	rontCount						
15									01	i[i].Guii	entoount						
24	Counter 2 Current Count								Ct	r[2] Curr							
25									01	i[2].0uii	entoount						
30	Counter 3 Current Count								۲t	r[3] Curr	rentCount						
31									01	101.0011	GIROOUIII						

This is the 32-bit count value from the counter.

# Stored Count (Ctr[n].StoredCount)

	Input Array Words	15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00
6	Counter 0 Stored Count								Ct	tr[N] Stor	redCount						
7									01		eucount						
16	Counter 1 Stored Count								Ct	tr[1] Stor	radCount						
17									01		eucount						

This is the last stored 32-bit value from counter (n). The count value is stored depending on the Ctr*n*Config.StorageMode and Z*n* inputs.

When a storage event occurs, the Ctr[n].RisingEdgeZ bit is set, indicating that the value is new. If more than one Zn occurs before the Ctr[n].RisingEdgeZ bit is reset (using the CtrnResetRisingEdgeZbit), the Ctr[n].StoredCount word will contain only the last Ctr[n].StoredCount value. There is no indication that the data has been overwritten.

# Current Rate (Ctr[0].CurrentRate to Ctr[3].CurrentRate)

	Input Array Words	15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00
8	Counter 0 Current Rate						•	•	د	tr[0] Cur	rontPato		•				
9									U	u [U].Gui	reninale						
18	Counter 1 Current Rate								C	tr[1] Cur	rontBato						
19									0	u[1].0ui	rentiate						
26	Counter 2 Current Rate								C	tr[2] Cur	rontBato						
27									U	u[2].0ui	rentiate						
32	Counter 3 Current Rate								ſ	tr[3] Cur	rontRato						
33									0	սլշյ.օս	rentrate						

This 32-bit value is the current rate value, scaled by Ctr*n*Scalar, from the counter. This uses the Cyclic Rate Calculation Method (see page 2-19 for more information).

Rate-based ranges use this value for comparisons, even when the Ctr[n].RateValid bit is zero.

IMPORTANT

This value is only current when the Ctr[n].RateValid bit is set (1).

# Pulse Interval (Ctr[0].PulseInterval and Ctr[1].PulseInterval)

	Input Array Words	15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00
10	Counter 0 Pulse Interval								Ct	r[0] Pulo	alatoryal						
11									01		ennervar						
20	Counter 1 Pulse Interval								Ct	r[1] Dulo	alatoryal						
21									01	i[i].i uis	ennervar						

This is the time, in microseconds, between the last two pulses for the counter. The pulses indicated here are those transitions on which the count value can change. For example, in quadrature X1 mode, these are the successive rising edges of A only.

If more than two pulses have occurred since the value was last read, the value indicates only the time between the *last two pulses* that have been processed.

#### **Status Flags**

	Input Array Words	15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00
12	Counter 0 Status Flags		•	•		Not	Used				COPW	RV	Not Used	IDW	REZ	CUdf	COvf
22	Counter 1 Status Flags					Not	Used				C1PW	RV	IC	IDW	REZ	CUdf	COvf
28	Counter 2 Status Flags					Not	Used				C2PW	RV	IC	IDW	Not	CUdf	COvf
34	Counter 3 Status Flags					Not	Used				C3PW	RV	IC	IDW	Used	CUdf	COvf

The status bits for the counter (n) are described below.

#### COvf - Count Overflow (Ctr[0].Overflow to Ctr[3].Overflow)

For linear counters, this bit is set when the counter is, or has been, in an overflow condition. For ring counters, this bit is set when the counter has rolled over. COvf is reset when the Ctr*n*ResetCountOverflow bit transitions from 0 to 1.

See Counter Types on page 2-14 for more information about linear and ring counters.

#### *CUdf - Count Underflow (Ctr[0].Underflow to Ctr[3].Underflow)*

For linear counters, this bit is set when the counter is, or has been, in an underflow condition. For ring counters, this bit is set when the counter has rolled under. CUdf is reset when the CtrnResetCountUnderflow bit transitions from 0 to 1.

See Counter Types on page 2-14 for more information about linear and ring counters.

#### REZ - Rising Edge Z (Ctr[0].RisingEdgeZ to Ctr[1].RisingEdgeZ)

This bit is set (1) when Zn, as modified by the Ctr*n*ZInvert and Ctr*n*ZInhibit bits, has a rising edge. It is reset (0) by a 0 to 1 transition of the Ctr*n*ResetRisingEdgeZ bit in the Output Array. *N* is equal to 0 or 1 depending upon which input is used, Z0 or Z1.

# *IDW - Invalid Direct Write (Ctr[0].InvalidDirectWrite to Ctr[3].InvalidDirectWrite)*

This bit is set when the Range12To15[*n*].HiLimOrDirWr is invalid. (For example, if Ctr*n*MaxCount < Range12To15[*n*].HiLimOrDirWr or Range12To15[*n*].HiLimOrDirWr < Ctr*n*MinCount.)

When this error occurs, the entire Output Array is rejected until a valid configuration is detected.

#### IC - Invalid Counter (Ctr[1].InvalidCounter to Ctr[3].Invalid Counter)

When set (1) this bit indicates that an invalid control bit is set for the counter. Depending on the value of NumberOfCounters, the following errors will occur:

- If NumberOfCounters < 1, then setting one of the control bits for Counter 1 will result in input error flag Ctr[1].InvalidCounter.
- If NumberOfCounters < 2, then setting one of the control bits for Counter 2 will result in input error flag Ctr[2].InvalidCounter.
- If NumberOfCounters < 3, then setting one of the control bits for Counter 3 will result in input error flag Ctr[3].InvalidCounter.

When this error occurs, the entire Output Array is rejected until an Output Array that does not have this error is sent.

The control bits are shown on page 4-24.

RV - Rate Valid (Ctr[0].RateValid to Ctr[3].RateValid)

This bit is set (1) when the rate value indicated in Ctr[n].CurrentRate is current. When this bit is reset (0), Ctr[n].CurrentRate is frozen at the last known good value.

This bit is reset when the Ctr[n].Overflow or Ctr[n].Underflow bits have been set during the last CtrnCyclicRateUpdateTime period. See page 2-21 for more Rate Valid reset conditions.

*CnPW - Counter Preset Warning (Ctr[0].PresetWarning to Ctr[3].PresetWarning)* 

This bit is set when Ctr[n].CurrentCount has been forced, by the module, to the CtrnPreset value. This will happen when a Configuration Array is accepted which sets:

Ctr*n*MinCount > Ctr[*n*].CurrentCount, or

Ctr*n*MaxCount < Ctr[*n*].CurrentCount.

This bit is reset by a 0 to 1 transition of the CtrnResetCtrPresetWarning bit in the Output Array.



You must manually reset C*n*PW, COvf, CUdf and REZ (but not IDW, RV or IC) to enable them to be set again.

# **Diagnostics and Troubleshooting**

This chapter describes troubleshooting the module. This chapter contains information on:

- safety considerations when troubleshooting
- module vs. counter operation
- the module's diagnostic features
- critical vs. non-critical errors
- error codes

# **Safety Considerations**

Safety considerations are an important element of proper troubleshooting procedures. Actively thinking about the safety of yourself and others, as well as the condition of your equipment, is of primary importance.

The following sections describe several safety concerns you should be aware of when troubleshooting your control system.

> Never reach into a machine to actuate a switch because unexpected motion can occur and cause injury.

Remove all electrical power at the main power disconnect switches before checking electrical connections or inputs/outputs causing machine motion.

# **Indicator Lights**

ATTENTION

When any LED on the module is illuminated, it indicates that power is applied to the module.

#### **Stand Clear of the Machine**

When troubleshooting any system problem, have all personnel remain clear of the machine. The problem could be intermittent, and sudden unexpected machine motion could occur. Have someone ready to operate an emergency stop switch in case it becomes necessary to shut off power to the machine.

# **Program Alteration**

There are several possible causes of alteration to the user program, including extreme environmental conditions, Electromagnetic Interference (EMI), improper grounding, improper wiring connections, and unauthorized tampering. If you suspect a program has been altered, check it against a previously saved program on an EEPROM or UVPROM memory module.

# **Safety Circuits**

Circuits installed on the machine for safety reasons, like over-travel limit switches, stop push buttons, and interlocks, should always be hard-wired to the master control relay. These devices must be wired in series so that when any one device opens, the master control relay is de-energized, thereby removing power to the machine. Never alter these circuits to defeat their function. Serious injury or machine damage could result.
Module Operation vs. Counter Operation	<ul><li>The module performs operations at two levels:</li><li>module level</li><li>counter level</li></ul>				
	Module-level operations include functions such as power-up, configuration, and communication with a bus master, such as a MicroLogix 1500 controller.				
	Counter-level operations include counter-related functions, such as data conversion and overflow or underflow detection.				
	Internal diagnostics are performed at both levels of operation. When detected, module error conditions are immediately indicated by the module status LED. Both module hardware and configuration error conditions are reported to the controller. Counter overflow or underflow conditions are reported in the module's input data table. Module hardware errors are typically reported in the controller's I/O status file. Refer to your controller manual for details.				
Counter Defaults	When the module powers-up, all Output Array and Configuration Array values are set to their default values (see Chapter 4 or Appendix D for default values). All Input Array values are cleared. None of the module data is retentive through a power cycle.				
	<ul><li>In effect, this means that power cycling clears the module:</li><li>stored counts are lost</li><li>faults and flags are cleared</li><li>outputs are off</li></ul>				
	The bus master will attempt to write program data to the Output Array and Configuration Array.				

## **Module Diagnostics**

## **Power-up Diagnostics**

At module power-up, a series of internal diagnostic tests are performed. These diagnostic tests must be successfully completed or the OK LED remains off and a module error results and is reported to the controller.

LED	Color	Indicates				
0 OUT	Amber	ON/OFF logic status of output 0				
1 OUT	Amber	ON/OFF logic status of output 1				
2 OUT	Amber	ON/OFF logic status of output 2				
3 OUT	Amber	ON/OFF logic status of output 3				
FUSE	Red	Overcurrent				
OK	Off	No power is applied.				
	Red (briefly)	Performing self-test.				
	Solid Green	OK, normal operating condition.				
	Flashing Green	OK, module in Program or Fault mode.				
	Solid Red or Amber	Hardware error. Cycle power to the module. If problem persists, replace the module.				
	Flashing Red	Recoverable fault. Reconfigure, reset, or perform error recovery. See section on page 5-5, Non-Critical vs. Critical Module Errors. The OK LED flashes red for all of the error codes in Table 5.6.				
A0	Amber	ON/OFF status of input A0				
A1	Amber	ON/OFF status of input A1				
B0	Amber	ON/OFF status of input B0				
B1	Amber	ON/OFF status of input B1				
Z0	Amber	ON/OFF status of input Z0				
Z1	Amber	ON/OFF status of input Z1				
ALL ON	<ul> <li>Possible causes for all LEDs to be on:</li> <li>Bus Error has occurred: Controller hard fault. Cycle power.</li> <li>During Flash Upgrade of Controller: Normal. Do not cycle power during the Flash Upgrade.</li> <li>All LEDs will flash on briefly during power-up. This is normal.</li> </ul>					

#### **Configuration Diagnostics**

When a configuration is sent, the module performs a diagnostic check to see that the configuration is valid. This results in either a valid ModConfig bit or module configuration error. See Table 5.6 for configuration error codes.

## **Post Configuration Diagnostics**

If the ModConfig bit in the input array is set, then the module has accepted the configuration. Now, on every scan, each channel status flag in the Input Array is examined. The Output Array is checked on each scan for compatibility with the Configuration Array.

+OUT	0 2 FUSE 1 3 OK	
└ NI ()	A0 B0 Z0 A1 B1 Z1 High Speed Counter	

## Non-Critical vs. Critical Module Errors

#### **Non-Critical Errors**

Non-critical module errors are typically recoverable. Non-critical error conditions are indicated by the extended error code. See Table 5.6 Configuration Error Codes on page 5-9.



The OK LED will be in a flashing red state for all of the error codes in Table 5.6.

## **Critical Errors**

Critical module errors are conditions that prevent normal or recoverable operation of the system. When these types of errors occur, the system typically leaves the run or program mode and enters the fault mode of operation until the error can be dealt with. Critical module errors are indicated in Table 5.5 General Common Hardware Error Codes on page 5-8.

## **Module Error Definition**

Module errors are expressed in two fields as four-digit Hex format with the most significant digit as "don't care" and irrelevant. The two fields are "Module Error" and "Extended Error Information". The structure of the module error data is shown below.

#### **Table 5.2 Module Error Definition**

	"Don't C	are" Bit	s	M	odule Er	ror			Ex	xtended	Error In	formati	on		
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
	Hex Digit 4 Hex Digit 3			Hex Digit 2 Hex Digit 1											

### **Module Error Field**

The purpose of the module error field is to classify module errors into three distinct groups, as described in the table below. The type of error determines what kind of information exists in the extended error information field. These types of module errors are typically reported in the controller's I/O status file. Refer to your controller manual for details.

#### **Table 5.3 Module Error Types**

Error Type	Module Error Field Value Bits 11 through 09 (Binary)	Description
No Errors	000	No error is present. The extended error field holds no additional information.
Hardware Errors	001	General and specific hardware error codes are specified in the extended error information field.
Configuration Errors	010	Module-specific error codes are indicated in the extended error field. These error codes correspond to options that you can change directly. For example, the input range or input filter selection.

#### **Extended Error Information Field**

Check the extended error information field when a non-zero value is present in the module error field. Depending upon the value in the module error field, the extended error information field can contain error codes that are module-specific or common to all 1769 modules.



If no errors are present in the module error field, the extended error information field will be set to zero.

#### Hardware Errors

General or module-specific hardware errors are indicated by module error code 1. See Table 5.5 General Common Hardware Error Codes on page 5-8.

#### Configuration Errors

If you set the fields in the configuration file to invalid or unsupported values, the module ignores the invalid configuration, generates a non-critical error, and keeps operating with the previous configuration.

Table 5.6 Configuration Error Codes on page 5-9 lists the possible module-specific configuration error codes defined for the module. Correct the error by providing proper configuration data to the module.

Table 5.4 describes configuration errors in more general terms.

**Table 5.4 Error Conditions by Type of Configuration** 

Programming Words	Error Conditions
General Configuration Bits, Filters and Safe State Words	<ul> <li>Unused or Reserved bit(s) were set.</li> <li>A counter or counters were running when the general configuration bits or filter and safe state words were sent.</li> </ul>
Counter Configuration	<ul> <li>Unused or Reserved bit(s) were set.</li> <li>Operational Mode is invalid for the counter. (NumberOfCounters may be incorrect.)</li> <li>Operational Mode is invalid for the counter. (mode selection may be incorrect).</li> <li>The selected counter was running when the configuration was sent.</li> <li>Ctr<i>n</i>MaxCount ≤Ctr<i>n</i>MinCount</li> <li>Ctr<i>n</i>Hysteresis &lt; 0</li> <li>Ctr<i>n</i>CyclicRateUpdateTime &lt; 1</li> <li>The preset value is outside its valid range. (Ctr<i>n</i>Preset not equal to or between Ctr<i>n</i>MinCount or Ctr<i>n</i>MaxCount)</li> <li>Counter was running when the minimum/maximum count value was changed.</li> </ul>
Range Configuration	<ul> <li>Unused or Reserved bit(s) were set.</li> <li>Range0to11[<i>n</i>].HighLimit ≤Range0to11[<i>n</i>].LowLimit</li> <li>Range0To11[<i>n</i>].ToThisCounter refers to a non-declared counter (Range0To11[<i>n</i>].ToThisCounter &gt; Number0fCounters)</li> </ul>

## **Error Codes**

The tables in this section explain the extended error codes for general common hardware errors, configuration errors, and runtime errors.

Error Type	Hex Equivalent <sup>(1)</sup>	ModuleExtended ErrorErrorInformationCodeCode		Description	Status of the OK LED <sup>(2)</sup>
		Binary	Binary		
No Error	X000	000	0 0000 0000	OK, normal operating condition.	Solid or flashing green
General Common Hardware Error	X200	001	0 0000 0000	General hardware error; no additional information	Solid red
	X201	001	0 0000 0001	Power-up reset state	Briefly red
	X202	001	0 0000 0010	Bus master incompatibility	Solid red
	X203	001	0 0000 0011	General hardware error	Solid red
	X20A	001	0 0000 1010	General microprocessor error	Solid red
	X20B	001	0 0000 1011	Microprocessor internal register error	Solid red
	X20C	001	0 0000 1100	Microprocessor special function register error	Solid red
	X20D	001	0 0000 1101	Microprocessor internal memory error	Solid red
	X20E	001	0 0000 1110	Microprocessor timer error	Solid red
	X20F	001	0 0000 1111	Microprocessor interrupt error	Solid red
	X210	001	0 0001 0000	Microprocessor watchdog error	Solid red
	X218	001	0 0001 1000	Firmware corrupt	Solid red
	X219	001	0 0001 1001	Firmware checksum error in non-volatile RAM	Solid red
	X21A	001	0 0001 1010	Firmware checksum error in RAM	Solid red
	X21E	001	0 0001 1110	External RAM test error	Solid red
	X21F	001	0 0001 1111	External RAM cell test error	Solid red
	X224	001	0 0010 0100	Gate array loading failed	Solid red
	X232	001	0 0011 0010	External watchdog error	Solid red

 Table 5.5 General Common Hardware Error Codes

(1) X represents the "Don't Care" digit.

(2) See Table 5.1 on page 5-4 for recommendation based on LED operation.

# TIP

The OK LED will be in a flashing red state for all of the error codes in Table 5.6.

## Table 5.6 Configuration Error Codes

Hex	Module Error Code	Extended Error Information Code		
Equivalent <sup>(1)</sup>	Binary	Binary	Error	Description
X400	010	0 0000 0000	General Configuration Error	no additional information
X401	010	0 0000 0001	UnusedConfigBitSet	One or more of the unused module configuration bits are set.
X402	010	0 0000 0010	BadModConfigUpdate	Occurs when you attempt to change a forbidden module configuration parameter while a counter or range is still enabled. See Table 5.7 on page 5-13 for a list of the forbidden parameters.
X411	010	0 0001 0001	BadCounterNum_1	Nonzero configuration values were entered for Counter 1, when Counter 1 was not available.
X412	010	0 0001 0010	BadCounterNum_2	Nonzero configuration values were entered for Counter 2, when Counter 2 was not available.
X413	010	0 0001 0011	BadCounterNum_3	Nonzero configuration values were entered for Counter 3, when Counter 3 was not available.
X420	010	0 0010 0000	BadCounterMode_0	Operation Mode_0 is set to an invalid value. For example, value is reserved (011 or 111) or nonzero when NumberofCounters = 11.
X421	010	0 0010 0001	BadCounterMode_1	Operation Mode_1 is set to an invalid value. For example, value is reserved (011 or 111) or nonzero when NumberofCounters = 10 or 11.
X430	010	0 0011 0000	BadMin_0	Programmed Ctr0MinCount is greater than the Ctr0MaxCount.
X431	010	0 0011 0001	BadMin_1	Programmed Ctr1MinCount is greater than the Ctr1MinCount .
X432	010	0 0011 0010	BadMin_2	Programmed Ctr2MinCount is greater than the Ctr2MaxCount.
X433	010	0 0011 0011	BadMin_3	Programmed Ctr3MinCount is greater than the Ctr3MaxCount.
X440	010	0 0100 0000	BadPreset_0	The programmed Ctr0Preset is greater than the Ctr0MaxCount or less than the Ctr0MinCount.
X441	010	0 0100 0001	BadPreset_1	The programmed Ctr1Preset is greater than the Ctr1MaxCount or less than the Ctr1MinCount.
X442	010	0 0100 0010	BadPreset_2	The programmed Ctr2Preset is greater than the Ctr2MaxCount or less than the Ctr2MinCount.
X443	010	0 0100 0011	BadPreset_3	The programmed Ctr3Preset is greater than the Ctr3MaxCount or less than the Ctr3MinCount.

Publication 1769-UM006A-EN-P - March 2002

#### Table 5.6 Configuration Error Codes

Hex	Module Error Code	Extended Error Information Code		
Equivalent <sup>(1)</sup>	Binary	Binary	Error	Description
X450	010	0 0101 0000	BadHysteresis_0	The Ctr0Hysteresis value is invalid, i.e. less than zero.
X451	010	0 0101 0001	BadHysteresis_1	The Ctr1Hysteresis value is invalid, i.e. less than zero.
X452	010	0 0101 0010	BadHysteresis_2	The Ctr2Hysteresis value is invalid, i.e. less than zero.
X453	010	0 0101 0011	BadHysteresis_3	The Ctr3Hysteresis value is invalid, i.e. less than zero.
X460	010	0 0110 0000	BadScalar_0	The CtrOScalar value is invalid, i.e. less than one.
X461	010	0 0110 0001	BadScalar_1	The Ctr1Scalar value is invalid, i.e. less than one when NumberofCounters = 01, 10 or 11.
X462	010	0 0110 0010	BadScalar_2	The Ctr2Scalar value is invalid, i.e. less than one when NumberofCounters = 10 or 11.
X463	010	0 0110 0011	BadScalar_3	The Ctr3Scalar value is invalid, i.e. less than one when NumberofCounters = 11.
X470	010	0 0111 0000	BadScale_0	The Ctr0CyclicRateUpdateTime is invalid, i.e. less than one.
X471	010	0 0111 0001	BadScale_1	The Ctr1CyclicRateUpdateTime is invalid, i.e. less than one when NumberofCounters = 01, 10 or 11.
X472	010	0 0111 0010	BadScale_2	The Ctr2CyclicRateUpdateTime is invalid, i.e. less than one when NumberofCounters = 10 or 11.
X473	010	0 0111 0011	BadScale_3	The Ctr3CyclicRateUpdateTime is invalid, i.e. less than one when NumberofCounters = 11.
X480	010	0 1000 0000	BadRangeLimit_0	The RangeOTo11[0].LowLimit is greater than or equal to the RangeOTo11[0].HighLimit.
X481	010	0 1000 0001	BadRangeLimit_1	The Range0To11[1].LowLimit is greater than or equal to the Range0To11[1].HighLimit.
X482	010	0 1000 0010	BadRangeLimit_2	The RangeOTo11[2].LowLimit is greater than or equal to the RangeOTo11[2].HighLimit.
X483	010	0 1000 0011	BadRangeLimit_3	The RangeOTo11[3].LowLimit is greater than or equal to the RangeOTo11[3].HighLimit.
X484	010	0 1000 0100	BadRangeLimit_4	The Range0To11[4].LowLimit is greater than or equal to the Range0To11[4].HighLimit.
X485	010	0 1000 0101	BadRangeLimit_5	The Range0To11[5].LowLimit is greater than or equal to the Range0To11[5].HighLimit.
X486	010	0 1000 0110	BadRangeLimit_6	The Range0To11[6].LowLimit is greater than or equal to the Range0To11[6].HighLimit.
X487	010	0 1000 0111	BadRangeLimit_7	The Range0To11[7].LowLimit is greater than or equal to the Range0To11[7].HighLimit.
X488	010	0 1000 1000	BadRangeLimit_8	The RangeOTo11[8].LowLimit is greater than or equal to the RangeOTo11[8].HighLimit.
X489	010	0 1000 1001	BadRangeLimit_9	The RangeOTo11[9].LowLimit is greater than or equal to the RangeOTo11[9].HighLimit.
X48A	010	0 1000 1010	BadRangeLimit_10	The Range0To11[10].LowLimit is greater than or equal to the Range0To11[10].HighLimit.
X48B	010	0 1000 1011	BadRangeLimit_11	The RangeOTo11[11].LowLimit is greater than or equal to the RangeOTo11[11].HighLimit.

	Module	Extended Frror		
Hex	Error Code	Information Code		
Equivalent <sup>(1)</sup>	Binary	Binary	Error	Description
X490	010	0 1001 0000	BadCtrAssignToRange_0	This error occurs if you try to set Range0To11[0].ToThisCounter to an invalid value (i.e. to a counter that is not available due to the number of counters selected).
X491	010	0 1001 0001	BadCtrAssignToRange_1	This error occurs if you try to set Range0To11[1].ToThisCounter to an invalid value (i.e. to a counter that is not available due to the number of counters selected).
X492	010	0 1001 0010	BadCtrAssignToRange_2	This error occurs if you try to set Range0To11[2].ToThisCounter to an invalid value (i.e. to a counter that is not available due to the number of counters selected).
X493	010	0 1001 0011	BadCtrAssignToRange_3	This error occurs if you try to set Range0To11[3].ToThisCounter to an invalid value (i.e. to a counter that is not available due to the number of counters selected).
X494	010	0 1001 0100	BadCtrAssignToRange_4	This error occurs if you try to set Range0To11[4].ToThisCounter to an invalid value (i.e. to a counter that is not available due to the number of counters selected).
X495	010	0 1001 0101	BadCtrAssignToRange_5	This error occurs if you try to set Range0To11[5].ToThisCounter to an invalid value (i.e. to a counter that is not available due to the number of counters selected).
X496	010	0 1001 0110	BadCtrAssignToRange_6	This error occurs if you try to set RangeOTo11[6].ToThisCounter to an invalid value (i.e. to a counter that is not available due to the number of counters selected).
X497	010	0 1001 0111	BadCtrAssignToRange_7	This error occurs if you try to set Range0To11[7].ToThisCounter to an invalid value (i.e. to a counter that is not available due to the number of counters selected).
X498	010	0 1001 1000	BadCtrAssignToRange_8	This error occurs if you try to set Range0To11[8].ToThisCounter to an invalid value (i.e. to a counter that is not available due to the number of counters selected).

#### Table 5.6 Configuration Error Codes

Hex	Module Error Code	Extended Error Information Code		
Equivalent <sup>(1)</sup>	Binary	Binary	Error	Description
X499	010	0 1001 1001	BadCtrAssignToRange_9	This error occurs if you try to set Range0To11[9].ToThisCounter to an invalid value (i.e. to a counter that is not available due to the number of counters selected).
X49A	010	0 1001 1010	BadCtrAssignToRange_10	This error occurs if you try to set Range0To11[10].ToThisCounter to an invalid value (i.e. to a counter that is not available due to the number of counters selected).
X49B	010	0 1001 1011	BadCtrAssignToRange_11	This error occurs if you try to set Range0To11[11].ToThisCounter to an invalid value (i.e. to a counter that is not available due to the number of counters selected).

#### **Table 5.6 Configuration Error Codes**

(1) X represents the "Don't Care" digit.

The BadModConfigUpdate error conditions are shown in the following table. They occur when you attempt to change a forbidden module configuration parameter while a counter or range is still enabled. To recover from this situation:

- correct the configuration problem
- $\bullet$  reconfigure the  $\operatorname{module}^{(1)}$

<sup>(1)</sup> Refer to your controller's documentation for available reconfiguration methods.

Configuration Parameter	Array Positi	on	Prohibited from changing when indicated (•) bits are set:		are set:		
	Word	Bit	Ctr0En	Ctr1En	Ctr2En	Ctr3En	RangeEn
OverCurrentLatchOff	0	0	•	•	•	•	•
ProgToFaultEn	0	4					
NumberOfCounters	0	8 and 9	•	•	•	•	•
Filter_A0	1	0 and 1	•			•	
Filter_BO	1	3 and 4	•			•	
Filter_ZO	1	6 and 7	•			•	
Filter_A1	1	8 and 9		•	•		
Filter_B1	1	11 and 12		•	•		
Filter_Z1	1	14 and 15		•	•		
Out <i>n</i> ProgramMode	2	0 to 3					
Out <i>n</i> ProgramStateRun	2	4 to 7					
Out <i>n</i> ProgramValue	3	0 to 3					
Out <i>n</i> 0FaultMode	4	0 to 3					
Out <i>n</i> FaultStateRun	4	4 to 7					
Out <i>n</i> FaultValue	5	0 to 3					
Ctr0MaxCount Ctr0MinCount Ctr0Preset <sup>(1)</sup> Ctr0Hysteresis Ctr0Scalar Ctr0CyclicRateUpdateTime Ctr0Config.OperationalMode Ctr0Config.StorageMode Ctr0Config.Linear Ctr1MaxCount Ctr1MaxCount Ctr1MinCount Ctr1Preset <sup>(1)</sup> Ctr1Hysteresis Ctr1Scalar Ctr1CyclicRateUpdateTime Ctr1CyclicRateUpdateTime Ctr1CyclicRateUpdateTime Ctr1Config.OperationalMode Ctr1Config.StorageMode Ctr1Config.Linear	6 and 7 8 and 9 10 and 11 12 13 14 15 15 15 15 16 and 17 18 and 19 20 and 21 22 23 24 25 25 25	   0 to 3 8 to 10 12      0 to 3 8 to 10 12	• (1) • •	• • • • •			
Ctr2MaxCount Ctr2MinCount Ctr2Preset <sup>(1)</sup> Ctr2Hysteresis Ctr2Scalar Ctr2CyclicRateUpdateTime Ctr2Config.Linear	26 and 27 28 and 29 30 and 31 32 33 34 35	    12			• (1) •		
Ctr3MaxCount Ctr3MinCount Ctr3Preset <sup>(1)</sup> Ctr3Hysteresis Ctr3Scalar Ctr3CyclicRateUpdateTime Ctr3Config.Linear Ranges	36 and 37 38 and 39 40 and 41 42 43 44 45 46 to 117	   12 	can be chang	ged while coun	ters and range	(1) • • • • •	

#### Table 5.7 "BadModConfigUpdate" Error Prohibited Configuration Settings - Do not set while counter or range is enabled.

(1) CtrnPreset can be changed while <math>CtrnEn = 1.

## Contacting Rockwell Automation

If you need to contact Rockwell Automation for assistance, please have the following information available when you call:

- a clear statement of the problem, including a description of what the system is actually doing. Note the LED state; also note input and output image words for the module.
- a list of remedies you have already tried
- processor type and firmware number (See the label on the processor.)
- hardware types in the system, including all I/O modules
- fault code if the processor is faulted

Then contact your local Allen-Bradley distributor or Rockwell Automation Technical Support.

Technical Support contact information:

- phone 440-646-5800
- internet http://support.rockwellautomation.com

# **Specifications**

# **General Specifications**

Specification	Value
Dimensions	118 mm (height) x 87 mm (depth) x 35 mm (width), height including mounting tabs is 138 mm 4.65 in. (height) x 3.43 in (depth) x 1.38 in (width), height including mounting tabs is 5.43 in.
Approximate Shipping Weight (with carton)	309g (0.681 lbs.)
Bus Current Draw (max.)	425 mA at 5V dc 0 mA at 24V dc
Heat Dissipation	6.21 Total Watts (The Watts per point, plus the minimum Watts, with all points energized.)
Storage Temperature	-40°C to +85°C (-40°F to +185°F)
Operating Temperature	0°C to +60°C (32°F to +140°F)
Operating Humidity	5% to 95% non-condensing
Operating Altitude	2000 meters (6561 feet)
Vibration	Operating: 10 to 500 Hz, 5G, 0.030 in. peak-to-peak Relay Operation: 2G <sup>(1)</sup>
Shock	Operating: 30G, 11 ms panel mounted (20G, 11 ms DIN rail mounted) Non-Operating: 40G panel mounted (30G DIN rail mounted)
System Power Supply Distance Rating	4 (The module may not be more than 4 modules away from a system power supply.)
Recommended Cable	individually shielded, twisted-pair cable (or the type recommended by the encoder or sensor manufacturer)
Agency Certification	<ul> <li>C-UL certified (under CSA C22.2 No. 142)</li> <li>UL 508 listed</li> <li>CE compliant for all applicable directives</li> </ul>
Hazardous Environment Class	Class I, Division 2, Hazardous Location, Groups A, B, C, D (UL 1604, C-UL under CSA C22.2 No. 213)
Radiated and Conducted Emissions	EN50081-2 Class A
Vendor I.D. Code	1
Product Type Code	109
Product Code	19
Electrical /EMC:	The module has passed testing at the following levels:
ESD Immunity (IEC61000-4-2)	• 4 kV contact, 8 kV air, 4 kV indirect
Radiated Immunity (IEC61000-4-3)	<ul> <li>10 V/m , 80 to 1000 MHz, 80% amplitude modulation, +900 MHz keyed carrier</li> </ul>
Fast Transient Burst (IEC61000-4-4)	• 2 kV, 5kHz
Surge Immunity (IEC61000-4-5)	1kV galvanic gun
Conducted Immunity (IEC61000-4-6)	• 10V, 0.15 to 80MHz <sup>(2)</sup>

(1) This rating applies for your system if a relay module such as the 1769-OW8 is used. If no relays are used, use the "Operating" vibration specification.

(2) Conducted Immunity frequency range may be 150 kHz to 30 MHz if the Radiated Immunity frequency range is 30 MHz to 1000 MHz.

# **Input Specifications**

Specification	Value
Input Voltage Range	-30 to 30V dc <sup>(1)</sup>
On-State Voltage (max.)	30V dc <sup>(1)</sup>
On-State Voltage (min.)	2.6V dc
On-State Current (min.)	6.8 mA
Off-State Voltage (max.)	1.0V dc
Off-State Current (max.)	1.5 mA
Off-State Leakage Current (max.)	1.5 mA
Input Current (max.)	15 mA
Input Current (min.)	6.8 mA
Input Impedance (nominal)	1950 Ω
Pulse Width (min.)	250 nsec
Phase Separation (min.)	131 nsec
Input Frequency (max.)	1 MHz
Isolation (Inputs to the Bus and Input to Input)	<ul> <li>Verified by one of the following dielectric tests:</li> <li>1200V ac or 1697V dc for 1 second</li> <li>75V dc working voltage (IEC Class 2 reinforced insulation)</li> </ul>

(1) See Maximum Input Voltage - 24V dc Operation temperature derating on page A-4.

Specification	Value
Output Voltage Range	5 to 30V dc <sup>(1)</sup>
On-State Voltage (max.)	User Power - 0.1V dc
On-State Output Current (max.)	1A per point <sup>(2)</sup>
	4A per module <sup>(3)</sup>
On-State Output Current (min.)	1 mA
On-State Voltage Drop (max.)	0.5V dc
Off-State Leakage Current (max.)	5 μΑ
Turn On Time (max.)	400 μs <sup>(4)</sup>
Turn Off Time (max.)	200 µs
Reverse Polarity Protection	30V dc
Isolation (Outputs to Bus)	<ul> <li>Verified by one of the following dielectric tests:</li> <li>1200V ac or 1697V dc for 1 second</li> <li>75V dc working voltage (IEC Class 2 reinforced insulation)</li> </ul>

# **Output Specifications**

(1) See Maximum Output Voltage - 24V dc Operation temperature derating on page A-4.

(2) See Maximum Output Current per Point - 5V dc Operation temperature derating on page A-5 and Maximum Output Current per Point - 24V dc Operation temperature derating on page A-6.

(3) See Maximum Output Current per Module - 5V dc Operation temperature derating on page A-5 and Maximum Output Current per Module - 24V dc Operation temperature derating on page A-6.

(4) Maximum turn-on time applies to output voltage range of 5 to 7V dc. For output voltages greater than 7V dc, the maximum turn-on time is 200 μs.

Operation	Description	Timing
Input File Update Time	The delay between the time the module receives a pulse and when the Compact bus count value is updated.	1 ms (maximum)
Output Turn-on Time	The time it takes for the real output to reach 90% output voltage after commanded by the module, not including processor scan time.	400 μs (maximum)
Output Turn-off Time	The time it takes for the real output to reach 10% output voltage after commanded by the module, not including the processor scan time.	200 µs (maximum)
Rate Accuracy	The accuracy of the reported rate as compared to actual input rate in the equation: reported rate/actual input rate.	Depends on frequency. See graph below.

# **Throughput and Timing**

## **Rate Accuracy**

The following graph shows rate error at various frequencies. Pointing out a few trends may assist you in reading the graph:

- Of the lines that rise at low frequencies, the leftmost is a 10 second update time (Ctr*n*CyclicRateUpdateTime = 10000).
- The rightmost of these lines is a 1 ms update time (Ctr*n*CyclicRateUpdateTime = 1).
- The line that rises at high frequencies illustrates Ctr[*n*].PulseInterval.

#### Figure A.1 Rate Errors Comparison



## **Temperature Derating**

## Maximum Input Voltage - 24V dc Operation



Voltage Derating Based on Temperature

Temperature	Derated Voltage <sup>(1)</sup>
0°C to 40°C (-32°F to 104°F)	30V dc
55°C (131°F)	26.4V dc
60°C (140°F)	5V dc

 Input voltage derating between 55°C and 60°C is achieved by using a dropping resistor. For 24V dc input voltage, use a 2.4 kΩ ½ Watt resistor.

For input voltages greater than 24V dc, use a ½ Watt resistor with value: 125 x (V<sub>in</sub> - 5V).

## Maximum Output Voltage - 24V dc Operation



Temperature	Derated Voltage
0°C to 40°C (-32°F to 104°F)	30V dc
55°C to 60°C (131°F to 140°F)	26.4V dc



## Maximum Output Current per Point - 5V dc Operation

Temperature	Derated Current
0°C to 40°C (-32°F to 104°F)	1A
60°C (140°F)	0.5A

## Maximum Output Current per Module - 5V dc Operation



Current Derating Based on Temperature

Temperature	Derated Current
0°C to 40°C (-32°F to 104°F)	4A
60°C (140°F)	2.0A



Maximum Output Current per Point - 24V dc Operation

Current Derating Based on Temperature

Temperature	Derated Current
0°C to 40°C (-32°F to 104°F)	1A
55°C (131°F)	0.5A
60°C (140°F)	0.25A

## Maximum Output Current per Module - 24V dc Operation



Current Derating Based on Temperature

Temperature	Derated Current
0°C to 40°C (-32°F to 104°F)	4A
55°C (131°F)	2A
60°C (140°F)	1A

#### Dimensions

NOTE: All dimensions are in mm (inches). Hole spacing tolerance: ±0.04 mm (0.016 in.).





Figure A.3 Compact I/O with MicroLogix 1500 Base Unit and Processor



# 1769-HSC Module with CompactLogix Controllers and an Allen-Bradley 845F Encoder

# System Diagram



# 845F Encoder Wiring to the 1769-HSC

#### **Table B.1 Encoder Wiring**

	1	
845F Encoder Wire	Color	1769-HSC Terminal
Blue/Black Wire Pair	Blue	A0+
	Black	A0-
White/Black Wire Pair	White	B0+
	Black	В0-
Green/Black Wire Pair	Green	Z0+
	Black	Z0-
Red/Black Wire Pair	Red	+24V dc Power Supply
	Black	24V dc Common

Purpose	The purpose of this application example is to demonstrate how to wire an Allen-Bradley 845F optical incremental encoder to a 1769-HSC module and ultimately monitor the Current Count value in the CompactLogix controller. We will also control 2 onboard outputs with 2 Ranges.
Scope	This example will cover the following steps:
	<b>1.</b> Add the 1769-HSC High Speed Counter module into a CompactLogix system using the Generic profile in RSLogix 5000 programming software.
	<b>2.</b> Configure the 1769-HSC by entering configuration information into Configuration and Output tags created in RSLogix 5000 for the 1769-HSC module.
	<b>3.</b> Monitor the Current Count value from the 1769-HSC module in the Input Tag created for the module.
	<b>4.</b> Verify that module outputs 0 and 1 turn on when the Current Counts value is in the specified Ranges.

## Adding a 1769-HSC High Speed Counter Module into a CompactLogix System

This example uses a 1769-L20 CompactLogix controller. The 1769-L30 controller will operate the same with respect to the 1769-HSC module.

**1.** Start the RSLogix 5000 programming software by double clicking its icon on your desktop. The following screen appears:

o RSLogix 5000	
$\underline{F} ile  \underline{E} dit  \underline{V} iew  \underline{S} earch  \underline{L} ogic  \underline{C} ommunications$	<u>I</u> ools <u>W</u> indow Help
	I KAA F VY QQ
	Path: AB_DF1-1\1
No Edits	
Redundancy by	Ty Favorites Bl Timer/Counter Input/Output Compare

**2.** Click the "New" icon or the File pull-down menu and select New. In the box that appears, choose the correct controller type (1769-L20 CompactLogix 5320 controller for this example) and give your project a name. Then click OK and the following screen will appear:



**3.** The area on the left of this screen is called the Controller Organizer. To add I/O modules to your CompactLogix Project, right-click on the last parameter listed in the Controller Organizer, called "[0] CompactBus Local" and choose "New Module". The following screen will appear:



- **4.** This screen displays all 1769 I/O modules that have a Thin Profile. Any module listed by its catalog number has such a profile. To add these modules to your CompactLogix system, click on the module, then click OK. The screen that appears allows you to name the module. All other parameters should be left at their defaults.
- **5.** Click "Finish" and your module will be displayed below the "[0] CompactBus Local" in slot 1. The next I/O module you configure, by default, will be placed in slot 2 and so on. Configure the remaining I/O modules that are listed by name in the same manner.
- **6.** The 1769-HSC module does not yet have a Thin Profile. This means that until this module appears in the I/O list by name, the "Generic 1769 Module" profile will be used to add the 1769-HSC module to your CompactLogix system. To add it to your system, click on the "Generic 1769 Module", then click OK and the following screen appears:

Module Prope	nties - Local (1769-MODULE 1.1)				x
Туре:	1769-MODULE Generic 1769 Module				
Parent:	Local	– Connection Pa	rameters Assembly Instance:	Size:	
Na <u>m</u> e:		<u>I</u> nput:	101	1 📩	(16-bit)
Descri <u>p</u> tion:		0 <u>u</u> tput:	104	0	
		Configuration:	102	0 🔺	(16-bit)
Comm <u>F</u> ormat	: Input Data - INT 📃 💌				
Sl <u>o</u> t:	2 .				
	Cancel < Back	Next >	Finish	>>	Help

**7.** Fill in this Generic profile screen as follows:

Name	Give your HSC module a name
Comm Format:	Data-INT
Input:	Assembly Instance = 101, size = 35
Output:	Assembly Instance = 100, size = 34
Configuration:	Assembly Instance = 102, size = 118
Slot:	For this example, the HSC module is in slot 4

**8.** When you have entered the data into your Generic profile screen, click Finish. Your module will be added to your CompactLogix system and it will be displayed under the [0] CompactBus Local in the Controller Organizer.

## Configuring Your 1769-HSC Module

When the 1769-HSC module is added to the CompactLogix project, Input, Output and Configuration tags are automatically created in the Controller Tags area.

**1.** Double click on Controller Tags. The following screen appears:

😿 RSLogix 5000 - HS( 📝 File Edit View Se	C_Appl_Exam arch Logic I	ple   Comn	1769-L20] - [Controller Tags nunications Tools Window H	- HSC_Appl_Exa elp	nple(controller)]					
		ר ס כ	<u> </u>		3 <b>F</b> 78	QQ				 
Offline □ , □ R No Forces ), No Edits 2 □ //	UN K AT D	L	Path: AB_DF1-	FAL FSC COP	FLL AVE SRT	Shift K Sei				
⊡ 📾 Controller HSC_A	ppl_Example	S	cope: HSC_Appl_Examplel	Sh <u>o</u> w: Show All	💌 So <u>r</u> t:	Tag Name	-			
Controller Tag	js 🛛		Tag Name 🛛 🗸	Value 🔶	Force Mask 🛛 🗲	Style	Ту	De	Description	
Controller Fau	ılt Handler		+-buffer1	0		Decimal	DIN	٦T		
				0		Decimal	DIN	1T		
📄 🛱 MainTask				{}	{}		AB	:1769_IQ6×0		
📋 🗄 🚭 MainProg	ram 🔰		+-Local:1:I	{}	{}		AB	:1769_IQ6×0		
Progr	am Tags			{}	{}		AB	:1769_IQ6X0		
Maini 🖂 Maini	-loutine		+-Local:2:C	{}	{}		AB	:1769_D016:C:0		
	Filograms		+-Local:2:1	{}	{}		AB	:1769_D016:I:0		
Data Types			∓-Local:2:0	{}	{}		AB	:1769_D016:0:0		
User-Defined			+-Local:3:C	{}	{}		AB	:1769_IF4:C:0		
🖃 🖏 Strings			+-Local:3:I	{}	{}		AB	:1769_IF4:I:0		
I STRING				{}	{}		AB	:1769_MODUL		
⊞			+-Local:4:I	{}	{}		AB	:1769_MODUL		
			+-Local:4:0	{}	{}		AB	:1769_MODUL		
(1) CompactB (1) 1763- (1) 1763- (1) 1763- (1) 1763- (1) 1763- (1) 1763- (1) 1763- (1) 1763-	us Local Q6X0W4/A DV16/A F4/A MODULE HS									

This screen displays all the tags created for all the I/O modules added to the system. Discrete I/O modules are not configurable at this time, but all other types of I/O modules must be configured. In this example, the 1769-IF4 and the 1769-HSC must be configured. Refer to your *Compact I/O Analog Modules User Manual*, publication 1769-UM002A-EN-P, for information on configuring the 1769-IF4 module.

The tags for I/O modules are displayed in the following format, where s is the slot number of the module:

Tag	Description
Local:s:1	Input Image
Local:s:0	Output Image
Local:s:C	Configuration Data

Each of these tags has a plus sign to its left. Click on the plus sign to the left of any tag to open it. For the 1769-HSC in slot 4,

click on the plus sign to the left of Local:4:C. A Reserved tag along with a Data tag are displayed. We need only be concerned with the Data tag. This is where we enter our configuration parameters for the 1769-HSC module.

2. Expand Local:4:C.Data by clicking its plus sign. A configuration tag with a length of 198 words is displayed, but only the first 118 words are needed to configure the 1769-HSC module. This 118 word configuration file is shown in Table 4.3. Word 0 in Table 4.3 corresponds to Local:4:C.Data[0], Word 1 corresponds to Local:4:C.Data[1] and so on.

It is best to configure the module in your offline project, then download the project to your CompactLogix controller. This is due to the fact that configuration files are downloaded to the I/O modules only at download, when an inhibited module is uninhibited and at power up. For this example, we will configure the module to operate in the following way:

Configuration Parameter	Value	
Number of Counters	1	
Maximum Count Value	1,200,000	
Minimum Count Value	0	
Scalar	1	
Update Time Value	1	
Operational Mode	Quadrature	encoder X 4
Ring Counter Two Ranges	Range0	Maximum Value: 600,000
		Minimum Value: 500,000
		Control Output 0 with this range
		Range Type: Count Value
		ToThisCounter: 0
	Range1	Maximum Value: 1,200,000
		Minimum Value: 1,000,000
		Control Output 1 with this range
		Range Type: Count Value
		ToThisCounter: 0

Configuration Tag	Hex Value	Description	
Local:4:C.Data[0]	16#0000	Number of Counters =1	
Local:4:C.Data[1]	16#0000	No filters used in this example	
Local:4:C.Data[2]	16#0000	PSO and PSR not used	
Local:4:C.Data[3]	16#0000	PVO not used	
Local:4:C.Data[4]	16#0000	FSO and FSR not used	
Local:4:C.Data[5]	16#0000	FVO not used	
Local:4:C.Data[6]	16#4F80	Low word for Ctr0MaxCount	
Local:4:C.Data[7]	16#0012	High word for Ctr0MaxCount	
Local:4:C.Data[8]	16#0000	Low word for Ctr0MinCount	
Local:4:C.Data[9]	16#0000	High word for Ctr0MinCount	
Local:4:C.Data[10]	16#0000	Low word for CtrOPreset	
Local:4:C.Data[11]	16#0000	High word for CtrOPreset	
Local:4:C.Data[12]	16#0000	Hysteresis not used	
Local:4:C.Data[13]	16#0001	Not used, must set to 1	
Local:4:C.Data[14]	16#0001	Not used, valid range:1-32767	
Local:4:C.Data[15]	16#0006	Operational Mode: Quadrature Encoder X4	
Local:4:C.Data[16] throu Since we are only using	igh Local:4:C.Da counter 0 in thi	ta[45] are for configuring counters 1 through 3. s example, these words should not be modified.	
Local:4:C.Data[46]	16#27C0	Low word for Range0HighLimit	
Local:4:C.Data[47]	16#0009	High word for Range0HighLimit	
Local:4:C.Data[48]	16#A120	Low word for Range0LowLimit	
Local:4:C.Data[49]	16#0007	High word for Range0LowLimit	
Local:4:C.Data[50]	16#0001	Enable Output 0 for Range0	
Local:4:C.Data[51]	16#0000	For Counter0, Counter Value	
Local:4:C.Data[52]	16#4F80	Low word for Range1HighLimit	
Local:4:C.Data[53]	16#0012	High word for Range1HighLimit	
Local:4:C.Data[54]	16#4240	Low word for Range1LowLimit	
Local:4:C.Data[55]	16#000F	High word for Range1LowLimit	
Local:4:C.Data[56]	16#0002	Enable Output 1 for Range1	
Local:4:C.Data[57]	16#0000	For Counter0, Counter Value	
Local:4:C.Data[58] through Local:4:C.Data[117] are for configuring ranges 2 through 11. Since we are only using ranges 0 and 1 in this example, these words should not be			

Translate the configuration parameters above into the 1769-HSC Configuration file, per Chapter 4 as follows:

modified.

### TIP

To enter double integer (DINT) values into 2 integer words, create a single DINT in your Controller Tags area and call it "Buffer" or something similar.

Enter any DINT value into this tag in the decimal radix, then change the radix to Hex. The DINT value will be displayed in two 4-digit hex values. The 4-digit hex value on the left is the high word and the one on the right is the low word.

Enter these values into the Configuration file or Output file where appropriate, in the hex radix. For example, the Ctr0MaxCount value is a DINT, represented in the Configuration tag for the 1769-HSC as 2 integer words, Local:4:C.Data[6] and Local:4:C.Data[7]. The value we want to enter here is 1,200,000.

Enter this value into our DINT "Buffer" in decimal, then change to the hex radix. The result is 16#0012\_4f80. The low word is 4f80 hex and must be entered into tag Local:4:C.Data[6]. The high word is 0012 hex and must be entered into tag Local:4:C.Data[7]. Be sure to be in the hex radix before entering the hex values into these words.

**3.** To fully configure the 1769-HSC module, we must now modify parameters in the Output tag as well. Click the plus sign to the left of Local:4:O, then click the plus sign to the left of Local:4:O.Data. 34 words of output image appear. Addresses for these 34 words are:

Local:4:0.Data[0] through Local:4:0.Data[33].

For this example, only the first 6 words are modified. Words Local:4:O.Data[6] through Local:4:O.Data[33] are for Counters 1 to 3 and Ranges 12 to 15, which we are not using in this example.

Output Tag	Hex Value	Description
Local:4:0.Data[0]	16#0000	
Local:4:0.Data[1]	16#0003	Enables Outputs 0 and 1 to be controlled by Ranges 0 and 1.
Local:4:0.Data[2]	16#0003	Enable Ranges 0 and 1
Local:4:0.Data[3]	16#0000	Not using Interrupts
Local:4:0.Data[4]	16#0000	Not using Interrupts
Local:4:0.Data[5]	16#0001	Enable Counter 0
Local:4:0.Data[6] through be modified	Local:4:0.Data[33] a	re not used by this example and should not

The 6 Output words are as follows:

## Monitoring the Current Count Value and Verifying Output Operation

The Current Count value for Counter0 is represented in the Input tag for the module with 2 integer words. Since this value is a DINT value, we must copy the two integer words to a DINT tag to properly view the Current Count of Counter0.

**1.** In the Controller tags screen, enter the edit mode and create a tag called "Ctr0CurrentCount". Be sure this tag is a DINT. Then enter the following ladder rung:

<b>So RSLogix 5000 - HSC_Appl_Exar</b>	nple [1769-L20] - Communications I	[MainProgram - MainRoutine] ools Window <u>H</u> elp	
	2 21	<u> &amp;&amp;&amp;&amp; Ferral Colored States (1997)</u>	
Offline     Image: Constraint of the second se		Path:     AB_DF1-1\1       H     H       H     H       FRL     FSC       ComputeMath     ( Move/Logical )	
Controller HSC_AppLExample Controller Tags Controller Fault Handler Power-Up Handler Tasks MainTask MainProgram Program Tags MainBoutine Unscheduled Programs Trends Data Types User-Defined Strings Module-Defined Module-Defined Module-Defined (1/2) Configuration (1/2) Configuration (2) (1/1759-0V16/A (3) 1769-IF4/A (4) 1769-MODULE HS	0 (End) -		COP Copy File Source Locat 4:I.Data[4] Dest Ctr0_CurrentCount Length 1

- 2. Notice that the Source of the COP instruction is the first of the two integer tags that represent the Current Count for Counter0. The destination of the COP instruction is the DINT you just created. The length of a COP instruction is always determined by the Destination tag, in this case a single DINT. If this were reversed and the Source of the COP were the DINT and the Destination was the address of the first of two integers, then the length would be 2.
- **3.** Save the program and download it to your controller. Place the controller into the RUN mode and spin the shaft on your 845F encoder. Tag "Ctr0CurrentCount" will display the current count data for Counter0 of the 1769-HSC. This count, for this example is the number of pulses received from the encoder times 4 (we chose the operating mode to be "Quadrature Encoder X4").
- **4.** Continue to spin the encoder shaft until the current count value is within the limits set for Range0 (500,000 to 600,000). Output0 should turn on only when the current count value is equal to or within the Range0 limits. Output1 should turn on only when the Current Counts value is equal to or within the Range1 limits (1,000,000 to 1,200,000). These two outputs will be off for all other values of the Current Count for Counter0.

# 1769-HSC Module with MicroLogix 1500 Controllers and an Allen-Bradley 845F Encoder

# System Diagram



# 845F Encoder Wiring to the 1769-HSC

#### **Table C.1 Encoder Wiring**

845F Encoder Wire	Color	1769-HSC Terminal
Blue/Black Wire Pair	Blue	A0+
	Black	A0-
White/Black Wire Pair	White	B0+
	Black	В0-
Green/Black Wire Pair	Green	Z0+
	Black	Z0-
Red/Black Wire Pair	Red	+24V dc Power Supply
	Black	24V dc Common

Purpose	The purpose of this application example is to demonstrate how to wire an Allen-Bradley 845F optical incremental encoder to a 1769-HSC module and ultimately monitor the Current Count value in the MicroLogix 1500 controller. We will also control 2 onboard outputs with 2 Ranges.
Scope	This example will cover the following steps:
	<b>1.</b> Add the 1769-HSC High Speed Counter module into a MicroLogix 1500 system using the RSLogix 500 programming software.
	<b>2.</b> Configure the 1769-HSC by entering configuration information into I/O Configuration created in RSLogix 500 for the 1769-HSC module.
	3. Monitor the Current Count value from the 1769-HSC module
	<b>4.</b> Verify that module outputs 0 and 1 turn on when the Current Count value is within the specified Ranges.
Adding a 1769-HSC High	This example uses a MicroLogix 1500 controller.

## Adding a 1769-HSC High Speed Counter Module into a MicroLogix 1500 System

**1.** Start the RSLogix 500 programming software by double clicking its icon on your desktop or from the

Start>Programs>Rockwell Software>RSLogix 500 English>RSLogix 500 English. The following screen appears:

BSLogix 500		
Eile ⊻iew ⊈omms ⊥ools Window <u>H</u> elp		
	<u>_</u>	] ⊕ ] →
OFFLINE 🛃 No Forces 🔮 🚰	I →+ I → B → B → C> -C> -C> -A00 A00 A00	
No Edits Forces Disabled E	All Nuser & Bt & Timer/Counter & Input/Output & Compare	
Driver: AB_DF1-1 Node : 1d		
For Help, press F1		0:0000

**2.** Click the "New" icon or the File pull down menu and select New. The following screen appears:

I	Select Process	or Type	x
		<u>0</u> K	
I	1747-L524	5/02 CPU - 4K Mem.	<u>C</u> ancel
I	1747-L514 1747-L511	5/01 CPU - 4K Mem. 5/01 CPU - 1K Mem.	Help
I	Bul.1764	Micrologix 1500 LRP Series C	
I	Bul 1764	Micrologix 1500 LRP Series B	
I	Bul 1764	Micrologix 1500 LSP Series C	
I	Bul.1764	MicroLogix 1500 LSP Series A	
I	Bul.1762	MicroLogix 1200 Series C	
I	Bul 1762	MicroLogix 1200 Series B MicroLogix 1200 Series A	
I	Bul. 1761	MicroLogix 1000 Analog	
I	Bul.1761	MicroLogix 1000 DH-485/HDSlave	
I	Bul.1761	MicroLogix 1000	
Communication settings			
I	Driver	Processor Node: Reply Timeout:	
I	AB DE1-1	Vho Active. 10 (Sec.)	
I	1.10_01111	Detail	
		0000	

**3.** Choose the correct controller type (Bul.1764 MicroLogix 1500 LRP series C controller for this example) and give your processor a name. Then click OK and the following screen appears:



**4.** The area on the left of this screen is called the Project Menu. To add I/O modules to your MicroLogix 1500 Project, left click on the I/O Configuration parameter listed in the Project Menu. The following screen appears:

當 RSLogix 500 - Hsc_app		_ 8 ×
File Edit View Search Comms Iools Window Help		
	<u>-</u> ] % & % [2] 😫 역 역 🗖 _ ] 🕂 ] →	
OFFLINE 🛓 No Forces 🛓 🛃 🖬 🖬 🖬 🖬 🗄	√E <> +0.> +0.0 ABL ABS	
No Edits 🛓 Forces Enabled 🗄		
Driver: AB_DF1-1 Node : 1d User ABt	A limer/counter A input/output A compare	
W Hsc_app IIIX KLAD 2		_ 🗆 ×
Project		
		(END > 📃
Controller Properties		1
	Current Cards Available	
🗘 Function Files	Filter All IO	
	Part # Description	
	1759468 Science 120 VAC	
Program Files	1769-IA16 16-Input 79/132 VAC	
SYS1-	1769-IF4 Analog 4 Channel Input Module 1769-IF4X0F2 Analog 4 Chan Inp/2 Chan Out	
LAD 2 - # Part # Description	<ul> <li>1769-IM12 12-Input 159/265 VAC</li> </ul>	
Data Files Deul. 1764 Micrologix 1500 Li	RP Series C 1759-1016 16-Input 10/30 VDC 1769-006X0W4 6-Input 24 VDC, 4-Output (RLY)	
Cross Reference	1769-IR6 6 Channel RTD Module	
B H - NPLIT 4	1769-DA8 8-Dutput 120/240 VAC	
S2 - STATUS	1769-0B16 16-Output 24 VDC Source 1769-0B16P 16 Output 24 VDC Source VDC Source	
B3-BINARY 7	1769-0F2 Analog 2 Channel Dutput Module	
	1769-0V16 16-Output 24 VDC Sink	
C5 - COUNTER 10	1769-0W8 8-Output Isolated Relay	
NZ NTEGER 12	1769-SDN DeviceNetScanner 1769-PA2 Power Sunch	
F8 - FLOAT	1769-PB2 Power Supply	
Deta Logging Adv. Config Help	Hide All Cards 1769-PA4 Power Supply	
Configuration		
Status		
RCP Configuration Files		
1 H - NPUT		•
File 2		Þ
For Help, press F1	1	0.0000 APP REA

**5.** This screen displays all 1769 I/O modules supported by the MicroLogix 1500. To add the 1769-HSC module to your MicroLogix 1500 system, double left click on the module or click, hold and drag the module to its desired slot. In this case we will use slot 1.


### Configuring Your 1769-HSC Module

Configuration of the module is done in your offline project, and then downloaded to the MicroLogix 1500 controller. This is due to the fact that configuration files are downloaded to the I/O modules only at download.

- **1.** Click the Adv Config button to open the 1746-HSC-module configuration file.
- **2.** Then select the Counter Tab to display the counter configuration screen with all its default values.

Module #1: 1769-HSC - High Speed Count	er 🛛 🗶
Expansion General Configuration Gen Cour	nters Ranges Generic Extra Data Config
Counter #0 < Previous	ext>
Pulse Internal Dir.	Storage Mode
2147483647 Max Count	Hold while Z=1
-2147483648 Min Count	Preset on Rizing Z
0 Preset	
10 Update Time (x1ms)	Ring Counter Over/Under Flow
Retained Count Behavior on	Filter
0 Hysteresis	
RPM Scale Factor	None Z
OK	Cancel Apply Help

Number of Counters : 1 (default = 2)Maximum Count Value: 1,200,000 (default = 2147483647) Minimum Count Value: 0 (default = -2147483648)Preset: 1 (default = 0)Update Time Value: 1 (default = 10)**Operational Mode:** (Quadrature) Encoder X 4 (default = Pulse Internal Dir) **Count Behavior** On Configuration: Retained (default = Retained) Hysteresis: 0 (default = 0)**RPM Scale Factor** 1 (default = 0)Number Of Counters 1 (default = 2)All Unchecked (default = all unchecked) Storage modes Acc behavior on Over/Under flow Ring Counter (default = Ring counter) A, B, Z Filters None (default = none)

Module #1: 1769-HSC - High Speed Count	ter X
Expansion General Configuration Gen Cou	nters   Ranges   Generic Extra Data Config
Counter #0 < Previous N	lext> 1 # of Counters
Pulse Internal Dir.   Operational Mode	Storage Mode
1200 Max Count	Hold while Z=1
0 Min Count	Preset on Rizing Z
0 Preset	Acc behavior on
1 Update Time (x1ms)	Hing Counter Over/Under Flow
Retained Count Behavior on	None
0 Hysteresis	None B
1 RPM Scale Factor	None Z
OK	Cancel <u>A</u> pply Help

**3.** For this example, configure the module to operate in the following way:

**4.** Select the Range Tab to display the counter range configuration screen with all its default values. This configuration will use two of the 12 ranges available for the ring counter.

Module #1: 1769-HSC - High Spee	d Counter	x
Expansion General Configuration Ger	n Counters Ra	anges Generic Extra Data Config
< Pi	revious Next	>
#0		#1
Counter #0	Counter Used	Counter #0
Count Value	Range Type	Count Value
600	High Limit	1200
500	Low Limit	1000
Within the Limits 💌	Range Active	Within the Limits 💌
0001	Output Mask (hex)	0002
	OK Ca	ncel <u>Apply</u> Help

5. Configure the module to operate with the following values:

Range #0:	
Counter used:	Counter #0
Range Type:	Count Value
High limit	600,000
Low limit	500,000
Range Active	Within the limits
Output Mask	0001
Range #1:	
Counter used:	Counter #0
Range Type:	Count Value
High limit	1,200,000
Low limit	1,000,000
Range Active	Within the limits
Output Mask	0002

- **6.** In order to fully configure the 1769-HSC module, we must now modify parameters in the Output Data file as well. Click on the Output Data file on the left side under the Data files. 34 words of output image will appear. Addresses for these 34 words are Output word [0] through Output word [33].
- **7.** For this example, only the first 6 words are modified. Output Word [6] through Output Word [33] are for Counters 1 –3 and Ranges 12-15, which we are not using in this example.

Output Data File	Decimal Value	Description
Output Word [0]	0	Not used
Output Word [1]	3	Enables Outputs 0 and 1 to be controlled by Ranges 0 and 1.
Output Word [2]	3	Enable Ranges 0 and 1
Output Word [3]	0	Not using Interrupts
Output Word [4]	0	Not using Interrupts
Output Word [5]	1	Enable Counter O

The 6 Output words are as follows:

Output Word [6] through Output Word [33] are not used by this example and should not be modified.

# No program logic is needed for this example. Save the program and download it to your controller. Place the controller into the RUN mode and spin the shaft on your 845F encoder. Input words 4 and 5 "Current Count" will display the current count data for Counter #0 of the 1769-HSC. This count, for this example, is the number of pulses received from the encoder times 4 (we chose the operating mode to be "Quadrature Encoder X4").

Continue to spin the encoder shaft until the current count value is within the limits set for Range0 (500,000 to 600,000). Output 0 should turn on only when the current count value is equal to or within the Range0 limits. Output1 should turn on only when the Current Count value is equal to or within the Range1 limits (1,000,000 to 1,200,000). These two outputs will be off for all other values of the Current Count for Counter 0.

You could also use a CPW instruction to monitor 32-bit values via ladder logic.

#### Monitoring the Current Count and Verifying Output Operation

# **Programming Quick Reference**

This appendix contains at-a-glance listings of the:

- Configuration Array
- Output Array
- Input Array

These sheets are also available electronically. They can be downloaded from **www.theautomationbookstore.com**.

Search for Item Number 1769-QR002A-EN-E. You can print out the PDF file for your reference.

# **Configuration Array**

The default value for the Configuration Array is all zeros except where noted.

	15 14 13 12 11	76	5	4	3	2	1	0	Desci	ption				
0		NumberOfCtrs			PFE			CtrRst	OCLO	GeneralConfigBits $\rightarrow$	OvercurrentLatchOff			
1	Filter_Z1 Filter_B1	Filter_A1	Filter_Z0		Filte	r_B0		Filte	r_A0	FilterA0_0, FilterA0_1Z1_1	ProgToFaultEn			
2			Out3 Out PSR PS	2 Out1 R PSR	Out0 PSR	Out3 PM	Out2 PM	Out1 PM	Out0 PM	Out0ProgramStateRunOut3 and Out0ProgramMode Out3	NumberOfCounters_0 <sup>(1)</sup> NumberOfCounters_1			
3			Out0ProgramValue Out3											
4			Out3 Out FSR FS	2 Out1 R FSR	Out0 FSR	Out3 FM	Out2 FM	Out1 FM	Out0 FM	Out0FaultStateRunOut3FaultState Out0FaultMode Out3FaultMode	Run and			
5						Out3 FV	Out2 FV	Out1 FV	Out0 FV	Out0FaultValue Out3FaultValue				
6 7		Ctr0Max	xCount <sup>(2)</sup>							Ctr0MaxCount				
8 9		Ctr0Mir	nCount <sup>(3)</sup>							Ctr0MinCount				
10 11		CtrOF	Preset							CtrOPreset				
12		CtrOHy	CtrOHysteresis											
13		CtrOSo	calar <sup>(4)</sup>							Ctr0Scalar				
14		Ctr0CyclicRate	eUpdateTime <sup>(!</sup>	5)						CtrOCyclicRateUpdateTime				
15	Linear	Storage Mode					Oper	ational	Mode	Ctr0ConfigFlags $\rightarrow$	Ctr0Config.OperationalMode_0 Ctr0Config.OperationalMode_1			
16 17		Ctr1Ma	kCount <sup>(2)</sup>							Ctr1MaxCount	CtroConfig.OperationalMode_2 CtroConfig.StorageMode_0 CtroConfig.StorageMode_1			
18 19		Ctr1Mir	nCount <sup>(3)</sup>							Ctr1MinCount	Ctr0Config.StorageMode_2 Ctr0Config.Linear			
20 21		Ctr1F	Preset							Ctr1Preset				
22		Ctr1Hy:	steresis							Ctr1Hysteresis	_			
23		Ctr1So	calar <sup>(4)</sup>							Ctr1Scalar				
24		Ctr1CyclicRate	eUpdateTime <sup>(!</sup>	5)						Ctr1CyclicRateUpdateTime				
25	Linear	Storage Mode					Oper	ational	Mode	Ctr1ConfigFlags $\rightarrow$	Ctr1Config.OperationalMode_0 Ctr1Config.OperationalMode_1			
26 27		Ctr2Ma	kCount <sup>(2)</sup>							Ctr2MaxCount	Ctr1Config.OperationalMode_2 Ctr1Config.StorageMode_0			
28 29		Ctr2Mir	nCount <sup>(3)</sup>							Ctr2MinCount	Ctr1Config.StorageMode_1 Ctr1Config.StorageMode_2 Ctr1Config.Linear			
30 31		Ctr2F	Preset							Ctr2Preset	_			
32		Ctr2Hy:	steresis							Ctr2Hysteresis	_			
33		Ctr2So	calar <sup>(4)</sup>	-1						Ctr2Scalar	_			
34		Ctr2CyclicRate	eUpdateTime <sup>(</sup>	5)						Ctr2CyclicRateUpdateTime				
35	Linear									Ctr2ConfigFlags $\rightarrow$	Ctr2Config.Linear			
36 37		Ctr3Max	xCount <sup>(2)</sup>							Ctr3MaxCount				
38 39		Ctr3Mir	nCount <sup>(3)</sup>							Ctr3MinCount				
40 41		Ctr3F	Preset							Ctr3Preset				
42		Ctr3Hy	steresis							Utr3Hysteresis				
43		Ctr3So	calar <sup>(4)</sup>	-1						Utrascalar				
44		Ctr3CyclicRate	eUpdateTime <sup>(</sup>	) 						Ctr3CyclicRateUpdateTime				
45	Linear									Ctr3ConfigFlags $\rightarrow$	Ctr3Config.Linear			
46 47		RangeOto11	[0].HighLimit							Range0to11[0].HighLimit				
48 49		RangeOto11	[0].LowLimit							RangeOto11[0].LowLimit				
50	Out15 Out14 Out13 Out12 Out11	Out10 Out09 Out08	Out07 Out	06 Out05	Out04	Out03	Out02	Out01	Out00	RangeOto11[0].OutputControl	D			
51		Inv	lisutr	$Kangeotoilloj.ConfigHags \to$	RangeoTo11[0].ToThisCounter_0 RangeoTo11[0].ToThisCounter_1									
52 53		RangeOto11		RangeOto11[1].HighLimit	Kange0To11[0].Type Range0To11[0].Invert									
55 56	Que15 Que14 Que12 Que12 Que14	RangeOto11	RangeOto11[1].LowLimit											
50 57					Type	00103	00102	ToTh	uisCtr	RangeOto11[1]ConfigElage	Range()To11[1] To This Counter 0			
57 58 59		RangeOto11	[2].HighLimit		ivpe					Range0to11[2].HighLimit	Range0To11[1].ToThisCounter_1 Range0To11[1].Type			
60 61		RangeOto11	[2].LowLimit							Range0to11[2].LowLimit	KangeUTo11[1].Invert			
01										nangeoto i i[2].LUWLIIIII				

	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	Description			
62	Out15	Out14	Out13	Out12	Out11	Out10	Out09	Out08	Out07	Out06	Out05	Out04	Out03	Out02	Out01	Out00	Range0to11[2].OutputControl			
63								Inv				Туре			ToTh	lisCtr	RangeOto11[2].ConfigFlags	$\uparrow$	Range0To11[2].ToThisCounter_0 Bange0To11[2] ToThisCounter_1	
64 65							Rang	geOto11[	3].HighL	imit							Range0to11[3].HighLimit		RangeOTo11[2].Type RangeOTo11[2].Invert	
66 67							Ran	geOto11[	3].LowL	imit							Range0to11[3].LowLimit			
68	Out15	Out14	Out13	Out12	Out11	Out10	Out09	Out08	Out07	Out06	Out05	Out04	Out03	Out02	Out01	Out00	RangeOto11[3].OutputControl			
69								Inv				Туре			ToTh	isCtr	RangeOto11[3].ConfigFlags	Range0To11[3].ToThisCounter_0 Bange0To11[3] ToThisCounter_1		
70 71							Rang	geOto11[	4].HighL	imit						Range0to11[4].HighLimit		RangeOTo11[3].Type RangeOTo11[3].Invert		
72 73	RangeOto11[4].LowLimit RangeOto11[4].LowLimit												RangeOto11[4].LowLimit							
74	Out15	Out14	Out13	Out12	Out11	Out10	Out09	Out08	Out07	Out06	Out05	Out04	Out03	Out02	Out01	Out00	RangeOto11[4].OutputControl	-		
75								Inv				Туре			ToTh	lisCtr	RangeOto11[4].ConfigFlags	$\rightarrow$	RangeOTo11[4].ToThisCounter_0 RangeOTo11[4].ToThisCounter_1	
76 77 70							Rang	geOto11[	5].HighL	imit							RangeOto11[5].HighLimit		Range0To11[4].Type Range0To11[4].Invert	
78 79	0415	0	0	0	0.411	0	Ran	geOto11[	5].LowL	imit Ouroc	0	0	0	0	0	0	RangeOto11[5].LowLimit			
8U 01	UUTIS	UUT14	Outis	Outiz	UUTT	OUTIO	Outos	UUU8	Uut07	UULUO	UUIUS	Uut04	Outos	Outoz	Uutui	Outoo	Rangeoto11[5].OutputControl		Pango0To11[E] ToThioCountor 0	
01 02								IIIV				Type			1011	iiscu	naliyeolo i i[ɔ].coliliyriays	Ť	RangeOTo11[5].ToThisCounter_1	
83 84	RangeOto11[6].HighLimit RangeOto11[6].HighLimit													Range0To11[5].Type Range0To11[5].Invert						
85							Ran	ge0to11[	6].LowL	imit							Range0to11[6].LowLimit			
86	Out15	Out14	ut14 Out13 Out12 Out11 Out10 Out09 Out08 Out07 Out06 Out05 Out04 Out03 Out02 Out01 Out00 RangeOto11[6].OutputControl																	
87								Inv				Туре			ToTh	isCtr	RangeOto11[6].ConfigFlags	$\rightarrow$	Range0To11[6].ToThisCounter_0 Range0To11[6].ToThisCounter_1 Range0To11[6].Type Range0To11[6].Invert	
88 89							Rang	geOto11[	7].HighL	imit							Range0to11[7].HighLimit			
90 91							Ran	geOto11[	7].LowL	imit							Range0to11[7].LowLimit			
92	Out15	Out14	Out13	Out12	Out11	Out10	Out09	Out08	Out07	Out06	Out05	Out04	Out03	Out02	Out01	Out00	RangeOto11[7].OutputControl			
93								Inv				Туре			ToTh	isCtr	RangeOto11[7].ConfigFlags	$\rightarrow$	Range0To11[7].ToThisCounter_0 Range0To11[7].ToThisCounter_1	
94 95							Ran	geOto11[	8].HighL	imit							RangeOto11[8].HighLimit		Range0To11[7].Type Range0To11[7].Invert	
96 97							Ran	geOto11[	8].LowL	imit							RangeOto11[8].LowLimit			
98	Out15	Out14	Out13	Out12	Out11	Out10	Out09	Out08	Out07	Out06	Out05	Out04	Out03	Out02	Out01	Out00	RangeOto11[8].OutputControl	-		
99								Inv				Туре			ToTh	lisCtr	RangeOto11[8].ConfigFlags	$\rightarrow$	Range0To11[8].ToThisCounter_0 Range0To11[8].ToThisCounter_1	
100 101							Rang	geOto11[	9].HighL	imit							Range0to11[9].HighLimit		Range0To11[8].Type Range0To11[8].Invert	
102 103							Ran	geOto11[	9].LowL	imit							Range0to11[9].LowLimit			
104	Out15	Out14	Out13	Out12	Out11	Out10	Out09	Out08	Out07	Out06	Out05	Out04	Out03	Out02	Out01	Out00	RangeOto11[9].OutputControl			
105			Inv									Туре			ToTh	isCtr	RangeOto11[9].ConfigFlags	$\rightarrow$	Range0To11[9].ToThisCounter_0 Range0To11[9] ToThisCounter_1	
106 107							Rang	e0to11[1	0].Highl	Limit							Range0to11[10].HighLimit		RangeOTo11[9].Type RangeOTo11[9].Invert	
108 109	RangeOto11[10].LowLimit RangeOto11[10].LowLimit											Range0to11[10].LowLimit								
110	Out15	Out14	Out13	Out12	Out11	Out10	Out09	Out08	Out07	Out06	Out05	Out04	Out03	Out02	Out01	Out00	Range0to11[10].OutputControl			
111								Inv				Туре			ToTh	isCtr	RangeOto11[10].ConfigFlags	$\uparrow$	Range0To11[10].ToThisCounter_0 Range0To11[10] ToThisCounter_1	
112 113	Ran								1].Highl	Limit							Range0to11[11].HighLimit	RangeOTo11[10].Type RangeOTo11[10].Invert		
114 115		RangeOto11[11].LowLimit RangeOto11[11].LowLimit																		
116	Out15	Out14	Out13	Out12	Out11	Out10	Out09	Out08	Out07	Out06	Out05	Out04	Out03	Out02	Out01	Out00	RangeOto11[11].OutputControl			
117								Inv				Туре			ToTh	lisCtr	RangeOto11[11].ConfigFlags	$\rightarrow$	Range0To11[11].ToThisCounter_0 Range0To11[11].ToThisCounter_1 Range0To11[11].Type Range0To11[11].Invert	

(1) The default value for NumberOfCounters is 01 (two counters declared).

(2) The default value for CtrnMaxCount is +2,147,483,647 decimal for counters 0 and 1. The default value is 0 for counters 2 and 3.

(3) The default value for CtrnMinCount is -2,147,483,648 decimal for counters 0 and 1. The default value is 0 for counters 2 and 3.

(4) The default value for CtrnScalar is 1 for counters 0 and 1. The default value is 0 for counters 2 and 3.

(5) The default value for CtrnCyclicRateUpdateTime is 10 for counters 0 and 1. The default value is 0 for counters 2 and 3.

# **Output Array**

The default value for the Output Array is all zeros.

ſ	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	Desc	ription	
0	Out15	Out14	Out13	Out12	Out11	Out10	0 ut09	Out08	Out07	Out06	Out05	Out04	Out03	Out02	Out01	0 ut00	OutputOnMask.0 OutputOnMa	sk.15	
1	Out15	Out14	Out13	Out12	Out11	Out10	0 ut09	Out08	Out07	Out06	Out05	Out04	Out03	Out02	Out01	O ut00	OutputOffMask.0 OutputOffMask.15		
2	R15	R14	R13	R12	R11	R10	R09	R08	R07	R06	R05	R04	R03	R02	R01	R00	RangeEn.0 RangeEn.15		
3																	Reserved		
4		RBF ResetBlownFuse																	
5							RPW	RREZ	Z Inh	Z Inv	D Inh	D Inv	RCU	RCO	SP	En	Ctr0ControlBits $\rightarrow$	Ctr0En Ctr0SoftPreset	
6		RPW RREZ Z Inh Z Inv D Inh D Inv RCU RCO SP En Ctr1ControlBits														Ctr1ControlBits	CtroResetCountOverflow		
7		RPW         D Inv         RCU         RCO         SP         En         Ctr2ControlBits													CtroDirectionInvert				
8	RPW     D Inv     RCU     RCO     SP     En     Ctr3ControlBits       Reserved													Ctr0DirectionInhibit Ctr0ZInvert					
9														CtroZInhibit					
10 11							Range	12To15[0	].HiLimO	rDirWr							Range12To15[0].HiLimOrDirWr	CtroResetCtrPresetWarning	
12 13							Ran	ge12To1!	5[0].Lowl	.imit							Range12To15[0].LowLimit		
14	Out15	Out14	Out13	Out12	Out11	Out10	0 ut09	Out08	Out07	Out06	0 ut05	Out04	Out03	Out02	Out01	Out00	Range12To15[0].OutputControl.0		
15								Inv			LDW	Туре			ToTh	isCtr	Range12To15[0].Config $ ightarrow$ Flags	Range12To15[0].ToThisCounter_0 Range12To15[0].ToThisCounter_1	
16 17							Range	12To15[1	].HiLimO	rDirWr							Range12To15[1].HiLimOrDirWr	Range12To15[0].lype Range12To15[0].LoadDirectWrite Range12To15[0].Invert	
18 19							Ran	ge12To1!	5[1].Lowl	.imit							Range12To15[1].LowLimit		
20	Out15	Out14	Out13	Out12	Out11	Out10	0 ut09	Out08	Out07	Out06	0 ut05	Out04	Out03	Out02	Out01	Out00	Range12To15[1].OutputControl.0	15	
21								Inv			LDW	Туре			ToTh	isCtr	$\begin{array}{c c} \mbox{Range12To15[1].Config} \\ \mbox{Flags} \end{array} \rightarrow$	Range12To15[1].ToThisCounter_0 Range12To15[1].ToThisCounter_1	
22 23							Range	12To15[2	].HiLimO	rDirWr							Range12To15[2].HiLimOrDirWr	Range121015[1].lype Range12To15[1].LoadDirectWrite Range12To15[1].lnvert	
24 25							Ran	ge12To1!	5[2].Lowl	.imit							Range12To15[2].LowLimit		
26	Out15	Out14	Out13	Out12	Out11	Out10	O ut 09	Out08	Out07	Out06	0 ut05	Out04	Out03	Out02	Out01	Out00	Range12To15[2].OutputControl.0	15	
27								Inv			LDW	Туре			ToTh	isCtr	$\begin{array}{c c} \mbox{Range12To15[2].Config} \\ \mbox{Flags} \end{array} \rightarrow$	Range12To15[2].ToThisCounter_0 Range12To15[2].ToThisCounter_1 Ronge12To15[2].Turne	
28 29							Range	12To15[3	].HiLimO	rDirWr							Range12To15[3].HiLimOrDirWr	Range12To15[2].LoadDirectWrite Range12To15[2].lnvert	
30 31							Ran	ge12To1!	5[3].Lowl	.imit							Range12To15[3].LowLimit		
32	Out15	Out14	Out13	Out12	Out11	Out10	0 ut09	Out08	Out07	Out06	0 ut05	Out04	Out03	Out02	Out01	Out00	Range12To15[3].OutputControl.0		
33								Inv			LDW	Туре			ToTh	isCtr	$\begin{array}{c c} \mbox{Range12To15[3].Config} \\ \mbox{Flags} \end{array} \rightarrow$	Range12To15[3].ToThisCounter_0 Range12To15[3].ToThisCounter_1 Range12To15[3].Type	
																		Range12To15[3].LoadDirectWrite Range12To15[3].Invert	

# Input Array

The default value for the Input Array is all zeros.

Γ	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0		Description					
0											Z1	B1	A1	ZO	BO	A0	InputStateA0 InputStateZ1						
1	Out15	Out14	Out13	Out12	Out11	Out10	Out09	Out08	Out07	Out06	Out05	O ut04	Out03	0 ut02	0 ut01	0 ut00	Readback.0 Readbac	k.15					
2	Inva	alidRange	Limit12.	15	Invalid	CtrAssig	nToRange	1215	GenErr	InvOut	MCfg		OutO	)Overcuri	rent Ou	t <b>3</b>	Status Flags $\rightarrow$	InvalidRangeLimit12 15 InvalidCtrAssignToRange12 15					
3	R15	R14	R13	R12	R11	R10	R09	R08	R07	R06	R05	R04	R03	R02	R01	R00	RangeActive.0 RangeActive.15	GenError InvalidOutput					
4 5		Ctr[0] CurrentCount															Ctr[0].CurrentCount	Out00vercurrent0 3					
6 7		Ctr[0].StoredCount															Ctr[0].StoredCount						
8 9	Ctr[0].CurrentRate															Ctr[0].CurrentRate							
10 11								Ctr[0].Pul	selnterva	I							Ctr[0].PulseInterval						
2										COPW	RV		IDW	REZ	CUdf	COvf	Ctr[0].StatusFlags $\rightarrow$	Ctr[0].Overflow Ctr[0].Underflow					
13																	Reserved	Ctr[0].RisingEdgeZ					
14 15								Ctr[1].Cur	rentCoun	t							Ctr[1].CurrentCount	Ctr[0].InvalidDirectWrite  Ctr[0].RateValid					
16 17								Ctr[1].Sto	redCount	t							Ctr[1].StoredCount	Ctr[0].PresetWarning					
18 19								Ctr[1].Cu	rrentRate								Ctr[1].CurrentRate						
20 21								Ctr[1].Pul	selnterva	I							Ctr[1].PulseInterval						
22										C1PW	RV	IC	IDW	REZ	CUdf	COvf	Ctr[1].StatusFlags $\rightarrow$	Ctr[1].Overflow Ctr[1].Underflow					
23																	Reserved	Ctr[1].RisingEdgeZ					
24 25								Ctr[2].Cur	rentCoun	t							Ctr[2].CurrentCount	Ctr[1].InvalidDirectWrite Ctr[1].InvalidCounter Ctr[1].RateValid					
26 27								Ctr[2].Cu	rrentRate								Ctr[2].CurrentRate	Ctr[1].PresetWarning					
28										C2PW	RV	IC	IDW		CUdf	COvf	Ctr[2].StatusFlags $\rightarrow$	Ctr[2].Overflow Ctr[2].Underflow					
29																	Reserved						
80 81								Ctr[3].Cur	rentCoun	t							Ctr[3].CurrentCount	Utr[2].InvalidDirectWrite Ctr[2].InvalidCounter _Ctr[2].RateValid					
32 33								Ctr[3].Cu	rrentRate								Ctr[3].CurrentRate	Ctr[2].PresetWarning					
34										C3PW	RV	IC	IDW		CUdf	COvf	Ctr[3].StatusFlags $\rightarrow$	Ctr[3].Overflow Ctr[3].Underflow					
																		Ctr[3].InvalidDirectWrite Ctr[3].InvalidCounter Ctr[3].RateValid Ctr[3].PresetWarning					

#### A

Allen-Bradley contact information P-3, 5-14

### C

cable 3-11, A-1 channel diagnostics 5-4 CompactLogix controller application example B-1 compatibility 1-1 user manual P-2 configuration 4-1 Configuration Array 4-2, D-2 configuration errors 4-2, 5-7 Configuration Flags 4-3, 4-4, 4-15 **Control Bits 4-24 Count Overflow** 4-38 **Count Underflow** 4-38 count value 2-14, 2-15 counter basic description 1-1 counter configuration summary 2-4 Counter Control Bits 4-21 **Counter Preset Warning** 4-39 counter types linear counter 2-14 ring counter 2-15 Ctr0Config.Linear 5-13 Ctr0Config.OperationalMode 5-13 Ctr0Config.StorageMode 5-13 Ctr0CyclicRateUpdateTime 5-13 Ctr0Hysteresis 5-13 Ctr0MaxCount 5-13 Ctr0MinCount 5-13 Ctr0Preset 5-13 CtrOScalar 5-13 Current Count 4-32, 4-36 current draw A-1 Current Rate 4-37 Cyclic Rate Update Time 4-3, 4-14

#### D

Defaults Configuration Array 4-2, D-2 Counter Defaults 2-1, 5-3 Counter Maximum Count 4-12, D-3 Counter Minimum Count 4-12, D-3

Counter Preset 4-13 Counter Reset 2-17, 4-7 Counter Scalar 4-14, D-3 Cyclic Rate Update Time 4-14, D-3 Default Safe State 2-30 Input Array D-4 Number of Counters 4-8, D-3 Output Array 4-21, D-4 **DeviceNet** adapter compatibility 1-1 user manual P-2 dimensions A-4 **DIN rail mounting 3-9** Direct Write 2-16 **Direct Write Value** 4-26 **Direction Inhibit** 2-7, 4-25 Direction Invert 2-7, 4-25

## Ε

electrical noise 3-4 **EMC Directive 3-1 Enable Counter** 4-24 error cyclic rate error 2-23 general error bit 4-32, 4-34 invalid counter 4-24, 4-39 invalid counter assigned to range 4-29, 4-35 invalid direct write 4-38 invalid output 4-34 invalid output bit 4-21 invalid range 4-26, 4-27 invalid range limit 4-35 per pulse error 2-22 error codes 5-8 error definitions 5-5 errors BadCounterMode 5-9 BadCounterNum 5-9 BadCtrAssignToRange 5-11 BadHysteresis 5-10 BadMin 5-9 BadModConfigUpdate 5-9, 5-12 BadPreset 5-9 BadRangeLimit 5-10 BadScalar 5-10 BadScale 5-10 configuration 5-7 configuration errors 4-2

critical 5-5 extended error information field 5-6 General Configuration Error 5-9 hardware 5-6 module error field 5-6 non-critical 5-5 UnusedConfigBitSet 5-9 European Union Directives 3-1 extended error codes 5-8 extended error information field 5-6

#### F

Fault State Run 2-29 Filter Selection 4-3, 4-8 FilterA0 5-13 FilterA1 5-13 FilterB0 5-13 FilterB1 5-13 FilterZ0 5-13 FilterZ1 5-13 finger-safe terminal block 3-13

#### G

gate/preset functions 2-4 gating 2-16 General Configuration Bits 4-3, 4-6 General Error Bit 4-34 grounding 3-11

#### H

hardware errors 5-6 hardware features 1-3 heat considerations 3-4 Hold Last State 2-27 Hysteresis 2-20, 4-3, 4-13

#### I

Input Array D-5 input array 4-31 input operational mode 2-7 pulse/external direction 2-8 pulse/internal direction 2-9 up and down pulses 2-10 X1 quadrature encoder 2-11 X2 quadrature encoder 2-12 X4 quadrature encoder 2-12 Input State 4-32, 4-33

#### inputs

basic description 1-2 block diagram 2-2 differential encoder wiring 3-17 discrete device wiring 3-19 isolation 3-11 reducing noise 3-4, 3-12 single-ended encoder wiring 3-18 terminal block wiring 3-16 installation grounding 3-11 heat and noise considerations 3-4 **Invalid Counter** 4-39 Invalid Counter Assigned to Range 4-35 Invalid Direct Write 4-38 Invalid Output 4-34 **Invalid Range Limit** 4-35

L

LEDs overview 1-4 power-up diagnostics 5-4 safety considerations 5-1 troubleshooting status 1-4, 5-4 linear counter 2-14, 4-16 Load Direct Write 4-30

#### М

Masks 2-23 Maximum Count 4-3, 4-11 MicroLogix 1500 application example C-1, D-1 compatibility 1-1 user manual P-2 Minimum Count 4-3, 4-12 Module Configured 4-34 module error field 5-6 mounting 3-7

#### Ν

nameplate label 1-3 number of counters 2-4, 4-8, 5-13

#### 0

operating block diagrams 2-2 description 2-1 **Operational Mode** 4-15 **Output Array** D-4 output array 4-21 output control 2-23 **Output Control Example** 2-30 Output Fault Mode 4-3, 4-10 **Output Fault State Run** 4-3, 4-10 Output Fault Value 4-3, 4-11 Output Off Mask 2-24, 4-21, 4-23 **Output On Mask** 2-23, 4-21, 4-22 **Output Program Mode** 4-3 **Output Program State Run** 4-3 **Output Program Value** 4-3, 4-10 outputs basic description 1-2 block diagram 2-3 isolation 3-20 overcurrent autoreset operation 3-20 required power supply 3-20 short-circuits 3-20 terminal block wiring 3-16 thermal protection 3-20 transient pulse warning 3-21 wiring diagram 3-22 **Overcurrent 2-27 Overcurrent Feedback** 4-33 OverCurrentLatchOff bit 3-20, 4-6, 5-13 overflow 2-14, 2-15, 2-21 linear counter 2-14

#### P

panel mounting 3-7 power-up diagnostics 5-4 Preset 4-3, 4-13 preset/reset 2-17 program alteration 5-2 Program Mode 4-9 Program State Run 2-28, 4-9 Program to Fault Enable 2-29, 4-7 programming 4-1 Pulse Interval 4-32, 4-37 pulse/external direction 2-8 pulse/internal direction 2-9

#### R

Range Active 4-32, 4-35 Range Configuration Flags 4-19, 4-21, 4-22, 4-29 range control 2-24

Range Enable 4-21, 4-23 **Range High Limit** 4-4, 4-17, 4-26 Range High Limit Direct Write Value 4-21, 4-22 **Range Invert** 4-20, 4-30 **Range Low Limit** 4-4, 4-17, 4-21, 4-22, 4-27 **Range Output Control** 4-4, 4-18, 4-21, 4-22, 4-28 Range Type 4-19 RangeType 4-29 **Rate** 2-18 rate accuracy A-3 Rate Method 2-22 rate range 2-18 **Rate Valid** 2-21, 4-39 Readback 2-31, 4-32, 4-33 real outputs 2-23 removing terminal block 3-12 replacing a module 3-10 Reset 2-17, 4-7 Reset Blown Fuse 4-21, 4-23 **Reset Counter Overflow** 4-24 **Reset Counter Preset Warning** 4-25 **Reset Counter Underflow 4-24 Reset Rising Edge Z** 4-25 reset/preset 2-17 ring counter 2-15, 4-16 **Rising Edge Z** 4-38 **Rockwell Automation contact information P-3**, 5-14 **Rockwell Software** application example B-2, C-2

#### S

Safe State Control 2-27 safety circuits 5-2 Scalar 2-20, 4-3, 4-14 short-circuits 3-20 Soft Preset 4-24 spacing 3-7 specifications A-1 Status bits 4-31 Status Flags 4-32, 4-33, 4-38 Storage Mode 4-16 Stored Count 4-36

#### Т

technical support 5-14 temperature derating A-4 terminal block identification drawing 1-3 removing 3-12 wiring 3-13 terminal door label 3-15 terminal screw torque 3-14 Throughput and Timing A-3 Timing A-3 ToThisCounter 4-19 troubleshooting safety considerations 5-1

#### U

underflow 2-14, 2-15, 2-21 linear counter 2-14 up and down pulses 2-10 User-Defined Safe State 2-28 utput 4-21

#### V

virtual outputs 2-23

#### W

wire size 3-14 wiring 3-1 grounding and wiring guidelines manual P-2 module 3-14 routing considerations 3-4 terminal block 3-13

#### X

X1 quadrature encoder 2-11 X2 quadrature encoder 2-12 X4 quadrature encoder 2-12

#### Ζ

Z Inhibit 4-25 Z input functions 2-16 gating 2-16 preset/reset 2-16 setting in output array 4-38 Z Invert 4-25

#### www.rockwellautomation.com

#### **Corporate Headquarters**

Rockwell Automation, 777 East Wisconsin Avenue, Suite 1400, Milwaukee, WI, 53202-5302 USA, Tel: (1) 414.212.5200, Fax: (1) 414.212.5201

#### Headquarters for Allen-Bradley Products, Rockwell Software Products and Global Manufacturing Solutions

Americas: Rockwell Automation, 1201 South Second Street, Milwaukee, WI 53204-2496 USA, Tel: (1) 414.382.2000, Fax: (1) 414.382.4444 Europe: Rockwell Automation SA/NV, Vorstlaan/Boulevard du Souverain 36-BP 3A/B, 1170 Brussels, Belgium, Tel: (32) 2 663 0600, Fax: (32) 2 663 0640 Asia Pacific: Rockwell Automation, 27/F Citicorp Centre, 18 Whitfield Road, Causeway Bay, Hong Kong, Tel: (852) 2887 4788, Fax: (852) 2508 1846

#### Headquarters for Dodge and Reliance Electric Products

Americas: Rockwell Automation, 6040 Ponders Court, Greenville, SC 29615-4617 USA, Tel: (1) 864.297.4800, Fax: (1) 864.281.2433 Europe: Rockwell Automation, Brühlstraße 22, D-74834 Elztal-Dallau, Germany, Tel: (49) 6261 9410, Fax: (49) 6261 17741 Asia Pacific: Rockwell Automation, 55 Newton Road, #11-01/02 Revenue House, Singapore 307987, Tel: (65) 351 6723, Fax: (65) 355 1733 Publication 1769-UM006A-EN-P - March 2002