

# EtherNet/IP Communication Modules in Logix5000 Control Systems

Catalog Number 5069-AEN2TR



## Important User Information

Read this document and the documents listed in the additional resources section about installation, configuration, and operation of this equipment before you install, configure, operate, or maintain this product. Users are required to familiarize themselves with installation and wiring instructions in addition to requirements of all applicable codes, laws, and standards.

Activities including installation, adjustments, putting into service, use, assembly, disassembly, and maintenance are required to be carried out by suitably trained personnel in accordance with applicable code of practice.

If this equipment is used in a manner not specified by the manufacturer, the protection provided by the equipment may be impaired.

In no event will Rockwell Automation, Inc. be responsible or liable for indirect or consequential damages resulting from the use or application of this equipment.

The examples and diagrams in this manual are included solely for illustrative purposes. Because of the many variables and requirements associated with any particular installation, Rockwell Automation, Inc. cannot assume responsibility or liability for actual use based on the examples and diagrams.

No patent liability is assumed by Rockwell Automation, Inc. with respect to use of information, circuits, equipment, or software described in this manual.

Reproduction of the contents of this manual, in whole or in part, without written permission of Rockwell Automation, Inc., is prohibited.

Throughout this manual, when necessary, we use notes to make you aware of safety considerations.



**WARNING:** Identifies information about practices or circumstances that can cause an explosion in a hazardous environment, which may lead to personal injury or death, property damage, or economic loss.



**ATTENTION:** Identifies information about practices or circumstances that can lead to personal injury or death, property damage, or economic loss. Attentions help you identify a hazard, avoid a hazard, and recognize the consequence.

---

### IMPORTANT

Identifies information that is critical for successful application and understanding of the product.

---

Labels may also be on or inside the equipment to provide specific precautions.



**SHOCK HAZARD:** Labels may be on or inside the equipment, for example, a drive or motor, to alert people that dangerous voltage may be present.



**BURN HAZARD:** Labels may be on or inside the equipment, for example, a drive or motor, to alert people that surfaces may reach dangerous temperatures.



**ARC FLASH HAZARD:** Labels may be on or inside the equipment, for example, a motor control center, to alert people to potential Arc Flash. Arc Flash will cause severe injury or death. Wear proper Personal Protective Equipment (PPE). Follow ALL Regulatory requirements for safe work practices and for Personal Protective Equipment (PPE).

---

<b>Preface</b>	Additional Resources . . . . .	5
	<b>Chapter 1</b>	
<b>5000 Series EtherNet/IP Communication Module Overview</b>	EtherNet/IP Communication Module Functionality . . . . .	8
	5069-AEN2TR EtherNet/IP Adapter Overview . . . . .	10
	Secure Digital Card . . . . .	11
	Power a 5069 Compact I/O System . . . . .	12
	MOD Power . . . . .	13
	SA Power . . . . .	14
	<b>Chapter 2</b>	
<b>Configure EtherNet/IP and USB Drivers on Your Workstation</b>	Configure the Ethernet Communication Driver in RSLinx Classic Software . . . . .	20
	Configure the USB Communication Driver in RSLinx Classic Software . . . . .	22
	<b>Chapter 3</b>	
<b>Configure an EtherNet/IP Communication Module</b>	Determine Network Parameters . . . . .	25
	Set the Network IP Address on a Module . . . . .	27
	Set the Network IP Address with the BOOTP/DHCP Server . . . . .	28
	Configure the Adapter with RSLinx Classic Software through the USB Port . . . . .	32
	Duplicate IP Address Detection . . . . .	35
	Duplicate IP Address Resolution . . . . .	36
	DNS Addressing . . . . .	36
	<b>Chapter 4</b>	
<b>Add an EtherNet/IP Communication Module to a Controller Project</b>	Add the Module to a Project . . . . .	39
	Time Synchronization . . . . .	50
	<b>Chapter 5</b>	
<b>Use the Module on a Device-level Ring Network</b>	. . . . .	51

	<b>Chapter 6</b>	
<b>Module Diagnostics</b>	5069-AEN2TR EtherNet/IP Adapter Diagnostics	
	with the Logix Designer Application .....	53
	Connection Category .....	54
	Module Info Category .....	56
	Port Configuration Category .....	58
	Time Sync Category .....	60
	5069-AEN2TR EtherNet/IP Adapter Diagnostics	
	with RSLinx Software .....	62
	General Tab .....	62
	Port Diagnostics Tab .....	63
	Connection Manager Tab .....	65
	USB Tab .....	66
	5069-AEN2TR EtherNet/IP Adapter Diagnostic Web Pages .....	67
	Access Web Browser Support .....	68
	Diagnostic Overview Page .....	69
	Network Settings .....	70
	Ethernet Statistics .....	71
	Ring Statistics .....	72
	5069-AEN2TR EtherNet/IP Adapter Reset Button .....	73
	<b>Appendix A</b>	
<b>EtherNet/IP Communication Module</b>	5069-AEN2TR EtherNet/IP Adapter Status Indicators .....	75
<b>Status Indicators</b>	Multi-character Display .....	75
	Status Indicators .....	76
	<b>Appendix B</b>	
<b>Module Tags</b>	.....	77
<b>Index</b>	.....	81

This manual describes how to use EtherNet/IP communication modules in Logix5000™ control systems.

Make sure that you are familiar with the following:

- Use of a controller in a Logix5000 control system
- Use of an EtherNet/IP network, if the analog I/O modules are installed in a remote location from the controller that is accessible via the EtherNet/IP network
- Studio 5000 Logix Designer® environment
- RSLinx® Classic software

**IMPORTANT**

Remember the following when you use 5000 series EtherNet/IP communication modules:

- You cannot use 5000 series EtherNet/IP communication modules with all Logix5000 controllers. For example, you can use the 5069-AEN2TR EtherNet/IP adapter with ControlLogix® 5580 controllers but not with ControlLogix 5570 controllers.

For more information on which Logix5000 controllers that you can use with 5000 series EtherNet/IP communication modules, see the product description at <http://www.ab.com>.

- You must use the Logix Designer application, **version 28 or greater**, to configure the 5000 series analog I/O modules.

## Additional Resources

These documents contain more information concerning related products from Rockwell Automation.

**Table 1 - Additional Resources**

Resource	Description
5069 Compact I/O EtherNet/IP Adapter Installation Instructions, publication <a href="#">5069-IN003</a>	Describes how to install the 5069-AEN2TR EtherNet/IP adapter in a 5069 Compact I/O™ system.
5069 Compact I/O Modules Specifications Technical Data, publication <a href="#">5069-TD001</a>	Provides 5069-AEN2TR EtherNet/IP adapter and 5069 Compact I/O module specifications.
EtherNet/IP Media Planning and Installation Manual	Describes how to use the required media components and how to plan for, install, verify, troubleshoot, and certify your EtherNet/IP network. This manual is available from the Open DeviceNet Vendor Association (ODVA) at: <a href="http://www.odva.org">http://www.odva.org</a> .

**Table 1 - Additional Resources**

Resource	Description
EtherNet Design Considerations Reference Manual, publication <a href="#">ENET-RM002</a>	Describes the following Ethernet concepts: <ul style="list-style-type: none"> <li>• Overview</li> <li>• Network layout and components</li> <li>• Network infrastructure devices</li> <li>• Network infrastructure features</li> <li>• Protocol</li> </ul>
EtherNet/IP Socket Interface Application Technique, publication <a href="#">ENET-AT002</a>	Describes the socket interface that you can use to program MSG instructions to communicate between a Logix5000™ controller and Ethernet devices. In this case, the interface is used because the Ethernet devices that do not support the EtherNet/IP application protocol. Such devices include bar code scanners, RFID readers, or other standard Ethernet devices.
EtherNet/IP Embedded Switch Technology Application Guide, publication <a href="#">ENET-AP005</a>	Describes how to install, configure, and maintain linear and Device Level Ring (DLR) networks by using Rockwell Automation® EtherNet/IP devices that are equipped with embedded switch technology.
5000 Series Digital I/O Module User Manual, publication <a href="#">5000-UM004</a>	Provides information on how to install, configure, and operate 5000 Series digital I/O modules.
5000 Series Analog I/O Module User Manual, publication <a href="#">5000-UM005</a>	Provides information on how to install, configure, and operate 5000 Series analog I/O modules.
5000 Series High-speed Counter Module User Manual, publication <a href="#">5000-UM006</a>	Provides information on how to install, configure, and operate 5000 Series high-speed counter modules.
Integrated Architecture and CIP Sync Configuration Application Technique, publication <a href="#">IA-AT003</a>	Provides information on CIP Sync and the IEEE 1588-2008 Precision Time Protocol.
Integrated Motion on the EtherNet/IP Network Reference Manual, publication <a href="#">MOTION-RM003</a>	Reference descriptions of the AXIS_CIP_DRIVE attributes and the Studio 5000 Logix Designer® application Control Modes and Methods
Electronic Keying in Logix5000 Control Systems Application Technique, publication <a href="#">LOGIX-AT001</a>	Describes how to use electronic keying in Logix5000 control system applications.
Network Technology web page, <a href="http://www.rockwellautomation.com/rockwellautomation/products-technologies/network-technology/overview.page?">http://www.rockwellautomation.com/rockwellautomation/products-technologies/network-technology/overview.page?</a>	Provides information on reference architectures and white papers on networking.
Industrial Automation Wiring and Grounding Guidelines, publication <a href="#">1770-4.1</a>	Provides general guidelines for installing a Rockwell Automation industrial system.
Product Certifications website, <a href="http://www.rockwellautomation.com/rockwellautomation/certification/overview.page">http://www.rockwellautomation.com/rockwellautomation/certification/overview.page</a>	Provides declarations of conformity, certificates, and other certification details.

You can view or download publications at <http://www.rockwellautomation.com/literature/>. To order paper copies of technical documentation, contact your local Allen-Bradley distributor or Rockwell Automation sales representative.

## 5000 Series EtherNet/IP Communication Module Overview

Topic	Page
EtherNet/IP Communication Module Functionality	8
5069-AEN2TR EtherNet/IP Adapter Overview	10

EtherNet/IP networks offer a comprehensive suite of messages and services for many automation applications.

These application examples use EtherNet/IP networks:

- Real-time Control
- Time Synchronization
- Motion

This open network standard uses standard Ethernet communication products to support real-time I/O messaging, information exchange, and general messaging.

EtherNet/IP networks also support CIP Safety. Such support makes the simultaneous transmission of safety and standard control data and diagnostics information over a common network possible.

## **EtherNet/IP Communication Module Functionality**

EtherNet/IP communication modules can provide the following functionality:


- Support for messaging, produced/consumed tags, and distributed I/O
- Encapsulate messages within standard TCP/UDP/IP protocol
- Share a common application layer with ControlNet and DeviceNet network protocols
- Interface via RJ45, category 5, unshielded, twisted-pair cable connectors
- Fiber connectors - Not available on all modules
- Support for full-duplex 10/100/1000 Mbps operation - Rate options are specific to modules
- No network scheduling or routing table requirements
- Communicate with Logix5000™ controllers to function as a remote gateway for I/O modules
- Option to operate in multiple EtherNet/IP topologies
- Option to operate as a Ring supervisor on a Device Level Ring (DLR) network - Not available on all modules



Figure 1 shows how Rockwell Automation® EtherNet/IP communication modules fit into a control system. In this example, the following can occur over the EtherNet/IP network:

- Controllers produce and consume tags
- Controllers initiate MSG instructions that send and receive data and configure devices
- Control of I/O modules
- Use of Integrated Motion over an EtherNet/IP network
- Workstations upload or download projects to the controllers

**Figure 1 - EtherNet/IP Communication Modules in a Control System**




## 5069-AEN2TR EtherNet/IP Adapter Overview

The 5069-AEN2TR EtherNet/IP adapter is the only required component of a 5069 Compact I/O™ system. The adapter performs the following functions:

- Facilitates high-speed data transfer between some Logix5000 controllers and remote 5069 Compact I/O modules.
- Provides system-side power and field-side power to 5069 Compact I/O system. For more information on how the adapter powers a 5069 Compact I/O system, see [page 12](#).
- Connects to multiple EtherNet/IP network topologies, as shown in the graphics that begin on [page 9](#).
- Supports as many as 31 I/O modules in one 5069 Compact I/O system.

[Figure 2](#) shows an example 5069 Compact I/O system.

**Figure 2 - 5069 Compact I/O System**




## Secure Digital Card

The 5069-AEN2TR EtherNet/IP adapter supports the use of a Secure Digital (SD) card to store all configuration data that is stored in non-volatile memory, for example, the adapter IP address.

Remember the following:

- The adapter supports the use of a 1784-SD1 (1 GB) and 1784-SD2 (2 GB) card.
- The adapter detects the presence of an SD card at power-up or if a card is inserted during adapter operation.
- An SD card slot is located on the front of the adapter.



## Power a 5069 Compact I/O System

The 5069-AEN2TR EtherNet/IP adapter provides power to a 5069 Compact I/O system as follows:

- System-side power that powers the 5069 Compact I/O system and lets modules transfer data and execute logic.

System-side power is provided through the Module (MOD) Power connector and is passed to each module as it is added to the system.


System-side power is also known as MOD power.

- Field-side power that powers some 5069 Compact I/O modules and field-side devices that are connected to them.

Field-side power is provided through the Sensor/Actuator (SA) Power connector and is passed to each module as it is added to the system.

Field-side power is also known as SA power.

**Figure 3 - 5069-AEN2TR EtherNet/IP Adapter Power Connectors**



Power begins at the 5069-AEN2TR EtherNet/IP adapter and passes across the 5069 Compact I/O module internal circuitry via power buses. The MOD power bus and SA power bus are isolated from each other.

You connect external power supplies to removable terminal blocks (RTBs) to provide MOD power and SA power.

---

**IMPORTANT** We recommend that you use separate external power supplies for MOD power and SA power respectively. This practice can prevent unintended consequences that can result if you use one supply.

If you use separate external power supplies, the loss of power from one external power supply does not affect the availability of power from the other supply. For example, if separate external power supplies are used and SA power is lost, MOD power remains available for the 5069 Compact I/O modules.

---

For more information on how to connect MOD power and SA power, see the 5069 Compact I/O EtherNet/IP Adapter Installation Instructions, publication [5069-IN003](#).

## MOD Power

MOD power is system-side power that lets 5069 Compact I/O modules transfer data and execute logic.

### *5069 Compact I/O System MOD Power Bus*

When the MOD power source is turned on, that is, a 5069 Compact I/O system receives system-side power, the following occurs.

1. The 5069-AEN2TR EtherNet/IP adapter draws current from the MOD power bus current and passes the remaining current through to the next module.
2. The next module draws MOD power bus current and passes the remaining current through to the next module.
3. The process continues until MOD power bus current needs are met for all modules in the system.

---

**IMPORTANT** Remember the following:

- A 5069 Compact I/O system includes only one MOD power bus.
- You must limit the MOD power source to up to 10 A, max, at 18...32V DC.  
We recommend that you use an external MOD power supply that is adequately sized for the total MOD power bus current draw. For example, if the total MOD power current draw is 5 A, you can use a MOD power supply that is limited to 5 A at 18...32V DC.
- The MOD power source must meet the 5069 Compact I/O system inrush requirements.

---

For more information on the current that the 5069 Compact I/O modules draw from the MOD power bus, see the 5069 Compact I/O Modules Specifications Technical Data, publication [5069-TD001](#).

## SA Power

SA power is field-side power that some 5069 Compact I/O module use to power field-side devices that are connected to them.

### *5069 Compact I/O System SA Power Bus*

When the SA power source is turned on, that is, a 5069 Compact I/O system receives field-side power, the following occurs.

1. The 5069-AEN2TR EtherNet/IP adapter draws current from the SA power bus current and passes the remaining current through to the next module.
2. The next module completes one of the following tasks.
  - If the module uses SA power to power a field-side device, the module draws current from the SA power bus and passes the remaining current through to the next module.
  - If the module does not use SA power bus current, the module passes the remaining current through to the next module.
3. The process continues until all SA power bus current needs are met for the modules on the SA power bus.

---

**IMPORTANT** Remember the following:

- A 5069 Compact I/O system can use multiple SA power buses. You can use a 5069-FPD field potential distributor to establish additional SA power buses in a 5069 Compact I/O system, as described on [page 16](#).
- You must limit SA power sources to the following:
  - Up to 10 A, max, at 18...32V DC
  - Up to 10 A, max, at 0...240V AC

We recommend that you use an external SA power source that is adequately sized for the total SA power bus current draw. For example, if the total current draw from an SA power bus is 5 A, you can use an SA power supply that is limited to 5 A at 18...32V DC or 0...240V AC.

- Connections to the SA power bus use a **shared common**. All inputs that draw SA power bus current to power field-side devices have a return through circuitry to the SA - terminal on the SA power connector.
- 

For more information on the current that the 5069 Compact I/O modules draw from the SA power bus, see the 5069 Compact I/O Modules Specifications Technical Data, publication [5069-TD001](#).

### Track SA Power Bus Current Draw

We recommend that you track the SA power bus current draw, max, per module, and collectively for the 5069 Compact I/O system.


Consider the following with this example:

- The values in this example represent a worst-case calculation. That is, all modules that draw SA power bus current, draw the maximum available on the module.
- Not all modules that are shown in [Figure 4](#) use SA power bus current. For example, the 5069-ARM and 5069-OW4I modules only pass SA power bus current to the next module. Other modules that do not use SA power bus current, but are not shown in the graphic, include the 5069-OB16, 5069-OB16F, and 5069-OX4I modules.
- System SA power bus current, max, is calculated as each module draws SA power bus current.

In the example in [Figure 4](#), after the 5069-IB16 module in slot 1 draws SA power bus current, the system SA power bus current, max, is 138 mA. After the 5069-IB16 module in slot 2 draws SA power bus current, the system SA power bus current draw is 266 mA.

This process continues until the system SA power bus current, max, is 1.222 A.

**Figure 4 - 5069 Compact I/O System - Calculate SA Power Bus Current Draw**



### 5069-FPD Field Potential Distributor Creates Additional SA Power Buses

The 5069-FPD Field Potential Distributor lets you change the field-side power distribution source for 5069 Compact I/O modules to the right of the field power distributor. The field potential distributor passes MOD power bus signals through to the next module in the system.


You can use a 5069-FPD field potential distributor to add an SA power bus to a 5069 Compact I/O system. The field potential distributor blocks the current that passes across the SA power bus to the left of the field potential distributor and establishes a new SA power bus for modules to the right.

The SA power bus that is established by a field potential distributor functions in the same way as the SA power bus that a 5069-AEN2TR EtherNet/IP adapter establishes, as described on [page 14](#).

Examples of system configurations that use multiple SA power buses include:

- The modules in the system collectively draw more than 10 A of SA power. That is, the maximum current that one SA power bus can provide.
- The modules in the system must be isolated according to module types, such as digital I/O and analog I/O modules.
- The modules in the system are isolated according to the type of field-side device to which they are connected. For example, you can separate modules that are connected to field-side devices that require DC voltage for SA power from modules that are connected to field-side devices that require AC voltage for SA power.

**Figure 5 - 5069-FPD Field Potential Distributor**






*Create a New SA Power Bus in a 5069 Compact I/O System*

**Figure 6** shows a 5069 Compact I/O system that uses a 5069-FPD field potential distributor to create a second SA power bus. The configuration uses separate SA power buses to isolate the digital I/O modules from the analog I/O modules.

**Figure 6 - 5069 Compact I/O System - Create a New SA Power Bus**



### *SA Power - Additional Notes*

Remember the following:

- We recommend that you use a separate power supply for the SA power connection from the power supply used with the MOD power connection.
- The actual current in a 5069 Compact I/O system changes based on the operating conditions at a given time.

For example, the SA power bus current draw on some modules is different if all channels power field devices or half of the channels power field devices.

- Not all 5069 Compact I/O modules use SA power.

For example, the 5069-ARM, 5069-OB16, 5069-OB16F, 5069-OW4I, and 5069-OX4I modules do not use SA power.

- Some 5069 Compact I/O modules use field-side power but do not draw it from a SA power bus. The modules receive field-side power from an external power supply that is connected to the module RTB.

For example, the 5069-OB16 and 5069-OB16F modules use Local Actuator (LA) terminals, that is, LA+ and LA- terminals for all module channels.

---

## Configure EtherNet/IP and USB Drivers on Your Workstation

Topic	Page
Configure the Ethernet Communication Driver in RSLinx Classic Software	20
Configure the USB Communication Driver in RSLinx Classic Software	22

You must configure an Ethernet communication driver in RSLinx® software for your workstation to operate on the EtherNet/IP network. A workstation needs the drivers to perform these tasks:

- Upload and download the Logix Designer application project to controllers over an EtherNet/IP network.
- Configure EtherNet/IP network parameters for devices via RSNetWorx™ for EtherNet/IP software.
- Collect controller data for electronic operator interfaces, for example, PanelView™ Plus terminals, and visualization software, for example, FactoryTalk® View software.
- Configure a communication module through the USB port.
- Load firmware through the USB port.

## Configure the Ethernet Communication Driver in RSLinx Classic Software

Before you add an Ethernet driver, confirm that these conditions exist:


- Workstation is properly connected to the EtherNet/IP network.
- IP address and other network parameters are correctly configured for the workstation.

For Ethernet, you can choose either of these drivers:

- AB\_ETHIP
- AB\_ETH


To configure the EtherNet/IP driver, follow these steps.

1. From the Communications menu, choose Configure Drivers.




The Configure Drivers dialog box appears.

2. From the Available Driver Types pull-down menu, choose EtherNet/IP Driver.
3. Click Add New.



The Add New RSLinx Driver dialog box appears.

4. Type a name for the new driver and click OK.




The Configure driver dialog box appears.


5. Click Browse Local Subnet.

**TIP** To view devices on another subnet or VLAN from the workstation running RSLinx software, click Browse Remote Subnet.

6. Select the desired driver, and click OK.



7. When the Configure Drivers dialog box appears with the new driver listed, click Close.



## Configure the USB Communication Driver in RSLinx Classic Software

To use the USB port, you must have RSLinx Classic software, version 2.51 or later, installed on your computer. The Logix Designer application version that you use with your application can require a higher version of RSLinx Classic software. For more information, see your programming software requirements.

You can download programs to controllers and configure other devices accessible via the communication module through this connection.



**ATTENTION:** The USB port is intended for temporary, local programming purposes only and is not intended for permanent connection. The USB cable is not to exceed 3.0 m (9.84 ft) and must not contain hubs.



**WARNING:** Do not use the USB port in hazardous locations.

**IMPORTANT**

Do not simultaneously load firmware for multiple modules through a USB port. If you do, one or more of the firmware loads can fail in the middle of the loading process.

To configure RSLinx software to use a USB port, you first install the USB driver. To install the USB driver, follow these steps.

1. Connect one end of the USB cable to your workstation, and the other end to the USB port on the communication module.


The RSLinx Found New Hardware Wizard dialog box appears.

2. Click Install the software automatically (recommended).
3. Click Next.




These RSLinx dialog boxes appear consecutively.

4. Click Finish.



5. In RSLinx Classic software, from the Communications menu, choose RSWho.

The RSLinx Workstation organizer appears, and your module appears under two different drivers, a virtual chassis and the USB port.





## Configure an EtherNet/IP Communication Module

Topic	Page
Determine Network Parameters	25
Set the Network IP Address on a Module	27
Duplicate IP Address Detection	35
Duplicate IP Address Resolution	36
DNS Addressing	36



**ATTENTION:** The EtherNet/IP communication module must be assigned a fixed network address to operate on an EtherNet/IP network. The IP address of this module must not be dynamically provided. That is, do not use Dynamic as the Network Configuration Type. You must use Static.

Failure to observe this precaution can result in unintended machine motion or loss of process control.

### Determine Network Parameters

To operate an EtherNet/IP network, you must define these parameters.

EtherNet/IP Network Parameter	Description
IP address	<p>The IP address uniquely identifies the module. The IP address is in the form <i>xxx.xxx.xxx.xxx</i> where each <i>xxx</i> is a number from 000 . . . 254.</p> <p>There are some reserved values that you <b>cannot use as the first octet</b> in the address. These numbers are <b>examples</b> of values you cannot use:</p> <ul style="list-style-type: none"> <li>• 001.<i>xxx.xxx.xxx</i></li> <li>• 127.<i>xxx.xxx.xxx</i></li> <li>• 223 to 255.<i>xxx.xxx.xxx</i></li> </ul> <p>The specific reserved values that cannot be used vary according to the conditions of each application. The previous values are only examples of reserved values.</p>
Subnet mask	<p>Subnet addressing is an extension of the IP address scheme that allows a site to use one network ID for multiple physical networks. Routing outside of the site continues by dividing the IP address into a net ID and a host ID via the class. Inside a site, the subnet mask is used to redivide the IP address into a custom network ID portion and host ID portion. This field is set to 0.0.0.0 by default.</p> <p>If you change the subnet mask of an already-configured module, you must cycle power to the module for the change to take effect.</p>
Gateway	<p>A gateway connects individual physical networks into a system of networks. When a node communicates with a node on another network, a gateway transfers the data between the two networks. This field is set to 0.0.0.0 by default.</p>

If you use DNS addressing, or reference the module via host name in MSG instructions, define these parameters.

**Table 2 - EtherNet/IP Network Parameters for DNS Addressing**

EtherNet/IP Network Parameter	Description
Host name	A host name is part of a text address that identifies the host for a module. The full text address of a module is <i>host_name.domain_name</i> .
Domain name	A domain name is part of a text address that identifies the domain in which the module resides. The full text address of a module is <i>host_name.domain_name</i> . The domain name has a 48-character limit. If you specify a DNS server, you must type a domain name. Also, if you send email from the module, some mail relay servers require a domain name during the initial handshake of the SMTP session.
Primary DNS server address	The server address identifies any DNS servers that are used in the network. You must have a DNS server that is configured if you specified a domain name or a host name in the module configuration. The DNS server converts the domain name or host name to an IP address that is used by the network. For more information on DNS addressing, see <a href="#">page 36</a> .
Secondary DNS server address	

Check with your Ethernet network administrator to determine if you must specify these parameters.

Consider these factors when you determine how to set the network IP address:

- Network isolation from or integration into the plant/enterprise network
- Network size - For large networks or isolated networks, it can be more convenient to use BOOTP/DHCP server. The BOOTP/DHCP server also limits the possibility that duplicate IP addresses are assigned.
- Company policies and procedures that deal with plant floor network installation and maintenance
- Level of involvement by IT personnel in plant-floor network installation and maintenance
- Type of training that is offered to control engineers and maintenance personnel

If you use BOOTP/DHCP server in an uplinked subnet where an enterprise DHCP server exists, the enterprise server can assign an address before the BOOTP/DHCP server. In this case, you must disconnect from the uplink to set the address and configure the module to retain its static address before reconnecting to the uplink. This process is not a problem if you configured node names in the module and leave DHCP enabled.

## Set the Network IP Address on a Module

You can use the following tools to set the network Internet Protocol (IP) address.

- Rotary switches - If the network uses 192.168.1.x, we recommend using the rotary switches to set the last octet of network IP address.

Valid numbers range from 001...254. The switches are only for setting 192.168.1.xxx IP addresses.

Switch changes are recognized only at module power-up.

For more information, see the 5069 Compact I/O EtherNet/IP Adapter Installation Instructions, publication [5069-IN003](#).



**WARNING:** When you change switch settings while power is on, an electrical arc can occur. This could cause an explosion in hazardous location installations. Be sure that power is removed or the area is nonhazardous before proceeding.

---

- BOOTP/DHCP server

For more information, see [Set the Network IP Address with the BOOTP/DHCP Server on page 28](#).

- RSLinx® Classic software


For more information, see [Configure the Adapter with RSLinx Classic Software through the USB Port on page 32](#).

EtherNet/IP communication modules are shipped with this configuration:

- BOOTP/DHCP enabled
- Rotary switches set to 000 - when applicable

Figure 7 shows the process that the module uses to set the IP address.

Figure 7 - How the Module IP Address is Set



### Set the Network IP Address with the BOOTP/DHCP Server

BOOTP/DHCP server is a standalone server that you can use to set an IP address. The BOOTP/DHCP server sets an IP address and other Transport Control Protocol (TCP) parameters.

You can use the BOOTP/DHCP server to set the IP address if the rotary switches are not set to a valid IP address, and the module is BOOTP/DHCP enabled.

Access the BOOTP/DHCP server from one of these locations:

- Programs > Rockwell Software > BOOTP-DHCP Server
- Tools directory on the Studio 5000® environment installation CD

---


**IMPORTANT** Before you start the BOOTP/DHCP server, make sure that you have the hardware (MAC) address of the module. The hardware address is on a sticker on the side of the communication module and uses an address in a format similar to the following:

00-00-BC-14-55-35

---

To set the IP address with BOOTP/DHCP server, complete the following steps.


1. Start the BOOTP/DHCP software.
2. From the Tools menu, choose Network Settings.



3. Type the Subnet Mask of the network.


The Gateway address, Primary and/or Secondary DNS address, and Domain Name fields are optional.

4. Click OK.




The Request History panel appears with the hardware addresses of all modules that issue BOOTP requests.

5. Select the appropriate module.



6. Click Add to Relation List.




The New Entry dialog box appears.


7. Type an IP Address, Hostname, and Description for the module.

The Hostname and Description are optional.


8. Click OK.



9. To assign this configuration to the module, wait for the module to appear in the Relation List panel and select it.

**10. Click Disable BOOTP/DHCP.**

The Status field shows a success message.



When power is recycled, the module uses the assigned configuration and does not issue a BOOTP request.

---

**IMPORTANT** If you do not click Disable BOOTP/DHCP, on a power cycle, the host controller clears the current IP configuration and begins sending BOOTP requests again.

---

To reset the module to the factory default settings, see [5069-AEN2TR EtherNet/IP Adapter Reset Button on page 73](#).

### *Use DHCP Software*

Dynamic Host Configuration Protocol (DHCP) software automatically assigns IP addresses to client stations logging on to a TCP/IP network. DHCP is based on BOOTP and maintains some backward compatibility. The main difference is that BOOTP allows for manual configuration (static), while DHCP allows for both static and dynamic allocation of network addresses and configurations to newly attached modules.

Be cautious when using DHCP software to configure a module. A BOOTP client, such as the EtherNet/IP communication modules, can start from a DHCP server only if the DHCP server is written to handle BOOTP queries. This condition is specific to the DHCP software package used. Consult your system administrator to see if a DHCP package supports BOOTP commands and manual IP allocation.



**ATTENTION:** The EtherNet/IP communication module must be assigned a fixed network address. The IP address of this module must not be dynamically provided. That is, do not use Dynamic as the Network Configuration Type. You must use Static.

Failure to observe this precaution can result in unintended machine motion or loss of process control.

---

## Configure the Adapter with RSLinx Classic Software through the USB Port



**WARNING:** Do not use the USB port in hazardous locations.




**ATTENTION:** The USB port is intended for temporary local programming purposes only and not intended for permanent connection. The USB cable is not to exceed 3.0 m (9.84 ft) and must not contain hubs.

If the following conditions exist, you can connect to the adapter through the USB port and configure the adapter using RSLinx Classic software:

- If the adapter is new and does not have an IP address
- The IP address is outside of the 192.168.1.xxx subnet
- You do not have access to BOOTP/DHCP server or a DHCP server.

To use RSLinx software to configure the module, follow these steps.

1. Remove power from the adapter.
2. Connect a USB cable from your workstation to the adapter.
3. Power on the adapter.
4. On your workstation, start RSLinx software.
5. In RSLinx Classic software, double-click USB to expand the menu tree.
6. Under USB, right-click the EtherNet/IP module and choose Module Configuration.



The Module Configuration dialog box appears.

7. Click the Port Configuration tab.



- For Network Configuration Type, click Static to assign this configuration to the port.

---

**IMPORTANT** If you click Dynamic, on a power cycle, the adapter clears the current IP configuration and resumes sending BOOTP requests.

---


- Type this information in the appropriate fields:

- The IP address.
- The Network Mask address.
- The Gateway Address (optional).
- The Primary Name Server (optional).
- The Secondary Name Server (optional).
- The Domain Name (optional).
- The Host Name (if needed).

The screenshot shows a Windows-style dialog box titled "USB\16 5069-AEN2TR/A\_LnxMain\_152 Configuration". It has four tabs: "General", "Port Configuration", "Advanced Port Configuration", and "Network". The "Network" tab is active. Under "Network Configuration Type", the "Static" radio button is selected, and the "Dynamic" radio button is unselected. Below this, there are two unselected radio buttons: "Use DHCP to obtain network configuration." and "Use BOOTP to obtain network configuration.". The "IP Address" field is set to "192 . 168 . 1 . 17". The "Network Mask" field is set to "255 . 255 . 255 . 0". The "Gateway Address" field is set to "0 . 0 . 0 . 0". The "Primary Name Server" field is set to "0 . 0 . 0 . 0". The "Secondary Name Server" field is set to "0 . 0 . 0 . 0". The "Domain Name" and "Host Name" fields are empty. The "Status" field at the bottom shows "Network Interface not Configured". At the bottom right, there are four buttons: "OK", "Cancel", "Apply", and "Help".

10. Click the Advanced Port Configuration tab.


- IMPORTANT** Consider the following when you configure the port settings:
- The 5069-AEN2TR EtherNet/IP adapter supports only full-duplex mode.
  - The speed and duplex settings for the devices on the same Ethernet network must be the same to avoid transmission errors.
  - Fixed speed and full-duplex settings are more reliable than autonegotiate settings and are recommended for some applications.
  - If the module is connected to an unmanaged switch, leave Auto-negotiate checked or the module fails.
  - If you force the port speed and duplex with a managed switch, the corresponding port of the managed switch must be forced to the same settings or the module fails.
  - If you connect a manually configured device to an autonegotiate device (duplex mismatch), a high rate of transmission errors can occur.
  - To disable a port, clear the Enable checkbox.



Task	Action
Let the module automatically set the port speed and duplex settings.	Leave the Auto-negotiate enabled.
Manually configure the port speed and duplex settings.	Follow these steps. 1. Clear the Auto-negotiate port speed and duplex checkbox. 2. From the Current Port Speed pull-down menu, choose a port speed. 3. From the Current Duplex pull-down menu, choose full-duplex.


11. On the Module Configuration dialog box, click OK.

12. On the ControlLogix Gateway Tool dialog box that appears, click Yes.



13. In RSLinx Classic software, click RSWho.
14. Open the USB branch on the menu tree.

The adapter shows the IP address.



## Duplicate IP Address Detection

The adapter verifies that its IP address does not match any other device IP address on the network when you perform either of these tasks:

- Connect the adapter to a EtherNet/IP network.
- Change the IP address on the adapter.

If the IP address matches that of another device on the network, the EtherNet/IP port on the adapter transitions to conflict mode. In conflict mode, these conditions exist:

- OK status indicator blinks red.
- Network (NET) status indicator is solid red.
- The following message scrolls across the 4-character display:

```
<IP_address_of_this_module> Duplicate IP -
<MAC_address_of_duplicate_node_detected>
```

For example: 10.88.60.196 Duplicate IP - 00:00:BC:02:34:B4

## Duplicate IP Address Resolution

This table describes how to resolve duplicate IP addresses.

Duplicate IP Address Detection Conditions	Resolution Process
<ul style="list-style-type: none"> <li>Both modules support duplicate IP address detection</li> <li>Second module is added to the network after the first module is operating on the network</li> </ul>	<ol style="list-style-type: none"> <li>The module that began operation first uses the IP address and continues to operate without interruption.</li> <li>The module that begins operation second detects the duplication and enters Conflict mode. To assign a new IP address to the module and leave Conflict mode, see <a href="#">Set the Network IP Address on a Module on page 27</a>.</li> </ol>
<ul style="list-style-type: none"> <li>Both modules support duplicate IP address detection</li> <li>Both modules were powered up at approximately the same time</li> </ul>	<p>Both EtherNet/IP devices enter Conflict mode.</p> <p>To resolve this conflict, follow these steps:</p> <ol style="list-style-type: none"> <li>Assign a new IP address to one of the modules by using the methods that are described in <a href="#">Set the Network IP Address on a Module on page 27</a>.</li> <li>Cycle power to the other module.</li> </ol>
One module supports duplicate IP address detection and a second module does not	<ol style="list-style-type: none"> <li>Regardless of which module obtained the IP address first, the module that does not support IP address detection uses the IP address and continues to operate without interruption.</li> <li>The module that supports duplicate IP address detection detects the duplication and enters Conflict mode. To assign a new IP address to the module and leave Conflict mode, see <a href="#">Set the Network IP Address on a Module on page 27</a>.</li> </ol>

## DNS Addressing

To qualify the module address further, use DNS addressing to specify a host name for a module. When you specify a host name for the module, you also specify a domain name and DNS servers. DNS addressing makes it possible to create similar network structures and IP address sequences under different domains.

DNS addressing is necessary only if you refer to the module by host name, such as in path descriptions in MSG instructions.

To use DNS addressing, follow these steps.

- Assign a host name to the module.

A network administrator can assign a host name. Valid host names must be IEC-1131-3 compliant.

---

**2.** Configure the module parameters:

- IP address
- Subnet mask
- Gateway address
- Host name for the module
- Domain name
- primary/secondary DNS server addresses.

In the DNS server, the host name must match the IP address of the module.

---

**IMPORTANT**

Make sure the DNS enable bit is set.

- If you use **Logix Designer application**, version 28 or later, to configure your module, the enable bit is set and **DNS addressing is successful**.
  - If you use **RSLinx software**, version 2.41.00 or later, to configure your module, the enable bit is cleared and **DNS addressing fails**.
- 

**3.** In the Logix Designer application, add the module to the I/O configuration tree.

For more information, see Chapter 4, [Add an EtherNet/IP Communication Module to a Controller Project on page 39](#).

---

**IMPORTANT**

If a child module resides in the same domain as its parent module, type the host name. If the domain name of the child module differs from its parent module, type the host name and the domain name (host.domain)

---

---

**IMPORTANT**

You can also use DNS addressing in a module profile in the I/O controller tree or in a message path. If the domain name of the destination module differs from the source module, use a fully qualified DNS name (hostname.domainname). For example, to send a message from AEN2TR1.location1.companyA to AEN2TR1.location2.company, the host names match, but the domains differ. Without the entry of a fully qualified DNS name, the module adds the default domain name to the specified host name.

---

**Notes:**

## Add an EtherNet/IP Communication Module to a Controller Project


Topic	Page
Add the Module to a Project	39
Time Synchronization	50

After you install the communication module and set the IP address, you must add the module to a controller project. The project must be online to set the Speed and Duplex configurable parameters on the module.

**IMPORTANT** You must use the Logix Designer application, **version 28 or greater**, to configure the 5069-AEN2TR EtherNet/IP adapter. Version 28 or greater is slightly different from previous programming software versions. For example, in some cases, instead of tabs across the top of the Module Properties dialog box, the application uses categories on the left side of the dialog box.

### Add the Module to a Project


1. Verify that your project is offline.
2. Right-click your network port, and choose New Module.



3. On the Select Module Type dialog box, complete the following tasks:
  - a. In the search field, type 5069-AEN2TR.
  - b. In the Catalog Number field, select the 5069-AEN2TR, 5069 Ethernet adapter.

For some modules, the Select Major Revision dialog box can appear. If the dialog box appears, choose the major revision of the module and click OK.

- c. Click Create.



4. On the New Module dialog box, complete the following tasks on the General category page:
  - a. Type a name.
  - b. Enter the IP address.


---

**IMPORTANT** If you do not enter an IP address, the application alerts you that the IP address is invalid. You cannot continue until you enter an IP address.


---



c. In the Module Definition area, click Change.



The Module Definition dialog box appears.



5. Complete the following tasks.

- a. Set the appropriate Revision of the firmware that is on your adapter.

Major Revision (left pull-down menu)	This field only displays the major revisions that are applicable to the selected series. This field appears dimmed when online unless the module supports allowing major revision changes to be made while online.
Minor Revision (right field)	Sets the minor revision of the module. The valid range is 1 . . . 255. This field is enabled while offline, and while in the Program, Remote Program, and Remote Run modes. It appears dimmed when in Run mode, or when electronic keying is set to Disable Keying

- b. Select the appropriate the Electronic Keying setting.

Electronic Keying is enabled while offline, and while in Program, Remote Program, and Remote Run modes. It appears dimmed when in Run mode.

Electronic Keying reduces the possibility that you use the wrong device in a control system. It compares the device that is defined in your project to the installed device. If keying fails, a fault occurs. These attributes are compared.

Attribute	Description
Vendor	The device manufacturer.
Device Type	The general type of the product, for example, digital I/O module.
Product Code	The specific type of the product. The Product Code maps to a catalog number.
Major Revision	A number that represents the functional capabilities of a device.
Minor Revision	A number that represents behavior changes in the device.

The following Electronic Keying options are available.

Keying Option	Description
Compatible Module	Lets the installed device accept the key of the device that is defined in the project when the installed device can emulate the defined device. With Compatible Module, you can typically replace a device with another device that has the following characteristics: <ul style="list-style-type: none"> <li>• Same catalog number</li> <li>• Same or higher Major Revision</li> <li>• Minor Revision as follows: <ul style="list-style-type: none"> <li>– If the Major Revision is the same, the Minor Revision must be the same or higher.</li> <li>– If the Major Revision is higher, the Minor Revision can be any number.</li> </ul> </li> </ul>
Disable Keying	Indicates that the keying attributes are not considered when attempting to communicate with a device. With Disable Keying, communication can occur with a device other than the type specified in the project. <b>ATTENTION:</b> Be cautious when using Disable Keying; if used incorrectly, this option can lead to personal injury or death, property damage, or economic loss. We <b>strongly recommend</b> that you <b>do not use</b> Disable Keying. If you use Disable Keying, you must take full responsibility for understanding whether the device being used can fulfill the functional requirements of the application.
Exact Match	Indicates that all keying attributes must match to establish communication. If any attribute does not match precisely, communication with the device does not occur.

Carefully consider the implications of each keying option when selecting one.

---

**IMPORTANT** When you change Electronic Keying parameters online, it interrupts connections to the device and any devices that are connected through the device. Connections from other controllers can also be broken.  
If an I/O connection to a device is interrupted, the result can be a loss of data.

---

For more detailed information on Electronic Keying, see Electronic Keying in Logix5000 Control Systems Application Technique, publication [LOGIX-AT001](#).


c. Select the Connection.

None	No direct connection from Controller (Originator) to the adapter.
Status	Reports device status.


d. Set the Chassis Size to the number of modules including the adapter.

For example, one adapter with nine I/O modules would equal a chassis size of ten.

e. Click OK.




If you set the Connection to Status, click Yes on the RSLogix 5000® dialog box.




6. On the New Module dialog box, click the Connection category and complete the tasks:
  - a. Set the Requested Packet Interval (RPI). The range is 25...750 ms, with 100 ms as the default. This connection is for status data only, with no I/O.
  - b. Select the Connection over EtherNet/IP, Unicast, or Multicast.

For non-redundant controllers, the default value is Unicast when the target device supports unicast; otherwise, the default value is Multicast. For redundant controllers, the default value is Multicast when the target device supports multicast; otherwise, the default value is Unicast.


- c. Click OK.




7. Save the project.
8. If the project does not have a communication path to the controller, click Browse to create a path.




9. On the Who Active dialog box, choose the desired path and click Set Project Path.




10. Verify that the controller mode switch is in the PROG mode position
11. Click the Controller Status icon, and choose Go Online.




12. On the Connected To Go Online dialog box, click Download.




13. On the Download dialog box, click Download.




The project downloads to the controller. The dialog box closes when the download is complete.




14. If you did not already configure the Ethernet port speed and duplex settings with RSLinx software, complete these tasks:
  - a. Put the controller mode switch in the REM position.
  - b. Change the Logix Designer application project to Run mode.



- c. When prompted to Change controller mode to Remote Run, click Yes.



- d. Right-click the adapter, and choose Properties.




e. On the Module Properties dialog box, click the Port Configuration category.

Desired Task	Action
Let the module automatically set the port speed and duplex settings.	Leave Auto-negotiate enabled.
Manually configure your port speed and duplex settings.	Follow these steps. 1. Clear the Auto-negotiate port speed and duplex checkbox. 2. From the Current Port Speed pull-down menu, choose a port speed. 3. From the Current Duplex pull-down menu, choose full-duplex.

**IMPORTANT**

Consider the following when you configure the port settings:

- The 5069-AEN2TR EtherNet/IP adapter only supports full-duplex mode.
- The speed and duplex settings for the devices on the same Ethernet network must be the same to avoid transmission errors.
- Fixed speed and full-duplex settings are more reliable than autonegotiate settings and are recommended for some applications.
- If the module is connected to an unmanaged switch, leave Auto-negotiate checked or the module fails.
- If you force the port speed and duplex with a managed switch, the corresponding port of the managed switch must be forced to the same settings or the module fails.
- If you connect a manually configured device to an autonegotiate device (duplex mismatch), a high rate of transmission errors can occur.






**15.** Click the Internet Protocol category.


If needed, you can set Internet Protocol properties such as:

- Domain Name
- Host Name
- Gateway Address
- Primary and secondary DNS Server Addresses.



f. On the Module Properties dialog box, click OK.

**IMPORTANT** If you try to change the IP Address on this page, the following alert appears:



g. Save the project.

## Time Synchronization

In certain situations, the I/O modules can synchronize with the adapter before the adapter synchronizes with the system Grandmaster clock. This synchronization occurrence leads to a time difference between the I/O and the Grandmaster clock until the adapter synchronizes with the Grandmaster clock.

In your logic, verify that the adapter is synchronized with the Grandmaster clock (CIPSyncValid) before you initiate timestamp requests or scheduled outputs from your I/O modules. A system with intermediate devices, such as network bridges and switches, can require that you insert a delay until the time stabilizes in the system.

For information on how to verify that the adapter is synchronized to a Grandmaster clock, see CIP Sync Diagnostics in the Integrated Architecture and CIP Sync Configuration Application Technique, publication [IA-AT003](#). This publication also includes information on Time Sync Object Attributes.


## Use the Module on a Device-level Ring Network

**IMPORTANT** This chapter summarizes a DLR network. For information on how to plan, configure, and monitor a DLR network, see the EtherNet/IP Embedded Switch Technology Application Guide, publication [ENET-AP005](#).

A device-level ring (DLR) network is a single-fault-tolerant ring network that is intended for the interconnection of automation devices without the need for additional switches. The ring topology offers these advantages:

- Media redundancy
- Fast network fault detection and reconfiguration
- Resiliency of a single-fault tolerant network
- Easy implementation without any additional hardware requirements

One DLR network can support as many as 50 nodes. A DLR network supports copper connections (maximum of 100 m [328 ft]), fiber-optic connections (maximum of 2 km [1.24 mi]), or a mix of copper and fiber.



A DLR network includes the following nodes.

Node	Description
Supervisor node	<p>A DLR network requires at least one node to be configured as ring supervisor.</p> <p><b>IMPORTANT:</b> By default, the supervisor function is disabled on supervisor-capable devices, so they are ready to participate in a linear/star network or as a ring node on a DLR network.</p> <p>In a DLR network, you must configure at least one of the supervisor-capable devices as the ring supervisor before physically connecting the ring. If you do not, the DLR network does not work.</p> <p>The ring supervisor provides these main functions:</p> <ul style="list-style-type: none"> <li>• Manages traffic on the DLR network</li> <li>• Collects diagnostic information for the network</li> </ul> <p>We recommend that you do the following:</p> <ul style="list-style-type: none"> <li>• Configure at least one back-up supervisor.</li> <li>• Configure the desired active ring supervisor with a numerically higher precedence value as compared to the back-up supervisors.</li> <li>• Track the supervisor-precedence values for all supervisor-enabled nodes in the DLR network.</li> </ul>
Ring node	<p>A ring node is any node that operates on the network to process data that is transmitted over the network. A ring node can also pass on the data to the next node on the network. When a fault occurs on the DLR network, the ring nodes reconfigure themselves and relearn the network topology. Additionally, ring nodes can report fault locations to the active ring supervisor.</p>

## Module Diagnostics

Topic	Page
5069-AEN2TR EtherNet/IP Adapter Diagnostics with the Logix Designer Application	53
5069-AEN2TR EtherNet/IP Adapter Diagnostics with RSLinx Software	62
5069-AEN2TR EtherNet/IP Adapter Diagnostic Web Pages	67
5069-AEN2TR EtherNet/IP Adapter Reset Button	73

This chapter describes how to diagnose and troubleshoot issues with the 5069-AEN2TR EtherNet/IP adapter.

### 5069-AEN2TR EtherNet/IP Adapter Diagnostics with the Logix Designer Application


You can use the Module Properties in the Logix Designer application to diagnose the 5069-AEN2TR EtherNet/IP adapter.

When your project is online, these categories display information about the state and status of the adapter:

- [Connection Category](#)
- [Module Info Category](#)
- [Port Configuration Category](#)
- [Time Sync Category](#)

## Connection Category

The Connection category displays information about the condition of the connection between the controller and the module. The data on this tab comes directly from the controller.



### Module Fault

Module Fault displays the fault code that is returned from the controller, and text on the Module Fault that occurred. In the Logix Designer online help, type the fault code into the Search field to find information on the fault code.

The following are common categories for errors.

Connection Request Error	The controller is attempting to make a connection to the module and has received an error. The connection was not made.
Service Request Error	The controller is attempting to request a service from the module and has received an error. The service was not performed successfully.
Module Configuration Invalid	The configuration in the module is invalid.
Electronic Keying Mismatch	Electronic Keying is enabled and some part of the keying information differs between the software and the module.

*Status*

The Status line at the bottom of the Module Properties dialog box displays the status that the controller has about the module.


<b>Status</b>	<b>Meaning</b>
Standby	A transient state that occurs when shutting down.
Faulted	The controller is unable to communicate with the module. When the status is Faulted, the Connection tab displays the fault.
Validating	A transient state that occurs before connecting to the module.
Connecting	A state that occurs while connections are being established to the module.
Running	The module is communicating and everything is working as expected.
Shutting Down	The connections are closing.
Inhibited	The connection to the module is inhibited.
Waiting	The connection to this module is not made due to one of the following: <ul style="list-style-type: none"> <li>• The parent has not yet made a connection to it.</li> <li>• The parent is inhibited.</li> <li>• The parent is faulted.</li> </ul>
Offline	You are not online.
Reconfiguring	The configuration information is being downloaded to the module again.
Firmware Updating	The modules firmware is being updated.
Configuring	Indicates that the Logix controller is configuring the module.

## Module Info Category

Module Info displays the module identity and status information about the module. See [Table 3 on page 56](#) for parameter descriptions. You can also reset the module to its power-up state if needed. See [Reset Module on page 57](#).



**ATTENTION:** When you reset a module, all connections to or through the module are closed, and can result in loss of control.



**Table 3 - Module Info Parameters**

Parameter	Description
Identification	<p>Displays the following:</p> <ul style="list-style-type: none"> <li>• Vendor</li> <li>• Product Type</li> <li>• Product Code</li> <li>• Revision</li> <li>• Serial Number</li> <li>• Product Name</li> </ul> <p>The name that is displayed in the Product Name field is read from the module. This name displays the series of the module.</p>
Major/Minor Fault	<p>Displays one of the following fault types:</p> <ul style="list-style-type: none"> <li>• None</li> <li>• Unrecoverable</li> <li>• Recoverable</li> </ul>



**Table 3 - Module Info Parameters**

Parameter	Description
Internal State	<p>Displays the current operational state of the module:</p> <ul style="list-style-type: none"> <li>• Self-test</li> <li>• Flash update</li> <li>• Communication fault</li> <li>• Unconnected</li> <li>• Flash configuration bad</li> <li>• Major Fault (refer to Major/Minor Fault)</li> <li>• Run mode</li> <li>• Program mode</li> <li>• (16#xxxx) unknown</li> </ul> <p>If you selected the wrong module from the module selection tab, this field displays a hexadecimal value. A textual description of this state is only given when the module identity you provide is a match with the actual module.</p>
Configured/Owned	For I/O modules only. Does not apply to adapters, scanners, bridges, or other communication modules
Module Identity	<p>Match</p> <ul style="list-style-type: none"> <li>• Agrees with what is specified on the General Tab.</li> <li>• For the Match condition to exist, the following must agree: <ul style="list-style-type: none"> <li>– Vendor</li> <li>– Module Type (the combination of Product Type and Product Code for a particular Vendor)</li> <li>– Major Revision</li> </ul> </li> </ul> <p>Mismatch</p> <ul style="list-style-type: none"> <li>• Does not agree with what is specified on the General Tab.</li> </ul> <p>The Module Identity field does not take into account the Electronic Keying or Minor Revision selections for the module that were specified on the General Tab.</p>

***Refresh***

Click this button to refresh the tab with new data from the module.

***Reset Module***


To reset a module to its power-up state, click Reset Module.



**ATTENTION:** When you reset a module, all connections to or through the module are closed, and can result in loss of control.


## Port Configuration Category

If communication with the adapter has failed, click Refresh communication to try to restart communication with the module.



### Port Diagnostics

On the Port Configuration category, click the Port Diagnostics button to view information for the port. See [Table 4 on page 59](#) for parameter descriptions.




**Table 4 - Port Diagnostics Parameters - Logix Designer**

Parameter	Description
<b>Interface Counters</b>	The interface Counters values have no value when you are offline or online and there is a communication error.
Octets Inbound	Displays the number of octets that are received on the interface.
Octets Outbound	Displays the number of octets that are transmitted to the interface.
Unicast Packets Inbound	Displays the number of unicast packets that are received on the interface.
Unicast Packets Outbound	Displays the number of unicast packets that are transmitted on the interface.
Non-unicast Packets Inbound	Displays the number of non-unicast packets that are received on the interface.
Non-unicast Packets Outbound	Displays the number of non-unicast packets that are transmitted on the interface.
Packets Discarded Inbound	Displays the number of inbound packets that are received on the interface but discarded.
Packets Discarded Outbound	Displays the number of outbound packets that are transmitted on the interface but discarded.
Packets With Errors Inbound	Displays the number of inbound packets that contain errors (excludes discarded inbound packets).
Packets With Errors Outbound	Displays the number of outbound packets that contain errors (excludes discarded outbound packets).
Unknown Protocol Packets Inbound	Displays the number of inbound packets with unknown protocol.
Media Counters	The Media Counters values have no value when you are offline or online and there is a communication error.
Alignment Errors	Displays the number of frames received that are not an integral number of octets in length.
FCS Errors	Displays the number of frames received that do not pass the FCS check.
Single Collisions	Displays the number of successfully transmitted frames that experienced exactly one collision.
Multiple Collisions	Displays the number of successfully transmitted frames that experienced multiple collisions.
SQE Test Errors	Displays the number of times an SQE test error message was generated.
Deferred Transmissions	Displays the number of frames for which the first transmission attempt is delayed because the medium is busy.
Late Collisions	Displays the number of times a collision is detected later than 512 bit-times into the transmission of a packet.
Excessive Collisions	Displays the number of frames for which transmission fails due to excessive collisions.
MAC Transmit Errors	Displays the number of frames for which transmission fails due to an internal MAC sub layer transmit error.
MAC Receive Errors	Displays the number of frames for which reception on an interface fails due to an internal MAC sub layer receive error.
Carrier Sense	Displays the number of times that the carrier sense condition was lost or never asserted when attempting to transmit a frame.
Frame Too Long	Displays the number of frames received that exceed the maximum permitted frame size.
Reset Counters	Click Reset Counter to reset the interface and media counter values to zero. The values then update to the current counter values. Reset Counter appears dimmed in the following conditions: <ul style="list-style-type: none"> <li>The project is offline.</li> <li>The project is online and a communication error occurred.</li> </ul>

## Time Sync Category

The Time Sync displays information that is related to CIP Sync time synchronization. The information appears only if the project is online and CIP Sync is enabled.



**Table 5 - Time Sync Parameters**

Grandmaster Clock	
Description	<p>Displays information about the Grandmaster clock. The vendor of the Grandmaster device controls this information. The following information is specified:</p> <ul style="list-style-type: none"> <li>• User Name</li> <li>• User Location</li> <li>• Protocol Address</li> <li>• Physical Address</li> <li>• Clock Type</li> <li>• Manufacturer Name</li> <li>• Model</li> <li>• Serial Number</li> <li>• Hardware Revision</li> <li>• Firmware Revision</li> <li>• Software Revision</li> <li>• Profile Identity</li> <li>• Physical Protocol</li> <li>• Network Protocol</li> <li>• Port Number</li> </ul> <p>Use the vertical scroll bar to view the data.</p>
Identity	Displays the unique identifier for the Grandmaster clock. The format depends on the network protocol. Ethernet network encodes the MAC address into the identifier.
Class	Displays a measure of the quality of the Grandmaster clock. Values are defined from 0...255 with zero as the best clock.
Accuracy	Indicates the expected absolute accuracy of the Grandmaster clock relative to the PTP epoch. The accuracy is specified as a graduated scale that starts at 25 nsec and ends at greater than 10 seconds or unknown. The lower the accuracy value, the better the clock.
Variance	Displays the measure of inherent stability properties of the Grandmaster clock. The value is represented in offset scaled log units. The lower the variance, the better the clock.

**Table 5 - Time Sync Parameters**

Source	Displays the time source of the Grandmaster clock. The available values are: <ul style="list-style-type: none"> <li>• Atomic Clock</li> <li>• GPS</li> <li>• Radio</li> <li>• PTP</li> <li>• NTP</li> <li>• HAND set</li> <li>• Other</li> <li>• Oscillator</li> </ul>
Priority 1 / Priority 2	Displays the relative priority of the Grandmaster clock to other clocks in the system. The priority values range from 0...255. The highest priority is zero. The default value for both settings is 128.
<b>Local Clock</b>	
Synchronization Status	Displays whether the local clock is synchronized or not synchronized with the Grandmaster reference clock. A clock is synchronized if it has one port in the slave state and is receiving updates from the time master.
Offset to Master	Displays the amount of deviation between the local clock and the Grandmaster clock in nanoseconds.
Backplane State	Displays the current state of the backplane. The available values are: Initializing, Faulty, Disabled, Listening, PreMaster, Master, Passive, Uncalibration, Slave, or None.
Ethernet State	Displays the state of the Ethernet port. The available values are: Initializing, Faulty, Disabled, Listening, PreMaster, Master, Passive, Uncalibration, Slave, or None.
Identity	Displays the unique identifier for the local clock. The format depends on the network protocol. Ethernet network encodes the MAC address into the identifier.
Class	Displays a measure of quality of the local clock. Values are defined from 0...255, with zero as the best clock.
Accuracy	Indicates the expected absolute accuracy of the local clock relative to the PTP epoch. The accuracy is specified as a graduated scale that starts at 25 nsec and ends at greater than 10 seconds or unknown. The lower the accuracy value, the better the clock.
Variance	Displays the measure of inherent stability properties of the local clock. The value is represented in offset scaled log units. The lower the variance, the better the clock.
Source	Displays the time source of the local clock. The available values are: <ul style="list-style-type: none"> <li>• Atomic Clock</li> <li>• GPS</li> <li>• Terrestrial Radio</li> <li>• PTP</li> <li>• NTP</li> <li>• HAND set</li> <li>• Other</li> <li>• Oscillator</li> </ul>

## 5069-AEN2TR EtherNet/IP Adapter Diagnostics with RSLinx Software


You can also view diagnostic information in RSLinx® software. Diagnostic information is available on the following tabs:

- [General Tab](#)
- [Port Diagnostics Tab](#)
- [Connection Manager Tab](#)
- [USB Tab](#)

1. From the Communications menu, choose RSWho.


The RSWho dialog box appears.

2. Navigate to the Ethernet network.
3. Right-click the EtherNet/IP module and choose Module Statistics.




### General Tab

The General tab shows device information and any faults on the adapter.



## Port Diagnostics Tab

The Port Diagnostics tab shows information for the port. See [Table 6 on page 63](#) for parameter descriptions.



**Table 6 - Port Diagnostics Parameters - RSLinx**

Parameter	Description
<b>Interface Counters</b>	Provides information relevant to receipt of packets on the interface
In Octets	Octets received on the interface.
Out Octets	Octets sent out from the interface.
In Ucast Packets	Unicast packets that are received on the interface.
Out Ucast Packets	Unicast packet sent out from the interface.
In NUcast Packets	Non-unicast packets that are received on the interface.
Out NUcast Packets	Non-unicast packets sent out from the interface.
In Discards	Inbound packets that were received on the interface but discarded.
Out Discards	Outbound packets that were sent out from the interface but were discarded.
In Errors	Inbound packets that contain errors (excludes In Discards).
Out Errors	Outbound packets that contain errors.
In Unknown Protos	Inbound packets with unknown protocol.


**Table 6 - Port Diagnostics Parameters - RSLinx**

Parameter	Description
<b>Media Counters</b>	Provides information specific to Ethernet media you are using
Alignment Errors	Frames received that are not an integral number of octets in length.
FCS Errors	Frames received that do not pass the FCS (Frame Check Sequence) check.
Single Collisions	Successfully transmitted frames that experienced exactly one collision.
Multiple Collisions	Successfully transmitted frames that experienced multiple collision.
SQE Test Errors	Number of times an SQE test error message was generated.
Deferred Transmissions	Frames for which the first transmission attempt is delayed because the medium is busy.
Late Collisions	Number of times a collision is detected later than 512 bit-times into the transmission of a packet.
Excessive Collisions	Frames for which transmission fails due to excessive collisions.
MAC Transmit Errors	Frames for which transmission fails due to an internal MAC sub layer transmit error.
MAC Receive Errors	Frames for which reception on an interface fails due to an internal MAC sub layer receive error.
Carrier Sense	Times that the carrier sense condition was lost or never asserted when attempting to transmit a frame.
Frame Too Long	Frames received that exceed the maximum permitted frame size.
Reset Counters	Click Reset Counter to reset the interface and media counter values to zero. The values then update to the current counter values. Reset Counter appears dimmed in the following conditions: <ul style="list-style-type: none"> <li>• The project is offline.</li> <li>• The project is online and a communication error occurred.</li> </ul>



## Connection Manager Tab

See [Table 7](#) for a description of the Connection Manager properties.




**Table 7 - Connection Manager Properties**

Field	Description
Requests	Number of open/close connection requests that this module has received.
Format Rejects	Number of open/close connection requests that this module has rejected because the request was not formatted correctly or because some parameter value was not within a supported range of values.
Resource Rejects	Number of open connection requests that this module has rejected because the module did not have enough resources (buffers, link bandwidth, or CPU utilization) to honor the request.
Other Rejects	Number of forwarded open/close connection requests a module rejects.
Timeouts	Number of connections that are not explicitly closed by the connection originator, but closed by this module because they were not being used.

## USB Tab

The USB tab provides the following information about the adapter USB object.



**Table 8 - General Information**

Attribute Name	Description
State	State (Initializing, Fault, Initialized, Configured, Ready, and Reserved) of the USB interface.
Suspend	The USB interface was suspended by the host.
Disabled	The USB interface was disabled by the host.
Logical Address	Logical address of the USB interface (slot number in the virtual backplane).
Bus Speed	The highest USB bus speed the USB interface supports.
OTG Support	USB On The Go (OTG) capability support.
Mode	The operating mode (slave/host) of the USB interface, if the interface supports OTG.

**Table 9 - Interface Counters provide diagnostic information in the USB-CIP layer**

Counter Name	Description
Rx Good Counter	Total number of good USB-CIP transfers received.
Rx Bad Counter	Total number of bad USB-CIP transfers received.
Rx Dropped Counter	Total number of dropped USB-CIP transfers.
Tx Good Counter	Total number of USB-CIP transfers sent.
Tx Retry Counter	Total number of USB-CIP transfers retried.
Tx Dropped Counter	Total number of USB-CIP transfers dropped.

**Table 10 - Media Counters provide diagnostic information in the USB driver layer.**

Counter Name	Description
Rx Byte Counter	Total number of bytes received.
Rx Dropped Counter	Total number of received bytes dropped.
Tx Byte Counter	Total number of bytes sent.
Tx Dropped Bytes	Total number of transmit bytes dropped.
FIFO Overflow	Total number of FIFO (First in First Out) overflows.

## 5069-AEN2TR EtherNet/IP Adapter Diagnostic Web Pages

The 5069-AEN2TR EtherNet/IP adapter provides diagnostic web pages.

---

**IMPORTANT** The diagnostic web pages have many fields that you can use to monitor the EtherNet/IP adapter operating state. This section describes only the most common fields that are used during monitoring.

To troubleshoot problems that you diagnose, see the Troubleshoot EtherNet/IP Networks Application Technique, publication [ENET-AT003](#).

---

The most commonly used diagnostic web pages for the 5069-AEN2TR EtherNet/IP adapter are the following:

- [Diagnostic Overview Page](#)
- [Network Settings](#)
- [Ethernet Statistics](#)
- [Ring Statistics](#)

---

**IMPORTANT** The 5069-AEN2TR EtherNet/IP adapter also offers other diagnostic web pages. These web pages are not as commonly used as the two described in this section and are not described here.

---


## Access Web Browser Support

To access the diagnostic web pages, follow these steps.

1. Open your web browser.
2. In the Address field, type the IP address of the adapter and press Enter.

The Home diagnostic web page appears.

EtherNet/IP Module Internet Protocol (IP) Address



3. Open the Diagnostics folder in the left-most navigation bar, and click the link for each diagnostic web page you need to monitor.

## Diagnostic Overview Page

The Diagnostic Overview web page shows the status of the adapter.

The screenshot shows the 'Diagnostic Overview' page for a module identified as '5069-AEN2TR/A\_LnxMain\_152'. The page is part of the Rockwell Automation Allen-Bradley interface. It features a navigation menu on the left and a main content area with several data tables and summary sections.

**Module Resource Utilization (All Ports)**

I/O Comms Utilization (Actual)	0.0 %
I/O Comms Utilization (Theoretical)	0.0 %

**CIP Connection Statistics (All Ports)**

Active Total	0
Active Messaging	0
Active I/O	0
Maximum Total Observed	1
Maximum Total Supported	320

**TCP Connections (EtherNet/IP Port)**

Active	1
Maximum Observed	1
Maximum Supported	32

**HMI/MSG Unconnected (EtherNet/IP Port)**

Sent Packets Per Second	0
Received Packets Per Second	0
Sent Packet Count	224
Received Packet Count	224

**HMI/MSG Connected (EtherNet/IP Port)**

Sent Packets Per Second	0
Received Packets Per Second	0
Sent Bytes Per Second	0
Received Bytes Per Second	0
Sent Packet Count	518
Received Packet Count	518

**I/O Packets Per Second (EtherNet/IP Port)**

Total	0
Sent	0
Received	0

**I/O Packet Counts (EtherNet/IP Port)**

Total	0
Sent	0
Received	0
Rejected	0
Missed	0

**Multicast Producers (EtherNet/IP Port)**

Active	0
Maximum Observed	0
Maximum Supported	32
Base Address	239.192.3.0

Seconds Between Refresh:  Disable Refresh with 0.

Copyright © 2015 Rockwell Automation, Inc. All Rights Reserved.

## Network Settings

The Network Settings diagnostic web page shows the settings for the Network Interface configuration, Ethernet Interface Configuration, and the Ethernet ports.

The screenshot displays the 'Network Settings' diagnostic web page for a Rockwell Automation device (5069-AEN2TR/A\_LnxMain\_152). The interface includes a navigation menu on the left and a main content area with several configuration sections.

**Network Interface**

Ethernet Address (MAC)	E4:90:69:AA:0C:0F
IP Address	192.168.1.17
Subnet Mask	255.255.255.0
Default Gateway	
Primary Name Server	
Secondary Name Server	
Default Domain Name	
Host Name	
Name Resolution	DNS Enabled
SMTP Server	

**Ethernet Interface Configuration**

Obtain Network Configuration	Static
Switches	999

**Ethernet Port 1**

Interface State	Enabled
Link Status	Active
Speed	1000 Mbps
Duplex	Full Duplex
Autonegotiate Status	Autonegotiate Speed and Duplex

**Ethernet Port 2**


Interface State	Enabled
Link Status	Inactive
Speed	
Duplex	
Autonegotiate Status	

Seconds Between Refresh:  Disable Refresh with 0.

Copyright © 2015 Rockwell Automation, Inc. All Rights Reserved.

## Ethernet Statistics

The Ethernet Statistics diagnostic web page shows the status of communication activity on the Ethernet network. The most commonly monitored fields are described in [Table 11](#).



**Table 11 - Ethernet Statistic Fields**


Field	Specifies
<b>Ethernet Port 1 and Ethernet Port 2</b>	
Interface State	Whether the port is turned off or on. Active or inactive indicates whether there is a cable that is connected.
Link Status	Whether the port is blocked for DLR protocol frames.
Speed	Whether the Ethernet port is operating at 10, 100, or 1000 Mbps.
Duplex	If the Ethernet port is operating at full-duplex mode.
Autonegotiate Status	Whether the port speed and Duplex mode were determined via autonegotiation or whether they were manually configured.

**Table 11 - Ethernet Statistic Fields**

Field	Specifies
<b>Media Counters Port 1 and Port 2</b>	
Alignment Errors	A frame containing bits that do not total an integral multiple of eight.
FCS Errors	A frame containing eight bits, at least one of which has been corrupted.
Single Collisions	The number of outgoing packets that encountered only one collision during transmission.
Multiple Collisions	The number of outgoing packets that encountered 2 . . . 15 collisions during transmission.
SQE Test Errors	A test to detect the collision-present circuit between a transceiver and a network interface card (NIC). <b>IMPORTANT:</b> Because most NICs now have an integrated transceiver, the SQE test is unnecessary. Ignore this media counter.
Deferred Transmissions	The number of outgoing packets whose transmission is deferred because the network is busy when the first attempt is made to send them.
Late Collisions	The number of times two devices transmit data simultaneously.
Excessive Collisions	The number of frames that experience 16 consecutive collisions.
MAC Transmit Errors	Frames for which transmission fails due to an internal MAC sublayer transmit error.
Carrier Sense Errors	Times that the carrier sense condition was lost or never asserted when attempting to transmit a frame.
Frame Too Long	The number of incoming packets that exceed the maximum Ethernet packet size.
MAC Receive Errors	Frames for which reception on the Ethernet interface failed due to an internal MAC sublayer receive error.

## Ring Statistics

The Ring Statistics diagnostic web page shows the status of the Device-level Ring.





## 5069-AEN2TR EtherNet/IP Adapter Reset Button

You can reset the adapter to its factory default values with the reset button.




**ATTENTION:** When you reset a module, all connections to or through the module are closed, and can result in loss of control.



**WARNING:** When you press the reset button while power is on, an electrical arc can occur. This could cause an explosion in hazardous location installations. Be sure that power is removed or the area is nonhazardous before proceeding.

1. Power down the adapter.
2. Open the front door on the adapter.
3. Use a small tool or screwdriver to press and hold the reset button.
4. While holding in the reset button, power up the adapter.
5. Continue to hold the reset button while the 4-character display cycles through TEST, DFLT, 4, 3, 2, 1.
6. Factory Default scrolls one time across the display.
7. Release the reset button.



**Notes:**

## EtherNet/IP Communication Module Status Indicators

EtherNet/IP communication modules have multi-character displays and status indicators to assist with module performance and diagnostics.

### 5069-AEN2TR EtherNet/IP Adapter Status Indicators

You can view the status with the following:

- [Multi-character Display](#)
- [Status Indicators](#)

### Multi-character Display


The 4-character display shows the following information.

**Table 12 - Messages on 4-character Display**

Message Type	Example Message on 4-character Display	Description
TEST	TEST	Message appears while power-up tests run.
PASS	PASS	Message appears when power-up tests complete.
Embedded software version	Rev 2.003	Message appears once, after the power-up tests complete successfully.
OK	OK	The first message in the scrolling message display. Message scrolls continuously during operation.
Port Down	Link 2 - Port Down	Message appears when an EtherNet/IP port does not have a connection. Message scrolls continuously during operation.
Port Rate/Duplex State	Port 1 - 1Gb/FULL	The current port rate and duplex state. Message scrolls continuously during operation. If not connected to a 1 Gb switch, the message shows 100/FULL.
IP Address	192.168.1.17	The IP address of the adapter. Message scrolls continuously during operation.
Link Disabled	Port 2 - Link Disabled	Message appears when the you have disabled an EtherNet/IP port. Message scrolls continuously during operation.
Duplicate IP	Duplicate IP - 00:00:BC:02:34:B4	Message appears when the adapter detects a device with the same IP Address on the network. The message shows the MAC address of the device with the duplicate IP Address. Message scrolls continuously during operation.
Fault	Cycle power to unit.	Message appears, and scrolls continuously, during a fault.

## Status Indicators

The 5069-AEN2TR EtherNet/IP adapter has these status indicators.



Indicator	State	Description
OK	Off	There is no power applied to the device.
	Steady green	The device is operating in a normal condition.
	Flashing red	<ul style="list-style-type: none"> <li>The device has a recoverable fault. The fault can be read from the device through the USB or Ethernet ports.</li> <li>A firmware update is being performed on the module.</li> </ul>
	Steady red	The device has an unrecoverable fault. Minimum recovery is to power cycle.
SD	Off	There is no activity to the SD card.
	Flashing green	The controller is reading from, or writing to the SD card.
	Flashing red	The SD card does not have a valid file system.
NET	Off	The module is not configured, or does not have an IP address.
	Flashing green	The adapter has an IP address, but no active connections are established.
	Steady green	The adapter has an IP address and at least one established active connection.
	Steady red	Duplicate IP Address or invalid configuration.
LINK1	Off	No activity. One of these conditions exists: <ul style="list-style-type: none"> <li>The module is not powered.                             <ul style="list-style-type: none"> <li>Verify that there is power.</li> <li>Verify that the module RTB is properly seated in the adapter.</li> <li>Verify that the RJ45 cables are properly seated in the adapter and connected devices.</li> </ul> </li> <li>No link exists on the port.</li> </ul>
	Flashing green	Activity exists on the port.
LINK2	Off	No activity. One of these conditions exists: <ul style="list-style-type: none"> <li>The module is not powered.                             <ul style="list-style-type: none"> <li>Verify that there is power.</li> <li>Verify that the module RTB is properly seated in the adapter.</li> <li>Verify that the RJ45 cables are properly seated in the adapter and connected devices.</li> </ul> </li> <li>No link exists on the port.</li> <li>The port is administratively disabled.</li> <li>The port is disabled due to rapid ring faults.</li> </ul>
	Flashing green	Activity exists on the port.
	Steady green	Adapter is the supervisor of a Device Level Ring network.
MOD Power	Off	There is no Module Power applied to the device.
	Steady green	Module Power is present.
SA Power	Off	Status of SA Power is unknown.
	Steady green	SA Power is present.

## Module Tags

Module tags are created when you add an EtherNet/IP communication module to the Logix Designer application project, and set the connection to Status.

**Table 13 - 5069-AEN2TR EtherNet/IP Adapter Module Tags**

Tag Name	Data Type	Definition	Valid Values
RunMode	BOOL	Module's operating state	<ul style="list-style-type: none"> <li>0 = Idle</li> <li>1 = Run</li> </ul>
ConnectionFaulted	BOOL	Indicates if a connection to the target is running. The module always returns a zero in this member. The controller overwrites the zero with a one when the connection is not up.	<ul style="list-style-type: none"> <li>0 = Connection running</li> <li>1 = Connection not running</li> </ul>
DiagnosticActive	BOOL	Indicates if any diagnostics are active or if the prognostics threshold is reached.	<ul style="list-style-type: none"> <li>0 = No diagnostics active</li> <li>1 = One or more diagnostics are active or the prognostics threshold is reached</li> </ul>
CIPSyncValid	BOOL	Indicates if the module is synced with a 1588 master.	<ul style="list-style-type: none"> <li>0 = Module is not synced</li> <li>1 = Module is synced</li> </ul>
CIPSyncTimeout	BOOL	Indicates if the module was once synced with a 1588 master, but is not now due to a timeout.	<ul style="list-style-type: none"> <li>0 = A valid time master has not timed out.</li> <li>1 = A valid time master was detected on the backplane, but the time master has timed out. The module is using its local clock and can be drifting away from the last known time master.</li> </ul>
DiagnosticSequenceCount	SINT	Increments for each time a distinct diagnostic condition is detected, and when a distinct diagnostic condition transitions from detected to not detected. Set to zero by product reset or power cycle. Wraps from 255 (-1) to 1 skipping zero.	-128...127 The value of 0 is skipped except during module power-up.
OverTemperature	BOOL	Indicates if the module is at its maximum thermal rating.	<ul style="list-style-type: none"> <li>0 = Module is not at its maximum thermal rating</li> <li>1 = Module is at its maximum thermal rating</li> </ul>
CriticalTemperature	BOOL	Indicates if the temperature is approaching (but below) the point of thermal runaway.	<ul style="list-style-type: none"> <li>0 = Temperature is not approaching the point of thermal runaway</li> <li>1 = Temperature is approaching the point of thermal runaway</li> </ul>
Port1Connected	BOOL	Indicates if the numbered Ethernet port is active.	<ul style="list-style-type: none"> <li>0 = Ethernet port is not active</li> <li>1 = Ethernet port is active</li> </ul>
Port2Connected	BOOL	Indicates if the numbered Ethernet port is active.	<ul style="list-style-type: none"> <li>0 = Ethernet port is not active</li> <li>1 = Ethernet port is active</li> </ul>
Port1FullDuplex	BOOL	Indicates if the numbered Ethernet port, if it is connected, is running full-duplex mode or half-duplex mode.	<ul style="list-style-type: none"> <li>0 = Ethernet port is running in half-duplex mode</li> <li>1 = Ethernet port is running in full-duplex mode</li> </ul>

**Table 13 - 5069-AEN2TR EtherNet/IP Adapter Module Tags**

Tag Name	Data Type	Definition	Valid Values
Port2FullDuplex	BOOL	Indicates if the numbered Ethernet port, if it is connected, is running full-duplex mode or half-duplex mode.	<ul style="list-style-type: none"> <li>0 = Ethernet port is running in half-duplex mode</li> <li>1 = Ethernet port is running in full-duplex mode</li> </ul>
Port1AutoNegotiationStatus	SINT	Indicates the status of link auto-negotiation	<ul style="list-style-type: none"> <li>0 = Auto-negotiation in progress.</li> <li>1 = Auto-negotiation and speed detection failed. Using default values for speed and duplex. Default values are product-dependent; recommended defaults are 10 Mbps and half-duplex.</li> <li>2 = Auto negotiation failed, but detected speed. Duplex was defaulted. Default value is product-dependent; recommended default is half-duplex mode.</li> <li>3 = Successfully negotiated speed and duplex mode.</li> <li>4 = Auto-negotiation not attempted. Forced speed and duplex mode.</li> </ul>
Port2AutoNegotiationStatus	SINT	Indicates the status of link auto-negotiation	<ul style="list-style-type: none"> <li>0 = Auto-negotiation in progress.</li> <li>1 = Auto-negotiation and speed detection failed. Using default values for speed and duplex. Default values are product-dependent; recommended defaults are 10 Mbps and half-duplex.</li> <li>2 = Auto negotiation failed, but detected speed. Duplex was defaulted. Default value is product-dependent; recommended default is half-duplex mode.</li> <li>3 = Successfully negotiated speed and duplex mode.</li> <li>4 = Auto-negotiation not attempted. Forced speed and duplex mode.</li> </ul>
Port1Speed	INT	Indicates the actual port speed in Mbps.	10, 100, 1000
Port2Speed	INT	Indicates the actual port speed in Mbps.	10, 100, 1000
TCPConnections	INT	The number of TCP/IP connections currently open to the adapter.	All positive values
CIPConnections	INT	The number of CIP connections currently open to and through the adapter.	All positive values
CIPLostPackets	DINT	A running sum of the number of Sequenced Address Item Sequence Numbers that are skipped in Class 0 and Class 1 connections that are consumed by the adapter and its children.	All positive values
CIPTimeouts	DINT	A running count of the number of connections that time out, both originated and targeted, and connections to and through the adapter.	All positive values

**Table 13 - 5069-AEN2TR EtherNet/IP Adapter Module Tags**

Tag Name	Data Type	Definition	Valid Values
HMIPacketRate	DINT	The number of Class 3 packets and unconnected packets that are sent and received by the device in the previous second.	All
IOPacketRate	DINT	The number of class 0 and class 1 packets transmitted or received by the adapter in the previous second.	All positive values
EthernetErrors	DINT	The sum over all ports of the Ethernet Link object values: In Discards, In Errors, In Unknown Protos, Out Discards, Out Errors, Alignment Errors, FCS Errors, Single Collisions, Multiple Collisions, SQE Test Errors, Deferred Transmissions, Late Collisions, Excessive Collisions, MAC Transmit Errors, Carrier Sense Errors, Frame Too Long, and MAC Receive Errors.	All positive values
CPUUtilization	INT	The percentage of the capacity of the product's compute engine (whether that is a CPU, or a core of a CPU, or a thread) most important to the performance of communication of packets by the product. The value equals the percentage.	0 . . . 100
DLRNetworkState	SINT	The current value of the Network Status instance attribute of the DLR object for devices with multiple Ethernet ports that support DLR.	0 - Normal 1 - Ring Fault 2 - Unexpected Loop Detected 3 - Partial Network Fault 4 - Rapid Fault/Restore Cycle
DLRSupervisorState	SINT	The current value of the Ring Supervisor Status instance attribute of the DLR object for devices with multiple Ethernet ports that support DLR.	0 - Device is functioning as a backup 1 - Device is functioning as the active ring supervisor 2 - Device is functioning as a normal ring node 3 - Device is operating in a non-DLR topology 4 - Device cannot support the current ring parameters (Beacon Interval and Beacon Timeout)
LocalClockOffset	LINT	The offset from the local clock to the system time. This value helps to detect steps in time. This value updates when a PTP update is received.	All.
LocalClockOffsetTimestamp	LINT	The time when the Local Clock Offset was sampled. This value is initially zero, and the first time stamp occurs when the module synchronizes with the master clock.	N/A
GrandMasterClockID	SINT[8]	The EUI-64 Identity of the CIP Sync Grandmaster clock the module is synced to.	All

**Notes:**



## Numerics

### 4-character display

5069-AEN2TR adapter 75

### 5069-AEN2TR adapter

configure  
     set network IP address 27  
 diagnostics  
     web pages 68  
     with Logix Designer 53  
     with RSLinx software 62  
 reset button 73  
 status indicators 75  
     4-character display 75

## B

### BOOTP/DHCP server

set network IP address 28-31

## C

### configure

communication drivers 19-24  
 communication module with RSLinx software  
     32-35  
 DHCP server 31  
 EtherNet/IP communication driver 20-21  
 set network IP address  
     5069-AEN2TR adapter 27  
 USB communication driver 22-24  
 workstation 19-24

## D

### Device Level Ring network 51

### DHCP server 31

### diagnostics 53-73

5069-AEN2TR adapter diagnostic web pages  
     67  
     access web browser support 68  
     diagnostic overview page 69  
     ethernet statistics 71  
     network settings 70  
     ring statistics 72  
 5069-AEN2TR adapter diagnostics with Logix  
     Designer 53  
     connection category 54  
     module info category 56, 57  
     port configuration category 58  
     time sync category 60  
 5069-AEN2TR adapter diagnostics with  
     RSLinx software 62  
     connection manager tab 65  
     general tab 62  
     port diagnostics tab 63  
     USB tab 66  
 5069-AEN2TR adapter reset button 73

DNS addressing 36-37

domain name 26

duplicate address detection 35-36

## E

Ethernet communication driver 20-21

Ethernet statistics 71

EtherNet/IP communication driver 20-21

EtherNet/IP communication module

    set network IP address 27  
     status indicators 75

## G

gateway 25

## H

host name 26

## I

### IP address

definition 25  
 duplicate address detection 35-36  
 set network IP address with DHCP server 31  
 set network IP address with RSLinx software  
     32-35

## M

mode switch 45

module fault 54

## N

### network address

DNS addressing 36-37  
 set network IP address 27

### network parameters

DNS addressing 26  
 domain name 26  
 gateway 25  
 host name 26  
 IP address 25  
 subnet mask 25

## P

### port diagnostics

with Logix Designer 58  
 with RSLinx software 63

## R

**Refresh** 57

**reset button**

5069-AEN2TR adapter 73

**ring statistics** 72

**rotary switches**

set IP network address 27

**RSLinx software**

5069-AEN2TR adapter diagnostics 62

configuring network parameters 32-35

Ethernet communication driver 20-21

setting network IP address 27

USB communication driver 22-24

## S

**set network IP address** 27

BOOTP/DHCP server 27, 28-31

rotary switches 27

RSLinx software 32-35

**status indicators**

5069-AEN2TR adapter 75

4-character display 75

EtherNet/IP communication modules 75

**subnet mask** 25

## T

**troubleshoot**

web browser support 68

## U

**USB communication driver** 22-24

## W

**web browser support** 68



## Rockwell Automation Support

Rockwell Automation provides technical information on the Web to assist you in using its products.

At <http://www.rockwellautomation.com/support> you can find technical and application notes, sample code, and links to software service packs. You can also visit our Support Center at <https://rockwellautomation.custhelp.com/> for software updates, support chats and forums, technical information, FAQs, and to sign up for product notification updates.

In addition, we offer multiple support programs for installation, configuration, and troubleshooting. For more information, contact your local distributor or Rockwell Automation representative, or visit <http://www.rockwellautomation.com/services/online-phone>.

## Installation Assistance

If you experience a problem within the first 24 hours of installation, review the information that is contained in this manual. You can contact Customer Support for initial help in getting your product up and running.

United States or Canada	1.440.646.3434
Outside United States or Canada	Use the <a href="#">Worldwide Locator</a> at <a href="http://www.rockwellautomation.com/rockwellautomation/support/overview.page">http://www.rockwellautomation.com/rockwellautomation/support/overview.page</a> , or contact your local Rockwell Automation representative.

## New Product Satisfaction Return

Rockwell Automation tests all of its products to help ensure that they are fully operational when shipped from the manufacturing facility. However, if your product is not functioning and needs to be returned, follow these procedures.

United States	Contact your distributor. You must provide a Customer Support case number (call the phone number above to obtain one) to your distributor to complete the return process.
Outside United States	Please contact your local Rockwell Automation representative for the return procedure.

## Documentation Feedback

Your comments will help us serve your documentation needs better. If you have any suggestions on how to improve this document, complete this form, publication [RA-DU002](#), available at <http://www.rockwellautomation.com/literature/>.

Rockwell Automation maintains current product environmental information on its website at <http://www.rockwellautomation.com/rockwellautomation/about-us/sustainability-ethics/product-environmental-compliance.page>.

Rockwell Otomasyon Ticaret A.Ş., Kar Plaza İş Merkezi E Blok Kat:6 34752 İçerenköy, İstanbul, Tel: +90 (216) 5698400

**[www.rockwellautomation.com](http://www.rockwellautomation.com)**

### Power, Control and Information Solutions Headquarters

Americas: Rockwell Automation, 1201 South Second Street, Milwaukee, WI 53204-2496 USA, Tel: (1) 414.382.2000, Fax: (1) 414.382.4444  
Europe/Middle East/Africa: Rockwell Automation NV, Pegasus Park, De Kleetlaan 12a, 1831 Diegem, Belgium, Tel: (32) 2 663 0600, Fax: (32) 2 663 0640  
Asia Pacific: Rockwell Automation, Level 14, Core F, Cyberport 3, 100 Cyberport Road, Hong Kong, Tel: (852) 2887 4788, Fax: (852) 2508 1846