



Send comments to nx5000-docfeedback@cisco.com

CHAPTER 3

Ethernet Show Commands

This chapter describes the Cisco NX-OS Ethernet **show** commands available on Cisco Nexus 5000 Series switches.

■ show interface brief***Send comments to nx5000-docfeedback@cisco.com***

show interface brief

To display a brief summary of the interface configuration information, use the **show interface brief** command.

show interface brief

Syntax Description This command has no arguments or keywords.

Command Default None

Command Modes EXEC mode

Command History	Release	Modification
	4.0(0)N1(1a)	This command was introduced.

Examples This example shows how to display the summary configuration information of the specified interface:

```
switch# show interface brief

-----
Ethernet      VLAN   Type Mode  Status  Reason           Speed    Port
Interface                            Reason          Ch #
-----
```

Ethernet Interface	VLAN	Type	Mode	Status	Reason	Speed	Port Ch #
Eth1/1	1	eth	trunk	up	none	10G(D)	4000
Eth1/2	1	eth	trunk	up	none	10G(D)	4000
Eth1/3	1	eth	trunk	up	none	10G(D)	4000
Eth1/4	1	eth	trunk	up	none	10G(D)	4000
Eth1/5	1	eth	access	down	SFP not inserted	10G(D)	--
Eth1/6	1	eth	access	down	SFP not inserted	10G(D)	--
Eth1/7	1	eth	trunk	up	none	10G(D)	10
Eth1/8	1	eth	trunk	up	none	10G(D)	10
Eth1/9	1	eth	trunk	up	none	10G(D)	10
Eth1/10	1	eth	trunk	up	none	10G(D)	10
Eth1/11	1	eth	access	down	SFP not inserted	10G(D)	--
Eth1/12	1	eth	access	down	SFP not inserted	10G(D)	--
Eth1/13	1	eth	access	down	SFP not inserted	10G(D)	--
Eth1/14	1	eth	access	down	SFP not inserted	10G(D)	--
Eth1/15	1	eth	access	down	SFP not inserted	10G(D)	--
Eth1/16	1	eth	access	down	SFP not inserted	10G(D)	--
Eth1/17	1	eth	access	down	SFP not inserted	10G(D)	--
Eth1/18	1	eth	access	down	SFP not inserted	10G(D)	--
Eth1/19	1	eth	access	down	SFP not inserted	10G(D)	--
Eth1/20	1	eth	access	down	SFP not inserted	10G(D)	--
Eth1/21	1	eth	access	down	SFP not inserted	10G(D)	--
Eth1/22	1	eth	access	down	SFP not inserted	10G(D)	--
Eth1/23	1	eth	access	down	Link not connected	10G(D)	--
Eth1/24	1	eth	access	down	Link not connected	10G(D)	--
Eth1/25	1	eth	access	down	SFP not inserted	10G(D)	--
Eth1/26	1	eth	access	down	SFP not inserted	10G(D)	--
Eth1/27	1	eth	access	down	SFP not inserted	10G(D)	--

Send comments to nx5000-docfeedback@cisco.com

```

Eth1/28      1     eth  access  down    SFP not inserted      10G(D) --
Eth1/29      1     eth  access  down    SFP not inserted      10G(D) --
Eth1/30      1     eth  access  down    SFP not inserted      10G(D) --
Eth1/31      1     eth  access  down    SFP not inserted      10G(D) --
Eth1/32      1     eth  access  down    SFP not inserted      10G(D) --
Eth1/33      1     eth  access  down    SFP not inserted      10G(D) --
Eth1/34      1     eth  access  down    SFP not inserted      10G(D) --
Eth1/35      1     eth  access  down    SFP not inserted      10G(D) --
Eth1/36      1     eth  access  down    SFP not inserted      10G(D) --
Eth1/37      1     eth  access  down    SFP not inserted      10G(D) --
Eth1/38      1     eth  access  down    SFP not inserted      10G(D) --
Eth1/39      1     eth  access  down    SFP not inserted      10G(D) --
Eth1/40      1     eth  trunk   up      none                  10G(D) --
Eth2/1       1     eth  access  down    SFP not inserted      10G(D) --
Eth2/2       1     eth  access  up      none                  10G(D) --
Eth2/3       1     eth  access  down    SFP not inserted      10G(D) --
Eth2/4       1     eth  access  up      none                  10G(D) --
Eth2/5       1     eth  access  up      none                  10G(D) --
Eth2/6       1     eth  access  down    SFP not inserted      10G(D) --

-----
Port-channel VLAN Type Mode Status Reason          Speed Protocol
Interface

-----
Po10        1     eth  trunk   up      none          a-10G(D) lacp
Po4000      1     eth  trunk   up      none          a-10G(D) lacp

-----
Port      VRF           Status IP Address          Speed MTU
-----
mgmt0    --            up      192.168.10.37      100   1500

-----
Interface Secondary VLAN(Type)          Status Reason
-----
Vlan1     --            down    Administratively down

switch#

```

Related Commands**Command****Description**

interface ethernet	Configures an Ethernet IEEE 802.3 interface.
---------------------------	--

■ show interface capabilities

Send comments to nx5000-docfeedback@cisco.com

show interface capabilities

To display detailed information about the capabilities of an interface, use the **show interface capabilities** command.

show interface ethernet slot/port capabilities

Syntax Description	ethernet slot/port	Specifies an Ethernet interface slot number and port number. The <i>slot</i> number is from 1 to 255, and the <i>port</i> number is from 1 to 128.
Command Default	None	
Command Modes	EXEC mode	
Command History	Release	Modification
	4.0(0)N1(1a)	This command was introduced.
Usage Guidelines	You can use the show interface capabilities command only for physical interfaces.	
Examples	This example shows how to display the interface capabilities for a specific interface:	
	<pre>switch# show interface ethernet 1/1 capabilities Ethernet1/1 Model: N5K-C5020P-BF-XL-SU Type (SFP capable): SFP-H10GB-CU1M Speed: 1000,10000 Duplex: full Trunk encap. type: 802.1Q Channel: yes Broadcast suppression: percentage(0-100) Flowcontrol: rx-(off/on),tx-(off/on) Rate mode: none QOS scheduling: rx-(6q1t),tx-(1p6q0t) CoS rewrite: no ToS rewrite: no SPAN: yes UDLD: yes Link Debounce: yes Link Debounce Time: yes MDIX: no Pvlan Trunk capable: yes TDR capable: no Port mode: Switched FEX Fabric: yes switch#</pre>	

Send comments to nx5000-docfeedback@cisco.com

Related Commands	Command	Description
	interface ethernet	Configures an Ethernet IEEE 802.3 interface.

■ **show interface debounce**

Send comments to nx5000-docfeedback@cisco.com

show interface debounce

To display the debounce time information for all interfaces, use the **show interface debounce** command.

show interface debounce

Syntax Description This command has no arguments or keywords.

Command Default None

Command Modes EXEC mode

Command History	Release	Modification
	4.0(0)N1(1a)	This command was introduced.

Examples This example shows how to display the debounce status of all interfaces:

```
switch# show interface debounce
```

Port	Debounce time	Value(ms)
Eth1/1	enable	100
Eth1/2	enable	100
Eth1/3	enable	100
Eth1/4	enable	100
Eth1/5	enable	100
Eth1/6	enable	100
Eth1/7	enable	100
Eth1/8	enable	100
Eth1/9	enable	100
Eth1/10	enable	100
Eth1/11	enable	100
Eth1/12	enable	100
Eth1/13	enable	100
Eth1/14	enable	100
Eth1/15	enable	100
Eth1/16	enable	100
Eth1/17	enable	100
Eth1/18	enable	100
Eth1/19	enable	100
Eth1/20	enable	100
Eth1/21	enable	100
Eth1/22	enable	100
Eth1/23	enable	100
Eth1/24	enable	100
Eth1/25	enable	100
Eth1/26	enable	100
Eth1/27	enable	100
Eth1/28	enable	100
Eth1/29	enable	100

Send comments to nx5000-docfeedback@cisco.com

```
Eth1/30      enable          100
Eth1/31      enable          100
Eth1/32      enable          100
--More--
switch#
```

Related Commands	Command	Description
	link debounce	Enables the debounce timer on an interface.

■ show interface ethernet

Send comments to nx5000-docfeedback@cisco.com

show interface ethernet

To display information about the interface configuration, use the **show interface ethernet** command.

show interface ethernet slot/port [counters | description | status]

Syntax Description	slot/port Ethernet interface slot number and port number. The <i>slot</i> number is from 1 to 255, and the <i>port</i> number is from 1 to 128. counters (Optional) Displays information about the counters configured on an interface. description (Optional) Displays the description of an interface configuration. status (Optional) Displays the operational state of the interface.
---------------------------	--

Command Default Displays all information for the interface.

Command Modes EXEC mode

Command History	Release	Modification
	4.0(0)N1(1a)	This command was introduced.

Examples This example shows how to display the detailed configuration of the specified interface:

```
switch# show interface ethernet 1/1
Ethernet1/1 is up
    Hardware: 1000/10000 Ethernet, address: 000d.ece7.df48 (bia 000d.ece7.df48)
    MTU 1500 bytes, BW 10000000 Kbit, DLY 10 usec,
        reliability 255/255, txload 1/255, rxload 1/255
    Encapsulation ARPA
    Port mode is fex-fabric
    full-duplex, 10 Gb/s, media type is 1/10g
    Beacon is turned off
    Input flow-control is off, output flow-control is off
    Rate mode is dedicated
    Switchport monitor is off
    Last link flapped 09:03:57
    Last clearing of "show interface" counters never
    30 seconds input rate 2376 bits/sec, 0 packets/sec
    30 seconds output rate 1584 bits/sec, 0 packets/sec
    Load-Interval #2: 5 minute (300 seconds)
        input rate 1.58 Kbps, 0 pps; output rate 792 bps, 0 pps
    RX
        0 unicast packets 10440 multicast packets 0 broadcast packets
        10440 input packets 11108120 bytes
        0 jumbo packets 0 storm suppression packets
        0 runts 0 giants 0 CRC 0 no buffer
        0 input error 0 short frame 0 overrun 0 underrun 0 ignored
        0 watchdog 0 bad etype drop 0 bad proto drop 0 if down drop
        0 input with dribble 0 input discard
        0 Rx pause
```

Send comments to nx5000-docfeedback@cisco.com

```

TX
 0 unicast packets  20241 multicast packets  105 broadcast packets
 20346 output packets  7633280 bytes
 0 jumbo packets
 0 output errors  0 collision  0 deferred  0 late collision
 0 lost carrier  0 no carrier  0 babbie
 0 Tx pause
 1 interface resets

switch#

```

This example shows how to display the counters configured on a specified interface:

```
switch# show interface ethernet 1/1 counters
```

Port	InOctets	InUcastPkts	InMcastPkts	InBcastPkts
Eth1/1	17193136	0	16159	0
Port	OutOctets	OutUcastPkts	OutMcastPkts	OutBcastPkts
Eth1/1	11576758	0	28326	106

Related Commands

Command	Description
interface ethernet	Configures an Ethernet IEEE 802.3 interface.

 show interface port-channel

Send comments to nx5000-docfeedback@cisco.com

show interface port-channel

To display the information about an EtherChannel interface configuration, use the **show interface port-channel** command.

show interface port-channel *number[.subinterface-number]* [brief | counters | description | status]

Syntax Description	<table border="0"> <tr> <td><i>number</i></td><td>EtherChannel number. The range is from 1 to 4096.</td></tr> <tr> <td><i>.subinterface-number</i></td><td>(Optional) Port-channel subinterface configuration. Use the EtherChannel number followed by a dot (.) indicator and the subinterface number. The format is <i>portchannel-number.subinterface-number</i>.</td></tr> <tr> <td>counters</td><td>(Optional) Displays information about the counters configured on the EtherChannel interface.</td></tr> <tr> <td>description</td><td>(Optional) Displays the description of the EtherChannel interface configuration.</td></tr> <tr> <td>status</td><td>(Optional) Displays the operational state of the EtherChannel interface.</td></tr> </table>	<i>number</i>	EtherChannel number. The range is from 1 to 4096.	<i>.subinterface-number</i>	(Optional) Port-channel subinterface configuration. Use the EtherChannel number followed by a dot (.) indicator and the subinterface number. The format is <i>portchannel-number.subinterface-number</i> .	counters	(Optional) Displays information about the counters configured on the EtherChannel interface.	description	(Optional) Displays the description of the EtherChannel interface configuration.	status	(Optional) Displays the operational state of the EtherChannel interface.
<i>number</i>	EtherChannel number. The range is from 1 to 4096.										
<i>.subinterface-number</i>	(Optional) Port-channel subinterface configuration. Use the EtherChannel number followed by a dot (.) indicator and the subinterface number. The format is <i>portchannel-number.subinterface-number</i> .										
counters	(Optional) Displays information about the counters configured on the EtherChannel interface.										
description	(Optional) Displays the description of the EtherChannel interface configuration.										
status	(Optional) Displays the operational state of the EtherChannel interface.										

Command Default None

Command Modes EXEC mode

Command History	Release	Modification
	4.0(0)N1(1a)	This command was introduced.

Examples This example shows how to display the configuration information of a specified EtherChannel interface:

```
switch# show interface port-channel 21
port-channel21 is up
  Hardware: Port-Channel, address: 000d.ece7.df72 (bia 000d.ece7.df72)
  MTU 1500 bytes, BW 10000000 Kbit, DLY 10 usec,
    reliability 255/255, txload 1/255, rxload 1/255
  Encapsulation ARPA
  Port mode is trunk
  full-duplex, 10 Gb/s
  Beacon is turned off
  Input flow-control is on, output flow-control is on
  Switchport monitor is off
  Members in this channel: Eth2/3
  Last clearing of "show interface" counters never
  30 seconds input rate 0 bits/sec, 0 packets/sec
  30 seconds output rate 352 bits/sec, 0 packets/sec
  Load-Interval #2: 5 minute (300 seconds)
    input rate 0 bps, 0 pps; output rate 368 bps, 0 pps
  RX
    0 unicast packets 0 multicast packets 0 broadcast packets
    0 input packets 0 bytes
```

Send comments to nx5000-docfeedback@cisco.com

```
0 jumbo packets 0 storm suppression packets
0 runts 0 giants 0 CRC 0 no buffer
0 input error 0 short frame 0 overrun 0 underrun 0 ignored
0 watchdog 0 bad etype drop 0 bad proto drop 0 if down drop
0 input with dribble 0 input discard
0 Rx pause
TX
0 unicast packets 15813 multicast packets 9 broadcast packets
15822 output packets 1615917 bytes
0 jumbo packets
0 output errors 0 collision 0 deferred 0 late collision
0 lost carrier 0 no carrier 0 babble
0 Tx pause
1 interface resets

switch#
```

Related Commands

Command	Description
interface port-channel	Configures an EtherChannel interface.

■ show interface mac-address

Send comments to nx5000-docfeedback@cisco.com

show interface mac-address

To display the information about the MAC address, use the **show interface mac-address** command.

show interface [type slot/port | portchannel-no] mac-address

Syntax Description	<table border="0"> <tr> <td><i>type</i></td><td>(Optional) Interface for which MAC addresses should be displayed. The <i>type</i> can be either Ethernet or EtherChannel.</td></tr> <tr> <td><i>slot/port</i></td><td>Ethernet interface port number and slot number. The slot number is from 1 to 255, and the port number is from 1 to 128.</td></tr> <tr> <td><i>portchannel-no</i></td><td>EtherChannel number. The EtherChannel number is from 1 to 4096.</td></tr> </table>	<i>type</i>	(Optional) Interface for which MAC addresses should be displayed. The <i>type</i> can be either Ethernet or EtherChannel.	<i>slot/port</i>	Ethernet interface port number and slot number. The slot number is from 1 to 255, and the port number is from 1 to 128.	<i>portchannel-no</i>	EtherChannel number. The EtherChannel number is from 1 to 4096.
<i>type</i>	(Optional) Interface for which MAC addresses should be displayed. The <i>type</i> can be either Ethernet or EtherChannel.						
<i>slot/port</i>	Ethernet interface port number and slot number. The slot number is from 1 to 255, and the port number is from 1 to 128.						
<i>portchannel-no</i>	EtherChannel number. The EtherChannel number is from 1 to 4096.						

Command Default None

Command Modes EXEC mode

Command History	Release	Modification
	4.0(0)N1(1a)	This command was introduced.

Usage Guidelines If you do not specify an interface, the system displays all the MAC addresses.

Examples This example shows how to display the information on MAC addresses for the entire switch:

```
switch# show interface mac-address
```

Interface	Mac-Address	Burn-in Mac-Address
Ethernet1/1	0005.9b78.6e7c	0005.9b78.6e48
Ethernet1/2	0005.9b78.6e7c	0005.9b78.6e49
Ethernet1/3	0005.9b78.6e7c	0005.9b78.6e4a
Ethernet1/4	0005.9b78.6e7c	0005.9b78.6e4b
Ethernet1/5	0005.9b78.6e7c	0005.9b78.6e4c
Ethernet1/6	0005.9b78.6e7c	0005.9b78.6e4d
Ethernet1/7	0005.9b78.6e7c	0005.9b78.6e4e
Ethernet1/8	0005.9b78.6e7c	0005.9b78.6e4f
Ethernet1/9	0005.9b78.6e7c	0005.9b78.6e50
Ethernet1/10	0005.9b78.6e7c	0005.9b78.6e51
Ethernet1/11	0005.9b78.6e7c	0005.9b78.6e52
Ethernet1/12	0005.9b78.6e7c	0005.9b78.6e53
Ethernet1/13	0005.9b78.6e7c	0005.9b78.6e54
Ethernet1/14	0005.9b78.6e7c	0005.9b78.6e55
Ethernet1/15	0005.9b78.6e7c	0005.9b78.6e56
Ethernet1/16	0005.9b78.6e7c	0005.9b78.6e57
Ethernet1/17	0005.9b78.6e7c	0005.9b78.6e58
Ethernet1/18	0005.9b78.6e7c	0005.9b78.6e59
Ethernet1/19	0005.9b78.6e7c	0005.9b78.6e5a

Send comments to nx5000-docfeedback@cisco.com

```
Ethernet1/20          0005.9b78.6e7c  0005.9b78.6e5b
Ethernet1/21          0005.9b78.6e7c  0005.9b78.6e5c
Ethernet1/22          0005.9b78.6e7c  0005.9b78.6e5d
--More--
switch#
```

This example shows how to display the MAC address information for a specific port channel:

```
switch# show interface port-channel 5 mac-address
```

```
-----
Interface           Mac-Address      Burn-in Mac-Address
-----
port-channel5      0005.9b78.6e7c  0005.9b78.6e7c
switch#
```

Related Commands

Command	Description
mac address-table static	Adds static entries to the MAC address table or configures a static MAC address with IGMP snooping disabled for that address.
show mac address-table	Displays information on the MAC address table.

 show interface private-vlan mapping

Send comments to nx5000-docfeedback@cisco.com

show interface private-vlan mapping

To display information about private VLAN mapping for primary VLAN interfaces, use the **show interface private-vlan mapping** command.

show interface private-vlan mapping

Syntax Description This command has no arguments or keywords.

Command Default None

Command Modes EXEC mode

Command History	Release	Modification
	4.0(0)N1(1a)	This command was introduced.

Usage Guidelines Before you can configure private VLANs, you must enable them by using the **feature private-vlan** command. The commands for configuring private VLANs are not visible until you enable private VLANs.

This command displays the mapping information between the primary and secondary VLANs that allows both VLANs to share the VLAN interface of the primary VLAN.

Examples This example shows how to display information about primary and secondary private VLAN mapping:

```
switch# show interface private-vlan mapping
```

Related Commands	Command	Description
	feature private-vlan	Enables private VLANs.
	show interface switchport	Displays information about the ports, including those in private VLANs.
	show vlan	Displays summary information for all VLANs.
	show vlan private-vlan	Displays information for all private VLANs on the device.

Send comments to nx5000-docfeedback@cisco.com

show interface status err-disabled

To display the error disabled state of interfaces, use the **show interface status err-disabled** command.

show interface status err-disabled

Syntax Description This command has no arguments or keywords.

Command Default None

Command Modes EXEC mode

Command History	Release	Modification
	4.2(1)N1(1)	This command was introduced.

Examples This example shows how to display the error disabled state of interfaces:

```
switch# show interface status err-disabled
```

Port	Name	Status	Reason
Eth114/1/27	--	down	BPDUGuard errDisable
Eth114/1/28	--	down	BPDUGuard errDisable
Eth114/1/29	--	down	BPDUGuard errDisable
Eth114/1/30	--	down	BPDUGuard errDisable
Eth114/1/31	--	down	BPDUGuard errDisable
Eth114/1/32	--	down	BPDUGuard errDisable
Eth114/1/33	--	down	BPDUGuard errDisable
Eth114/1/34	--	down	BPDUGuard errDisable
Eth114/1/35	--	down	BPDUGuard errDisable
Eth114/1/36	--	down	BPDUGuard errDisable
Eth114/1/39	--	down	BPDUGuard errDisable
Eth114/1/40	--	down	BPDUGuard errDisable
Eth114/1/41	--	down	BPDUGuard errDisable
Eth114/1/42	--	down	BPDUGuard errDisable
Eth114/1/43	--	down	BPDUGuard errDisable
Eth114/1/44	--	down	BPDUGuard errDisable
Eth114/1/45	--	down	BPDUGuard errDisable
Eth114/1/46	--	down	BPDUGuard errDisable
Eth114/1/47	--	down	BPDUGuard errDisable
--More--			
switch#			

■ show interface status err-disabled

Send comments to nx5000-docfeedback@cisco.com

Related Commands	Command	Description
	errdisable detect cause	Enables the error disabled (err-disabled) detection.
	errdisable recovery cause	Enables error disabled recovery on an interface.

Send comments to nx5000-docfeedback@cisco.com

show interface switchport

To display information about all the switch port interfaces, use the **show interface switchport** command.

show interface switchport

Syntax Description This command has no arguments or keywords.

Command Default None

Command Modes EXEC mode

Command History	Release	Modification
	4.0(0)N1(1a)	This command was introduced.

Examples This example shows how to display information for all Ethernet interfaces:

```
switch# show interface switchport
Name: Ethernet1/1
  Switchport: Enabled
  Switchport Monitor: Not enabled
  Operational Mode: fex-fabric
  Access Mode VLAN: 1 (default)
  Trunking Native Mode VLAN: 1 (default)
  Trunking VLANs Enabled: 1-3967,4048-4093
  Administrative private-vlan primary host-association: none
  Administrative private-vlan secondary host-association: none
  Administrative private-vlan primary mapping: none
  Administrative private-vlan secondary mapping: none
  Administrative private-vlan trunk native VLAN: none
  Administrative private-vlan trunk encapsulation: dot1q
  Administrative private-vlan trunk normal VLANs: none
  Administrative private-vlan trunk private VLANs:
  Operational private-vlan: none
  Unknown unicast blocked: disabled
  Unknown multicast blocked: disabled

Name: Ethernet1/2
  Switchport: Enabled
  Switchport Monitor: Not enabled
  Operational Mode: fex-fabric
  Access Mode VLAN: 1 (default)
  Trunking Native Mode VLAN: 1 (default)
  Trunking VLANs Enabled: 1-3967,4048-4093
  Administrative private-vlan primary host-association: none
--More--
switch#
```

■ show interface switchport

Send comments to nx5000-docfeedback@cisco.com

Related Commands	Command	Description
	switchport access vlan	Sets the access VLAN when the interface is in access mode.

Send comments to nx5000-docfeedback@cisco.com

show interface transceiver

To display the information about the transceivers connected to a specific interface, use the **show interface transceiver** command.

show interface ethernet *slot/port* transceiver [details]

Syntax Description	ethernet <i>slot/port</i> Displays information about an Ethernet interface slot number and port number. The <i>slot</i> number is from 1 to 255, and the <i>port</i> number is from 1 to 128. details (Optional) Displays detailed information about the transceivers on an interface.
---------------------------	---

Command Default	None
------------------------	------

Command Modes	EXEC mode
----------------------	-----------

Command History	Release	Modification
	4.0(0)N1(1a)	This command was introduced.

Usage Guidelines	You can use the show interface transceiver command only for physical interfaces.
-------------------------	---

Examples	This example shows how to display the transceivers connected to a specified Ethernet interface:
-----------------	---

```
switch# show interface ethernet 1/1 transceiver
Ethernet1/1
  transceiver is present
  type is SFP-H10GB-CU1M
  name is CISCO-MOLEX
  part number is 74752-9044
  revision is 07
  serial number is MOC14081360
  nominal bitrate is 10300 MBit/sec
  Link length supported for copper is 1 m
  cisco id is --
  cisco extended id number is 4
```

```
switch#
```

■ show interface transceiver

Send comments to nx5000-docfeedback@cisco.com

Related Commands	Command	Description
	interface ethernet	Configures an Ethernet IEEE 802.3 interface.
	show interface capabilities	Displays detailed information about the capabilities of an interface.

Send comments to nx5000-docfeedback@cisco.com

show interface vlan

To display brief descriptive information about specified VLANs, use the **show interface vlan** command.

show interface vlan *vlan-id* [brief | private-vlan mapping]

Syntax Description	<p><i>vlan-id</i> Number of the VLAN. The range is from 1 to 4094.</p> <p>brief (Optional) Displays a summary information for the specified VLAN.</p> <p>private-vlan mapping (Optional) Displays the private VLAN mapping information, if any, for the specified VLAN.</p>
---------------------------	--

Command Default	None
------------------------	------

Command Modes	EXEC mode
----------------------	-----------

Command History	Release	Modification
	4.0(0)N1(1a)	This command was introduced.

Usage Guidelines You must enable interface VLANs by using the **feature interface-vlan** or the **svi enable** command. The commands for configuring interface VLANs are not visible until you enable this feature.

This command displays descriptive information for the specified VLAN, including private VLANs.

The switch displays output for the **show interface vlan *vlan-id* private-vlan mapping** command only when you specify a primary private VLAN. If you specify a secondary private VLAN, the output is blank.

Examples This example shows how to display information about the specified VLAN:

```
switch# show interface vlan 10
Vlan10 is up, line protocol is up
  Hardware is EtherSVI, address is 0005.9b78.6e7c
  MTU 1500 bytes, BW 1000000 Kbit, DLY 10 usec,
  switch#
```

This example shows how to display a brief description for the specified VLAN:

```
switch# show interface vlan 10 brief
-----
Interface Secondary VLAN(Type)          Status Reason
-----
Vlan10      --                                up      --
switch#
```

■ **show interface vlan**

Send comments to nx5000-docfeedback@cisco.com

This example shows how to display the private VLAN mapping information, if any, for the VLAN:

```
switch# show interface vlan 10 private-vlan mapping
```

When you specify a primary VLAN, the switch displays all secondary VLANs mapped to that primary VLAN.

Related Commands

Command	Description
show interface switchport	Displays information about the ports, including those in private VLANs.
show vlan	Displays summary information for all VLANs.
show vlan private-vlan	Displays summary information for all private VLANs.

Send comments to nx5000-docfeedback@cisco.com

show ip igmp snooping

To display the Internet Group Management Protocol (IGMP) snooping configuration of the switch, use the **show ip igmp snooping** command.

```
show ip igmp snooping [explicit-tracking vlan vlan-id | groups [detail | vlan vlan-id] | mrouter [vlan vlan-id] | querier [vlan vlan-id] | vlan vlan-id]
```

Syntax Description	explicit-tracking (Optional) Displays information about the explicit host-tracking status for IGMPv3 hosts. If you provide this keyword, you must specify a VLAN.
vlan vlan-id	(Optional) Specifies a VLAN. The VLAN ID range is from 1 to 4094.
groups	(Optional) Displays information for the IGMP group address.
detail	(Optional) Displays detailed information for the group.
mrouter	(Optional) Displays information about dynamically detected multicast routers.
querier	(Optional) Displays information about the snooping querier if defined.

Command Default	None				
Command Modes	EXEC mode				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>4.0(0)N1(1a)</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	4.0(0)N1(1a)	This command was introduced.
Release	Modification				
4.0(0)N1(1a)	This command was introduced.				

Examples	<p>This example shows how to display the IGMP snooping configuration of the switch:</p> <pre>switch# show ip igmp snooping Global IGMP Snooping Information: IGMP Snooping enabled IGMPv1/v2 Report Suppression enabled IGMPv3 Report Suppression disabled Link Local Groups Suppression enabled IGMP Snooping information for vlan 1 IGMP snooping enabled IGMP querier none Switch-querier disabled IGMPv3 Explicit tracking enabled IGMPv2 Fast leave disabled IGMPv1/v2 Report suppression enabled IGMPv3 Report suppression disabled Link Local Groups suppression enabled Router port detection using PIM Hellos, IGMP Queries Number of router-ports: 1 Number of groups: 0 VLAN vPC function enabled Active ports:</pre>
-----------------	---

■ **show ip igmp snooping**

Send comments to nx5000-docfeedback@cisco.com

```
Po19          Po400    Eth170/1/17      Eth171/1/7
              Eth171/1/8   Eth198/1/11      Eth199/1/13
IGMP Snooping information for vlan 300
  IGMP snooping enabled
  IGMP querier none
  Switch-querier disabled
  IGMPv3 Explicit tracking enabled
--More--
switch#
```

Related Commands	Command	Description
	ip igmp snooping (EXEC)	Globally enables IGMP snooping. IGMP snooping must be globally enabled in order to be enabled on a VLAN.
	ip igmp snooping (VLAN)	Enables IGMP snooping on the VLAN interface.

Send comments to nx5000-docfeedback@cisco.com

show lacp

To display Link Aggregation Control Protocol (LACP) information, use the **show lacp** command.

```
show lacp { counters | interface ethernet slot/port | neighbor [interface port-channel number] |
            port-channel [interface port-channel number] | system-identifier }
```

Syntax Description	counters Displays information about the LACP traffic statistics.
interface ethernet	Displays LACP information for a specific Ethernet interface. The <i>slot</i> number is from 1 to 255, and the <i>port</i> number is from 1 to 128.
neighbor	Displays information about the LACP neighbor.
port-channel	Displays information about all EtherChannels.
interface port-channel	(Optional) Displays information about a specific EtherChannel. The <i>number</i> EtherChannel number is from 1 to 4096.
system-identifier	Displays the LACP system identification. It is a combination of the port priority and the MAC address of the device.

Command Default	None				
Command Modes	EXEC mode				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>4.0(0)N1(1a)</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	4.0(0)N1(1a)	This command was introduced.
Release	Modification				
4.0(0)N1(1a)	This command was introduced.				

Usage Guidelines	Use the show lacp command to troubleshoot problems related to LACP in a network.
-------------------------	---

Examples	This example shows how to display the LACP system identification:
	<pre>switch# show lacp system-identifier 32768,0-5-9b-78-6e-7c switch#</pre>

This example shows how to display the LACP information for a specific interface:

```
switch# show lacp interface ethernet 1/1
Interface Ethernet1/1 is up
  Channel group is 1 port channel is Po1
    PDUs sent: 1684
    PDUs rcvd: 1651
    Markers sent: 0
    Markers rcvd: 0
    Marker response sent: 0
    Marker response rcvd: 0
    Unknown packets rcvd: 0
    Illegal packets rcvd: 0
```

■ show lACP

Send comments to nx5000-docfeedback@cisco.com

```
Lag Id: [ [(8000, 0-5-9b-78-6e-7c, 0, 8000, 101), (8000, 0-d-ec-c9-c8-3c, 0, 800
0, 101)] ]
Operational as aggregated link since Wed Apr 21 00:37:27 2010

Local Port: Eth1/1 MAC Address= 0-5-9b-78-6e-7c
System Identifier=0x8000,0-5-9b-78-6e-7c
Port Identifier=0x8000,0x101
Operational key=0
LACP_Activity=active
LACP_Timeout=Long Timeout (30s)
Synchronization=IN_SYNC
Collecting=true
Distributing=true
Partner information refresh timeout=Long Timeout (90s)
Actor Admin State=(Ac-1:To-1:Ag-1:Sy-0:Co-0:Di-0:De-0:Ex-0)
Actor Oper State=(Ac-1:To-0:Ag-1:Sy-1:Co-1:Di-1:De-0:Ex-0)
Neighbor: 1/1
MAC Address= 0-d-ec-c9-c8-3c
System Identifier=0x8000,0-d-ec-c9-c8-3c
Port Identifier=0x8000,0x101
Operational key=0
LACP_Activity=active
LACP_Timeout=Long Timeout (30s)
Synchronization=IN_SYNC
Collecting=true
Distributing=true
Partner Admin State=(Ac-0:To-1:Ag-0:Sy-0:Co-0:Di-0:De-0:Ex-0)
Partner Oper State=(Ac-1:To-0:Ag-1:Sy-1:Co-1:Di-1:De-0:Ex-0)
switch#
```

Related Commands

Command	Description
lacp port-priority	Sets the priority for the physical interfaces for the LACP.
lacp system-priority	Sets the system priority of the switch for the LACP.

Send comments to nx5000-docfeedback@cisco.com

show mac address-table aging-time

To display information about the time-out values for the MAC address table, use the **show mac address-table aging-time** command.

show mac address-table aging-time [vlan *vlan-id*]

Syntax Description	vlan <i>vlan-id</i>	(Optional) Displays information for a specific VLAN. The VLAN ID range is from 1 to 4094.
---------------------------	----------------------------	---

Command Default	None
------------------------	------

Command Modes	EXEC mode
----------------------	-----------

Command History	Release	Modification
	4.0(0)N1(1a)	This command was introduced.
	4.2(1)N1(1)	The command syntax is changed to show mac address-table aging-time .

Examples	This example shows how to display MAC address aging times:
-----------------	--

```
switch# show mac address-table aging-time
Vlan Aging Time
-----
2023 300
2022 300
2021 300
2020 300
2019 300
2018 300
2017 300
2016 300
2015 300
2014 300
2013 300
2012 300
2011 300
2010 300
2009 300
2008 300
2007 300
2006 300
2005 300
2004 300
2003 300
--More--
switch#
```

■ show mac address-table aging-time

Send comments to nx5000-docfeedback@cisco.com

Related Commands	Command	Description
	mac address-table aging-time	Configures the aging time for entries in the MAC address table.
	show mac address-table	Displays information about the MAC address table.

Send comments to nx5000-docfeedback@cisco.com

show mac address-table count

To display the number of entries currently in the MAC address table, use the **show mac address-table count** command.

```
show mac address-table count [address EEEE.EEEE.EEEE] [dynamic | static] [interface
{ethernet slot/port | port-channel number}] [vlan vlan-id]
```

Syntax Description	address EEEE.EEEE.EEEE	(Optional) Displays a count of the MAC address table entries for a specific address.
dynamic		(Optional) Displays a count of the dynamic MAC addresses.
static		(Optional) Displays a count of the static MAC addresses.
interface		(Optional) Specifies the interface. The interface can be Ethernet or EtherChannel.
ethernet slot/port		(Optional) Specifies the Ethernet interface slot number and port number. The <i>slot</i> number is from 1 to 255, and the <i>port</i> number is from 1 to 128.
port-channel number		(Optional) Specifies the EtherChannel interface. The EtherChannel number is from 1 to 4096.
vlan vlan-id		(Optional) Displays information for a specific VLAN. The range is from 1 to 4094.

Command Default	None
------------------------	------

Command Modes	EXEC mode
----------------------	-----------

Command History	Release	Modification
	4.0(0)N1(1a)	This command was introduced.
	4.2(1)N1(1)	The command syntax is changed to show mac address-table count .

Examples	This example shows how to display the number of dynamic entries currently in the MAC address table:
	<pre>switch# show mac address-table count dynamic MAC Entries for all vlans: Total MAC Addresses in Use: 7 switch#</pre>

Related Commands	Command	Description
	show mac address-table	Displays information about the MAC address table.

 show mac address-table notification

Send comments to nx5000-docfeedback@cisco.com

show mac address-table notification

To display notifications about the MAC address table, use the **show mac address-table notification** command.

show mac address-table notification {mac-move | threshold}

Syntax Description	mac-move Displays notification messages about MAC addresses that were moved. threshold Displays notification messages sent when the MAC address table threshold was exceeded.
--------------------	--

Command Default	None
-----------------	------

Command Modes	EXEC mode
---------------	-----------

Command History	Release	Modification
	4.0(0)N1(1a)	This command was introduced.
	4.2(1)N1(1)	The command syntax is changed to show mac address-table notification .

Examples	This example shows how to display MAC address move notifications:
	<pre>switch# show mac address-table notification mac-move MAC Move Notify : disabled switch#</pre>

Related Commands	Command	Description
	show mac address-table	Displays information about the MAC address table.

Send comments to nx5000-docfeedback@cisco.com

show mac address-table

To display the information about the MAC address table, use the **show mac address-table** command.

```
show mac address-table [address mac-address] [dynamic | multicast | static] [interface
{ethernet slot/port | port-channel number}] [vlan vlan-id]
```

Syntax Description	address mac-address (Optional) Displays information about a specific MAC address. dynamic (Optional) Displays information about the dynamic MAC address table entries only. interface (Optional) Specifies the interface. The interface can be either Ethernet or EtherChannel. ethernet slot/port (Optional) Specifies the Ethernet interface slot number and port number. The <i>slot</i> number is from 1 to 255, and the <i>port</i> number is from 1 to 128. port-channel number (Optional) Specifies the EtherChannel interface. The EtherChannel number is from 1 to 4096. multicast (Optional) Displays information about the multicast MAC address table entries only. static (Optional) Displays information about the static MAC address table entries only. vlan vlan-id (Optional) Displays information for a specific VLAN. The VLAN ID range is from 1 to 4094.						
Command Default	None						
Command Modes	EXEC mode						
Command History	<table border="1"> <thead> <tr> <th>Release</th><th>Modification</th></tr> </thead> <tbody> <tr> <td>4.0(0)N1(1a)</td><td>This command was introduced.</td></tr> <tr> <td>4.2(1)N1(1)</td><td>The command syntax is changed to show mac address-table.</td></tr> </tbody> </table>	Release	Modification	4.0(0)N1(1a)	This command was introduced.	4.2(1)N1(1)	The command syntax is changed to show mac address-table .
Release	Modification						
4.0(0)N1(1a)	This command was introduced.						
4.2(1)N1(1)	The command syntax is changed to show mac address-table .						
Usage Guidelines	The switch maintains static MAC address entries that are saved in its startup configuration across reboots and flushes the dynamic entries.						
Examples	<p>This example shows how to display information about the entries for the MAC address table:</p> <pre>switch# show mac address-table Legend: * - primary entry, G - Gateway MAC, (R) - Routed MAC, O - Overlay MAC age - seconds since last seen,+ - primary entry using vPC Peer-Link VLAN MAC Address Type age Secure NTFY Ports -----+-----+-----+-----+-----+-----+ </pre>						

■ **show mac address-table**

Send comments to nx5000-docfeedback@cisco.com

```
+ 100      0000.0001.0003    dynamic   0        F     F  Po1
+ 100      0000.0001.0004    dynamic   0        F     F  Po1
+ 100      0000.0001.0009    dynamic   0        F     F  Po1
+ 100      0000.0001.0010    dynamic   0        F     F  Po1
* 1       001d.7172.6c40    dynamic   300     F     F  Eth100/1/20
switch#
```

This example shows how to display information about the entries for the MAC address table for a specific MAC address:

```
switch# show mac address-table address 0018.bad8.3fb0
```

This example shows how to display information about the dynamic entries for the MAC address table:

```
switch# show mac address-table dynamic
```

Legend:

```
* - primary entry, G - Gateway MAC, (R) - Routed MAC, O - Overlay MAC
age - seconds since last seen,+ - primary entry using vPC Peer-Link
```

VLAN	MAC Address	Type	age	Secure	NTFY	Ports
+ 100	0000.0001.0003	dynamic	0	F	F	Po1
+ 100	0000.0001.0004	dynamic	0	F	F	Po1
+ 100	0000.0001.0009	dynamic	0	F	F	Po1
+ 100	0000.0001.0010	dynamic	0	F	F	Po1
* 1	001d.7172.6c40	dynamic	300	F	F	Eth100/1/20

switch#

This example shows how to display information about the MAC address table for a specific interface:

```
switch# show mac address-table interface ethernet 1/3
```

This example shows how to display static entries in the MAC address table:

```
switch# show mac address-table static
```

This example shows how to display entries in the MAC address table for a specific VLAN:

```
switch# show mac address-table vlan 1
```

Legend:

```
* - primary entry, G - Gateway MAC, (R) - Routed MAC, O - Overlay MAC
age - seconds since last seen,+ - primary entry using vPC Peer-Link
```

VLAN	MAC Address	Type	age	Secure	NTFY	Ports
* 1	001d.7172.6c40	dynamic	60	F	F	Eth100/1/20

switch#

Related Commands

Command	Description
mac address-table static	Adds static entries to the MAC address table or configures a static MAC address with IGMP snooping disabled for that address.
show mac address-table aging-time	Displays information about the time-out values for the MAC address table.
show mac address-table count	Displays the number of entries currently in the MAC address table.
show mac address-table notifications	Displays information about notifications for the MAC address table.

Send comments to nx5000-docfeedback@cisco.com

show monitor session

To display information about the Switched Port Analyzer (SPAN) sessions, use the **show monitor session** command.

show monitor session [session | all [brief] | range range [brief] | status]

Syntax Description	<i>session</i> (Optional) Number of the session. The range is from 1 to 18. all (Optional) Displays all sessions. brief (Optional) Displays a brief summary of the information. range range (Optional) Displays a range of sessions. The range is from 1 to 18. status (Optional) Displays the operational state of all sessions.
--------------------	---

Command Default	None
Command Modes	EXEC mode

Command History	Release	Modification
	4.0(0)N1(1a)	This command was introduced.

Examples This example shows how to display information about SPAN session 1:

```
switch# show monitor session 1
```

This example shows how to display a range of SPAN sessions:

```
switch# show monitor session range 1-4
```

Related Commands	Command	Description
	monitor session	Displays the contents of the startup configuration file.

■ **show port-channel capacity**

Send comments to nx5000-docfeedback@cisco.com

show port-channel capacity

To display the total number of EtherChannel interfaces and the number of free or used EtherChannel interfaces, use the **show port-channel capacity** command.

show port-channel capacity

Syntax Description This command has no arguments or keywords.

Command Default None

Command Modes EXEC mode

Command History	Release	Modification
	4.0(0)N1(1a)	This command was introduced.

Examples This example shows how to display the EtherChannel capacity:

```
switch# show port-channel capacity
Port-channel resources
    768 total      29 used      739 free      3% used
switch#
```

Related Commands	Command	Description
	port-channel	Configures the load-balancing algorithm for EtherChannels.
	load-balance ethernet	
	show tech-support	Displays Cisco Technical Support information about EtherChannels.
	port-channel	

Send comments to nx5000-docfeedback@cisco.com

show port-channel compatibility-parameters

To display the parameters that must be the same among the member ports in order to join an EtherChannel interface, use the **show port-channel compatibility-parameters** command.

show port-channel compatibility-parameters

Syntax Description This command has no arguments or keywords.

Command Default None

Command Modes EXEC mode

Command History	Release	Modification
	4.0(0)N1(1a)	This command was introduced.

Examples This example shows how to display the EtherChannel interface parameters:

```
switch# show port-channel compatibility-parameters
* port mode
```

Members must have the same port mode configured.

```
* port mode
```

Members must have the same port mode configured, either E,F or AUTO. If they are configured in AUTO port mode, they have to negotiate E or F mode when they come up. If a member negotiates a different mode, it will be suspended.

```
* speed
```

Members must have the same speed configured. If they are configured in AUTO speed, they have to negotiate the same speed when they come up. If a member negotiates a different speed, it will be suspended.

```
* MTU
```

Members have to have the same MTU configured. This only applies to ethernet port-channel.

```
* shut lan
```

Members have to have the same shut lan configured. This only applies to ethernet port-channel.

```
* MEDIUM
```

Members have to have the same medium type configured. This only applies to ethernet port-channel.

■ show port-channel compatibility-parameters

Send comments to nx5000-docfeedback@cisco.com

* Span mode

Members must have the same span mode.

* load interval

Member must have same load interval configured.

--More--

<---output truncated--->
switch#

Related Commands

Command	Description
port-channel	Configures the load-balancing algorithm for EtherChannels.
load-balance ethernet	
show tech-support	Displays Cisco Technical Support information about EtherChannels.
port-channel	

Send comments to nx5000-docfeedback@cisco.com

show port-channel database

To display the aggregation state for one or more EtherChannel interfaces, use the **show port-channel database** command.

show port-channel database [interface port-channel number[.subinterface-number]]

Syntax Description	interface (Optional) Displays information for an EtherChannel interface. port-channel number (Optional) Displays aggregation information for a specific EtherChannel interface. The <i>number</i> range is from 1 to 4096. .subinterface-number (Optional) Subinterface number. Use the EtherChannel number followed by a dot (.) indicator and the subinterface number. The format is <i>portchannel-number.subinterface-number</i> .
---------------------------	---

Command Default	None
------------------------	------

Command Modes	EXEC mode
----------------------	-----------

Command History	Release	Modification
	4.0(0)N1(1a)	This command was introduced.

Examples	This example shows how to display the aggregation state of all EtherChannel interfaces:
-----------------	---

```

switch# show port-channel database
port-channel19
    Last membership update is successful
    4 ports in total, 4 ports up
    First operational port is Ethernet199/1/24
    Age of the port-channel is 0d:09h:11m:30s
    Time since last bundle is 0d:09h:12m:20s
    Last bundled member is
        Ports:   Ethernet199/1/24  [active ] [up] *
                  Ethernet199/1/28  [active ] [up]
                  Ethernet199/1/30  [active ] [up]
                  Ethernet199/1/31  [active ] [up]

port-channel21
    Last membership update is successful
    1 ports in total, 1 ports up
    First operational port is Ethernet2/3
    Age of the port-channel is 0d:09h:11m:30s
    Time since last bundle is 0d:09h:12m:20s
    Last bundled member is
        Ports:   Ethernet2/3      [on]  [up] *

port-channel50
    Last membership update is successful
--More--
<---output truncated--->

```

■ show port-channel database

Send comments to nx5000-docfeedback@cisco.com

```
switch#
```

This example shows how to display the aggregation state for a specific EtherChannel interface:

```
switch# show port-channel database interface port-channel 21
port-channel21
    Last membership update is successful
    1 ports in total, 1 ports up
    First operational port is Ethernet2/3
    Age of the port-channel is 0d:09h:13m:14s
    Time since last bundle is 0d:09h:14m:04s
    Last bundled member is
    Ports:   Ethernet2/3      [on] [up] *
```

```
switch#
```

Related Commands

Command	Description
port-channel	Configures the load-balancing algorithm for EtherChannels.
load-balance ethernet	
show tech-support	Displays Cisco Technical Support information about EtherChannels.
port-channel	

Send comments to nx5000-docfeedback@cisco.com

show port-channel load-balance

To display information about EtherChannel load balancing, use the **show port-channel load-balance** command.

```
show port-channel load-balance [forwarding-path interface port-channel number { . | vlan
    vlan_ID } [dst-ip ipv4-addr] [dst-ipv6 ipv6-addr] [dst-mac dst-mac-addr] [l4-dst-port
    dst-port] [l4-src-port src-port] [src-ip ipv4-addr] [src-ipv6 ipv6-addr] [src-mac
    src-mac-addr]]
```

Syntax Description	
forwarding-path	(Optional) Identifies the port in the EtherChannel interface that forwards the packet.
interface	EtherChannel number for the load-balancing forwarding path that you want to display. The range is from 1 to 4096.
.	(Optional) Subinterface number separator. Use the EtherChannel number followed by a dot (.) indicator and the subinterface number. The format is <i>portchannel-number.subinterface-number</i> .
vlan	(Optional) Identifies the VLAN for hardware hashing.
vlan_ID	VLAN ID. The range is from 1 to 3967 and 4048 to 4093.
dst-ip	(Optional) Displays the load distribution on the destination IP address.
ipv4-addr	IPv4 address to specify a source or destination IP address. The format is <i>A.B.C.D</i> .
dst-ipv6	(Optional) Displays the load distribution on the destination IPv6 address.
ipv6-addr	IPv6 address to specify a source or destination IP address. The format is <i>A:B::C:D</i> .
dst-mac	(Optional) Displays the load distribution on the destination MAC address.
dst-mac-addr	Destination MAC address. The format is <i>AAAA:BBBB:CCCC</i> .
l4-dst-port	(Optional) Displays the load distribution on the destination port.
dst-port	Destination port number. The range is from 0 to 65535.
l4-src-port	(Optional) Displays the load distribution on the source port.
src-port	Source port number. The range is from 0 to 65535.
src-ip	(Optional) Displays the load distribution on the source IP address.
src-ipv6	(Optional) Displays the load distribution on the source IPv6 address.
src-mac	(Optional) Displays the load distribution on the source MAC address.
src-mac-addr	source MAC address. The format is <i>AA:BB:CC:DD:EE:FF</i> .
Command Default	None
Command Modes	EXEC mode

 show port-channel load-balance

Send comments to nx5000-docfeedback@cisco.com

Command History	Release	Modification
	4.0(0)N1(1a)	This command was introduced.
	4.2(1)N1(1)	The vlan keyword was added.

Usage Guidelines

You must use the **vlan** keyword to determine the use of hardware hashing.

When you do not use hardware hashing, the output displays all parameters used to determine the outgoing port ID. Missing parameters are shown as zero values in the output.

If you do not use hardware hashing, the outgoing port ID is determined by using control-plane selection. Hardware hashing is not used in the following scenarios:

- The specified VLAN contains an unknown unicast destination MAC address.
- The specified VLAN contains a known or an unknown multicast destination MAC or destination IP address.
- The specified VLAN contains a broadcast MAC address.
- The EtherChannel has only one active member.
- The destination MAC address is unknown when the load distribution is configured on the source IP address (src-ip), source port (l4-src-port), or source MAC address (src-mac).
- If multichassis EtherChannel trunk (MCT) is enabled and the traffic flows from a virtual port channel (vPC) peer link, the output displays “Outgoing port id (vPC peer-link traffic)”.

To get accurate results, you must do the following:

- (For unicast frames) Provide the destination MAC address (dst-mac) and the VLAN for hardware hashing (vlan). When the destination MAC address is not provided, hardware hashing is assumed.
- (For multicast frames) For IP multicast, provide either the destination IP address (dst-ip) or destination MAC address (dst-mac) with the VLAN for hardware hashing (vlan). For non-ip multicast, provide the destination MAC address with the VLAN for hardware hashing.
- (For broadcast frames) Provide the destination MAC address (dst-mac) and the VLAN for hardware hashing (vlan).

Examples

This example shows how to display the port channel load balance information:

```
switch# show port-channel load-balance
Port Channel Load-Balancing Configuration:
System: source-dest-ip

Port Channel Load-Balancing Addresses Used Per-Protocol:
Non-IP: source-dest-mac
IP: source-dest-ip source-dest-mac

switch#
```

Table 3-1 describes the fields shown in the display:

Send comments to nx5000-docfeedback@cisco.com

Table 3-1 show port-channel load-balance Field Descriptions

Field	Description
System	The load-balancing method configured on the switch.
Non-IP	The field that will be used to calculate the hash value for non-IP traffic.
IP	The fields used for IPv4 and IPv6 traffic.

This example shows how to display the port channel load balance information when hardware hashing is not used:

```
switch# show port-channel load-balance forwarding-path interface port-channel 5 vlan 3
dst-ip 192.168.2.37
Missing params will be substituted by 0's.
Load-balance Algorithm on FEX: source-dest-ip
crc8_hash: Not Used      Outgoing port id: Ethernet133/1/3
Param(s) used to calculate load-balance (Unknown unicast, multicast and broadcast packets):
    dst-mac: 0000.0000.0000
    vlan id: 3
switch#
```

This example shows how to display the port channel load balance information when hardware hashing is not used to determine the outgoing port ID:

```
switch# show port-channel load-balance forwarding-path interface port-channel 10 vlan 1
dst-ip 192.168.2.25 src-ip 192.168.2.10 dst-mac ffff.ffff.ffff src-mac aa:bb:cc:dd:ee:ff
14-src-port 0 14-dst-port 1
Missing params will be substituted by 0's.
Load-balance Algorithm on switch: source-dest-port
crc8_hash: Not Used      Outgoing port id: Ethernet1/1
Param(s) used to calculate load-balance (Unknown unicast, multicast and broadcast packets):
    dst-mac: ffff.ffff.ffff
    vlan id: 1
switch#
```

This example shows how to display the port channel load balance information when MCT is enabled and traffic flows from a vPC peer link:

```
switch# show port-channel load-balance forwarding-path interface port-channel 10 vlan 1
dst-ip 192.168.2.25 src-ip 192.168.2.10 dst-mac ffff.ffff.ffff src-mac aa:bb:cc:dd:ee:ff
14-src-port 0 14-dst-port 1
Missing params will be substituted by 0's.
Load-balance Algorithm on switch: source-dest-port
crc8_hash: Not Used      Outgoing port id (non vPC peer-link traffic): ethernet1/2
crc8_hash: Not Used      Outgoing port id (vPC peer-link traffic): Ethernet1/1
Param(s) used to calculate load-balance (Unknown unicast, multicast and broadcast packets):
    dst-mac: ffff.ffff.ffff
    vlan id: 1
switch#
```

This example shows how to display the port channel load balance information when hardware hashing is used to determine the outgoing port ID:

■ show port-channel load-balance

Send comments to nx5000-docfeedback@cisco.com

```
switch# show port-channel load-balance forwarding-path interface port-channel 10 vlan 1
dst-ip 192.168.2.25 src-ip 192.168.2.10 src-mac aa:bb:cc:dd:ee:ff 14-src-port 0
14-dst-port 1
Missing params will be substituted by 0's.
Load-balance Algorithm on switch: source-dest-port
crc8_hash: 204 Outgoing port id: Ethernet1/1
Param(s) used to calculate load-balance:
    dst-port: 1
    src-port: 0
    dst-ip: 192.168.2.25
    src-ip: 192.168.2.10
    dst-mac: 0000.0000.0000
    src-mac: aabb.ccdd.eeff

switch#
```

Related Commands

Command	Description
port-channel	Configures the load-balancing method among the interfaces in the channel-group bundle.
load-balance ethernet	

Send comments to nx5000-docfeedback@cisco.com

show port-channel summary

To display summary information about EtherChannels, use the **show port-channel summary** command.

show port-channel summary

Syntax Description This command has no arguments or keywords.

Command Default None

Command Modes Global configuration mode
EXEC mode

Command History	Release	Modification
	4.0(0)N1(1a)	This command was introduced.

Usage Guidelines Before you use this command, you must configure an EtherChannel group using the **interface port-channel** command.

Examples This example shows how to display summary information about EtherChannels:

```
switch# show port-channel summary
Flags:  D - Down          P - Up in port-channel (members)
       I - Individual      H - Hot-standby (LACP only)
       S - Suspended        R - Module-removed
       S - Switched         R - Routed
       U - Up (port-channel)

-----
```

Group	Port-Channel	Type	Protocol	Member Ports
1	Po1 (SU)	Eth	LACP	Eth1/1(P) Eth1/2(P) Eth1/3(P) Eth1/4(P) Eth1/21(P) Eth1/22(P) Eth1/23(P) Eth1/24(P) Eth1/25(P) Eth1/26(P) Eth1/27(P) Eth1/28(P) Eth1/29(P) Eth1/30(P) Eth1/31(P) Eth1/32(P)
3	Po3 (SU)	Eth	NONE	Eth1/9(P) Eth1/10(P) Eth1/13(P) Eth1/14(P) Eth1/40(P)
5	Po5 (SU)	Eth	NONE	Eth3/5(P) Eth3/6(P)
6	Po6 (SU)	Eth	NONE	Eth1/5(P) Eth1/6(P) Eth1/7(P) Eth1/8(P)
12	Po12 (SU)	Eth	NONE	Eth3/3(P) Eth3/4(P)
15	Po15 (SD)	Eth	NONE	--
20	Po20 (SU)	Eth	NONE	Eth1/17(P) Eth1/18(P) Eth1/19(D) Eth1/20(P)
24	Po24 (SU)	Eth	LACP	Eth105/1/27(P) Eth105/1/28(P) Eth105/1/29

■ show port-channel summary

Send comments to nx5000-docfeedback@cisco.com

```

(P)                                         Eth105/1/30 (P)   Eth105/1/31 (P)   Eth105/1/32
25   Po25 (SU)      Eth       LACP      Eth105/1/23 (P)   Eth105/1/24 (P)   Eth105/1/25
(P)                                         Eth105/1/26 (P)
33   Po33 (SD)      Eth       NONE     --
41   Po41 (SD)      Eth       NONE     --
44   Po44 (SD)      Eth       NONE     --
48   Po48 (SD)      Eth       NONE     --
100  Po100 (SD)     Eth       NONE     --
101  Po101 (SD)     Eth       NONE     --
102  Po102 (SU)     Eth       LACP     Eth102/1/2 (P)
103  Po103 (SU)     Eth       LACP     Eth102/1/3 (P)
104  Po104 (SU)     Eth       LACP     Eth102/1/4 (P)
105  Po105 (SU)     Eth       LACP     Eth102/1/5 (P)
106  Po106 (SU)     Eth       LACP     Eth102/1/6 (P)
107  Po107 (SU)     Eth       LACP     Eth102/1/7 (P)
108  Po108 (SU)     Eth       LACP     Eth102/1/8 (P)
109  Po109 (SU)     Eth       LACP     Eth102/1/9 (P)
110  Po110 (SU)     Eth       LACP     Eth102/1/10 (P)
111  Po111 (SU)     Eth       LACP     Eth102/1/11 (P)
<---output truncated--->
switch#

```

Related Commands

Command	Description
channel-group (Ethernet)	Assigns and configures a physical interface to an EtherChannel.
interface port-channel	Creates an EtherChannel interface and enters interface configuration mode.

Send comments to nx5000-docfeedback@cisco.com

show port-channel traffic

To display the traffic statistics for EtherChannels, use the **show port-channel traffic** command.

show port-channel traffic [interface port-channel number[.subinterface-number]]

Syntax Description	interface (Optional) Displays traffic statistics for a specified interface. port-channel number (Optional) Displays information for a specified EtherChannel. The range is from 1 to 4096. .subinterface-number (Optional) Subinterface number. Use the EtherChannel number followed by a dot (.) indicator and the subinterface number. The format is <i>portchannel-number.subinterface-number</i> .
---------------------------	---

Command Default	None
------------------------	------

Command Modes	EXEC mode
----------------------	-----------

Command History	Release	Modification
	4.0(0)N1(1a)	This command was introduced.

Examples This example shows how to display the traffic statistics for all EtherChannels:

```
switch# show port-channel traffic
ChanId      Port Rx-Ucst Tx-Ucst Rx-Mcst Tx-Mcst Rx-Bcst Tx-Bcst
----- -----
  10    Eth1/7    0.0%   0.0%   0.0%   0.0%   0.0%   0.0%   0.0%
  10    Eth1/8    0.0%   0.0%   0.0%   0.0%   0.0%   0.0%   0.0%
  10    Eth1/9    0.0%   0.0%   0.0%   0.0%   0.0%   0.0%   0.0%
  10    Eth1/10   0.0%   0.0%   0.0%   0.0%   0.0%   0.0%   0.0%
----- -----
 4000   Eth1/1    0.0%   0.0%  99.64%  99.81%   0.0%   0.0%
 4000   Eth1/2    0.0%   0.0%   0.06%   0.06%   0.0%   0.0%
 4000   Eth1/3    0.0%   0.0%   0.23%   0.06%   0.0%   0.0%
 4000   Eth1/4    0.0%   0.0%   0.06%   0.06%   0.0%   0.0%
switch#
```

This example shows how to display the traffic statistics for a specific EtherChannel:

```
switch# show port-channel traffic interface port-channel 10
ChanId      Port Rx-Ucst Tx-Ucst Rx-Mcst Tx-Mcst Rx-Bcst Tx-Bcst
----- -----
  10    Eth1/7    0.0%   0.0%   0.0%   0.0%   0.0%   0.0%   0.0%
  10    Eth1/8    0.0%   0.0%   0.0%   0.0%   0.0%   0.0%   0.0%
  10    Eth1/9    0.0%   0.0%   0.0%   0.0%   0.0%   0.0%   0.0%
  10    Eth1/10   0.0%   0.0%   0.0%   0.0%   0.0%   0.0%   0.0%
switch#
```

■ show port-channel traffic

Send comments to nx5000-docfeedback@cisco.com

Related Commands	Command	Description
	port-channel load-balance ethernet	Configures the load-balancing algorithm for EtherChannels.
	show tech-support port-channel	Displays Cisco Technical Support information about EtherChannels.

Send comments to nx5000-docfeedback@cisco.com

show port-channel usage

To display the range of used and unused EtherChannel numbers, use the **show port-channel usage** command.

show port-channel usage

Syntax Description This command has no arguments or keywords.

Command Default None

Command Modes EXEC mode

Command History	Release	Modification
	4.0(0)N1(1a)	This command was introduced.

Examples This example shows how to display the EtherChannel usage information:

```
switch# show port-channel usage
Total 29 port-channel numbers used
=====
Used : 19 , 21 , 50 , 100 , 150 , 170 - 171 , 198 - 199 , 256
       301 , 400 - 401 , 1032 - 1033 , 1111 , 1504 , 1511 , 1514 , 1516 - 1520
       1532 , 1548 , 1723 , 1905 , 1912
Unused: 1 - 18 , 20 , 22 - 49 , 51 - 99 , 101 - 149 , 151 - 169
        172 - 197 , 200 - 255 , 257 - 300 , 302 - 399 , 402 - 1031
        1034 - 1110 , 1112 - 1503 , 1505 - 1510 , 1512 - 1513 , 1515 , 1521 - 1531
        1533 - 1547 , 1549 - 1722 , 1724 - 1904 , 1906 - 1911 , 1913 - 4096
(some numbers may be in use by SAN port channels)

switch#
```

Related Commands	Command	Description
	port-channel	Configures the load-balancing algorithm for EtherChannels.
	load-balance ethernet	
	show tech-support port-channel	Displays Cisco Technical Support information about EtherChannels.

show resource

Send comments to nx5000-docfeedback@cisco.com

show resource

To display the number of resources currently available in the system, use the **show resource** command.

show resource [resource]

Syntax Description	<i>resource</i>	Resource name, which can be one of the following:
		<ul style="list-style-type: none"> • port-channel—Displays the number of EtherChannels available in the system. • vlan—Displays the number of VLANs available in the system. • vrf—Displays the number of virtual routing and forwardings (VRFs) available in the system.

Command Default	None
------------------------	------

Command Modes	EXEC mode
----------------------	-----------

Command History	Release	Modification
	4.0(0)N1(1a)	This command was introduced.

Examples	This example shows how to display the resources available in the system:
-----------------	--

```
switch# show resource

      Resource    Min     Max    Used   Unused   Avail
-----  -----  -----  -----  -----  -----
      vlan        16    4094    509      0       3
monitor-session      0        2      0      0       2
      vrf         2     1000      2      0     998
port-channel        0      768      2      0     766
u4route-mem        32       32      1     31      31
u6route-mem        16       16      1     15      15
m4route-mem        58       58      0     58      58
m6route-mem        8        8      0      8       8
bundle-map          0      16      2      0     14

switch#
```

Related Commands	Command	Description
	show interface port-channel	Displays information about EtherChannels.

Send comments to nx5000-docfeedback@cisco.com

show running-config

To display the contents of the currently running configuration file, use the **show running-config** command.

show running-config [all]

Syntax Description	all	(Optional) Displays the full operating information including default settings.
---------------------------	------------	--

Command Default	None
------------------------	------

Command Modes	EXEC mode
----------------------	-----------

Command History	Release	Modification
	4.0(0)N1(1a)	This command was introduced.

Examples	This example shows how to display information on the running configuration:
-----------------	---

```
switch# show running-config
```

This example shows how to display detailed information on the running configuration:
--

```
switch# show running-config all
```

Related Commands	Command	Description
	show startup-config	Displays the contents of the startup configuration file.

 show running-config spanning-tree

Send comments to nx5000-docfeedback@cisco.com

show running-config spanning-tree

To display the running configuration for the Spanning Tree Protocol (STP), use the **show running-config spanning-tree** command.

show running-config spanning-tree [all]

Syntax Description	all	(Optional) Displays current STP operating information including default settings.
---------------------------	------------	---

Command Default	None
------------------------	------

Command Modes	EXEC mode
----------------------	-----------

Command History	Release	Modification
	4.0(0)N1(1a)	This command was introduced.

Examples	This example shows how to display information on the running STP configuration:
-----------------	---

```
switch# show running-config spanning-tree
```

This example shows how to display detailed information on the running STP configuration:

```
switch# show running-config spanning-tree all
```



Note Display output differs slightly depending on whether you are running Rapid Per VLAN Spanning Tree Plus (Rapid PVST+) or Multiple Spanning Tree (MST).

Related Commands	Command	Description
	show spanning-tree	Displays information about STP.

Send comments to nx5000-docfeedback@cisco.com

show running-config vlan

To display the running configuration for a specified VLAN, use the **show running-config vlan** command.

show running-config vlan *vlan-id*

Syntax Description	<i>vlan-id</i>	Number of VLAN or range of VLANs. Valid numbers are from 1 to 4096.
Command Default	None	
Command Modes	EXEC mode	
Command History	Release	Modification
	4.0(0)N1(1a)	This command was introduced.
Usage Guidelines	This command provides information on the specified VLAN, including private VLANs. The display varies with your configuration. If you have configured the VLAN name, shutdown status, or suspended status, these are also displayed.	
Examples	This example shows how to display the running configuration for VLAN 5: <pre>switch# show running-config vlan 5</pre>	
Related Commands	Command	Description
	show vlan	Displays information about all the VLANs on the switch.

■ show spanning-tree

Send comments to nx5000-docfeedback@cisco.com

show spanning-tree

To display information about the Spanning Tree Protocol (STP), use the **show spanning-tree** command.

show spanning-tree [blockedports | inconsistentports | pathcost method]

Syntax Description	
blockedports	(Optional) Displays the alternate ports blocked by STP.
inconsistentports	(Optional) Displays the ports that are in an inconsistent STP state.
pathcost method	(Optional) Displays whether short or long path cost method is used. The method differs for Rapid Per VLAN Spanning Tree Plus (Rapid PVST+) (configurable, default is short) and Multiple Spanning Tree (MST) (nonconfigurable, operational value is always long).

Command Default	None
------------------------	------

Command Modes	EXEC mode
----------------------	-----------

Command History	Release	Modification
	4.0(0)N1(1a)	This command was introduced.

Usage Guidelines The STP port type displays only when you have configured the port as either an STP edge port or an STP network port. If you have not configured the STP port type, no port type displays.

Table 3-2 describes the fields that are displayed in the output of **show spanning-tree** commands.

Table 3-2 show spanning-tree Command Output Fields

Field	Definition
Role	Current port STP role. Valid values are as follows: <ul style="list-style-type: none"> • Desg (designated) • Root • Altn (alternate) • Back (backup)

Send comments to nx5000-docfeedback@cisco.com

Table 3-2 show spanning-tree Command Output Fields (continued)

Field	Definition
Sts	Current port STP state. Valid values are as follows: <ul style="list-style-type: none"> • BLK (blocking) • DIS (disabled) • LRN (learning) • FWD (forwarding)
Type	Status information. Valid values are as follows: <ul style="list-style-type: none"> • P2p/Shr—The interface is considered as a point-to-point (shared) interface by the spanning tree. • Edge—The port is configured as an STP edge port (either globally using the default command or directly on the interface) and no BPDU has been received. • Network—The port is configured as an STP network port (either globally using the default command or directly on the interface). • *ROOT_Inc, *LOOP_Inc, *PVID_Inc, *BA_Inc, and *TYPE_Inc—The port is in a broken state (BKN*) for an inconsistency. The broken states are Root inconsistent, Loopguard inconsistent, PVID inconsistent, Bridge Assurance inconsistent, or Type inconsistent.



Note Display output differs slightly depending on whether you are running Rapid Per VLAN Spanning Tree Plus (Rapid PVST+) or Multiple Spanning Tree (MST).

Examples

This example shows how to display spanning tree information:

```
switch# show spanning-tree

VLAN0001
  Spanning tree enabled protocol rstp
    Root ID  Priority      1
              Address      000d.ecb0.fdbc
              Cost          2
              Port          4096 (port-channel1)
              Hello Time   2 sec  Max Age 20 sec  Forward Delay 15 sec

    Bridge ID Priority      61441 (priority 61440 sys-id-ext 1)
              Address      0005.9b78.6e7c
              Hello Time   2 sec  Max Age 20 sec  Forward Delay 15 sec

  Interface      Role Sts Cost      Prio.Nbr Type
  -----          --- -- --      --.--
  Po1            Root FWD 1      128.4096 (vPC peer-link) Network P2p
  Po3            Root FWD 1      128.4098 (vPC) P2p
  Po123          Desg FWD 4      128.4218 Edge P2p
  Eth1/11        Desg BKN*2     128.139  P2p *TYPE_Inc
  Eth1/12        Desg BKN*2     128.140  P2p *TYPE_Inc
  Eth1/15        Desg BKN*2     128.143  P2p *TYPE_Inc
  Eth1/16        Desg BKN*2     128.144  P2p *TYPE_Inc
  Eth1/33        Desg FWD 2      128.161  Edge P2p
  Eth1/35        Desg FWD 2      128.163  Edge P2p
```

■ show spanning-tree

Send comments to nx5000-docfeedback@cisco.com

```

Eth1/36      Desg FWD 2      128.164  Edge P2p
Eth1/38      Desg FWD 2      128.166  Edge P2p
Eth100/1/1   Desg FWD 1      128.1025 (vPC) Edge P2p
Eth100/1/2   Desg FWD 1      128.1026 (vPC) Edge P2p
Eth100/1/3   Desg FWD 1      128.1027 (vPC) Edge P2p
Eth100/1/4   Desg FWD 1      128.1028 (vPC) Edge P2p
--More--
switch#

```

This example shows how to display the blocked ports in spanning tree:

```

switch(config)# show spanning-tree blockedports

Name          Blocked Interfaces List
-----
VLAN0001      Eth1/11, Eth1/12, Eth1/15, Eth1/16

```

Number of blocked ports (segments) in the system : 4

switch#

This example shows how to determine if any ports are in any STP-inconsistent state:

```
switch# show spanning-tree inconsistentports
```

Name	Interface	Inconsistency
VLAN0001	Eth1/11	Port Type Inconsistent
VLAN0001	Eth1/12	Port Type Inconsistent
VLAN0001	Eth1/15	Port Type Inconsistent
VLAN0001	Eth1/16	Port Type Inconsistent

Number of inconsistent ports (segments) in the system : 4

switch#

This example shows how to display the path cost method:

```

switch(config)# show spanning-tree pathcost method
Spanning tree default pathcost method used is short
switch#

```

Related Commands

Command	Description
show spanning-tree active	Displays information about STP active interfaces only.
show spanning-tree bridge	Displays the bridge ID, timers, and protocol for the local bridge on the switch.
show spanning-tree brief	Displays a brief summary about STP.
show spanning-tree detail	Displays detailed information about STP.
show spanning-tree interface	Displays the STP interface status and configuration of specified interfaces.
show spanning-tree mst	Displays information about Multiple Spanning Tree (MST) STP.

Send comments to nx5000-docfeedback@cisco.com

Command	Description
show spanning-tree root	Displays the status and configuration of the root bridge for the STP instance to which this switch belongs.
show spanning-tree summary	Displays summary information about STP.
show spanning-tree vlan	Displays STP information for specified VLANs.

■ show spanning-tree active

Send comments to nx5000-docfeedback@cisco.com

show spanning-tree active

To display Spanning Tree Protocol (STP) information on STP-active interfaces only, use the **show spanning-tree active** command.

show spanning-tree active [brief | detail]

Syntax Description	brief (Optional) Displays a brief summary of STP interface information. detail (Optional) Displays a detailed summary of STP interface information.
---------------------------	--

Command Default	None
------------------------	------

Command Modes	EXEC mode
----------------------	-----------

Command History	Release	Modification
	4.0(0)N1(1a)	This command was introduced.

Examples	This example shows how to display STP information on the STP-active interfaces:
-----------------	---

```
switch# show spanning-tree active
```

Related Commands	Command	Description
	show spanning-tree	Displays information about STP.
	show spanning-tree bridge	Displays the bridge ID, timers, and protocol for the local bridge on the switch.
	show spanning-tree brief	Displays a brief summary about STP.
	show spanning-tree detail	Displays detailed information about STP.
	show spanning-tree interface	Displays the STP interface status and configuration of specified interfaces.
	show spanning-tree mst	Displays information about Multiple Spanning Tree (MST) STP.
	show spanning-tree root	Displays the status and configuration of the root bridge for the STP instance to which this switch belongs.
	show spanning-tree summary	Displays summary information about STP.
	show spanning-tree vlan	Displays STP information for specified VLANs.

Send comments to nx5000-docfeedback@cisco.com

show spanning-tree bridge

To display the status and configuration of the local Spanning Tree Protocol (STP) bridge, use the **show spanning-tree bridge** command.

```
show spanning-tree bridge [address | brief | detail | forward-time | hello-time | id | max-age |
priority [system-id] | protocol]
```

Syntax Description	address brief detail forward-time hello-time id max-age priority system-id protocol	(Optional) Displays the MAC address for the STP local bridge. (Optional) Displays a brief summary of the status and configuration for the STP bridge. (Optional) Displays a detailed summary of the status and configuration for the STP bridge. (Optional) Displays the STP forward delay interval for the bridge. (Optional) Displays the STP hello time for the bridge. (Optional) Displays the STP bridge identifier for the bridge. (Optional) Displays the STP maximum-aging time for the bridge. (Optional) Displays the bridge priority for this bridge. (Optional) Displays the bridge priority with the system ID extension for this bridge. (Optional) Displays whether the Rapid Per VLAN Spanning Tree Plus (Rapid PVST+) or Multiple Spanning Tree (MST) protocol is active.
Command Default	None	
Command Modes	EXEC mode	
Command History	Release 4.0(0)N1(1a)	Modification This command was introduced.
Examples	This example shows how to display STP information for the bridge: <pre>switch# show spanning-tree bridge</pre>	
Related Commands	Command show spanning-tree show spanning-tree active	Description Displays information about STP. Displays information about STP active interfaces only.

■ show spanning-tree bridge

Send comments to nx5000-docfeedback@cisco.com

Command	Description
show spanning-tree brief	Displays a brief summary about STP.
show spanning-tree detail	Displays detailed information about STP.
show spanning-tree interface	Displays the STP interface status and configuration of specified interfaces.
show spanning-tree mst	Displays information about Multiple Spanning Tree (MST) STP.
show spanning-tree root	Displays the status and configuration of the root bridge for the STP instance to which this switch belongs.
show spanning-tree summary	Displays summary information about STP.
show spanning-tree vlan	Displays STP information for specified VLANs.

Send comments to nx5000-docfeedback@cisco.com

show spanning-tree brief

To display a brief summary of the Spanning Tree Protocol (STP) status and configuration on the switch, use the **show spanning-tree brief** command.

show spanning-tree brief [active]

Syntax Description	active	(Optional) Displays information about STP active interfaces only.
---------------------------	---------------	---

Command Default	None
------------------------	------

Command Modes	EXEC mode
----------------------	-----------

Command History	Release	Modification
	4.0(0)N1(1a)	This command was introduced.

Examples	This example shows how to display a brief summary of STP information:
-----------------	---

```
switch(config)# show spanning-tree brief

VLAN0001
  Spanning tree enabled protocol rstp
    Root ID  Priority  32769
              Address   000d.ecb0.fc7c
              Cost      1
              Port      4495 (port-channel1400)
              Hello Time 2 sec  Max Age 20 sec  Forward Delay 15 sec

    Bridge ID Priority  32769 (priority 32768 sys-id-ext 1)
              Address   000d.ece7.df7c
              Hello Time 2 sec  Max Age 20 sec  Forward Delay 15 sec

    Interface      Role Sts Cost      Prio.Nbr Type
    -----  -----
    Po19          Desg FWD 1       128.4114 Edge P2p
    Po400         Root FWD 1     128.4495 (vPC peer-link) Network P2p
    Eth170/1/17   Desg FWD 2     128.3857 Edge P2p
    Eth171/1/7    Desg FWD 1     128.3975 (vPC) Edge P2p
    Eth171/1/8    Desg FWD 1     128.3976 (vPC) Edge P2p
    Eth198/1/11   Desg FWD 1     128.1291 (vPC) Edge P2p
    Eth199/1/13   Desg FWD 2     128.1677 Edge P2p

VLAN0300
  Spanning tree enabled protocol rstp
    Root ID  Priority  4396
    --More--
switch#
```

■ show spanning-tree brief

Send comments to nx5000-docfeedback@cisco.com

Related Commands	Command	Description
	show spanning-tree	Displays information about STP.
	show spanning-tree active	Displays information about STP active interfaces only.
	show spanning-tree bridge	Displays the bridge ID, timers, and protocol for the local bridge on the switch.
	show spanning-tree detail	Displays detailed information about STP.
	show spanning-tree interface	Displays the STP interface status and configuration of specified interfaces.
	show spanning-tree mst	Displays information about Multiple Spanning Tree (MST) STP.
	show spanning-tree root	Displays the status and configuration of the root bridge for the STP instance to which this switch belongs.
	show spanning-tree summary	Displays summary information about STP.
	show spanning-tree vlan	Displays STP information for specified VLANs.

Send comments to nx5000-docfeedback@cisco.com

show spanning-tree detail

To display detailed information on the Spanning Tree Protocol (STP) status and configuration on the switch, use the **show spanning-tree detail** command.

show spanning-tree detail [active]

Syntax Description	active (Optional) Displays information about STP active interfaces only.	
Command Default	None	
Command Modes	EXEC mode	
Command History	Release	Modification
	4.0(0)N1(1a)	This command was introduced.
Examples	This example shows how to display detailed information on the STP configuration: <pre>switch(config)# show spanning-tree detail</pre>	
Related Commands	Command	Description
	show spanning-tree	Displays information about STP.
	show spanning-tree active	Displays information about STP active interfaces only.
	show spanning-tree bridge	Displays the bridge ID, timers, and protocol for the local bridge on the switch.
	show spanning-tree brief	Displays a brief summary about STP.
	show spanning-tree interface	Displays the STP interface status and configuration of specified interfaces.
	show spanning-tree mst	Displays information about Multiple Spanning Tree (MST) STP.
	show spanning-tree root	Displays the status and configuration of the root bridge for the STP instance to which this switch belongs.
	show spanning-tree summary	Displays summary information about STP.
	show spanning-tree vlan	Displays STP information for specified VLANs.

■ show spanning-tree interface

Send comments to nx5000-docfeedback@cisco.com

show spanning-tree interface

To display information on the Spanning Tree Protocol (STP) interface status and configuration of specified interfaces, use the **show spanning-tree interface** command.

```
show spanning-tree interface {ethernet slot/port | port-channel number} [active [brief | detail]
| brief [active] | cost | detail [active] | edge | inconsistency | priority | rootcost | state]
```

Syntax Description	
interface	Specifies the interface. The interface can be Ethernet or EtherChannel.
ethernet slot/port	Specifies the Ethernet interface slot number and port number. The <i>slot</i> number is from 1 to 255, and the <i>port</i> number is from 1 to 128.
port-channel number	Specifies the EtherChannel interface and number. The EtherChannel number is from 1 to 4096.
active	(Optional) Displays information about STP active interfaces only on the specified interfaces.
brief	(Optional) Displays brief summary of STP information on the specified interfaces.
detail	(Optional) Displays detailed STP information about the specified interfaces.
cost	(Optional) Displays the STP path cost for the specified interfaces.
edge	(Optional) Displays the STP-type edge port information for the specified interfaces.
inconsistency	(Optional) Displays the port STP inconsistency state for the specified interfaces.
priority	(Optional) Displays the STP port priority for the specified interfaces.
rootcost	(Optional) Displays the path cost to the root for specified interfaces.
state	(Optional) Displays the current port STP state.

Command Default	None
------------------------	------

Command Modes	EXEC mode
----------------------	-----------

Command History	Release	Modification
	4.0(0)N1(1a)	This command was introduced.

Usage Guidelines	The STP port type displays only when you have configured the port as either an STP edge port or an STP network port. If you have not configured the STP port type, no port type displays. If you specify an interface that is not running STP, the switch returns an error message. When you are running Multiple Spanning Tree (MST), this command displays the Per VLAN Spanning Tree (PVST) simulation setting.
-------------------------	--

Send comments to nx5000-docfeedback@cisco.com

**Note**

If you are running Multiple Spanning Tree (MST), use the **show spanning-tree mst** command to show more detail on the specified interfaces.

Examples

This example shows how to display STP information on a specified interface:

```
switch(config)# show spanning-tree interface ethernet 1/3
```

This example shows how to display detailed STP information on a specified interface:

```
switch(config)# show spanning-tree interface ethernet 1/3 detail
```

Related Commands

Command	Description
show spanning-tree	Displays information about STP.
show spanning-tree active	Displays information about STP active interfaces only.
show spanning-tree bridge	Displays the bridge ID, timers, and protocol for the local bridge on the switch.
show spanning-tree brief	Displays a brief summary about STP.
show spanning-tree detail	Displays detailed information about STP.
show spanning-tree mst	Displays information about Multiple Spanning Tree (MST) STP.
show spanning-tree root	Displays the status and configuration of the root bridge for the STP instance to which this switch belongs.
show spanning-tree summary	Displays summary information about STP.
show spanning-tree vlan	Displays STP information for specified VLANs.

■ show spanning-tree mst

Send comments to nx5000-docfeedback@cisco.com

show spanning-tree mst

To display information on Multiple Spanning Tree (MST) status and configuration, use the **show spanning-tree mst** command.

show spanning-tree mst [instance-id [detail | interface {ethernet slot/port | port-channel number} [detail]]]

show spanning-tree mst [configuration [digest]]

show spanning-tree mst [detail | interface {ethernet slot/port | port-channel number} [detail]]

Syntax Description	
<i>instance-id</i>	(Optional) Multiple Spanning Tree (MST) instance range that you want to display. For example, 0 to 3, 5, 7 to 9.
detail	(Optional) Displays detailed Multiple Spanning Tree (MST) information.
interface	(Optional) Specifies the interface. The interface can be Ethernet or EtherChannel.
ethernet slot/port	(Optional) Specifies the Ethernet interface and its slot number and port number. The <i>slot</i> number is from 1 to 255, and the <i>port</i> number is from 1 to 128.
port-channel number	(Optional) Specifies the EtherChannel interface and number. The EtherChannel number is from 1 to 4096.
configuration	(Optional) Displays current Multiple Spanning Tree (MST) regional information including the VLAN-to-instance mapping of all VLANs.
digest	(Optional) Displays information about the MD5 digest.

Command Default None

Command Modes EXEC mode

Command History	Release	Modification
	4.0(0)N1(1a)	This command was introduced.

Usage Guidelines If the switch is not running in STP Multiple Spanning Tree (MST) mode when you enter this command, it returns the following message:

ERROR: Switch is not in mst mode

Examples This example shows how to display STP information about Multiple Spanning Tree (MST) instance information for the VLAN ports that are currently active:

```
switch# show spanning-tree mst
```

Send comments to nx5000-docfeedback@cisco.com

This example shows how to display STP information about a specific Multiple Spanning Tree (MST) instance:

```
switch) # show spanning-tree mst 0
```

This example shows how to display detailed STP information about the Multiple Spanning Tree (MST) protocol:

```
switch) # show spanning-tree mst detail
```

This example shows how to display STP information about specified Multiple Spanning Tree (MST) interfaces:

```
switch) # show spanning-tree mst interface ethernet 8/2
```

This example shows how to display information about the Multiple Spanning Tree (MST) configuration:

```
switch) # show spanning-tree mst configuration
```

This example shows how to display the MD5 digest included in the current Multiple Spanning Tree (MST) configuration:

```
switch) # show spanning-tree mst configuration digest
```

See [Table 3-2 on page 3-52](#) for descriptions of the fields that are displayed in the output of the **show spanning-tree** commands.

Related Commands	Command	Description
	show spanning-tree	Displays information about STP.
	show spanning-tree active	Displays information about STP active interfaces only.
	show spanning-tree bridge	Displays the bridge ID, timers, and protocol for the local bridge on the switch.
	show spanning-tree brief	Displays a brief summary about STP.
	show spanning-tree detail	Displays detailed information about STP.
	show spanning-tree interface	Displays the STP interface status and configuration of specified interfaces.
	show spanning-tree root	Displays the status and configuration of the root bridge for the STP instance to which this switch belongs.
	show spanning-tree summary	Displays summary information about STP.
	show spanning-tree vlan	Displays STP information for specified VLANs.

■ show spanning-tree root

Send comments to nx5000-docfeedback@cisco.com

show spanning-tree root

To display the status and configuration of the Spanning Tree Protocol (STP) root bridge, use the **show spanning-tree root** command.

```
show spanning-tree root [address | brief | cost | detail | forward-time | hello-time | id | max-age | port | priority [system-id]]
```

Syntax Description	address brief cost detail forward-time hello-time id max-age port priority system-id	(Optional) Displays the MAC address for the STP root bridge. (Optional) Displays a brief summary of the status and configuration for the the root bridge. (Optional) Displays the path cost from the root to this bridge. (Optional) Displays detailed information on the status and configuration for the root bridge. (Optional) Displays the STP forward delay interval for the root bridge. (Optional) Displays the STP hello time for the root bridge. (Optional) Displays the STP bridge identifier for the root bridge. (Optional) Displays the STP maximum-aging time for the root bridge. (Optional) Displays which port is the root port. (Optional) Displays the bridge priority for the root bridge. (Optional) Displays the bridge identifier with the system ID extension for the root bridge.
Command Default	None	
Command Modes	EXEC mode	
Command History	Release 4.0(0)N1(1a)	Modification This command was introduced.
Examples	This example shows how to display information for the root bridge: <pre>switch(config)# show spanning-tree root</pre>	
Related Commands	Command show spanning-tree show spanning-tree active	Description Displays information about STP. Displays information about STP active interfaces only.

Send comments to nx5000-docfeedback@cisco.com

Command	Description
show spanning-tree bridge	Displays the bridge ID, timers, and protocol for the local bridge on the switch.
show spanning-tree brief	Displays a brief summary of STP information.
show spanning-tree detail	Displays detailed information about STP.
show spanning-tree interface	Displays the STP interface status and configuration of specified interfaces.
show spanning-tree mst	Displays information about Multiple Spanning Tree (MST) STP.
show spanning-tree summary	Displays summary information about STP.
show spanning-tree vlan	Displays STP information for specified VLANs.

■ show spanning-tree summary

Send comments to nx5000-docfeedback@cisco.com

show spanning-tree summary

To display summary Spanning Tree Protocol (STP) information on the switch, use the **show spanning-tree summary** command.

show spanning-tree summary [totals]

Syntax Description	totals (Optional) Displays totals only of STP information.																		
Command Default	None																		
Command Modes	EXEC mode																		
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>4.0(0)N1(1a)</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	4.0(0)N1(1a)	This command was introduced.														
Release	Modification																		
4.0(0)N1(1a)	This command was introduced.																		
Usage Guidelines	The display output for this command differs when you are running Rapid Per VLAN Spanning Tree Plus (Rapid PVST+) or Multiple Spanning Tree (MST).																		
Examples	<p>This example shows how to display a summary of STP information on the switch:</p> <pre>switch(config)# show spanning-tree summary</pre>																		
Related Commands	<table border="1"> <thead> <tr> <th>Command</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>show spanning-tree</td> <td>Displays information about STP.</td></tr> <tr> <td>show spanning-tree active</td> <td>Displays information about STP active interfaces only.</td></tr> <tr> <td>show spanning-tree bridge</td> <td>Displays the bridge ID, timers, and protocol for the local bridge on the switch.</td></tr> <tr> <td>show spanning-tree detail</td> <td>Displays detailed information about STP.</td></tr> <tr> <td>show spanning-tree interface</td> <td>Displays the STP interface status and configuration of specified interfaces.</td></tr> <tr> <td>show spanning-tree mst</td> <td>Displays information about Multiple Spanning Tree (MST) STP.</td></tr> <tr> <td>show spanning-tree root</td> <td>Displays the status and configuration of the root bridge for the STP instance to which this switch belongs.</td></tr> <tr> <td>show spanning-tree vlan</td> <td>Displays STP information for specified VLANs.</td></tr> </tbody> </table>	Command	Description	show spanning-tree	Displays information about STP.	show spanning-tree active	Displays information about STP active interfaces only.	show spanning-tree bridge	Displays the bridge ID, timers, and protocol for the local bridge on the switch.	show spanning-tree detail	Displays detailed information about STP.	show spanning-tree interface	Displays the STP interface status and configuration of specified interfaces.	show spanning-tree mst	Displays information about Multiple Spanning Tree (MST) STP.	show spanning-tree root	Displays the status and configuration of the root bridge for the STP instance to which this switch belongs.	show spanning-tree vlan	Displays STP information for specified VLANs.
Command	Description																		
show spanning-tree	Displays information about STP.																		
show spanning-tree active	Displays information about STP active interfaces only.																		
show spanning-tree bridge	Displays the bridge ID, timers, and protocol for the local bridge on the switch.																		
show spanning-tree detail	Displays detailed information about STP.																		
show spanning-tree interface	Displays the STP interface status and configuration of specified interfaces.																		
show spanning-tree mst	Displays information about Multiple Spanning Tree (MST) STP.																		
show spanning-tree root	Displays the status and configuration of the root bridge for the STP instance to which this switch belongs.																		
show spanning-tree vlan	Displays STP information for specified VLANs.																		

Send comments to nx5000-docfeedback@cisco.com

show spanning-tree vlan

To display Spanning Tree Protocol (STP) information for specified VLANs, use the **show spanning-tree vlan** command.

```
show spanning-tree vlan {vlan-id} [active [brief | detail]]
show spanning-tree vlan {vlan-id} [blockedports]
show spanning-tree vlan {vlan-id} [bridge [address] | brief | detail | forward-time | hello-time |
    id | max-age | priority [system-id] | protocol]
show spanning-tree vlan {vlan-id} [brief [active]]
show spanning-tree vlan {vlan-id} [detail [active]]
show spanning-tree vlan {vlan-id} [inconsistentports]
show spanning-tree vlan {vlan-id} [interface {ethernet slot/port | port-channel number} [active
    [brief | detail]] | brief [active] | cost | detail [active] | edge | inconsistency | priority | rootcost
    | state]]
show spanning-tree vlan {vlan-id} [root [address | brief | cost | detail | forward-time | hello-time
    | id | max-age | port | priority [system-id]]]
show spanning-tree vlan {vlan-id} [summary]
```

Syntax Description	
vlan-id	VLAN or range of VLANs that you want to display.
active	(Optional) Displays information about STP VLANs and active ports.
brief	(Optional) Displays a brief summary of STP information for the specified VLANs.
detail	(Optional) Displays detailed STP information for the specified VLANs.
blockedports	(Optional) Displays the STP alternate ports in the blocked state for the specified VLANs.
bridge	(Optional) Displays the status and configuration of the bridge for the specified VLANs.
address	(Optional) Displays the MAC address for the specified STP bridge for the specified VLANs.
forward-time	(Optional) Displays the STP forward delay interval for the bridge for the specified VLANs.
hello-time	(Optional) Displays the STP hello time for the bridge for the specified VLANs.
id	(Optional) Displays the STP bridge identifier for the specified VLANs.
max-age	(Optional) Displays the STP maximum-aging time for the specified VLANs.
priority	(Optional) Displays the STP priority for the specified VLANs.
system-id	(Optional) Displays the bridge identification with the system ID added for the specified VLANs.
protocol	(Optional) Displays which STP protocol is active on the switch.

show spanning-tree vlan

Send comments to nx5000-docfeedback@cisco.com

inconsistentports	(Optional) Displays the ports that are in an inconsistent STP state for specified VLANs.
interface	(Optional) Specifies the interface. The interface can be Ethernet or EtherChannel.
ethernet slot/port	(Optional) Specifies the Ethernet interface and its slot number and port number. The <i>slot</i> number is from 1 to 255, and the <i>port</i> number is from 1 to 128.
port-channel number	(Optional) Specifies the EtherChannel interface and number. The EtherChannel number is from 1 to 4096.
cost	(Optional) Displays the STP path cost for the specified VLANs.
edge	(Optional) Displays the STP-type edge port information for the specified interface for the specified VLANs.
inconsistency	(Optional) Displays the STP port inconsistency state for the specified interface for the specified VLANs.
priority	(Optional) Displays the STP priority for the specified VLANs.
rootcost	(Optional) Displays the path cost to the root for specified interfaces for the specified VLANs.
state	(Optional) Displays the current port STP state. Valid values are blocking, disabled, learning, and forwarding.
port	(Optional) Displays information about the root port for the specified VLANs.
summary	(Optional) Displays summary STP information on the specified VLANs.

Command Default None

Command Modes EXEC mode

Command History	Release	Modification
	4.0(0)N1(1a)	This command was introduced.

Examples This example shows how to display STP information on VLAN 1:

```
switch# show spanning-tree vlan 1
```

Related Commands	Command	Description
	show spanning-tree	Displays information about STP.
	show spanning-tree active	Displays information about STP active interfaces only.
	show spanning-tree bridge	Displays the bridge ID, timers, and protocol for the local bridge on the switch.

Send comments to nx5000-docfeedback@cisco.com

Command	Description
show spanning-tree brief	Displays a brief summary about STP.
show spanning-tree detail	Displays detailed information about STP.
show spanning-tree interface	Displays the STP interface status and configuration of specified interfaces.
show spanning-tree mst	Displays information about Multiple Spanning Tree (MST) STP.
show spanning-tree root	Displays the status and configuration of the root bridge for the STP instance to which this switch belongs.
show spanning-tree summary	Displays summary information about STP.

■ **show startup-config**

Send comments to nx5000-docfeedback@cisco.com

show startup-config

To display the contents of the currently running configuration file, use the **show startup-config** command.

show startup-config

Syntax Description This command has no arguments or keywords.

Command Default None

Command Modes EXEC mode

Command History	Release	Modification
	4.0(0)N1(1a)	This command was introduced.

Examples This example shows how to display information from the startup configuration file:

```
switch# show startup-config
```

Related Commands	Command	Description
	show running-config	Displays the contents of the currently running configuration file.

Send comments to nx5000-docfeedback@cisco.com

show tech-support port-channel

To display troubleshooting information about EtherChannel interfaces, use the **show tech-support port-channel** command.

show tech-support port-channel

Syntax Description This command has no arguments and keywords.

Command Default None

Command Modes EXEC mode

Command History	Release	Modification
	4.0(0)N1(1a)	This command was introduced.

Usage Guidelines The output from the **show tech-support port-channel** command is very long. To better manage this output, you can redirect the output to a file.

Examples This example shows how to display Cisco technical support information for EtherChannel interfaces:

```
switch# show tech-support port-channel
`show port-channel internal event-history all`
Low Priority Pending queue: len(0), max len(2) [Thu Jul  8 04:05:04 2010]
High Priority Pending queue: len(0), max len(32) [Thu Jul  8 04:05:04 2010]
PCM Control Block info:
pcm_max_channels      : 4096
pcm_max_channel_in_use : 1912
pc count              : 29
hif-pc count          : 20
Max PC Cnt            : 768
=====
PORT CHANNELS:

port-channel19
channel      : 19
bundle       : 65535
ifindex      : 0x16000012
admin mode   : active
oper mode   : active
fop ifindex  : 0x1fc605c0
nports       : 4
active       : 4
pre cfg     : 0
ltl:         : 0
lif:         : 0
iod:         : 43
global id   : 1
```

■ show tech-support port-channel

Send comments to nx5000-docfeedback@cisco.com

```
flag          : 0
--More--
<---output truncated--->
switch#
```

Related Commands	Command	Description
	port-channel load-balance ethernet	Configures the load-balancing method among the interfaces in the channel-group bundle.
	show port-channel load-balance	Displays information on EtherChannel load balancing.

Send comments to nx5000-docfeedback@cisco.com

show udld

To display the Unidirectional Link Detection (UDLD) information for a switch, use the **show udld** command.

show udld [ethernet slot/port | global | neighbors]

Syntax Description	ethernet slot/port Displays UDLD information for an Ethernet IEEE 802.3z interface. The <i>slot</i> number is from 1 to 255, and the <i>port</i> number is from 1 to 128. global Displays the UDLD global status and configuration information on all interfaces. neighbors Displays information about UDLD neighbor interfaces.
--------------------	---

Command Default	None
------------------------	------

Command Modes	EXEC mode
----------------------	-----------

Command History	Release	Modification
	4.0(1a)N1(1)	This command was introduced.

Examples	This example shows how to display UDLD information for all interfaces:
-----------------	--

```

switch# show udld

Interface Ethernet1/1
-----
Port enable administrative configuration setting: device-default
Port enable operational state: enabled
Current bidirectional state: bidirectional
Current operational state: advertisement - Single neighbor detected
Message interval: 15
Timeout interval: 5

Entry 1
-----
Expiration time: 41
Cache Device index: 1
Current neighbor state: bidirectional
Device ID: FLC12280095
Port ID: Ethernet1/1
Neighbor echo 1 devices: SSI130205RT
Neighbor echo 1 port: Ethernet1/1

Message interval: 15
Timeout interval: 5
CDP Device name: N5Kswitch-2(FLC12280095)

```

Interface Ethernet1/2

■ show udld

Send comments to nx5000-docfeedback@cisco.com

```
Port enable administrative configuration setting: device-default
Port enable operational state: enabled
Current bidirectional state: bidirectional
Current operational state: advertisement - Single neighbor detected
Message interval: 15
Timeout interval: 5

Entry 1
-----
--More--
switch#
```

This example shows how to display the UDLD information for a specified interface:

```
switch# show udld ethernet 1/1

Interface Ethernet1/1
-----
Port enable administrative configuration setting: device-default
Port enable operational state: enabled
Current bidirectional state: bidirectional
Current operational state: advertisement - Single neighbor detected
Message interval: 15
Timeout interval: 5

Entry 1
-----
Expiration time: 41
Cache Device index: 1
Current neighbor state: bidirectional
Device ID: FLC12280095
Port ID: Ethernet1/1
Neighbor echo 1 devices: SSI130205RT
Neighbor echo 1 port: Ethernet1/1

Message interval: 15
Timeout interval: 5
CDP Device name: N5Kswitch-2(FLC12280095)

switch#
```

This example shows how to display the UDLD global status and configuration on all interfaces:

```
switch# show udld global

UDLD global configuration mode: enabled
UDLD global message interval: 15
switch#
```

This example shows how to display the UDLD neighbor interfaces:

```
switch# show udld neighbors
-----
```

Port	Device Name	Device ID	Port ID	Neighbor State
Ethernet1/1	FLC12280095	1	Ethernet1/1	bidirectional
Ethernet1/2	FLC12280095	1	Ethernet1/2	bidirectional
Ethernet1/3	FLC12280095	1	Ethernet1/3	bidirectional
Ethernet1/4	FLC12280095	1	Ethernet1/4	bidirectional
Ethernet1/7	JAF1346000H	1	Ethernet1/7	bidirectional
Ethernet1/8	JAF1346000H	1	Ethernet1/8	bidirectional
Ethernet1/9	JAF1346000C	1	Ethernet1/9	bidirectional
Ethernet1/10	JAF1346000C	1	Ethernet1/10	bidirectional

```
switch#
```

Send comments to nx5000-docfeedback@cisco.com

Related Commands	Command	Description
	udld (configuration mode)	Configures the UDLD protocol on the switch.
	udld (Ethernet)	Configures the UDLD protocol on an Ethernet interface.

show vlan

Send comments to nx5000-docfeedback@cisco.com

show vlan

To display VLAN information, use the **show vlan** command.

show vlan [brief | name {name} | summary]

Syntax Description	brief	(Optional) Displays only a single line for each VLAN, naming the VLAN, status, and ports.
Command Default	None	
Command Modes	EXEC mode	
Command History	Release	Modification
	4.0(0)N1(1a)	This command was introduced.

Usage Guidelines This command displays information for all VLANs, including private VLANs, on the switch.

Each access port can belong to only one VLAN. Trunk ports can be on multiple VLANs.



Note

Although a port can be associated with a VLAN as an access VLAN, a native VLAN, or one of the trunk allowed ports, only access VLANs are shown under Ports in the display.

If you shut down a VLAN using the **state suspend** or the **state active** command, these values appear in the Status field:

- suspended—VLAN is suspended.
- active—VLAN is active.

If you shut down a VLAN using the **shutdown** command, these values appear in the Status field:

- act/lshut—VLAN status is active but shut down locally.
- sus/lshut—VLAN status is suspended but shut down locally.

If a VLAN is shut down internally, these values appear in the Status field:

- act/ishut—VLAN status is active but shut down internally.
- sus/ishut—VLAN status is suspended but shut down internally.

If a VLAN is shut down locally and internally, the value that is displayed in the Status field is act/ishut or sus/ishut. If a VLAN is shut down locally only, the value that is displayed in the Status field is act/lshut or sus/lshut.

Send comments to nx5000-docfeedback@cisco.com

Examples

This example shows how to display information for all VLANs on the switch:

```
switch# show vlan
```

This example shows how to display the VLAN name, status, and associated ports only:

```
switch# show vlan brief
```

This example shows how to display the VLAN information for a specific VLAN by name:

```
switch# show vlan name test
```

This example shows how to display information about the number of VLANs configured on the switch:

```
switch# show vlan summary
```

Related Commands

Command	Description
show interface switchport	Displays information about the ports, including those in private VLANs.
show vlan private-vlan	Displays private VLAN information.

■ **show vlan dot1Q tag native**

Send comments to nx5000-docfeedback@cisco.com

show vlan dot1Q tag native

To display the status of tagging on the native VLANs, use the **show vlan dot1Q tag native** command.

show vlan dot1Q tag native

Syntax Description This command has no arguments or keywords.

Command Default None

Command Modes EXEC mode

Command History	Release	Modification
	4.0(0)N1(1a)	This command was introduced.

Examples This example shows how to display the status of 802.1Q tagging on the native VLANs:

```
switch# show vlan dot1Q tag native
vlan dot1q native tag is enabled
switch#
```

Related Commands	Command	Description
	vlan dot1q tag native	Enables dot1q (IEEE 802.1Q) tagging for all native VLANs on all trunked ports on the switch.

Send comments to nx5000-docfeedback@cisco.com

show vlan id

To display information and statistics for an individual VLAN or a range of VLANs, use the **show vlan id** command.

show vlan id {vlan-id}

Syntax Description	<i>vlan-id</i>	VLAN or range of VLANs that you want to display.
---------------------------	----------------	--

Command Default	None
------------------------	------

Command Modes	EXEC mode
----------------------	-----------

Command History	Release	Modification
	4.0(0)N1(1a)	This command was introduced.

Usage Guidelines	Use this command to display information and statistics on an individual VLAN or a range of VLANs, including private VLANs.
-------------------------	--



You can also display information about individual VLANs using the **show vlan name** command.

Examples	This example shows how to display information for the individual VLAN 5:
	switch# show vlan id 5

Related Commands	Command	Description
	show vlan	Displays information about VLANs on the switch.

■ **show vlan private-vlan**

Send comments to nx5000-docfeedback@cisco.com

show vlan private-vlan

To display private VLAN information, use the **show vlan private-vlan** command.

show vlan [id {vlan-id}] private-vlan [type]

Syntax Description	id <i>vlan-id</i> (Optional) Displays private VLAN information for the specified VLAN. type (Optional) Displays the private VLAN type (primary, isolated, or community).
---------------------------	---

Command Default	None
------------------------	------

Command Modes	EXEC mode
----------------------	-----------

Command History	Release	Modification
	4.0(0)N1(1a)	This command was introduced.

Examples	This example shows how to display information on all private VLANs on the switch:
-----------------	---

```
switch(config)# show vlan private-vlan
```

This example shows how to display information for a specific private VLAN:
--

```
switch(config)# show vlan id 42 private-vlan
```

This example shows how to display information on the types of all private VLANs on the switch:
--

```
switch(config)# show vlan private-vlan type
```

Related Commands	Command	Description
	show interface private-vlan mapping	Displays information about the private VLAN mapping between the primary and secondary VLANs so that both VLANs share the same primary VLAN interface.
	show interface switchport	Displays information about the ports, including those in private VLANs.
	show vlan	Displays information about all the VLANs on the switch.

Send comments to nx5000-docfeedback@cisco.com

show vtp status

To display the VLAN Trunking Protocol (VTP) domain status information, use the **show vtp status** command.

show vtp status

Syntax Description This command has no arguments or keywords.

Command Default None

Command Modes EXEC mode

Command History	Release	Modification
	4.2(1)N1(1)	This command was introduced.

Usage Guidelines Before you use this command, you must enable VTP on the switch by using the **feature vtp** command.

Examples This example shows how to display the VTP domain status:

```
switch# show vtp status
VTP Version : 1
Configuration Revision : 0
Maximum VLANs supported locally : 1005
VTP Operating Mode : Transparent
VTP Domain Name :
VTP Pruning Mode : Disabled
VTP V2 Mode : Disabled
VTP Traps Generation : Disabled
switch#
```

Related Commands	Command	Description
	feature vtp	Enables VTP on the switch.
	vtp domain	Configures the VTP domain.
	vtp mode	Configures the VTP device mode.
	vtp version	Configures the VTP version.

■ show vtp status

Send comments to nx5000-docfeedback@cisco.com