


Maintenance Manual MM-1736

System Saver HP Air Dryer

Revised 12-17



Service Notes

About This Manual

This manual provides service and repair procedures for Meritor WABCO's System Saver HP air dryer.

Before You Begin

1. Read and understand all instructions and procedures before you begin to service components.
2. Read and observe all Warning and Caution hazard alert messages in this publication. They provide information that can help prevent serious personal injury, damage to components, or both.
3. Follow your company's maintenance and service, installation, and diagnostics guidelines.
4. Use special tools when required to help avoid serious personal injury and damage to components.


Hazard Alert Messages and Torque Symbols

WARNING

A Warning alerts you to an instruction or procedure that you must follow exactly to avoid serious personal injury and damage to components.

CAUTION

A Caution alerts you to an instruction or procedure that you must follow exactly to avoid damage to components.

 This symbol alerts you to tighten fasteners to a specified torque value.

How to Obtain Additional Maintenance, Service and Product Information

Visit meritorwabco.com to access additional information.

Contact the Meritor OnTrac™ Customer Call Center at 866-668-7221 (United States and Canada); 001-800-889-1834 (Mexico); or email OnTrac@meritor.com.

If Tools and Supplies are Specified in This Manual

Contact Meritor's Commercial Vehicle Aftermarket at 888-725-9355.

Information contained in this publication was in effect at the time the publication was approved for printing and is subject to change without notice or liability. WABCO reserves the right to revise the information presented or to discontinue the production of parts described at any time.

pg. 1	Section 1: Introduction
	Overview
	Air Dryer Identification
	How the Air Dryer Works
2	Air Dryer Cycle
4	Air Dryer Components
6	Dryer Identification
	Description of Components
8	Section 2: Component Removal and Installation
	Component Replacement
	Requirements
9	Component Removal and Installation
	Desiccant Cartridge
10	Outlet Check Valve Assembly
	Heater Assembly
11	Turbo Cut-Off Valve Assembly
	Governor
	Purge Valve Assembly
12	Air Dryer Assembly
13	Section 3: Troubleshooting and Testing
	Maintenance
	Maintenance Tips
14	Troubleshooting
18	Tests
	Heater Resistance
	Electric Power to Dryer
19	Leak Test
	Air Pressure Checks
	Operational Test for System Saver Series Air Dryers
20	Section 4: Appendix I — Glossary
	Definitions
	Basic Air System/Air Dryer Terms
21	Section 5: Appendix II — Application Information
	Recommendations
	Operating Environment
22	System Saver IP Installation Criteria

Overview

Maintenance Manual 1736 contains troubleshooting steps and service information for the Meritor WABCO System Saver HP single cartridge air dryer.

NOTE: If you have a Meritor WABCO System Saver (1200 or 1800) single cartridge air dryer, use Maintenance Manual 34, Meritor WABCO System Saver Series (1200 and 1800) Single Cartridge Air Dryers. If you have a Meritor WABCO System Saver Twin air dryer, use Maintenance Manual 35, Meritor WABCO System Saver Twin Air Dryer. To obtain these publications, refer to the Service Notes page on the front inside cover of this manual.

Air Dryer Identification

System Saver HP: Has the governor integrated into the body of the air dryer and also has an integrated purge tank. Figure 1.1.




Figure 1.1

How the Air Dryer Works

During system pressure build-up, compressed air passes into the air dryer where the filter system removes contaminants and passes the air into the drying stage.

Moisture-laden air passes through the desiccant bed in the air dryer cartridge and moisture is retained by the desiccant. Moisture that condenses out also collects in the base of the dryer. When the compressor unloads, the water is expelled and dried air flows back through the dryer, drying the desiccant for the next cycle.


1 Introduction

Air Dryer Cycle

A single cartridge air dryer cycle is illustrated in Table A.


Table A:

The governor turns the compressor loading on when supply tank pressure drops below cut-in pressure, between 105 psi and 115 psi (724-792 kPa) depending on governor settings.




Compressed air passes into the air dryer at the inlet port:

- Moisture-laden air and contaminants enter the desiccant.
- Moisture is retained by desiccant; moisture also collects in the base of the dryer.
- Contaminants are removed as air passes through the desiccant bed.




1 Introduction

The governor unloads compressor when system reaches cut-out level 132 psi (910 kPa) +/-3 psi, depending on governor settings.



When the compressor unloads, the purge valve opens. On the System Saver HP:

- Dry air flows from the integrated purge tank back through the air dryer. Air can be felt and heard flowing from the purge valve for an extended period of time.
- Dry system air flows back through the air dryer to regenerate the desiccant.



1 Introduction

System Saver HP Air Dryer System





Figure 1.2

Air Dryer Components

Meritor WABCO single cartridge air dryers contain replaceable component parts. System Saver HP components are listed in Figure 1.3. Refer to Section 2 for instructions for removal of old parts and installation of new parts.



4013289a

Figure 1.3

1 Introduction

Dryer Identification

The identification tag on the face of the dryer provides important information about the air dryer — information you will need when servicing or replacing components. Figure 1.4.




Figure 1.4

Description of Components

Replacement components for single canister air dryers are described below.

Spin-on/spin-off design allows quick and easy maintenance.

Always replace cartridges with authentic Meritor WABCO brand cartridges.

Coalescing Cartridge: Utilizes a filter element added to the standard desiccant to remove aerosols and oil particles.

Heater: Located in the air dryer base, the heater prevents water that collects in the air dryer from freezing. It consists of a cylindrical resistive-type heating element and a small circular thermostat. Heater is available for 12- and 24-volt air dryers. Figure 1.5.




Figure 1.5

Outlet Check Valve: A valve located in the outlet port (port 21) of the air dryer. It prevents air from flowing back through the air dryer and escaping out the purge valve during a compressor unload cycle. Figure 1.6.




Figure 1.6

Pressure Relief Valve: A valve that protects the air dryer from over-pressurization. Figure 1.7.




Figure 1.7

Purge Valve Assembly: A valve assembly located on the bottom of the air dryer base that remains open during a compressor unload cycle. It allows collected moisture, condensation and contamination to be expelled from the air dryer during a purge cycle. Figure 1.8.




Figure 1.8

Turbo Cut-off Valve: A valve located in the inlet port of the air dryer. It closes the path between the air compressor and the air dryer purge valve during compressor unload. This prevents a loss of turbocharger boost pressure during a compressor unload cycle, thereby maintaining boost pressure for maximum engine horsepower. Figure 1.9 (used exclusively on 1200 Plus and HP models).




Figure 1.9

Heater Power Harness: Twelve-inch cable with Metri-Pack plug provides electrical connection to air dryer heating unit. Figure 1.10.




Figure 1.10

2 Component Removal and Installation

Hazard Alert Messages

Read and observe all Warning and Caution hazard alert messages in this publication. They provide information that can help prevent serious personal injury, damage to components, or both.

WARNING

To prevent serious eye injury, always wear safe eye protection when you perform vehicle maintenance or service.

Park the vehicle on a level surface. Block the wheels to prevent the vehicle from moving. Support the vehicle with safety stands. Do not work under a vehicle supported only by jacks. Jacks can slip and fall over. Serious personal injury and damage to components can result.

Remove all pressure from the air system before you disconnect any component, including the desiccant cartridge. Pressurized air can cause serious personal injury.

NOTE: The pressure protection elements are not serviceable on the System Saver HP. The entire air dryer needs to be replaced if these parts are not operating effectively.

Component Replacement

Requirements

Refer to Table B for component replacement requirements. If necessary, you may also refer to Table D for System Saver Series air dryer troubleshooting. Before replacing any air dryer component, verify that the air compressor and air governor are working correctly, then drain the air tanks. Repair or replace these parts, if necessary. Check the entire air system for leaks, and repair as necessary. When draining air tanks before servicing the air dryer, check for water and/or oil that may have accumulated in the tanks. Water and/or oil in the air tanks could indicate a problem with the dryer or compressor.

Table B:

Replacement Requirements

Component	When to Replace	Why
Cartridge	Every two to three years for standard desiccant.	Preventative maintenance.
	Every one to two years for coalescing.	
	When compressor is replaced.	Contaminated cartridge.
	Water in supply tank.	Saturated or contaminated cartridge, high duty cycle (wrong application of air dryer).
Heater Assembly	Water collecting in air dryer is freezing — electrical power to dryer is OK.	Heater assembly not working (internal short or open circuit).
Outlet Check Valve	Air continues to flow from purge valve after purge cycle, but stops flowing when the compressor load cycle begins.	Valve is stuck in the open position, or not functioning correctly.
	No pressure build-up in system, everything else is OK.	Valve is stuck in closed position.
Purge Valve	No purge cycle when compressor unloads — normal pressure at dryer control port 4 (governor port).	Valve is stuck in the closed position, or not functioning correctly.
	Air flows from purge valve during compressor's load cycle — no pressure at dryer control port.	Valve is stuck in the open position, or not functioning correctly.

2 Component Removal and Installation

Replacement Requirements

Component	When to Replace	Why
Turbo Cut-Off Valve	Air compressor stuck pumping, TCU remains open. System will build pressure until safety valve opens in system.	Signal line loss.
	Air flows from purge valve during compressor unload cycle after purge cycle, and flow is noticeably stronger at high engine RPM, especially under load.	Turbo cut-off valve leaking.
	No pressure build-up in system — high compressor discharge line pressure.	Valve stuck in closed position.

NOTE: When replacing air dryer components, use only Meritor WABCO replacement parts.

The exploded view of the air dryer in Section 1 shows the location of the various air dryer components.

Component Removal and Installation

Desiccant Cartridge

IMPORTANT NOTE: For air dryer part numbers 432 480 001 0, 432 480 101 0 and 432 480 141 0 (see dryer tag), you must use air cartridges S432 901 248 2, S432 901 250 2 and S432 480 004 2.

1. Replacement kit contains one cartridge and one O-ring. Figure 2.1.



Figure 2.1

2. Loosen and remove the old cartridge. Use strap wrench if necessary.
3. Remove and discard O-ring from dryer base.

NOTE: If the seal seats are damaged so badly that a tight seal cannot be maintained, replace the air dryer. Refer to Figure 2.2.

4. Inspect and clean seal seat. Repair any minor damage.
5. Lubricate and install the new O-ring on the stem.
6. Lubricate cartridge seal.
7. Thread replacement cartridge onto the base until the seal touches the base. Then, tighten the cartridge **ONE** additional turn. **DO NOT OVERTIGHTEN.** Figure 2.2. If the cartridge will not fully spin on the dryer, the wrong cartridge is being used (see IMPORTANT NOTE).




Figure 2.2

2 Component Removal and Installation

Outlet Check Valve Assembly

1. Review Figure 2.3 to ensure you have all of the parts required to replace the outlet check valve. Use the grease included with the replacement kit to lubricate the O-ring seal.




Figure 2.3

2. Remove the snap ring, washer, spring, valve body and O-ring.
3. Clean and inspect the valve bore. If the bore is damaged so that a tight seal cannot be maintained, replace the air dryer.
4. Install the new O-ring on the valve body. Figure 2.4.




Figure 2.4

5. Apply a thin layer of grease from the kit to the valve bore and the O-ring.
6. Install the new valve body with its long end in the bore.
7. Install the new spring with its small end around the "Y"-shaped fins on the valve body.
8. Install the new washer and the new snap ring to hold the components in place.

Heater Assembly

1. Review Figure 2.5 to ensure you have all of the parts required to replace the heater assembly.




Figure 2.5

2. Disconnect the plug.
3. Remove the screws, receptacle and O-ring from the base to access the retainer screw.
4. Remove the retainer screw and then remove the entire heater assembly.
5. Install the O-ring to heater connector housing.
6. Install the new element and thermostat in their cavities.
7. Install the new retainer and screw to hold the element and the thermostat in place.
8. Install the receptacle and fasten them in place with the screws. Figure 2.6.




Figure 2.6

2 Component Removal and Installation

Turbo Cut-Off Valve Assembly

NOTE: Use the grease included with the replacement kit to lubricate O-rings and seals.

1. Remove the snap ring. Figure 2.7.




Figure 2.7

2. Remove the cover.
3. Remove the piston and sleeve.
4. Clean and inspect the valve bore.
 - **If the bore is damaged so that a tight seal cannot be maintained:** Replace the air dryer.
5. Apply a thin layer of grease to the valve bore and the O-rings.
6. Install new O-rings on the piston and sleeve.
7. Press the piston into the sleeve.
8. Press the piston-sleeve assembly into the air dryer.
9. Install the cover and snap ring.
10. Replace the desiccant cartridge using the detailed instructions provided earlier in this section.

Governor

Function— The governor controls the cut-in and cut-out pressure of the compressor through signal lines from the system reservoir as well as the compressor head controlling on/offload.

Use only the Meritor WABCO governor specified for use with the System Saver HP air dryer.

1. Using a 1-3/16" wrench, remove the governor from the air dryer. Figure 2.8.





Figure 2.8

2. Install the new governor into the air dryer. Use a 1-3/16" wrench to tighten it to **no more than 8.85 ft-lb (12 N·m)**. 

Purge Valve Assembly

1. Use a 1-11/16" wrench to remove the purge valve assembly from the air dryer. Figure 2.9.





Figure 2.9

2. Clean and inspect the valve bore.

2 Component Removal and Installation

- If the bore is damaged so that a tight seal cannot be maintained: Replace the air dryer.

3. Install the purge valve assembly in the air dryer. Use a 1-11/16" wrench to tighten it to no more than 11 ft-lb (15 N•m). 

Air Dryer Assembly

NOTE: This procedure is for removing and replacing a unit. For instructions on an initial installation, refer to TP-92116, Installing the Meritor WABCO System Saver Air Dryer. To obtain this publication, refer to the Service Notes page on the front inside cover of this manual.

1. Drain all pressure from the air system. Disconnect the air lines from port 1, port 2.2 and port 4.

Use markers to label the lines for correct reinstallation.

2. Disconnect the heater electrical plug from the heater receptacle.
3. Remove the three mounting bolts. Remove the air dryer from its mounting location. Figure 2.10.





Figure 2.10

4. Attach the new unit to the frame or mounting bracket with new mounting bolts and washers. Tighten the bolts to 22-30 ft-lb (30-40 N•m). Figure 2.11. 




Figure 2.11

5. Connect heater electrical plug to heater receptacle.
6. Reconnect all system air lines.
7. Test the installation for correct operation. Refer to the procedure in this section.

Maintenance

Read and observe all Warning and Caution hazard alert messages in this publication. They provide information that can help prevent serious personal injury, damage to components, or both.

WARNING

To prevent serious eye injury, always wear safe eye protection when you perform vehicle maintenance or service.

Park the vehicle on a level surface. Block the wheels to prevent the vehicle from moving. Support the vehicle with safety stands. Do not work under a vehicle supported only by jacks. Jacks can slip and fall over. Serious personal injury and damage to components can result.

Remove all pressure from the air system before you disconnect any component, including the desiccant cartridge. Pressurized air can cause serious personal injury.

To keep your Meritor WABCO air dryer operating efficiently, the routine maintenance in Table C is recommended.

Table C:

Action	Interval
Ensure the dryer purges when compressor unloads.	Weekly.
Drain the purge tank (dedicated purge tank dryers).	Weekly, or as recommended by the manufacturer.
Check for moisture in the system by opening the drain cock on vehicle system reservoirs slowly.	Weekly, or as recommended by the manufacturer, whichever is most frequent.
Replace the standard desiccant cartridge.	Every two to three years, or more often depending on usage, vocation, and condition of compressor.
	Whenever compressor is rebuilt.
Replace the coalescing cartridge.	Every one to two years.

Maintenance Tips

With correct maintenance, the Meritor WABCO air dryer will provide years of reliable service, even under adverse operating conditions. To provide additional protection against the harmful effects of extreme heat or cold, here are a few helpful tips.

Extreme Heat

Make sure the compressor discharge line is long enough to keep air dryer inlet air below 175°F (80°C). Figure 3.1. (Refer to Section 5.)

3 Troubleshooting and Testing




Figure 3.1

Extreme Cold

Make sure the air dryer heater is in good working order by running a heater resistance test. Refer to the procedure in this section.

Check the line from the governor to port 4 of the dryer for oil and/or water. Keep this line clean to help prevent freezing.

Meritor WABCO air dryer components are installed in the air dryer at the factory and are designed to last for the life of the dryer. Under some operating conditions, however, a replacement may be required. Refer to Section 2 for replacement guide instructions.

Troubleshooting

Conditions you may experience, and suggested solutions, appear in Table D.

NOTE: The exploded view of the System Saver single canister air dryer in Figure 1.3 illustrates the location of components in the dryer.

Table D: System Saver Series Air Dryer Troubleshooting

Condition	Possible Cause	Purge Tank Air Dryers	Solution
Dryer leaks from purge valve during compressor loaded cycle. The leak may cause excessive compressor cycling or prevent the system from building air pressure.	Purge valve frozen open (cold weather operation).	Yes	Check heater. Repair/replace if necessary. Make sure governor to dryer port 4 line is free of water/oil. Remove and inspect purge valve and clean water/oil from top of piston.
	Debris under purge valve seat, such as particles from fittings or air inlet line.	Yes	Remove and clean purge valve mating surfaces. Remove cartridge and clean dryer sump area.
	Purge valve washer installed upside-down.	Yes	Ensure lip on aluminum washer faces DOWN , away from dryer.
	Wrong air line connected to dryer port 4 (unloader port).	Yes	Verify correct air line installation and correct as needed.
	Purge valve snap ring not fully seated in groove.	Yes	Seat snap ring fully into groove.
Regeneration cycle too long (more than 30 seconds), accompanied by loss of pressure in the supply tank.	Outlet check valve not seating.	Yes	Inspect and replace outlet check valve as needed.
	Regeneration valve not shutting off regeneration airflow.	No	Replace regeneration valve.
Regeneration cycle too short (less than 10 seconds).	High air system demands during compressor unloaded cycle.	Yes	Increase air system capacity or reduce air demands.
	Pressure-controlled check valve not installed in system or not working correctly.	Yes	Check and replace pressure-controlled check valve as needed.
	One-way check valve installed in system reservoir instead of, or with, pressure-controlled check valve.	No	Remove one-way check valve. Make sure pressure-controlled check valve is installed correctly.
	Regeneration valve not working.	No	Remove regeneration valve and clean oil from diaphragm. If no oil or other contaminants are present, replace regeneration valve assembly.
	Air governor not working correctly.	Yes	Inspect air governor. Repair/replace per manufacturer's instructions.
Water in purge tank.	Block in purge tank line.	Yes	Clear blockage. Replace desiccant cartridge.

3 Troubleshooting and Testing

Condition	Possible Cause	Purge Tank Air Dryers	Solution
No regeneration cycle. No airflow from purge valve after initial purge blast (dryer decompression).	Air dryer not connected to supply tank or connections reversed at dryer.	No	Verify correct dryer installation per system diagram.
	Regeneration valve not working.	No	Replace regeneration valve.
	One-way check valve installed in supply tank.	No	Remove one-way check valve.
	Alcohol evaporator installed between dryer and supply tank.	No	Install bypass line around evaporator or remove evaporator from system.
Air dryer does not purge when compressor unloads (no blast of air from purge valve).	Blocked line/pinched line from purge tank.	Yes	Clear/repair line.
	Air line between governor and air dryer port 4 kinked or plugged.	Yes	Repair air line.
	Purge valve stuck closed.	Yes	Replace purge valve.
	Air governor not working correctly.	Yes	Inspect air governor. Repair/replace per manufacturer's instructions.
Air dryer purges too often, perhaps as frequently as every 15 seconds, accompanied by excessive cycling of the compressor.	Cut-out pressure never achieved by air compressor.	Yes	Check for air leaks in system and repair as needed. If no leaks in system, check compressor output. Repair/replace per manufacturer's instructions.
	Leak in line between governor and dryer port 4.	No	Repair air line.
	Leak in line between supply tank and governor.	Yes	Repair air line.
	Leaks in the air system.	Yes	Repair leaks.
	Excessive air system demands.	Yes	Increase air system capacity or reduce air demand.
	Outlet check valve not seating.	Yes	Inspect and replace outlet check valve as needed.
	Leaking air compressor unloader(s).	Yes	Inspect compressor. Repair/replace per manufacturer's instructions.

3 Troubleshooting and Testing

Condition	Possible Cause	Purge Tank Air Dryers	Solution
On air dryers equipped with turbo cut-off valves, the air flows out of purge valve entire time compressor is unloaded.	Turbo cut-off valve not sealing.	Yes	Replace turbo cut-off valve.
	Outlet check valve not seating.	Yes	Replace outlet check valve.
Rapid “spitting” of air from purge valve in small amounts. Frequency varies with engine speed.	Holset E-type compressor used, but no Econ valve installed.	Yes	Install Econ valve to provide make-up air to compressor.
	Compressor not completely unloading when cut-out pressure is reached.	Yes	Inspect compressor. Repair/replace per manufacturer’s instructions.
Air dryer frozen (water collecting in base of dryer is freezing).	No electrical power to heater connector.	Yes	Check for a blown fuse. Repair heater circuit. NOTE: There must be power to the heater connector the entire time the vehicle’s ignition is ON .
	Low voltage to heater connector.	Yes	Repair cause of low voltage, such as poor electrical ground, bad connections, corroded wire splices, etc.
	Heater assembly not working.	Yes	Replace heater assembly.
	Wrong voltage air dryer used; i.e., 12-volt air dryer used in a 24-volt system.	Yes	Replace with correct voltage air dryer.

3 Troubleshooting and Testing

Condition	Possible Cause	Purge Tank Air Dryers	Solution
No air pressure build-up in system.	Air dryer not plumbed correctly (connections reversed).	Yes	Ensure compressor discharge line is plumbed to air dryer port 1, and air dryer port 21 is connected to vehicle's supply tank.
	Wrong air line connected to dryer port 4.	Yes	Ensure dryer port 4 line is connected to the "UNL" port of the air governor.
	Air governor not working correctly.	Yes	Inspect the governor and replace it, if needed, with a Meritor WABCO governor kit.
	Air system leaks, such as compressor discharge line, air dryer, reservoirs, brake or suspension valves, etc.	Yes	Locate leak(s) and repair.
	Air dryer leaks from purge valve.	Yes	Refer to purge valve conditions listed in this chart.
Water, oil, or sludge in air system tanks.	Desiccant contaminated with oil.	Yes	Replace desiccant. Inspect compressor per manufacturer's instructions.
Water in system tanks.	Desiccant saturated.	Yes	Replace the desiccant cartridge with a genuine Meritor WABCO cartridge.
	Maintenance interval not followed.		
Water in system tanks, everything else checks out okay.	Dryer not suitable for application.	Yes	Review the application guidelines. Refer to TP-9672. For assistance, call the Meritor OnTrac™ Customer Call Center at 866-OnTrac1 (668-7221).

Tests

Heater Resistance

1. Set volt-ohmmeter to ohms.
2. Disconnect the vehicle harness at the heater.
3. Hold the leads together. Check the lead ohms. This value will be subtracted from the heater ohms in Step 5.
4. Place leads on the two pins on the heater connector at the air dryer.
5. Check the resistance. A resistance of 1.0-2.0 ohms should be seen for a 12-volt heater assembly and 5.0-7.0 ohms should be seen for a 24-volt heater assembly.

- **If there is correct resistance on the dryer side and there is sufficient voltage at the harness:** The heater is functioning correctly. Reinstall the components and harness.

- **If resistance is less than 1.0 ohm for a 12-volt heater assembly or 5.0 ohms for a 24-volt heater assembly:** Replace the heater.

To avoid damaging components, Meritor WABCO recommends performing this resistance check with the heater in place.

NOTE: The dryer temperature must be in thermostat closed range (below 35°F [1.65°C]) in order to check heater resistance.

Electric Power to Dryer

1. Set the volt-ohmmeter to volts.
2. Disconnect the vehicle harness at the heater.
3. Add a small electrical lead at the wire harness connector.
4. Place leads on each pin of the wiring harness connector.
5. If there is an abnormal voltage reading, inspect the wiring harness, wires and fuses.

Leak Test

1. Drain air from all system tanks.
2. Close reservoir draincocks.
3. Start the vehicle. Allow air system pressure to build while engine idles.
4. When the system reaches cut-out pressure there will be a purge, or strong blast of air, followed by a mild flow which will last 10-45 seconds.
5. Shut off the engine.
6. Apply a soap solution to each connection that contains pressurized air. Check the connections to see if soap solution bubbles.

No Soap Bubbles: Connections are sealed correctly.

Soap Bubbles Appear: Connections are NOT sealed correctly.

2. Verify that there is no visible pressure drop in the supply and secondary tanks during regeneration. If there is a visible pressure drop, perform a check valve leak test on the system check valves.

To Repair Incorrectly Sealed Connections

1. Drain all reservoirs.
2. Remove leaking connection.
3. Inspect the connectors and ports for damaged threads or cracks. Replace if necessary.
4. Apply pipe sealant to the connection.
5. Repeat leak test until all connections are sealed.

Air Pressure Checks

NOTE: When checking air pressure during these tests, do not rely on cab air gauges for accurate readings. Install a calibrated air gauge, accurate to within one psi (7 kPa), in the secondary air tank to determine if air pressure is within the required ranges.

Operational Test for System Saver Series Air Dryers

1. Check compressor loaded and unloaded cycle.

When the compressor is in the **loaded cycle**, air pressure will build to approximately 120-140 psi (827-965 kPa) (cut-out pressure). When the compressor reaches the **unloaded cycle**, the air dryer will purge, initiating regeneration of the air dryer.

Definitions

Basic Air System/Air Dryer Terms

Air Compressor	A device that pumps air to and builds air pressure in an air system.
Air Dryer	A device that cools, filters and dries the air delivered by an air compressor.
Air Governor	A device that controls the operation of the air compressor by constantly monitoring air pressure in the supply tank of the air system. The air governor initiates the compressor load cycle when “cut-in” pressure is realized, and initiates the compressor unload cycle when the “cut-out” pressure is reached. The air governor also controls the air dryer by sending an air signal (at the beginning of the compressor unload cycle) to the control port of the air dryer, initiating the purge cycle. When this air signal is removed by the governor (at the beginning of the compressor load cycle), the purge valve closes and the drying cycle begins.
Compressor Load Cycle	The time during which the air compressor is building air pressure in an air system.
Compressor Unload Cycle	The time during which the air compressor is idling and is not building air pressure in an air system.
Cut-In Pressure	The pressure level in the air system supply tank which triggers the compressor load cycle.
Cut-Out Pressure	The pressure level in the air system supply tank which triggers the compressor unload cycle.
Dedicated Purge Tank	A separate air tank used exclusively for holding air used in an air drying cycle. This tank eliminates the need for a regeneration valve. Optimum mounting location for the dedicated purge tank is ABOVE the air dryer.
Desiccant	A granular substance that has a high affinity for water and is used to retain moisture from the air stream flowing through the air dryer cartridge.
Discharge Line — Unloaded Compressor	An unloader or air discharge line used to dump unused air to atmosphere once system has reached cut-out pressure.
Drying Cycle	The time during which the air dryer cools, filters and removes moisture from the air delivered by the air compressor. The drying cycle begins and ends the same as the compressor load cycle.
Purge	The initial blast of air (decompression) from the air dryer purge valve at the beginning of the unload cycle of the air compressor.
Purge Cycle	The time during which the air dryer is undergoing purge and regeneration. This cycle starts at the beginning of the compressor unload cycle and normally ends well before the beginning of the compressor load cycle.
Regeneration	The mild backflow of air through the air dryer and out the purge valve that begins immediately after the purge and lasts normally 10 to 25 seconds. This backflow of air from the air system and through the air dryer removes moisture from the desiccant cartridge and readies the air dryer for the next compressor load cycle.

Hazard Alert Messages

Read and observe all Warning and Caution hazard alert messages in this publication. They provide information that can help prevent serious personal injury, damage to components, or both.

WARNING

To prevent serious eye injury, always wear safe eye protection when you perform vehicle maintenance or service.

Recommendations

NOTE: For complete installation and operating requirements, refer to TP-9672, Air Dryer Application Guidelines. To obtain this publication, refer to the Service Notes page on the front inside cover of this manual.

- Compressor discharge line should have a continual downhill run to the air dryer. There should be no water traps (low points or kinks) in the line before or after the dryer.
- Mount air dryer so that there is no direct splash or spray from a wheel.
- For maximum operating efficiency, mount dedicated purge tank ABOVE the air dryer.
- Keep air dryer at least 12-inches (305 mm) from any heat-producing sources like exhaust manifolds or pipes, transmissions, etc.
- Make sure there are no valves or other devices in the dryer-to-supply-tank line to prohibit or restrict the flow of air back from the supply tank to the air dryer.
- Feed purge valve by a direct line from the air governor.

Operating Environment

Operating Parameter	Requirement
Temperature (ambient operating range)	−40°F to 175°F (−40°C to 80°C)
Electrical Power (for heater and solenoid/timer power)	12 or 24 volts available
Thermostat Range (On/Off temp)	45°F, 86°F (7°C, 30°C)

Discharge Line:

- Diameter from compressor to air dryer
 - 5/8-inch (15.875 mm) ID minimum for 25.5 cfm and under
 - 3/4-inch (19.05 mm) ID minimum for over 25.5 cfm

IMPORTANT NOTE: Line size and fittings must comply with the compressor manufacturer's guidelines for backpressure and peak pressure.

- Length from compressor to air dryer
 - Determined by temperature of air at the inlet port of the air dryer. At normal vehicle operating temperature, the combination of length or increased diameter must be sufficient to keep temperature **BELOW 175°F (80°C)**.

5 Appendix II — Application Information

System Saver IP Installation Criteria

Operating Parameters		Requirements
Pressure requirements	Maximum pressure	140 psi (965 kPa)
	Minimum governor cut-out pressure	115 psi (793 kPa)
	Governor range	15 to 25 psi (103 to 172 kPa) (cut-out — cut-in)
Flow capacity	Compressor rating	25 cfm maximum
Compressor on-time	Normal running	Two minutes maximum
	Occasional (three times per day maximum)	Seven minutes
Compressor unloaded time	Minimum for purge cycle	20 seconds
Maximum duty cycle	Compressor on-time total running time	30%
Discharge line	Temperature at inlet port determines required length and diameter.	To minimize the likelihood of a discharge line blockage during cold climate operation, it is recommended that for discharge lines exceeding nine feet (2.75 m) in length, a minimum of three feet (0.91 m) of 1/2-inch (127 mm) thick closed-cell polyethylene pipe insulation be used at the connection to the air dryer.

WABCO Vehicle Control Systems

2135 West Maple Road
Troy, MI 48084-7121
866-OnTrac1 (668-7221)
meritorwabco.com

Copyright 2017
WABCO, Inc.

Printed in USA

Revised 12-17
Maintenance Manual MM-1736 (16579)

WABCO