

Rosemount™ 5300:SIS Level Transmitter

Guided Wave Radar



NOTICE

Read this manual before working with the product. For personal and system safety, and for optimum product performance, ensure you thoroughly understand the contents before installing, using, or maintaining this product.

For technical assistance, contacts are listed below:

Customer Central

Technical support, quoting, and order-related questions.

- United States - 1-800-999-9307 (7:00 am to 7:00 pm CST)
- Asia Pacific- 65 777 8211

North American Response Center

Equipment service needs.

- 1-800-654-7768 (24 hours a day — includes Canada)
- Outside of these areas, contact your local Emerson representative.

⚠ WARNING

Failure to follow safe installation and servicing guidelines could result in death or serious injury.

- Ensure the transmitter is installed by qualified personnel and in accordance with applicable code of practice.
- Use the equipment only as specified in this manual. Failure to do so may impair the protection provided by the equipment.
- Do not perform any services other than those contained in this manual unless you are qualified.

Explosions could result in death or serious injury.

- Verify that the operating atmosphere of the transmitter is consistent with the appropriate hazardous locations certifications.
- Before connecting a handheld communicator in an explosive atmosphere, ensure the instruments are installed in accordance with intrinsically safe or non-incendive field wiring practices.
- Do not remove the gauge cover in explosive atmospheres when the circuit is alive.
- To prevent ignition of flammable or combustible atmospheres, disconnect power before servicing.

Process leaks could result in death or serious injury.

- Ensure that the transmitter is handled carefully. If the process seal is damaged, gas might escape from the tank if the transmitter head is removed from the probe.

High voltage that may be present on leads could cause electrical shock.

- Avoid contact with the leads and terminals.
- Ensure the main power to the transmitter is off and the lines to any other external power source are disconnected or not powered while wiring the transmitter.
- Probes covered with plastic and/or with plastic discs may generate an ignition-capable level of electrostatic charge under certain extreme conditions. Therefore, when the probe is used in a potentially explosive atmosphere, appropriate measures must be taken to prevent electrostatic discharge.
- Eliminate the risk of Electrostatic Discharge (ESD) discharge prior to dismounting the transmitter head. Probes may generate an ignition-capable level of electrostatic charge under extreme conditions. During any type of installation or maintenance in a potentially explosive atmosphere, the responsible person should ensure that any ESD risks are eliminated before attempting to separate the probe from the transmitter head.

Electrical shock could cause death or serious injury.

- Use extreme caution when making contact with the leads and terminals.

Any substitution of non-recognized parts may jeopardize safety. Repair (e.g. substitution of components) may also jeopardize safety and is not allowed under any circumstances.

- Unauthorized changes to the product are strictly prohibited as they may unintentionally and unpredictably alter performance and jeopardize safety. Unauthorized changes that interfere with the integrity of the welds or flanges, such as making additional perforations, compromise product integrity and safety. Equipment ratings and certifications are no longer valid on any products that have been damaged or modified without the prior written permission of Emerson. Any continued use of product that has been damaged or modified without the written authorization is at the customer's sole risk and expense.

⚠ WARNING

Physical access

Unauthorized personnel may potentially cause significant damage to and/or misconfiguration of end users' equipment. This could be intentional or unintentional and needs to be protected against.

Physical security is an important part of any security program and fundamental to protecting your system. Restrict physical access by unauthorized personnel to protect end users' assets. This is true for all systems used within the facility.

⚠ CAUTION

Hot surfaces

The flange and process seal may be hot at high process temperatures. Allow to cool before servicing.



⚠ CAUTION

The products described in this document are NOT designed for nuclear-qualified applications. Using non-nuclear qualified products in applications that require nuclear-qualified hardware or products may cause inaccurate readings. For information on Rosemount nuclear-qualified products, contact your local Emerson Sales Representative.

⚠ CAUTION

This product is designed to meet FCC and R&TTE requirements for a non-intentional radiator. It does not require any licensing whatsoever and has no tank restrictions associated with telecommunications issues.

⚠ CAUTION

This device complies with Part 15 of the FCC Rules. Operation is subject to the following conditions:

- This device may not cause harmful interference.
- This device must accept any interference received, including interference that may cause undesired operation.

Contents

Chapter 1	Before you begin.....	7
	1.1 About this document.....	7
	1.2 About this product.....	7
	1.3 Related documents.....	7
Chapter 2	Installation and commissioning.....	9
	2.1 Safety Instrumented System (SIS) certification.....	9
	2.2 Safety-certified identification.....	9
	2.3 Installation.....	11
	2.4 Configuration.....	12
	2.5 Site acceptance.....	15
Chapter 3	Proof tests.....	17
	3.1 Overview.....	17
	3.2 Prepare for proof-testing.....	18
	3.3 Perform comprehensive proof-test (A).....	19
	3.4 Perform comprehensive, fully remote proof-test (B).....	23
	3.5 Perform comprehensive proof-test using reference reflector (High Level Supervision) (C).....	26
	3.6 Perform comprehensive, fully remote proof-test using reference reflector (High Level Supervision) (D).....	30
	3.7 Perform proof-test using reference reflector (High Level Supervision) (E).....	33
	3.8 Perform fully remote proof-test using reference reflector (High Level Supervision) (F).....	35
	3.9 Perform partial proof-test (G).....	37
Chapter 4	Operating constraints.....	41
	4.1 Specifications.....	41
	4.2 Product repair.....	42
	4.3 Reset to factory settings.....	42
Appendix A	Terms and definitions.....	43

1 Before you begin

1.1 About this document

This document provides information about how to install, commission, and proof-test a Rosemount 5300 Level Transmitter to comply with Safety Instrumented Systems (SIS) requirements.

Note

The following conditions must apply:

- The transmitter has been installed correctly and completely according to the instructions in the Reference Manual and Quick Start Guide.
 - The installation complies with all applicable safety requirements.
 - The operator is trained in local and corporate safety standards.
-

1.2 About this product

The Rosemount 5300 is a two-wire transmitter for continuous level measurements over a broad range of liquids, slurries, and solids. The measurement principle is Time Domain Reflectometry (TDR).

The Rosemount 5300 can be used as the level sensor in a BPCS or as a safety device in a safety instrumented system.

1.2.1 Application examples

- Level range monitoring
- Dry-run prevention
- Overfill prevention

1.3 Related documents

You can find all product documentation at [Emerson.com/Rosemount](https://www.emerson.com/Rosemount).

For more information, see the following documents:

Table 1-1: Related Documentation

Document	Document type
00809-0100-4530	Reference Manual
00813-0100-4530	Product Data Sheet
00825-0100-4530	Quick Start Guide
00809-0900-4530	Manual Supplement : High Level Supervision
00809-1800-4530	Manual Supplement : Cold Temperature Option Code BR5

2 Installation and commissioning

2.1 Safety Instrumented System (SIS) certification

For safety instrumented systems usage, the 4-20 mA analog output is used as the primary safety variable. It is configured to activate the alarm function if an error occurs. If a measured value goes beyond the measurement range, the transmitter enters saturation mode (limit alarm is disabled) or alarm mode, depending on the current configuration. The minimum time for the alarm condition is 200 ms.

The measurement signal used by the logic solver must be the analog 4-20 mA signal proportional to the level generated. The HART[®] protocol can only be used for setup, calibration, and diagnostic purposes, not for safety critical operation.

The Rosemount[™] 5300 Level Transmitter is IEC 61508 certified accordingly:

- Low and high demand: Type B element
- SIL 2 for random integrity @ HFT=0
- SIL 3 for random integrity @ HFT=1
- SIL 3 for systematic capability

2.2 Safety-certified identification

All Rosemount 5300 Level Transmitter must be identified as safety-certified before installing into SIS systems. [Table 2-1](#) lists the versions of the Rosemount 5300 Level Transmitter that have been considered for the hardware assessment, to which this section applies.

- Models with the QS option code are supplied with a manufacturer’s prior use certificate of FMEDA data.
- Models with the QT option code are IEC 61508 certified by an accredited 3rd party agency for use in safety instrumented systems up to SIL 3. (For single use (1oo1) capable up to SIL 2 and for redundant use (1oo2 or 2oo3) capable up to SIL 3.)

Table 2-1: Rosemount 5300 Series Safety-Certified Option Model Codes

Rosemount 5300 4-20 mA HART Guided Wave Radar Level and Interface Transmitter	
Hardware	Model 5301HxxxxxxxxxxxxZZ Model 5302HxxxxxxxxxxxxZZ Model 5303HxxxxxxxxxxxxZZ Note Transmitters will be marked with “QS” or “QT” at the end of the model number in place of ZZ above.
Software/Firmware	2.A1 or higher

2.2.1 Identify a safety-certified transmitter

To identify a Rosemount 5300 Level Transmitter safety-certified transmitter:

Procedure

1. Verify the option code QS or QT in the model code, on the label affixed to the outside of the transmitter head.
2. Check if a yellow label is affixed to the transmitter head for option code QT.

2.3 Installation

Refer to the [Reference Manual](#) for installation instructions. No special installation is required in addition to the standard installation practices outlined in this manual.

The loop must be designed so that the terminal voltage does not drop below the minimum input voltage when the transmitter output is 22.5 mA. See values in [Power supply](#).

Check that environmental conditions do not exceed the ratings provided in the Rosemount 5300 [Product Data Sheet](#).

Note

The Rosemount 5300 Level Transmitter is not safety-rated during maintenance work, configuration changes, multidrop, loop test, proof-test, or other activity that affects the safety function. Alternative means should be used to ensure process safety during such activities.

It is assumed that the personnel installing, configuring, and operating the system have the knowledge equal or greater than that of a qualified Instrument Technician familiar with safety-related systems, process control applications, and general instrument use.

2.3.1 Power supply

Table 2-2: Minimum Input Terminal Voltage (U_i) at Different Currents

Hazardous approval	Current			
	3.60 mA	3.75 mA	21.75 mA	22.50 mA
	Minimum input voltage (U_i)			
Non-Hazardous / Intrinsically Safe / Non-sparking Installations	16 Vdc	16 Vdc	11 Vdc	11 Vdc
Explosion-proof / Flameproof Installations	20 Vdc	20 Vdc	15.5 Vdc	15.5 Vdc

2.4 Configuration

Use a HART-compliant master, such as Rosemount Radar Master, AMS Device Manager, or a handheld communicator, to communicate with and verify configuration of the Rosemount 5300 Level Transmitter.

A full review of configuration methods is available in [Reference Manual](#).


2.4.1 Make sure you are connected to the correct transmitter

Verify that the serial number on the label matches the one in your configuration tool.

Procedure

1. Write down the serial number from the transmitter label.
2. Verify the same serial number in your configuration tool.
 - Rosemount Radar Master:
 - Select **Device** → **Properties**.

Figure 2-1: Device Properties Window



- A. *Serial No*
- B. *Software/Firmware*
- C. *Safety Device (QS option)*

- AMS Device Manager and handheld communicator:
 - Select **Overview** → **Device Information** → **Identification**.

Postrequisites

Be sure to enable write protection as soon as you are finished.


2.4.2 Configure device using Guided Setup

Follow the Guided Setup wizard for transmitter configuration. When configuring parameters not included in the Guided Setup, it may be necessary to do additional verification.

Configure using Rosemount Radar Master

Procedure

1. Start Rosemount Radar Master.
2. Connect to the desired transmitter.
3. In the *Guided Setup* window, click **Run Wizard for guided setup** and follow the instructions.




4. In the *Guided Setup* window, continue with steps 2 to 5.
5. Click **View live values from device** to verify that the transmitter works correctly.

Configure using AMS Device Manager or handheld communicator

Connect to device using AMS Device Manager

Procedure

1. Start AMS Device Manager.
2. Select **View** → **Device Connection View**.
3. In the *Device Connection View*, double-click the modem icon.
4. Double-click the device icon.



Connect to device using a handheld communicator

Procedure

Turn on the handheld communicator and connect to the device.

Configure HART® devices

Procedure

1. Select **Configure** → **Guided Setup**.
2. Select **Level Measurement Setup** and follow the instructions.
3. Select **Device Specific Setup**.
4. Run **Verify Level** to check your level measurement.
5. (Optional) Select **Volume Setup**.
6. (Optional) Select **Display Setup**.

2.4.3 Damping

User adjusted damping will affect the transmitter's ability to respond to process changes. Therefore, the *damping values + response time* should not exceed the loop requirements. For further information on damping, see [Reference Manual](#).

2.4.4 Write protection

A Rosemount 5300 Level Transmitter safety-certified transmitter should always be protected from unintentional configuration changes by a password protected function. It is recommended to use write protection described in [Reference Manual](#).

2.4.5 Alarm and saturation levels


DCS or safety logic solver should be configured to handle both High alarm and Low alarm. In addition, the transmitter must be configured for High or Low alarm.

Note

In certain cases, the transmitter does not go into the user defined alarm state. For example, in case of a short circuit, the transmitter goes into High Alarm state even if Low Alarm has been configured.

[Figure 2-2](#) identifies the alarm levels available and their operation values.

Figure 2-2: Alarm Levels and Operation Values



- A. Rosemount Alarm Level
- B. Normal Operation
- C. Namur Alarm Level

1. Transmitter Failure, hardware or software alarm in Low position.
2. Transmitter Failure, hardware or software alarm in High position.
3. Low saturation
4. High saturation

It is assumed that the current output signal is fed to a SIL 2-compliant analog input board of a safety logic solver. For instructions on alarm level settings see [Reference Manual](#).

Note

Only the High or Low Alarm Mode can be used for the safety function. Do not choose Freeze Current.

2.5 Site acceptance

After installation and/or configuration, proper operation of the transmitter (including verification of all configuration changes) must be verified. A site acceptance test is therefore recommended. The proof tests can be used for this.

3 Proof tests

3.1 Overview

The Rosemount 5300 Level Transmitter must be tested at regular intervals to reveal faults which are undetected by automatic diagnostics. It is the user's responsibility to choose the type of testing and the frequency of these tests.

Results from periodic proof tests shall be recorded and periodically reviewed. If an error is found in the safety functionality, the transmitter shall be put out of operation and the process shall be kept in a safe state by other measures.

Note

For a valid result, always perform the proof test on the product that will be stored in the tank while the device is in operation.

The following proof-tests are suggested:

- (A) Comprehensive proof-test
- (B) Comprehensive, fully remote proof-test
- (C) Comprehensive proof-test using reference reflector (High Level Supervision)
- (D) Comprehensive fully remote proof-test using reference reflector (High Level Supervision)
- (E) Proof-test using reference reflector (High Level Supervision)
- (F) Fully remote proof-test using reference reflector (High Level Supervision)
- (G) Partial proof-test

Table 3-1 can be used as a guidance for selecting the appropriate proof-test.

Table 3-1: Proof-Tests

Proof-test #	Type	Proof-test coverage (%) of DU	Remaining DU failures	Remaining DU failures, with option code BR5	Test coverage		Can be performed remotely
					Output circuitry	Measurement electronics	
A	Comprehensive	94%	6 FIT	6 FIT	Y	Y	No
B	Comprehensive	85%	14 FIT	16 FIT	Y	Y	Yes
C	Comprehensive	94%	6 FIT	6 FIT	Y	Y	No
D	Comprehensive	86%	13 FIT	15 FIT	Y	Y	Yes
E	Partial	82%	17 FIT	19 FIT	N	Y	No
F	Partial	74%	25 FIT	27 FIT	N	Y	Yes
G	Partial	55%	43 FIT	47 FIT	Y	N	Yes

3.1.1 Proof test interval

The time intervals for proof testing are defined by the SIL verification calculation (subject to the PFD_{AVG}). The SIL verification calculation is an analytical method to calculate an appropriate proof test interval for the specific safety function based on equipment's reliability and required risk reduction for the specific SIF.

The proof tests must be performed more frequently than or as frequently as specified in the SIL verification calculation, in order to maintain the required safety integrity of the overall SIF.

3.1.2 Tools required

- HART host/communicator or Rosemount Radar Master
- Current meter
- Safety logic solver
- Independent measuring device (e.g. BPCS level sensor, measuring tape)

3.2 Prepare for proof-testing

3.2.1 Prepare for proof-testing using Rosemount Radar Master

Note that prior to these tests, inspect the echo curve to ensure that no disturbing echoes affecting the measurement performance are present.

Procedure

Select **Setup** → **Echo Curve**.

3.2.2 Prepare for proof-testing using AMS Device Manager and handheld communicator

Note that prior to these tests, inspect the echo curve to ensure that no disturbing echoes affecting the measurement performance are present.

Procedure

Select **Service Tools** → **Echo Tuning** → **Echo Curve**.

3.3 Perform comprehensive proof-test (A)

3.3.1 Perform comprehensive proof-test (A) with Rosemount Radar Master

Prerequisites

⚠ WARNING

During the proof-test, the transmitter will not output measurement values corresponding to the product surface level. Ensure systems and people relying on measurement values from the transmitter are made aware of the changed conditions. Failure to do so could result in death, serious injury and/or property damage.

Procedure

1. Bypass the safety function and take appropriate action to avoid a false trip.
2. Disable write protection in device (if enabled).
 - a) Select **Tools** → **Lock/Unlock Configuration Area**.
 - b) Enter password to unlock.
3. Using Loop Test, enter current value (mA) representing high alarm current. Verify that analog output current is correct using the reference meter.
 - a) Select **Setup** → **Output** → **Analog Out 1** and click **Loop test**.
 - b) Enter current value representing high alarm current.
 - c) Click **Start** to output current.
 - d) Verify that analog output current is correct.
 - e) Click **Stop** to end loop test.
4. Using Loop Test, enter current value (mA) representing low alarm current. Verify that analog output current is correct using the reference meter.

This step tests for possible quiescent current related failures.


 - a) Select **Setup** → **Output** → **Analog Out 1** and click **Loop test**.
 - b) Enter current value representing low alarm current.
 - c) Click **Start** to output current.
 - d) Verify that analog output current is correct.
 - e) Click **Stop** to end loop test.
5. Enable write protection.
 - a) Select **Tools** → **Lock/Unlock Configuration Area**.
 - b) Enter password to lock.
6. Inspect the transmitter for any leaks, visible damage, or contamination.

7. Perform a one-point level measurement verification of the device. Verify the current level measurement with an independent measurement such as the BPCS level-sensor or a manual reading.

This step verifies that the analog output is correct in the operating range and that the Primary Variable is properly configured.

Note that the applied level has to be between Upper and Lower Range values, otherwise the device enters alarm mode. If level is outside Maximum Measuring Range, the level reading accuracy may be reduced. For best performance, use the 4-20 mA range points as calibration points. See [Figure 3-1](#).

Figure 3-1: Range Values



- A. Upper Reference Point
- B. Upper Blind Zone
- C. Reduced Accuracy
- D. Maximum Measuring Range
- E. Lower Blind Zone
- F. 20mA
- G. Range 0 -100 %
- H. 4mA
- I. Zero Reference Point

8. Remove the bypass and otherwise restore normal operation.
For troubleshooting the transmitter, see [Reference Manual](#).

3.3.2 Perform comprehensive proof-test (A) with AMS Device Manager and handheld communicator

Prerequisites

⚠ WARNING

During the proof-test, the transmitter will not output measurement values corresponding to the product surface level. Ensure systems and people relying on measurement values from the transmitter are made aware of the changed conditions. Failure to do so could result in death, serious injury and/or property damage.

Procedure

1. Bypass the safety function and take appropriate action to avoid a false trip.
2. Disable write protection in device (if enabled).
 - a) Select **Configure** → **Manual Setup** → **Device Setup** → **Security**.
 - b) Click **Write Protect** and follow the instructions.
3. Using Loop Test, enter current value (mA) representing high alarm current. Verify that analog output current is correct using the reference meter.
 - a) Select **Configure** → **Manual Setup** → **Device Setup** → **Analog Output**.
 - b) Click **Loop Test** and select **Other**.
 - c) Enter current value representing high alarm current.
 - d) Verify that analog output current is correct.
 - e) Click **Abort** to end loop test.
4. Using Loop Test, enter current value (mA) representing low alarm current. Verify that analog output current is correct using the reference meter.

This step tests for possible quiescent current related failures.

 - a) Select **Configure** → **Manual Setup** → **Device Setup** → **Analog Output**.
 - b) Click **Loop Test** and select **Other**.
 - c) Enter current value representing low alarm current.
 - d) Verify that analog output current is correct.
 - e) Click **Abort** to end loop test.
5. Enable write protection.
 - a) Select **Configure** → **Manual Setup** → **Device Setup** → **Security**.
 - b) Click **Write Protect** and follow the instructions.
6. Inspect the transmitter for any leaks, visible damage, or contamination.

7. Perform a one-point level measurement verification of the device. Verify the current level measurement with an independent measurement such as the BPCS level-sensor or a manual reading.

This step verifies that the analog output is correct in the operating range and that the Primary Variable is properly configured.

Note that the applied level has to be between Upper and Lower Range values, otherwise the device enters alarm mode. If level is outside Maximum Measuring Range, the level reading accuracy may be reduced. For best performance, use the 4-20 mA range points as calibration points. See [Figure 3-1](#).

8. Remove the bypass and otherwise restore normal operation.
For troubleshooting the transmitter, see [Reference Manual](#).

3.4 Perform comprehensive, fully remote proof-test (B)

3.4.1 Perform comprehensive, fully remote proof-test (B) with Rosemount Radar Master

Prerequisites

⚠ WARNING

During the proof-test, the transmitter will not output measurement values corresponding to the product surface level. Ensure systems and people relying on measurement values from the transmitter are made aware of the changed conditions. Failure to do so could result in death, serious injury and/or property damage.

Procedure

1. Bypass the safety function and take appropriate action to avoid a false trip.
2. Disable write protection in device (if enabled).
 - a) Select **Tools** → **Lock/Unlock Configuration Area**.
 - b) Enter password to unlock.
3. Using Loop Test, enter current value (mA) representing high alarm current. Verify that analog output current is correct using the reference meter.
 - a) Select **Setup** → **Output** → **Analog Out 1** and click **Loop test**.
 - b) Enter current value representing high alarm current.
 - c) Click **Start** to output current.
 - d) Verify that analog output current is correct.
 - e) Click **Stop** to end loop test.
4. Using Loop Test, enter current value (mA) representing low alarm current. Verify that analog output current is correct using the reference meter.
 - a) Select **Setup** → **Output** → **Analog Out 1** and click **Loop test**.
 - b) Enter current value representing low alarm current.
 - c) Click **Start** to output current.
 - d) Verify that analog output current is correct.
 - e) Click **Stop** to end loop test.
5. Enable write protection.
 - a) Select **Tools** → **Lock/Unlock Configuration Area**.
 - b) Enter password to lock.

6. Perform a one-point level measurement verification of the device. Verify the current level measurement with an independent measurement such as the BPCS level-sensor or a manual reading.
7. Remove the bypass and otherwise restore normal operation.
For troubleshooting the transmitter, see [Reference Manual](#).

3.4.2 Perform comprehensive, fully remote proof-test (B) with AMS Device Manager and handheld communicator

Prerequisites

WARNING

During the proof-test, the transmitter will not output measurement values corresponding to the product surface level. Ensure systems and people relying on measurement values from the transmitter are made aware of the changed conditions. Failure to do so could result in death, serious injury and/or property damage.

Procedure

1. Bypass the safety function and take appropriate action to avoid a false trip.
2. Disable write protection in device (if enabled).
 - a) Select **Configure** → **Manual Setup** → **Device Setup** → **Security**.
 - b) Click **Write Protect** and follow the instructions.
3. Using Loop Test, enter current value (mA) representing high alarm current. Verify that analog output current is correct using the reference meter.
 - a) Select **Configure** → **Manual Setup** → **Device Setup** → **Analog Output**.
 - b) Click **Loop Test** and select **Other**.
 - c) Enter current value representing high alarm current.
 - d) Verify that analog output current is correct.
 - e) Click **Abort** to end loop test.
4. Using Loop Test, enter current value (mA) representing low alarm current. Verify that analog output current is correct using the reference meter.
 - a) Select **Configure** → **Manual Setup** → **Device Setup** → **Analog Output**.
 - b) Click **Loop Test** and select **Other**.
 - c) Enter current value representing low alarm current.
 - d) Verify that analog output current is correct.
 - e) Click **Abort** to end loop test.

5. Enable write protection.
 - a) Select **Configure** → **Manual Setup** → **Device Setup** → **Security**.
 - b) Click **Write Protect** and follow the instructions.
6. Perform a one-point level measurement verification of the device. Verify the current level measurement with an independent measurement such as the BPCS level-sensor or a manual reading.
7. Remove the bypass and otherwise restore normal operation.
For troubleshooting the transmitter, see [Reference Manual](#).

3.5 Perform comprehensive proof-test using reference reflector (High Level Supervision) (C)

3.5.1 Perform comprehensive proof-test using reference reflector (High Level Supervision) (C) with Rosemount Radar Master

Prerequisites

⚠ WARNING

During the proof-test, the transmitter will not output measurement values corresponding to the product surface level. Ensure systems and people relying on measurement values from the transmitter are made aware of the changed conditions. Failure to do so could result in death, serious injury and/or property damage.

Prerequisites

This proof-test can only be performed on devices with Verification reflectors (high level supervision) option code HL1, HL2 or HL3.

Procedure

1. Bypass the safety function and take appropriate action to avoid a false trip.
2. Disable write protection in device (if enabled).
 - a) Select **Tools** → **Lock/Unlock Configuration Area**.
 - b) Enter password to unlock.
3. Using Loop Test, enter current value (mA) representing high alarm current. Verify that analog output current is correct using the reference meter.
 - a) Select **Setup** → **Output** → **Analog Out 1** and click **Loop test**.
 - b) Enter current value representing high alarm current.
 - c) Click **Start** to output current.
 - d) Verify that analog output current is correct.
 - e) Click **Stop** to end loop test.

4. Using Loop Test, enter current value (mA) representing low alarm current. Verify that analog output current is correct using the reference meter.
 - a) Select **Setup** → **Output** → **Analog Out 1** and click **Loop test**.
 - b) Enter current value representing low alarm current.
 - c) Click **Start** to output current.
 - d) Verify that analog output current is correct.
 - e) Click **Stop** to end loop test.
5. Enable write protection.
 - a) Select **Tools** → **Lock/Unlock Configuration Area**.
 - b) Enter password to lock.
6. Perform High Level Supervision test.
 - a) Select **Setup** → **Advanced**.
 - b) Select the **Level Supervision** tab.
 - c) Select **Start/Stop Test Mode**.
 - d) Verify that the output from the device corresponds to the alarm limit in the host system.
 - e) End test mode by clicking **Start/Stop Test Mode**.
The device will automatically exit the test mode after 30 minutes (default).
7. Inspect the transmitter for any leaks, visible damage, or contamination.
8. Remove the bypass and otherwise restore normal operation.
For more information on the High Level Supervision, refer to Rosemount 5300 Level Transmitter High Level Supervision [Manual Supplement](#).
For troubleshooting the transmitter, see [Reference Manual](#).

3.5.2 Perform comprehensive proof-test using reference reflector (High Level Supervision) (C) with AMS Device Manager and handheld communicator

Prerequisites

⚠ WARNING

During the proof-test, the transmitter will not output measurement values corresponding to the product surface level. Ensure systems and people relying on measurement values from the transmitter are made aware of the changed conditions. Failure to do so could result in death, serious injury and/or property damage.

Prerequisites

This proof test can only be performed on devices with Verification reflectors (high level supervision) option code HL1, HL2 or HL3.

Procedure

1. Bypass the safety function and take appropriate action to avoid a false trip.
2. Disable write protection in device (if enabled).
 - a) Select **Configure** → **Manual Setup** → **Device Setup** → **Security**.
 - b) Click **Write Protect** and follow the instructions.
3. Using Loop Test, enter current value (mA) representing high alarm current. Verify that analog output current is correct using the reference meter.
 - a) Select **Configure** → **Manual Setup** → **Device Setup** → **Analog Output**.
 - b) Click **Loop Test** and select **Other**.
 - c) Enter current value representing high alarm current.
 - d) Verify that analog output current is correct.
 - e) Click **Abort** to end loop test.
4. Using Loop Test, enter current value (mA) representing low alarm current. Verify that analog output current is correct using the reference meter.
 - a) Select **Configure** → **Manual Setup** → **Device Setup** → **Analog Output**.
 - b) Click **Loop Test** and select **Other**.
 - c) Enter current value representing low alarm current.
 - d) Verify that analog output current is correct.
 - e) Click **Abort** to end loop test.
5. Enable write protection.
 - a) Select **Configure** → **Manual Setup** → **Device Setup** → **Security**.
 - b) Click **Write Protect** and follow the instructions.
6. Perform High Level Supervision test.
 - a) Select **Configure** → **Alert Setup** → **Level Supervision**.
 - b) Select **Start/Stop Test Mode**.
 - c) Verify that the output from the device corresponds to the alarm limit in the host system.
 - d) End test mode by clicking **Start/Stop Test Mode**.
The device will automatically exit the test mode after 30 minutes (default).
7. Inspect the transmitter for any leaks, visible damage, or contamination.

8. Remove the bypass and otherwise restore normal operation.
For more information on the High Level Supervision, refer to Rosemount 5300 Level Transmitter High Level Supervision [Manual Supplement](#).
For troubleshooting the transmitter, see [Reference Manual](#).

3.6 Perform comprehensive, fully remote proof-test using reference reflector (High Level Supervision) (D)

3.6.1 Perform comprehensive, fully remote proof-test using reference reflector (High Level Supervision) (D) with Rosemount Radar Master

Prerequisites

⚠ WARNING

During the proof-test, the transmitter will not output measurement values corresponding to the product surface level. Ensure systems and people relying on measurement values from the transmitter are made aware of the changed conditions. Failure to do so could result in death, serious injury and/or property damage.

Prerequisites

This proof-test can only be performed on devices with Verification reflectors (high level supervision) option code HL1, HL2 or HL3.

Procedure

1. Bypass the safety function and take appropriate action to avoid a false trip.
2. Disable write protection in device (if enabled).
 - a) Select **Tools** → **Lock/Unlock Configuration Area**.
 - b) Enter password to unlock.
3. Using Loop Test, enter current value (mA) representing high alarm current. Verify that analog output current is correct using the reference meter.
 - a) Select **Setup** → **Output** → **Analog Out 1** and click **Loop test**.
 - b) Enter current value representing high alarm current.
 - c) Click **Start** to output current.
 - d) Verify that analog output current is correct.
 - e) Click **Stop** to end loop test.

4. Using Loop Test, enter current value (mA) representing low alarm current. Verify that analog output current is correct using the reference meter.
 - a) Select **Setup** → **Output** → **Analog Out 1** and click **Loop test**.
 - b) Enter current value representing low alarm current.
 - c) Click **Start** to output current.
 - d) Verify that analog output current is correct.
 - e) Click **Stop** to end loop test.
5. Enable write protection.
 - a) Select **Tools** → **Lock/Unlock Configuration Area**.
 - b) Enter password to lock.
6. Perform High Level Supervision test.
 - a) Select **Setup** → **Advanced**.
 - b) Select the **Level Supervision** tab.
 - c) Select **Start/Stop Test Mode**.
 - d) Verify that the output from the device corresponds to the alarm limit in the host system.
 - e) End test mode by clicking **Start/Stop Test Mode**.
The device will automatically exit the test mode after 30 minutes [default].
7. Remove the bypass and otherwise restore normal operation.
For more information on the High Level Supervision, refer to Rosemount 5300 Level Transmitter High Level Supervision [Manual Supplement](#).
For troubleshooting the transmitter, see [Reference Manual](#).

3.6.2 Perform comprehensive, fully remote proof-test using reference reflector (High Level Supervision) (D) with AMS Device Manager and handheld communicator

Prerequisites

⚠ WARNING

During the proof-test, the transmitter will not output measurement values corresponding to the product surface level. Ensure systems and people relying on measurement values from the transmitter are made aware of the changed conditions. Failure to do so could result in death, serious injury and/or property damage.

Prerequisites

This proof-test can only be performed on devices with Verification reflectors (high level supervision) option code HL1, HL2 or HL3.

Procedure

1. Bypass the safety function and take appropriate action to avoid a false trip.
2. Disable write protection in device (if enabled).
 - a) Select **Configure** → **Manual Setup** → **Device Setup** → **Security**.
 - b) Click **Write Protect** and follow the instructions.
3. Using Loop Test, enter current value (mA) representing high alarm current. Verify that analog output current is correct using the reference meter.
 - a) Select **Configure** → **Manual Setup** → **Device Setup** → **Analog Output**.
 - b) Click **Loop Test** and select **Other**.
 - c) Enter current value representing high alarm current.
 - d) Verify that analog output current is correct.
 - e) Click **Abort** to end loop test.
4. Using Loop Test, enter current value (mA) representing low alarm current. Verify that analog output current is correct using the reference meter.
 - a) Select **Configure** → **Manual Setup** → **Device Setup** → **Analog Output**.
 - b) Click **Loop Test** and select **Other**.
 - c) Enter current value representing low alarm current.
 - d) Verify that analog output current is correct.
 - e) Click **Abort** to end loop test.
5. Enable write protection.
 - a) Select **Configure** → **Manual Setup** → **Device Setup** → **Security**.
 - b) Click **Write Protect** and follow the instructions.
6. Perform High Level Supervision test.
 - a) Select **Configure** → **Alert Setup** → **Level Supervision**.
 - b) Select **Start/Stop Test Mode**.
 - c) Verify that the output from the device corresponds to the alarm limit in the host system.
 - d) End test mode by clicking **Start/Stop Test Mode**.
The device will automatically exit the test mode after 30 minutes [default].
7. Remove the bypass and otherwise restore normal operation.
For more information on the High Level Supervision, refer to Rosemount 5300 Level Transmitter High Level Supervision [Manual Supplement](#).
For troubleshooting the transmitter, see [Reference Manual](#).

3.7 Perform proof-test using reference reflector (High Level Supervision) (E)

3.7.1 Perform proof-test using reference reflector (High Level Supervision) (E) with Rosemount Radar Master

Prerequisites

⚠ WARNING

During the proof-test, the transmitter will not output measurement values corresponding to the product surface level. Ensure systems and people relying on measurement values from the transmitter are made aware of the changed conditions. Failure to do so could result in death, serious injury and/or property damage.

Prerequisites

This proof-test can only be performed on devices with Verification reflectors (high level supervision) option code HL1, HL2 or HL3.

Procedure

1. Bypass the safety function and take appropriate action to avoid a false trip.
2. Perform High Level Supervision test.
 - a) Select **Setup** → **Advanced**.
 - b) Select the **Level Supervision** tab.
 - c) Select **Start/Stop Test Mode**.
 - d) Verify that the output from the device corresponds to the alarm limit in the host system.
 - e) End test mode by clicking **Start/Stop Test Mode**.
The device will automatically exit the test mode after 30 minutes [default].
3. Inspect the transmitter for any leaks, visible damage, or contamination.
4. Remove the bypass and otherwise restore normal operation.
For more information on the High Level Supervision, refer to Rosemount 5300 Level Transmitter High Level Supervision [Manual Supplement](#).
For troubleshooting the transmitter, see [Reference Manual](#).

3.7.2 Perform proof-test using reference reflector (High Level Supervision) (E) with AMS Device Manager and handheld communicator

Prerequisites

⚠ WARNING

During the proof-test, the transmitter will not output measurement values corresponding to the product surface level. Ensure systems and people relying on measurement values from the transmitter are made aware of the changed conditions. Failure to do so could result in death, serious injury and/or property damage.

Prerequisites

This proof-test can only be performed on devices with Verification reflectors (high level supervision) option code HL1, HL2 or HL3.

Procedure

1. Bypass the safety function and take appropriate action to avoid a false trip.
2. Perform High Level Supervision test.
 - a) Select **Configure** → **Alert Setup** → **Level Supervision**.
 - b) Select **Start/Stop Test Mode**.
 - c) Verify that the output from the device corresponds to the alarm limit in the host system.
 - d) End test mode by clicking **Start/Stop Test Mode**.
The device will automatically exit the test mode after 30 minutes [default].
3. Inspect the transmitter for any leaks, visible damage, or contamination.
4. Remove the bypass and otherwise restore normal operation.
For more information on the High Level Supervision, refer to Rosemount 5300 Level Transmitter High Level Supervision [Manual Supplement](#).
For troubleshooting the transmitter, see [Reference Manual](#).

3.8 Perform fully remote proof-test using reference reflector (High Level Supervision) (F)

3.8.1 Perform fully remote proof-test using reference reflector (High Level Supervision) (F) with Rosemount Radar Master

Prerequisites

⚠ WARNING

During the proof-test, the transmitter will not output measurement values corresponding to the product surface level. Ensure systems and people relying on measurement values from the transmitter are made aware of the changed conditions. Failure to do so could result in death, serious injury and/or property damage.

Prerequisites

This proof-test can only be performed on devices with Verification reflectors (high level supervision) option code HL1, HL2 or HL3.

Procedure

1. Bypass the safety function and take appropriate action to avoid a false trip.
2. Perform High Level Supervision test.
 - a) Select **Setup** → **Advanced**.
 - b) Select the **Level Supervision** tab.
 - c) Select **Start/Stop Test Mode**.
 - d) Verify that the output from the device corresponds to the alarm limit in the host system.
 - e) End test mode by clicking **Start/Stop Test Mode**.
The device will automatically exit the test mode after 30 minutes [default].
3. Remove the bypass and otherwise restore normal operation.
For more information on the High Level Supervision, refer to Rosemount 5300 Level Transmitter High Level Supervision [Manual Supplement](#).
For troubleshooting the transmitter, see [Reference Manual](#).

3.8.2 Perform fully remote proof-test using reference reflector (High Level Supervision) (F) with AMS Device Manager and handheld communicator

Prerequisites

⚠ WARNING

During the proof-test, the transmitter will not output measurement values corresponding to the product surface level. Ensure systems and people relying on measurement values from the transmitter are made aware of the changed conditions. Failure to do so could result in death, serious injury and/or property damage.

Prerequisites

This proof-test can only be performed on devices with Verification reflectors (high level supervision) option code HL1, HL2 or HL3.

Procedure

1. Bypass the safety function and take appropriate action to avoid a false trip.
2. Perform High Level Supervision test.
 - a) Select **Configure** → **Alert Setup** → **Level Supervision**.
 - b) Select **Start/Stop Test Mode**.
 - c) Verify that the output from the device corresponds to the alarm limit in the host system.
 - d) End test mode by clicking **Start/Stop Test Mode**.
The device will automatically exit the test mode after 30 minutes [default].
3. Remove the bypass and otherwise restore normal operation.
For more information on the High Level Supervision, refer to Rosemount 5300 Level Transmitter High Level Supervision [Manual Supplement](#).
For troubleshooting the transmitter, see [Reference Manual](#).

3.9 Perform partial proof-test (G)

3.9.1 Perform partial proof-test (G) with Rosemount Radar Master

Prerequisites

⚠ WARNING

During the proof-test, the transmitter will not output measurement values corresponding to the product surface level. Ensure systems and people relying on measurement values from the transmitter are made aware of the changed conditions. Failure to do so could result in death, serious injury and/or property damage.

Procedure

1. Bypass the safety function and take appropriate action to avoid a false trip.
2. Disable write protection in device (if enabled).
 - a) Select **Tools** → **Lock/Unlock Configuration Area**.
 - b) Enter password to unlock.
3. Using Loop Test, enter current value (mA) representing high alarm current. Verify that analog output current is correct using the reference meter.
 - a) Select **Setup** → **Output** → **Analog Out 1** and click **Loop test**.
 - b) Enter current value representing high alarm current.
 - c) Click **Start** to output current.
 - d) Verify that analog output current is correct.
 - e) Click **Stop** to end loop test.
4. Using Loop Test, enter current value (mA) representing low alarm current. Verify that analog output current is correct using the reference meter.
 - a) Select **Setup** → **Output** → **Analog Out 1** and click **Loop test**.
 - b) Enter current value representing low alarm current.
 - c) Click **Start** to output current.
 - d) Verify that analog output current is correct.
 - e) Click **Stop** to end loop test.
5. Enable write protection.
 - a) Select **Tools** → **Lock/Unlock Configuration Area**.
 - b) Enter password to lock.

6. Remove the bypass and otherwise restore normal operation.
For troubleshooting the transmitter, see [Reference Manual](#).

3.9.2 Perform partial proof-test (G) with AMS Device Manager and handheld communicator

Prerequisites

⚠ WARNING

During the proof-test, the transmitter will not output measurement values corresponding to the product surface level. Ensure systems and people relying on measurement values from the transmitter are made aware of the changed conditions. Failure to do so could result in death, serious injury and/or property damage.

Procedure

1. Bypass the safety function and take appropriate action to avoid a false trip.
2. Disable write protection in device (if enabled).
 - a) Select **Configure** → **Manual Setup** → **Device Setup** → **Security**.
 - b) Click **Write Protect** and follow the instructions.
3. Using Loop Test, enter current value (mA) representing high alarm current. Verify that analog output current is correct using the reference meter.
 - a) Select **Configure** → **Manual Setup** → **Device Setup** → **Analog Output**.
 - b) Click **Loop Test** and select **Other**.
 - c) Enter current value representing high alarm current.
 - d) Verify that analog output current is correct.
 - e) Click **Abort** to end loop test.
4. Using Loop Test, enter current value (mA) representing low alarm current. Verify that analog output current is correct using the reference meter.
 - a) Select **Configure** → **Manual Setup** → **Device Setup** → **Analog Output**.
 - b) Click **Loop Test** and select **Other**.
 - c) Enter current value representing low alarm current.
 - d) Verify that analog output current is correct.
 - e) Click **Abort** to end loop test.
5. Enable write protection.
 - a) Select **Configure** → **Manual Setup** → **Device Setup** → **Security**.
 - b) Click **Write Protect** and follow the instructions.

6. Remove the bypass and otherwise restore normal operation.
For troubleshooting the transmitter, see [Reference Manual](#).

4 Operating constraints

4.1 Specifications

The Rosemount 5300 Level Transmitter must be operated according to the functional and performance specifications provided in the Rosemount 5300 Level Transmitter [Product Data Sheet](#).

4.1.1 Measuring range

Up to 164 ft (50 m)

4.1.2 Failure rate data

The [FMEDA report](#) includes failure rate data, assessment details, and assumptions regarding failure rate analysis.

4.1.3 Safety deviation

2.0 %⁽¹⁾

4.1.4 Transmitter response time

At least below 8 seconds for specific configurations

Higher Transmitter response time is allowed for other user-selectable configurations, for example damping, level rate etc. See [Reference Manual](#) for more information.

4.1.5 Diagnostic test interval

< 90 minutes

4.1.6 Start-up time

< 40 s⁽²⁾

4.1.7 Useful lifetime

50 years

- based on worst case component wear-out mechanisms
- not based on wear-out of process wetted materials

(1) The safety deviation of the Rosemount 5300 Level Transmitter safety-certified option is $\pm 2\%$ of full span (± 0.32 mA).

(2) The start-up time is extended with five additional minutes for option code BR5 at temperatures below -40°F (-40°C). Refer to Rosemount 5300 Cold Temperature Option Code BR5 [Manual Supplement](#).

4.2 Product repair

The Rosemount 5300 Level Transmitter is repairable by major component replacement. All failures detected by the transmitter diagnostics or by the proof test must be reported. Feedback can be submitted electronically at [Go.EmersonAutomation.com/Contact-Us](https://www.emerson.com/go/contact-us) (Contact Us).

4.3 Reset to factory settings

Transmitters with option code QS or QT are shipped with a special factory pre-configuration. If the device needs to be reset to factory settings, please contact your local Emerson representative to get the factory pre-configuration file to be uploaded to the device or use the backup file created upon receiving the transmitter. This will ensure the proper settings for your safety device are configured and your QS or QT certificate is still valid.

A Terms and definitions

Table A-1: Terms and Definitions

Term	Definition
BPCS	Basic Process Control System
DU	Dangerous Undetected
Diagnostic test interval	The time from when a dangerous failure/condition occurs until the device has set the safety related output in a safe state (total time required for fault detection and fault reaction).
FIT	Failure In Time per billion hours
FMEDA	Failure Modes, Effects and Diagnostic Analysis
HART®	Highway Addressable Remote Transducer
HFT	Hardware Fault Tolerance
High demand mode	The safety function is only performed on demand, in order to transfer the EUC (Equipment Under Control) into a specified safe state, and where the frequency of demands is greater than one per year (IEC 61508-4).
Low demand mode	The safety function is only performed on demand, in order to transfer the EUC into a specified safe state, and where the frequency of demands is no greater than one per year (IEC 61508-4).
PFD _{AVG}	Average Probability of Failure on Demand
Proof test coverage factor	The effectiveness of a proof test is described using the coverage factor which specifies the share of detected dangerous undetected failures (λ_{DU}). The coverage factor is an indication of a proof test's effectiveness to detect dangerous undetected faults.
Safety deviation	<p>The maximum allowed deflection of the safety output due to a failure within the device (expressed as a percentage of span).</p> <p>Any failure causing the device output to change less than the Safety Deviation is considered as a "No Effect" failure. All failures causing the device output to change more than the Safety Deviation and with the device output still within the active range (non-alarm state) are considered dangerous failures.</p> <p>Note that the Safety Deviation is independent of the normal performance specification or any additional application specific measurement error.</p>
SFF	Safe Failure Fraction
SIF	Safety Instrumented Function

Table A-1: Terms and Definitions (continued)

Term	Definition
SIL	Safety Integrity Level – a discrete level (one out of four) for specifying the safety integrity requirements of the safety instrumented functions to be allocated to the safety instrumented systems. SIL 4 has the highest level of safety integrity, and SIL 1 has the lowest level.
SIS	Safety Instrumented System – an instrumented system used to implement one or more safety instrumented functions. An SIS is composed of any combination of sensors, logic solvers, and final elements.
Systematic Capability	Systematic Capability is a measure (expressed on a scale of SC 1 to SC 4) of the confidence that the systematic safety integrity of an element meets the requirements of the specified SIL, in respect of the specified element safety function, when the element is applied in accordance with the instructions specified in the compliant item safety manual for the element.
Safety Response Time	The delay between a change in the measured process and the indication of that change at the safety-rated output.
Transmitter response time	The time from a step change in the process until transmitter output reaches 90% of its final steady state value (step response time as per IEC 61298-2).
Type B device	Complex device using controllers or programmable logic, as defined by the standard IEC 61508.
Useful lifetime	Useful lifetime is a reliability engineering term that describes the operational time interval where the failure rate of a device is relatively constant. It is not a term which covers product obsolescence, warranty, or other commercial issues.

Emerson Automation Solutions

6021 Innovation Blvd.
Shakopee, MN 55379, USA
📞 +1 800 999 9307 or +1 952 906 8888
📠 +1 952 949 7001
✉️ RFQ.RMD-RCC@Emerson.com

North America Regional Office

Emerson Automation Solutions
8200 Market Blvd.
Chanhassen, MN 55317, USA
📞 +1 800 999 9307 or +1 952 906 8888
📠 +1 952 949 7001
✉️ RMT-NA.RCCRFQ@Emerson.com

Latin America Regional Office

Emerson Automation Solutions
1300 Concord Terrace, Suite 400
Sunrise, FL 33323, USA
📞 +1 954 846 5030
📠 +1 954 846 5121
✉️ RFQ.RMD-RCC@Emerson.com

Europe Regional Office


Emerson Automation Solutions Europe
GmbH
Neuhofstrasse 19a P.O. Box 1046
CH 6340 Baar
Switzerland
📞 +41 (0) 41 768 6111
📠 +41 (0) 41 768 6300
✉️ RFQ.RMD-RCC@Emerson.com


Asia Pacific Regional Office

Emerson Automation Solutions
1 Pandan Crescent
Singapore 128461
📞 +65 6777 8211
📠 +65 6777 0947
✉️ Enquiries@AP.Emerson.com


Middle East and Africa Regional Office

Emerson Automation Solutions
Emerson FZE P.O. Box 17033
Jebel Ali Free Zone - South 2
Dubai, United Arab Emirates
📞 +971 4 8118100
📠 +971 4 8865465
✉️ RFQ.RMTMEA@Emerson.com

 [Linkedin.com/company/Emerson-Automation-Solutions](https://www.linkedin.com/company/Emerson-Automation-Solutions)

 [Twitter.com/Rosemount_News](https://twitter.com/Rosemount_News)

 [Facebook.com/Rosemount](https://www.facebook.com/Rosemount)

 [Youtube.com/user/RosemountMeasurement](https://www.youtube.com/user/RosemountMeasurement)

©2020 Emerson. All rights reserved.

Emerson Terms and Conditions of Sale are available upon request. The Emerson logo is a trademark and service mark of Emerson Electric Co. Rosemount is a mark of one of the Emerson family of companies. All other marks are the property of their respective owners.