



BMS Bulut Makina Sanayi Ve Ticaret Ltd. Şti.

İkitelli Organize Sanayi Bölgesi Dolapdere Sanayi Sitesi

Ada 4 No : 7-9 Başakşehir / İSTANBUL

Tel : 0 212 671 02 24 / 25 Fax : 0 212 671 02 26

web site : www.bulutmak.com e-mail : bms@bulutmak.com

CONTENT

1. Forewords.....	3
1.1. History	3
1.2. Leeb Hardness Test (definition)	3
2. Features and Applications	4
2.1. Introduction	4
2.2. Specifications.....	4
2.3. Applications	4
3. Layout and Key-pad Description.....	5
3.1. Layout of HARTIP 2000	5
3.2. Function of Key.....	6
4. Symbols and Illustrations.....	6
4.1. Symbols and Illustrations.....	6
4.2. Measurement and Conversion Table	6
5. Preparation before Measuring	7
5.1. Requirements for the sample.....	7
5.2. Requirements for the weight of the sample.....	7
5.3. Requirement for the surface hardened layer of the sample	7
5.4. Surface of the test sample should not be magnetic.	8
5.5. For test sample of curving surface with radius of curvature R less than 30mm, a small support ring should be used.....	8
5.6. Supporting the Samples during Testing	8
5.7. Samples with Curved Surfaces.....	8
6. Operation.....	9
6.1. Parameter Setup.....	9
6.2. Operation	11
6.3. Data storing and re-reading	12
6.4. Statistics.....	12
6.5. Print-Out	12
6.6. Restore default setting.....	13
6.7. Calibration.....	13
7. Maintenance and Repair.....	14
7.1. Maintenance of the Impact Device.....	14
8. Optional Accessories	15

1. Forewords

1.1. History

The Leeb measuring method was first brought into measurement technology in 1978. It is defined as the quotient of an impact body's rebound velocity over its impact velocity, multiplied by 1000. Harder materials produce a higher rebound velocity than softer materials. For a specific group of material (e.g. steel, aluminum, etc.), Leeb hardness value represents a direct relationship to its hardness properties. For ordinary metal, conversion curves of hardness HL versus other standard static hardness (HB, HV, HRC, etc.) are available, enabling you to convert HL into other hardness values.

1.2. Leeb Hardness Test (definition)

An impact body with a spherical test tip made of tungsten carbide is propelled against the sample surface by a spring force and then rebounds back. At a distance of 1mm from the sample surface, the impact and rebound velocity of the impact body are measured by the following method: A permanent magnet embedded in the impact body, when passing through the coil in its coil holder, induces in the coil an electric voltage proportional to the velocities of the magnet. Leeb hardness is expressed by the following formula:


$$HL = 1000 \times (V_B / V_A)$$

Where: HL is Leeb Hardness

V_B is the rebound velocity of the impact body

V_A is the impact velocity of the impact body

The voltage characteristic of output signal, when the impact body passes through the induction coil is illustrated in the following figure:



Voltage characteristic of output signal

A Leeb's Hardness Tester measures the hardness of sample material in terms of Hardness Leeb (HL), which can be converted into other Hardness units (Rockwell B and C, Vicker, Brinell and Shore D).

2. Features and Applications

2.1. Introduction

HARTIP 2000 is an innovative portable Leeb hardness tester with our new patent technology which makes HARTIP 2000 a universal impact direction hardness tester. It is no need to set up impact direction when taking measurement by any angle. Therefore, HARTIP 2000 offers a linear accuracy comparing to the angle compensating method. HARTIP 2000 is also a cost saving hardness tester and has many other features.

2.2. Specifications

<i>Principle</i>	<i>Leeb hardness measurement</i>
<i>Accuracy</i>	<i>±0.3% @ HL=800, Repeatability: ±2HL</i>
<i>Display</i>	<i>Digital LCD with backlight</i>
<i>Hardness scale</i>	<i>HL/HRC/HRB/HB/HV/HS/σb</i>
<i>Measuring range</i>	<i>HL170-960/HRC17-69/HRB13-109/HB20-655/HV80-940/ HS32-99.5/σb (rm) 255-2639N/mm²</i>
<i>Impact device</i>	<i>DU (External)</i>
<i>Impact direction</i>	<i>Universal angle type</i>
<i>Materials</i>	<i>10 common metal materials</i>
<i>Memory</i>	<i>300 data can be stored and re-readable</i>
<i>Statistics</i>	<i>Calculated automatically</i>
<i>Recalibration</i>	<i>Allowed by user</i>
<i>Indicator</i>	<i>Low battery</i>
<i>Communication interface</i>	<i>RS232 to micro-printer</i>
<i>Auto power off</i>	<i>Auto</i>
<i>Power supply</i>	<i>1.5V AA alkaline battery x 2</i>
<i>Working environment</i>	<i>-10~+45 °C</i>
<i>Dimension (mm)</i>	<i>124x67x30</i>
<i>Net weight (g)</i>	<i>240</i>
<i>Standard</i>	<i>Conforming to ASTM A956</i>

2.3. Applications

Hardness tests on installed machines or steel structures: e.g. on heavy and large work-piece or on permanently installed system parts.

Rapid testing of multiple measuring areas for examination of hardness variations over larger regions.



Measuring hardness for produced parts at production line.

Identifying metallic material stored in a warehouse.







Ineffectiveness analysis of permanent parts, pressure -vessel, turbo generator.

3. Layout and Key-pad Description

3.1. Layout of HARTIP 2000



3.2. Function of Key

	:	Power On Power Off
	:	Menu Increase the value Turn the page forth
	:	Change parameter Decrease the value Turn the page back
	:	Confirm the setup View the statistics values
	:	Read the memory
	:	Delete the current reading Delete the stored values

4. Symbols and Illustrations

4.1. Symbols and Illustrations

Symbols	Illustrations
HLD	Leeb hardness value used with impact device D
HB	Brinell hardness value
HRB	Rockwell B hardness value
HRC	Rockwell C hardness value
HSD	Shore hardness value
HV	Vicker hardness value
σ_b (N/mm ²)	Strength value

4.2. Measurement and Conversion Table

Range for measurement and conversion:

IMPACT DEVICE	D					σ_b (N/mm ²)
	H R C	H R B	H B	H V	H S	
STEEL	20.0-67.9	59.6-99.5	80-647	80-940	32.5-99.5	375-1710
ALLOY TOOL STEEL	20.5-67.1			80-898		1170-2639
ST.STEEL	19.6-62.4	46.5-101.7	85-655	85-802		740-1725
GC.IRON			93-334			
NC.IRON			131-387			
C.ALUM			30-159			
BRASS		13.5-95.3	40-173			
BRONZE			60-290			
COPPER			45-315			

5. Preparation before Measuring

5.1. Requirements for the sample

The surface temperature of sample should be less than 120 °C.

The samples must feature a metallic smooth, ground surface, in order to eliminate erroneous measurements brought about by coarse grinding or lathe scoring. The roughness of the finished surface should not exceed 2µm.

5.2. Requirements for the weight of the sample

For samples weighing over 5 kg and of compact shape, no support is needed.

Samples weighing between 2-5 kg, and also for heavier samples with protruding parts or thin walls, should be placed on a solid support in such a manner that they do not bend or move by the impact force.

Samples weighing less than 2 kg should be firmly coupled with a stable support weighing over 5 kg.

For coupling purposes,

- * The coupling surface between the sample and base plate should be flat, plane parallel and ground.
- * A thin proper layer of coupling paste is to be applied to the contact surface of the sample.
- * The sample should be firmly pressed against the surface of the base plate by moving it with a circular motion.
- * The direction of impact should be perpendicular to the coupling surface.
- *


For the coupling operation, the following prerequisites must be fulfilled:

- * The contact surface of the sample and the surface of the base plate must be flat, plane parallel and ground.
- * The direction of the test impact must be perpendicular to the coupled surface.
- * Minimum thickness of the sample for coupling (5mm).

Proper Coupling:

Proper coupling requires a little experience. Insufficiently coupled samples produce large variations of individual measurements, L-values which are too low and the operation is characterized by a rattling noise upon impact of the test tip.

Example for coupling a test piece with a base plate:



Application of the coupling paste

5.3. Requirement for the surface hardened layer of the sample

Surface -hardened steels and especially case-hardened steels produce L-values which are too low when case-hardening depth is small because of their soft core. When measuring with impact device D the depth of the hardened layer should be no less than 0.8 mm.

5.4. Surface of the test sample should not be magnetic.

5.5. For test sample of curving surface with radius of curvature R less than 30mm, a small support ring should be used.

5.6. Supporting the Samples during Testing

Type of impact device	Classification of samples		
	heavy	medium-weight	light-weight
D	more than 5 kg	2 – 5 kg	0.05– 2 kg

When measuring hardness with HARTIP 1800, the following has to be noticed: Despite the low mass of the impact body and low impact energy, a relatively large impact force of short duration is generated when the impact body hits the measuring surface. The max. impact force of impact device D is 900N.

For heavy samples of compact shape, no particular precautions are necessary.

Smaller and lighter samples or work pieces yield or flex under this force, producing L-values which are too small and of excessively large variation. Even with big or heavy work pieces it is possible for thin-wall regions or thinner protruding parts to yield upon impact. Depending on the frequency of the resilient yielding action, the measured L-value may be too small or too large. In many situations, potential problems can be checked in the following manner:


- a) Medium-weight samples and also heavier samples with protruding parts or thin walls should be placed on a solid support in such a manner that they do not move or flex during the test impact.
- b) Light-weight samples should be rigidly “coupled” with a non-yielding support such as a heavy base plate. Clamping in a vice is of no value, since the samples become exposed to stress and because complete rigidity is never attained. As a rule, the measured L-values would be too small and show excessive variations.

5.7. Samples with Curved Surfaces

Impact testers only work properly, if the impact body has a certain position in the guide tube at the moment of impacting the test surface. In the normal position, automatically present when testing flat and convex-cylindrical samples (such as round samples), the spherical test tip is located exactly at the end of the guide tube.

However, when testing spherically or cylindrically shaped concave surfaces, the impact body remains further within the guide tube or protrudes further therefore. Thus, with such types of curved surfaces, it is to be observed that radii of curvature do not drop below the values indicated in the following Fig.



Curved surfaces should always be tested with the small support ring.



Impact device types D $R_{min}=30mm$


For impact devices D, special support rings are available to accommodate smaller radii on convex or concave surface.

6. Operation

Press the key  to switch on the tester and press the key  again to switch off the tester. When the tester is switched on, the tester will enter into measuring mode.

6.1. Parameter Setup


Operation Diagram





- M1: Steel/Cast Steel
- M2: Cold Work Tool Steel
- M3: Stainless Steel
- M4: Grey Cast Iron
- M5: Cast Iron nod.
- M6: Cast Alum. Alloys
- M7: Brass
- M8: Bronze
- M9: Wrought Copper All.
- M0: Wrought Steel



Materials Selection

The material selected is prior to the conversion from HL value to other scales.


* Press key  to enter into the menu until "MATE" displays on LCD.



* Press key  to change material from M1→M2→M3→ ... →M0 with each pressing key .



* Press key  to confirm the setting or press key  again to change other parameters.
Hardness Scale (Conversion)

Hardness scale is based on the material selected. Not every single material has same conversion. For example, for steel, it has conversions to HRC, HRB, HB, HV, HSD; but for cast iron, only has conversions to HB.

* Press key  consecutively to enter into the menu until "CONV" displays on LCD.

* Press key  to change the hardness scale from HLD→HRC→HB→HV→HS→σ b with each pressing key .





* Press key  to confirm the setting or press key  again to go to next item of menu.

Mean Time

With HARTIP2000, the statistics values can be calculated automatically after setup mean time.

* Press key  consecutively to enter into menu until "AVER" displays on LCD.


* Press key  to select mean time from 0→3→4→5 circularly by each pressing key .





* Press  to confirm the setting or press key  again to go to next item of menu.



Storage

The HARTIP2000 has a memory capacity of 300 data. The stored values can be re-readable on LCD.


* Press key  consecutively to enter into menu until "SOFF" displays on LCD.


* Press key  to change the setting between "SOFF" and "SON" alternatively.






* Press key  to confirm the setting or press key  again to go to next item of menu. When select "SON", a "S" appears on LCD which means the function of storage is activated.

Printing Setup

* Press key  consecutively to enter into the menu until "POFF" displays on LCD.

* Press key  to change the setting between "POFF" and "PON" alternatively.




* Press key  to confirm the setting or press key  again to go to first item of menu. When selecting "PON", an indicator "▽" will appear on LCD which means the communication function is activated for printing or for PC. (Communication with PC needs special software for downloading.)

6.2. Operation

Take measurement


Switch on the tester, the instrument will go into measuring mode automatically. If the parameters are needed to change, please refer to 6.1.

Load spring force



Hold the impact device with left hand while push the loading tube with right hand toward to the end. Then loose the force and let the loading tube back to original position.

Release




Place the impact device against the object to be measured. Then press the release button on top of the impact device with finger of right hand. The measuring value will display on LCD.


Please note : During the measurement, the impact device must be placed vertically with a little force against the surface of workpiece. Otherwise, it may affect the accuracy.



6.3. Data storing and re-reading


Set the storage function of tester to be activated. A “S” displays on LCD. At this time, all measuring values will be stored automatically into the memory.



During the tester power on, press key  after “MEMR” displays and then the last stored value will display.





Press key  or  to turn the page and view measuring values. When “EOF” or “bOF” displays with turning page, it reminds you it is at the end.



Clear the memory

Delete the stored data from memory.

Under the re-readable mode, press and hold the key  until “dELE” displays on LCD.


Then press key  to confirm the deletion.




6.4. Statistics

With this function, the statistics values will be calculated automatically by the tester.

View statistics value

After mean time was setup in the tester, the mean time number will display on LCD. With each measurement, the number will increase one by one until all finished. Then press key  consecutively to view value of average, maximum, minimum and mean square root.

Delete the non-realistic value

When mean time was setup, in order to avoid wrong calculation, if there are random values occurs, you should delete the random value. Press key , the current value will be deleted.


6.5. Print-Out


The tester is designed to print our measuring values by two ways. One is print-out all from memory and the other is print-out online while measuring.

Printing stored values


* Activate the storage function on the tester, there is a “R” displays on LCD. Please refer to 0

* Connect the tester to the printer with cable. (The printer and cable will be ordered optionally)

* Press key  , a "R" displays on LCD which means the tester is in the re-readable mode, at this time, the last value will display on LCD.



* Press and hold key  until "PALL" displays on LCD.





* Press key  to print out all data.



Printing on line

- * Activate the communication on the tester, there is a "▽" displayed on LCD. Please refer to 0
- * Connect the tester to the printer with cable.
- * Take measurements, all values will be printed out one by one with each measurement.

6.6. Restore default setting


- * Set 3 times for average on tester. Please refer to 0
- * Set Material to be M1(Steel & cast steel).
- * Take 3 measurements on standard test block.
- * Press key  to display average value.





* Press and hold key  and  simultaneously for 3 seconds until "dEFA" displays on LCD, then the tester will come back to factory setting.

6.7. Calibration

After long time of use, the ball tip on impact body may worn which would lead inaccuracy. In order to compensate such error, the tester is designed to re-calibrate by user.


* Press key  in turn to display "CAL" on the LCD.




*
* Press and hold Key  for 3 seconds to enter into the mode of calibration.






* At the mode of calibration, you are asked to take 5 measurements on standard test block in total. Among them, 3 measurements are needed to impact downward ↓ and 2 measurements are needed to impact upward ↑. Please follow up the indication on LCD to take measurements.


During the measurements, you can delete the unsatisfied reading by press key . Also, by any time, at this mode, you can abandon the operation by letting the instrument shut down automatically after 3 minutes of no use.

* After taking 5 measurements on test block, press key  to display average value. At this time, the arrow disappears and an indicator “AVE” is displayed on the right bottom of LCD.



* If the average value differs from the standard value of test block, you can press and hold key  for 3 seconds, “CALD” will flash once on the screen, and then an indicator “CAL” will display on the right bottom of the LCD, you can press key  or  to increase or decrease the value on LCD until the value is same as the value of test block.



* Press key  to finish the calibration and turn back to normal measuring mode.

7. Maintenance and Repair

Do your best to avoid shock, heavy dust, damp, strong magnetic field, and oil stain.







7.1. Maintenance of the Impact Device

The devices do not require any particular care other than periodic cleaning of the impact body and the guide tube after performing approximately 1000-2000 tests. During cleaning, the following procedures need to be observed:

- * **Unscrew support ring and remove impact body from guide tube.**
- * **Clean off any dirt and metallic dust from the impact body and the spherical test tip.**
- * **Clean guide tube with the special brush provided.**
- * **Do not apply oil to any parts for the impact device.**

8. Optional Accessories

Support Rings for Impact Device D

Part designation and dimensions:		Suitable for the following test surfaces		
D6	$\Phi 19.5 \times 5.5\text{mm}$		R $\geq 60\text{mm}$	plane cylindrical hollow-cylindrical spherical hollow-spherical
D6a	$\Phi 13.5 \times 5.5\text{mm}$		R $\geq 30\text{mm}$	plane cylindrical hollow-cylindrical spherical hollow-spherical
Z 10-15 Z 14.5-30 Z 25-50	20 \times 20 \times 7.5mm 20 \times 20 \times 6.5mm 20 \times 20 \times 6.5mm		R 10mm-15mm R 14.5mm-30mm R 25mm-50mm	cylindrical R<10mm not possible R $\geq 30\text{mm}$ D6/D6a
HZ 11-13 HZ 12.5-17 HZ 16.5-30	20 \times 18 \times 5mm 20 \times 20 \times 5mm 20 \times 20 \times 5mm		R 11mm-13mm R 12.5mm-17mm R 16.5mm-30mm	hollow-cylindrical R<11mm not possible R $\geq 30\text{mm}$ D6a
K 10-15 K 14.5-30	$\Phi 20 \times 7.7\text{mm}$ $\Phi 20 \times 6.7\text{mm}$		R 10mm-13mm R 14.5mm-30mm	spherical R<10mm not possible R $\geq 30\text{mm}$ D6/D6a
HK 11-13 HK 12.5-17 HK 16.5-30	$\Phi 17 \times 5\text{mm}$ $\Phi 18 \times 5\text{mm}$ $\Phi 20 \times 5\text{mm}$		R 11mm-13mm R 12.5mm-17mm R 16.5mm-30mm	hollow-spherical R<11mm not possible R $\geq 30\text{mm}$ D6a
UN	$\Phi 52 \times 20 \times 16\text{mm}$	