


 COMMERCIAL



*An Employee-Owned Company*

# ***EFT SERIES*** WATER SOFTENERS



Water Control Corporation  
7150 143rd Ave NW • Ramsey, MN 55303  
1-866-405-1268 • [www.watercontrolinc.com](http://www.watercontrolinc.com)  
WC-OM-EFT-FRONTPG © Water Control Corporation 042722



# TABLE OF CONTENTS

WARNINGS.....	3
BASIC PRINCIPLES.....	4
SOFTENING OPERATION.....	5
SPECIFICATIONS.....	6
DIMENSIONS.....	8
SET-UP PROCEDURES.....	9
INSTALLATION PROCEDURES.....	10
INSTALLATION DIAGRAMS.....	11
WIRING DIAGRAMS.....	12
PROGRAMMING INSTRUCTIONS.....	13
START-UP PROCEDURES.....	19
MAINTENANCE PROCEDURES.....	22
SERVICE.....	24
TROUBLESHOOTING.....	25
COMPONENTS.....	28
OFFICIAL WARRANTY.....	32

## WARNINGS



SYSTEM MUST BE INSTALLED AND MAINTAINED PER THE MANUFACTURER'S RECOMMENDATIONS IN THIS MANUAL. FAILURE TO DO SO MAY CAUSE INJURY, EQUIPMENT FAILURE AND/OR DAMAGE, AND WILL RESULT IN WARRANTY BEING VOID.



RISK OF SHOCK! ELECTRICAL INSTALLATION SHOULD BE DONE BY QUALIFIED, TRAINED ELECTRICIANS. INSTALLATION SHOULD BE TO LOCAL CODES.



ALWAYS TURN OFF THE UNIT, SHUT OFF THE FEEDWATER, RELIEVE PRESSURE, AND DISCONNECT THE ELECTRICAL POWER BEFORE WORKING ON THE UNIT.



DO NOT USE WHERE THE WATER IS MICROBIOLOGICALLY UNSAFE OR OF UNKNOWN QUALITY WITHOUT ADEQUATE DISINFECTION BEFORE OR AFTER THE SYSTEM.



NEVER ALLOW THE UNIT TO FREEZE OR OPERATE WITH A FEEDWATER TEMPERATURE/PRESSURE OUTSIDE THE RECOMMENDED PARAMETERS (34-110°F / 20-125 PSI).



SYSTEM MUST BE INSTALLED IN ACCORDANCE WITH LOCAL PLUMBING CODES AND REGULATIONS. CONTACT WCC (WATER CONTROL CORPORATION) FOR MORE INFORMATION.



READ THE ENTIRE MANUAL BEFORE INSTALLING, OPERATING, OR MAINTAINING THIS EQUIPMENT.



THIS SYSTEM CONTAINS FLOWING WATER, UNDER PRESSURE. ENSURE THAT INSTALL LOCATION HAS ADEQUATE DRAINAGE AND WATERPROOFING TO ACCOMMODATE POTENTIAL LEAKAGE AND/OR OVERFLOW SITUATIONS. FAILURE TO DO SO COULD RESULT IN FLOODING/DAMAGE.

## BASIC PRINCIPLES

A water softener works via a process known as Ion Exchange. In this process, a special media bed is used to exchange undesirable hardness minerals, including calcium, potassium, and magnesium (as well as low levels of iron and manganese) for something more desirable -- in this case, a small amount of sodium.

A water softener uses a mechanically driven control valve. During normal operation, this valve distributes the flow of raw (hard) water evenly over the top of the media bed. As the hard water passes down through the media, hardness minerals -- primarily calcium, which exists in solution in a calcium bicarbonate form -- are removed from solution and affixed to the media. In place of this calcium, trace amounts of sodium ions are released. What was calcium carbonate dissolved in the water becomes sodium bicarbonate (i.e., baking soda).

Once the resin has absorbed all the hardness minerals, and released all the sodium, that it can, regeneration is required. Regeneration is the process of removing calcium/hardness minerals from the media and resetting it with fresh sodium ions. To achieve this, a piston in the softener control valve changes position. The media is first backwashed, to lift and unpack the bed. Next, it is bathed in a supersaturated brine (sodium chloride) solution. This bombards the media with sodium ions, forcing the calcium/hardness minerals off and sending them down the drain. A relatively small percentage of sodium ions remain on the media, though the majority pass to the drain as well. After this brine cycle, the media is rinsed off, the brine tank is refilled, and the system goes back into service.

Twin-Alternating softener's feature 24/7 service functionality. While one tank is online, the other remains in standby mode. Once the capacity of the online tank has expired, regeneration is signaled, and the standby tank comes online. The two tanks alternate online and standby mode as needed. This ensures 24/7 soft water, and regeneration occurs one tank at a time.

For more information on commercial water softening systems, please visit WCC's website at: [watercontrolinc.com](http://watercontrolinc.com) or call us at 763-427-9638.

We thank you for your business!

# SOFTENER OPERATION

As water enters the softener, it passes over a resin bed in a special tank. The resin consists of tiny beads of a plastic called styrene. These beads attract and hold sodium ions and exchange the sodium for hardness ions when encountered. Over time, the resin becomes saturated with hardness ions and no longer removes hardness materials. The softener goes into a “regeneration” to flush hardness materials to the drain and refresh the resin with sodium. Regeneration of single tank systems is typically programmed to take place in the middle of the night when little or no water is in use. Regeneration of individual tanks in a Twin-Alternating system occurs immediately (as needed), with the other tank remaining available.

## REGENERATION CONSISTS OF FOUR CYCLES:

### 1. CYCLE: BACKWASH POSITION

Backwash is a rapid upward flow of water that loosens the resin bed and flushes iron particles, dirt and sediments filtered in the bed out to the drain.

### 2. CYCLE: BRINE DRAW / SLOW RINSE POSITION

Brine Draw is the process in which brine is drawn out of the brine cabinet and passed through the resin in a downward direction. This rinses the resin and large amounts of sodium ions re- place the hardness ions accumulated during service.

Slow Rinse. After brine is completely removed from the brine cabinet into the resin tank the brine valve closes. Water replaces any remaining brine from the resin, flushing hardness ions removed from the resin to drain.

### 3. CYCLE: FAST RINSE POSITION

Fast Rinse is a fast flow of water down through the resin tank that follows a Backwash. This flushes all remaining brine from the tank and packs the resin bed for softening efficiency.

### 4. CYCLE: BRINE FILL

Brine is water saturated with large amounts of a salt (sodium chloride). During Brine Fill, water flows into the salt storage area after each regeneration and dissolves salt. During the regeneration process, hardness ions on the resin beads are replaced or exchanged for sodium ions from the brine solution.

## NOTE: SERVICE

When the softener is in service, normal operation is occurring. Water is flowing through the softener and hardness minerals are being removed from the water. In service, one resin tank will be online while the other resin tank is in standby.

# EFT SERIES

## TWIN ALTERNATING WATER SOFTENERS

WCC's "EFT" Series softeners feature 1" service connections, light duty electronic (dual-service) control valves, two (2) high-strength fiberglass-reinforced mineral tanks, and long-lasting synthetic cation resin. This series is perfectly designed for smaller applications where 24 hour soft water is required. "EFT" Series softeners feature a dual tank, alternating system, allowing one tank to be in service at all times.



### SPECIFICATIONS

Model Series Number	Exchange Capacity Per Tank* (grains)			Valve Size (in)	Cv	Flow Rate (GPM)			Pipe Size (in)		Back Wash (GPM)	Resin (cu.ft.)	Brine Tank Capacity (lbs)	Regen. Time (min)	Tank Size (in)		Approx. Ship Weight (lbs)
	Min <sup>1</sup>	Mid <sup>2</sup>	Max <sup>3</sup>			7 psid	Cont. 15 psid	Peak 25 psid	Service	Drain					Resin	Salt	
EFT-30	23000	27000	30000	1	4.6	12	18	23	1	¾	3	1/tank	250	88	10 X 44	18 X 33	225
EFT-48	36800	43200	48000	1	4.4	12	17	22	1	¾	1.7	1.6/tank	225	88	10 X 54	18 X 33	275
EFT-60	46000	54000	60000	1	4.8	13	19	24	1	¾	3	2/tank	225	88	12 X 52	18 X 33	350
EFT-90	69000	81000	90000	1	5.4	14	21	27	1	¾	5	3/tank	650	90	14 X 65	24 X 50	575
EFT-120	92000	108000	120000	1	5.4	14	21	27	1	¾	7	4/tank	650	94	16 X 65	24 X 50	700
EFT-150	115000	135000	150000	1	5	13	19	25	1	¾	5	5/tank	625	96	16 X 65	24 X 50	800

<sup>1</sup> Based on 7 lbs salt per cubic foot.

<sup>2</sup> Based on 10 lbs salt per cubic foot.

<sup>3</sup> Based on 13 lbs salt per cubic foot.

All "EFT" Series softeners utilize series 9100 controllers.

\*Exchange capacity based on treating water with 10 gpg total hardness as CaCo3 and 400 ppm total dissolved solids. Capacities may vary with different influent water characteristics and other factors. Due to varying water conditions, tank sizes and water pressures, the above should only be used as a guideline. Capacity listed is per tank, and should therefore be multiplied by 2 for total system capacity.

**WITH OVER 50 YEARS OF EXPERIENCE IN THE WATER CONDITIONING AND PLUMBING INDUSTRIES,** WCC CAN DESIGN AND MANUFACTURE EQUIPMENT FOR VIRTUALLY ANY APPLICATION. WE OFFER A COMPLETE MENU OF SERVICES, INCLUDING WATER TESTING, SYSTEM SIZING, BIM MODELING (REVIT®), DELIVERY, SETUP, STARTUP, AND AFTER-MARKET SERVICE PLANS. WE MAINTAIN A UNIQUE FOCUS ON MECHANICAL ENGINEERS, CONTRACTORS, AND THE PLUMBING INDUSTRY. DEPEND ON US TO PROVIDE QUALITY, INNOVATIVE SOLUTIONS FOR ALL YOUR COMMERCIAL WATER CONDITIONING NEEDS.

## HOW TO SPECIFY “EFT” SERIES SOFTENERS:

**ORDER CODE:**



**MODEL (from other side)**

**SYSTEM SIZE**

Two Tank (Alternating): **TWIN - ALT**

### Additional Options: (check options below)

- Steel Tank(s) (optional ASME Rating)
- Accu-Pipe Skid-Mounted System (pre-plumbed\*, pre-wired system, mounted on heavy-duty powder-coated steel skid)
- Accu-Pipe LS: Same as Accu-Pipe System, less skid base (piping/wiring only)
- Brine Silo (large volume salt storage / brine generation & delivery system)
- Salt Sock and Access Door (lockable) for blow-in salt delivery

\*Standard piping is grooved, type L copper, other materials available.

For a detailed, model-specific specification, please contact WCC (Water Control Corporation). Detailed drawings also available upon request (CAD® or Revit®).

Water softening system requires a minimum inlet water pressure of 30 psig and maximum of 120 psig. If resin tank is subject to vacuum, an adequate vacuum relief valve must be properly installed. Tank warranty is void if subjected to vacuum. Feed water temperature shall be between 40°F and 100°F. Each control valve requires a 120 volt wall outlet (2-prong, 1.3FLA, 60Hz).



CONTACT YOUR LOCAL  
SALES REPRESENTATIVE

To find your authorized WCC representative, please visit: [www.watercontrolinc.com/representative-locator/](http://www.watercontrolinc.com/representative-locator/).



VISIT US ONLINE

Go to [www.watercontrolinc.com](http://www.watercontrolinc.com), where you'll find detailed product specification info and application design questionnaires.



SPEAK DIRECTLY WITH ONE OF  
WCC'S DESIGN ENGINEERS

Call 1-866-405-1268 or email [techsupport@watercontrolinc.com](mailto:techsupport@watercontrolinc.com).

*We look forward to working with you!*


Water Control Corporation  
7150 143rd Ave NW • Ramsey, MN 55303  
1-866-405-1268 • [www.watercontrolinc.com](http://www.watercontrolinc.com)



WC-EFT © Water Control Corporation 0122

# Two Tank (TWIN ALTERNATING) Models

## WATER SOFTENER DIMENSIONS



Model Series Number	(A)	(B)	(C)	(D)	(E)	(F)
	Resin Tank Diameter (+/-0.5 in)	Resin Tank Height (+/-1 in)	Inlet/ Outlet Height (in)	Overall Height (in)	Brine Tank Diameter (in)	Overall Length (in)
EFT-60-MR	12.0	53.4	55.7	60.7	18.0	49.0
EFT-90-MR	14.0	66.1	68.4	73.4	24.0	57.0
EFT-120-MR	16.0	66.2	68.5	73.5	24.0	59.0
EFT-150-MR	16.0	66.2	68.5	73.5	24.0	59.0
MFT-60-MR	12.0	53.4	56.0	61.2	18.0	55.0
MFT-90-MR	14.0	66.1	68.7	73.9	24.0	57.0
MFT-120-MR	16.0	66.2	68.8	74.0	24.0	59.0
MFT-150-MR	16.0	66.2	68.8	74.0	24.0	59.0
MFT-150X-MR	18.0	67.0	69.6	74.8	24.0	73.0
MFT-180-MR	21.0	67.0	69.6	74.8	24.0	73.0
MFT-210-MR	21.0	67.0	69.6	74.8	24.0	73.0
MFT-240-MR	24.0	74.2	76.8	82.0	30.0	81.0
MFT-300-MR	24.0	74.2	76.8	82.0	30.0	81.0

All dimensions are approximate and subject to change without notice. Please consult our technical department for additional system information.



CONTACT YOUR LOCAL SALES REPRESENTATIVE

To find your authorized WCC representative, please visit: [www.watercontrolinc.com/representative-locator/](http://www.watercontrolinc.com/representative-locator/).



VISIT US ONLINE

Go to [www.watercontrolinc.com](http://www.watercontrolinc.com), where you'll find detailed product specification info and application design questionnaires.



SPEAK DIRECTLY WITH ONE OF WCC'S DESIGN ENGINEERS

Call 1-866-405-1268 or email [techsupport@watercontrolinc.com](mailto:techsupport@watercontrolinc.com).

*We look forward to working with you!*



# EFT SET-UP PROCEDURES

Inspect distributor assembly inside of each tank for damage. The distributor assembly is shipped secured to the resin tank, but damage can occur during shipping. If the distributor is damaged, do not fill resin tank with gravel/media as it will need to be removed for distributor repair. Contact WCC at 763-427-9638.

1. Unpackage the resin tanks and place them into/near their installation location. Leave the knockout plug on the distributor tube. This will be removed after the gravel/media has been loaded into the resin tanks.
2. Load the gravel into the resin tanks using the supplied funnel. The funnel is shipped in the brine tank. See gravel chart for number of gravel bags per tank.
3. Load the softening media into the resin tanks using the supplied funnel. The funnel is shipped in the brine tank. See chart for number of resin bags to install per tank.
4. Remove the knockout plug on the distributor tube.
5. Snap on black deflector onto the bottom of valve.
6. Screw valve onto resin tank..
7. Silicone O-rings on yolk.
8. Connect the resin tanks together with yolk.
9. Install flow meter and by pass assembly.
10. Contact WCC for startup instructions: (763) 427-9638.

MODEL SERIES NUMBER	# OF RESIN BAGS (per tank)	# OF GRAVEL BAGS (per tank)
EFT-30	1	0
EFT-48	1.6	0
EFT-60	2	0.25
EFT-90	3	0.5
EFT-120	4	1
EFT-150	5	1

# INSTALLATION PROCEDURES


1. **IDENTIFY INSTALLATION LOCATION FOR WATER SOFTENER.** Piping should be such that all hard water, except for outside hydrants, flows through softener. This system and installation must comply with state and local laws and regulations.
2. **CONNECT WATER PIPING.** See install diagrams for plumbing layout. Important: Make all sweat-solder connections within 6 inches of softener before applying threaded fittings. Overheating may cause damage to valve. Note: WCC recommends installing isolation valves on the inlet and outlet of each control valve.
3. **CONNECT DRAIN LINE.** Be sure not to submerge drain line end into drain, as a 1-1/2" minimum air gap must be maintained to prevent potential backflow hazard. Firmly secure at drain, while maintaining a minimum 1-1/2" air gap. Note: Floor drain must be capable of handling full backwash flow rate (see page 6 for backwash rates).
4. **CONNECT BRINE LINE.** For HF series softeners with a capacity of 600,000 grains and lower, connect brine line using supplied parts. For HF series softeners with a capacity over 600,000 grains, contractor must hard plumb each resin tank brine line individually to the brine tank. Recommended hard plumbed pipe size is 1 inch PEX, PVC, or CPVC. Note: Brine line size may vary depending on distances between the softener and the brine tank. Hard plumbing material is not supplied by WCC..
5. **INSTALL BRINE TANK OVERFLOW LINE.** Install overflow fitting into hole inside of brine tank. An owner-supplied overflow line should then be attached and run to a nearby drain. Failure to run overflow line could cause flooding and water damage should the brine tank overflow. *See the table below for brine tank overflow recommended line size. Note: Line sizes over 0.5 inches are to be hard plumbed to the drain.*

BLFC (gpm)	SOFTENER CAPACITY (kgrains)	BRINE TANK OVERFLOW (in)
1	up to 150	0.5
2	150X - 300	0.75
5	360 - 600	1
10	800 and up	1.5


6. **CONNECT TO ELECTRICAL POWER SOURCE.** Connect power cord to a separate 120v, 15-amp, ground fault interrupt (GFI) outlet. Note: Each control valve should have a dedicated 120V outlet

**NOTE:** *This system is not intended to be used for treating water that is microbiologically unsafe or of unknown quality without disinfection before or after the system.*

# EFT TWIN-ALTERNATING INSTALLATION DIAGRAM



# 9000SXT/9100SXT/9500SXT WIRING DIAGRAM



42743 Rev A

# FLECK® SXT ELECTRONIC CONTROLLER

COMPLETELY CUSTOMIZE-ABLE

**MADE IN THE  
USA**  
OF FOREIGN & DOMESTIC PARTS



## FEATURES/BENEFITS

Time of day super capacitor backup for power loss

Large LCD display with blue backlit

Service and queued regeneration faucet icon

Easy electronic programming

LCD display alternates between time of day, volume remaining or days till regen, and tank in service

Displays regeneration step and time remaining during regeneration

Programming stored in memory and will not be lost due to power outages

Regeneration tonight and regeneration now option

Diagnostics

- Current Flow Rate
- Peak Flow Rate (can be reset)
- Reserve Capacity
- Software Version
- Hours in Service
- Volume Used

## SYSTEM TYPE

System Type 4

## VALVE TYPE

2750	9500
2850s	5600SXT
2850	5800
9000	7000
9100	5000SXT

## REGENERATION TYPE

---

Meter Delayed  
Meter Immediate  
Time Clock Delayed  
Volume Override Delayed  
Volume Override Immediate  
Day of the Week

## REGENERATION FLOW

---

Upflow Brine First  
Downflow Double Backwash  
Downflow Backwash  
Upflow Backwash  
Filter  
Upflow Filter  
Other

## ELECTRICAL RATING

---

12V DC (5800 only)  
24V Transformers:

- 115V AC +/- 20% input, 24V AC output
- 230V AC +/- 20% input, 24V AC output



### FILTRATION & PROCESS

5730 NORTH GLEN PARK ROAD, MILWAUKEE, WI 53209  
P: 262.238.4400 | F: 262.518.4404 | WWW.PENTAIRAQUA.COM | CUSTOMER CARE: 800.279.9404

All Pentair trademarks and logos are owned by Pentair, Inc. or its affiliates. All other registered and unregistered trademarks and logos are the property of their respective owners. Because we are continuously improving our products and services, Pentair reserves the right to change specifications without prior notice. Pentair is an equal opportunity employer.

42748 REV B NV13 © 2013 Pentair Residential Filtration, LLC. All Rights Reserved.

# TIMER FEATURES




Figure 1

## Features of the SXT:

- Power backup that continues to keep time and the passage of days for a minimum of 48 hours in the event of power failure. During a power outage, the control goes into a power-saving mode. It does not monitor water usage during a power failure, but it does store the volume remaining at the time of power failure.
- Settings for both valve (basic system) and control type (method used to trigger a regeneration).
- Day-of-the-Week controls.
- While in service, the display alternates between time of day, volume remaining or days to regeneration, and tank in service (twin tank systems only).
- The Flow Indicator flashes when outlet flow is detected.
- The Service Icon flashes if a regeneration cycle has been queued.
- A Regeneration can be triggered immediately by pressing the Extra Cycle button for five seconds.
- The Parameter Display displays the current Cycle Step (BW, BF, RR, etc) during regeneration, and the data display counts down the time remaining for that cycle step. While the valve is transferring to a new cycle step, the display will flash. The parameter display will identify the destination cycle step (BW, BF, RR, etc) and the data display will read "----". Once the valve reaches the cycle step, the display will stop flashing and the data display will change to the time remaining. During regeneration, the user can force the control to advance to the next cycle step immediately by pressing the extra cycle button.

## Setting the Time of Day

1. Press and hold either the Up or Down buttons until the programming icon replaces the service icon and the parameter display reads DO.
2. Adjust the displayed time with the Up and Down buttons.
3. When the desired time is set, press the Extra Cycle button to resume normal operation. The unit will also return to normal operation after 5 seconds if no buttons are pressed.



## Queueing a Regeneration

1. Press the Extra Cycle button. The service icon will flash to indicate that a regeneration is queued.
2. To cancel a queued regeneration, press the Extra Cycle button.

## Regenerating Immediately

Press and hold the Extra Cycle button for five seconds.

## TIMER OPERATION

---

### Meter Immediate Control

A meter immediate control measures water usage and regenerates the system as soon as the calculated system capacity is depleted. The control calculates the system capacity by dividing the unit capacity (typically expressed in grains/unit volume) by the feedwater hardness and subtracting the reserve. Meter Immediate systems generally do not use a reserve volume. However, in twin tank systems with soft-water regeneration, the reserve capacity should be set to the volume of water used during regeneration to prevent hard water break-through. A Meter Immediate control will also start a regeneration cycle at the programmed regeneration time if a number of days equal to the regeneration day override pass before water usage depletes the calculated system capacity.

### Meter Delayed Control

A Meter Delayed Control measures water usage and regenerates the system at the programmed regeneration time after the calculated system capacity is depleted. As with Meter Immediate systems, the control calculates the system capacity by dividing the unit capacity by the feedwater hardness and subtracting the reserve. The reserve should be set to insure that the system delivers treated water between the time the system capacity is depleted and the actual regeneration time. A Meter Delayed control will also start a regeneration cycle at the programmed regeneration time if a number of days equal to the regeneration day override pass before water usage depletes the calculated system capacity.

### Time Clock Delayed Control

A Time Clock Delayed Control regenerates the system on a timed interval. The control will initiate a regeneration cycle at the programmed regeneration time when the number of days since the last regeneration equals the regeneration day override value.

### Day of the Week Control

This control regenerates the system on a weekly schedule. The schedule is defined in Master Programming by setting each day to either "off" or "on." The control will initiate a regeneration cycle on days that have been set to "on" at the specified regeneration time.

### Control Operation During Regeneration

During regeneration, the control displays a special regeneration display. In this display, the control shows the current regeneration step number the valve is advancing to, or has reached, and the time remaining in that step. The step number that displays flashes until the valve completes driving to this regeneration step position. Once all regeneration steps are complete the valve returns to service and resumes normal operation.

Pressing the Extra Cycle button during a regeneration cycle immediately advances the valve to the next cycle step position and resumes normal step timing.

### Control Operation During Programming

The control only enters the Program Mode with the valve in service. While in the Program Mode, the control continues to operate normally monitoring water usage and keeping all displays up to date. Control programming is stored in memory permanently, eliminating the need for battery backup power.

### Manually Initiating a Regeneration

1. When timer is in service, press the Extra Cycle button for 5 seconds on the main screen.
2. The timer advances to Regeneration Cycle Step #1 (rapid rinse), and begins programmed time count down.
3. Press the Extra Cycle button once to advance valve to Regeneration Cycle Step #2 (backwash).
4. Press the Extra Cycle button once to advance valve to Regeneration Cycle Step #3 (brine draw & slow rinse).
5. Press the Extra Cycle button once to advance valve to Regeneration Cycle Step #4 (brine refill).
6. Press the Extra Cycle button once more to advance the valve back to in service.

**NOTE: If the unit is a filter or upflow, the cycle step order may change.**

**NOTE: A queued regeneration can be initiated by pressing the Extra Cycle button. To clear a queued regeneration, press the Extra Cycle button again to cancel. If regeneration occurs for any reason prior to the delayed regeneration time, the manual regeneration request shall be cleared.**

### Control Operation During A Power Failure

The SXT includes integral power backup. In the event of power failure, the control shifts into a power-saving mode. The control stops monitoring water usage, and the display and motor shut down, but it continues to keep track of the time and day for a minimum of 48 hours.

The system configuration settings are stored in a non-volatile memory and are stored indefinitely with or without line power. The Time of Day flashes when there has been a power failure. Press any button to stop the Time of Day from flashing.

If power fails while the unit is in regeneration, the control will save the current valve position before it shuts down. When power is restored, the control will resume the regeneration cycle from the point where power failed. Note that if power fails during a regeneration cycle, the valve will remain in its current position until power is restored. The valve system should include all required safety components to prevent overflows resulting from a power failure during regeneration.

The control will not start a new regeneration cycle without line power. If the valve misses a scheduled regeneration due to a power failure, it will queue a regeneration. Once power is restored, the control will initiate a regeneration cycle the next time that the Time of Day equals the programmed regeneration time. Typically, this means that the valve will regenerate one day after it was originally scheduled. If the treated water output is important and power interruptions are expected, the system should be setup with a sufficient reserve capacity to compensate for regeneration delays.



## USER PROGRAMMING MODE

User Programming Mode Options		
Abbreviation	Parameter	Description
DO	Day Override	The timer's day override setting
RT	Regeneration Time	The time of day that the system will regenerate (meter delayed, timeclock, and day-of-week systems)
H	Feed Water Hardness	The hardness of the inlet water - used to calculate system capacity for metered systems
RC or SF	Reserve Capacity	The fixed reserve capacity
CD	Current Day	The current day of week


**NOTE: Some items may not be shown depending on timer configuration. The timer will discard any changes and exit User Mode if any button is not pressed for sixty seconds.**

### User Programming Mode Steps


1. Press the Up and Down buttons for five seconds while in service, and the time of day is NOT set to 12:01 PM.
2. Use this display to adjust the Day Override. This option setting is identified by "DO" in the upper left hand corner of the screen.



3. Press the Extra Cycle button. Use this display to adjust the Regeneration Time. This option setting is identified by "RT" in the upper left hand corner of the screen.




4. Press the Extra Cycle button. Use this display to adjust the Feed Water Hardness. This option setting is identified by "H" in the upper left hand corner of the screen.



Range: 1-199 hardness

5. Press the Extra Cycle button. Use this display to adjust the Fixed Reserve Capacity. This option setting is identified by "RC" or "SF" in the upper left-hand Corner of the screen.



6. Press the Extra Cycle button. Use this display to set the Current Day of the Week. This option setting is identified by "CD" in the upper left hand corner of the screen.



7. Press the Extra Cycle button to end User Programming Mode.

## DIAGNOSTIC PROGRAMMING MODE

Diagnostic Programming Mode Options		
Abbreviation	Parameter	Description
FR	Flow Rate	Displays the current outlet flow rate
PF	Peak Flow Rate	Displays the highest flow rate measured since the last regeneration
HR	Hours in Service	Displays the total hours that the unit has been in service
VU	Volume Used	Displays the total volume of water treated by the unit
RC	Reserve Capacity	Displays the system's reserve capacity calculated from the system capacity, feedwater hardness, and safety factor
SV	Software Version	Displays the software version installed on the controller


**NOTE: Some items may not be shown depending on timer configuration. The timer will exit Diagnostic Mode after 60 seconds if no buttons are pressed. Press the Extra Cycle button to exit Diagnostic Mode at any time.**

### Diagnostic Programming Mode Steps

1. Press the Up and Extra Cycle buttons for five seconds while in service.
2. Use this display to view the current Flow Rate. This option setting is identified by "FR" in the upper left hand corner of the screen.




3. Press the Up button. Use this display to view the Peak Flow Rate since the last regeneration cycle. This option setting is identified by "PF" in the upper left hand corner of the screen.



4. Press the Up button. Use this display to view the Hours in Service since the last regeneration cycle. This option setting is identified by "HR" in the upper left hand corner of the screen.



5. Press the Up button. Use this display to view the Volume Used since the last regeneration cycle. This option setting is identified by "VU" in the upper left hand corner of the screen.



6. Press the Up button. Use this display to view the Reserve Capacity. This option setting is identified by "RC" in the upper left hand corner of the screen.



7. Press the Up button. Use this display to view the Software Version. This option setting is identified by "SV" in the upper left hand corner of the screen.



8. Press the Extra Cycle button to end Diagnostic Programming Mode.

# Commercial Water Softener Startup Procedures

*(TECHNICIAN TO INITIAL EACH ITEM SUCCESSFULLY TESTED.)*

Date \_\_\_\_\_

Project Name/Location \_\_\_\_\_

Technician \_\_\_\_\_

Model/Serial Number \_\_\_\_\_

Number/Size of Resin Tanks \_\_\_\_\_

Size of Brine Tank \_\_\_\_\_

Brine Reclaim System \_\_\_\_\_

- Meter     
  Timeclock     
  Progressive Flow     
  Alternating

## Installation Verification

1.  Confirm the system O&M manual is onsite.
2.  Confirm 120 VAC power supplied.
3.  Verify water lines are all properly plumbed, and water is available.
4.  Verify drain lines properly plumbed.
5.  Verify meter(s) plumbed in correct direction.
6.  Verify brine reclamation properly plumbed (if applicable).
7.  Verify salt is available onsite
8.  Bypass installed? Yes  No  Master Bypass  Each Valve
9.  Water test kit provided to end user (only if specified).
10.  Fully photographed system and system plumbing.

## Pre-Startup

1.  Install brine line tubing.
2.  Install meter cables.

3.  Wire brine reclamation valves (if applicable).
4.  Install communication cables between valves
5.  Plug in all valves to GFCI approved wall receptacle.
6.  Open system bypass and isolate off softener inlets/outlets.

### Startup

1.  Set time of day on Valve #1.
2.  Initiate Manual Regeneration, advance to regeneration cycle 3 (Rapid Rinse) and slowly open softener inlet valve (roughly halfway) to fill mineral tank with water
3.  Once water is running to the drain, advance from regeneration cycle 3 (Rapid Rinse) back to the home screen. Reinitiate a manual regeneration and remain in cycle 1 (Backwash). With inlet valve halfway open, allow water flow and air expulsion. Verify all air is purged.
4.  Once all air is purged, fully open softener inlet valve to allow full backwash flow to drain. Continue until discharge water is free and clear of resin/debris.
5.  Advance to regeneration cycle 4 (Brine Tank Refill). Allow approximately 6 inches of water to fill in brine tank.
6.  Advance back through Service cycle (home screen) and cycle 1 (Backwash), to cycle 2 (Brine and Rinse). Verify water is properly drawn from brine tank.
7.  Close softener inlet bypass valve again. Repeat steps 2-5 for the additional resin tank.
8.  When purging and testing the final valve, allow cycle 2 (Brine & Rinse) to run until brine tank is dry.
9.  Once step 7 is complete, advance final valve to cycle 4 (Brine Tank Refill) and allow cycle to run completely, so that brine tank has correct service water level upon completion.
10.  Open system inlets/outlets and close system bypass.

### Operation Verification

1.  Run softened water fixtures in facility and verify proper meter operation for each valve, individually (use regen button to advance to different valves).
2.  If possible, run larger loads in facility to verify Progressive Flow (tank staging) is functioning correctly, per the flow rates indicated in the system specifications (Note, if necessary, valves may be temporarily re-programmed to actuate Progressive Service at lower flow rates, for confirmation of operation. This requires entering the system Master Programming Functionality. It also requires returning all set points to their previous levels when completed! Contact WCC for more details).
3.  If Brine Reclamation system is installed, initiate regeneration steps 2-4 (Brine Draw, Rapid Rinse, and Brine Refill) on Valve #1. Observe steps 2-4 to ensure that Brine Reclamation solenoid valves are functioning properly.

**Brine Tank Fill and Final Observations**

1.  Add salt to brine tank. How many lbs.? \_\_\_\_\_
2.  Other thoughts/concerns about this system  
\_\_\_\_\_  
\_\_\_\_\_
3.  Warranty Activated? Yes  No  If no, list any items that must be addressed prior to warranty activation:  
\_\_\_\_\_  
\_\_\_\_\_

**Trainees Present**

Name	Organization	Email
_____	_____	_____
_____	_____	_____
_____	_____	_____
_____	_____	_____

**Signature(s) of Start-Up Agents**

Signature: \_\_\_\_\_

Signature: \_\_\_\_\_

Signature: \_\_\_\_\_

**Signature of Installing Contractor**

***I CERTIFY THAT STARTUP AND TRAINING HAVE BEEN COMPLETED PER AGREEMENT.***

Name: \_\_\_\_\_

Company: \_\_\_\_\_

Signature: \_\_\_\_\_

Date: \_\_\_\_\_

# Commercial Water Softener Maintenance Procedures

*(TECHNICIAN TO INITIAL EACH ITEM SUCCESSFULLY TESTED.)*

Date \_\_\_\_\_

Project Name/Location \_\_\_\_\_

Technician \_\_\_\_\_

Model/Serial Number \_\_\_\_\_

## Pre-Maintenance Audit Checklist

1.  Test Water Quality Levels (Hardness on Cold/Hot)
2.  Check for Blinking Time? Yes  No
3.  Check Volume of Meter (Per System)
4.  Verify Appropriate Inlet Pressure (If Applicable)
5.  Verify System Outlet Pressure (If Applicable)
6.  Inspect Brine Tank and Overflow
7.  Check Brine Tank for Bridging/Salt Quality/Water Level
8.  Verify Correct Solenoid Valve Operation (If Applicable)
9.  Verify Correct Programming for Specific Softener
10.  Test/Verify Brine Reclamation Operation
11.  Check Inlet/Outlet Bypass

## Scheduled Maintenance Procedures

1.  Cycle Test Water Softener (Manual Regeneration)
  - Check for Leaks
  - Check Meters Counts Down Properly
  - Check If Brine Line Draws Water
  - Check Brine Line Refill

- 2.  Replace Any Parts That Have Failed
- 3.  Inspect/Clean Injectors and Brine Line
- 4.  Photograph System for Job Folder
- 5.  Record Pentair Serial Number
- 6.  Perform Any Work Covered by Warranty (If Applicable, see notes)
- 7.  Include 12 postage-paid water sample bottles per year, plus testing by WCC lab (if needed) (Results will include testing for hardness, iron, TDS, pH)
- 8.  Re-Examine Water Quality Levels (Hardness)

**Notes:**

---

---

**Billing Information**

Name: \_\_\_\_\_

Phone: \_\_\_\_\_

Street: \_\_\_\_\_

City/State/Zip: \_\_\_\_\_

Purchase Order #: \_\_\_\_\_

**Acceptance of Work:**

Tech. Signature: \_\_\_\_\_

Client Printed: \_\_\_\_\_

Client Signature: \_\_\_\_\_

# SERVICE

You must keep salt in the tank. The salt tank operates best when the salt level is below half full. If the tank is filled more than halfway, salt bridging may occur. The salt pellets wedge against each other and do not fall into the water at the bottom. Bridging will eventually provide no salt to make brine. The softener will re-charge but not recondition the media. A salt bridge can be broken up using a broom handle or similar rod. Carefully pound it into the salt and the pellets will collapse. After loosening the salt pellets, wait 2 hours and start a regeneration. A second recharge may be needed to fully recondition the media. You should also use sodium chloride pellet salt for water softeners. Other types of salt (rock or snow melting) will contain dirt or chemicals that will affect your softener.

## Checking for a Salt Bridge:

A hard crust or "salt bridge" can form in the lower half of the salt storage tank. This can be deceiving because the tank will appear to have plenty of salt, but underneath, salt is hardened and when the system regenerates, water cannot quite reach this level to be made into brine (water and salt).

## Breaking a Salt Bridge:

Take a wooden broom handle and carefully push it down into the salt, working it up and down. If the tool strikes a hard object, (be sure it's not the bottom or sides of the tank), it's probably a salt bridge. Carefully break the bridge with the broom handle. Do not pound on the walls of the tank.

***Note: Salt bridges are typically caused by high humidity or using the wrong kind of salt. And humid areas, it is best to fill the with less salt, more often. Use only nugget, pellet or coarse solar salt with a purity of 99.5% or higher. DO NOT use rock, block, granulated, and ice cream-making salts, or salt with iron removing additives.***

## Cleaning the Brine Injector Assembly:

It is recommended to clean the injector and injector screen annually to ensure proper system operation.

From time to time, a softeners brine water injection assembly can become clogged with dirt and debris. This resulted in for water softener regeneration, which, in-turn, can lead to poor softening performance. Plugging of a brine injector can also cause brine tanks to fill up with water, and eventually overflow.

Cleaning and unplugging a dirty brine injector is an easy process. For a detailed instructional video please visit <https://www.watercontrolinc.com/residential-technical-videos/>.



## Troubleshooting

<b>1. Softener Fails To Regenerate.</b>	A. Electrical service to unit has been interrupted.	A. Assure permanent electrical service (check fuse, plug, pull chain or switch).
	B. Timer programming bad (improper programming).	B. Check programming and reset as needed.
<b>2. Softener Delivers Hard Water.</b>	A. By-pass valve is open.	A. Close by-pass valve.
	B. No salt in brine tank.	B. Add salt to brine tank and maintain salt level above water level.
	C. Injectors or screen plugged.	C. Clean or replace injectors and screen.
	D. Insufficient water flowing into brine tank.	D. Check brine tank fill time and clean brine line flow if plugged.
	E. Hot water tank hardness.	E. Repeated flushings of the hot water tank is required.
	F. Flow meter jammed.	F. Check flow indicator light for flow. Remove obstruction from flow meter.
	G. Flow meter cable disconnected or not plugged into meter.	G. Check meter cable connection to timer and meter.
	H. Improper programming.	H. Reprogram the control to the proper regeneration type, inlet water hardness, capacity or flow meter size.
	I. Plugged brine line or air check.	I. Remove and clean any sediment from brine tank and brine valve assembly.
	J. Salt bridge has formed.	J. Refer to <i>Breaking a Salt Bridge</i> section in manual.
	K. No water in brine tank.	K. Ensure safety float is not stuck.
	L. Unit is plumbed backwards.	L. Check that the unit is plumbed correctly.
	M. Water hardness has increased or is set incorrectly.	M. Retest hardness and change settings.
	N. Water pressure is too low.	N. Line pressure must be at least 20 PSI.
<b>3. Unit Uses Too Much Salt.</b>	A. Improper salt setting.	A. Check salt usage and salt setting.
	B. Excessive water in brine tank.	B. See problem No. 7.
	C. Improper programming.	C. Check programming and reset as needed.
<b>4. Loss of Water Pressure.</b>	A. Iron buildup in line to water conditioner.	A. Clean line to water conditioner.
	B. Iron buildup in water conditioner.	B. Clean control and add resin cleaner to resin bed. Increase frequency of regeneration.

## Troubleshooting (continued)

<b>5. Loss of Resin Through Drain Line.</b>	A. Air in water system.	A. Assure that well system has proper air eliminator control and check for dry well condition.
	B. Drain line flow control is too large.	B. Ensure drain line flow control is sized correctly.
<b>6. Iron in Conditioned Water.</b>	A. Fouled resin bed.	A. Check backwash, brine draw and brine tank fill. Increase frequency of regeneration. Increase backwash time.
	B. Iron content exceeds recommended parameters.	B. Add iron removal filter or system.
<b>7. Excessive Water in Brine Tank.</b>	A. Plugged drain line flow control.	A. Clean flow control.
	B. Brine valve failure.	B. Clean brine valve.
	C. Improper programming.	C. Check programming and reset as needed.
<b>8. Salt Water in Service Line.</b>	A. Plugged injector system.	A. Clean injector and replace screen.
	B. Improper programming.	B. Check programming and reset as needed.
	C. Foreign material in brine	C. Clean or replace brine valve.
	D. Foreign material in brine line	D. Clean brine line flow control.
	E. Low water pressure.	E. Raise water pressure.
<b>9. Softener Fails to Draw Brine.</b>	A. Drain line flow control is plugged.	A. Clean drain line flow control.
	B. Injector is plugged.	B. Clean or replace injectors.
	C. Improper programming.	C. Check programming and reset as needed.
	D. Line pressure is too low.	D. Increase line pressure (line pressure must be at least 20 PSI at all times.)
<b>10. Drain Flows Continuously.</b>	A. Foreign material in control.	A. Remove piston assembly and inspect bore, remove foreign material & check control in various ports.
<b>12. Loss of capacity.</b>	A. Increased raw water hardness	A. Reset unit to the new capacity.
	B. Brine concentration and/or quantity.	B. Keep brine tank full of salt at all times. Clean it yearly. Salt may be bridged. If using a salt grid plate ensure refill water is over it.
	C. Resin fouling. Future fouling.	C. Call Water Control Corp, find out how to confirm it, clean the resin and prevent.
	D. Poor distribution, channeling (uneven bed surface).	D. Call Water Control Corp. Check distributors and backwash flow.

# TROUBLESHOOTING

## Error Codes

**NOTE: Error codes appear on the In Service display.**

Error Code	Error Type	Cause	Reset and Recovery
0	Cam Sense Error	The valve drive took longer than 6 minutes to advance to the next regeneration position	<p>Unplug the unit and examine the powerhead. Verify that all cam switches are connected to the circuit board and functioning properly. Verify that the motor and drive train components are in good condition and assembled properly. Check the valve and verify that the piston travels freely. Replace/reassemble the various components as necessary.</p> <p>Plug the unit back in and observe its behavior. The unit should cycle to the next valve position and stop. If the error re-occurs, unplug the unit and contact technical support.</p>
1	Cycle Step Error	The control experienced an unexpected cycle input	<p>Unplug the unit and examine the powerhead. Verify that all cam switches are connected to the circuit board and functioning properly. Enter Master Programming mode and verify that the valve type and system type are set correctly with regard to the unit itself.</p> <p>Step the unit through a manual regeneration and verify that it functions correctly. If the error re-occurs unplug the unit and contact technical support.</p>
2	Regen Failure	The system has not regenerated for more than 99 days (or 7 days if the Control Type has been set to Day-of-Week)	<p>Perform a Manual Regeneration to reset the error code.</p> <p>If the system is metered, verify that it is measuring flow by running service water and watching for the flow indicator on the display. If the unit does not measure flow, verify that the meter cable is connected properly and that the meter is functioning properly.</p> <p>Enter a Master Programming Mode and verify that the unit is configured properly. As appropriate for the valve configuration, check that the correct system capacity has been selected, that the day override is set properly, and that meter is identified correctly. If the unit is configured as a Day-of-Week system, verify that at least one day is set ON. Correct the settings as necessary.</p>
3	Memory Error	Control board memory failure	Perform a Master Reset and reconfigure the system via Master Programming Mode. After reconfiguring the system, step the valve through a manual regeneration. If the error re-occurs unplug the unit and contact technical support.
UD	Upper Drive Sync	Power failure install programming change	Valve will automatically recover.

# FLECK 9100 VALVE

## LIGHT COMMERCIAL/RESIDENTIAL TWIN TANK VALVE

PRECISION CONTROL AND IMMEDIATE REGENERATION



### FEATURES/BENEFITS

Fleck Fiber-reinforced polymer valve body for superior strength and durability, non-corrosive, and UV-resistant

Continuous service flow rate of 20.1 GPM with a backwash of 8.5 GPM

Backwash capability accommodates softener tanks up to 16"

Fully adjustable 5-cycle control for efficient and reliable water treatment system

Time-tested, hydraulically-balanced

piston for service and regeneration  
Rugged-built electromechanical timer designed with heavy duty 3/8" wide plastic gears

Salt and water savings by using 100% capacity of the tank in service before switching to the second tank

Regenerates immediately when needed for continuous soft water

Regenerates with soft water keeping system clean for optimum operating efficiency and minimum maintenance

### OPTIONS

Brine cam auxiliary switch

Electromechanical timer auxiliary switch

Plumbing connections in 3/4" to 1-1/4" NPT, BSP, and sweat

Fiber-reinforced polymer or stainless steel bypass valve

**SXT**-Large LCD display and user-selectable time clock or metered function; usable for filtration and softener systems

**XT**- Offers a two-line, 16 character LCD backlit display for easy entering of master and user programming as well as view of diagnostics

**Electromechanical Timer**- Simple to adjust and easy to service with quick access to all internal components



TESTED and CERTIFIED by the WQA to NSF/ANSI Standard 44 for Water Softener Performance.



TESTED and CERTIFIED by the WQA to NSF/ANSI Standard 372 for Lead Free Compliance.



UL recognized to 979



Restriction of Hazardous Substance Compliant

## FLOW RATES (50 PSI INLET) – VALVE ALONE

Continuous 15 psi drop	3/4" Meter:	18 GPM (4.1 m <sup>3</sup> /h)
	1" Meter:	20 GPM (4.5 m <sup>3</sup> /h)
Peak 25 psi drop	3/4" Meter:	23 GPM (5.5 m <sup>3</sup> /h)
	1" Meter:	26 GPM (5.9 m <sup>3</sup> /h)
Cv flow at 1 psi drop	3/4" Meter:	4.6
	1" Meter:	5.1
Max. Backwash 25 psi drop	3/4" Meter:	8 GPM (2 m <sup>3</sup> /h)
	1" Meter:	8 GPM (2 m <sup>3</sup> /h)

## REGENERATION

Downflow/Upflow	Downflow only
Adjustable Cycles	Yes
Time Available	
Electromechanical:	0 - 164 min/regeneration
SXT:	0 - 199 min/cycle
XT:	0 - 240 min/cycle

## METER INFORMATION

Meter Accuracy	
3/4" Paddle:	0.25 - 15 GPM ± 5% (0.06 - 3 m <sup>3</sup> /h)
1" Paddle:	0.7 - 40 GPM ± 5% (0.16 - 9 m <sup>3</sup> /h)

## METER INFORMATION (CONTINUED)

Meter Capacity Range	
3/4" Standard:	125 - 2,125 gal (0.5 - 8 m <sup>3</sup> )
3/4" Extended:	625 - 10,625 gal (2.5 - 40 m <sup>3</sup> )
1" Standard:	310 - 5,270 gal (1.2 - 20 m <sup>3</sup> )
1" Extended:	1,550 - 26,350 gal (6 - 100 m <sup>3</sup> )
SXT:	1 - 999,900 gal (0 - 3,785 m <sup>3</sup> )
XT:	1,000 - 9,900,000 gal (3.8 - 37,476 m <sup>3</sup> )

## DIMENSIONS

Distributor Pilot	1.05" O.D. (32 mm)
Drain Line	1/2" NPTF
Brine Valve 1600:	3/8"
Injector System	1600
Mounting Base	2.5" - 8 NPSM
Height from Top of Tank	7.3" (185 mm)
Riser Tube Diameter	3/4" (19 mm)
Riser Height	1/4" Below top of tank

## TYPICAL APPLICATIONS

Water Softener	6 - 16" diameter
----------------	------------------

## ADDITIONAL INFORMATION

Electrical Rating	24/110/220V 50/60 Hz
Max VA	8.9
Estimated Shipping Weight	
Mechanical Valve:	14-1/2 lbs
SXT and XT Valve:	12 lbs
Pressure	
Hydrostatic:	300 psi (20 bar)
Working:	20 - 125 psi (1.4 - 8.5 bar)
Temperature	
Cold Water Valve:	34 - 110°F (1 - 43°C)



13845 BISHOPS DR., SUITE 200, BROOKFIELD, WI 53005 USA  
P: 262.238.4400 | WATERPURIFICATION.PENTAIR.COM | CUSTOMER CARE: 800.279.9404 | tech-support@pentair.com  
© 2018 Pentair Residential Filtration, LLC. All rights reserved.

§For a detailed list of where Pentair trademarks are registered, please visit [waterpurification.pentair.com/brands](http://waterpurification.pentair.com/brands). Pentair trademarks and logos are owned by Pentair plc or its affiliates. Third party registered and unregistered trademarks and logos are the property of their respective owners.

40821 REV E JL18

# 18 Inch Round Brine Tanks



**18x40 Brine Tank with Blow Molded Cover**



**18x33 Brine Tank with Black Injection Molded Cover**

Clack's 18 inch blow molded round brine tanks offer a refreshing look in the residential and light commercial brine tank field. Durable materials and the latest in plastic processing technology provide trouble-free performance. Ultraviolet inhibitors (UVI) are now standard in all tanks except black, which has a natural resistance to the sun's rays. Three different sizes are available for up to 450 lbs. of salt capacity.

## Advantages:

- Attractive design to meet customer appeals with four modern stock colors to choose from — almond, blue, black and white. (Custom colors available.)
- Blow molded from high-density polyethylene to give exceptional environmental stress-crack properties providing years of trouble-free service.
- These tanks can be top loaded on other Clack water treatment components and drinking water systems to substantially reduce total shipping costs.
- All round brine tanks are individually shipped in a durable 150# test reshipper carton.
- Optional injection molded grid promotes uniform brining and reduced salt bridging.

ORDER NUMBER	DESCRIPTION
G21826BB1C00	18x36 Blue Brine Tank with Blow Molded Cover
G21833[*]B1C00	18x33 Brine Tank with Blow Molded Cover
G21833[*]G7CWG	18x33 Brine Tank with Black Injection Molded Cover
G21840[*]B1C00	18x40 Brine Tank with Blow Molded Cover
G21840[*]G7CWG	18x40 Brine Tank with Black Injection Molded Cover

[\*] Color code digit: A - Almond, B - Blue, C - Black, W - White

TANK SIZE	LIQUID CAPACITY		SALT CAPACITY		DIAMETER		HEIGHT W/ LID		SHIPPING WEIGHT		MASTER CARTON
in.	gal.	liters	lbs.	Kg	in.	cm	in.	cm	lbs.	Kg	ft. <sup>3</sup> /units per
18 x 26	27	102	275	125	18½	47	25	64	12	5.5	5.5/1
18 x 33	36	136	375	170	18½	47	33¼	84	12	5.5	7/1
18 x 40	43	163	450	205	18½	47	40¾	104	15	6.8	9/1

# Commercial/Industrial Rotationally Molded Brine Tanks



Commercial and industrial water softeners require a large volume of brine during each regeneration.

From a capacity of 95 gallons to 500 gallons, our Rotationally Molded Brine Tanks are built to last.

Molded out of durable, chemically resistant high density polyethylene, their ¼" seamless walls won't bulge.

Rotationally Molded Brine Tanks are strong enough to handle your toughest brine requirements. (All tanks and covers are black.)

## Also Available:

24" Plastic Grids

30" Plastic Grids

TANK SIZE	ORDER NUMBER	DIAMETER	HEIGHT	SALT CAPACITY	VOLUME	WEIGHT
24 x 48	G22448CB1P00	24"	48"	800 lbs.	95 gal.	30 lbs.
24 x 60	G22460CB1P00	24"	60"	1000 lbs.	115 gal.	32 lbs.
30 x 48	G23048CB1P00	30"	48"	1200 lbs.	145 gal.	48 lbs.
30 x 60	G23060CB1P00	30"	60"	1600 lbs.	180 gal.	56 lbs.
39 x 48	G23948CB1P00	39"	48"	2200 lbs.	250 gal.	67 lbs.
39 x 60	G23960CB1P00	39"	60"	2700 lbs.	300 gal.	80 lbs.
42 x 60	G24260CB1P00	42"	60"	3100 lbs.	350 gal.	84 lbs.
50 x 60	G25060CB1P00	50"	60"	4500 lbs.	500 gal.	107 lbs.

# Official Warranty

## Water Control Corporation

### Commercial Water Softeners

#### Limited Warranty

Water Control Corporation warrants the water softener control valve, plastic brine tank(s), and fiberglass-reinforced mineral tank(s) to be free of manufacturers defects for the lesser of 18 months from shipment or 12 months from system startup. Epoxy-lined steel mineral tank(s) shall be free from manufacturers defects for the lesser of 30 months from shipment or 24 months from system startup. We will, at our discretion, repair or replace defective products. This warranty does not include any costs associated with removal of defective products, or installation of replacement products. All replacement parts will be provided FOB Ramsey, MN. This warranty is transferable.

#### DISCLAIMER OF IMPLIED WARRANTIES

Water Control Corporation makes no warranties except those expressly stated in this document. To the extent permitted by the laws of the applicable state, **ALL WARRANTIES CONTAINED IN THIS DOCUMENT ARE EXPRESSLY IN LIEU OF, AND WATER CONTROL CORPORATION EXPRESSLY DISCLAIMS, ANY AND ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING THE WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.**

#### WHAT IS NOT COVERED BY THESE WARRANTIES

1. Conditions and damages resulting from any of the following:
  - Wear caused by unfavorable water conditions
  - Improper installation, delivery, or maintenance
  - Failure to provide system with adequate salt
  - Any repair, modification, alteration, or adjustment not authorized by the manufacturer or an authorized servicer
  - Misuse, abuse, accidents, or unreasonable use
  - Improper setting of any control
  - Incorrect electric current, voltage, or supply
2. Warranties are void if the original serial numbers have been removed, altered, or cannot be readily determined
3. The cost of service or service call to:
  - Correct installation errors
  - Instruct the user on proper use of the product
  - Transport the product to the servicer
4. Any costs associated with removal of defective products, or installation of replacement products.
5. Consequential, special, or incidental damages sustained by any person as a result of the breach of these warranties. Some states do not allow the exclusion or limitation of consequential or incidental damages, so the above exclusion may not apply to you.