

# 2014

## Pike Service Manual

---



# SRAM LLC WARRANTY

## EXTENT OF LIMITED WARRANTY

Except as otherwise set forth herein, SRAM warrants its products to be free from defects in materials or workmanship for a period of two years after original purchase. This warranty only applies to the original owner and is not transferable. Claims under this warranty must be made through the retailer where the bicycle or the SRAM component was purchased. Original proof of purchase is required. **Except as described herein, SRAM makes no other warranties, guaranties, or representations of any type (express or implied), and all warranties (including any implied warranties of reasonable care, merchantability, or fitness for a particular purpose) are hereby disclaimed.**

## LOCAL LAW

This warranty statement gives the customer specific legal rights. The customer may also have other rights which vary from state to state (USA), from province to province (Canada), and from country to country elsewhere in the world.

To the extent that this warranty statement is inconsistent with the local law, this warranty shall be deemed modified to be consistent with such law, under such local law, certain disclaimers and limitations of this warranty statement may apply to the customer. For example, some states in the United States of America, as well as some governments outside of the United States (including provinces in Canada) may:

- a. Preclude the disclaimers and limitations of this warranty statement from limiting the statutory rights of the consumer (e.g. United Kingdom).
- b. Otherwise restrict the ability of a manufacturer to enforce such disclaimers or limitations.

## For Australian customers:

This SRAM limited warranty is provided in Australia by SRAM LLC, 1333 North Kingsbury, 4th floor, Chicago, Illinois, 60642, USA. To make a warranty claim please contact the retailer from whom you purchased this SRAM product. Alternatively, you may make a claim by contacting SRAM Australia, 6 Marco Court, Rowville 3178, Australia. For valid claims SRAM will, at its option, either repair or replace your SRAM product. Any expenses incurred in making the warranty claim are your responsibility. The benefits given by this warranty are additional to other rights and remedies that you may have under laws relating to our products. Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

## LIMITATIONS OF LIABILITY

To the extent allowed by local law, except for the obligations specifically set forth in this warranty statement, in no event shall SRAM or its third party suppliers be liable for direct, indirect, special, incidental, or consequential damages.

## LIMITATIONS OF WARRANTY

This warranty does not apply to products that have been incorrectly installed and/or adjusted according to the respective SRAM user manual. The SRAM user manuals can be found online at [sram.com](http://sram.com), [rockshox.com](http://rockshox.com), [avidbike.com](http://avidbike.com), [truvativ.com](http://truvativ.com), or [zipp.com](http://zipp.com).

This warranty does not apply to damage to the product caused by a crash, impact, abuse of the product, non-compliance with manufacturers specifications of usage or any other circumstances in which the product has been subjected to forces or loads beyond its design.

This warranty does not apply when the product has been modified, including, but not limited to any attempt to open or repair any electronic and electronic related components, including the motor, controller, battery packs, wiring harnesses, switches, and chargers.

This warranty does not apply when the serial number or production code has been deliberately altered, defaced or removed.

This warranty does not apply to normal wear and tear. Wear and tear parts are subject to damage as a result of normal use, failure to service according to SRAM recommendations and/or riding or installation in conditions or applications other than recommended.

## Wear and tear parts are identified as:

- Dust seals
- Bushings
- Air sealing o-rings
- Glide rings
- Rubber moving parts
- Foam rings
- Rear shock mounting hardware and main seals
- Upper tubes (stanchions)
- Stripped threads/bolts (aluminium, titanium, magnesium or steel)
- Brake sleeves
- Brake pads
- Chains
- Sprockets
- Cassettes
- Shifter and brake cables (inner and outer)
- Handlebar grips
- Shifter grips
- Jockey wheels
- Disc brake rotors
- Wheel braking surfaces
- Bottomout pads
- Bearings
- Bearing races
- Pawls
- Transmission gears
- Spokes
- Free hubs
- Aero bar pads
- Corrosion
- Tools
- Motors
- Batteries

**Notwithstanding anything else set forth herein**, the battery pack and charger warranty does not include damage from power surges, use of improper charger, improper maintenance, or such other misuse.

This warranty shall not cover damages caused by the use of parts of different manufacturers.

This warranty shall not cover damages caused by the use of parts that are not compatible, suitable and/or authorised by SRAM for use with SRAM components.

This warranty shall not cover damages resulting from commercial (rental) use.

# TABLE OF CONTENTS

<b>Exploded View - RCT3/Dual Position Air</b> .....	<b>4</b>
<b>Exploded View - RC/Solo Air</b> .....	<b>5</b>
<b>RockShox Suspension Service</b> .....	<b>6</b>
Parts and Tools Needed for Service .....	6
<b>Lower Leg Removal</b> .....	<b>7</b>
Lower Leg Seal Service .....	9
<b>Solo Air Spring Service</b> .....	<b>12</b>
Optional Travel Change Adjustment .....	12
Air Spring Removal .....	13
Air Spring Installation.....	18
<b>Damper Service</b> .....	<b>20</b>
Charger Damper™ Removal.....	20
Charger Damper™ Assembly and Bleed .....	27
<b>Lower Leg Assembly</b> .....	<b>37</b>




# **SAFETY FIRST!**

We care about YOU. Please, always wear your safety glasses and protective gloves when servicing RockShox products.  
Protect yourself! Wear your safety gear!


**Exploded View - RCT3/Dual Position Air**

**RCT3**

**Dual Position Air (DPA)**



# Exploded View - RC/Solo Air



## RockShox Suspension Service

We recommend that you have your RockShox suspension serviced by a qualified bicycle mechanic. Servicing RockShox suspension requires knowledge of suspension components as well as the special tools and fluids used for service.

For exploded diagram and part number information, please refer to the Spare Parts Catalog available on our website at [sram.com/service](http://sram.com/service). For order information, please contact your local SRAM distributor or dealer.

Information contained in this publication is subject to change at any time without prior notice. For the latest technical information, please visit our website at [sram.com/service](http://sram.com/service).

**Your product's appearance may differ from the pictures contained in this publication.**

### Parts and Tools Needed for Service

- Safety glasses
- Nitrile gloves
- Apron
- Clean, lint-free rags
- Oil pan
- Isopropyl alcohol
- Bike stand
- Bench vise with aluminum soft jaws
- RockShox 3wt suspension fluid
- RockShox 0w-30 suspension fluid
- Suspension specific grease
- Shock pump
- Seal installation tool
- Downhill tire lever
- Rubber mallet
- Flat head screwdriver
- Schrader valve core tool
- (2) 21, and (1) 25 mm open end wrenches
- 21 and 25 mm crowfoot wrenches
- 2, 2.5, 4, and 5 mm hex wrenches
- 2, 2.5, 4, and 5 mm hex bit sockets
- 6, 10, 15, 24, and 30 mm socket wrenches
- Torque wrench
- 5/8" bit socket
- Needle-nose pliers
- Large internal snap ring pliers
- Small internal snap ring pliers
- Pick
- Long plastic or wooden dowel
- Rockshox Syringe with Charger bleed tip
- Loctite® Threadlocker Blue 242®

### SAFETY INSTRUCTIONS

Always wear safety glasses and nitrile gloves when working with suspension fluid.

Place an oil pan on the floor underneath the area where you will be working on the fork.

## Lower Leg Removal

- 1 Remove the air valve cap from the top cap located on the non-drive side fork leg.



- 2 Use a small hex wrench to depress the Schrader valve and release all of the air pressure from the air chamber.


Use a Schrader valve core tool to remove the valve core from the valve body. Cycle the air shaft a few times to release the remaining trapped air. Install a new Schrader valve.

### **⚠ CAUTION- EYE HAZARD**


Verify all pressure is removed from the fork before proceeding. Failure to do so can result in injury and/or damage to the fork. Wear safety glasses.



- 3 Use a 2.5 mm hex wrench to loosen the set screw and remove the rebound adjuster knob located at the bottom of the drive side fork leg.




- 4 Use a 5 mm hex wrench to loosen both bottom bolts 3 to 4 turns.





- 5** Place an oil pan beneath the fork to catch any draining fluid. Use a plastic mallet to firmly strike each bottom bolt to dislodge the air and damper shafts from the lower legs. Use a 5 mm hex wrench to remove the bottom bolt from the lower legs.



- 6** Firmly pull the lower legs downward until fluid begins to drain. Continue pulling downward to remove the lower legs from the fork. *If the lower legs do not slide off of the upper tubes or if fluid doesn't drain from either side, the press fit of the shaft(s) to the lower legs may still be engaged. Reinstall the bottom bolts 2 to 3 turns and repeat step 5.*

**NOTICE**

Do not hit the brake arch with any tool when removing the lower leg as this could damage the fork.



## Lower Leg Seal Service

- 1 Place the tip of a downhill tire lever underneath the lower lip of the dust wiper seal.

### NOTICE

If using a flat head screwdriver, make sure it has a round shaft. A screwdriver with a square shaft will damage the fork leg.



- 2 Stabilize the lower legs on a bench top or on the floor. Press down on the tire lever handle to remove the dust wiper seal. Repeat on the other side.

### NOTICE

Keep the lower leg assembly stable. Do not allow the lower legs to twist in opposite directions, compress toward each other, or be pulled apart. This will damage the lower leg.



- 3 Use your fingers to remove and discard the foam rings inside the lower legs.



- 4 Soak the new foam rings in RockShox 0w-30 suspension fluid.



- 5** Spray isopropyl alcohol on the inside and outside of the lower legs. Wipe the outside of the lower legs with a rag.

Wrap a rag around a long dowel and insert it into each lower leg to clean the inside of the lower leg.




- 6** Reinstall new foam rings on the top bushings in the lower legs.



- 7** Remove the wire spring from the new dust wiper seal and set aside.



- 8** Insert the narrow end of a new dust wiper seal into the recessed end of the seal installation tool.



**9** Hold the lower legs steady and use the seal installation tool to push the dust wiper seal evenly into the lower legs until the seal surface is flush with the top of the lower leg surface.

Reinstall the wire spring onto the dust wiper seal.

Repeat steps 7 and 8 for the other side of the lower legs.



# Solo Air Spring Service

## Solo Air Travel Change Adjustment

To change the travel in your Rockshox Pike fork, use the chart below to help determine the necessary air shaft length and recommended number of bottomless tokens for your wheel size. Some shaft lengths are compatible with multiple wheel sizes. The air shaft will have the wheel size and travel information located near the bottom. This chart is for Solo Air forks only.

For ordering information, please contact your local SRAM distributor or dealer. Please refer to the Spare Parts Catalog available on our website at [sram.com/service](http://sram.com/service) for further information.

29" Wheel		27.5" Wheel		26" Wheel	
Desired Travel	Recommended Bottomless Tokens	Desired Travel	Recommended Bottomless Tokens	Desired Travel	Recommended Bottomless Tokens
29-160 mm	1	-	-	-	-
29-150 mm	1	-	-	-	-
29-140 mm	2	27-160 mm	0	-	-
29-130 mm	3	27-150 mm	0	26-160 mm	0
29-120 mm	4	27-140 mm	1	26-150 mm	0
-	-	27-130 mm	2	26-140 mm	1
-	-	27-120 mm	3	26-130 mm	2
-	-	-	-	26-120 mm	3



## Air Spring Removal

### NOTICE

Inspect each part for scratches. Do not scratch any sealing surfaces when servicing your suspension. Scratches can cause leaks.

When replacing seals and o-rings, use your fingers or a pick to remove the seal or o-ring. Spray isopropyl alcohol on each part and clean with a rag. Apply grease to the new seal or o-ring.

- 1 Verify all air pressure was removed earlier during lower leg removal.

### ⚠ CAUTION- EYE HAZARD

Verify all pressure is removed from the fork before proceeding. Failure to do so can result in injury and/or damage to the fork. Wear safety glasses.




- 2 **Dual Position Air Only:** Use a 10 mm socket wrench to loosen and remove the DPA Adjuster Knob.



- 3 Use a 24 mm socket wrench to remove the top cap. Spray isopropyl alcohol on the upper tube threads and clean the threads with a rag.




- 4 Use a pick or your fingers to remove the top cap o-ring. Use your fingers to install a new o-ring. Do not apply any grease to the top cap threads.



**5 Dual Position Air Only:** Push the air shaft into the upper tube to prevent scratching the air shaft when removing the retaining ring. Scratches on the air shaft will allow air to bypass the seal head into the lower legs, resulting in reduced spring performance.

Use a flat head screw driver to push the DPA seal head tab under the retaining ring.


Place the tips of large snap ring pliers into the eyelets of the retaining ring. Press firmly on the pliers to push the DPA seal head into the upper tube enough to compress and remove the retaining ring.



**Solo Air Only:** Use a flat head screw driver to push the SA seal head tab under the retaining ring.


Place your finger over the end of the air spring shaft to prevent scratching the air shaft when removing the retaining ring. Scratches on the air shaft will allow air to bypass the seal head into the lower legs, resulting in reduced spring performance.

Place the tips of large internal snap ring pliers into the eyelets of the retaining ring. Press firmly on the pliers to push the SA seal head into the upper tube enough to compress and remove the retaining ring. Slide the retaining ring onto your finger and release the air spring shaft.



**6** Install the bottom bolt in the air shaft to pull the air shaft out of the upper tube.

Firmly pull on the air shaft to remove the air shaft assembly from the upper tube. Clean and inspect the assembly for damage.



**7** Spray isopropyl alcohol on the inside and outside of the upper tube. Wipe the outside of the upper tube with a clean rag.

Wrap a rag around a long dowel and insert it into the upper tube to clean inside the upper tube.





**8** Remove the seal head, wave spring, and backup ring from the air shaft.







- 9** Use a pick or your fingers to remove the outer seal head o-ring.  
Use a pick to pierce and remove the inner o-ring and scraper.  
Use your fingers to install new o-rings and scraper.



- 10 Dual Position Air Only:** Use a pick or your fingers to remove the outer o-ring. Use a pick to pierce and remove the inner o-ring.  
Use your fingers to install new o-rings.



- Solo Air Only:** Use a pick or your fingers to remove the air piston quad ring.  
Use your fingers to install a new quad ring.



**11** Use your fingers to remove the bumper cone from the air shaft.

**Dual Position Air Only:** Install a new bumper cone with the broad base facing the DPA piston.




**Solo Air Only:** Install a new bumper cone with the broad base facing away from the SA piston.



## Air Spring Installation

- 1** Apply a liberal amount of suspension specific grease to the air piston and seal head.





- 2** Install a new backup ring, new wave spring, and the seal head, in that order, onto the air shaft.



- 3** **Dual Position Air Only:** Firmly push the air shaft assembly into the bottom of the upper tube while gently rocking the air shaft side to side.

**Solo Air Only:** Firmly push the air shaft assembly into the bottom of the upper tube while gently rocking the air shaft side to side. Leave the seal head exposed.




- 4** **Dual Position Air Only:** Push the air shaft into the upper tube to prevent scratching the air shaft when installing the retaining ring.

Place the tips of large internal snap ring pliers into the eyelets of the retaining ring, then use the pliers to push the seal head into the upper tube while installing the retaining ring into the groove. The tab of the seal head should be positioned between the retaining ring eyelets.

Install the bottom bolt in the air shaft to pull the air shaft out of the upper tube.

**Check that the retaining ring is properly seated in the retaining ring groove by using the snap ring pliers to rotate the retaining ring and seal head back and forth a few times, then firmly pull down on the air shaft.**

*Retaining rings have a sharper-edged side and a rounder-edged side. Installing retaining rings with the sharper-edged side facing the tool will allow for easier installation and removal.*




**Solo Air Only:** While the seal head is exposed, push the air shaft into the upper tube to prevent scratching when installing the retaining ring. Then push the seal head into the upper tube.

Place the tips of large internal snap ring pliers into the eyelets of the retaining ring and install the retaining ring into the groove. The tab of the seal head should be positioned between the retaining ring eyelets.

Install the bottom bolt in the air shaft to pull the air shaft out of the upper tube.

**Check that the retaining ring is properly seated in the retaining ring groove by using the snap ring pliers to rotate the retaining ring and seal head back and forth a few times, then firmly pull down on the air shaft.**

*Retaining rings have a sharper-edged side and a rounder-edged side. Installing retaining rings with the sharper-edged side facing the tool will allow for easier installation and removal.*



- 5** Insert the top cap into the top of the upper tube. Use a torque wrench with a 24 mm socket to tighten the top cap to 28 N·m (250 in-lb).



- 6** **Dual Position Air Only:** Place the DPA adjuster knob and the knob retaining bolt onto the top cap with the long tab near the front of the crown. Turn the DPA adjuster knob counter-clockwise until it engages the first detent space. Use a torque wrench with a 10 mm socket to tighten the knob retaining nut to 1.7-2.2 N·m (15-20 in-lb).



## Damper Service

### Charger Damper™ Removal

#### NOTICE

Use aluminum soft jaws to protect the Charger Damper assembly when using a vice.

Inspect each part for scratches. Do not scratch any sealing surfaces when servicing your suspension. Scratches can cause leaks.

When replacing seals and o-rings, use your fingers or a pick to remove the seal or o-ring. Spray isopropyl alcohol on each part and clean with a rag. Apply grease to the new seal or o-ring.

- 1 RCT3 Only:** Use a 2 mm hex wrench to remove the low speed adjuster knob bolt. Remove the low speed adjuster knob.  
Use a 6 mm socket wrench to remove the knob retaining nut. Remove the compression mode adjuster knob.




- RC Only:** Use a 4 mm hex wrench to remove the knob retaining nut. Remove the low speed adjuster knob.





- 2** Use a 30 mm socket wrench to loosen the damper top cap. Remove the Charger Damper assembly and clean the upper tube threads with a rag.




**3** Use a pick or your fingers to remove the damper top cap o-ring.



**4** Lightly clamp the damper assembly into a bike stand with the rebound shaft facing up.  
Place a 21 mm open wrench on the wrench flats of the damper. Place another 21 mm open end wrench on the damper seal head. Hold the lower wrench in place while turning the upper wrench counter-clockwise to loosen and remove the rebound assembly.




**5** Remove the damper assembly from the bicycle stand and pour the suspension fluid into an oil pan.



**6** Remove the seal head assembly from the rebound damper.



**7** Use a pick or your fingers to remove the seal head o-ring. Use a pick to pierce and remove the scraper. Use your fingers to install a new o-ring and scraper.



**8** Use your fingers to remove the glide ring from the rebound damper. Use your fingers to install a new glide ring.



**9** Clamp the wrench flats of the Charger Damper™ coupler into a vice. Place a 21 mm open wrench on the wrench flats of the cartridge tube. Hold the bladder assembly in place and turn the wrench counter-clockwise to loosen and remove the cartridge tube from the coupler. Pour the suspension fluid into an oil pan.

**NOTICE**


Do not clamp the cartridge tube in the vise.




**10 RCT3 Only:** Use small snap ring pliers to remove the retaining ring from the low speed compression adjuster.




**RC Only:** Use small snap ring pliers to remove the retaining ring from the bleed plug.



**11 RCT3 Only:** Use needle-nose pliers to remove the low speed compression adjuster from the compression top cap assembly.  
Use a pick to remove the o-ring on the low speed compression adjuster.  
Use your fingers to install a new o-ring.



**RC Only:** Use needle-nose pliers to remove the bleed plug from the compression adjuster.  
Use a pick to remove the o-ring on the bleed plug.  
Use your fingers to install a new o-ring.





**12 RCT3 Only:** Use small snap ring pliers to remove the retaining ring from the compression cam assembly.

**RC Only:** Use small snap ring pliers to remove the retaining ring from the compression adjuster.




**13** Use a 2.5 mm hex wrench to remove the low speed compression needle.



**14 RCT3 Only:** Use needle-nose pliers to grasp the wrench flats on the compression cam assembly. Pull the compression cam assembly out of the bladder assembly.

Use a pick or your fingers to remove the o-ring on the compression cam assembly. Use a pick to pierce and remove the inner o-ring.


Use your fingers to install the new o-rings.



**RC Only:** Use needle-nose pliers to grasp the wrench flats on the compression adjuster. Pull the compression adjuster out of the bladder assembly.

Use a pick or your fingers to remove the o-ring on the compression adjuster.



Use your fingers to install a new o-ring.



**15** Lightly clamp the bladder assembly into a vise. Use a 30 mm socket wrench to remove the compression top cap assembly from the bladder assembly.

Use a pick or your fingers to remove the o-ring on the compression top cap assembly.

Use your fingers to install a new o-ring.




**16** Turn the bladder assembly over to remove the compression piston assembly.


Use a pick or your fingers to remove the o-ring on the compression piston assembly.

Use your fingers to install a new o-ring.


Do not apply grease to this o-ring.



- 17** Clamp a 5/8" bit socket into a vise. Set the bladder assembly on the bit socket, and use a 25 mm open end wrench to remove the coupler.
- Use a pick or your fingers to remove the o-ring inside the coupler.
- Use your fingers to install a new o-ring.



- 18** Remove the bladder from the bladder sleeve and inspect the bladder for any tears or cracks. If there are any tears or cracks, replace the bladder. Spray isopropyl alcohol on the bladder and clean it with a rag.



## Charger Damper™ Assembly and Bleed

### NOTICE


Use aluminum soft jaws to protect the Charger Damper™ assembly when using a vice.

Inspect each part for scratches. Do not scratch any sealing surfaces when servicing your suspension. Scratches can cause leaks.


When replacing seals and o-rings, use your fingers or a pick to remove the seal or o-ring. Spray isopropyl alcohol on each part and clean with a rag. Apply grease to the new seal or o-ring.

- 1** Apply a liberal amount of suspension specific grease onto both ends of the bladder.

Thread the top cap and coupler into either side of the bladder assembly.



- 2** Lightly clamp the coupler wrench flats into a vice. Use a torque wrench with a 30 mm socket to tighten the top cap to 4.5-5.5 N•m (40-50 in-lb).




- 3** Spray isopropyl alcohol on the inside and outside of the cartridge tube. Wipe the outside of the cartridge tube with a rag.

Wrap a rag around a long dowel and insert it into the cartridge tube to clean inside the upper tube.



- 4** Lightly clamp the cartridge tube into a bike stand. Thread the rebound assembly into the cartridge tube by hand.

Place a 21 mm open wrench on the wrench flats of the damper. Place a torque wrench with a 21 mm crowfoot open end wrench on the damper seal head. Hold the lower wrench in place while turning the upper wrench clockwise to tighten the damper seal head to 9-10 N•m (80-90 in-lb).




- 5** Pour RockShox 3wt suspension fluid into the cartridge tube until it is approximately half full.




- 6** Use the palm of your hand or a rag to cover the cartridge tube, and cycle the rebound assembly shaft a few times to help pre-bleed air from the damper.

Pour additional RockShox 3wt suspension fluid into the cartridge tube until the fluid is level with the top of the tube.

Use your finger to wipe any air bubbles from the surface of the fluid.



- 7** Wrap a rag around the cartridge tube. Insert the compression piston assembly into the cartridge tube.  
Spray isopropyl alcohol on the cartridge tube threads and clean the threads with a rag.




- 8** Spray isopropyl alcohol on the threads inside the coupler and clean the threads with a rag.



- 9** Apply a small amount of Loctite® Threadlocker Blue 242® to the coupler threads.


**NOTICE**

Do not allow the Loctite to come in contact with o-rings or bladder.



- 10** Thread the bladder assembly onto the cartridge tube assembly by hand.

Use a torque wrench with a 26 mm crowfoot open end wrench to tighten the seal head 9-10 N•m (80-90 in-lb).




**11** Pour RockShox 3wt suspension fluid into the bladder assembly until it is approximately half full.




**12** Use the palm of your hand or a rag to cover the bladder assembly, and cycle the rebound assembly shaft a few times to help pre-bleed air from the damper.

Pour additional RockShox 3wt suspension fluid into the bladder assembly until the fluid is level with the top of the top cap.

Use your finger to wipe any air bubbles from the surface of the fluid.




**13 RC Only:** Use a 2.5 mm hex wrench to thread the low speed compression needle into the compression piston assembly until it stops, and then unthread it 1/4 of a turn.



**14 RCT3 Only:** Insert the compression cam assembly into the bladder assembly and turn clockwise to lock into place.

**RC Only:** Insert the compression adjuster into the bladder assembly and turn clockwise to lock into place.




**15 RCT3 Only:** Use snap ring pliers to install the outer retaining ring to secure the compression cam assembly. Use a rag to soak up excess fluid.

**RC Only:** Use snap ring pliers to install the outer retaining ring to secure the compression adjuster. Use a rag to soak up excess fluid.




**16** Open the rebound assembly by pulling down on the rebound shaft to extend it. Then insert a 2.5 mm hex wrench into the bottom of the rebound shaft and turn it counter-clockwise until it stops.



**17** Fill the bleed syringe half full with 3wt suspension fluid and thread the syringe into the compression top cap assembly.

Use a 15 mm cone wrench to turn the compression cam assembly counter-clockwise to the open position.






**18** Hold the rebound shaft in place and pull up on the syringe handle to create a vacuum in the bladder.

Slowly push up and pull down on the rebound shaft multiple times to purge bubbles from the damper assembly.

Push down on the syringe handle and push up on the rebound shaft simultaneously to force bubbles out of the damper assembly. This will cause the bladder to expand and contract. This is normal.

Repeat step 18 until only very small bubbles emerge from the bladder assembly.



**19** Make sure the rebound shaft is fully extended.

Push the syringe handle down and release it. Allow the bladder to come to its natural resting position by waiting a few moments until the syringe stops filling.

Use a rag to cover the bleed tip and charger bleed port, then unthread and remove the syringe.

**⚠ CAUTION- EYE HAZARD**


Fluid may be ejected from the bladder assembly if the bladder is not in its resting position. Wear safety glasses.



**20** **RCT3 Only:** Use a 2.5 mm hex wrench to thread the low speed compression needle into the bladder assembly until it stops, and then unthread it 1/4 of a turn.



**21** **RCT3 Only:** Insert the low speed compression adjuster into the compression cam assembly. Push down and turn the low speed compression adjuster clockwise until it clicks into place.



**RC Only:** Use needle-nose pliers to insert the bleed plug into the compression adjuster until it clicks into place.




**22** Use snap ring pliers to install the inner retaining ring into the retaining ring groove. The retaining ring should be able to spin if correctly installed.

**RCT3 Only:** The low speed compression adjuster must be installed properly for the retaining ring to be seated in its groove.

**RC Only:** The bleed plug must be installed properly for the retaining ring to be seated in its groove.



**23** Spray isopropyl alcohol on the Charger Damper™ assembly and clean it with a rag.



**24** Insert and thread the compression top cap assembly into the top of the upper tube. Use a torque wrench with a 30 mm socket to tighten the compression top cap assembly to 28 N•m (250 in-lb).




**25** **RCT3 Only:** Use a 15 mm socket wrench to turn the compression cam assembly **counter-clockwise** until it stops.




**RC Only:** Use a 15 mm socket wrench to turn the low speed compression adjuster **clockwise** until it stops.



**26 RCT3 Only:** Place the compression mode adjuster knob onto the Charger Damper™ assembly with the long tab near the **front** of the crown. Turn the compression mode adjuster **clockwise** until it engages the first detent space.




**RC Only:** Place the compression mode adjuster knob onto the Charger Damper assembly with the long tab near the **back** of the crown. Turn the compression mode adjuster **counter-clockwise** until it engages the first detent space.



**27 RCT3 Only:** Thread the knob retaining nut into the compression cam assembly.

While holding down the compression mode adjuster knob, tighten the knob retaining nut. Turn the knob clockwise through both clicks until it stops, and use a torque wrench with a 6 mm socket to tighten the knob retaining nut to 3.5-4 N•m (30-35 in-lb).


**Make sure the nut is not cross-threaded as it can move the adjuster knob beneath it.**



**28 RC Only:** Install the knob retaining nut. While holding down the compression mode adjuster, use a torque wrench with a 4 mm hex bit socket to tighten the nut to 4-5.5 N•m (40-50 in-lb).



**29 RCT3 Only:** Install the low speed adjuster knob and knob retaining nut. Use a torque wrench with a 2 mm hex bit socket to tighten the nut to 1-1.5 N•m (8-13 in-lb).



## Lower Leg Assembly

- 1 Spray isopropyl alcohol on the upper tubes and clean them with a rag.



- 2 Apply a liberal amount of suspension specific grease to the inner surfaces of the dust wiper seals.



- 3 Slide the lower leg assembly onto the upper tube assembly just enough to engage the upper bushing with the upper tubes.

**Make sure both dust wiper seals slide onto the tubes without folding the outer lip of either seal.**




- 4 Position the fork at a slight angle with the bottom bolt holes oriented upward. Angle the syringe fitting in each lower leg bolt hole so as not to fill the shaft. Inject 5 mL of RockShox 0w-30 suspension fluid into the drive side leg, and 15 mL of RockShox 0w-30 suspension fluid into the non-drive side leg.

### NOTICE

Do not exceed the recommended fluid volume per leg as this can damage the fork.

Lower Leg Fluid Volume

Non-Drive Side	15 mL
Drive Side	5 mL



- 5** Slide the lower leg assembly along the upper tubes until it stops and the spring and damper shafts are visible through the lower leg bolt holes.


Use a rag to wipe all excess fluid from the outer surface of the lower legs.



- 6** Install a new o-ring into the top gland of a new bottom bolt. Install a new spring clip in the lower gland of the shaft bolt.


Replace the crush washers and crush washer retainers.

**Dirty or damaged crush washers can cause leaks.**



- 7** Thread the bottom bolts into the corresponding shaft of each lower leg.

Use a torque wrench with a 5 mm hex bit socket to tighten the bolts to 7.3 N·m (65 in-lb).



- 8** Install the rebound adjuster knob onto the rebound damper bottom bolt.

Use a torque wrench with a 2.5 mm hex bit socket to tighten the set screw to 1.1 N·m (10 in-lb).

**Make sure to hold the rebound adjuster knob in place during installation to prevent damage to the bolt hole.**



**9** Refer to the air chart on the fork lower leg and pressurize the air spring to the appropriate pressure for your rider weight.

*You may see a drop in the indicated air pressure on the pump gauge while filling the air spring; this is normal. Continue to fill the air spring to the recommended air pressure.*



**10** Thread the air valve cap onto the top cap of the non-drive side fork leg until it stops.



**11** Spray isopropyl alcohol on the entire fork and clean it with a rag.



**This concludes the service for RockShox Pike front suspension forks.**



This publication includes trademarks and registered trademarks of the following companies:  
Loctite® and 242® are registered trademarks of Henkel Corporation

[www.sram.com](http://www.sram.com)