




PLANETA

**OPERATING AND MAINTENANCE INSTRUCTIONS FOR
PLANETA – ELECTRIC WINCHES**

DV-12000/15000



Self-Recovery Winch

Thank you for purchasing a **Winch**. This manual covers operation and maintenance of the winch. All information in this publication is based on the latest production information available at the time of printing

General Safety Precautions

A Winch is designed to give safe and dependable service if operated according to the instructions. Read and understand this manual before installation and operation of winch.

Follow these general safety precautions:

- Don't use unsuitable pulleys or accessories.
- Don't use unsuitable rope in construction, strength or having any defects.
- Check the winch for smooth operation without load before winching operation.
- Make sure the wire rope is wound evenly on the first layer on the drum, rewind it if not evenly wound.




1. The winch is rated for intermittent-periodic duty.
2. The winch is not to be used to lift, support or otherwise transport personnel.
3. A minimum of five (5) wraps of rope around the drum is necessary to support the rated load.
4. When choosing the right winch, you need to consider the vehicle size and weight. As a general guide, you need a winch with a maximum load rating of at least one and a half times greater than the gross vehicle weight.
5. The rated line pull of the winch must be powerful enough to overcome the added resistance caused by whatever the vehicle is stuck in.
6. Operate the winch cable in and cable out at no load if a winch has had any ingress of water.


I. Safety Precautions

Please read and understand this Instruction Manual before installing your winch.


- ⚠ Don't use unsuitable wire rope in construction, strength or having any defects.
- ⚠ Don't use an unsuitable hook or snatch block for wire rope.
- ⚠ The operator of a winch in some cases, is required to have qualifications according to applicable laws and ordinances.
- ⚠ Do not use the winch as a lifting device or a hoist for vertical lifting (Fig1).
- ⚠ Do not use winch to move people.
- ⚠ Do not exceed maximum line pull ratings shown in tables. Shock load must not exceed these ratings.
- ⚠ Keep hands clear of wire rope and fairlead opening.
- ⚠ Pull from an angle below 15 degree to straighten up the vehicle or load. (Fig2)
- ⚠ Use leather gloves or a heavy rag when handling the wire rope.
- ⚠ When winching a heavy load lay a heavy blanket or jacket over the wire rope near the hook end.
- ⚠ Do not operate the winch under the water.



(Fig1)



(Fig2)



II. Performance Data

► Specifications

Model		DV-12000ES	DV-15000ES
Line Pull (first layer)		5,443kg / 12,000lb	6,803kg / 15,000lb
Line Speed (first layer, no load)		8.3mpm / 27fpm	6.9mpm / 22fpm
Amp. Draw	12V	440 A	460 A
	24V	290 A	340 A
Motor	Type	Series wound	
	Output	12V	4,175 w / 5.6 hp
		24V	2,684 w / 3.6 hp
Gear Train	Type	3 stage planetary	
	Ratio	261:1	315:1
Free-spool		Rotating ring gear	
Brake		Automatic, full load cone brake	
Control		Detachable Solenoid pack	
Wire Rope	Type	A7 x 19 aircraft galvanized 6 x W(19)	
	Length	38 m / 125 ft	27 m / 89 ft
	Size	9.5 mm / 3/8 in	11 mm / 7/16 in


► Performance

Model		DV-12000ES	DV-15000ES
1 st layer	Line pull (kg / lb)	5,443 / 12,000	6,803 / 15,000
	Line speed (mpm / fpm)	1.2 / 4	0.76 / 2.5
	Rope cap (m / ft)	6.2 / 20.3	5.3 / 17.4
2 nd layer	Line pull (kg / lb)	4,561 / 10,056	5,575 / 12,292
	Line speed (mpm / fpm)	1.43 / 4.7	0.92 / 3.01
	Rope cap (m / ft)	13.6 / 44.6	11.8 / 38.7
3 rd layer	Line pull (kg / lb)	3,926 / 8,657	4,723 / 10,413
	Line speed (mpm / fpm)	1.67 / 5.47	1.09 / 3.57
	Rope cap (m / ft)	22.1 / 72.5	19.5 / 64
4 th layer	Line pull (kg / lb)	3,446 / 7,599	4,097 / 9,033
	Line speed (mpm / fpm)	1.9 / 6.23	1.26 / 4.13
	Rope cap (m / ft)	31.9 / 105	27 / 89
5 th layer	Line pull (kg / lb)	3,070 / 6,770	
	Line speed (mpm / fpm)	2.13 / 6.98	
	Rope cap (m / ft)	38 / 125	

►Line speed /Amp Draw

At the first layer of wire rope on the drum.

Model		DV-12000ES				DV-15000ES			
Line Pull		Line Speed		Amp.		Line Speed		Amp.	
Kg	lb	mpm	fpm	12V	24V	mpm	fpm	12V	24V
0	0	8.3	27	60	50	6.9	22	60	50
907	2,000	*	*	*	*	*	*	*	*
1,814	4,000	2.6	8.6	200	100	1.6	5.4	180	90
2,722	6,000	*	*	*	*	*	*	*	*
3,629	8,000	1.7	5.8	310	190	1.2	3.8	280	190
4,082	9,000	*	*	*	*	*	*	*	*
4,535	10,000	1.4	4.4	370	230	1.0	3.3	330	220
5,443	12,000	1.2	4.0	440	290	0.9	2.9	385	260
6,805	15,000	*	*	*	*	0.8	2.5	460	340




DV-12000ES/DV-15000ES

1:Winch Ass'y with Wire Rope
2:Remote Control
3:Motor Lead
4:Roller Fairlead
5:Handsaver Strap
6:Mounting Hardware
7:Detachable Solenoid Pack

► Main Components

► How the winch is rated

Load and speed vary according to how much wire rope is on the drum. The first layer of rope on the drum delivers the slowest speed and the maximum load. A full drum delivers the maximum speed and the minimum load. For this reason, winches are rated on their performance first layer of rope on the drum.




III. Installation

Before using the winch, make sure all electrical components have no corrosion or damaged; the environment should be clean and dry. The voltage drop from the battery connections to the winch must not exceed 10% of the nominal voltage under normal operating condition.

Note : Roller Fairlead does not mount to winch.


► Mounting

1. It is very important that the winch will be mounted on a flat and hard surface in order to make sure the motor, drum and gearbox housing are aligned correctly.
2. It is recommended that you use a mounting channel to prevent from damaging winch or vehicle.
3. Eight (8) M12 x 1.75 pitch 8.8 Grade High Tensile Steel Bolts must be used in order to sustain the load imposed on the winch mounting.
4. Two (2) M12 x 1.75 pitch 8.8 Grade High Tensile Steel Bolts must be used for fastening the roller fairlead into the mounting channel.



► Remote control Connection

1. A remote switch with ϕ 1.25 mm X 3c X 5 m (16AWG X 3c X 17') lead supplied
2. Open the dust-proof cover of the winch, and then insert the switch plug into the socket (fig3).




(Fig3)

► Battery lead connection

Battery lead specification:

Model	DV-12000ES	DV-15000ES
Control Type	Detachable solenoid pack	
Volt	12V or 24V	
	Red lead: 2AWG x 1.83 m/ 72"	
	Black lead: 2AWG x 1.83 m/ 72"	

1. Attach the black lead (grounding) firmly to the negative (-) battery terminal.
2. Attach the red lead to the circuit breaker; connect the other end to the positive (+) battery terminal.
3. The circuit breaker shall be recommended to be fitted.



IV. Operation


► Precautions

- ⚠ Check all safety and environmental conditions prior and during use.
- ⚠ A wire rope should be replaced if it shows signs of excessive wear, broken wires, corrosion or any other defects.
- ⚠ The operator must remain with the winch when it is being operated.
- ⚠ The winches duty rating is S3 (intermittent – periodic)
- ⚠ If the winch fails to pull a load under normal conditions, stop the operation within 30 seconds otherwise motor damage may be occurred.
- ⚠ Ensure that the winch is connected to the correct voltage. 12VDC or 24VDC only
- ⚠ Check that the free-spool T-handle is in the “Engaged” position during and after use.
- ⚠ Remove the switch from the winch when not in use.
- ⚠ Do not wrap the wire rope around the load and back onto itself. Always use a strap to ensure that the wire rope does not fray or kink.
- ⚠ Keep hands and clothes away from the winch, wire rope, and roller fairlead.
- ⚠ Never unplug the remote control when winching a load.
- ⚠ Before use, ensure that you are familiar with all winching operations (winch speeds & direction).
- ⚠ To avoid insufficient power when winching a load, the vehicle should be running and in neutral.
- ⚠ Keep the remote control clear of the wire rope at all times.
- ⚠ If noise or vibration occurs when running, stop the winch immediately and return it for repair.


► Cable-in/ Cable-out Operation

- 1). To determine “Cable - Out”, trigger → out (fig.4)
- 2). To determine “Cable - In”, trigger ← in (fig.5)

To stop winching, release the trigger



(Fig4)




(Fig5)

► Free-spool Function

The free-spool allows rapid pay-out of the wire rope for hooking onto a load or anchor points and is operated by a free spool knob.

The free-spool T-handle must be in the “Engaged” position before winching.

- 1). To disengage the free-spool lift the free-spool T-handle up and turn it at 90° clockwise rotation to the “Disengaged” position, wire rope can now be free-spoiled off the drum.
- 2). To engage the free-spool lift the free-spool T-handle up and turn it at 90° counter-clockwise rotation to the “Engaged” position.
- 3). If a free-spool T-handle can't be properly locked in the “Engaged” position, rotate the drum to make the free-spool device coupled to the gear train.
- 4). Wear leather gloves and use a strap when guiding the wire rope off the drum.




(Engaged)

(Disengaged)

► Recovery Procedures

Followings are some safety tips to get out of trouble during a recovery.

- 1).Using a snatch block will increase the capacity, but the speed will decrease accordingly.
- 2).Experience has shown the best wire rope service is obtained when the maximum fleet angle is not more than 15 degree. Keep the wire rope as close as possible to the centre line of the anchor point.
- 3).It is the best to work with the most of wire rope unreeled from the drum to get more pulling power, but a minimum of five (5) wraps of wire rope should be wound around the drum to support the rated load.




V. Maintenance

► Wire rope Replacement

- Never use a wire rope of a different size or material and only use genuine Re-placement parts.
- If the winch is subjected to a high duty or excess load, the wire rope may require frequent replacement.


- 1). Disengage the free-spool T-handle (Fig6)
- 2). Spool the entire wire rope, and then remove it from the drum.
- 3). Place the replacement wire rope through the fairlead opening, pass below the drum, and insert it into the hole on the drum core. (Fig7)
- 4). Tighten the screw downwards to secure the wire rope (Fig7).



► Brake adjustment

When the brake wears to the point that the load begins to slip. The brake can be adjusted as follows:

- 1). Loosen the bolt on the brake cover and take out retaining rings
- 2). Insert few washers to maintain the brake spacer between to be 2.2 ± 0.25 mm
- 3). Make sure to keep the free-spool base plate counter-clockwise by 150 – 180 degree



► Lubrication

All moving parts in the winch are permanently lubricated at the time of assembly. Under normal conditions factory lubrication will suffice. If re-lubrication of gear box is necessary after repair or disassembly use Shell EP2 or equivalent grease with 0.25 litre. Free-spool T-handle lubricates regularly with light oil. It is not allowed to have brake ass'y lubricated.

► Maintenance Schedule

- Ensure that a responsible person carries out all inspections as per schedule.
- Inspections are divided into Daily, Monthly and 3 Monthly.

Classification of check			Item	Checking method	Checking reference	
Daily	Periodical					
	One month	Three month				
○			Installation	Mounting bolts & alignment.	Bolt tension & wear.	Existence of abnormalities
○			Remote control	Working	Manual	Reasonable actuation
		○		Wearing in contact points	Visual.	Free of wear or damage.
○			Wire rope	Broken strands	Visual, measuring	Less than 10%
○	○			Decrease in rope diameter	Visual, measuring	7% of nominal diameter max
○				Deforming or corrosion	Visual	Existence of abnormalities
○				Fastening condition of end	Visual	Existence of abnormalities
		○	Free-spool assembly	Wear in free-spool assembly	Visual evidence of wear	Free of wear or damage.
		○	Motor	Staining, damage	Visual evidence of wear	Existence of abnormalities
		○	Brake	Wearing of brake disc	Visual evidence of wear	Free of wear or damage.
○				Performance	Visual	Reasonable actuation
		○	Gear	Damage, wearing	Visual evidence of wear	Free of wear or damage.


VII. Trouble Shooting

When the winch fails to operate after several attempts, or if there is any fault while

Symptom	Possible Cause	Remedy
Winch will not operate	Cut circuit	Check battery lead.
	Weak battery	Recharge or replace battery (at least 650CCA)
	Damaged over-load protector(option)	Replace over-load protector(option)
	Bad connection of wirings	Reconnect tightly
	Damaged solenoid	Replace solenoid
	Cut circuit on switch	Replace switch
	Damaged motor or worn carbon brush.	Replace motor or carbon brush
	Dropt or lost motor wirings.	Replace wirings or tight it.
Motor runs in one direction.	Broken wirings or bad connections	Reconnect or replace wirings
	Damaged or stuck solenoid	Replace solenoid
	Switch inoperative	Replace switch
	Dropt or lost wirings.	Replace wirings and tighten.
Drum will not free-spool.	Free-spool does not disengaged	Engaged free-spool
	Damaged 1st shaft	Replace 1 st shaft
	Damaged brake cam and disc	Replace brake cam and disc
	Damaged output shaft	Replace output shaft
No brake	Damaged brake cam and disc	Replace brake cam and disc
	Damaged gear box	Replace gear box
	Dropt retaining ring	Replace retaining ring
	Oil leakage at brake cavity	Clean oil leakage
	Damaged or inoperative spiral spring	Replace and position spiral spring
Brake distance is too long	Worn or damaged brake	Replace or adjust brake
	Oil leakage at brake cavity	Clean oil leakage
Brake will be locked	Too much brake powder	Clean brake ass'y
	Over pre-pressed spiral spring	Adjust pre-pressed spiral spring
	Stuck between brake lining and gear box	Replace a new winch
Damaged gear box	Hit by certain exterior force.	Replace the damaged components
	Damaged gear train.	Replace the damaged components
	Over load operation.	Replace a new winch
Motor runs extremely hot	Long period of operation	Allow to cool
	Damaged motor	Replace or repair motor
	Damaged or inoperative brake	Replace or repair brake

VII. Replacement parts List

►DV-12000/15000ES



Ver:6

No.	Description	Q'ty	No.	Description	Q'ty	No.	Description	Q'ty
1	Motor 12V	1	26	Brake base	1	52	Remote control	1
	Motor 24V		27	Brake free-spool base	1	53	Solenoid passably 12V	1
2	Motor support rack	1	28	Brake cover	1		Solenoid assembly 24V	1
3	Gearbox support rack	1	29	Tie bar	3	-1	Solenoid upper box	1
4	Drum bushing	2	31	Retaining ring	1	-2	Solenoid lower plate	1
5	Drum	1	32	Handsaver strap	1	-3	Remote socket assembly	1
6	Motor coupling	1	33	Wire rope w/hook	1	-4	Socket gland	1
7	1 st shaft	1	34	Bearing	1	-5	Cross screw	2
8	1 st pinion	1	35	Anti-leakage seal A	2	-6	Remote socket plate	1
9	1 st stage carrier	1	36	Anti-leakage seal B	1	-7	Hex nut	2
10	2 nd stage carrier	1	37	Retaining ring	2	-8	Solenoid 12	1
11	3 rd stage carrier	1	38	Tie bar screw	6		Solenoid 24V	1
12	1 st & 2 nd ring gear	1	39	Hex. bolt	10	-9	Hex cross screw	4
13	3 rd ring gear	1	40	Hex. bolt	9	-10	Round cross screw	2
14	Gear box	1	41	Hex. bolt	1	-11	Spring washer	2
15	Plain washer	1	42	Hex. bolt	1	-12	Plain washer	6
16	Free-spool lever	1	43	Hex. bolt	1	-13	Lead	1
18	Pressed Spring	1	45	Hex. bolt	10	-14	Lead gland	3
19	Free-spool barrel	1	46	Spring washer	10	54	Foot print	1
20	Spring pin	1	47	Spring washer	6	56	Grounding lead	1
21	Free-spool T-handle	1	48	Spring washer	10	57	Bearing	1
22	Spiral spring	1	49	Spring washer	9	58	Packing	1
24	Brake cam A	1	50	Mounting hardware	1	59	O-ring	1
25	Cone brake disc	1	51	Roller fairlead	1	60	Free-spool assembly	1

EG-DECLARATION OF INCORPORATION

Declaration of incorporation of partly completed machinery according to EU directives 2006/42/EC,
Appendix II B

We hereby declare,

PLANETA-Hebetechnik GmbH, Resser Straße 17, D-44653 Herne

that the partly completed machinery

ELECTRIC-WINCHES Type DV 15000
Capacity 6.800 kg

are in the standard version, including load control, intended for installation in a machine and the basic requirements of the EC Directives listed below, as applicable for the supplied scope correspond to:

EG-Machinery Directive 2006/42/EG

We also declare that the technical documentation referred to in Annex VII, Part B of Directive 2006/42/EC were created. We commit ourselves to the special documents to the above mentioned Products to submit a reasoned request to national bodies. The transmission is electronic.

This statement applies only to the above-mentioned Products. Commissioning is prohibited until it has been determined that the above-mentioned Products have been installed properly and the provisions of the above EC Directives.

Authorized to compile the relevant technical documentation:

**Dipl.-Ing. Matthias B. Klawitter, CE-Koordinator,
PLANETA-Hebetechnik GmbH, Resser Straße 17, D-44653 Herne**

Herne, 21.08.2018

PLANETA-Hebetechnik GmbH



Dipl.-Ök. Christian P. Klawitter
(General Manager)

Is responsible for the completion, installation and commissioning according to the manual responsible:

Location: Date:

Responsible for:

Company: