

PLUS+1[™] GUIDE Software

PLUS+1 Compliant S90 EDC Control Function Block User Manual





SAUER PLUS+1 Compliant S90 EDC Control Function Block User Manual

About this Manual

| Organization and Headings | To help you quickly find information in this manual, the material is divided into sections, topics, subtopics, and details, with descriptive headings set in red type. Section titles appear at the top of every page in large red type. |
|------------------------------|--|
| | In the PDF version of this document, clicking an item <u>underlined in blue italic type</u> jumps you to the referenced page in the document. |
| Special Text Formatting | Controls and indicators are set in bold black type . |
| Table of Contents | A Table of Contents (TOC) appears on the next page. In the PDF version of this document, the TOC entries are hyperlinked. |

Revision History

| Revision | Date | Comment |
|----------|--------------|---------|
| Rev CA | October 2011 | |

©2011 Sauer-Danfoss. All rights reserved.

Sauer-Danfoss accepts no responsibility for possible errors in catalogs, brochures and other printed material. Sauer-Danfoss reserves the right to alter its products without prior notice. This also applies to products already ordered provided that such alterations can be made without affecting agreed specifications.

All trademarks in this material are properties of their respective owners.

PLUS+1, GUIDE, and Sauer-Danfoss are trademarks of the Sauer-Danfoss Group. The PLUS+1 GUIDE, PLUS+1 Compliant, and Sauer-Danfoss logotypes are trademarks of the Sauer-Danfoss Group.



SAUER PLUS+1 Compliant S90 EDC Control Function Block User Manual Contents

| S90_EDC Function Block | 4 |
|--|----|
| Overview | 4 |
| Inputs | 4 |
| Function Block Internal Constants | 5 |
| Function Block Parameters | 6 |
| Outputs | 8 |
| About Function Block Connections | 9 |
| Status and Fault Logic | 10 |
| Configuration Values | 12 |
| About Modifying the Config_Data Page | 15 |
| About the Relationship between the Function Block Input and Output Signals | 17 |
| MC Controller—Output Configuration | 18 |
| How to Configure an MFOut | 18 |
| SC Controller—Output Configuration | 20 |
| How to Configure an MFOut | 20 |
| How to Calibrate the Function Block | 21 |
| How to Calibrate an Individual Parameter | 23 |
| About Manual Calibration | 24 |
| About the Name Space Feature | 25 |
| How to Enter a Name Space Value | 25 |





Overview

The output of an **S90_EDC** function block interfaces between your application and a Sauer-Danfoss S90 EDC (Electronic Displacement Control). The output of this function block drives the coils that control flow direction and magnitude through a pump's A and B ports.

PLUS+1 I/O modules do not have the fault-checking feedback signals that are needed by this function block. An application that uses this function block to control an I/O module will fail to compile.

See:

- <u>About Function Block Connections</u> on page <u>9</u> for an overview of this function block's connections and signals.
- <u>About the Name Space Feature</u> on page 25 if you are using more than one of these function blocks in your application.

Inputs

S90_EDC Function Block Inputs

| Input | Туре | Range | Description |
|--------|------|-------|--|
| Pwr | | | Reports controller power supply voltage. |
| | | | The function block uses this voltage when it calculates the measured resistance of the control circuit. |
| Fdbk_A | | | Reports the status of the MFOut (Multifunction Output) block that receives the function block's Out_A (Output A) bus. |
| | | | Each MFOut block in the Outputs page has a corresponding MFOut block in the Inputs page that reports on its status through a Status bus. The Inputs bus on the Application page contains these Status buses. |
| Fdbk_B | | | Reports the status of the MFOut (Multifunction Output) block that receives the function block's Out_B (Output B) bus. |
| | | | Each MFOut block in the Outputs page has a corresponding MFOut block in the Inputs page that reports on its status through a Status bus. The Inputs bus on the Application page contains these Status buses. |



S90_EDC Function Block Inputs

| Input | Туре | Range | Description |
|--------|------|--------|---|
| Setup | | | Allows common configuration to be applied to multiple function blocks. |
| | | | See <u>About Modifying the Config_Data Page</u> on page <u>15</u> for more information. |
| Enable | BOOL | | Enables the OutputValue signals in the Out_A and Out_B buses. |
| | | | - T = OutputValue signals follow the CmdIn signal. |
| | | | - F = Holds both OutputValue signals at zero. |
| | | | - F/T = Clears latched faults if CmdIn is zero. |
| CmdIn | S16 | ±10000 | Specifies the requested speed and direction. |
| | | | +10000 = Requests maximum Out_A speed. |
| | | | - 0 = Requests neutral (stop). |
| | | | - 10000 = Requests maximum Out_B speed. |

Function Block Internal Constants

The following table lists constant values that are provided in the function blocks for setting limits. These constants cannot be edited.

S90_EDC Internal Constants

| Constant | Value | Description |
|------------------|--------|--|
| MaxCrnt | 100 mA | The maximum current for displacement or proportional control. |
| Nominal Ω | 18.0 Ω | The resistance of the load normally connected to Out_A and Out_B . |



Function Block Parameters

Warning

Using the PLUS+1 Service Tool program download new parameter values to an application can result in unexpected and sudden machine movements.

Unexpected and sudden machine movements can result in personal injury and equipment damage.

Always secure your machine against unexpected and sudden movements before you use the Service Tool program download new parameter values.

The following table lists function block parameters that are stored in the controller's non-volatile memory.

You can change these values by:

- Execution of the calibration process.
- Direct access to serial EE memory using the PLUS+1 Service Tool.
- Recalling default values.

S90_EDC Function Block Parameters

| Parameter | Туре | Range | Description | | | | |
|--------------|------|--------------------------|--|--|--|--|--|
| A.EE_Thid, | U16 | CalThldMin to CalThldMax | Calibrated threshold values for Out_A and Out_B . | | | | |
| B.EE_Thid | | | | | | | |
| A.EE_EndCrnt | U16 | Thid + 1 to MaxCurrent | Calibrated end current values for Out_A and Out_B . | | | | |
| B.EE_EndCrnt | | | | | | | |
| A.EE_CalFlg, | U8 | | Calibration flags for Out_A and Out_B . | | | | |
| B.EE_CalFlg | | | Bit 1 = 1 (0x0001)—Threshold is not calibrated. | | | | |
| | | | Bit 2 = 1 (0x0002)—End current is not calibrated. | | | | |
| | | | The CalFlg signal in the Diag bus contains both pairs of flags, with the Out_B bits | | | | |
| | | | shifted to positions 3 and 4. | | | | |

These parameters determine the values used as threshold and end current for each direction during normal operation. However, the values actually applied might be different because:

- Thid and EndCrnt are both subject to range limits.
- Thid is modified by the ThidMult value.



The following intermediate values represent the values that are actually applied:

- EndCrntApplied = MIN(EE_EndCrnt, MaxCrnt).
- ThIdApplied = MIN((EE_ThId × ThIdMult), EndCrntApplied).

This assures that:

- EndCrntApplied never exceeds MaxCrnt.
- ThidApplied never exceeds EndCrntApplied.

Also note that, while the **CalTask** value is set to select a calibration task:

- EndCrntApplied = MaxCrnt.
- ThIdApplied = 1.

The applied values are available in the **Diag** bus as **Thld_A**, **Thld_B**, **EndCrnt_A**, and **EndCrnt_B**.



Outputs

S90_EDC Function Block Outputs

| Output | Туре | Range | Description | | | |
|-------------------------|------|--------|--|--|--|--|
| Status | U16 | | Reports the function block's status conditions. | | | |
| | | | This output uses the standard bitwise scheme described in the Basic Function Blocks Library User's Manual. | | | |
| | | | For more information about status logic, see <u>Status and Fault Logic</u> on page <u>10</u> . | | | |
| Fault | —— | | Reports the function block's fault conditions. | | | |
| | | | This output uses the standard bitwise scheme described in the Basic Function Blocks Library User's Manual. | | | |
| | | | For more information about fault logic, see <u>Status and Fault Logic</u> on page <u>10</u> . | | | |
| Fault_A | U16 | | Reports fault conditions for the A output. | | | |
| Fault_B | U16 | | Reports fault conditions for the B output. | | | |
| Diag | | | Outputs a bus with the following signals: | | | |
| | | | - CalFlg (Calibration Flag). | | | |
| | | | – EndCrnt_A (End Current A). | | | |
| | | | – FltTmr_A (Fault Timer A). | | | |
| | | | – MeasOhm (Ohm A). | | | |
| | | | – Thid_A (Threshold A). | | | |
| | | | – EndCrnt_B (End Current B). | | | |
| | | | – FltTmr_B (Fault Timer B). | | | |
| | | | – MeasOhm_B (Ohm B). | | | |
| | | | – Thid_B (Threshold B). | | | |
| | | | The Diag bus also has Config and Define sub-buses that report the configuration and setup values used | | | |
| | | | by the function block. | | | |
| | | | Use these signals for troubleshooting. | | | |
| CalFlg | U8 | | The CalFlg signal is a bitmask value that indicates the state of calibration values. | | | |
| | | | Bit 1 = 1 (0x0001)—Threshold A is not calibrated. | | | |
| | | | Bit 2 = 1 (0x0002)—End current A is not calibrated. | | | |
| | | | Bit 3 = 1 (0x0004)—Threshold B is not calibrated. | | | |
| | | | Bit 4 = 1 (0x0008)—End current B is not calibrated. | | | |
| | | | Use these flags to manage the calibration process. | | | |
| EndCrnt_A, | U16 | | Report the active end current value for the A and B outputs. | | | |
| EndCrnt_B | | | During: | | | |
| | | | Normal operation, end current values equal A.EE_EndCrnt and B.EE_EndCrnt. | | | |
| | | | Calibration, the active end current values equal MaxCrnt. | | | |
| FltTmr_A, FltTmr_B | U16 | | Reports the value of the forward fault delay timer. | | | |
| MeasOhm_A, MeasOhm_B | U16 | | Indicate the measured resistance of the control circuits that drive the pump's coils. | | | |
| Out_A | U16 | 0-8500 | Has an OutputValue signal that drives the A coil. | | | |
| Out_B | U16 | 0-8500 | Has an OutputValue signal that drives the B coil. | | | |



About Function Block Connections



Function Block Connections

| ltem | Description |
|------|---|
| 1 | Controller power supply voltage. |
| 2 | Status of Out_A . |
| 3 | Status of Out_B . |
| 4 | Input for configuration values from an external source. |
| 5 | T enables Out_A and Out_B . |
| 6 | Commands direction and speed. |
| 7 | Reports the status of the function block. |
| 8 | Reports the faults of the function block. |
| 9 | Diagnostic signals. |
| 10 | Drives the A and B coils. |



Status and Fault Logic

The following table lists function block status codes. These codes indicate the calibration state of the function block.

Status Logic

| Status | Bit* | Reported While |
|----------------------------|------|---|
| Block is not calibrated. | 1 | Any CalFlg bit is set to 1. |
| Calibration active. | 2 | Enable is T and the CalTask = $-2, -1, +1, \text{ or } +2$. |
| Parameters are corrupt. | 3 | (EE_EndCrnt > MaxCrnt) or (EE_ThId × ThIdMult) > EndCrntApplied) for either direction A or direction B. The actual tests in the software are: (EndCrntApplied ≠ EE_EndCrnt)—happens when (EE_EndCrnt > MaxCrnt). It means that EndCrntApplied = MaxCrnt. (ThIdApplied = EndCrntApplied)—happens when ((EE_ThId × ThIdMult) ≥ EndCrntApplied). |
| Invalid setup/calibration. | 4 | Any of the following setup and configuration values are not within their valid ranges: CalThldMin. CalThldMax. ThldMult. FltDelay. CalTask. Also reported while PinStatus reports a configuration error (value =1). |
| Value too low. | 7 | Threshold calibration is active and the OutputValue < CalThIdMin for the calibration direction. |
| Value too high. | 8 | Threshold calibration is active and the OutputValue > CalThIdMax for the calibration direction. |

*Position of set bit in a 16 bit fault code or status code. Bit 1 is the least significant bit. Bit 16 set to 1 identifies a standard Sauer-Danfoss status code or fault code.



The function block's **Out_A** bus contains an **OutputValue** signal that drives a forward EDC coil, while its **Out_B** bus contains an **OutputValue** signal that drives a reverse EDC coil. The following table lists function block faults and how they affect the two **OutputValue** signals.

| Fault | Cause | | Response | \mathbf{Delay}^{\dagger} | Latch‡ | Correction |
|-----------------------|--|---|---------------------------|----------------------------|--------|--|
| Input value too low. | Cmdin < -100000. | 1 | | | | 5. 6. 11 |
| Input value too high. | Cmdin > +10000. | 2 | | No. | NO. | Fix Cmdin. |
| Open circuit. | Measured $\Omega > (Nominal \Omega \times 3).^{\$}$ | 3 | | | | Check for open circuit or high resistance between output pin and ground. |
| Short circuit. | Measured $\Omega < (Nominal \Omega \div 3).^{\$}$ | 4 | OutputValue held at 0. | | | Check for short circuit or low resistance between output pin and ground. |
| Hardware. | Current exceeds continuous or peak rating. | 6 | | Yes. | Yes. | Correct cause of overload. |
| General. | Current flow between Out_A and Out_B . Possible cause is loss of a common ground connection. | 7 | | | | Correct open ground connection. |

Fault Logic

*Position of set bit in a 16 bit status or fault code. Bit 1 is the least significant bit. Bit 16 set to 1 identifies a standard Sauer-Danfoss status code or fault code.

[†]A delayed fault gets reported if the detected fault condition persists for a specified delay time. A delayed fault cannot be cleared until the fault condition remains undetected for the delay time.

[‡]A latched fault report maintains until the latch is released. A release is attempted each time that **Enable** becomes **T** while **CmdIn** is 0.

[§]The nominal Ω value is an internal constant of each function block. It can be viewed, with other defined constants, in the **Define** sub-bus of the **Diag** bus. The other constants specify the maximum current and the range limits for configuration values.



Configuration Values



The default **Config_Data** page contains constant values that set the function block's operating characteristics. Typically, you do not have to change any of these values for the correct operation of the function block.

Optionally, you can:

- Modify the constant values on this page.
- Replace some or all the constant values on this page with signals brought in on the Setup bus, which is connected to the function block's Setup input. See <u>About</u> <u>Modifying the Config_Data Page</u> on page <u>15</u> for more information.



Config_Data Function Block Configuration Values

| Input | Туре | Range | Description | |
|---------------|------|--------------------------------|---|--|
| CalTask | S16 | -2 to +3 | Selects a calibration process. -2 = Calibrate the B end current. -1 = Calibrate the B threshold. 0 = Not in the calibration mode. +1 = Calibrate the A threshold. | |
| | | | +1 = Calibrate the A threshold. +2 = Calibrate the A end current. +3 = Applies default calibration values for both outputs on a transition to +3. The default value of +3 applies default values each time the controller powers up and allows normal operation. | |
| StoreCalVal | BOOL | | While calibration is active, a StoreCalVal (Store Calibration Value) F/T transition writes the selected calibration value to memory and sets the CalFlg to indicate this value as calibrated. The CalFlg in the Diag bus reports the status of each calibration value. T = Not calibrated. F = Calibrated. | |
| SetCalReqd | BOOL | | A SetCalReqd (Set Calibration Required) F to T transition sets all CalFig bits to 1 to mark all calibration values as uncalibrated. | |
| CirCalReqd | BOOL | | A CIrCalReqd (Clear Calibration Required) F to T transition clears all CalFIg bits to 0 to mark all calibration values as calibrated. | |
| CalThIdMin | U16 | 0–89 | Sets the lower limit of the valid range for the threshold parameter. 10000 = 1000 mA. | |
| CalThIdMax | U16 | 90-300 | Sets the upper limit for of the valid range for the threshold parameter. 10000 = 1000 mA. | |
| ThidMult | U16 | 0–10000 | The function block multiplies the Out_A and Out_B thresholds by the ThIdMult (Threshold Multiplier) to calculate the applied threshold. Enter a value of less than 10000 to reduce the applied threshold. For example, a value of 7500 reduces both the Out_A and Out_B thresholds by 25%. 10000 = 100.00%. | |
| DfitThid_A | U16 | CalThldMin to CalThldMax | When the CalTask becomes +3, the Out_A threshold parameter resets to equal the DfltThld_A (Default Threshold A). 10000 = 1000 mA. | |
| DfitThid_B | U16 | CalThldMin to CalThldMax | When the CalTask becomes +3, the Out_B threshold parameter resets to equal the DfltThld_B (Default Threshold B). 10000 = 1000 mA. | |
| DfltEndCrnt_A | U16 | 0–100 | When the CalTask becomes +3, the Out_A end current parameter resets to equal the DfltEndCrnt_A (Default End Current A). 10000 = 1000 mA. | |
| DfltEndCrnt_B | U16 | 0–100 | When the CalTask becomes +3, the Out_B end current parameter resets to equal the DfltEndCrnt_B (Default End Current B). 10000 = 1000 mA. | |



Config_Data Function Block Configuration Values

| Input | Туре | Range | Description |
|--------------|------|----------|--|
| FltDet | BOOL | | The FitDet (Fault Detection) signal enables the detection of open and short conditions, based on the measured resistance of the EDC control circuit. – T = Enable fault detection. |
| | | | - F = Disable fault detection. |
| FltDetectTm | U16 | 100–2000 | Sets the time before the fault detection logic reports or clears fault conditions. This value specifies how long a fault condition must be detected before it is reported. It also specifies how long the fault condition must remain undetected before the report can be cleared. 1000 = 1000 ms. |
| FltDetThId | U16 | | For each direction, the open and short faults are only detected while the OutputValue exceeds the FltDetThld (Fault Detect Threshold). Typically, set this value below the Out_A and Out_B threshold values. If you set the value too: Low, you get nuisance faults. High, you turn off fault detection for some or all of the output range. |
| NegCrntThld | U16 | | Negative feedback current in an uncommanded direction must be greater than the NegCrntThld (Negative Current Threshold) value to set a fault. Typically, this fault results when the A and B outputs drive coils that share a common ground and their connection to the controller ground is lost. |
| FdbkFltrTime | U16 | | Sets the time constant for the exponential filtering applied to the current measurement used to detect a fault caused by negative feedback in an uncommanded direction. |



About Modifying the Config_Data Page

Modify the **Config_Data** page to control the configuration process with signals routed into the function block from an application.



The preceding figure shows an unmodified **Config_Data** page. This **Config_Data** page has all the values that are needed to configure the function block.





The preceding figure shows the changes made to a **Config_Data** page to allow an application to control the configuration process using signals routed via the **Setup** bus.



About the Relationship between the Function Block Input and Output Signals

The function block's **Out_A** and **Out_B** buses each contain an **OutputValue** signal.

The following figure plots the relationship between the function block's **CmdIn** and **OutputValue** signals.



- The Thid_A value sets the Out_A OutputValue of the block when it receives a Cmdin of +1.
- The ThId_B value sets the Out_B OutputValue of the block when it receives a CmdIn of -1.
- The EndCrnt_A value sets the Out_A OutputValue of the block when it receives a CmdIn of +10000.
- The EndCrnt_B value sets the Out_B OutputValue of the block when it receives a CmdIn of -10000.



MC Controller—Output Configuration

If you have an SC controller, see <u>SC Controller—Output Configuration</u> on page <u>20</u>.

You route the function block's **Output** bus to an **MFOut**.

How to Configure an MFOut

You must configure an **MFOut** to receive the signals in an **Output** bus.



1. In the GUIDE template, enter the **Outputs** block.



2. In the **Group** that receives the signals in an **Output** bus, make the changes that are shown in the preceding figure.





3. In the individual **MFOut** that receives the signals in an **Output** bus, make the changes that are shown in the preceding figure.



SC Controller—Output Configuration

If you have an MC controller, see <u>MC Controller—Output Configuration</u> on page <u>18</u>.

You route the function block's **Output** bus to an **MFOut**.

How to Configure an MFOut

You must configure the **MFOut** to receive the signals in an **Output** bus.



1. In the GUIDE template, enter the **Outputs** block.



2. In the **MFOut** that receives the signals in an **Output** bus, make the changes that are shown in the preceding figure.



How to Calibrate the Function Block

See <u>About Modifying the Config</u> <u>Data Page</u> on page <u>15</u> for an example of a **Config_Data** page that has been modified to allow an application program to control the calibration process.

- 1. Prepare to calibrate.
 - A. Set the **SetCalReq** signal to F.
 - B. Set the ClrCalReq signal to F.
 - C. Set the StoreCalVal signal to F.
 - D. Toggle the **SetCalReq** signal from F to T.

Toggling sets the "not calibrated" bits in the **CalFlag** signal to 1.

- 2. Set the **Enable** signal to T.
- 3. Calibrate the **Out_A** threshold parameter.
 - A. Set the **CalTask** signal to +1.
 - B. Gradually modify the **CmdIn** signal in a positive (0 to +10000) direction to find the minimum command that causes motion.

In the **Status** signal, monitor bit 7—**Value too low** and bit 8—**Value too high** to make sure that the **OutputValue** signal is within the valid threshold range.

C. Toggle the **StoreCalVal** signal from F to T to write the **OutputValue** to memory.

In the **CalFlag** signal, check that bit 1 clears to 0, to verify that the controller has written the **Out_A** threshold parameter to memory.

- 4. Calibrate the reverse threshold parameter.
 - A. Set the **CalTask** signal to -1.
 - B. Gradually modify the **CmdIn** signal in a negative (0 to –10000) direction to find the minimum command that causes motion.

In the **Status** signal, monitor bit 7—**Value too low** and bit 8—**Value too high** to make sure that the **OutputValue** signal is within the valid threshold range.

C. Toggle the **StoreCalVal** signal from F to T to write the **OutputValue** to memory.

In the **CalFlag** signal, check that bit 3 clears to 0, to verify that the controller has written the **Out_B** threshold parameter to memory.



- 5. Calibrate the **Out_A** end current parameter.
 - A. Set the **CalTask** signal to +2.
 - B. Gradually modify the **CmdIn** signal in a positive direction to find the command that produces the desired maximum pump flow.
 - C. Toggle the **StoreCalVal** signal from F to T to write the **OutputValue** to memory.

In the **CalFlag** signal, check that bit 2 clears to 0, to verify that the controller has written the **Out_A** end current parameter to memory.

- 6. Calibrate the **Out_B** end current parameter.
 - A. Set the **CalTask** signal to -2.
 - B. Gradually modify the **CmdIn** signal in a negative direction to find the command that produces the desired maximum pump flow.
 - C. Toggle the **StoreCalVal** signal from F to T to write the **OutputValue** to memory.

In the **CalFlag** signal, check that bit 4 clears to 0, to verify that the controller has written the **Out_B** end current parameter to memory.

- 7. End the calibration process.
 - A. Set the **CalTask** signal to 0.
 - B. In the **CalFlag** signal, verify that all bits are now 0.
 - C. Verify that no Status or Fault conditions are reported.
 - D. Set the **ThidMult** signal to the desired value.



How to Calibrate an Individual Parameter

Partial calibration allows you to calibrate an individual parameter while leaving the values of other parameters unchanged.

- 1. Prepare to calibrate.
 - A. Set the **SetCalReq** signal to F.
 - B. Set the **ClrCalReq** signal to F.
 - C. Set the **StoreCalVal** signal to F.
 - D. Toggle the **SetCalReq** signal from F to T.

Toggling sets all the "not calibrated" bits in the **CalFlag** signal to 1.

- 2. Set the **Enable** signal to T.
- 3. Use the **CalTask** signal to select the parameter to be calibrated.
- 4. Calibrate the parameter.
 - A. Toggle the **StoreCalVal** signal from F to T to write the **OutputValue** to memory.
 - B. In the **CalFlag** signal, check that the calibration bit for the selected parameter clears to 0, to verify that the controller has written the parameter to memory.
- 5. End the calibration process.
 - A. Set the **CalTask** signal to 0.
 - B. Toggle the **ClrCalReqd** signal from F to T.
 - C. In the **CalFlag** signal, verify that all bits are now 0.
 - D. Verify that no **Status** or **Fault** conditions are reported.



About Manual Calibration



Using the PLUS+1 Service Tool program download new parameter values to an application can result in unexpected and sudden machine movements.

Unexpected and sudden machine movements can result in personal injury and equipment damage.

Always secure your machine against unexpected and sudden movements before you use the Service Tool program download new parameter values.

You can manually calibrate the function block using the PLUS+1 Service Tool program to download calibration parameters.

When you manually calibrate, make sure that the:

- Calibration parameters are valid. If the values are out of range for a given direction, the block limits the values of **ThIdApplied**, **EndCrntApplied** or both for that direction. This condition is indicated by the "Parameters are corrupt" status and can produce unintended output commands.
- **Status** signal indicates normal status conditions.



About the Name Space Feature

If you use this function block more than once in an application, you must change each function block's **Name Space** value to avoid compiler errors.

These function blocks allocate memory using memory names ("aliases"). Identical function blocks have identical memory names. Identical memory names will cause a compiler error.

The **Name Space** value adds a unique prefix to each memory name to avoid memory allocation errors. Keep **Name Space** values short to save controller memory.



How to Enter a Name Space Value

- 1. In the PLUS+1 GUIDE menu bar, click the Query/Change button.
- 2. Click the function block's page name to display the **Edit Page** window.
- 3. In the Edit Page window, enter a meaningful Name Space value.
- 4. Press Enter ← .
- 5. Repeat these steps to enter unique **Name Space** values for other identical function blocks.



Products we offer:

- Bent Axis Motors
- Closed Circuit Axial Piston Pumps and Motors
- Displays
- Electrohydraulic Power Steering
- Electrohydraulics
- Hydraulic Power Steering
- Integrated Systems
- Joysticks and Control Handles
- Microcontrollers and Software
- Open Circuit Axial Piston Pumps
- Orbital Motors
- PLUS+1[™] GUIDE
- Proportional Valves
- Sensors
- Steering
- Transit Mixer Drives

Members of the Sauer-Danfoss Group:

Comatrol www.comatrol.com

Schwarzmüller-Inverter www.schwarzmueller-inverter.com

Turolla www.turollaocg.com

Hydro-Gear www.hydro-gear.com

Sauer-Danfoss-Daikin www.sauer-danfoss-daikin.com

Sauer-Danfoss is a global manufacturer and supplier of highquality hydraulic and electronic components. We specialize in providing state-of-the-art technology and solutions that excel in the harsh operating conditions of the mobile off-highway market. Building on our extensive applications expertise, we work closely with our customers to ensure exceptional performance for a broad range of off-highway vehicles.

We help OEMs around the world speed up system development, reduce costs and bring vehicles to market faster. Sauer-Danfoss—Your Strongest Partner in Mobile Hydraulics.

Go to www.sauer-danfoss.com for further product information.

Wherever off-highway vehicles are at work, so is Sauer-Danfoss.

We offer expert worldwide support for our customers, ensuring the best possible solutions for outstanding performance. And with an extensive network of Global Service Partners, we also provide comprehensive global service for all of our components.

Please contact the Sauer-Danfoss representative nearest you.

Local address: Sauer-Danfoss Inc. 3500 Annapolis Lane North Minneapolis, MN 55447, USA Phone: +1 763 509-2000 Fax: +1 763 559-5769

Sauer-Danfoss (US) Company 2800 East 13th Street Ames, IA 50010, USA Phone: +1 515 239-6000 Fax: +1 515 239-6618

Sauer-Danfoss GmbH & Co. OHG Postfach 2460, D-24531 Neumünster Krokamp 35, D-24539 Neumünster, Germany Phone: +49 4321 871-0 Fax: +49 4321 871 122

Sauer-Danfoss ApS DK-6430 Nordborg, Denmark Phone: +45 7488 4444 Fax: +45 7488 4400

Sauer-Danfoss-Daikin LTD Shin-Osaka TERASAKI 3rd Bldg. 6F 1-5-28 Nishimiyahara, Yodogawa-ku Osaka 532-0004, Japan Phone: +81 6 6395 6066 Fax: +81 6 6395 8585

www.sauer-danfoss.com