



# POWERHEAD

## Section 4

### Table of Contents

Specifications .....	4-1	Seals .....	4-23
Special Tools .....	4-3	Bearings .....	4-23
Powerhead Torque Sequence .....	4-5	Connecting Rod .....	4-24
Cylinder Block and Covers .....	4-6	Pistons .....	4-27
Crankshaft, Pistons and Flywheel .....	4-10	Reed Block .....	4-28
Powerhead Removal .....	4-12	Bleed System .....	4-30
Powerhead Disassembly .....	4-13	Thermostat (If Equipped) .....	4-31
Cylinder Block .....	4-13	Powerhead Reassembly .....	4-32
Crankshaft .....	4-16	General Information .....	4-32
Powerhead Cleaning and Inspection .....	4-20	Crankshaft .....	4-32
Cylinder Block and Crankcase Cover ...	4-20	Cylinder Block .....	4-39
Exhaust Manifold and Exhaust Cover ...	4-20	Powerhead Installation .....	4-44
Cylinder Bore .....	4-20	Set-Up and Test-Run Procedures .....	4-45
Crankshaft .....	4-22	Break-In Procedure .....	4-45

4

### Specifications

Model 6/8/9.9/10/15		
<b>KW (HP)</b>	<b>Model 6</b> <b>Model 8</b> <b>Model 8 Sailmate</b> <b>Model 9.9</b> <b>Model 9.9 Sailpower</b> <b>XR/MAG/Viking10</b> <b>Model Sea Pro/Marathon 10</b> <b>Model 15</b> <b>Model Sea Pro/Marathon 15</b>	4.5 (6) 5.9 (8) 5.9 (8) 7.4 (9.9) 7.4 (9.9) 7.5 (10.0) 7.5 (10.0) 11.2 (15) 11.2 (15)
<b>STATIC THRUST</b>	<b>Model 9.9 Sailpower</b>	W.O.T. in Forward – 920.7 N (207 Lbs.) W.O.T. in Reverse – 667.2 N (150 Lbs.)
<b>OUTBOARD WEIGHT</b>	<b>Manual Start</b> 6 8 8 Sailmate 9.9 9.9 Sailpower XR/MAG/Viking 10 Sea Pro/Marathon 10 15 Sea Pro/Marathon 15 <b>Electric Start</b> 6 8 9.9 9.9 Sailpower 15	33.1 kg (73.0 lb) 33.1 kg (73.0 lb) 33.8 kg (74.5 lb) 33.8 kg (74.5 lb) 34.2 kg (76.5 lb) 33.8 kg (74.5 lb) 33.8 kg (74.5 lb) 34.0 kg (75.0 lb) 34.0 kg (75.0 lb) 36.1 kg (79.5 lb) 36.1 kg (79.5 lb) 36.7 kg (81.0 lb) 37.7 kg (83.0 lb) 37.0 kg (81.5 lb)




<b>Model 6/8/9.9/10/15</b>		
<b>CYLINDER BLOCK</b>	<b>Type</b> <b>Displacement (1994 Model)</b> 6 8 9.9 9.9 Sailpower 10 Sea Pro/Marathon XR/MAG10 15 <b>Displacement (1995 and Newer)</b> 9.9 9.9 Sailpower 10 Sea Pro/Marathon XR/MAG/Viking 10 15 15 Sea Pro/Marathon	<b>Two-Stroke Cycle – Cross Flow</b>  209cc (12.8 cu. in.) 209cc (12.8 cu. in.) 209cc (12.8 cu. in.) 209cc (12.8 cu. in.) 262cc (16.0 cu. in.) 262cc (16.0 cu. in.) 262cc (16.0 cu. in.)  262cc (16.0 cu. in.) 262cc (16.0 cu. in.) 262cc (16.0 cu. in.) 262cc (16.0 cu. in.) 262cc (16.0 cu. in.) 262cc (16.0 cu. in.)
<b>STROKE</b>	<b>Length</b>	45.7mm (1.800 in.)
<b>CYLINDER BORE</b>	<b>Diameter (Standard)(1994 Model)</b> 6 8 8 Sailmate 9.9 9.9 Sailpower 10 Sea Pro/Marathon XR/Mag 10 15 <b>Diameter (Standard)(1995 Model)</b> 9.9 9.9 Sailpower 10 Sea Pro/Marathon XR/Mag/Viking 10 15 15 Sea Pro/Marathon <b>Taper/Out of Round Maximum Bore Type</b>	53.975mm (2.125 in.) 53.975mm (2.125 in.) 53.975mm (2.125 in.) 53.975mm (2.125 in.) 53.975mm (2.125 in.) 60.325mm (2.375 in.) 60.325mm (2.375 in.) 60.325mm (2.375 in.)  60.325mm (2.375 in.) 60.325mm (2.375 in.) 60.325mm (2.375 in.) 60.325mm (2.375 in.) 60.325mm (2.375 in.) 60.325mm (2.375 in.) 0.1016mm (0.004 in.) Cast Iron
<b>CRANKSHAFT</b>	<b>Top Main Bearing Journal</b> <b>Center Main Bearing Journal</b> <b>Bottom Ball Bearing Journal</b> <b>Connecting Rod Journal</b> <b>Runout</b>	19.1mm (0.7517 in.) 20.6mm (0.8108 in.) 20.0mm (0.7880 in.) 20.6mm (0.8125 in.) 0.076mm (0.003 in.)
<b>CONNECTING ROD</b>	<b>Piston Pin End (I.D.)</b> <b>Crankpin End (I.D.)</b>	20.8mm (0.8195 in.) 27.0mm (1.0635 in.)
<b>PISTON</b>	<b>Piston Type</b> <b>Ring End Gap</b>	Aluminum 0.25 mm - 0.46 mm (0.010 in. - 0.018 in.)
<b>REEDS</b>	<b>Reed Stand Open (Maximum)</b> <b>All Models</b> <b>Reed Stop Opening (Maximum)</b> <b>All Models</b>	0.178mm (0.007 in.)  7.54mm (0.296 in.)




# Special Tools

1. Powerhead Stand 91-13662T1




**a** - Bushing 23-13653  
**b** - Stand 91-13662

2. Piston Pin Tool 91-13663T1




3. Snap Ring Pliers 91-24283 \* **NLA**




4. Torque Wrench (0-200 lb. ft.) 91-32610\* **NLA**



5. Universal Puller Plate 91-37241




6. Torque Wrench (0-150 lb. in.) (91-66274)\*




\*May be obtained locally.

7. Compression Tester 91-29287






8. Flywheel Puller 91-83164M



9. Flywheel Holder 91-52344




54964

10. Strap Wrench 91-24937A1




11. Ring Expander 91-24697




12. Slide Hammer 91-34569A1



13. Expanding Rod **CG40-4** (Snap-On)




14. Collet **CG40-15** (Snap-On)






# Powerhead Torque Sequence

## EXHAUST COVER TORQUE SEQUENCE




6.8 Nm (60 lb. in.)

## CYLINDER BLOCK COVER TORQUE SEQUENCE




6.8 Nm (60 lb. in.)

## CRANKCASE COVER TORQUE SEQUENCE




22.6 Nm (16.7 lb. ft.)





# Cylinder Block and Covers



12 Loctite Master Gasket

33 Loctite 680 Retaining Compound




## Cylinder Block and Covers (continued)

REF. NO.	QTY.	DESCRIPTION	TORQUE		
			lb. in.	lb. ft.	N-m
1	1	CYLINDER BLOCK (6)			
	1	CYLINDER BLOCK (8)			
	1	CYLINDER BLOCK (9.9/15)			
2	2	DOWEL PIN–cylinder block			
3	2	STUD–carburetor			
4	1	CHECK VALVE–bleed hose			
5	1	HOSE–bleed (2-1/2 IN.)			
6	2	STUD–cylinder block			
7	6	SCREW–crankcase to cylinder block		16.5	22.6
8	1	GROOVE PIN (9.9/15)			
9	2	NUT–cylinder block stud	100		11.3
10	1	GASKET–powerhead			
11	1	PLUG-Serial Number			
12	1	REED BLOCK			
13	3	SCREW–reed block			
14	2	NUT–carburetor stud	125		14.1
15	1	COVER–exhaust			
16	11	SCREW–exhaust cover to cylinder block	60		6.8
17	1	GASKET–exhaust cover			
18	1	BAFFLE PLATE			
19	1	GASKET–baffle plate			
20	3	SCREW–cover to cylinder block	60		6.8
21	1	FITTING			
22	1	TUBING (7 IN.)			
23	1	TUBING (5-1/4 IN.)			
24	1	TEE			
25	AR	CABLE-TIE			



# Cylinder Block and Covers (continued)



12 Loctite Master Gasket

33 Loctite 680 Retaining Compound






## Cylinder Block and Covers (continued)

REF. NO.	QTY.	DESCRIPTION	TORQUE		
			lb. in.	lb. ft.	N-m
26	1	GASKET <b>6/8</b>			
27	1	INTAKE COVER			
28	2	O-RING <b>9.9/15</b>			
29	1	INTAKE COVER			
30	1	HOSE—tell tale (6 IN.)			
31	1	FITTING—tell tale hose - bottom cowl			
32	1	COVER ASSEMBLY			
33	1	GASKET			
34	1	COVER—thermostat			
35	1	GASKET			
36	2	SCREW	60		6.8
37	1	THERMOSTAT (120 degrees) <b>9.9/15</b>			
38	1	GASKET—thermostat			
39	1	FITTING			
40	6	SCREW—cover attaching	60		6.8
41	2	STUD-carb ( <b>RESTRICTED/NORWAY MODELS</b> )			
42	1	RECTIFIER			
43	2	SCREW (5/8) <b>ELECTRIC</b>		Drive Tight	
44	3	NUT	25		2.8
45	1	TERMINAL BLOCK			
46	2	SCREW (5/8 IN.) <b>ALTERNATOR MODELS</b>		Drive Tight	
47	2	SCREW (3/8 IN.)		Drive Tight	
48	1	STARTER SOLENOID			
49	1	BATTERY CABLE ( <b>NEGATIVE</b> )			
50	2	SCREW (M6 x 14) <b>ELECTRIC</b>	70		7.9
51	2	NUT (10-32)	15		1.7
52	1	BATTERY CABLE ( <b>POSITIVE</b> )			
53	1	WIRE (YELLOW)			
54	2	NUT (1/4-20)	30		3.4
55	1	WIRE (RED)( <b>15 ELECTRIC HANDLE</b> )			



# Crankshaft, Pistons and Flywheel



7 Loctite 271

14 2 Cycle Outboard Oil

95 2-4-C with Teflon



## Crankshaft, Pistons and Flywheel (continued)

REF. NO.	QTY.	DESCRIPTION	TORQUE		
			lb. in.	lb. ft.	N-m
1	1	NUT		50	67.8
2	1	FLYWHEEL ASSEMBLY			
3	1	RING GEAR-flywheel <b>ELECTRIC</b>			
4	4	SCREW (M5 x 13)	65		7.3
5	1	CRANKSHAFT ASSEMBLY			
6	1	SLEEVE			
7	1	O-RING			
8	1	BALL BEARING - lower			
9	1	WASHER			
10	1	RETAINING RING			
11	1	WASHER - lower			
12	1	OIL SEAL - lower			
13	1	KEY			
14	1	ROLLER BEARING			
15	1	OIL SEAL - upper			
16	2	CONNECTING ROD ASSEMBLY			
17	4	SCREW	100		11.3
18	3	ROLLER BEARING			
19	48	NEEDLE BEARING - piston end			
20	4	THRUST BEARING			
21	2	PISTON AND PIN ASSEMBLY <b>(6/8)</b>			
	2	PISTON AND PIN ASSEMBLY <b>(9.9/15)</b>			
22	1	PISTON RING ASSEMBLY <b>(6/8)</b>			
	1	PISTON RING ASSEMBLY <b>(9.9/15)</b>			
23	2	PISTON RING - top <b>(6/8)</b>			
	2	PISTON RING - top <b>(9.9/15)</b>			
24	4	LOCK RING			
25	1	LINER – center main bearing <b>(6/8)</b>			
26	1	BEARING <b>(9.9/15)</b>			
27	1	SEAL – main bearing			
28	1	ROLLER BEARING <b>(9.9/15)</b>			





# Powerhead Removal

1. Remove the following components/assemblies referring to the listed service manual sections:

Component/Assembly	Section
Rewind Starter	8
Flywheel and Ignition/Electrical Components	2A/B
Throttle/Shift Mechanism	7A/B/C
Carburetor	3

2. Disconnect tell-tale hose from bottom cowl.
3. Remove 4 bolts and 2 nuts.





53204

53125

- a** - Tell-tale hose
- b** - Bolts (2 each side)
- c** - Nut (1 each side)

4. Push powerhead sideways to break gasket and lift powerhead from drive shaft housing.
5. Place powerhead on bench or powerhead stand mounted in vise.



53203

53197


- a** - Powerhead Stand (91-13662T1)



# Powerhead Disassembly

## Cylinder Block

1. Remove 3 bolts and remove intake manifold/reed block.




53191

- a - Bolts
- b - Intake manifold/reed block

**IMPORTANT:** Reed block can be inspected without disassembling. Refer to **Cleaning and Inspection**, following. If inspection of reed block indicates that replacement of a part is necessary, disassemble reed block as outlined.


2. If necessary, disassemble reed block as follows:
  - a. Pull ends of rubber seal from holes in intake manifold/reed block.
  - b. Remove 6 screws and separate reed stops and reeds.

### 1994 – 1996 Reed Blocks



53202

- a - Rubber seal
- b - Screws
- c - Reed stop
- d - Reeds




53196




**1997 and Newer Reed Blocks (Rubber Coated)**

**NOTE:** Individual components of 1997 and newer reed block assemblies are not sold separately. If individual components are found to be not serviceable, entire reed block assembly must be replaced.




- a** - Rubber seal
- b** - Screws
- c** - Reed stop
- d** - Reeds

3. Remove 2 bolts and remove thermostat cover.
4. Remove thermostat (if equipped).
5. Remove 6 bolts and remove cylinder block cover.



- a** - Bolts (2)
  - b** - Cover
- c** - Bolts
  - d** - Cover
  - e** - Thermostat (if equipped)






6. Remove 10 bolts and separate exhaust cover and exhaust manifold from cylinder block.

**NOTE:** If engine is suspected of having been overheated or spark plugs are grayish colored (a sign of possible water intrusion), inspect exhaust manifold for warpage or for proper placement and integrity of gaskets which may allow water to enter cylinders through exhaust ports.


7. Remove 2 bolts and intake cover.

**NOTE:** 1995-newer Model 9.9/15 powerheads have O-rings under intake cover instead of a gasket. This style intake cover with O-rings WILL NOT backfit prior models.



53188


- a - Bolts (10)
- b - Exhaust cover
- c - Exhaust manifold



53198


8. Remove 6 bolts which secure crankcase cover to cylinder block.

9. Use soft mallet to break seal between crankcase cover and cylinder block.



53192


- a - Bolts (6)



53145




10. Lift crankcase cover from block.




53124

## Crankshaft

1. Lift crankshaft assembly from cylinder block.
2. **All Models Except 15 and 1995 9.9/10:** Remove center main bearing halves and sleeve halves from crankshaft and/or cylinder block.
3. Remove upper crankshaft seal and bearing.
4. Remove lower crank shaft seal, stuffer washer and retaining ring.



53273



53183


- a** - Bearing halves (hidden)
- b** - Sleeve halves
- c** - Crankshaft seal (upper)
- d** - Bearing
- e** - Crankshaft seal (lower)
- f** - Stuffer washer
- g** - Retainer





- 5. Remove (and discard) coupling seal using:  
Snap On\* Expanding Rod (CG 40-4)  
Snap On\* Collet (CG 40-15)  
Slide Hammer (91-34569A1)


\*Purchase from: Snap On Tools Corporation  
2801 - 80th Street  
Kenosha, WI 53141-1410



- a - Coupling seal
- b - Collet (CG 40-15)
- c - Expanding Rod (CG 40-4)
- d - Slide Hammer (91-34569A1)

6. **Model 15 and 1995 9.9/10 Center Main Bearing Removal:**

- a. Remove retaining ring from groove of center main bearing race.
- b. Remove center main bearing races and center main bearing halves.



- a - Retaining ring
- b - Bearing halves




7. Remove sealing ring.

### ⚠ CAUTION

Eye protection **MUST BE** worn while removing piston pin lockrings.

**IMPORTANT:** Identify upper (#1) and lower (#2) pistons and connecting rods. Store piston pin, piston pin needle bearings, locating washers, connecting rod bearings, rod caps and bolts together with corresponding piston and connecting rod for reassembly.


8. Remove (and discard) piston pin lockrings.



**IMPORTANT:** It is recommended that the piston and rod assembly be removed from the crankshaft before removing the piston pin to prevent possible bending of the connecting rod.

9. Remove rod bolts and remove piston and rod assembly from crankshaft.

10. While supporting piston, use Piston Pin Tool and soft faced mallet to drive piston pin from piston.






**IMPORTANT: Piston pin needle bearings and locating washers will fall out when piston is removed from connecting rod.**

11. Slide piston pin tool from piston and remove piston, needle bearings and locating washers.


12. Using Piston Ring Expander, remove (and discard) piston rings.



- a - Needle bearings
- b - Locating washers
- c - Ring Expander (91-24697)

**IMPORTANT: DO NOT remove ball bearing from crank shaft unless replacement is necessary as removal process will damage bearing. Refer to Cleaning and Inspection following.**

13. Remove lower crankshaft ball bearing using Universal Puller Plate, suitable mandrel (to protect crank shaft while pressing) and press.



- a - Universal Puller Plate (91-27241)
- b - Ball bearing
- c - Mandrel




# Powerhead Cleaning and Inspection

## Cylinder Block and Crankcase Cover

**IMPORTANT:** Crankcase cover and cylinder block are a matched, line-bored assembly and must be replaced as a set.

1. Thoroughly clean cylinder block and crankcase cover. Verify that all sealant and old gaskets are removed from mating surfaces. Remove all carbon deposits from exhaust ports, decompression ports and cylinder dome.
2. Inspect cylinder block and crankcase cover for cracks or fractures.
3. Check gasket surfaces for nicks, deep grooves, cracks and distortion.
4. Inspect all water and fuel passages in cylinder block and crankcase cover for obstructions.
5. Verify that all fittings and plugs are tight.



53148

**a** - Decompression ports

## Exhaust Manifold and Exhaust Cover

1. Remove all carbon deposits and gasket material from exhaust manifold and cover.
2. Inspect for grooves, cracks or distortion that could cause leakage. Replace parts as required.

## Cylinder Bore


**NOTE:** Cylinder sleeve is part of the cylinder block and cannot be replaced.

### MEASURING CYLINDER BORE

1. Inspect cylinder bores for scoring, scuffing or a transfer of aluminum from piston to cylinder wall. Scoring or scuffing, if NOT TOO SEVERE, can normally be removed by honing. If a transfer of aluminum has occurred, an acidic solution such as TIDY BOWL CLEANER should be applied to the areas of the cylinder bore where transfer of aluminum has occurred. After the acidic solution has removed the transferred aluminum, thoroughly flush the cylinder bores to remove any remaining acid. Cylinder walls may now be honed to remove any glaze and to aid in the seating of new piston rings.
2. Measure ring traveled area of cylinder bore at 3 depths, (6 places) by positioning measuring instrument in-line with and at right angle (90°) to piston pin centerline.



3. If cylinder bore is tapered, egg shaped or out-of-round by more than 0.1mm (0.004 in.), replace cylinder block.



### STANDARD CYLINDER BORE DIAMETER

1994 MODEL	6/8/9.9	53.98MM (2.125 IN.)
	10/15	60.3MM (2.375 IN.)
1995 - NEWER MODEL	6/8	53.98MM (2.125 IN.)
	9.9/10/15	60.3MM (2.375 IN.)

### HONING PROCEDURE

- a. When cylinders are to be honed, follow the hone manufacturer's recommendations for use of the hone and cleaning and lubrication during honing.
- b. For best results, a continuous flow of honing oil should be pumped into the work area. If pumping oil is not practical, use an oil can. Apply oil generously and frequently on both stones and work area.

#### **⚠ CAUTION**

**When honing cylinder block, remove hone frequently and check condition of cylinder walls. DO NOT hone any more than absolutely necessary, as hone can remove cylinder wall material rapidly.**

- c. Start stroking at smallest diameter. Maintain firm stone pressure against cylinder wall to assure fast stock removal and accurate results.
  - d. Localize stroking in the smallest diameter until drill speed is constant throughout length of bore. Expand stones, as necessary, to compensate for stock removal and stone wear. Stroke at a rate of 30 complete cycles per minute to produce best cross-hatch pattern. Use honing oil generously.
  - e. Thoroughly clean cylinder bores with hot water and detergent. Scrub well with a stiff bristle brush and rinse thoroughly with hot water. A good cleaning is essential. If any of the abrasive material is allowed to remain in the cylinder bore, it will cause rapid wear of new piston rings and cylinder bore in addition to bearings. After cleaning, bores should be swabbed several times with engine oil and a clean cloth, then wiped with a clean, dry cloth. Cylinders **should not** be cleaned with kerosene or gasoline. Clean remainder of cylinder block to remove excess material spread during honing operation.
4. Hone all cylinder walls **just enough** to de-glaze walls.




5. Measure cylinder bore diameter (with a snap gauge micrometer) at top, middle and bottom of each cylinder. Check for tapered, out-of-round (egg-shaped) and oversize bore.

**IMPORTANT: Ports must be deburred after honing.**

## Crankshaft

1. Inspect crankshaft to drive shaft splines for wear.
2. Check crankshaft for straightness [runout – 0.076mm (0.003 in.)].
3. Inspect crankshaft oil seal surfaces. Sealing surfaces must not be grooved, pitted or scratched. If top crankshaft sealing surface is severely worn, replace crankshaft. If bottom crankshaft sealing surface is worn, replace crankshaft coupling seal.
4. Check all crankshaft bearing surfaces for rust, water marks, chatter marks, uneven wear and/or overheating (blued).
5. If necessary, clean up crankshaft bearing surfaces with crocus cloth.




**a** - Crocus Cloth

6. Thoroughly clean crankshaft with solvent and dry with compressed air.
7. Recheck surfaces of crankshaft and replace crankshaft if surfaces can not be properly cleaned up.
8. If crankshaft will be reused, apply light oil to prevent rust.



## Seals

It is recommended that all seals be replaced as a standard rebuilding procedure.



53200

- a - Top crankshaft seal
- b - Bottom crankshaft seal


## Bearings

### BALL BEARINGS

#### **⚠ WARNING**

**DO NOT spin-dry crankshaft ball bearings with compressed air.**

1. Clean ball bearings with solvent and dry with compressed air.
2. Work inner bearing race in and out. There should not be excessive play.
3. Rotate bearing race. Bearing should have smooth action and no rust stains. If ball bearing sounds or feels rough or has catches, remove and discard bearing. Apply light oil to bearing after inspection to prevent rust.




53200

### ROLLER BEARINGS

1. Clean roller bearing with solvent and dry with compressed air.
2. Inspect roller bearing for rust, fracturing, wear, galling or overheating (blued). Always replace bearings as a set if replacement is necessary.




3. Apply light oil to bearings after inspection to prevent rust.



## Connecting Rod

1. Check connecting rods for alignment by placing rods on a surface plate. If light can be seen under any portion of machined surfaces, if rod has a slight wobble on plate, or if a 0.051mm (0.002 in.) feeler gauge can be inserted between any machined surface and surface plate, rod is bent and must be discarded.



53205


- a** - Feeler gauge
- b** - Surface plate
- c** - Even downward pressure

2. **Overheating:** Overheating is visible as a bluish bearing surface color that is caused by inadequate lubrication or excessive RPM.
3. **Rust:** Rust formation on bearing surfaces causes pits to form on surfaces.






4. **Water Marks:** When bearing surfaces are subjected to water contamination, a bearing surface, etching occurs. This etching resembles the size of the bearing.




51853

**a** - Pitting


51853

5. **Spalling:** Spalling is the loss of bearing surface, and it resembles flaking or chipping. Spalling will be most evident on the thrust portion of the connecting rod in line with the I beam. General bearing surface deterioration could be caused by or accelerated by improper lubrication.

6. **Chatter Marks:** Chatter marks are the result of a combination of low speed - low load - cold water temperature operation, aggravated by inadequate lubrication and/or improper fuel. Under these conditions, the crankshaft journal is hammered by the connecting rod. As ignition occurs in the cylinder, the piston pushes the connecting rod with tremendous force, and this force is transferred to the connecting rod journal. Since there is little or no load on the crankshaft, it bounces away from the connecting rod. The crankshaft then remains immobile for a split second until the piston travel causes the connecting rod to catch up to the waiting crankshaft journal, then hammers it. The repetition of this action causes a rough bearing surfaces which resembles a tiny washboard. In some instances, the connecting rod crank pin bore becomes highly polished. During operation, the engine will emit a whirr and/or chirp sound when it is accelerated rapidly from idle speed to approximately 1500 RPM, then quickly returned to idle. If the preceding conditions are found, replace both the crankshaft and connecting rods.




51853

**a** - Spalling**b** - Chatter marks between arrows

51853



7. **Uneven Wear:** Uneven wear could be caused by a bent connecting rod.



51853

**a** - Uneven wear between arrows

8. If necessary, clean connecting rod bearing surfaces as follows
- Be sure that etched marks on connecting rod (crankshaft end) are perfectly aligned with etched marks on connecting rod cap. Tighten connecting rod cap attaching screws securely.


### ⚠ CAUTION

**Crocus cloth MUST BE USED to clean bearing surface at CRANKSHAFT END OF CONNECTING ROD.**

**320 grit Carborundum cloth MUST BE USED to clean bearing surface at PISTON PIN END OF CONNECTING ROD.**

- Clean crankshaft end of connecting rod by using CROCUS CLOTH placed in a slotted 9.5 mm (3/8 in.) diameter shaft as shown. Secure shaft in a drill press. Operate press at a high speed while keeping connecting rod at a 90° angle to slotted shaft.

**IMPORTANT: Clean connecting rod just enough to clean up bearing surface. DO NOT continue to clean after marks are removed from bearing surface.**



51083


- Clean Piston pin end of connecting rod using the same method as in step "b" preceding, but using 320 carborundum cloth instead of crocus cloth.
- Thoroughly wash connecting rod to remove abrasive grit. Recheck bearing surface of connecting rod. Replace any connecting rod that cannot be properly cleaned up. Lubricate bearing surfaces of connecting rod with a light oil to prevent rust from forming.



## Pistons

**IMPORTANT:** If engine was submerged while engine was running, piston and/or connecting rod may be bent. If piston pin is bent, piston must be replaced. If piston pin is bent, connecting rod must be checked for straightness.

1. Inspect pistons for scoring and excessive piston skirt wear.
2. Check tightness of piston ring locating pins. Locating pins must be tight.



3. Thoroughly clean pistons. Carefully remove carbon deposits from pistons, with a soft wire brush or carbon removal solution. Do not burr or round off machined edges of ring grooves.

Inspect piston ring grooves for wear and carbon accumulation. If necessary, scrape carbon from piston ring grooves. Refer to procedure following for cleaning piston ring grooves.

### CLEANING PISTON RING GROOVES


#### Keystone (tapered) ring grooves

#### **CAUTION**

**Care must be taken not to scratch the side surfaces of the ring groove. Scratching the side surface of the ring groove will damage the ring groove.**

1. Use a bristle brush and carbon removal solution to remove carbon from side surfaces.
2. A tool can be made for cleaning the inner diameter of the tapered ring grooves. For the top ring groove, break a tapered piston ring. This will enable the inside edge of the ring to reach the inner diameter of the groove. For the bottom ring groove, break a rectangular ring. Carefully scrape carbon from inner diameter of ring grooves. Care must be taken not to damage the grooves by scratching the side surfaces of the grooves.

**Piston with one (1) half keystone (half tapered) and one (1) rectangular ring.**




Enlarged View of Piston Ring Grooves



## MEASURING PISTON

1. Measure piston skirt at right angle (90°) to piston pin centerline.



56958

Standard Piston Diameter	
1994 – 6/8/9.9	53.92mm (2.123 in.)
1994 – 10/15	60.27mm (2.373 in.)
1995 and newer – 6/8	53.92mm (2.123 in.,)
9.9/10/15	60.27mm (2.373 in.)

## PISTON CLEARANCE

MINIMUM BORE MEASUREMENT  
 – MAXIMUM PISTON MEASUREMENT

= PISTON CLEARANCE

<p><b>PISTON CLEARANCE</b>                  0.05MM – 0.13MM                  (0.002 IN. – 0.005 IN.)</p>
--

## Reed Block


**IMPORTANT: DO NOT** remove reeds from reed block unless replacement is necessary. **DO NOT** turn used reeds over for reuse. Replace reeds in sets only.

1. Thoroughly clean reeds and reed block.
2. Check for wear (indentations), cracks or grooves on sealing surfaces of reed block that could cause leakage.
3. Check for chipped or broken reeds.
4. Inspect reed block seal for swelling or looseness. Replace seal if necessary.
5. Replace reeds as necessary.
6. After installing new reeds [having torqued screws to 2.3 Nm (20 lb. in.)], check new reeds as outlined in **Reed Opening** and **Reed Stop Opening** following.



### REED OPENING


1. Check reeds for preload and stand open conditions. Stand open should not exceed 0.178mm (0.007 in.). Replace reeds if necessary.



- a - Feeler gauge
- b - Reed
- c - Seal

### REED STOP OPENING

Reed stop opening can be checked by placing the appropriate sized drill bit between reeds and reed stops. Carefully bend reed stops if adjustment is necessary.




ALL MODELS	7.6mm (19/64 in.)
------------	-------------------



## Bleed System

1. Inspect bleed hoses for deterioration. Replace hoses as required.
2. Inspect bleed check valve in lower crankcase cover for proper function. Valve should flow fuel only one way – from bottom of crankcase cover to top crankshaft bearing via bleed fitting at top of crankcase cover. If check ball in valve is stuck open or closed, replace check valve. Bleed fitting at base of carburetor drains excess fuel which puddles at base of reed block.




- a** - Check valve  
**b** - Bleed fitting



## Thermostat (If Equipped)

<b>6/8/Work 10 (1999 And Prior)</b>	No Thermostat
<b>6/8/Work 10 (2000 And Newer)</b>	120° Thermostat
<b>9.9/10/15</b>	120° Thermostat

1. Wash thermostat with clean water. Using a thermostat tester, similar to the one shown, test thermostat as follows:
2. Open thermostat valve, then insert a thread between valve and thermostat body. Allow valve to close against thread.
3. Suspend thermostat (from thread) and thermometer inside tester so that neither touches the container. Bottom of thermometer must be even with bottom of thermostat to obtain correct thermostat opening.
4. Fill thermostat tester with water to cover thermostat.
5. Plug tester into electrical outlet.
6. Observe temperature at which thermostat begins to open. Thermostat will drop off thread when it starts to open. Thermostat must begin to open when temperature reaches 3° C (5° F) above designated stamping on bottom of thermostat.
7. Continue to heat water until thermostat is completely open.
8. Unplug tester unit.
9. Replace thermostat, if it fails to open at the specified temperature, or if it does not fully open.





# Powerhead Reassembly

## General Information

Before proceeding with powerhead reassembly, be sure that all parts to be reused have been carefully cleaned and thoroughly inspected, as outlined in **Cleaning and Inspection**. Parts, which have not been properly cleaned (or which are questionable), can severely damage an otherwise perfectly good powerhead within a few minutes of operation. All new powerhead gaskets must be installed during assembly.

During reassembly, lubricate parts with 2-Cycle Outboard Oil whenever 2-cycle oil is specified, and 2-4-C with Teflon whenever grease is specified.


### ⚠ CAUTION

Any **GREASE** used for bearings **INSIDE** the powerhead **MUST BE** gasoline soluble. Use only Needle Bearing Assembly Lubricant or 2-4-C with Teflon.

**IMPORTANT: A torque wrench is essential for correct reassembly of powerhead. DO NOT attempt to reassemble powerhead without using a torque wrench.**


## Crankshaft

1. Support crankshaft in press and install lower crankshaft ball bearing (open side of ball retainer facing crank) using powerhead stand with bearing sleeve. Bearing inner race must be firmly seated against crank shoulder.
2. Lubricate O-ring of new coupling seal with 2-4-C with Teflon. Install seal using powerhead stand.



53134

- a - Bearing
- b - Powerhead Stand (91-13662A1)
- c - Sleeve




53150

- d - Seal
- e - Powerhead Stand





3. Install a new sealing ring.



**a** - Sealing Ring



**NOTE:** It is recommended that the piston pin and piston be installed on the connecting rod prior to installing the connecting rod on the crankshaft to avoid possible bending of the rod during piston pin installation.

4. Install piston onto connecting rod as follows:

**IMPORTANT:** When replacing needle bearings, replace all needles as a set. **DO NOT** use old and new needles together.

- a. Lubricate sleeve of Piston Pin Tool with Needle Bearing Assembly Lubricant or 2-4-C with Teflon.
- b. Hold lower locating washer and sleeve onto piston pin bore of connecting rod and install needle bearing set of 24.


**NOTE:** If the tip of an awl can be inserted between the needle bearings, one or more needle is missing and must be replaced.



**a** - Sleeve  
**b** - Locating washer  
**c** - Needle bearings (24)




- c. Install upper locating washer.



53267

- a** - Locating washer

- d. Slide piston onto connecting rod, centering piston pin bore over sleeve.  
 e. Slide piston tool up through piston pin bore and remove sleeve.  
 f. Apply light oil to piston pin and place piston pin onto tool.



53275


53277

- a** - Sleeve  
**b** - Piston Pin Tool (91-13663A1)  
**c** - Piston pin


- g. Support bottom of piston and hold piston pin tool up against piston pin.  
 h. Drive piston pin into piston pin bore (with a soft face mallet) until pin is flush with piston.



i. Move piston pin tool to top of piston pin bore and center piston pin in piston.



53276




53143

- a - Piston Pin Tool (91-13663A1)
- b - Piston pin

5. Install new lockrings into grooves in both ends of piston pin bore.
6. Install connecting rods onto crankshaft as follows:
  - a. Apply 2-4-C with Teflon to connecting rod big-end bearings.

**IMPORTANT: Replace roller bearing halves as a set. DO NOT use old and new halves together.**


- b. Place both halves of connecting rod big-end roller bearing onto crank pin.



53279

95 2-4-C with Teflon

- a - Lockring
- b - Roller bearing





53132



**IMPORTANT: Clean connecting rod bolts with solvent and dry with compressed air. Inspect threads for damage. If threads are not damaged, bolts may be reused. Apply light oil to threads prior to installation.**

- c. Observe connecting rod/cap fracture line for correct alignment. Secure connecting rod (with v-notch of rod toward flywheel end of crankshaft) onto crankshaft with rod cap and bolts. Torque bolts to 11.3 Nm (100 lb. in.).




53138

**14** 2 Cycle Premium Outboard Oil

- a** - Fracture line
- b** - Connecting rod
- c** - V-notch (Toward flywheel)
- d** - Rod cap
- e** - Bolts [Torque to 11.3 Nm (100 lb. in.)]
- f** - Intake side
- g** - Exhaust side




7. Install new piston rings using Piston Ring Expander. Install RECTANGULAR ring first in bottom ring groove. Install HALF-KEYSTONE ring in top ring groove. Align piston rings with ring locating pins.



- a - Piston Ring Expander (91-24697)
- b - Rectangular ring
- c - Half-keystone ring
- d - Locating pin

**IMPORTANT: Chamfered side of retaining ring faces away from lower crankshaft ball bearing.**

8. Install retaining ring, stuffer washer and lower crankshaft oil seal.
9. Install upper crankshaft roller bearing and oil seal.




- a - Retaining ring
- b - Stuffer washer
- c - Lower oil seal
- d - Roller bearing
- e - Upper oil seal



**IMPORTANT: When replacing roller bearing halves, replace both halves together.**

10. Apply 2-4-C with Teflon to center main bearing surface of crankshaft and install center main roller bearing halves.




53133

95 2-4-C with Teflon

**a** - Bearing halves

11. **Model 10 and 1995 and newer Model 9.9:** Position center main bearing race halves (retaining ring groove toward flywheel end of crankshaft) around center main roller bearing. Make sure fracture lines of race halves are correctly mated.

12. Secure center main bearing race halves together with retaining ring. Verify retaining ring bridges both fracture lines of bearing race.



53127

**a** - Bearing race halves  
**b** - Retaining ring groove  
**c** - Fracture lines  
**d** - Retaining ring




## Cylinder Block


1. Lubricate piston rings, piston and cylinder wall with light oil.

**IMPORTANT: DO NOT seat crankshaft fully into block until center main sleeve and bearing half are installed.**

2. Keeping crankshaft horizontal, guide pistons into cylinder bores.




3. **1994 Model 9.9 and all Model 6/8:** Install 1/2 of center main bearing sleeve and bearing into cylinder block.



- a - Bearing sleeve
- b - Bearing


4. **1994 Model 6/8/9.9 and 1995 Model 6/8:** Install 2nd half of center main sleeve and bearing.



- a - Alignment boss
- b - Notch
- c - Retaining ring
- d - Sleeve
- e - Bearing




5. **Model 10/15 and 1995 and newer Model 9.9:** Align hole in center main bearing race with pin of cylinder block.




**a** - Hole  
**b** - Pin (hidden)

6. Position alignment boss of upper crankshaft roller bearing into notch in cylinder block.
7. Firmly press retaining ring (bevel faces DOWN) into groove in cylinder block and gently seat crankshaft assembly into position.
8. Gently push seals inward to seat.
9. Check each piston ring for spring tension through transfer and exhaust ports by pressing with a screwdriver. If no spring tension exists (ring fails to return to position), it is likely that the piston ring was broken during assembly [replace broken piston rings]. Use caution not to burr piston rings while inspecting.
10. Clean crankcase sealing surfaces according to Loctite Master Gasket instructions. Apply a continuous bead of Loctite sealant along the inside of the mounting bolt holes of crankcase cover.



53124



53144


**a** - Sealant

**IMPORTANT:** For 1994 Model 9.9 and all Models 6/8, split line of center main bearing sleeve halves **MUST ALIGN** when crankcase cover is installed onto cylinder block.





11. Place crankcase cover onto cylinder block and secure with 6 bolts. Torque bolts to 22.7 Nm (16.7 lb. ft.) in numbered torque sequence.



53192

**a** - Bolts [Torque to 22.7 Nm (16.7 lb. ft.)]


12. Rotate crankshaft several times to assure free operation.

13. If disassembled, assemble reed block as follows:

- a. Pull ends of rubber seal into holes in intake manifold/reed block. Trim off installation tabs from rubber seal and apply RTV Silicone Sealer at each location where seal passes through manifold.

**NOTE:** 1997 and newer reed blocks are rubber coated and do not require sealant.

- b. Secure reeds and reed stops to intake manifold/reed block with 6 screws. Torque screws to 2.3 Nm (20 lb. in.).




53202

- a** - Rubber seal  
**b** - Apply sealant (each side)  
**c** - Reeds  
**d** - Reed stops  
**e** - Screws [Torque to 2.3 Nm (20 lb. in.)]



14. **1996 Models and prior:** Apply 2-4-C with Teflon to rubber seal (to prevent seal from moving out of position) and secure intake manifold/reed block (with new gasket) using 3 bolts.


**ALL Models:** Torque bolts to 6.8 Nm (60 lb. in.).



53191

- a** - Bolts [Torque to 6.8 Nm (60 lb in.)]  
**b** - Intake manifold/reed block

15. **1994 Models:** Secure intake cover (with new gasket) using 2 bolts.  
**1995 Models and newer:** Inspect O-rings on intake cover for cuts or abrasions. Replace if necessary. Secure cover with 2 bolts. Torque bolts to 6.8 Nm (60 lb. in.).




53198

- a** - Bolts [Torque to 6.8 Nm (60 lb. in.)]  
**b** - Intake cover




16. Secure exhaust manifold and cover (with new gaskets) using 11 bolts. Torque bolts to 6.8 Nm (60 lb. in.) in torque sequence listed.

17. Secure cylinder block cover to block with 6 bolts. Torque bolts to 6.8 Nm (60 lb. in.) in sequence shown. Install thermostat, if equipped.




53188



53193

a - Thermostat

18. Install thermostat cover. Torque bolts to 6.8 Nm (60 lb. in.).



53194

a - Cover

b - Bolts [Torque to 6.8 Nm (60 lb. in.)]


19. Install the following components/assemblies referring to the listed service manual sections.

Component/Assembly	Section
Carburetor	3
Throttle/Shift Mechanism	7A/B/C
Electrical/Ignition Components and Flywheel	2A/B
Rewind Starter	8




## Powerhead Installation

1. Verify powerhead base surface and driveshaft housing mating surfaces are free of old gasket material.
2. Secure powerhead (with new gasket) onto driveshaft housing using 4 bolts and 2 nuts. Apply Loctite 680 Retaining Compound to threads of bolts. Torque bolts and nuts to 11.3 Nm (100 lb. in.).
3. Attach tell-tale hose to thermostat cover and fitting on bottom cowl.




53204



53125

- a** - Bolts (2 each side) [Torque to 11.3 Nm (100 lb. in.)]
- b** - Nuts (1 each side) [Torque to 11.3 Nm (100 lb. in.)]
- c** - Tell-tale hose
- d** - Thermostat cover
- e** - Cowl fitting

4. Secure end of shift shaft to yoke of horizontal shift shaft with lever.



53052

- a** - Shift shaft
- b** - Yoke
- c** - Lever
- d** - Apply 2-4-C with Teflon
- e** - Detent spring
- f** - Bolts [Torque to 2.8 Nm (25 lb. in.)]



## Set-Up and Test-Run Procedures

### **⚠ CAUTION**

**When engine is started, IMMEDIATELY check for fuel leaks and water leaks. Check for water pump operation by water being discharged from tell-tale.**

1. Following powerhead repairs, refer to Section 2C Timing/Synchronizing/Adjusting to perform set-up procedures.
2. While test running engine, check powerhead assembly for leaks and/or unusual noises. Make any repairs BEFORE returning engine to service.

## Break-In Procedure

### **⚠ CAUTION**

**To avoid possible engine damage, break-in procedure MUST BE completed BEFORE operating engine continuously at full throttle. Failure to break-in engine in properly will result in engine failure or shortened powerhead life.**

**IMPORTANT:** Advise the owner that the break-in procedure must be followed EXACTLY when returning an overhauled engine to service.

1. Mix gasoline and oil at the normal 50:1 ratio.
2. Operate engine at varied throttle settings for the first hour (1 hour). AVOID both wide-open-throttle operation and prolonged idle in cold water areas during this period.
3. After the first hour of operation, the engine is ready for normal operation and may be run at any speed. DO NOT EXCEED the full throttle RPM range listed in **Specifications**, preceding.





# MID-SECTION

## Section 5A – Clamp/Swivel Brackets and Drive Shaft Housing

### Table of Contents

---



Clamp Bracket .....	5A-2	Drive Shaft Housing Disassembly	
Swivel Bracket .....	5A-4	Reassembly .....	5A-7
Drive Shaft Housing .....	5A-6		


---





# Clamp Bracket



 95 2-4-C with Teflon









# Clamp Bracket (continued)

REF. NO.	QTY.	DESCRIPTION	TORQUE		
			lb. in.	lb. ft.	N-m
1	1	CLAMP BRACKET ( <b>BLACK-PORT</b> )			
2	1	CLAMP BRACKET ( <b>BLACK-STARBOARD</b> )			
3	2	THUMB SCREW ASSEMBLY			
4	2	HANDLE			
5	2	RIVET			
6	2	WASHER–thumb screw			
7	2	SCREW–washer attaching	65		7.3
8	1	SPACER			
9	2	SCREW (M6 x 40)	60		6.8
10	1	DECAL (TILT)			
11	1	SHUTTLE–tilt lock			
12	1	TILT TUBE ( <b>HANDLE MODELS</b> )			
	1	TILT TUBE ( <b>RC MODELS</b> )			
13	1	CLIP–safety			
14	2	NUT–tilt tube	120		13.6
15	2	WASHER–tilt tube			
16	2	LEVER ASSEMBLY–tilt return			
17	2	SCREW (M5 x 35)			
18	2	SPRING			
19	2	KNOB			
20	1	STRAP–tilt stop - port side			
21	2	SCREW–strap to clamp bracket	60		6.8
22	1	WAVE WASHER–tilt stop strap screw			
23	2	BOLT–clamp bracket to transom (1/4-20 x 3-1/2)			
24	2	WASHER–clamp bracket bolt			
25	2	NUT–clamp bracket bolt			
26	1	SPACER			
27	2	NUT			
28	1	SEAL			
29	1	O RING			
30	1	SPACER <b>RC MODELS</b>			
31	2	NUT			
32	3	WASHER (.625 O.D.)			
33	1	WASHER			
34	1	WASHER			
35	2	SCREW (M8 x 30)			
36	1	BRACKET			
37	2	NUT			
38	1	BALL JOINT			
39	1	TIE ROD			
40	1	SPACER			
41	1	DECAL-Lower Tilt Limit			
42	1	DECAL-Tilt Lock			



# Swivel Bracket



-  7 Loctite 271
-  94 Anti-Corrosion Grease
-  95 2-4-C with Teflon






## Swivel Bracket (continued)

REF. NO.	QTY.	DESCRIPTION	TORQUE		
			lb. in.	lb. ft.	N-m
1	1	SWIVEL BRACKET ( <b>BLACK</b> )			
2	3	GREASE FITTING			
3	1	BEARING			
4	1	THRUST BEARING—upper			
5	1	BUSHING—lower			
6	1	SEAL			
7	1	THRUST WASHER—lower			
8	1	SPRING			
9	1	BRACKET			
10	1	PIN			
11	1	HOOK—reverse lock			
12	1	PIVOT PIN			
13	1	RETAINING RING			
14	1	WASHER			
15	1	SPRING			
16	1	CARRYING HANDLE ( <b>BLACK</b> )			
17	1	SPRING—reverse hook			
18	2	E-RING			
19	1	ROD			
20	2	BRAKE DISC			
21	1	SWIVEL HEAD PLATE			
22	2	SCREW (M6 x 13)	70		7.9
23	1	BRAKE PLATE			
24	1	WASHER			
25	1	HANDLE			
26	1	NUT	125		14.1
27	1	DECAL—co-pilot			
28	1	DECAL-Serial Overlamine			



# Drive Shaft Housing



-  33 Loctite 680 Retaining Compound
-  95 2-4-C With Teflon



## Drive Shaft Housing (continued)

REF. NO.	QTY.	DESCRIPTION	TORQUE		
			lb. in.	lb. ft.	N-m
1	1	HOUSING ASSEMBLY ( <b>BLACK-SHORT</b> )			
	1	HOUSING ASSEMBLY ( <b>BLACK-LONG</b> )			
2	1	GASKET—drive shaft housing			
3	4	MOUNT			
4	2	COVER—mount ( <b>BLACK</b> )			
5	2	SCREW—mount cover (M6 x 80)			
6	2	WASHER			
7	2	NUT—cover screw	110		12.4
8	4	SCREW (M6 x 35)	100		11.3
9	1	SEAL—adaptor plate			
10	1	ADAPTOR PLATE ( <b>NO EXHAUST TUBE</b> )(6/8/9.9)			
	1	ADAPTOR PLATE ( <b>WITH EXHAUST TUBE</b> ) (15)			
11	1	EXHAUST TUBE (15)			
12	1	WATER TUBE ( <b>SHORT</b> )			
	1	WATER TUBE ( <b>LONG</b> )			
13	1	SEAL—water tube			
14	1	BEARING BLOCK ( <b>LONG</b> )			

## Drive Shaft Housing Disassembly/Reassembly

Servicing components such as steering arm, drive shaft housing, exhaust assembly and swivel bracket will usually require powerhead and/or gear housing removal.

Refer to SECTION 4 for powerhead removal and SECTION 6 for gear housing removal.

**NOTE:** With powerhead removed, always inspect and remove any carbon buildup in exhaust tube.

The transom bracket, lower mount bracket, tilt tube and lower engine mounts can be serviced without powerhead/gear housing removal. However, OUTBOARD MUST BE SUPPORTED BEFORE SERVICING COMPONENTS.

**IMPORTANT:** All gaskets should be replaced when removing powerhead and/or disassembling drive shaft housing. Corresponding gasket mating surfaces should be cleaned of any gasket material before installing new gaskets.



# MID-SECTION

## Section 5B – Power Trim

### Table of Contents

Table of Contents .....	5B-1	Troubleshooting the Down Circuit .....	5B-9
Specifications .....	5B-1	Troubleshooting the Up Circuit .....	5B-10
Special Tools .....	5B-1	Troubleshooting the Down and Up Circuits (All Circuits Inoperative) .....	5B-11
Power Trim Components .....	5B-2	Power Trim .....	5B-12
Power Trim – General Information .....	5B-4	Cylinder Removal .....	5B-12
Troubleshooting .....	5B-5	Cylinder Assembly/Installation .....	5B-14
Hydraulic Troubleshooting .....	5B-5	Hydraulic Pump .....	5B-16
Electrical Troubleshooting .....	5B-5	Removal .....	5B-16
Power Trim Relay Test Procedure .....	5B-6	Installation .....	5B-17
Remote Control .....	5B-7	Filling Hydraulic Reservoir .....	5B-17
Tiller Handle .....	5B-8		
General Checks .....	5B-9		


**5  
B**

### Specifications

Total Trim Degrees	56°
Required Voltage	12V
Minimum Battery Size	335Marine Cranking Amperes (260 Cold Cranking Amperes)


### Special Tools

- DMT 2000 Digital Tachometer Multi-meter P/N 91-854009A1





# Power Trim Components



**95** 2-4-C with Teflon

**114** Power Trim & Steering Fluid



## Power Trim Components (continued)

REF. NO.	QTY.	DESCRIPTION	TORQUE		
			lb-in.	lb-ft	Nm
1	1	UPPER BRACKET			
2	1	LINE, HYDRAULIC			
3	1	CYLINDER			
4	1	HYDRAULIC PUMP			
5	1	LOWER BRACKET			
6	1	PIVOT PIN, UPPER			
7	1	LINE, HYDRAULIC			
8	2	WASHER .281 X .625			
9	2	WASHER .344			
10	1	MOUNTING PLATE			
11	6	NUT (.250-28)	144		16.3
12	1	TILT STOP STRAP			
13	2	NUT (.312-18)			
14	1	WAVE WASHER			
15	2	BOLT (.312-18 X 3.50)			
16	2	BOLT (.250-28 X 1.75)	144		16.3
17	2	BOLT (.250-28 X 1.25)	144		16.3
18	2	BOLT (.250-28 X 1.50)	144		16.3
19	3	BOLT (.250-20 X .625)	80		9
20	2	TRIM RELAY			
21	1	NYLON BUSHING, LOWER CYLINDER			
22	2	PIN SPACER, LOWER CYLINDER			
23	2	NUT LOCKING (.500 X 20)	120		13.6
24	1	PIVOT PIN , LOWER			
25	1	HARNESS			





## Power Trim – General Information

### DESCRIPTION

The Power Trim System consists of an electric motor, fluid reservoir, pump and a trim/tilt cylinder.

The remote control (or trim panel) has switches that trim the outboard UP or DOWN and tilt the engine for Trailing. The outboard can be trimmed and tilted while under power or when the outboard is not running.

### TRIMMING CHARACTERISTICS

**NOTE:** *Because hull designs react differently in varying water conditions, Varying the trim position will often improve the ride and boat handling.*

### TRIMMING UP (OUT)

#### **WARNING**

**Excessive trim OUT may cause steering instability resulting in loss of operational control.**

Trimming UP will lift the boat bow, increase the boat speed, may increase steering torque to the port, increases gearcase clearance over submerged objects, and/or can cause boat to porpoise and/or ventilation.

### TRIMMING DOWN (IN)

#### **WARNING**

**Excessive trim IN may cause undesirable and/or unsafe steering conditions.**

Trimming DOWN aids in planing particularly with heavy loads, improves ride in choppy water, can cause bow steering (boat veers to left or right), and/or improves acceleration to planing speed.



# Troubleshooting

**IMPORTANT: Determine if Electrical or Hydraulic problem exist.**

## Hydraulic Troubleshooting

CONDITION OF TRIM SYSTEM	PROBLEM
A. Trim motor runs; trim system does not move up or down.	1, 2, 5
B. Does not trim down.	1, 2,
C. Does not trim up.	1, 2
D. Partial or Jerky down/up.	1, 3
E. Thump noise when shifting.	2, 3
F. Does not trim under load.	1, 2,
G. Does not hold trim position under load.	2, 3
H. Trail out when backing off from high speed.	2
I. Leaks down and does not hold trim.	2, 3
J. Trim motor working hard and trims slow up and down.	1, 2, 4
K. Starts to trim up from full down position when IN trim button is depressed.	2
L. Trim position will not hold in reverse.	2, 3

### PROBLEM

1. Low oil level.
2. Pump assembly faulty.
3. Tilt ram piston O-ring leaking or cut.
4. Check condition of battery.
5. Broken motor/pump drive shaft.

## Electrical Troubleshooting

CONDITION OF TRIM SYSTEM	PROBLEM
A. Trim motor does not run when trim button is depressed.	1, 2, 4, 5, 6, 7, 8
B. Trim system trims opposite of buttons.	3

### PROBLEM

1. Battery low or discharged.
2. Open circuit in trim wiring.
3. Wiring reversed in remote control or in panel control.
4. Wire harness corroded through.
5. Internal motor problem (brushes, shorted armature).
6. Blown fuses.
7. Trim switch failure.
8. Verify relays are functioning correctly.



## Power Trim Relay Test Procedure

The trim motor relay system used on permanent magnet trim systems, connects each of the two wires from the trim motor to either ground, or positive, in order to allow the motor to run in both directions.

If the motor will not run in the UP direction, it could be either the UP relay is not making contact to 12 volts **OR** the DOWN relay is not making contact to ground. The opposite is true if the system will not run DOWN. When the system is not energized, both relays should connect the heavy motor leads to ground.

To test which relay is faulty if the trim system does not operate in one direction:

1. Disconnect the heavy gauge pump wires from the trim control relay.
2. Check for continuity between the heavy leads from the trim relays to ground.


Ohmmeter Leads Between	Resistance (Ohms)	Scale Reading (R x 1)
Green and Ground	0	Full Continuity (Rx1)
Blue and Ground	0	Full Continuity (Rx1)

Replace the relay that does not have continuity.

3. Connect a voltmeter to the heavy BLUE lead and to ground. You should have 12 volts on the BLUE lead when the UP switch is pushed. You should also have 12 volts on the GREEN lead when the DOWN switch is pushed. Replace the relay that does not switch the lead to positive.




# Remote Control



- BLK = Black
- BLU = Blue
- BRN = Brown
- GRY = Gray
- GRN = Green
- ORN = Orange
- PNK = Pink
- PUR = Purple
- RED = Red
- TAN = Tan
- WHT = White
- YEL = Yellow
- LT = Light
- DRK = Dark



# Tiller Handle



Transom/panel mounted Trim Switch

UP Relay

DOWN Relay

- BLK = Black
- BLU = Blue
- BRN = Brown
- GRY = Gray
- GRN = Green
- ORN = Orange
- PNK = Pink
- PUR = Purple
- RED = Red
- TAN = Tan
- WHT = White
- YEL = Yellow
- LT = Light
- DRK = Dark




## General Checks

Before troubleshooting the Power Trim electrical system, check the following:

1. Check for disconnected wires.
2. Make certain all connections are tight and corrosion free.
3. Check that plug-in connectors are fully engaged.
4. Make certain battery is fully charged.


Refer to the preceding Remote Control or Tiller Handle wiring diagram for connection points when troubleshooting the electrical system. (Connection points are specified by number.)

## Troubleshooting the Down Circuit






# Troubleshooting the Up Circuit





## Troubleshooting the Down and Up Circuits (All Circuits Inoperative)








# Power Trim

## Cylinder Removal


1. Support outboard in a trimmed up position.
2. Remove the tilt stop strap retaining bolts/nuts.
3. Remove the upper bracket.
4. Remove the upper pivot pin from the bracket.



- a** - Tilt stop strap retaining bolt
- b** - Tilt stop strap
- c** - Upper bracket nut
- d** - Upper pivot pin
- e** - Upper bracket



5. Loosen the cylinder hydraulic lines. Do not remove.
6. Remove the hydraulic lines from the pump assembly.
7. Remove the cylinder lower pivot pin nuts.
8. Remove the pivot pin.
9. Remove the hydraulic lines from the cylinder .




- a**- Cylinder hydraulic lines
- b**- Pump hydraulic lines
- c**- Lower pivot pin nut (2)
- d**- Lower pivot pin




## Cylinder Assembly/Installation

1. Install the hydraulic lines to cylinder. DO NOT TIGHTEN.
2. Insert the nylon bushing into the cylinder lower pivot bore.
3. Lubricate cylinder lower pivot bore with 2-4-C with Teflon.



- a** - Hydraulic line (2)
- b** - Nylon bushing

4. Insert the lower pivot pin into the support bracket.
5. Install the spacer.
6. Align the cylinder with the lower pivot pin. Push the pivot pin through the tilt cylinder so it is flush with cylinder.
7. Insert the remaining spacer and push pivot pin through.
8. Install pivot nuts. Tighten to the specified torque.
9. Install hydraulic lines to hydraulic pump finger tight. Be careful not to cross thread the hydraulic line flare nuts in the pump body.
10. Tighten all Hydraulic lines.



58073


- a** - Support bracket
- b** - Pivot pin
- c** - Spacer (2)
- d** - Pivot nut (2)
- e** - Hydraulic line flare nut

### Lower Pivot Pin Nut Torque

13.6 Nm (120 lb-in.)



11. Install the upper pivot pin into the upper bracket.
12. Guide the upper pivot through the trim cylinder rod eye and through the upper bracket.
13. Install the upper bracket to the swivel bracket.
14. Secure the bracket with 2 shoulder bolts inserted through the tilt stop brackets.
15. Install a washer and nylock nut on shoulder bolt. Tighten to specified torque.



- a** - Tilt stop strap retaining bolt (2)
- b** - Tilt stop strap (2)
- c** - Washer (2)
- d** - Upper bracket nut (2)
- e** - Upper pivot pin
- f** - Upper bracket
- g** - Swivel bracket

Tilt Stop Strap Retaining Bolt Torque
---------------------------------------


16.3 Nm (144 lb-in.)
----------------------



# Hydraulic Pump

## Removal


1. Support the outboard in a trimmed up position.
2. Loosen the hydraulic lines at the cylinder. (Do not remove hydraulic lines from cylinder).



58073

### **a**- Cylinder hydraulic lines

3. Disconnect the trim motor wires from the solenoid harness. (Refer to the Remote Control and Tiller Handle Wiring Diagrams in this section.)
4. Remove the hydraulic lines from the hydraulic pump.
5. Remove the 3 screws holding the hydraulic pump to the support bracket.



58073


### **a**- Hydraulic lines

### **b**- Hydraulic pump screws (3)



## Installation

1. Install hydraulic pump to support bracket with 3 screws. Do not tighten.
2. Install hydraulic lines to hydraulic pump finger tight. Be careful not to cross thread the hydraulic line flare nut in the pump body.
3. Tighten the hydraulic pump mounting screws to the specified torque.
4. Tighten the hydraulic lines at the pump and cylinder.
5. Connect the motor wires to the solenoid harness.



58073

- a**- Cylinder hydraulic lines
- b**- Hydraulic pump mounting screw (3)
- c**- Hydraulic pump lines

Hydraulic Pump Mounting Screw Torque
--------------------------------------

9 Nm (80 lb-in.)
------------------

## Filling Hydraulic Reservoir

1. Open the manual release valve 3 turns.
2. Fill the reservoir with Power Trim and Steering Fluid. Install the fill cap.
3. Manually raise and lower the trim several times.
4. Check the level of the fluid in the reservoir. Fill as needed. Install the fill cap.
5. Manually raise and lower the trim several times as needed.
6. Tighten the manual release valve.
7. Cycle the trim 3 times electrically. Check for proper operation and fluid level in reservoir.





# LOWER UNIT

## Section 6 – Gear Housing

### Table of Contents

Specifications .....	6-1	Drive Shaft Needle Bearing, Bushing and Lubrication Sleeve Installation .....	6-22
Special Tools .....	6-2	Forward Gear Bearing Race Installation .	6-24
Gear Housing (Drive Shaft) (2.00:1 Gear Ratio) .....	6-4	Forward Gear Reassembly .....	6-24
Gear Housing (Propeller Shaft) (2.00:1 Gear Ratio) .....	6-7	Bearing Carrier Reassembly .....	6-25
Gearcase Removal .....	6-8	Water Pump Base and Shift Shaft Reassembly .....	6-26
Gearcase Disassembly .....	6-9	Propeller Shaft Reassembly .....	6-27
Propeller Removal .....	6-9	Forward Gear, Pinion Gear and Drive Shaft Installation .....	6-28
Draining and Inspecting Gear Lubricant .	6-9	Shift Shaft and Water Pump Base Installation .....	6-29
Bearing Carrier .....	6-10	Water Pump Cover Reassembly .....	6-30
Propeller Shaft .....	6-12	Impeller and Pump Cover Installation ...	6-31
Water Pump, Drive Shaft and Shift Shaft .....	6-13	Propeller Shaft and Bearing Carrier Installation .....	6-32
Pinion Gear and Forward Gear .....	6-17	Installation .....	6-33
Drive Shaft Bushing, Bearing and Lubrication Sleeve .....	6-20	Propeller Installation .....	6-37
Aluminum Anode and Water Inlet .....	6-22	Filling Gear Housing with Lubricant .....	6-38
Reassembly .....	6-22		

**6**

### Specifications

<b>GEAR HOUSING</b>	<b>Gear Ratio</b> <b>Gearcase Capacity</b> <b>Lubricant Type</b> <b>Forward Gear - No. of Teeth-Type</b> <b>Pinion Gear - No. of Teeth-Type</b> <b>Pinion Height</b> <b>Forward Gear Backlash</b> <b>Reverse Gear Backlash</b> <b>Water Pressure</b> <b>With Thermostat</b> – @ W.O.T (5000 RPM) – @ Idle <b>Without Thermostat</b> – @ W.O.T (5000 RPM) – @ Idle (750 RPM)	2.0:1 200 ml (6.8 fl. oz.) Premium Blend Gear Lubricant 26 Spiral/Bevel 13 Spiral/Bevel Floating No Adjustment No Adjustment  (5 – 7 PSI) 3.4 - 10.3 kPa (.5 – 1.5 PSI)  34.5 - 48.3 kPa (5 – 7 PSI) 0 - 6.9 kPa (0 – 1 PSI)
---------------------	---	---


**NOTE:** Tell-tale at IDLE may be intermittent on engines with thermostats installed.






# Special Tools

- 1. Universal Puller Plate 91-37241



- 2. Puller Assembly 91-83165T and Puller Plate 91-29310




**a** - Puller Plate 91-29310


- 3. Slide Hammer 91-34569A1



- 4. Bearing Carrier Tool 91-13664




- 5. Drive Shaft Bearing Removal Tool 91-824788A1



**a** - Drive Shaft Bushing Removal Tool 23-824789


- 6. Drive Shaft Bushing Installation Tool 91-824790A1




**a** - Drive Shaft Bearing Installation Tool 91-824791




7. Mandrel 91-13658T



8. Bushing Removal Tool 91-824787




9. Seal Installation Tool 91-824785T1




**a** - Seal/Bushing Installation Tool 23-824786


10. Expanding Rod (SNAP ON P/N CG40-4)\*



11. Collet (Jaws) (SNAP ON P/N CG40-15)\*



12. Leakage Tester FT8950








\*Purchase From: SNAP ON TOOLS Corporation  
2801 - 80th Street  
Kenosha, Wi. 53141-1410



# Gear Housing (Drive Shaft) (2.00:1 Gear Ratio)

**2.60 IN./102MM  
TORPEDO DIA.**



-  Loctite 271
-  RTV 587 Silicone Sealer
-  High Performance Gear Lubricant
-  2-4-C with Teflon


**Gear Housing (Drive Shaft) (2.00:1 Gear Ratio) (continued)**





REF. NO.	QTY.	DESCRIPTION	TORQUE		
			lb. in.	lb. ft.	N-m
-	1	GEAR HOUSING ( <b>BLACK-SHORT</b> )			
-	1	GEAR HOUSING ( <b>BLACK-LONG</b> )			
1	1	GEAR HOUSING ( <b>BLACK-BASIC</b> )			
2	1	BUSHING–gear housing			
3	1	DRAIN SCREW			
4	1	SEALING WASHER			
5	1	SLEEVE ASSEMBLY			
6	1	SLEEVE			
7	1	BUSHING			
8	1	SCREW PLUG KIT			
9	1	SEALING WASHER			
10	1	SCREEN			
11	1	SCREW	30		3.4
12	1	ANODE ASSEMBLY			
13	1	SCREW	30		3.4
14	1	SEAL			
15	1	PINION GEAR (13 TEETH)			
16	1	WASHER–thrust			
17	1	BEARING			
18	1	WATER PUMP BASE			
19	1	GASKET			
20	1	SEAL			
21	1	RETAINER			
22	1	SCREW (10-16 x 1/2)		Drive Tight	
23	1	QUAD RING			
24	2	OIL SEAL			
25	1	GASKET			
26	1	WATER TUBE			
27	1	FACE PLATE			
28	1	COVER ASSEMBLY			
29	1	INSERT			
30	1	SEAL			
31	1	IMPELLER			
32	1	KEY ASSEMBLY			
33	2	WASHER			
34	1	GUIDE			
35	5	SCREW–water pump (M6 x 30)	50		5.6
36	1	CAM–shift			
37	1	SHIFT SHAFT ( <b>SHORT</b> )			
	1	SHIFT SHAFT ( <b>LONG</b> )			
38	1	E-RING			
39	2	GUIDE			
40	1	SCREW (M5 x 25)	45		5.1
41	1	NUT–guide screw	45		5.1
42	1	DRIVE SHAFT ( <b>SHORT</b> )			
	1	DRIVE SHAFT ( <b>LONG</b> )			
43	1	THRUST WASHER			



# Gear Housing (Propeller Shaft) (2.00:1 Gear Ratio)

2.60 IN./102MM  
TORPEDO DIA.



-  7 Loctite 271
-  87 High Performance Gear Lubricant
-  94 Anti-Corrosion Grease
-  95 2-4-C with Teflon



## Gear Housing (Propeller Shaft) (2.00:1 Gear Ratio) (continued)

REF. NO.	QTY.	DESCRIPTION	TORQUE		
			lb. in.	lb. ft.	N-m
-	1	GEAR HOUSING (BLACK-SHORT)			
-	1	GEAR HOUSING (BLACK-LONG)			
1	1	GEAR HOUSING (BLACK-BASIC)			
44	1	ROLLER BEARING			
45	1	CUP			
46	1	FORWARD GEAR (26 TEETH)			
47	1	BUSHING			
48	1	CAM FOLLOWER			
49	1	CLUTCH ASSEMBLY			
50	1	CROSS PIN			
51	1	SPRING			
52	1	PROPELLER SHAFT			
53	1	REVERSE GEAR (26 TEETH)			
54	1	BEARING CARRIER		85	115.2
55	1	O-RING			
56	1	BUSHING			
57	1	OIL SEAL			
58	1	OIL SEAL			
59	1	SCREW (M8 x 50)	180		20.3
60	2	SCREW (M8 x 30)	180		20.3
61	1	PROPELLER (9-1/4 IN. x 7 IN.)			
	1	PROPELLER (9 IN. x 9 IN.)			
	1	PROPELLER (9-3/4 IN. x 6-1/2 IN.)			
62	1	SPACER			
63	1	PROPELLER NUT	100		11.3
64	1	THRUST HUB			
65	1	HI-REVERSE THRUST CUP			




# Gearcase Removal

## ⚠ WARNING

To prevent accidental engine starting, remove (and isolate) spark plug leads from spark plugs **BEFORE** removing gear housing.


1. Remove and isolate spark plug leads from spark plugs.
2. Shift outboard into FORWARD gear.
3. Tilt outboard to full UP position.
4. Remove shift shaft retainer.



53049


**a** - Retainer

5. Remove reverse lock actuator.
6. Remove 3 bolts.



53004

**a** - Actuator  
**b** - Bolts (3)



52998




# Gearcase Disassembly

## Propeller Removal

### ⚠ WARNING

If gear housing is NOT removed from drive shaft housing, remove and isolate spark plug leads from spark plugs to prevent outboard from accidentally starting while removing and installing propeller.

1. Place a block of wood between anti-ventilation plate and propeller to prevent propeller from turning and to protect hands while removing prop.
2. Remove nut, thrust hubs and propeller.



- a - Wood
- b - Nut
- c - Thrust hub

52547

## Draining and Inspecting Gear Lubricant


1. Remove both VENT and FILL screws with gaskets.
2. Inspect gear lubricant for metal particles. Presence of a small amount of fine metal particles (resembling powder) indicates normal wear. Presence of large particles (chips) or a large quantity of fine particles indicates need for gear housing disassembly and component inspection.
3. Note color of gear lubricant. White or cream color indicates presence of water in lubricant.

**NOTE:** When draining gearcase for the first time, lubricant may appear cream colored due to the mixing of assembly lubricant and gear lubricant. This is NOT an indication of water intrusion. If, during subsequent draining of gearcase, lubricant appears cream colored or milky, water may be present, gearcase should be disassembled and all gaskets, seals and O-rings replaced. Inspect all components for water damage.






4. Check drain pan for water separation from lubricant. Presence of water in gear lubricant indicates the need for disassembly and inspection of oil seals, seal surfaces and gear housing components.



- a - Vent screw
- b - Fill screw


### Bearing Carrier

1. Remove bearing carrier (LEFT HAND thread) using Bearing Carrier Tool.



2. Remove carrier and propeller shaft assembly from housing.

**NOTE:** Cam follower is free to slide out of propeller shaft.




- a - Cam follower



3. Remove propeller shaft and REVERSE gear from bearing carrier.
4. Replace REVERSE gear if gear teeth or clutch teeth are chipped or worn.


**NOTE:** When using a punch to remove carrier seals, be careful to not to scar carrier seal surface with punch. If carrier seal surface is damaged, replace carrier.

5. Using a suitable punch, remove both seals from bearing carrier.



- a - Gear teeth
- b - Clutch teeth
- c - Oil seal
- d - Fish line cutter seal
- e - Punch

6. Replace bearing carrier bushing if bushing or area on propeller shaft that bushing contacts is pitted or worn. Press bushing from carrier using Bushing Removal Tool.




- a - Bushing
- b - Bushing Removal Tool (91-824787)




## Propeller Shaft

1. Inspect cam follower for wear. If cam follower is worn, replace follower and inspect shift cam for serviceability. Replace cam if worn.



**a** - Cam follower


2. Remove groove pin from clutch/propeller shaft applying pressure to side of pin that is NOT grooved. Discard pin.



53013

**a** - Punch  
**b** - Groove pin (discard)

3. Remove spring and sliding clutch.




53005

**a** - Spring  
**b** - Clutch

4. Replace clutch if jaws are rounded or chipped. Rounded jaws may be caused by the following:


- a. Improper shift cable adjustment.
- b. Engine idle speed too high while shifting.
- c. Shifting too slowly from NEUTRAL into FORWARD or REVERSE.



52990



5. Inspect bushing surfaces of propeller shaft for pitting or wear. Replace shaft and corresponding bushing if wear or pitting is observed.
6. Replace shaft if any of the following exist:
  - a. Splines are twisted or worn.
  - b. Oil seal surface is grooved.
  - c. Shaft has a noticeable wobble or is bent more than 0.15mm (.006 in.).




52997

- a** - Bushing surfaces  
**b** - Oil seal surface  
**c** - Measure here for wobble (When measuring shaft for wobble, use v-blocks and support at bushing surface)


## Water Pump, Drive Shaft and Shift Shaft

1. Remove 4 bolts from pump cover.
2. Remove cover, nylon washers above and below impeller, impeller and drive key from drive shaft.
3. It is recommended that impeller be replaced whenever gearcase is being serviced.

**NOTE:** If impeller is not going to be replaced, DO NOT install impeller in reverse rotation to its original state as vanes have taken a set. Vanes will crack and break shortly after outboard is returned to service.



53023




53048


- a** - Pump cover bolts (4)  
**b** - Cover  
**c** - Nylon washer  
**d** - Impeller  
**e** - Nylon washer  
**f** - Key



4. Remove guide from cover.
5. Replace rubber seal if damaged.
6. Replace cover if inside is grooved.
7. Remove plate, gasket, quad-ring, bolt and washer.
8. Replace plate if grooved.



53032



53012



- a** - Guide
- b** - Seal
- c** - Plate
- d** - Gasket (discard)
- e** - Quad-ring
- f** - Bolt and washer

9. Replace seal if damaged.




10. Remove water pump base and shift shaft from housing.

11. Remove gasket.




- a - Seal
- b - Pump base
- c - Shift shaft
- d - Gasket (discard)

12. Remove clip from shift shaft. Unthread shift cam. Remove shaft from water pump base.



- a - Clip
- b - Shift cam


13. Inspect shift cam for wear. Replace if worn.



- a - Shift cam




14. Remove screw and pull water tube from base.



- a - Screw
- b - Water tube


15. Replace seal if damaged. Replace water tube if corroded.



- a - Seal
- b - Water tube

16. Remove drive shaft from gear housing.

**NOTE:** Thrust washers, pinion gear and forward gear assembly are free to fall from housing when drive shaft is removed.



- a - Thrust washer (without oil groove)
- b - Thrust washer (with oil groove – groove faces down)
- c - Pinion gear
- d - Forward gear assembly



17. Inspect bearing/bushing surfaces of drive shaft for pitting or wear. If shaft is pitted or worn, replace shaft and corresponding bearing/bushing.



18. Replace drive shaft if the following exist:

- a. Splines are twisted or worn.
- b. Oil seal surface is grooved.

19. Using a screw driver or punch, carefully remove (and discard) seals from pump base.




- a** - Bushing surface
- b** - Bearing surface
- c** - Seal surface
- d** - Seals

## Pinion Gear and Forward Gear

### PINION GEAR

1. Inspect pinion gear teeth for breakage, rust, chipping or excessive wear.
2. If pinion gear teeth are damaged, inspect FORWARD and REVERSE gear for damage.
3. Replace gears as required.




- a** - Pinion gear






## FORWARD GEAR

1. Inspect forward gear teeth for breakage, rust, chipping and excessive wear.
2. Inspect forward gear clutch jaws for wear. Rounded jaws indicate the following:
  - a. Improper shift cable adjustment.
  - b. Engine idle speed too high.
  - c. Shifting too slowly.



- a** - Gear teeth  
**b** - Clutch teeth


3. Inspect propeller shaft FORWARD gear bushing surface to determine condition of bushing. If surface is discolored from lack of lubricant, pitted or worn, propeller shaft and bushing should be replaced.



- a** - Bushing  
**b** - Bushing surface



- If necessary, press bushing from gear using Bushing Removal Tool.




- a - Bushing
- b - Bushing Removal Tool (91-824787)

**IMPORTANT:** If FORWARD gear tapered bearing or race requires replacement, replace bearing and race as a set.

**NOTE:** DO NOT remove tapered bearing from FORWARD gear unless replacement is necessary as removal process will damage bearing.


- Inspect FORWARD gear tapered bearing and race for rust, roughness or excessive wear.
- If bearing is in serviceable condition, DO NOT remove bearing from gear as removal process will damage bearing.
- If bearing must be replaced, remove bearing from gear using Universal Puller Plate and a suitable mandrel.




- a - Bearing
- b - Universal Puller Plate (91-37241)
- c - Mandrel



- Replace FORWARD gear race if it is rusted or damaged or if FORWARD gear tapered bearing must be replaced. Remove race from housing using Bearing Puller Assembly and Puller Plate.



53031




52996


- a - Race
- b - Bearing Puller Assembly (91-83165M)
- c - Puller Plate (91-29310)

### Drive Shaft Bushing, Bearing and Lubrication Sleeve

- Inspect drive shaft bushing and bearing surface to determine condition of corresponding upper drive shaft bushing and lower drive shaft needle bearing. If drive shaft surface is rusted, pitted, discolored (blued – lack of lubrication) or worn; replace drive shaft and corresponding bushing/bearing. DO NOT remove bushing or bearing if replacement is not necessary.



53036



53041


- a - Bushing surface
- b - Bearing surface
- c - Upper drive shaft bushing
- d - Lower drive shaft needle bearing

**IMPORTANT:** If upper drive shaft bushing or lower drive shaft needle bearing appear to be spinning in their respective bores, the gear housing should be replaced.



- To replace upper drive shaft bushing, use  
Snap On\* Expanding Rod (CG 40-4)  
Snap On Collet (CG 40A6)  
Slide Hammer (91-34569A1)

\*Purchase from: Snap On Tools Corporation  
2801 - 80th Street  
Kenosha, WI 53141-1410




- a - Expanding Rod (CG 40-4)
- b - Collet (CG 40A6)
- c - Slide Hammer (91-34569A1)
- d - Bushing

- To gain access to lower drive shaft needle bearing, remove lubrication sleeve.

**NOTE:** When upper drive shaft bushing is installed, a burr may be formed preventing the removal of the lubrication sleeve. Use a knife to remove burr.

- Remove needle bearing using Drive Shaft Bearing Removal Tool (91-824788A1).




- a - Lubrication Sleeve
- b - Needle Bearing
- c - Driver Shaft Bearing Removal Tool
- d - Pilot



# Aluminum Anode and Water Inlet

1. Replace aluminum anode if more than 50% consumed.
2. Remove water inlet and check that holes are not obstructed.




- a** - Aluminum anode
- b** - Water inlet

## Reassembly

### Drive Shaft Needle Bearing, Bushing and Lubrication Sleeve Installation


1. Install lower drive shaft needle bearing (numbers/letters face down) using Drive Shaft Bushing Tool.



- a** - Puller bolt
- b** - Flat washer
- c** - Wafer bearing
- d** - Pilot
- e** - Needle bearing
- f** - Mandrel



2. Install lubrication sleeve.




53040

a - Sleeve

3. Install upper drive shaft bushing assembly using Drive Shaft Bushing Tool.

**NOTE:** The upper drive shaft bushing is pressed into a sleeve. If the bushing is not worn into the sleeve or the bushing is not spinning within the sleeve, the bushing alone may be replaced. Press the new bushing into the sleeve using a suitable mandrel. If the sleeve is damaged, the bushing/sleeve assembly must be replaced.




91-824790A1

- a - Puller bolt
- b - Flat washer
- c - Wafer bearing
- d - Pilot
- e - Bushing/Sleeve
- f - Mandrel



## Forward Gear Bearing Race Installation


Install race into housing using Mandrel and Bearing Carrier Tool.



- a** - Race
- b** - Mandrel (91-13658)
- c** - Bearing Carrier Tool (91-13664)

## Forward Gear Reassembly

Install bushing and bearing using Mandrel and press.





- a** - Mandrel (91-13658)
- b** - Bushing
- c** - Bearing



## Bearing Carrier Reassembly

1. Apply High Performance Gear Lubricant to bushing and press bushing into carrier using Mandrel.
2. Apply Loctite 271 to O.D. of seal and with lip facing bushing, press seal into carrier using Mandrel.





 High Performance Gear Lubricant


 Loctite 271

- a - Bushing
- b - Mandrel (91-824785A1)
- c - Mandrel (91-824785A1)
- d - Ring (used with mandrel)
- e - Seal (LIP FACES BUSHING)
- f - Bushing

3. Apply Loctite 271 to O.D. of fishline cutter seal. With ring removed from Mandrel, press seal, with LIP FACING Mandrel, into carrier. Apply 2-4-C with Teflon between lips of both seals.
4. Apply 2-4-C with Teflon to O-ring and install O-ring on carrier.



 Loctite 271

 2-4-C with Teflon

- a - Fishline cutter seal (LIP FACES MANDREL)
- b - Mandrel (without ring – 91-824785A1)
- c - O-ring


53011





## Water Pump Base and Shift Shaft Reassembly

1. Apply Loctite 271 to O.D. of seal. With lip of seal facing DOWN, push seal into base using Mandrel.
2. Apply Loctite 271 to O.D. of seal. With seal lip facing UP, push seal into base using Mandrel. Apply 2-4-C with Teflon between lips of both seals.




Loctite 271

- a** - Seal (Lip FACES DOWN)
- b** - Mandrel (91-13655)
- c** - Seal (Lip FACES UP)
- d** - Mandrel (91-13655)

2-4-C with Teflon


3. Install seal onto water tube.
4. Secure water tube to pump base with retainer and screw.



- a** - Seal
- b** - Pump base
- c** - Water tube
- d** - Retainer
- e** - Screw



5. Install shift shaft through pump base.
6. Install E-clip on shift shaft. Clip must be below pump base.
7. Thread shift cam onto shaft.




53034

- a - E-clip
- b - Shift cam

## Propeller Shaft Reassembly


1. Slide clutch onto propeller shaft.



53000

- a - Sliding clutch
- b - Short end (FORWARD gear side)
- c - Hole (must align with slot)
- d - Slot

2. Insert cam follower spring into shaft.




53005

- a - Spring




3. Compress spring and install NEW groove pin.



- a - Vise
- b - Screwdriver or small punch
- c - Spring
- d - Groove pin (press in until flush)
- e - Serrations


4. Apply 2-4-C with Teflon to cam follower (flat side) and install follower into shaft.



- a - Cam Follower
- b - Flat Side

### Forward Gear, Pinion Gear and Drive Shaft Installation

1. Install FORWARD gear assembly into forward gear race.
2. Install drive shaft through upper drive shaft bushing, oil sleeve and lower drive shaft needle bearing.
3. While lifting drive shaft slightly, install lower thrust washer (GROOVED SIDE FACES DOWN) and PINION gear. It may be necessary to rotate drive shaft slightly to engage pinion gear with splines of drive shaft and with forward gear teeth.
4. Install upper thrust washer above upper drive shaft bushing.




- a - FORWARD gear assembly
- b - Drive shaft bushing
- c - Oil sleeve
- d - Needle bearing

- e - Lower thrust washer (GROOVED SIDE FACES DOWN)
- f - Pinion gear
- g - Upper thrust washer




## Shift Shaft and Water Pump Base Installation


1. Apply 2-4-C with Teflon to I.D. of seal.
2. Install seal in housing with tapered end facing up.
3. Install base gasket with drain hole positioned as shown.



53041




53015

 2-4-C with Teflon

- a - Seal
- b - Tapered I.D.
- c - Base gasket
- d - Hole

**IMPORTANT: Verify seal is not pushed out of position when water tube is installed.**

4. Slide water pump base with shift shaft down drive shaft. Align water tube with seal in housing while seating water pump base.




53014

- a - Shift shaft
- b - Shift cam (POSITION AS SHOWN)
- c - Pump base
- d - Water tube
- e - Seal




5. Apply 2-4-C with Teflon to I.D. and O.D. of shift shaft quad ring. Seat quad ring in pump base.
6. Apply Loctite 271 to bolt threads and secure pump base to housing with bolt and washer. Torque bolt to 5.6 Nm (50 lb in.).
7. Install gasket and face plate.



53012



Loctite 271




2-4-C with Teflon

- a - Quad ring
- b - Bolt and washer [Torque to 5.6 Nm ( 50 lb. in.)]
- c - Gasket
- d - Face plate

### Water Pump Cover Reassembly

1. Apply 2-4-C with Teflon to O.D. of seal and seal surface.
2. Install seal into cover.
3. Place water tube guide onto seal.



53032



2-4-C with Teflon

- a - Seal
- b - Seal surface
- c - Guide





## Impeller and Pump Cover Installation

1. Install neoprene washer.
2. Install drive key. Use 2-4-C with Teflon to hold key to drive shaft.

**IMPORTANT:** It is recommended that the impeller be replaced regardless of appearance. If impeller must be reused, it must be installed in the direction of original rotation. Installing impeller with vanes reversed from their previous set will result in vane breakage shortly after unit is returned to service.

3. Install new impeller and align with drive key.
4. Install neoprene washer.
5. Lubricate I.D. of water pump cover with 2-4-C with Teflon.
6. Install cover on drive shaft and while pushing down on cover, rotate drive shaft CLOCKWISE and install cover over impeller.
7. Apply Loctite 271 to threads of bolts. Secure cover with bolts and torque to 5.6 Nm ( 50 lb. in.) per following numbered torque sequence.



 Loctite 271



 2-4-C with Teflon


- a - Neoprene washer
- b - Drive key
- c - Impeller
- d - Neoprene washer
- e - Cover



## Propeller Shaft and Bearing Carrier Installation

1. Install REVERSE gear into bearing carrier.
2. If not previously lubricated, apply 2-4-C with Teflon to o-ring.
3. Apply 2-4-C with Teflon to bearing carrier threads and pilot diameter.
4. Slide bearing carrier onto propeller shaft and install entire assembly into gear housing.
5. Torque bearing carrier to 115.2 Nm (85 lb. ft.) using Bearing Carrier Tool (91-13664).



 2-4-C with Teflon

- a** - Bearing carrier threads
- b** - Propeller shaft
- c** - Pilot diameter




# Installation

## ⚠ WARNING

To prevent accidental engine starting, remove and isolate spark plug leads from spark plugs. BEFORE installing gear housing.

1. Remove and isolate spark plug leads from spark plugs.
2. Place shift linkage on engine in FORWARD gear position.
3. Tilt engine to full up position.
4. Place gear housing in NEUTRAL. Propeller will rotate freely in either direction when gear housing is in NEUTRAL.
5. Position shift shaft as shown when measuring distance in Step 6.
6. Distance between top of water pump base and center of hole, must be as specified below. Turn shift shaft clockwise to decrease distance or counter clockwise to increase distance.



53051


- a - Shift shaft
- b - Shaft distance
- c - Center of hole

Drive Shaft Length	Distance
Short	419mm (16-1/2 in.)
Long	559mm (22 in.)
Extra Long	698mm (27-1/2 in.)






7. Place gear housing in FORWARD gear. Gear housing will ratchet when propeller shaft is turned clockwise.
8. Apply a 6.4mm (1/4 in.) diameter bead of RTV Sealer on water pump base.



53023

**a** - RTV Sealer

9. Install gear housing as follows:
  - a. Position gear housing so that drive shaft and shift shaft extend into drive shaft housing.
  - b. Move gear housing toward drive shaft housing while keeping mating surfaces parallel.
  - c. Guide shift shaft through hole in mid-section.
  - d. Guide water tube into water tube guide.
  - e. Rotate propeller counterclockwise while pushing upward on gear housing to align drive shaft splines with crankshaft splines.
  - f. Guide end of shift shaft into shift coupling yoke under cowl.





53004

**a** - Shift shaft hole





10. Secure detent spring to block with 2 bolts. Spring may have slotted holes. Install spring so that it is raised UP and at end of slot travel. Torque bolts to 2.8 Nm (25 lb. in.).
11. Secure end of shift shaft to yoke of horizontal shift shaft with coupler. Rotate coupler until it locks in place.



-  2-4-C with Teflon
- a** - Shift shaft
  - b** - Yoke
  - c** - Coupler
  - d** - Apply 2-4-C with Teflon
  - e** - Detent spring
  - f** - Bolts [Torque to 2.8 Nm (25 lb. in.)]

12. Apply Loctite 271 to 3 bolts and torque to 20.3 Nm (15.0 lb. ft.).




-  Loctite 271
- a** - Bolts [Torque to 20.3 Nm (15.0 lb. ft.)]

13. Check shift operation as follows:
  - a. Place shift lever in FORWARD. Gear housing should ratchet when propeller shaft is turned clockwise and resistance should be felt when propeller is turned counterclockwise.
  - b. Place shift lever in NEUTRAL. Resistance should NOT be felt when propeller shaft is rotated in either direction.
  - c. Place shift lever in REVERSE. Resistance should be felt when propeller shaft is rotated in either direction.
  - d. If shift operation is not as described, remove gear housing and recheck distance measurement in Step 6.
14. Place shift lever in NEUTRAL.



15. Install reverse lock actuator loosely on shift shaft.
16. Position reverse lock actuator so that it just contacts reverse lock hook; secure in this position. Torque actuator screw to 5.1 Nm (45 lb. in.). The outboard will now ONLY TILT UP IN FORWARD GEAR. If the operator wishes the outboard to tilt up in FORWARD and NEUTRAL, place shift lever in REVERSE. Install reverse lock actuator loosely on shift shaft. Position actuator so that 6.4mm (0.25 in.) clearance exists between reverse lock hook and actuator. Secure actuator in this position. Torque actuator screw to 5.1 Nm (45 lb. in. ).



53004

- a** - Reverse lock actuator
- b** - Screw and locknut [Torque to 5.1 Nm (45 lb. in.)]
- c** - Reverse lock hook




## Propeller Installation

### ⚠ WARNING

If gear housing is NOT removed from drive shaft housing, BEFORE attempting to remove or install the propeller, remove (and isolate) spark plug leads from spark plugs to prevent engine from starting accidentally.

1. Apply Anti-Corrosion Grease to propeller shaft.
2. Install inner thrust hub.
3. Slide propeller onto shaft.
4. Install outer thrust hub.
5. Thread propeller nut onto shaft.




 94 Anti-Corrosion Grease

52547

- a - Inner thrust hub
- b - Propeller
- c - Outer thrust hub
- d - Propeller nut

6. Place a block of wood between propeller and anti-ventilation plate to prevent propeller from turning and to protect hands. Torque nut to 7.9 Nm (70 lb. in.).



- a - Outer thrust hub
- b - Nut



## Filling Gear Housing with Lubricant


**NOTE:** Gear housing lubricant capacity – 6.8 oz. (200 ml).

**IMPORTANT: DO NOT use automotive grease in the gear housing. Use Premium Gear Lubricant or High Performance Gear Lubricant**

1. Remove any gasket material from “FILL” and “VENT” screws and housing.
2. Install new gaskets on “FILL” and “VENT” screws.

**IMPORTANT: Never apply lubricant to gear housing without first removing “VENT” screw or gear housing cannot be filled because of trapped air. Fill gear housing ONLY when housing is in a vertical position.**

3. Slowly fill housing through “FILL” hole until lubricant flows out of “VENT” hole and no air bubbles are present.
4. Reinstall “VENT” screw.
5. Remove grease tube from “FILL” hole and quickly install “FILL” screw.



52998

- a** - Vent screw  
**b** - Fill screw



# ATTACHMENTS/CONTROL LINKAGE

## Section 7A – Throttle/Shift Linkage (Tiller Handle Shift Models)

### Table of Contents

---


Throttle and Shift Linkage (Tiller Handle Shift)	7A-2	Removal .....	7A-8
Control Cables (Tiller Handle Shift) .....	7A-4	Reassembly .....	7A-8
Removal/Installation .....	7A-4	Installation .....	7A-10
Control Platform .....	7A-4	Neutral Interlock Control Lever .....	7A-11
Removal/Disassembly .....	7A-4	Reassembly/Installation .....	7A-11
Reassembly/Installation .....	7A-5	Horizontal Shift Shaft .....	7A-12
Throttle Cam/Control Lever .....	7A-8	Reassembly/Installation .....	7A-12

---





# Throttle and Shift Linkage (Tiller Handle Shift)



95 2-4-C with Teflon



# Throttle and Shift Linkage (continued)

REF. NO.	QTY.	DESCRIPTION	TORQUE		
			lb. in.	lb. ft.	N-m
1	1	CONTROL PLATFORM			
2	1	GEAR			
3	1	GEAR			
4	1	SCREW (M6 x 30)			
5	2	WASHER			
6	1	SPACER (SHORT)			
7	2	NUT	60		6.8
8	1	PRIMARY LEVER			
9	1	SCREW (M6 x 40)			
10	1	SPACER (LONG)			
11	2	SCREW (M6 x 16)	60		6.8
12	1	TIMING LINK			
13	1	CONTROL LEVER			
14	1	SCREW (M5 x 8 x 35)			
15	1	ACTUATOR			
16	1	LINK			
17	1	SCREW (M6 x 40)	70		7.9
18	1	WASHER			
19	1	BUSHING			
20	1	SPRING			
21	1	LOCKWASHER			
22	1	SPRING			
23	1	THROTTLE LINK			
24	1	SOCKET			
25	1	LEVER			
26	1	BUSHING			
27	1	SPRING			
28	1	SCREW (M6 x 30)	70		7.9
29	1	WASHER			
30	1	LEVER			
31	1	LEVER			
32	1	SHIFT SHAFT			
33	1	SHIFT LINK			
34	2	SCREW (M5 x 8 x 8)	25		2.8
35	1	SPRING			
36	1	SWITCH ASSEMBLY			
37	2	SCREW (20MM) <b>15 ELECTRIC HANDLE</b>			
38	1	PLATE			





# Control Cables (Tiller Handle Shift)


## Removal/Installation

Refer to **Section 7C** for removal and installation instructions.


## Control Platform

### Removal/Disassembly

1. Disconnect control cables from anchor bracket and pulley as outlined in **Section 7C**.
2. Disconnect throttle link rod from ball joint of primary throttle lever.
3. Disconnect shift link rod from ball joint of gear shift lever.




- a - Cables
- b - Bracket
- c - Pulley
- d - Link rod




- e - Throttle lever
- f - Shift link rod
- g - Gear shift lever
- h - Shift lever

4. Remove 3 bolts and control platform.
5. Remove nuts and flat washers.




- a - Bolts
- b - Control platform



- c - Nuts
- d - Flat washers



6. Disassemble control platform.




53174


- a** - Nuts (2) [Torque to 6.8 Nm ( 60 lb. in.)]
- b** - Flatwashers (2)
- c** - Primary throttle lever
- d** - Spacer (long)
- e** - Secondary gear
- f** - Spacer (short)
- g** - Gear shift lever
- h** - Control platform
- i** - Bolts (2)
- j** - Mount bolts [Torque to 6.8 Nm (60 lb. in.)]

**Reassembly/Installation**

1. Install short spacer and long spacer into recesses of control platform.
2. Lubricate spacers and area of platform traveled by gears with 2-4-C with Teflon.
3. Install gear shift lever and secondary gear over spacers and lubricate gear teeth with 2-4-C with Teflon.



53167




53168

- a** - Short spacer
- b** - Long spacer
- c** - Platform
- d** - Gear shift lever
- e** - Secondary gear




4. Index primary throttle lever into secondary gear.




- a** - Primary throttle lever
- b** - Secondary gear

5. Install bolts, washers and nuts. Torque nuts to 6.8 Nm (60 lb. in.).



- a** - Nuts [Torque to 6.8 Nm ( 60 lb. in.)]
- b** - Washers
- c** - Bolts


6. Secure assembled control platform onto cylinder block using 3 bolts. Torque bolts to 6.8 Nm (60 lb. in.).



- a** - Platform
- b** - Bolts [Torque to 6.8 Nm (60 lb. in.)]




- Adjust shift link rod to a length of 13.0 cm (5-1/8 in.) as measured between ball joint centerlines.
- Connect shift link rod between joints of gear shift lever and shift shaft lever.



- a** - Shift link rod [Adjust to length of 13.0 cm (5-1/8 in.)]
- b** - Shift shaft lever
- c** - Gear shift lever

- Adjust throttle link rod to a length of 12.4 cm (4-7/8 in.) as measured between ball joint centerlines.
- Connect throttle link rod between ball joints of primary throttle lever and throttle cam.
- Connect control cables to pulley of secondary gears and anchor bracket as outlined in **Section 7C**.




- a** - Primary throttle lever
- b** - Pulley
- c** - Control cables
- d** - Throttle cam
- e** - Anchor bracket
- f** - Throttle link rod [Adjust to length of 12.4cm (4-7/8 in. )]



# Throttle Cam/Control Lever

## Removal

1. Refer to **Section 7C** for removal of throttle cables.
2. Remove bolt and flat washer securing cam/lever to powerhead.




53162


- a - Bolt
- b - Washer
- c - Cam/lever

## Reassembly

1. Assemble inner spring and outer spring together.
2. Position spring assembly over hub of throttle cam.



53182




53177


- a - Inner spring
- b - Outer spring
- c - Inner spring ends
- d - Outer spring ends
- e - Hub
- f - Tabs



3. Wind end of inner spring to position tab of cam between inner spring ends. Verify spring windings are firmly held around diameter of cam hub and that no windings are positioned on top of hub.
4. Lubricate bushing with 2-4-C with Teflon and install bushing and wave washer.




53178




53176

- a - Inner spring end
- b - Tab
- c - Cam hub
- d - Bushing
- e - Wave washer

5. Install control lever onto throttle cam assembly so that tab of control lever is positioned between ends of inner spring.
6. Hook longer spring end of outer spring behind peg of control lever.



53179





53180

- a - Control lever
- b - Tab
- c - Ends of inner spring
- d - Longer spring end
- e - Peg




## Installation

1. Secure throttle cam/control lever assembly onto mounting boss of crankcase cover with bolt. Torque bolt to 7.9 Nm (70 lb. in.).
2. Connect timing link between ball joints of control lever and trigger assembly.



- a - Throttle cam
- b - Control lever
- c - Flat washer
- d - Bolt [Torque bolt to 7.9 Nm (70 lb. in.)]
- e - Timing link
- f - Control lever

3. Adjust throttle link rod to a length of 12.4 cm (4-7/8 in.) as measured between ball joint center lines.
4. Connect throttle link rod between ball joints of throttle cam and primary throttle lever.




- a - Throttle link rod [Adjust to a length of 12.4 cm (4-7/8 in.)]
- b - Throttle cam
- c - Primary throttle lever





## THROTTLE CAM/CONTROL LEVER CROSS SECTIONAL VIEW




- a** - Throttle cam
- b** - Control lever
- c** - Bushing
- d** - Wave washer

- e** - Springs
- f** - Flat washer
- g** - Bolt [Torque to 7.9 Nm (70 lb. in.)]


## Neutral Interlock Control Lever

### Reassembly/Installation

1. Lubricate bushing with 2-4-C with Teflon and install bushing and spring.
2. Secure interlock lever components with bolt onto mounting boss of crankcase cover.



53260



53171

- a** - Bushing
- b** - Spring
- c** - Interlock lever
- d** - Spring ends
- e** - Flat washer
- f** - Bolt [Torque to 7.9 Nm (70 lb. in.)]
- g** - Neutral interlock wire (install in top hole)







# Horizontal Shift Shaft

## Reassembly/Installation

1. Install horizontal shift shaft/shift lever assembly into opening in STARBOARD side of crankcase cover.
2. Apply 2-4-C with Teflon to detent of yoke and install yoke onto shift shaft.




53187



53147

- a - Horizontal shift shaft
- b - Shift lever
- c - Yoke
- d - Detent

3. Secure detent spring to block with 2 bolts. Spring may have slotted holes. Install spring so that it is raised UP and at end of slot travel. Torque bolts to 2.8 Nm (25 lb. in.).
4. Secure end of shift shaft to yoke of horizontal shift shaft with lever.



53052

- a - Shift shaft
- b - Yoke
- c - Lever
- d - Apply 2-4-C with Teflon
- e - Detent spring
- f - Bolts [Torque to 2.8 Nm (25 lb. in)]

5. Refer to **Control Platform/Throttle Cam/Control Lever** previous and reinstall platform, shift link and throttle cam.



# ATTACHMENTS/CONTROL LINKAGE

## Section 7B – Throttle Shift Linkage (Side Shift Models)

### Table of Contents

---


Throttle and Shift Linkage (Side Shift) .....	7B-2	Installation .....	7B-6
Throttle Cables (Side Shift Models) .....	7B-4	Neutral Interlock Control Lever .....	7B-8
Removal/Installation .....	7B-4	Reassembly/Installation .....	7B-8
Throttle Cam/Control Lever .....	7B-4	Horizontal Shift Shaft .....	7B-8
Removal .....	7B-4	Reassembly/Installation .....	7B-8
Reassembly .....	7B-4		


---





# Throttle and Shift Linkage (Side Shift)



 95 2-4-C with Teflon



## Throttle and Shift Linkage (Side Shift) (continued)

REF. NO.	QTY.	DESCRIPTION	TORQUE		
			lb. in.	lb. ft.	N-m
1	1	CABLE BRACKET			
2	2	SCREW	60		6.8
3	1	SCREW	35		4.0
4	1	WASHER			
5	1	SHIFT HANDLE			
6	1	GROMMET			
7	1	SHIFT SHAFT			
8	1	LEVER			
9	1	LEVER			
10	1	SPRING			
11	2	SCREW (M5 x 8 x 8)	25		2.8
12	1	TIMING LINK			
13	1	CONTROL LEVER			
14	1	SCREW (M5 x 8 x 35)			
15	1	LOCKWASHER			
16	1	SPRING			
17	1	SPRING			
18	1	ACTUATOR			
19	1	BUSHING			
20	1	WASHER			
21	1	SCREW	70		7.9
22	1	LINK			
23	1	LEVER			
24	1	SPRING			
25	1	SCREW	70		7.9
26	1	WASHER			
27	1	BUSHING			



## Throttle Cables (Side Shift Models)


### Removal/Installation

Refer to **Section 7C** for removal and installation instructions.

## Throttle Cam/Control Lever

### Removal

1. Refer to **Section 7C** for removal of throttle cables.
2. Remove bolt and flat washer securing cam/lever to powerhead.




53185

- a** - Throttle Cam
- b** - Control Lever
- c** - Flat Washer
- d** - Bolt [Torque bolt to 7.9 Nm (70 lb. in.)]

### Reassembly

1. Assemble inner spring and outer spring together.




53182


- a** - Inner spring
- b** - Outer spring



2. Position spring assembly over hub of throttle cam.
3. Wind end of inner spring to position tab of cam between inner spring ends. Verify spring windings are firmly held around diameter of cam hub and that no windings are positioned on top of hub.




53177




53178

- a - Inner spring ends
- b - Outer spring ends
- c - Hub
- d - Tabs
- e - Inner spring end
- f - Tab
- g - Cam hub

4. Lubricate bushing with 2-4-C with Teflon and install bushing and wave washer.
5. Install control lever onto throttle cam assembly so that tab of control lever is positioned between ends of inner spring.



53176




53179

- a - Bushing
- b - Wave washer
- c - Control lever
- d - Tab
- e - Ends of inner spring



- Hook longer spring end of outer spring behind peg of control lever.




53180

- a - Longer spring end
- b - Peg


## Installation

- Secure throttle cam/control lever assembly onto mounting boss of crankcase cover with bolt. Torque bolt to 7.9 Nm (70 lb. in.).
- Connect timing link between ball joints of control lever and trigger assembly.



53185

- a - Throttle cam
- b - Control lever
- c - Flat washer
- d - Bolt [Torque bolt to 7.9 Nm (70 lb. in.)]




53225

- e - Timing link
- f - Control lever




3. Connect throttle cables to throttle cam and throttle cable anchor bracket as outlined in Throttle Cable – Installation, preceding.



53189

- a - Throttle cables
- b - Throttle cam
- c - Bracket

### THROTTLE CAM/CONTROL LEVER CROSS SECTIONAL VIEW



- a - Throttle cam
- b - Control lever
- c - Bushing
- d - Wave washer
- e - Springs
- f - Flat washer
- g - Bolt [Torque to 7.9 Nm (70 lb. in.)]







# Neutral Interlock Control Lever

## Reassembly/Installation

1. Lubricate bushing with 2-4-C with Teflon and install bushing and spring.
2. Secure interlock lever components with bolt onto mounting boss of crankcase cover.





- a** - Bushing
- b** - Spring
- c** - Interlock lever
- d** - Spring ends
- e** - Flat washer
- f** - Bolt [Torque to 7.9 Nm (70 lb. in.)]
- g** - Neutral interlock wire (install in top hole)

# Horizontal Shift Shaft

## Reassembly/Installation


1. Install horizontal shift shaft/shift lever assembly into opening in STARBOARD side of crankcase cover.
2. Apply 2-4-C with Teflon to detent of yoke and install yoke onto shift shaft.



- a** - Horizontal shift shaft
- b** - Shift lever
- c** - Yoke
- d** - Detent




3. Install rubber grommet into opening in starboard side of bottom cowl.
4. Secure shift handle onto end of horizontal shift shaft with screw and flat washer. Torque screw to 4.0 Nm (35 lb. in.).



53181

- a** - Grommet
- b** - Shift handle
- c** - Screw
- d** - Washer

5. Secure detent spring to block with 2 bolts. Spring may have slotted holes. Install spring so that it is raised UP and at end of slot travel. Torque bolts to 2.8 Nm (25 lb. in.).
6. Secure end of shift shaft to yoke of horizontal shift shaft with coupler.



53052

- a** - Shift shaft
- b** - Yoke
- c** - Coupler
- d** - Apply 2-4-C with Teflon
- e** - Detent spring
- f** - Bolts [Torque to 2.8 Nm (25 lb. in.)]



# ATTACHMENTS/ CONTROL LINKAGE

## Section 7C – Tiller Handle

### Table of Contents

---


Swivel Head and Steering Handle . . . . .	7C-2	Removal . . . . .	7C-6
Control Cables (Tiller Handle Shift Models) . . .	7C-4	Installation . . . . .	7C-7
Removal . . . . .	7C-4	Control Cables (Tiller Handle Shift Models) . . .	7C-9
Throttle Cables (Side Shift Models) . . . . .	7C-5	Installation . . . . .	7C-9
Removal . . . . .	7C-5	Throttle Cable (Side Shift Models) . . . . .	7C-11
Tiller Handle Removal/Disassembly . . . . .	7C-6	Installation . . . . .	7C-11


---





# Swivel Head and Steering Handle



 95 2-4-C with Teflon



# Swivel Head and Steering Handle (continued)


REF. NO.	QTY.	DESCRIPTION	TORQUE		
			lb. in.	lb. ft.	N-m
1	1	SWIVEL HEAD (BLACK)			
2	2	BUSHING			
3	1	PLATE			
4	1	GREASE FITTING			
5	2	SCREW (M5 x 1 x 16)	70		7.9
6	2	WASHER			
7	1	WAVE WASHER			
8	1	WASHER			
9	1	STEERING HANDLE ARM (BLACK)			
10	1	RETAINER			
11	1	SCREW (M5 x .8 x 16)	35		4.0
12	1	COVER KIT			
13	1	PULLEY			
14	1	PULLEY CASE			
15	1	SCREW (10-16 x 1/2)	20		2.3
16	2	THROTTLE CABLE			
17	1	SLEEVE			
18	1	DECAL			
19	1	GRIP			
20	1	STOP SWITCH			
21	1	THROTTLE FRICTION KNOB			Finger Tight
22	1	THROTTLE FRICTION LOCK			As Required
23	1	SCREW (M6 x 1 x 25)			
24	1	THROTTLE HANDLE			
25	1	TILLER TUBE			
26	1	SPRING			
27	1	START/STOP SWITCH			
28	1	HOUSING <b>ELECTRIC HANDLE</b>			
29	1	CLIP			



## Control Cables (Tiller Handle Shift Models)

### Removal

1. Place tiller handle twist grip in NEUTRAL position.
2. Remove throttle link rod from throttle cam and primary throttle lever.




53046

- a** - Link rod
- b** - Throttle cam
- c** - Primary throttle lever

3. Loosen jam nuts which secure control cables to anchor bracket.
4. Unwrap and remove control cables from pulley of secondary gear.


**NOTE:** If not replacing control cables, mark top cable with a piece of tape to aid in reassembly.

5. Disconnect stop button wires – BLACK/YELLOW and BLACK.



53162

- a** - Jam nuts
- b** - Secondary gear
- c** - BLACK/YELLOW
- d** - BLACK



53157




# Throttle Cables (Side Shift Models)

## Removal

1. Loosen jam nuts which secure throttle cables to anchor bracket and remove cables from pulley of throttle cam.


**NOTE:** If not replacing throttle cables, mark top cable with a piece of tape to aid in reassembly.



53186

- a** - Jam nuts
- b** - Throttle cables
- c** - Anchor bracket
- d** - Throttle cam

2. Disconnect stop button wires – BLACK/YELLOW and BLACK.



53156


- a** - BLACK/YELLOW
- b** - BLACK



# Tiller Handle Removal/Disassembly

## Removal


1. Remove 2 bolts securing tiller handle to anchor bracket and remove tiller handle assembly.



53155


**a** - Bolts

2. Remove bushing, flatwashers (2), wave washer and tiller handle washer. Remove retainer and bolt.
3. Slide tiller tube out of pulley case.



53248

**a** - Bushing  
**b** - Flat washer (2)  
**c** - Wave washer  
**d** - Tiller handle washer  
**e** - Retainer  
**f** - Bolt




53256

**g** - Tiller tube  
**h** - Pulley case






4. Remove pulley case assembly from tiller handle and remove cover bolt.
5. Remove cover and lift pulley assembly from case. Replace cables as required.




### Installation

1. Wrap cables around pulley. Top cable wraps and locks in top groove. Bottom cable wraps and locks in bottom groove.
2. Place pulley and cable assembly into pulley case.
3. Install pulley cover and secure cover with bolt. Torque bolt to 2.3 Nm (20 lb. in.).




4. Install pulley assembly into tiller handle and slide tiller tube into pulley.






5. Secure tiller tube in handle with retainer and bolt. Torque bolt to 4.0 Nm (35 lb. in. ).
6. Install tiller washer (tab aligns with slot in handle), plain washer, wave washer, plain washer and flanged bushing over cable/harness assembly.




53248

- |   |                            |
|---|----------------------------|
| <b>a</b> - Retainer                             | <b>e</b> - Slot            |
| <b>b</b> - Bolt [Torque to 4.0 Nm (35 lb. in.)] | <b>f</b> - Plain washer    |
| <b>c</b> - Tiller washer                        | <b>g</b> - Wave washer     |
| <b>d</b> - Tab                                  | <b>h</b> - Flanged bushing |

7. Slide tiller handle assembly into anchor bracket.
8. Route stop button harness through fuel connector opening in bottom cowl.
9. Route control cables through opening in bottom cowl.
10. Align tabs of inner and outer flanged bushings with slots in anchor bracket.
11. Pull on cable ends to remove slack and secure tiller handle to anchor bracket with plate and 2 bolts. Torque bolts to 7.9 Nm (70 lb. in.).



53169



53155


- |  |
|--|
| <b>a</b> - Stop button harness                   |
| <b>b</b> - Control cables                        |
| <b>c</b> - Tabs                                  |
| <b>d</b> - Plate                                 |
| <b>e</b> - Bolts [Torque to 7.9 Nm (70 lb. in.)] |



# Control Cables (Tiller Handle Shift Models)


## Installation

1. Rotate tiller handle twist grip to REVERSE gear position.
2. Route extended cable over top of secondary gear pulley and secure cable into inner groove of pulley. Place cable jacket into inner notch of cable anchor bracket.



- a - Extended cable
- b - Inner groove
- c - Cable jacket
- d - Inner notch


3. Rotate tiller handle to FORWARD gear position.
4. Route remaining cable below secondary gear pulley and secure cable into outer groove of pulley. Place cable jacket into lower notch of cable anchor bracket.



- a - Cable
- b - Outer groove
- c - Cable jacket
- d - Lower notch




- Position tab washers to lock control cables to holes of cable anchor bracket.



**a** - Tab washers  
**b** - Hole

- Rotate tiller handle twist grip to NEUTRAL.
- Adjust jam nuts to remove slack from control cables while allowing full travel of throttle/shift linkage.



53165

**a** - Jam nuts  
**b** - Cables

- After cables are adjusted, verify FORWARD, NEUTRAL and REVERSE gears can be selected while smoothly advancing and retarding throttle. If throttle/shift operation is not correct, inspect for pinched or kinked cables, misaligned linkage or loose attaching bolts.


**NOTE:** It may be necessary to rotate propeller shaft in order to select REVERSE gear.



# Throttle Cable (Side Shift Models)


## Installation

1. Rotate tiller handle twist grip to FAST position.
2. Place gear shift lever into FORWARD gear.
3. Secure extended cable into groove in top side of throttle cam pulley. Place cable jacket into upper notch of cable anchor bracket.




- a - Extended cable
- b - Pulley
- c - Cable jacket
- d - Notch

4. Rotate tiller handle twist grip to SLOW position.
5. Secure remaining cable into groove in bottom side of pulley. Place cable jacket into lower notch of anchor bracket.
6. Secure throttle cables into notches of cable anchor bracket.
7. Rotate tiller handle twist grip to SLOW position.
8. Adjust jam nuts to remove slack from throttle cables while allowing full travel of throttle linkage/carburetor throttle shutter.



53186

- a - Cable
- b - Pulley
- c - Cable jacket
- d - Notch
- e - Jam nuts



53186



# MANUAL STARTER

## Section 8

### Table of Contents


---


Manual Starter .....	8-2	Starter Rope Replacement .....	8-6
Rewind Starter Assembly .....	8-4	Disassembly .....	8-8
Removal .....	8-4	Cleaning and Inspection .....	8-9
Installation .....	8-5	Reassembly .....	8-9

---



# Manual Starter



 2-4-C with Teflon



## Manual Starter (continued)

REF. NO.	QTY.	DESCRIPTION	TORQUE		
			lb. in.	lb. ft.	N-m
-	1	RECOIL STARTER ASSEMBLY			
1	1	STARTER HOUSING			
2	1	BUSHING			
3	1	RETAINING RING			
4	1	SPRING			
5	1	STARTER PULLEY			
6	1	ROPE-starter			
7	2	SPRING			
8	2	CAM			
9	2	RETAINING RING			
10	1	SPRING			
11	1	CAM			
12	1	SCREW	135		15.3
13	1	FELT PAD			
14	1	REST			
15	4	SPACER-rest screw			
16	1	SUPPORT			
17	2	SCREW-rest to starter housing (M5 x 35)			
18	2	NUT-rest screw	30		3.4
19	1	LEVER-lock ( <b>UPPER</b> )			
20	1	WASHER-upper lock lever			
21	1	LEVER-lock ( <b>LOWER</b> )			
22	1	SCREW-lower lock lever (10-16 x 1/2)	30		3.4
23	3	SCREW-starter housing attaching (M6 x 20)	70		7.9
24	1	HANDLE ASSEMBLY			
25	1	RETAINER			
26	1	DECAL-Servicing Referral			
27	1	DECAL-Warning-High Voltage			
28	1	DECAL-Emergency Starting Procedure			







# Rewind Starter Assembly

## Removal

**⚠ CAUTION**


**DO NOT** turn fuel filter assembly when removing. Remove fuel filter by pulling straight down. Turning fuel filter may break fuel line connection on filter.

1. Pry fuel filter from starter rope guide. DO NOT turn filter; pull straight down.
2. Unsnap interlock link rod from lower lock lever.



- a** - Filter
- b** - Guide
- c** - Link rod
- d** - Lock lever

3. Remove 3 bolts and lift rewind starter from engine.





- a** - Bolts
- b** - Rewind starter



## Installation

1. Secure rewind starter to engine with 3 bolts. Torque bolts to 7.9 Nm (70 lb. in.).
2. Snap interlock link rod into lower lock lever.




- 53242
- a** - Bolts [Torque to 7.9 Nm (70 lb. in.)]
  - b** - Rewind starter
  - c** - Link rod
  - d** - Lock lever

### ⚠ CAUTION

Push filter straight up when installing. Turning filter may break fuel line connection on filter.

3. Push ball of fuel filter into socket of rope guide. DO NOT turn fuel filter.




- 53247
- a** - Filter
  - b** - Guide



# Starter Rope Replacement

1. Remove rewind starter from engine, as outlined previously.
- NOTE:** If starter is broken, remove all remaining rope from sheave.
2. Disengage starter interlock from starter sheave.
3. Pull starter rope handle out from rewind starter about 30.5 cm (1 ft.) and tie a knot at this point to prevent rope from being pulled back into rewind starter.
4. Remove rope retainer from starter handle and rope.




5. Install starter handle on new rope [cut to a length of 157.5 cm (62 in.)]. Tie a knot into end of rope. Place knot into recess of rope retainer. Install rope retainer into starter handle.

**⚠ CAUTION**


**Starter sheave must be firmly held against spring tension to prevent spring from unwinding.**

6. Pull starter rope from rewind starter until rope is fully unwound from starter sheave.






7. While holding sheave in this position, lift knot from recess and pull all remaining rope from sheave.
8. Turn sheave COUNTERCLOCKWISE until stop, indicating spring is wound tight.
9. Slowly turn sheave CLOCKWISE (with spring tension) until knot recess is aligned with rope hole in starter housing.




53245




53218

- a - Sheave
- b - Knot
- c - Recess
- d - Sheave
- e - Knot recess
- f - Rope hole

10. Push end of new rope through rope holes in starter housing and starter sheave. Pull end of rope out of knot recess.
11. Tie a knot into end of rope and pull knot back into knot recess.



53222



53219

- a - Rope
- b - Holes
- c - Knot recess
- d - Knot
- e - Knot recess

12. Allow starter rope to be slowly rewound onto starter sheave.




# Disassembly

## ⚠ WARNING

When disassembling rewind starter, **SAFETY GLASSES MUST BE WORN** in case spring should uncoil out of housing.


1. Remove starter rope as outlined previously.
2. With rope removed, allow sheave to slowly unwind to release spring tension.
3. Remove bolt securing cam and sheave to housing.



5220

- a** - Bolt
- b** - Sheave

4. Gently lift starter sheave from housing.
5. Rewind spring assembly may be replaced as required. **DO NOT** remove spring from retainer. Spring and retainer are replaced as an assembly.



53241

- a** - Sheave
- b** - Rewind spring




## Cleaning and Inspection

1. Clean rewind spring assembly with solvent and dry with compressed air.
2. Inspect rewind spring (without removing spring from retainer) for kinks, burrs or breakage. Replace assembly if necessary.
3. Inspect cam tension spring for damage. Replace as necessary.
4. Inspect starter sheave and housing for nicks, grooves, cracks and distortion especially in area of rope travel. Replace assembly if necessary.
5. Inspect starter rope for wear and replace if necessary.


## Reassembly

1. Apply 2-4-C with Teflon to rewind spring and cam tension spring.
2. Install rewind spring assembly into recoil housing positioning end of spring in notch.



- a** - Rewind spring
- b** - Notch
- c** - Cam tension spring


3. Install starter sheave into housing aligning notches in sheave with appropriate locations on recoil spring retainer.



- a** - Sheave
- b** - Retainer
- c** - Alignment notches




**NOTE:** If sheave will not seat fully over recoil spring assembly, inspect spring retainer, through lock lever access hole in housing, for proper alignment with sheave.



- a** - Spring retainer
- b** - Lock lever access hole
- c** - Sheave

4. Secure cam to housing with bolt. Torque bolt to 7.9 Nm (70 lb. in.).



- a** - Cam
- b** - Bolt

**NOTE:** If, after tightening cam retaining bolt, sheave does not move freely, sheave is not aligned properly with recoil spring retainer. Remove cam retainer bolt and check alignment of sheave with spring retainer.

5. Install starter rope as outlined previously.
6. Install rewind starter as outlined previously.