

John Deere 1020, 1120 and 1630 Tractors



TECHNICAL MANUAL John Deere 1020, 1120 and 1630 Tractors

TM4286 (01AUG73) English

TM4286 (01AUG73)

LITHO IN U.S.A. (NEW)
ENGLISH



J020, 1120 and 1630 Tractors

(1020 and 1120 Tractors from Serial No. 115000L)

Technical Manual
TM-4286 (Aug-73)

CONTENTS

SECTION 10 — GENERAL

- Group 5 - Specifications
- Group 10 - Pre-delivery, delivery and after-sales inspections
- Group 15 - Lubrication and periodic service
- Group 20 - Engine and tractor tune-up
- Group 25 - Tractor separation

SECTION 20 — ENGINE

- Group 5 - General information, diagnosing malfunctions
- Group 10 - Cylinder head and camshaft
- Group 15 - Cylinder block, liners, pistons and connecting rods
- Group 20 - Crankshaft, main bearings and flywheel
- Group 25 - Timing gear train
- Group 30 - Oil pump, oil pressure regulating valve, oil cooler and oil filter
- Group 35 - Engine cooling system
- Group 40 - Speed control linkage

SECTION 30 — FUEL SYSTEM

- Group 5 - Diagnosing malfunctions
- Group 10 - fuel tank, water trap, transfer pump and fuel filter
- Group 15 - ROTO DIESEL fuel injection pump
- Group 20 - Fuel injection nozzles
- Group 25 - Cold weather starting aids

SECTION 40 — ELECTRICAL SYSTEM

- Group 5 - Diagnosing malfunctions
- Group 10 - "Bilux" lighting system
- Group 15 - Sealed-beam lighting system (on earlier tractor models)
- Group 16 - Sealed-beam lighting system (on later tractor models)
- Group 20 - Starting motor
- Group 25 - Alternator and regulator

SECTION 50 — POWER TRAIN

- Group 5 - Engine clutches and clutch linkage
- Group 10 - HIGH-LOW shift unit
- Group 15 - Collar-shift transmission
- Group 20 - Differential
- Group 25 - Final drives
- Group 30 - Independent PTO
- Group 35 - Continuous-running PTO

SECTION 60 — FRONT AXLE, STEERING SYSTEM AND BRAKES

- Group 5 - Front axle
- Group 10 - Steering system
- Group 15 - Hydraulic brakes

SECTION 70 — HYDRAULIC SYSTEM

- Group 5 - General information, diagnosing malfunctions, and pressure tests
- Group 10 - Oil reservoir, filter, valves and oil cooler
- Group 15 - Hydraulic pump and transmission oil pump
- Group 20 - Rockshaft
- Group 25 - Selective control valves
- Group 30 - Remote cylinder

SECTION 80 — MISCELLANEOUS

- Group 5 - Belt pulley
- Group 10 - Seats
- Group 15 - Front and rear wheels
- Group 20 - Roll guard

All information, illustrations, and specifications contained in this technical manual are based on the latest information available at the time of publication. The right is reserved to make changes at any time without notice.

Section JO

General

CONTENTS OF THIS SECTION

GROUP 5 — SPECIFICATIONS

	Page
Serial numbers	5-2
Model numbers	5-2
Engine	5-2
Engine clutch	5-2
Electrical system	5-2
Transmission	5-3
HIGH-LOW shift unit	5-3
Differential and final drives	5-3
Differential lock	5-3
PTO	5-3
Hydraulic system	5-3
Power steering	5-3
Manual steering	5-3
Hydraulic brakes	5-3
Handbrake	5-3
Capacities	5-3
Travel speeds	5-3
Front and rear wheels	5-3
Dimensions and weights	5-3

GROUP 10 — PREDELIVERY, DELIVERY AND AFTER-SALES INSPEC- TIONS

Predelivery inspection	10-1
Delivery inspection	10-4
After-sales inspection	10-4

GROUP 15 — LUBRICATION AND PERIODIC SERVICE

Lubrication and periodic service	Page 15-1
----------------------------------	---------------------

GROUP 20 — ENGINE AND TRACTOR TUNE-UP

General information	20-1
Preliminary engine testing . .	20-1
Enginetune-up	20-2
Checking engine performance	20-3
Tractor tune-up - - - - -	20-3
Standard torques	20-5
Special tools - - - - -	20-5

GROUP 25 — TRACTOR SEPARATION

Separating between engine and tractor front end	25-1
Removing and installing engine	25-3
Removing and installing clutch housing	25-5
Removing and installing final drives	25-7
Removing and installing rockshaft	25-8
Torques for hardware	25-9
Special tools	25-10

Group J Specifications

SERIAL NUMBERS

The engine serial number is stamped into the name plate located on the lower front right-hand side of the cylinder block.

NOTE: If ordering engine parts, indicate all digits of the serial number or the name plate.

The name plate showing the tractor serial number is located on the right-hand side of the front support.

NOTE: If ordering tractor parts, excluding engine parts, indicate all digits of the serial number or the name plate.

MODEL NUMBERS

The injection pump, injection nozzles, alternator, starting motor and hydraulic pump have model numbers to facilitate identification of different makes of a given unit.

SPECIFICATIONS

ENGINE

Number of cylinders 3

Cylinder liner bore
1020 and 1120 12 mm (4.02 in.)
1630 106.5 mm (4.19 in.)

Stroke 110 mm (4.33 in.)

Displacement
1020 and 1120 2688 cm³ (164 cu.in.)
1630 2938 cm³ (179 cu.in.)

Compression ratio
1020 and 1120 16.7 : 1
1630 12 : 1

Maximum torque
1020 at 1500 rpm 15.5 mkg (112 ft.lbs.)
1120 at 1500 rpm 17.0 mkg (123 ft.lbs.)
1630 at 1400 rpm ... 19.0 mkg (138 ft.lbs.) Firing

order 1-2-3

Valve clearance (engine hot or cold)
Intake valve 0.35 mm (0.014 in.)
Exhaust valve 0.45 mm (0.018 in.)

Fast idle 2650 rpm

Slow idle 6 rpm

Working speed range .. 1500 to 2500 rpm

Flywheel horsepower at 2500 rpm

1020	1120	1630
46 HP (33.8 kw) *	51 HP (37.5 kw)*	56 HP (41.2 kw)*
48 HP (35.8 kw) **	63 HP (39.6 kw)**	69 HP (44.0 kw)* *

* With accessories (DIN 70020) comprising : water pump, fan, alternator, air cleaner and muffler

** Less accessories (SAE J 816 b)

PTO horsepower* at 2500 rpm engine speed and 650/1210 rpm PTO shaft speed

1020	1120	1630
43 PS (31.6 kw)**	48 PS (35.3 kw)* *	62 PS (38.2 kw)**
40 HP (29.9 kw) ***	45 HP (33.6 kw) ***	49 HP (36.6 kw) ***

* With engine run in (more than 100 hours of operation) and having reached operating temperature (engine and transmission) ; measured by means of a dynamometer. Permissible variation + 5%.

** DIN 70020

*** SAE J 816 b

ELECTRICAL SYSTEM

Batteries 2 x 12 volts,
55 ampere-hours

Starting motor 12 volts, 4 HP

Alternator 14 volts, 28 amps.

Battery terminal grounded negative

ENGINE CLUTCH

Dual dry disk clutch, foot operated.

Single dry disk clutch with torsion damper (isolator), foot-operated (on tractors equipped with independent PTO).

TRANSMISSION

Collar shift transmission with helical cut gears.

This transmission is available in two variations:

8 speed transmission with parking track, without independent hand brake;
8 speed transmission with out parking lock and with independent hand brake.

With this transmission 8 forward and 4 reverse speeds are available.

HYDRAULICALLY CONTROLLED REDUCTION GEAR UNIT

A hydraulically controlled reduction gear which can be shifted under load, with "wet" multiple disk clutch and "wet" multiple disk brake. Allows reduction of the individual gear speeds by 21%.

DIFFERENTIAL AND FINAL DRIVE

Planetary reduction gear and differential with spiral bevel gears.

DIFFERENTIAL LOCK

Hand or foot operated; spring-loaded out of engagement.

PTO

Independent Running PTO

The PTO shafts are independent of the transmission if the tractor is equipped with a dual stage engine clutch.

Independent cut PTO

Independent of transmission, can be engaged and disengaged under load.

The independent PTO shaft is engaged by a hydraulically operated disc clutch. Disengaging the clutch is achieved by operating the hydraulically actuated band type brake.

PTO Shaft Speeds (in rpm)

Engine Speed rpm	540 rpm shaft	1000 rpm shaft
650	169	815
2067	588	1000
2075	540	1004
2500	650	1210
2650	689	1213

HYDRAULIC SYSTEM

Closed center, constant pressure system; also includes rockshaft, power steering and selective control valves.

Pressure 150 to 160 kg/cm²
(2220 to 2280 psi)

Pump 4 or 5-piston pump driven by the engine

POWER STEERING

The steering system is a "closed center" type incorporated in the hydraulic system and supplied with oil by the tractor hydraulic pump. It is connected to the front wheels by means of a steering linkage.

MANUAL STEERING

The manual steering is a recirculating ball bearing, worm and nut type. A number of steel balls between ball nut and steering wheel shaft provide for positive engagement of steering wheel and steering linkage.

HYDRAULIC BRAKES

The disk brakes run in an oil bath and are hydraulically controlled.

HANDBRAKE

Band-type locking brake acting on differential.

PARTS	Ltr.	U.S.gals.	Imp.gals.
Fuel tank			
1020 and 1120	62.5	16.5	13.75
1630	74	19.5	16.3
Cooling system			
1020 and 1120	10.5	2.75	2.3
1630	0	2.6	2.2
Engine crankcase incl. filter	5.7	1.5	1.25
Transmission-hydraulic system			
Dry system	36.0	9.5	7.9
At service intervals	28.0	7.4	6.2
Belt pulley	1.1	0.3	0.25

TRAVEL SPEEDS

See Operator's Manual.

FRONT AND REAR WHEELS

For tire sizes, treads, inflation pressure and weights see Operator's Manual.

DIMENSIONS AND WEIGHTS

See Operator's Manual.

Gr4up JO

Predelivery, Delivery and After-Sales Inspections

PREDELIVERY SERVICE

Every new JOHN DEERE tractor leaves the factory in such a condition that it can be delivered to the customer after a minimum of service.

The reverse side of this tag is filled in by the factory after the tractor has undergone a thorough inspection prior to shipping.

To promote complete customer satisfaction, proper predelivery service including mending of possible shipping damage and giving the finishing touches to the tractor, are of prime importance to the dealer.

After completing the factory-recommended dealer checks and services listed on the predelivery tag, remove the tag from the tractor and file it with the shop order for the job. The tag will then serve as a basis for certifying that the unit has received the proper predelivery service.

A tab pointing out the factory-recommended procedure for predelivery service is attached to

TEMPORARY TRACTOR STORAGE

Service	Specifications	Reference
<p>Check radiator for coolant loss and antifreeze protection (gravity of anti-freeze and rust inhibitor mixture)</p> <p>IMPORTANT: When the tractor is delivered, red cable is not connected to alternator terminal "B+". Further, the alternator three-terminal plug is not connected. Connect cable and plug before operating tractor for the first time.</p> <p>If the tractor is to be operated for a short time without battery (using a slave battery for starting), do not, under any circumstances, interrupt the circuit by switching off the key switch before stopping engine by means of fuel pump shut-off cable. Further, it is recommended to use additional current (lights) while engine is running. Insulating tape on battery cable end leading to starting motor should not be removed. If this advice is disregarded, damage to alternator and regulator may result.</p> <p>Remove batteries. Drain electrolyte and store batteries</p> <p>Reduce shipping pressure of tires</p> <p>Cover tractor and tires for protection and cleanliness</p>	<p>Coolant level should be mid-way between radiator core and bottom edge of filler neck</p> <p>Store at room temperature</p>	<p>Operator's manual</p> <p>Section 40, group 10</p> <p>Operator's manual</p>

PREDELIVERY INSPECTION

Service	Specifications	Reference
<p>COOLING SYSTEM</p> <p>Check radiator for coolant loss</p> <p>Check gravity of antifreeze and rust inhibitor mixture</p> <p>ELECTRICAL SYSTEM</p> <p>IMPORTANT: When the tractor is delivered, red cable is not connected to alternator terminal "B+".</p> <p>Further, the alternator three-terminal plug is not connected. Connect cable and plug before operating tractor for the first time.</p> <p>If the tractor is to be operated for a short time without battery (using a slave battery for starting), do not, under any circumstances, interrupt the circuit by switching off the key switch, before stopping engine by means of fuel pump shut-off cable. Further, it is recommended to use additional current (lights) while engine is running. Insulating tape on battery cable end leading to starting motor should not be removed.</p> <p>If this advice is disregarded, damage to alternator and regulator may result.</p> <p>If the batteries are to be installed in the tractor, remove insulating tape on terminal of battery cable. This is to be done if the tractor was shipped with dry-charged batteries or without batteries.</p> <p>Connect batteries in the proper polarity. If they are improperly connected ("+" and "-"), the rectifier diodes will be immediately destroyed.</p> <p>First connect positive (+) cable and then ground (-) strap of each battery. Only then start tractor engine.</p>	<p>Coolant level should be midway between radiator core and bottom edge of filler neck</p>	<p>Operator's manual</p> <p>Operator's manual</p> <p>Section 40, group 1U</p> <p>Section 40, group 10</p> <p>Section 40, group 10</p>

PREDELIVERY INSPECTION — Continued

S ervice	S pecification	R eference
TIRES AND WH EELS Check tire inflation pressure Retighten wheel bolts		Operator's manual Section 80, group 15 and Operator's manual
LUBRICATION Check crankcase oil level Check transmission-hydraulic system oil level Lubricate all lubrication points on the tractor	Top mark on dip stick	Operator's manual Operator's manual Operator's manual
ENGINE Check dry type air cleaner Fill fuel tank and start engine 1020 and 1120 1630	Fuel tank capacity: 62.5 liters (16.5 U.S.gals., 13. 75 Imp.gals.) 74 liters (19.5 U.S.gals., 16.3 Imp.gals.)	Operator's manual Operator's manual
Check lighting system, indicator lights and instruments for proper operation Check if speed control linkage moves easily Check engine idle speeds Check injection timing		Operator's manual Section 20, group 40 Section 20, group 40 Section 30, group 15
OPERATION Check clutch pedal adjustment Check operation of HIGH-LOW shift unit Shift transmission through all gears Check differential lock operation Check PTO operation Check 3-point hitch operation Check hydraulic system operation Check brake operation	Approx. 25 mm (1 in.) clutch pedal free travel	Section 50, group 5 Section 50, group 10 Operator's manual Operator's manual Operator's manual Operator's manual Section 70, group 5 Section 60, group 15

PREDELIVERY INSPECTION — Continued

S e r v i c e	S p e c i f i c a t i o n s	R e f e r e n c e
Check steering operation		Section 60, group 10
Check seat adjustment		Operator's manual
Check operation of remote cylinder (if equipped)		Section 70, group 5
GENERAL		
Tighten accessible nuts and attaching screws		Section 10, group 20
Attach roll guard	Tighten nuts and bolts to 13 mkp (94 ft.lbs.)	Section 80, group 20
Clean tractor and touch up paint		

DELIVERY SERVICE

A thorough discussion of the operation and service of the tractor at the time of its delivery helps to assure complete customer satisfaction.

Proper delivery should be an important phase of the dealer's program.

It is a well-known fact that many complaints have arisen simply because the owner was not shown how to operate and service his new tractor properly. Therefore, enough time should be devoted, at the customer's convenience, to introducing him to his new tractor and explaining to him how to operate and service it.

Using the tractor operator's manual as a guide, be sure that the owner understands the following points properly.

1. Adjusting the seat
2. Operation of control levers and instruments
3. Starting and shutting off the engine
4. The importance of the tractor break-in period
5. Use of counterweights and proper tire inflation pressure as well as filling of tires with water and calcium chloride, if required
6. All functions of the hydraulic system
7. Operating the PTO and belt pulley (If equipped)
8. The importance of the safety rules
9. The importance of lubrication and periodic service

AFTER-SALES INSPECTION

In the interest of the purchaser and the dealer an after-sales inspection should be carried out by the dealer after the first 100 hours of using a new John Deere tractor.

The purpose of this inspection is to make sure that the customer is receiving satisfactory performance from his tractor. At the same time, the inspection should reveal whether or not the tractor is being operated, lubricated and serviced properly.

Through this inspection a needless volume of service work can be eliminated by preventing

minor difficulties from developing into serious problems later on. It also will promote stronger dealer-customer relations and give the customer an opportunity to ask questions that may have arisen during the first few days of use.

Thereby the dealer has the further opportunity of promoting the possible sale of other new equipment.

The following inspection program is recommended:

AFTER-SALES INSPECT ION

S e r v i c e	S P e c i f i c a t i o n s	R e f e r e n c e
<p>C*OOL I NC. SYS'£EM</p> <p>Check coolant level</p> <p>filean exterior of radiator</p> <p>Check hose connections</p> <p>FUEL SYSTEM</p> <p>Check sediment howls and elements of fuel filter for water or sediment and clean transfer pump screen</p> <p>Check line connections</p> <p>ELfiif"£RICAL SY S) EM</p> <p>Check gravity of bat Very electrolyte</p> <p>Check electrolyte level of batteries</p> <p>Check tension of fan belt</p> <p>Start engine and check operation ot' lights, indicator lamps and instruments</p> <p>LUBR ICATIO N</p> <p>Check crankcase oil level</p> <p>Check transmission oil level</p> <p>Check oil level of manual steering gear housing</p> <p>Check oil level of belt pulley housing</p> <p>Lubricate clutch throw-out bearing</p> <p>Lubricate 3-point hitch</p>	<p>Coolant level should be midway between radiator core and bottom edge of Miller neck</p> <p>C ravity should be 1.250 at an electroly te tempera- ture of 27* C (80° F)</p> <p>To bottom of l'illt•r neck in each cell</p> <p>19 mm (3/4 in.) det'lection with a 9 kp (20 lbs.) force</p> <p>Top mark on dip stick</p> <p>Add oil up to filler hole</p> <p>Add oil up to filler h ole</p>	<p>Operator's manual</p> <p>Operator's manual</p> <p>OJaerator's manual</p> <p>Operator's manual and section 20, group 35</p> <p>Operator's manual</p> <p>Operator's manual</p> <p>Operator's manual</p> <p>Operator's manual</p> <p>Operator's manual</p> <p>Operator's manual</p> <p>Operator's manual</p>

AFTER-SALES INSPECTION

Service	Specifications	Reference
ENGINE		
Check dry-type air cleaner		Operator's manual
Check valve clearance	Intake valve: 0.35 mm (0.014 in.) Exhaust valve: 0.45 mm (0.018 in.)	Section 20, group 10
Check engine speed under load as well as fast and slow idle speed		Section 20, group 40
Check engine performance		Section 10, group 20
GENERAL		
Check clutch pedal adjustment	Approx. 25 mm (1 in.) free travel	Section 50, group 5
Check operation of HIGH-LOW shift unit	- - - - -	Section 50, group 10
Shift transmission through all gears		Operator's manual
Check operation of PTO		Operator's manual
Check differential lock		Operator's manual
Check operation of hydraulic system		Section 70, group 5
Check steering system		Section 60, group 10
Check brakes		Section 60, group 15
Tighten accessible nuts and cap screws		Section 10, group 20
Tighten roll guard attaching screws and nuts	13 mkp (94 ft.lbs.)	Section 80, group 20
Tighten accessible hydraulic lines		
Visual inspection of tractor	Damaged paint, loose connections, proper posi- tioning of hoses and lines, leaks, operation of all me- chanical parts	

Group J5

Lubrication and Periodic Service

For brands of oil and lubricants to be used as well as for lubricating and servicing the model 1020, 1120 and 1630 tractors, see operator's manuals.



Group 20

Engine and Tractor Tune-Up

GENERAL INFORMATION

Before tuning up the engine, determine whether a tune-up will restore operating efficiency. If there is doubt, the following preliminary tests will help to determine if the engine can be tuned up.


PRELIMINARY ENGINE TESTING

Service	Specifications	Reference
Checking air intake system by means of vacuum gauge	35 to 36 35 to 36 in. (14 to 26 in.) water head; engine running at fast idle speed	 "Fundamentals of Service, Engine" manual under "Diagnosis and Testing"
Check radiator for air bubbles or oil film		
Measure blow-by at crankcase vent tube *		
1020 and 1120	1.4 j3q3/h (50 cu.ft. Ohr.)	
1630	1.7 m /h (60 cu.ft. Ohr.)	
Check compression which should be at least (using special tool No. 19. 58-90. 578)	21 kp /cm ² (300 psi)	 "Fundamentals of Service, Engine" manual under "Diagnosis and Testing"
Measure engine horsepower at powershaft (using a dynamometer)	Record measured performance and compare with performance measured after carrying out "Engine Tune-up"	


* Measure with a standard gas gauge, placing hose over end of crankcase vent tube. The engine must be tested at 2500 rpm and full load, normal running temperature and should be run in (at least 100 hours). Measure over a period of 5 minutes and multiply measured value by 12 ((or hourly rate). Compare with values quoted above.

There is no undue wear on piston rings and cylinder liners if the measured value is lower than that quoted above. Should a further test be desired, carry out a compression test. If the "blow-by" reading is more than that quoted above, the decline in performance is due to excessive wear and the engine should be overhauled.

ENGINE TUNE-UP

Service	Specifications	Reference
AIR INTAKE SYSTEM		
Service air cleaner and check system for leaks		 Operator's manual and "Fundamentals of Service, Engine" manual
Check crankcase vent tube for foreign particles (restriction)		
Tighten cylinder head cap screws	15 m kp (110 ft.lbs.)	Section 20, group 10
Check and adjust valve clearance	Intake valve: 0.35 mm (0.014 in.) Exhaust valve: 0.45 mm (0.018 in.)	Section 20, group 10
BATTERIES		
Thoroughly clean wires, connections and batteries		
Tighten cable clamp screws		
Liberally coat battery terminals and cable connectors with petroleum jelly		
Check electrolyte level of battery		Operator's manual
Check specific gravity of electrolyte		Operator's manual
ALTERNATOR		
Check fan belt tension	19 mm (3/4 in.) deflection with 9 kp (20 lbs.) force	Section 20, group 35
FUEL SYSTEM		
Check fuel tank and lines for leaks or restriction		
Clean screen of fuel transfer pump		Operator's manual
Check fuel filter element and replace, if necessary		Section 30, group 10
Check injection timing and adjust, if necessary		Section 30, group 15
Bleed fuel system		Section 30, group 15
Check engine speeds and adjust speed control linkage, if necessary		Section 20, group 40

ENGINE TUNE-UP - Continued

Service	Specifications	Reference
ENGINE LUBRICATION SYSTEM		
Check engine oil pressure	3.5 to 4 kpc ^{m2} (51 to 60 ps) at 550 rpm	Section 20, group 00
COOLING SYSTEM		
Clean and flush cooling system	 "Fundamentals of Service, Engine" manual
Check radiator hoses for damage include leaks		
Clear radiator core of restrictions		

CHECKING ENGINE PERFORMANCE



After the engine has been tuned up as explained previously, determine power shaft horsepower by means of a dynamometer. See "Fundamentals of Service, Engine" manual.

Compare measured performance in IIP with that measured before carrying out "Engine Tune-Up"

TRACTOR TUNE-UP

After carrying out engine tune-up, make the following adjustments on the tractor:

Service	Specifications	Reference
ENGINE CLUTCH		
Adjust clutch pedal free travel	Approx. 25 mm (1 in.)	Section 50, group 5
FRONT WHEELS		
Clean and lubricate front wheel bearings		Section 80, group 15
Adjust front wheel bearings		Section 80, group 15
Check toe-in	3 to 6.5 mm (0.123 to 0.25 in.)	Section 60, group 5
Check torque of front wheel bolts	12 mkg (87 ft.lbs.)	
HYDRAULIC BRAKES		
Bleed brake system		Section 60, group 15

TRACTOR TUNE-UP - Continued

Service	Specifications	Reference
HYDRAULIC SYSTEM		
Check stand-by pressure of hydraulic pump	156 to 160 160 to 165 kpc/m ² (2220 to 2280 psi)	Section 70, group 5
Check rockshaft lift cycle time at 2500 rpm engine speed	1. 8 sec. to 2.3 sec.	Section 70, group 5
Check time required for extending or retracting remote cylinder at 2100 rpm engine speed	2 sec.	Section 70, group 5
Check operating pressure of HIGH-LOW shift unit	8.8 to 9.5 kpc/m ² (125 to 135 psi)	Section 60, group 10
Check operating pressure of PTO clutch and PTO brake	8.8 to 9.5 kpc/m ² (125 to 135 psi)	Section 50, group 30
TIRES		
Check tire inflation pressure		Operator's manual
TORQUES		
Check all accessible cap screws and nuts of tractor for proper torque		Torque chart

**John Deere 1020 1520
1530 2020 2030 Service
Manual**

**Then Instant Download
the Complete Manual
Thank you very much!**