

Thermo Scientific APEX Metal Detector User's Guide

REC 4248 Rev J
Part number 085381—English



Thermo
S C I E N T I F I C

For future reference, write your APEX serial number below.

APEX serial # = _____

Table of Contents

Getting Started	11
Setting Global and Application-Specific Parameters.....	11
Setting Product Parameters.....	11
Managing Product-Rejection Parameters	12
Choosing Your Application Type	12
Setting Up Conveyor Applications	13
Understanding Your Detector	14
Understanding the Detector's Control Panel.....	14
Using the Detector's Buttons.....	15
Understanding the Screen Shots Used in this Manual	16
Understanding the Detector's Main Menu	17
Choosing a Language.....	17
Clearing the Speed-Filter Warning Screen	20
Displaying Help Text	20
Choosing Your Preferred Units of Measure	22
Naming the Product.....	24
Setting Up the Conveyor and Photo-Eye	27
Keying In the Product Speed.....	27
Keying In the Photo-Eye-to-Detector Distance	28
Checking the Polarity of the Photo-Eye Input	30
Selecting the Correct Photo Registration for Rejects.....	32
Setting Product Parameters	35
Keying In the Pack Length	35
Keying In the No-Pack Distance.....	37
Disabling the Detection No-Pack Function.....	38
Keying In the Pack Gap	40
Setting Reject Parameters	43
Keying In the Distance to the Reject Device	44
Keying In the Signal Duration for the Reject Device.....	46
Setting Contaminant-Detection Parameters	47
Establishing Noise Thresholds with No Product Present.....	47
Calibrating the Speed Filter Using a Ferrous Test Stick.....	50
Establishing Basic Product Parameters.....	52
Changing the Current Product	60
Set-Up Check List for Conveyor Applications	61
Parameters You Have Already Set Up	61
Additional Parameters You May Want to Set Up.....	62
Setting Up Gravity-Feed Applications	63
Setting Reject Parameters	65
Understanding Reject-Delay and Reject-Duration Timing	65
Setting the Reject-Delay Time.....	66
Setting the Reject-Duration Time.....	67
Setting Contaminant-Detection Parameters	69
Establishing a Baseline with No Product Present.....	69
Calibrating the Speed Filter Using a Ferrous Test Ball.....	72
Establishing Basic Product Parameters.....	73

Set-Up Check List for Gravity-Feed Applications	76
Parameters You Have Already Set Up	76
Additional Parameters You May Want to Set Up	77
Setting Up Pipeline Applications	79
Setting Reject Parameters	81
Understanding Reject-Delay and Reject-Duration Timing	81
Setting the Reject-Delay Time	82
Setting the Reject-Duration Time	83
Setting Contaminant-Detection Parameters	85
Establishing a Baseline with No Product Present	85
Choosing the Appropriate Wide-Band Speed Filter	88
Establishing Basic Product Parameters	90
Set-Up Check List for Pipeline Applications	93
Parameters You Have Already Set Up	93
Additional Parameters You May Want to Set Up	94
Setting Up Pharmaceutical (Rx) Applications	95
Setting Reject Parameters	97
Understanding Reject-Delay and Reject-Duration Timing	97
Setting the Reject-Delay Time	98
Setting the Reject-Duration Time	99
Setting Contaminant-Detection Parameters	101
Establishing a Baseline with No Product Present	101
Choosing the Correct Speed-Filter Settings for the Rx	104
Establishing Basic Product Parameters	105
Set-Up Check List for Pharmaceutical Applications	108
Parameters You Have Already Set Up	108
Additional Parameters You May Want to Set Up	109
APEX Menu Structure	111
Main Menu—Page 1	111
Product Name	111
Product Speed	111
Reject-Totals Menu	112
Detect Level	113
Phase-Angle Menu	113
Peak Signal	114
Frequency and Gain Menu	114
System and Tools Menu	115
Security Menu	115
Main Sub-Menu—Page 1	115
Starting a Complete Product Calibration	116
Editing the Product Name	116
Main Sub-Menu—Page 2	116
Setting the Pack Length	117
Setting the Pack Gap	117
Setting the No-Pack Distance	117
Rejects Menu—Page 1	118
Resetting the Counts for Reject 1	118
Setting the Distance to the Reject-1 Device	119
Changing the Units of Measure	119

Setting the Signal Duration for the Reject-1 Device	119
Displaying the Number of Quality Test Rejects	120
Displaying the Number of AuditCheck Rejects	120
Rejects Menu—Page 2	121
Setting the Type of Photo Registration Used	121
Setting the Latching-Reject Function (Reject 1)	122
Inverting the Reject Function (Reject 1).....	123
Calibrating the Speed-Encoder Function.....	124
Understanding the Photo-Queue Pack Count.....	127
Rejects Menu—Page 3	128
Suppressing Rejection Using an External Trigger (Reject 1)	129
Activating Reject Suppression (Reject 1).....	130
Understanding Reject Suppression (Reject 1)	130
Activating Reject Suppression (Reject 1).....	131
Setting Suppression Time (Reject 1)	132
Setting Amplitude Suppression (Reject 1)	134
Rejects Menu—Page 4	136
Calibrating Reject-Confirm Times.....	137
Manually Setting the Timing for a Reject-1 Confirm	138
Manually Setting the Timing for a Reject-1 Complete	139
Rejects Menu—Page 5	141
Keying In the Distance to the Reject-2 Device	142
Keying In the Signal Duration for the Reject-2 Device.....	142
Assigning Tasks to the Reject-2 Device	143
Setting the Latching-Reject Function for Reject 2	144
Inverting the Reject Function for Reject 2	144
Rejects Menu—Page 6	145
Entering a Reject-Confirm Time for the Reject-2 Device	145
Calibrating the Reject-2 Confirm Time	147
Phase Angle—Page 1	150
Calibrating the Phase-Angle Setting	151
Locking the Phase-Angle Setting.....	152
Enabling the Detector's Phase-Tracking Function.....	153
Setting Acceptable Limits for Phase Tracking	155
Setting Limits for a Phase-Tracking Fault Notification.....	156
Phase Angle—Page 2	157
Selecting the Wet-Product Noise Filter	157
Selecting the Phased-Noise Reduction Filter	158
Selecting the Quadrature Noise-Reduction Filter.....	159
Frequency and Gain—Page 1	160
Setting High or Low Frequency.....	161
Setting High or Low Gain.....	162
Inhibiting Detection	162
Frequency and Gain—Page 2	163
Calibrating the Detect Level	163
Changing the Detect Level	164
Setting Multi-Zone Detection.....	165
Locking the Detect Level.....	166
Calibrating the <i>X</i> and <i>R</i> Noise Thresholds	166
Changing the Noise Threshold for <i>X</i>	167
Changing the Noise Threshold for <i>R</i>	167

System and Tools—Page 1	168
Quality Test	168
AuditCheck	168
Error Messages (WAFs)	169
Manual Print	169
Bar-Graph/Help-Text Set-Up for the Display Panel	169
IntelliTrack (IXR)	169
System and Tools—Page 2	170
Viewing Your Speed-Filter Settings	170
Inputs and Outputs Menu	172
Copying and Pasting Product Parameters	173
Setting the Time and Date	176
Setting Metric or Imperial Units	178
System and Tools—Page 3	179
Setting the Photo-Eye-to-Detector Distance	179
Setting Reject Duration (Time or Distance) for Your Reject Devices	180
Setting the “Reject Packs During Learn” Function	182
Resetting the Counts When Products Change	183
Resetting Product Parameters to the Default Settings	184
Resetting the NVRAM Parameters to the Default Settings	186
Oscilloscope	187
System and Tools—Page 4	192
Selecting the Language for the Display Panel’s Help Text	192
System and Tools—Page 5	193
Displaying Your Software Version	193
Displaying Your APEX Model Type	194
Displaying Your System Set-Up Code	194
Displaying Your Product Set-Up Code	195
Quality Test	196
Overview of How the Quality Test Function Works	197
Testing the Detector Using QA Test Samples	198
Setting the Time Interval Between QA Tests	200
Setting the Time Window for Doing a QA Test	201
Setting the Reject Device Used for the QA Test	202
Doing a Manual QA Test	203
Setting Limits for Peak Signal and Phase Angle	204
AuditCheck	206
Performing an AuditCheck Test	207
Displaying the Average Phase Angle	208
Displaying the Average Peak Signal	208
Setting the Lock-Values Function	208
Setting Manual-Start, Timing-Limits, and Reject-Device Parameters	209
Setting Limits for Peak Signal and Phase Angle	210
Setting the AuditCheck Overhang Distance	210
Setting the AuditCheck Pulse Length	211
Setting the AuditCheck Signal Time-Out	212
Error Messages (WAFs)	214
Defining Warnings, Alarms, and Faults (WAFs)	214
WAFs Are Not Mutually Exclusive	215
Setting a WAF for a Particular Function	215
Learning About Other WAFs	217

Inputs and Outputs	220
Inputs—Page 1	222
Viewing the Speed-Encoder Input	223
Assigning the Input for the In-Feed Photo Eye	223
Assigning the Input for the Reject-Confirm-1 Photo Eye (Reject 1)	224
Assigning the Input for the Bin-Full Photo Eye (Reject 1)	224
Inputs—Page 2	225
Using an External Device to Switch Products	226
Setting the Product-Select Inputs	227
Locking the Detector's Key Pad.....	228
Starting the Reject-Suppression Cycle	228
Inputs—Page 3	229
Assigning the Input for Verification of a Reject Using Photo-Eye 2	230
Assigning the Reject-2 Confirm Input	230
Clearing All WAF Inputs.....	231
Outputs	232
Changing the Assignment of an Output Device.....	235
Changing the Polarity of an Output Device	236
Printer Set-Up—Page 1	238
Attaching a Printer to the Detector.....	238
Navigating to the Printer Set-Up Menu.....	239
Activating the Printer	241
Manual Printing	242
Naming Your Detector	243
Naming Your Product Batches.....	244
Printer Set-Up—Page 2	245
Activating an End-of-Day Print-Out	245
Activating a Reject Print-Out	246
Activating a Print-Out on Power-Up	247
Security Level.....	249
Entering a Supervisor Password.....	250
Setting Engineer and Operator Passwords	253
Retrieving a Forgotten Password.....	253
Undoing the Need for Passwords.....	254
Logging In.....	255
Logging Out.....	256
Maintenance and Troubleshooting.....	259
Service, Repair, and Replacement Parts	265
Ordering Parts	269
Installing Your APEX Detector.....	271
Unpacking Your APEX.....	271
List of Included Components	272
APEX Specifications	272
Theory of Operation	276
Definition of Various Product Effects.....	276
Understanding Some Basic Detector Vocabulary.....	279
Safety Precautions	280

Electrical Set-Up	283
Removing the Control Panel.....	286
Installing Cable and Conduit to Your APEX	288
Input-Wiring Board—Pin Assignments.....	289
Output-Wiring Board—Relay Settings and Fuses.....	290
Mechanical Set-Up Instructions for Specific Applications	291
Mechanical Set-Up for Conveyor Applications	292
Mechanical Set-Up for Gravity-Feed and Rx Applications	299
Mechanical Set-Up for Pipeline Applications.....	307
Safety and Warranty Information	311
Appendix A—Modbus Communications Card	319
Overview	321
What the Modbus Communications Card Does	321
Engineering Details.....	322
Expert Knowledge Is Required to Modify Settings	323
Overview of the Installation Process	323
Modifying the Modbus Settings	323
Configuring Network Parameters with the APEX Software	325
Configuring a TCP/IP Network	325
Accessing the TCP/IP Communications Menu	326
Changing the DHCP Default Setting During Installation	329
Changing DHCP to “Off”	329
Manually Changing Communication Parameters	330
Changing the IP Address	330
Changing the Subnet-Mask Address	331
Changing the Gateway Address	332
MAC Addresses	332
Saving Your TCP/IP Settings	333
Changing DHCP to “On”.....	334
Configuring an RTU Network	335
Accessing the RTU Communications Menu.....	335
Changing the Slave Address.....	336
Changing the Baud Rate.....	337
Changing the Parity	338
Saving Your RTU Settings	339
Configuring the Modbus Hardware	341
Configuring the TCP/IP Card	342
Card Schematic.....	342
Installing the TCP/IP Card.....	342
Setting the Configuration Switches.....	343
Pin Assignments for the Ethernet (RJ45) Connector.....	343
Understanding the Status LEDs	344
Configuring the RTU RS-485 Card.....	345
Card Schematic.....	345
Installing the Card.....	345
Setting the Configuration Switches.....	346
Pin Assignments for a DB-9 Connector.....	347

Pin Assignments for a Screw Connector	347
Understanding the Status LEDs	348
Configuring the RTU RS-232 Card.....	349
Installing the Card	349
Setting the Configuration Switches.....	349
Pin Assignments for a DB-9 Connector.....	350
Pin Assignments for a Screw Connector	350
Understanding the Status LEDs	350
Understanding Registers	351
Data Handling	351
Supported Operation Codes	351
Read Data	352
Write Data.....	352
Register Details for Commonly Used APEX Functions.....	353
Changing Products.....	353
Retrieving Statistical Information.....	354
Backing Up Critical APEX Settings	355
Detailed List of Modbus Registers	357
Appendix B—IntelliTrack™ XR	367
Overview	369
System Requirements	369
Product Requirements	369
Discussion of Product Requirements	370
Setting Up Related Functions	371
Keying In the Pack Length	371
Keying In the “Detection No-Pack” Distance	372
Keying In the In-Feed Photo-Eye Distance.....	374
Enabling Photo-Eye Registration	376
Enabling the IXR Function	378
Calibrating the IXR Function	380
Learn the <i>X</i> and <i>R</i> Noise Thresholds	380
Using the Auto-Calibration Function	382
Using the IXR Calibration Function	385
Using the IXR Detect-Level Calibration Function.....	385
IXR Tracking.....	387
Understanding the IXR Display.....	388
Troubleshooting	391
Glossary	393
Contacting Thermo Fisher Scientific	399
Supplemental Information	403

Getting Started

Congratulations on the purchase of your new Thermo Scientific APEX metal detector! The first thing to do is unpack your detector and complete the electrical installation and application-specific mechanical set-up. For instructions on how to do this, go to page 283.

Now that your APEX™ detector is properly installed, you are ready—and, we hope, eager—to learn how to use it. Here, in outline, is what you will learn in this section.

Setting Global and Application-Specific Parameters

Once the detector is installed and ready to check your products for the presence of metallic contaminants, you will use the detector's control panel to set up various global and application-specific parameters. In this manual, the term "product" refers to anything you are testing for the presence of metallic contaminants. Whenever you encounter a technical term you do not understand in this manual, please go to the Glossary on page 393 for a brief explanation.

Global parameters are ones that you pretty much "set and forget," because they define how you want the detector's display screen to appear, what language and units (feet or meters) you prefer to use, and so on. In other words, global parameters are ones that you will not change very often.

In contrast, application-specific parameters are ones you use to get your particular type of application (conveyor, gravity-feed, pipeline, or pharmaceutical) set up and running properly. Application-specific parameters sometimes need to be fine tuned to optimize the detector's performance for your particular operating environment.

Setting Product Parameters

You use the detector's control panel to set up various product parameters. The most critical product parameters you need to set are the following.

- *Values for the X and R Noise Thresholds*
The *X* and *R* thresholds are background noise thresholds that are learned by the detector with no product present. In conveyor applications, the thresholds are learned with the conveyor running, but with no product present on the conveyor or in the search head. Similarly, in gravity-feed, pipeline, and pharmaceutical applications, the thresholds are learned with no product present in the duct, pipe or chute. When the *X* and *R* noise thresholds are exceeded, they indicate the presence of product—as shown by the activation of the green product-LED on the detector's control panel.
- *The Detect-Level Value*
Any signal from the detector's search head that exceeds the detect level, will be tagged as a contaminant. As a general rule, the detect level should exceed the level of the background noise by a factor of 2–3 times.

Managing Product-Rejection Parameters

Once the detector is up and running and detecting metal contaminants, the next task is to set up the all-important product-rejection parameters, which fine tune the accept-or-reject process for your products. Which parameters you use, however, depend on the type of application (conveyor, gravity-feed, pipeline, or pharmaceutical) you are using.

- *Conveyor Applications*
In this application, a conveyor belt is used to pass the product through the detector's search head.
- *Gravity-Feed (also known as "Drop-Through") Applications*
The search head surrounds a vertical duct where the product drops through the duct under the influence of gravity. The detector's search head is installed around the outside of the duct.
- *Pipeline Applications*
The detector's search head is installed surrounding a pipe, where product is flowing under pressure.
- *Pharmaceutical Applications*
The search head surrounds a chute where the product drops through the chute under the influence of gravity. The detector's search head is installed around the outside of the chute.

Choosing Your Application Type

Clearly, the product parameters and product-rejection parameters used by the APEX vary depending on the type of application you are using. As a result, you should now go to the *specific* section in this manual that explains the detailed set-up procedures for your particular type of application. Find the relevant section as follows.

- Conveyor applications—Go to the page that follows this one (page 13).
- Gravity-feed applications—Go to page 63.
- Pipeline applications—Go to page 79.
- Pharmaceutical (Rx) applications—Go to page 95.

Setting Up Conveyor Applications

The purpose of this section is to present you with a brief tutorial, allowing you to get your conveyor application up and running as quickly as possible. Here is an outline of what you will be learning. If you are already familiar with some of the information covered, you can always skip ahead to the next section.

Understanding Your Detector

In this section you will learn how to...

- Use the detector's display panel.
- Navigate the detector's menus and sub-menus.
- Set up global parameters for the detector.

Setting Up the Conveyor and Photo Eye

In this section you will learn how to...

- Set up the conveyor parameters.
- Set up the photo-eye parameters.

Setting Product Parameters

In this section you will learn how to...

- Key in pack length.
- Key in no-pack distance.
- Key in pack gap.

Setting Product-Reject Parameters

In this section you will learn how to...

- Key in the distance to the product reject device.
- Key in the signal duration for the product reject device.

Calibrating Your Detector

In this section you will learn how to...

- Establish a noise threshold with no product present in the search head.
- Calibrate the speed filter using a ferrous (or other) test stick.
- Establish basic product parameters (detect level and phase-angle).
- Have the detector do an AuditCheck learn, if applicable.

Understanding Technical Terms

If you encounter a technical term you do not understand in these sections, please refer to the Glossary on page 393. For example, the word "product" means anything the detector is testing for the presence of metal contaminants, and is a word you will encounter often in this manual.

Let's get started!

Understanding Your Detector


This section helps you understand the detector's control panel and Main Menu, and explains how to set up three global ("set it and forget it") parameters—language, help text, and units of measure.

Understanding the Detector's Control Panel

The main components of the detector's control panel are as follows.

- The display panel
- The three (red, green, and yellow) indicator lights
- The green Go button
- The red Back button
- The four blue triangular-shaped navigation buttons

The detector's control panel looks like this.



The Display Panel

The display panel allows you to access all the detector's functions.

The Indicator Lights

These give you a quick overview of how the detector is functioning.

- Red—Flashing once indicates an excess product effect; steady indicates a fault.
- Green—Indicates a product is present in the detector's search head.
- Yellow—Indicates a contaminant has been detected in the product.

The Navigation Buttons

These allow you to navigate around the detector's menus and sub-menus. When you press a navigation button, the display highlights an adjacent function (using a black background). You access the highlighted function by pressing the Go button. In addition, the four navigation buttons are used increase or decrease numbers and select characters and settings in various menus and input screens.

The Go Button

Press the Go button to select or start one of the detector's functions.

The Back Button

Press the Back button to stop one of the detector's functions or to return to the previous menu screen. Pressing the Back button repeatedly will always take you back to the detector's Main Menu.

Using the Detector's Buttons


The detector's buttons—unlike those on a cell phone, for example—are *not* activated by direct mechanical force. Instead, a sensor below the image of the button on the control panel detects the movement of your finger to and away from the button's location. As a result, the best way to activate the button is to lightly tap the button and—the key point here—immediately move your finger *away* from the button. For most people, this to-and-away motion is not intuitive but, with a little practice, you will find this is the best way to activate the detector's buttons.

Understanding the Screen Shots Used in this Manual

In this manual, a *large* screen shot means that is the only place (or section) in the manual where the function is explained. In contrast, a *small* screen shot means the function is explained elsewhere in the manual. Examples of both types of screen are shown below.


Large Screen Shot

This is an example of a large screen shot.



Small Screen Shot

This is an example of a small screen shot.




Tips on Using the Detector's Sub Menus

Here are some tips to help you navigate the detector's menus and access all of its functions.

- Use the navigation buttons on the control panel to navigate to and highlight the function you want to use.
- Press the Go button to access the function. If pressing the Go button does not work, try the down-navigation key, because some functions, menus, and options are accessed using the navigation buttons not the Go button.
- Use the Back button to back out of any function or menu you are not interested in. Note, too, that pressing the Back button allows you to exit a function without making any changes. Pressing the Back button repeatedly will always take you back to the Main Menu.

How to Use the Parameter Input Screens

Parameter input screens are used to set (or verify) a value for a particular function you are interested in. The right-hand number in all input screens is marked above and below with a small triangle—indicating that *all* the numbers in the screen can be changed using the navigation buttons.



- Use the up-navigation button to increase the number marked by triangles.
- Use the down-navigation button to decrease the number marked by triangles.
- Use the left-navigation button to move to the number to the left.
- Use the right-navigation button to move to the number to the right.

Understanding the Detector's Main Menu

In this section you are going to learn to navigate around some of the detector's menus and input screens. More specifically, you are going to set up a number of global parameters for the detector. Global parameters are ones you set at the start of a project, because this type of parameter—once set—does not often need to be changed. You are going to do the following.

- Choose the language shown in the display panel.
- Remove the bar-graph display (at the top of the Main Menu) and replace it with the more informative Help Text display.
- Set the appropriate units of measure (meters or feet), so the detector's menus display the units you prefer to work with.

Choosing a Language


The default language for the display panel is English, but it can also display help text in the following nine languages.

- French
- German
- Italian
- Spanish
- Dutch
- Chinese
- Czech
- Russian
- Polish


If you want to use a language other than English, follow the instructions below.

(continued...)


1) Turn on the detector and the Main Menu screen appears.



2) Press the navigation buttons to select the system and tools menu, as shown below.



3) Press the Go button, and page 1 of the system and tools menu appears.



Notice the notation "1/5" in the screen above. This tells you that you are currently on page 1 in the system and tools menu, which is five pages long.

- 4) Press the down-navigation button several times to scroll through pages 1–5 of the system and tools menu (to see what they look like.) Select page 4, which is shown below.



- 5) Press the right-navigation button to select English.



- 6) Press the Go button repeatedly to scroll through the available languages, and select the language you want displayed.
- 7) To exit (and have the detector use the language you chose in Step 6), press the Back button repeatedly until you return to the Main Menu.

Clearing the Speed-Filter Warning Screen

By now you will have noticed that a warning screen has appeared in the detector's display, as shown below.




This warning screen is telling you that the speed filter has not yet been calibrated—something you will get to at a later stage of the set-up process. For the time being, whenever this warning screen appears, just press the Back or Go buttons to clear it.


Displaying Help Text

In the Main Menu, the default setting is to display a bar graph at the top of the screen. You are now going to change this setting, so that Help Text is displayed. The Help Text provides a brief description of the screen you are looking at—which makes navigating and using the detector's functions much easier.


- 1) Make sure the detector's Main Menu is displayed.




- 2) Use the navigation buttons to select the system and tools menu.




- 3) Press the Go button and page 1 of the system and tools menu appears.




4) Use the navigation buttons to select the bar-graph/Help-Text menu.



5) Press the Go button, and the following screen appears.



6) Press the Go button *once* (to toggle the screen from the bar-graph setting to the Help Text setting). Notice that descriptive Help Text is now displayed at the top of the screen (and will continue to be displayed until you change this setting).




7) Press the Back button repeatedly to return to the Main Menu.


Choosing Your Preferred Units of Measure

The display panel presents information—such as conveyor speed—in either metric (meters) or imperial units (feet and inches). Follow these instructions to set the units you prefer to use and have the detector display.

- 1) Make sure the detector's Main Menu is displayed.




- 2) Use the navigation buttons to select the system and tools menu.



- 3) Press the Go button and page 1 of the system and tools menu appears.




- 4) Press the down-navigation key and page 2 of the system and tools menu appears.



(continued...)

5) Use the navigation buttons to select the metric/imperial function.



6) Press the Go button to toggle between imperial and metric units. Highlight the units of measure (meters, or feet and inches) you prefer to use.


7) To exit (and select the units you chose in Step 6), press the Back button repeatedly until you get back to the Main Menu.

Naming the Product


In the examples that follow, imagine you are a lead engineer in a dairy and are setting up the APEX detector to make sure no metallic contaminants have dropped into the dairy's products during the manufacturing process. Your first assignment is to test packets of salted butter for the presence of metallic contaminants. The packets of salted butter are rectangular in shape and are placed at regular intervals (with a space between each packet) on a conveyor that takes them through the detector's search-head for analysis. On the other side of the detector, contaminated packets are pushed off the conveyor into a rejects bin by a mechanical arm—your reject device. A photo-electric cell ("photo eye") attached to the detector monitor the flow of packets on the conveyor. This is photo-eye number 1, which monitors the packets just before they enter the detector's search head. (This is a fairly typical set-up for a conveyor application.)

Follow the instructions below to give a name to the product (in our example, salted butter) that you are testing.


- 1) Make sure the detector's Main Menu is displayed.



- 2) Press the Go button and page 1 of the product menu appears.



- 3) Navigate to the "Edit Product Name" function and make sure it is highlighted.




4) Press the Go button and the keyboard screen appears.



5) Please note there are four control keys in the keyboard screen, as follows.


- The move-cursor-left control key.
- The move-cursor-right control key.
- The delete key.
- The exit and save key.

All other keys are simple character-entry keys—and function exactly as they do on a computer keyboard.



The keyboard screen above shows the heading "Exit & Save" because this is the key that is currently active in the screen (as shown by its black highlight). If you change the active key (by using the navigation buttons in the detector's control panel), the heading in the keyboard screen will change.

- 6) Navigate to the keyboard's Delete key (using the four navigation buttons on the detector's control panel) and make sure the Delete key is highlighted. Press the Go button (on the detector's control panel) *four* times to delete the "P001" heading. Use the navigation buttons (on the detector's control panel) to select the appropriate letters, and type in the heading "SALTED BUTTER" by navigating to the appropriate letter in the keyboard and pressing the Go button (on the detector's control panel). Use the keyboard's Space key to create the gap between the two words. When finished, your keyboard screen should look like this.



- 7) Highlight the exit-and-save key (using the navigation buttons on the detector's control panel), and press the Go button (on the detector's control panel) to save the name of the product you are testing—in our example, "SALTED BUTTER."


Setting Up the Conveyor and Photo-Eye

This section assumes that the photo-eye is already connected to the detector (using Input 2 on the wiring board) and the conveyor is already running. (For more information about hard-wiring your detector, see page 289.) In addition, the example below assumes you are testing packets of salted butter, as described above in the “Naming the Product” section.


Keying In the Product Speed

This section assumes the conveyor belt is running and that you have already calculated its speed in either feet per minute or meters per minute using a mechanical tachometer. Before proceeding, make sure you have already set your preferred units of measure (metric or imperial) and that these are currently being displayed in the detector’s display panel. For more information about your setting your preferred units of measure, see page 22.

- 1) Make sure the detector’s Main Menu is displayed.




- 2) Select the product speed menu.



(continued...)

- 3) Press the Go button and the product-speed input screen appears. (The figures in your screen, however, may be different, because the screen displays the last setting used.)




- 4) Use the navigation buttons to input the speed of the conveyor in meters per minute or feet per minute. Press the Go button to save the conveyor speed (and exit the input screen).
- 5) Note that the speed of the conveyor is now displayed in the product-speed section of the Main Menu.


Keying In the Photo-Eye-to-Detector Distance

The photo-eye-to-detector distance is a critical parameter that must be entered to ensure your conveyor application works correctly.


- 1) Take a tape measure and note the distance from the photo-eye (on the upstream or "in-feed" side of the detector) to the in-feed side of the detector's search head.
- 2) Make sure the Main Menu is displayed.




- 3) Navigate to the system and tools menu.




4) Press the Go button and navigate to page 3 of the system and tools menu.




5) Navigate to the photo-eye set-up menu.




6) Press the Go button, and page 1 of the "Photo-Eye Distance and Head Width" menu appears.



7) Press the right-navigation button to select the "In-Feed Photo-Eye Distance" menu.



- 8) Press the Go button, and an input screen appears. (The figures in your screen, however, may be different, because the screen displays the last setting used.)




- 9) Use the navigation buttons to input the distance from the photo-eye to the center of the detector head. (In our example, we would enter a distance in centimeters and millimeters.) Press the Go button to save your setting and exit the input screen).

Checking the Polarity of the Photo-Eye Input


This section assumes that your photo-eye is already connected to Input 2 on the detector's wiring board.

Photo-electric cells can send a signal to the detector, either when it detects light or when it detects dark. A light-activated photo-cell sends a signal when light is detected, and a dark-activated photo-cell sends a signal when dark is detected. You need to tell the detector which type of photo-cell you are using. If you do not know for sure, key in a positive polarity in the input menu screen (step 7 below) and, if that does not work, try a negative polarity. In addition, *make sure* the photo-eye is hard wired to Input 2 on the detector's wiring board. (For more information about input wiring, see pages 222 and 289.)


- 1) Follow steps 1–4 in the “Choosing Your Preferred Units of Measure” section on page 22 to get to the menu shown below—page 2 of the system and tools menu.




- 2) Navigate to the inputs and outputs menu.




3) Press the Go button and the inputs and outputs menu appears.




4) Press the right-navigation button to select the inputs menu.



5) Press the Go button and page 1 of the input set-up menu appears.




6) Navigate to the "Infeed Photo Eye Input" menu, shown below.




Look carefully at the "+2" notation in this menu, which tells you two things:

- The in-feed photo-eye is connected to Input 2 on the detector's wiring board.
- The input voltage has a positive (+) polarity.

- 7) If you need to change the polarity on Input 2 to a negative polarity, press the Go button, and the in-feed photo-eye input screen appears.



- 8) Press the left-navigation button to underline the + sign.
- 9) Press the down-navigation button to change the polarity to minus (-), as shown below.



Note, if your photo eye were wired to Input 3 (or any other Input between 1 and 6), this menu would be used to make the change. For a positive polarity on Input 3, for example, you would enter "+3" in this input screen.

- 10) Press the Go button to save your setting and exit the input screen.

Selecting the Correct Photo Registration for Rejects

If you are using a photo eye to control your reject device, this function allows you to do the following.

- Make accurate and consistent rejects using a variety of reject devices—such as drop-nose, retracting-belt, air-pusher, and air-reject systems.
- Make accurate and consistent rejects, even when the gaps between your individual units of product varies.

This function is particularly useful if you are inspecting packages that exceed six inches in length. (Here "length" means that, as the front end of the package enters the search head, the distance to its trailing edge is six inches or more.) When testing products longer than six inches, using a photo eye (and the appropriate parameters for the photo-registration function) allows you to accurately reject contaminated products—

regardless of where the contamination is located in the package (at the front, in the middle, or at the back).

Matching Your Photo-Registration Parameters to Your Reject Device

It is important to match your photo-registration parameters to the type of reject device you are using. Rejects can be triggered in three different ways, as follows.

- By the leading-edge of the product.
- By the middle of the product.
- By the entire length of the product.

Use the following information to select the best photo-registration setting for your particular application.

Leading-Edge Rejects

This setting is recommended for drop-nose and retracting-belt reject devices.

Middle-of-the-Product Rejects


This setting is recommended for air-pusher and air-jet reject devices.

Entire-Length Rejects


This setting is recommended for applications where the gaps between the units of product are variable. When gaps vary, the photo eye registers the reject using the leading edge of the product, but automatically extends the reject duration to compensate for the length of the product.

Setting Photo-Registration Parameters

- 1) Make sure the detector's Main Menu is displayed.




- 2) Navigate to the reject-totals menu.




(continued...)

- 3) Press the Go button and navigate to page 2 of the rejects-totals menu.



- 4) Press the right-navigation button to select the photo-registration menu. (Your screen may look slightly different because the detector saves your previous setting.)



- 5) Press the Go button repeatedly until a check mark appears beside the type of photo registration you want to use. (These options are mutually exclusive.) Press the Back button to save your setting and exit the menu.



Reject is triggered by the product's leading edge.



Reject is triggered by the center of the product. This is the recommended setting for conveyor applications.



Reject is triggered by the entire length of the product.

Setting Product Parameters

The three critical product parameters you need to set for a conveyor application are as follows.


- Pack length
- No-pack distance
- Pack gap

Read on to learn what these terms mean and how to set up these parameters for your conveyor application.


Keying In the Pack Length

The length of the individual units of product moving along the conveyor (for example, packets of salted butter) is referred to as the “pack length” of the product.


- 1) Make sure the Main Menu is displayed.




- 2) Press the Go button and page 1 of the product menu appears.




- 3) Press the down-navigation button to highlight page 2, the “Product Shape and Flow” menu.




- 4) Press the right-navigation button to select the pack-length function.



- 5) Press the Go button, and the pack-length input screen appears.



- 6) In the real world, you would now measure the length of the product you are testing and key this value into the pack-length input screen using the navigation buttons. In our example, we measured the length of our packets of salted butter, noted that they are 12.4 centimeters in length, and have keyed in this number into the input screen, as shown below.




- 7) Press the Go button to save your pack-length setting and exit the input screen.

Keying In the No-Pack Distance


The no-pack distance function—in conjunction with the pack-gap function—allows you to fine-tune whether the APEX rejects only one or *both* units of product (also known as “packs” or “packages”) when there is uncertainty (explained in the “Keying In the Pack Gap” section below) about which of the packs is contaminated.

In most conveyor applications it is best to enter identical values for the pack-length and the no-pack distance functions.

- 1) Make sure the no-pack distance function is highlighted.




- 2) Press the Go button and an input screen appears.



- 3) Key in the same value you entered for the pack-length parameter. (In our example, where we are testing packets of salted butter, we entered a value of 12.4 cm for the no-pack distance.)
- 4) Press the Go button to save your setting and exit the input screen.


Disabling the Detection No-Pack Function

When the detection no-pack function is disabled (as shown in the screen below), no rejects are made when a contaminant is detected that is not associated with a package.




To disable the detection no-pack function, do the following.


- 1) Make sure the Main Menu is displayed.



- 2) Navigate to the systems and tools menu and make sure it is highlighted.




- 3) Press the Go button and page 1 of the system and tools menu appears.




(continued...)


4) Navigate to the “Warnings, Alarms, and Faults” (WAFs) menu.




5) Press the Go button and page 1 of the WAFs menu appears.



6) Press the down-navigation button and page 2 of the menu appears.




7) Navigate to the “detection no-pack” function and make sure it is highlighted.



Note that, currently, when the APEX detects a contaminant that is not associated with a package, a fault results—as shown by the presence of the fault symbol in the menu.




- 8) Press the Go button repeatedly until all the warning, alarm, and fault symbols are cleared from the menu, as shown below.



- 9) Press the Back button to save your setting and exit the menu. Now, no rejects are made when contamination that is not associated with a package, is detected by the APEX.

Keying In the Pack Gap

The "pack gap" is expressed as a percentage and, in most conveyor applications, should be set to 100%, the default value. Changing the pack gap, however, allows you to fine-tune whether the APEX rejects only one or *both* units of product (also known as "packs" or "packages"), when there is uncertainty (explained below) about which of two packs entering the search head one after another is contaminated.



Example


Let us assume the following.

- You are testing multiple units of product (packs or packets) in a conveyor application, where the length of the gap between the packs is about the same as the pack length.
- The pack-gap function is currently set to the detector's default value of 100%.

In this type of conveyor application, where you are testing multiple units of product (such as packets of salted butter), let us look at an individual packet of contaminated butter. Clearly, metallic contaminants could be present anywhere in the packet—in the top, middle, sides, or bottom of the package, or in the leading or trailing edge of the packet. Unfortunately, when testing multiple packets, if the metallic contaminant is in the *trailing* edge of Pack 1 (the first packet entering the search head), it may be hard for the detector to distinguish whether the contamination is in Pack 1, or the next pack that enters the search head, Pack 2.

Explanation of the Theory Underlying the Pack-Gap Function

In the above example, if you enter a value of 100% for the pack-gap function, *both* packs are rejected, because—as shown in the diagram below—the overlap distance of the two packs falls within the 100% zone of the pack-gap function—which, in turn, falls within the no-pack distances for Pack 1 and Pack 2. No-pack distances are calculated by the detector, using input from the photo eye on the conveyor; or, they can be set by you, the user—as described above.



Thus, by setting appropriate values for the pack-gap function, the detector will take one of the following actions.

- Reject Pack 1 only
- Reject both packs
- Reject Pack 2 only


The following table illustrates what action the APEX will take, when a contaminant is detected in one of the positions A–F in the diagram above and the pack-gap function is set to 100%, 50%, or 25%.

Pack gap	Pack rejected when contaminant in the following position (A–F)					
	A	B	C	D	E	F
100%	1	1	1 and 2	1 and 2	1 and 2	2
50%	1	1	1 and 2	1 and 2	1 and 2	2
25%	1	1	1	1 and 2	2	2


Entering a Value for the Pack-Gap Function

To enter a value for the pack-gap function, do the following.


- 1) If you are not already looking at page 2 of the “Product Shape and Flow” menu, follow steps 1–4 in the “Keying In the Pack Length” section above to reach this menu.




- 2) Use the navigation buttons to select the pack-gap menu.



- 3) Press the Go button and the pack-gap input screen appears.



- 4) Key in an appropriate value for pack gap. (In our example, we have keyed in a value of 50%.)



- 5) Press the Go button to save your pack-gap setting and exit the input screen.

Setting Reject Parameters

This section assumes that the reject device you are using to remove contaminated products from the conveyor is already connected to the detector's wiring board and ready to go to work. If a reject device is not already connected to your detector, see the "Mechanical Set-Up for Conveyor Applications" section on page 292.

In this manual—and in the detector's menus—the *main* reject device is referred to as the "Reject 1" device. Any secondary reject device is called the "Reject 2" device. The following sections are written on the assumption that you currently have only *one* reject device attached to your detector, a Reject-1 device. (For information about keying in parameters for a Reject-2 device, see page 141.)

Reject Totals					
P001			001		
↔	30.5	0/0	40	0/0	0/0
0	0	0/0	90.00	0/0	0/0
0	x	x	3	0	x

Measurements You Will Need Before Starting

Imagine our packets of salted butter moving along the conveyor and the search head suddenly detects a packet containing a metallic contaminant. For now, the contaminated packet continues its journey out of the search head and along the conveyor. Around one meter from the detector, however, the packet passes the main reject device and is suddenly ejected from the conveyor into the reject bin. (One down, more to go!)

However, before you can begin keying in parameters to control your reject device, you must have the following information ready.

- The distance from the *downstream* edge of the search head to the *center* of your reject device.
- The duration of the signal needed (expressed in seconds and hundredths of a second) to activate your reject device.


With this information in hand, you are now ready to key in the needed values. In our salted butter example, we are going to use the following values.

- Reject distance = 1.17 meters
- Reject-signal duration = 2.02 seconds


Keying In the Distance to the Reject Device

Before starting, make sure you know the distance from the downstream edge of the search head to the center of your main (Reject 1) device.


- 1) From the Main Menu navigate to the reject-totals menu.



- 2) Press the Go button and page 1 of the rejects menu appears.




- 3) Navigate to the “Reject 1 Distance/Delay” function




Stop and look *very carefully* at the highlighted number in the screen above, and note that the current setting is 0.300 meters—as shown by the *m* after the number. (In other words, the reject distance is *not* expressed in seconds, which for some applications, would be a valid setting.)


- a. If the number in the “Reject 1 Distance/Delay” menu is shown as a *time unit* (as indicated by an *s* after the number), you should now change it to a *distance unit*. To do so, press the right-navigation button and highlight the change-units function, as shown below.



- b. Press the Go button and the original units are changed from seconds to meters (or feet, if you have set these as your preferred distance unit). Notice that the numbers in the adjacent menu have now changed.



- c. Make sure the screen shown in step 3 is displayed (the one where the reject distance is expressed in meters). You are now ready to key in your reject distance in meters (or feet and inches, if these are your preferred units).
- 4) Press the Go button and the reject-distance input-screen appears. Use the navigation buttons to key in your reject distance. (In our salted butter example, we have entered our reject distance of 1.17 meters.)




- 5) Press the Go button to save your settings and exit the input screen.

Keying In the Signal Duration for the Reject Device


Before starting, make sure you know the signal-duration time (expressed in seconds and hundredths of a second) needed to activate your main (Reject 1) device.

- 1) If you are not already on page 1 of the rejects menu, follow steps 1–2 in the “Keying In Distance to the Reject Device” section to get there.
- 2) Navigate to the reject-device signal-duration function.



The screen above shows that, currently, the reject-1 device remains active for 1.50 seconds.

- 3) Press the Go button and the signal-duration input screen appears. Use the navigation buttons to key in your signal duration—in seconds and hundredths of a second. (In our salted butter example, we have entered our signal-duration time of 2.02 seconds.)



- 4) Press the Go button to save your settings and exit the input screen.
- 5) Press the Back button repeatedly to return to the Main Menu.

Setting Contaminant-Detection Parameters

This section assumes you have followed all the instructions from the start of the “Setting Up Conveyor Applications” to this point. The reason for this is that, before you can calibrate your detector, the parameters described above must already have been set.

This section tells you how to do the following.

- Set up a monitoring baseline for the detector by calibrating the *X* and *R* noise thresholds, which must be done when no product is present in the search head.
- Calibrate the speed filter using a *ferrous* test stick (for most applications, use the 2.0 to 4.0 millimeter test stick). If the red indicator light on the control panel lights when you pass the 4.0 millimeter test stick, use a smaller size.
- Have the detector learn the appropriate detect level, phase angle, and peak signal settings by passing uncontaminated product through the search head.
- Have the detector do a Quality Test learn, if applicable.
- Have the detector do an AuditCheck learn, if applicable.

Once you have finished this section, your detector will be set up and ready to go to work monitoring your product for the presence of metallic contaminants.


Establishing Noise Thresholds with No Product Present

Before you can establish noise thresholds for the *X* and *R* signals, you *must* do the following.

- Turn on the conveyor.
- Remove all product from the conveyor.


Now that the conveyor is running and no product is present in the search head, follow the instructions below to calibrate the detector’s settings for the *X* and *R* noise thresholds.

- 1) Make sure the Main Menu is displayed.




(continued...)


2) Navigate to the frequency and gain menu.




3) Press the Go button and page 1 of the "Frequency, Gain & Inhibit" menu appears.




4) Press the down-navigation key to select page 2 of the frequency and gain menu.



5) Navigate to the "Calibrate Noise Thresholds" menu. (Note: The *background* of the calibrate function is now highlighted in black.)



- 6) Press the Go button. The detector immediately starts measuring (calibrating) the background X and R noise thresholds, and the monitor screen (below) presents a bar graph of the progress of the calibration process. The calibration takes roughly 20 seconds to complete.



When finished, the monitor screen disappears and the “Calibrate Noise Threshold” menu (shown in step 5) reappears. The screen now displays the calibrated (measured) values for the X and R noise thresholds and, because these are *background* values, the numbers should be low. If the numbers are high (that is, larger than 1,000 for X and larger than 200 for R), it may be difficult to detect small metal contaminants over the background noise.


- *Reducing High X Noise Thresholds*
An X -threshold in excess of 1,000 usually indicates there is a problem with excessive vibration in your conveyor application. As a general rule, as the severity of the vibration increases, the X -threshold also increases. Thus, if higher conveyor speeds cause the X -threshold to increase, vibration is the likely cause. Possible remedies include making sure the detector is completely isolated mechanically from your conveyor, and/or installing shock mounts for the detector.
- *Reducing High R Noise Thresholds*
An R -threshold in excess of 200 usually indicates that one (or more) of the following conditions is present.
 - Excessive noise from electro-magnetic currents (EMCs) and variable frequency drives (VFDs). Rectify by installing an isolation transformer and/or line reactors.
 - Metal in the detector’s metal-free zone. Rectify by removing the metal.
 - A ground loop is present in the conveyor. Rectify by installing plastic rollers in the conveyor.

- 7) If you want to manually key in a different value for either the X or R noise threshold, make sure the “Calibrate Noise Thresholds” menu (shown in step 5) is displayed. Navigate to the appropriate menu (X or R) and press the Go button. An input screen appears, allowing you to manually enter a value.


Calibrating the Speed Filter Using a Ferrous Test Stick

In this section you will learn how to calibrate the speed filter using a *ferrous* test stick. The speed filter is a narrow-band pass filter that rejects most background noise, but still allows a maximum metal signal from the search head to be processed by the detector.


- 1) Follow steps 1–4 in the “Choosing Your Preferred Units of Measure” section on page 22 to get to the menu shown below—page 2 of the system and tools menu.



- 2) Press the right-navigation button to select the speed filter menu.




- 3) Press the Go button and the calibrate-filter menu appears.




- 4) Start up the conveyor and have the ferrous test stick ready. (If you are wearing a watch, ring, and so on and plan on catching the test stick as it exits the search head, now would be a good time to take them off, so they do not interfere with the search head.)

5) Press the Go button and the following monitor screen appears.



6) Place the ferrous test stick on the conveyor upstream of the detector, so that the test stick passes through the center (not the edge!) of the search head.

7) When the calibration is complete, the following screen appears showing the new setting for the speed filter. The value shown in your screen will probably be different because the setting depends on belt speed and aperture size of the search head.



Establishing Basic Product Parameters


Before putting your detector into service, you must have it learn how to identify your uncontaminated product. This is done using the detector's full-product calibration function, which sets the following basic parameters for your product.

- Frequency and gain
- Phase-angle setting
- Detect level
- AuditCheck parameters, if applicable


Setting Frequency and Gain to High

Before doing a full-product calibration, it is best to set the detector's frequency and gain settings to high. To do this, follow the instructions below.

1) Make sure the Main Menu is displayed.




Or, like this when IXR is enabled.




(continued...)


2) Navigate to the frequency and gain menu and make sure it is highlighted.




Or, like this when IXR is enabled.



3) Press the Go button and page 1 of the frequency and gain menu appears.



4) Press the right-navigation button to highlight the gain menu.




5) Make sure a checkmark is showing next to the *high-gain* icon, which looks like this.




High-gain icon

Note: If the checkmark is next to the low-gain icon, press the Go button to select the high-gain setting.

6) Press the Back button to save your setting and return to page 1 of the frequency and gain menu.



7) Navigate to the frequency menu.



8) Make sure a checkmark is showing next to the *high-frequency* icon, which looks like this.



High-frequency icon

Note: If the checkmark is next to the low-frequency icon, press the Go button to select the high-frequency setting.


9) Press the Back button repeatedly to save your settings, exit the menu, and return to the Main Menu.

Doing a Full-Product Calibration


Before doing a full-product calibration, it is best to set the frequency and gain settings to *high* (as described in the section above).

To do a full-product calibration, follow the instructions below.

- 1) Make sure that the conveyor is turned on and uncontaminated product is passing through the search head. (In the example below, we are monitoring jars of spaghetti sauce.)
- 2) Highlight your product name in the Main Menu. (Your screen will look different if IXR is enabled.)




- 3) Press the Go button and page 1 of the product menu appears.



(continued...)

4) Press the right-navigation button to highlight the “Full Product Calibration” menu.



The detector's auto-calibration function (as shown by the icons and check marks in the screen above) is now ready to do the following.

- Learn the phase angle.




- Learn the detect level.



- Conduct an AuditCheck, if this optional hardware is installed on your APEX.




5) Press the Go button and the “Performing Full Learn” monitor screen appears.




(continued...)

- 6) When the calibration is complete, the detector displays the Main Menu, which should now look something like this. (Your screen will look different if IXR is enabled.)




- 7) Sometimes, however, the high-frequency and high gain settings are *too* sensitive, which saturates the detector's circuit. When this occurs, the APEX halts the calibration and displays a screen (see below) showing the next-best option—the high-frequency/low gain option.

- a. High Frequency/Low Gain Option




- b. Press the Go button to restart the full product calibration. If this setting is too sensitive, the following screen appears—the low frequency/high gain option.

- c. Low Frequency/High Gain Option




Please note that if the frequency is changed, the APEX must relearn the *X* and *R* noise thresholds for optimal performance. The APEX software will take you to page 2 of the frequency and gain menu. Follow the directions on page 166 to calibrate the *X* and *R* noise thresholds. Then return to the full calibration and continue.

- d. Press the Go button to restart the full product calibration. If this setting is too sensitive, the following screen appears—the low frequency/low gain option.
- e. Low Frequency/Low Gain Option



Please note that this change in gain will result in the *R* and *X* noise thresholds being reduced by a factor of 4.


- f. Press the Go button to restart the full product calibration. If this setting is still too sensitive, the following warning screen appears. When this happens, please contact Thermo Fisher Scientific—as described in the “Contacting Thermo Fisher Scientific” section at the end of the manual.





- g. Press the Back button to exit the calibration menu.

(continued...)

- 8) When the auto-calibration function is finished, the detector displays the Main Menu screen, which should now look something like this. (Your screen will look different if IXR is enabled.)



Notice that, in our example, the auto-calibration function has learned the following basic parameters for our uncontaminated product (in our example, jars of spaghetti sauce).

- Detect level  = 53
- Phase angle  = 2.24

What the Main Menu Screen Is Telling You

The Main Menu screen is now telling you that, once the detector is monitoring your product stream, any unit of contaminated product that exceeds the detect level of 53, will be rejected. And, because the phase angle is 2.24 degrees, the detector is monitoring a wet product (in our example, jars of spaghetti sauce).

Set-Up Check List for Conveyor Applications

This section lists the parameters you have already set (by following the instructions from the start of the “Setting Up Conveyor Applications” section up to this point in the manual). This section also lists additional parameters you may want to set up to get your particular conveyor application running to your satisfaction.

Parameters You Have Already Set Up

Listed below are the parameters you have already set up for a typical conveyor application.

Product Parameters

- Product name
- Pack length
- No-pack distance
- Pack gap

Conveyor and Photo-Eye Parameters

- Conveyor belt-speed
- Photo-eye-to-detector distance
- Polarity of the photo-eye input
- Photo registration for product rejects

Reject Parameters

- Distance to the reject device
- Signal duration for the reject device

Contaminant-Detection Parameters (Set by the Detector’s Calibrate Functions)

- *X* and *R* noise thresholds
- Speed-filter setting
- Detect level
- Phase-angle setting

Additional Parameters You May Want to Set Up

Listed below are additional parameters you may want to set up to get your particular conveyor application running to your satisfaction.

Belt-Speed-Encoder Function

If your conveyor has a speed encoder, this function allows the conveyor speed parameter to be set automatically. For more details, see page 124.

Bin-Full Notification

If your reject bin is monitored by a photo-eye, this function allows you to be notified (or the conveyor stopped), when the reject bin is full. For more details, see page 217.

Reject-Confirm Function

If you have an additional photo eye to confirm that a reject has, indeed, occurred, this function notifies you if the reject does *not* occur. For more details, see page 137.

Warnings, Alarms, and Faults (WAFs)

Many of the detectors functions provide a warning, alarm, or fault when a condition needing your attention occurs. This menu—in conjunction with the appropriate hardwired external device—allows this to happen. For more details, see page 214.

Quality Test

A Quality Test allows you to verify that the detector is working properly, especially when testing products over long periods of time. The Quality Test is a manual, not an automatic, test. For more details, see page 196.

AuditCheck

If the optional AuditCheck equipment is installed on your search head, the AuditCheck function allows you to verify that the detector is working properly, especially when testing products over long periods of time. The AuditCheck tests occur automatically, while product is running, at time intervals you specify. For more details, see page 206.

Phase Tracking

The phase-tracking function allows the APEX to automatically adjust the product phase for small variations in phase over long periods of time, especially when testing wet products (where the phase angle is sensitive to product temperature). For more details, see page 153.

Copying and Pasting Product Parameters

This function is particularly useful when you are testing multiple products. You can save considerable amounts of time and effort using the copy and paste functions, because you do not need to re-enter the product parameters for each product, re-run the calibrations, and so on. For more details, see page 173.

Setting Up Gravity-Feed Applications

This section assumes you have already completed the electrical and mechanical installations for your detector. If not, see pages 283 (for electrical set-up instructions) and 299 (for mechanical set-up instructions).

The purpose of this section is to present you with a brief tutorial, allowing you to get your gravity-feed application up and running as quickly as possible. Here is an outline of what you will be learning. If you are already familiar with some of the information covered, you can always skip ahead to the next section.

Understanding Your Detector

In this section you will learn how to...

- Use the detector's display panel.
- Navigate the detector's menus and sub-menus.
- Set up global parameters for the detector.
- Key in a name for your product.

Setting Reject Parameters

In this section you will learn how to...

- Key in the reject-delay time.
- Key in the reject-duration time.

Setting Contaminant-Detection Parameters

In this section you will learn how to...

- Establish a noise threshold with no product present in the duct.
- Select the appropriate setting for the speed filter.
- Establish basic product parameters (detect level and phase-angle).

Understanding Technical Terms

If you encounter a technical term you do not understand in these sections, please refer to the Glossary on page 393. For example, the word "product" means anything the detector is testing for the presence of metal contaminants, and is a word you will encounter often in this manual.

Let's get started!

Understanding Your Detector

In order to minimize the length of this already lengthy manual, we are not going to repeat information here that has already been covered elsewhere in the manual—and we hope you agree this is a wise choice.

Please start at page 1 of the “Getting Started” section and read all the way through to the end of the “Naming the Product” section on page 26. When you have finished reading these sections you will know how to do the following.





- Use the detector’s display panel.
- Navigate the detector’s menus and sub-menus.
- Set up global parameters for the detector.
- Key in a name for your product.

The Next Step

Now that detour is over, welcome back! You are now ready to set up the specific parameters you will need to run your gravity-feed application. Read on for more details.

Setting Reject Parameters

This section tells you how to set reject parameters for a typical gravity-feed application.

Reject Totals			
P001		001	
→→	246.0 $\frac{0}{mm}$	40	$\frac{0}{mm}$
	0	90.00	
	0	6	

Understanding Reject-Delay and Reject-Duration Timing

In a gravity-feed application, the detector's search head surrounds a duct where product is falling vertically under the influence of gravity. When the search head detects metallic contaminants in the product, the product continues down the duct, and is diverted into a secondary duct by a gate that closes off the main duct. (Looking at the figure on page 304 will help you understand this explanation for a typical gravity-feed application.) The gate stays closed for a set period of time (usually about one second) to divert the contaminated product, then opens again to allow uncontaminated product to again flow freely. Thus, for the reject process to work properly, two critical time parameters must be set.

- *Reject-Delay Time*
In most gravity-feed applications, where the gate is located close to the search head, the reject-delay time is usually set to 0.00 seconds. Thus, when the search head detects contaminants, the gate closes immediately.

However, in applications where the gate is located some way from the search head, a time delay is needed, because the product takes a finite time to move from the search head to the vicinity of the gate. Clearly, the reject-delay time should be set to make sure that the gate closes completely *before* the contaminated product actually reaches the gate. Reject-delay times, when needed, are set in seconds and hundredths of a second.


- *Reject-Duration Time*
This is the time (in seconds and hundredths of a second) that the gate remains closed to divert contaminated product into the reject bin. A typical time for a normal gravity-feed application is one second.

Once you have set the reject-delay time and reject-duration time parameters, you must test the reject process. Then, if needed, you may want to fine-tune the detector's response to vibration caused by the gate opening and closing by enabling the reject suppression feature.


Setting the Reject-Delay Time

To set the reject-delay time, do the following.


- 1) From the Main Menu navigate to the rejects menu.




- 2) Press the Go button and page 1 of the rejects menu appears.



- 3) Navigate to the reject-1 distance/delay menu shown below.



- 4) Press the Go button and the reject-1 distance/delay input screen appears. Key in an appropriate value for reject-1 distance/delay. For a typical gravity-feed application, key in a value of 0.00 seconds. This allows the reject gate to close immediately, when metallic contaminants are detected.




- 5) Press the Go button to save your setting.
- 6) Press the Back button repeatedly to return to the Main Menu.


Setting the Reject-Duration Time

To set the reject-duration time, do the following.


- 1) From the Main Menu navigate to the rejects menu.



- 2) Press the Go button and page 1 of the rejects menu appears.




- 3) Navigate to the reject-1 duration menu shown below.



(continued...)

- 4) Press the Go button and the reject-1 duration input screen appears.



- 5) Key in a value for the reject-1 duration parameter. For a typical gravity-feed application, key in a value of 1.00.
- 6) Press the Go button to save your setting.
- 7) Press the Back button repeatedly to return to the Main Menu.

Setting Contaminant-Detection Parameters

This section assumes you have followed all the instructions from the start of the “Setting Up Gravity-Feed Applications” to this point. The reason for this is that, before you can calibrate your detector, the parameters described above must already have been set.

This section tells you how to do the following.


- Set up a monitoring baseline for the detector by calibrating the *X* and *R* noise thresholds, which must be done when *no* product is present in the duct.
- Select the appropriate value for the speed filter.
- Establish basic product parameters (detect level and phase-angle).

Once you have finished this section, your detector will be set up and ready to go to work monitoring your product stream for the presence of metallic contaminants.


Establishing a Baseline with No Product Present

Before you can establish a monitoring baseline (that is, establish a background-noise level) for the *X* and *R* thresholds (the parameters that allow the detector to identify metal contaminants), you *must* make sure no product is falling through the duct.


- 1) Make sure the Main Menu is displayed.




- 2) Navigate to the frequency and gain menu.




3) Press the Go button and page 1 of the "Frequency, Gain & Inhibit" menu appears.



4) Press the down-navigation key to select page 2 of the frequency and gain menu.




5) Navigate to the "Calibrate Noise Thresholds" menu. (Note: The *background* of the calibrate function is now highlighted in black.)



(continued...)


- 6) Press the Go button. The detector immediately starts measuring (calibrating) the background X and R noise thresholds, and the monitor screen (below) presents a bar graph of the progress of the calibration process. The calibration takes roughly 20 seconds to complete.



When finished, the monitor screen disappears and the “Calibrate Noise Threshold” menu (shown in step 5) reappears. The screen now displays the calibrated (measured) values for the X and R noise thresholds and, because these are *background* values, the numbers should be low. If the numbers are high, it may be difficult to detect small metal contaminants over the background noise.

- *Reducing High X Noise Thresholds*
An X -threshold in excess of 1,000 usually indicates there is a problem with excessive vibration in your application. As a general rule, as the severity of the vibration increases, the X -threshold also increases. Possible remedies include making sure the detector is completely isolated mechanically from the surrounding duct, and/or installing shock mounts for the detector.
- *Reducing High R Noise Thresholds*
An R -threshold in excess of 200 usually indicates that one (or more) of the following conditions is present.
 - Excessive noise from electro-magnetic currents (EMCs) and variable frequency drives (VFDs). Rectify by installing an isolation transformer and/or line reactors.
 - Metal in the detector’s metal-free zone. Rectify by removing the metal.


- 7) If you want to manually key in a different value for either the X or R noise threshold, make sure the “Calibrate Noise Thresholds” menu (shown in step 5) is displayed. Navigate to the appropriate menu (X or R) and press the Go button. An input screen appears, allowing you to manually enter a value.




Calibrating the Speed Filter Using a Ferrous Test Ball

In this section you will learn how to calibrate the speed filter using a 2.0 to 4.0 millimeter ferrous test ball. Please note that in a gravity-feed application the default speed filter is a narrow-band pass filter that rejects most background noise, but still allows a maximum metal signal from the search head to be processed by the detector.


- 1) Follow steps 1–4 in the “Choosing Your Preferred Units of Measure” section on page 22 to get to the menu shown below—page 2 of the system and tools menu.




- 2) Press the right-navigation button to select the speed filter menu.




- 3) Press the Go button and the calibrate-filter menu appears.



- 4) Press the Go button and the following monitor screen appears.



- 5) Insert the test ball into the duct's insertion port, which is always *upstream* of the detector. (Refer to the diagram on page 304, which shows a typical test set-up for a gravity-feed application.) If the red indicator light on the control panel lights when you pass the 4.0 millimeter test ball, use a smaller size.
- 6) Press the Back button to exit the calibration menu. Look at the screen below (the same screen as shown in step 3 above) and notice that the calibration process has set the speed filter to 25.00 Hz and the product speed to 234 meters per minute.



Establishing Basic Product Parameters


Before putting your detector into service, you must have it learn how to identify your uncontaminated product. This is done using the detector's full-product calibration function, which sets the following basic parameters for your product.

- Phase-angle setting
- Detect level


Doing a Full-Product Calibration

To do a full-product calibration, follow the instructions below.


- 1) Make sure product is falling through the duct.
- 2) Highlight your product name in the Main Menu.




Or, like this when IXR is enabled.



3) Press the Go button and page 1 of the product menu appears.



4) Press the right-navigation button to highlight the "Full Product Calibration" menu.



The detector's auto-calibration function (as shown by the symbols and check marks in the screen above) is now ready to do the following.

- Learn the phase angle



- Learn the detect level




- Conduct an AuditCheck, if this optional hardware is installed on your APEX.




(continued...)

5) Press the Go button and the “Performing Full Learn” monitor screen appears.



6) When the auto-calibration function is finished, the detector displays the Main Menu screen, which should now look something like this. (Your screen will look different if IXR is enabled.)



Notice that, in our example, the auto-calibration function has learned the following basic parameters for our uncontaminated product.

- Detect level  = 140
- Phase angle  = 89.31

What the Main Menu Screen Is Telling You

The Main Menu screen is now telling you that, once the detector is monitoring your product stream, any contaminated product that exceeds the detect limit of 140, will be rejected. And, because the phase angle is 89.31 degrees, the detector is monitoring a dry product.

Set-Up Check List for Gravity-Feed Applications

This section lists the parameters you have already set (by following the instructions from the start of the “Setting Up Gravity-Feed Applications” section up to this point in the manual). This section also lists additional parameters you may want to set up to get your particular gravity-feed application running to your satisfaction.

Parameters You Have Already Set Up

Listed below are the parameters you have already set up for a typical gravity-feed application.

Product Parameters

- Product name

Reject Parameters

- Reject-delay time
- Reject-duration time

Contaminant-Detection Parameters (Set by the Detector’s Calibrate Functions)

- X and R noise thresholds
- Speed-filter setting
- Detect level
- Phase-angle setting

Additional Parameters You May Want to Set Up

Listed below are additional parameters you may want to set up to get your particular gravity-feed application running to your satisfaction.

Suppression-Time and Suppression-Amplitude Functions

These functions are used to prevent vibration from the gate interfering with the search head. For more details, see page 130.

Reject-Confirm Function

If your gate is equipped with a position detector, this function allows the detector to confirm that, during a reject cycle, the gate has properly completed both the “open” and “close” phases of the reject cycle. In addition, if a gate failure occurs, the detector can stop the flow of product, or notify you that a gate failure has occurred—for example, because the air supply to the gate has failed, or product has built up on the gate or surrounding duct-work. For more details, see page 137.

Warnings, Alarms, and Faults (WAFs)

Many of the detector’s functions provide a warning, alarm, or fault when a condition needing your attention occurs. This menu—in conjunction with the appropriate hardwired external device—allows this to happen. For more details, see page 214.

Copying and Pasting Product Parameters

This function is particularly useful when you are testing multiple products. You can save considerable amounts of time and effort using the copy and paste functions, because you do not need to re-enter the product parameters for each product, re-run the calibrations, and so on. For more details, see page 173.

Setting Up Pipeline Applications

This section assumes you have already completed the electrical and mechanical installations for your detector. If not, see pages 283 (for electrical set-up instructions) and 307 (for mechanical set-up instructions).

The purpose of this section is to present you with a brief tutorial, allowing you to get your pipeline application up and running as quickly as possible. Here is an outline of what you will be learning. If you are already familiar with some of the information covered, you can always skip ahead to the next section.

Understanding Your Detector

In this section you will learn how to...

- Use the detector's display panel.
- Navigate the detector's menus and sub-menus.
- Set up global parameters for the detector.
- Key in a name for your product.

Setting Reject Parameters

In this section you will learn how to...

- Key in the reject-delay time.
- Key in the reject-duration time.

Setting Contaminant-Detection Parameters

In this section you will learn how to...

- Establish a noise threshold with no product present in the pipe.
- Select the appropriate setting for the speed filter.
- Establish basic product parameters (detect level and phase-angle).

Understanding Technical Terms

If you encounter a technical term you do not understand in these sections, please refer to the Glossary on page 393. For example, the word "product" means anything the detector is testing for the presence of metal contaminants, and is a word you will encounter often in this manual.

Let's get started!

Understanding Your Detector

In order to minimize the length of this already lengthy manual, we are not going to repeat information here that has already been covered elsewhere in the manual—and we hope you agree this is a wise choice.

Please start at page 1 of the “Getting Started” section and read all the way through to the end of the “Naming the Product” section on page 26. When you have finished reading these sections you will know how to do the following.





- Use the detector’s display panel.
- Navigate the detector’s menus and sub-menus.
- Set up global parameters for the detector.
- Key in a name for your product.

The Next Step

Now that detour is over, welcome back! You are now ready to set up the specific parameters you will need to run your pipeline application. Read on for more details.

Setting Reject Parameters

This section tells you how to set reject parameters for a typical pipeline application.

Reject Totals			
P001		001	
→→	246.0 $\frac{0}{mm}$	40	$\frac{0}{mm}$
	0	90.00	
	0	6	

Understanding Reject-Delay and Reject-Duration Timing

In a pipeline application, the detector's search head surrounds a pipe where product is flowing under pressure. When the search head detects metallic contaminants in the product, the product continues along the pipe, and is diverted into a waste tank by a valve that closes off the main pipe. The diverter valve stays closed for a set period of time (usually about three seconds) to divert the contaminated product, then opens again to allow uncontaminated product to again flow freely. Thus, for the reject process to work properly, two critical time parameters must be set.

- *Reject-Delay Time*

In most pipeline applications, where the diverter valve is located close to the search head, the reject-delay time is usually set to 0.00 seconds. Thus, when the search head detects contaminants, the valve closes immediately.

However, in applications where the diverter valve is located some way from the search head, a time delay is needed, because the product takes a finite time to move from the search head to the diverter valve. Clearly, the reject-delay time should be set to make sure that the valve closes *before* the contaminated product actually reaches the valve. Reject-delay times, when needed, are set in seconds and hundredths of a second.

- *Reject-Duration Time*


This is the time (in seconds and hundredths of a second) that the valve remains closed to divert contaminated product into the waste tank. A typical time for a normal pipeline application is three seconds.

Once you have set the reject-delay time and reject-duration time parameters, you must test the reject process. Then, if needed, you may want to fine-tune the detector's response to vibration caused by the diverter valve opening and closing by enabling the reject-suppression feature.


Setting the Reject-Delay Time

To set the reject-delay time, do the following.


- 1) From the Main Menu navigate to the rejects menu.




- 2) Press the Go button and page 1 of the rejects menu appears.



- 3) Navigate to the reject-1 distance/delay menu shown below.



- 4) Press the Go button and the reject-1 distance/delay input screen appears. Key in an appropriate value for reject-1 distance/delay. For a typical pipeline application, key in a value of 0.00 seconds. This allows the reject gate to close immediately, when metallic contaminants are detected.




- 5) Press the Go button to save your setting.
- 6) Press the Back button repeatedly to return to the Main Menu.


Setting the Reject-Duration Time

To set the reject-duration time, do the following.


- 1) From the Main Menu navigate to the rejects menu.



- 2) Press the Go button and page 1 of the rejects menu appears.




- 3) Navigate to the reject-1 duration menu shown below.



(continued...)

- 4) Press the Go button and the reject-1 duration input screen appears.



- 5) Key in a value for the reject-1 duration parameter. For a typical pipeline application, key in a value of 3.00 seconds.
- 6) Press the Go button to save your setting.
- 7) Press the Back button repeatedly to return to the Main Menu.

Setting Contaminant-Detection Parameters

This section assumes you have followed all the instructions from the start of the “Setting Up Pipeline Applications” to this point. The reason for this is that, before you can calibrate your detector, the parameters described above must already have been set.

This section tells you how to do the following.


- Set up a monitoring baseline for the detector by calibrating the X and R noise thresholds, which must be done when *no* product is present in the pipe.
- Select the appropriate value for the speed filter.
- Establish basic product parameters (detect level and phase-angle).

Once you have finished this section, your detector will be set up and ready to go to work monitoring your product stream for the presence of metallic contaminants.


Establishing a Baseline with No Product Present

Before you can establish a monitoring baseline (that is, establish a background-noise level) for the X and R thresholds (the parameters that allow the detector to identify metal contaminants), you *must* make sure no product is flowing through the pipe.


- 1) Make sure the Main Menu is displayed.




- 2) Navigate to the frequency and gain menu.




3) Press the Go button and page 1 of the "Frequency, Gain & Inhibit" menu appears.



4) Press the down-navigation key to select page 2 of the frequency and gain menu.




5) Navigate to the "Calibrate Noise Thresholds" menu. (Note: The *background* of the calibrate function is now highlighted in black.)



(continued...)


- 6) Press the Go button. The detector immediately starts measuring (calibrating) the background *X* and *R* noise thresholds, and the monitor screen (below) presents a bar graph of the progress of the calibration process. The calibration takes roughly 20 seconds to complete.



When finished, the monitor screen disappears and the “Calibrate Noise Threshold” menu (shown in step 5) reappears. The screen now displays the calibrated (measured) values for the *X* and *R* noise thresholds and, because these are *background* values, the numbers should be low. If the numbers are high, it may be difficult to detect small metal contaminants over the background noise.

- *Reducing High X Noise Thresholds*
An *X*-threshold in excess of 1,000 usually indicates there is a problem with excessive vibration in your application. As a general rule, as the severity of the vibration increases, the *X*-threshold also increases. Possible remedies include making sure the detector is completely isolated mechanically from the surrounding pipe work, and/or installing shock mounts for the detector.
- *Reducing High R Noise Thresholds*
An *R*-threshold in excess of 200 usually indicates that one (or more) of the following conditions is present.
 - Excessive noise from electro-magnetic currents (EMCs) and variable frequency drives (VFDs). Rectify by installing an isolation transformer and/or line reactors.
 - Metal in the detector’s metal-free zone. Rectify by removing the metal.

- 7) If you want to manually key in a different value for either the *X* or *R* noise threshold, make sure the “Calibrate Noise Thresholds” menu (shown in step 5) is displayed. Navigate to the appropriate menu (*X* or *R*) and press the Go button. An input screen appears, allowing you to manually enter a value.



Choosing the Appropriate Wide-Band Speed Filter

In this section you will learn how to select the appropriate wide-band speed filter setting based on the average product speed—expressed, for example, in feet per minute. Product speed is calculated from the product flow rate using the following formula.

$$\text{Gpm}/R^2 \times 6.13 = \text{Fpm}$$

Where:


Gpm = gallons per minute

R = inside radius of the pipe


Thus, the flow rate in gallons per minute, divided by the pipe's radius squared, times 6.13, equals the product flow rate in feet per minute (Fpm). Please note, however, that in the examples given below, product flow rates are expressed in *meters per minute*.

You can set the wide-band filter to the following speeds.


- *Speed filter #1—Slow*
This is the default setting and is used typically for products flowing from 10 to 75 meters per minute.



- *Speed filter #2—Medium*
This is used typically for products flowing from 75 to 300 meters per minute.



- *Speed filter #3—Fast*
This is used typically for products flowing from 300-800 meters per minute.




- *Custom speed*
This setting is used when your product is flowing through the pipe either very fast or very slowly. For help setting up a custom speed-filter setting, please contact Thermo Fisher Scientific—as described in the “Contacting Thermo Fisher Scientific” section at the end of the manual.


Setting Up the Speed Filter

To set up the appropriate speed-filter setting (slow, medium, or fast), do the following.

- 1) Make sure the Main Menu is displayed.



- 2) Navigate to the speed-filter menu and make sure it is highlighted.



- 3) Press the Go button repeatedly to scroll through the speed filter options (slow, medium, and fast) and select the one you want.
- 4) Press the Back button repeatedly to save your setting and return to the Main Menu.

Establishing Basic Product Parameters


Before putting your detector into service, you must have it learn how to identify your uncontaminated product. This is done using the detector's full-product calibration function, which sets the following basic parameters for your product.

- Phase-angle setting
- Detect level


Doing a Full-Product Calibration

To do a full-product calibration, follow the instructions below.

- 1) Make sure product is flowing through the pipe.
- 2) Highlight your product name in the Main Menu. (Your screen will look different if IXR is enabled.)




- 3) Press the Go button and page 1 of the product menu appears.



(continued...)

4) Press the right-navigation button to highlight the “Full Product Calibration” menu.



The detector's auto-calibration function (as shown by the icons and check marks in the screen above) is now ready to do the following.

- Learn the phase angle




- Learn the detect level



- Conduct an AuditCheck, if this optional hardware is installed on your APEX.




5) Press the Go button and the “Performing Full Learn” monitor screen appears.





(continued...)

- 6) When the auto-calibration function is finished, the detector displays the Main Menu screen, which should now look something like this. (Your screen will look different if IXR is enabled.)



Notice that, in our example, the auto-calibration function has learned the following basic parameters for our uncontaminated product.

- Detect level  = 202
- Phase angle  = 1.46

What the Main Menu Screen Is Telling You

The Main Menu screen is now telling you that, once the detector is monitoring your product stream, any contaminated product that exceeds the detect level of 202, will be rejected. And, because the phase angle is 1.46 degrees, the detector is monitoring a wet product.

Set-Up Check List for Pipeline Applications

This section lists the parameters you have already set (by following the instructions from the start of the “Setting Up Pipeline Applications” section up to this point in the manual). This section also lists additional parameters you may want to set up to get your particular pipeline application running to your satisfaction.

Parameters You Have Already Set Up

Listed below are the parameters you have already set up for a typical pipeline application.

Product Parameters

- Product name

Reject Parameters

- Reject-delay time
- Reject-duration time

Contaminant-Detection Parameters (Set by the Detector’s Calibrate Functions)

- X and R noise thresholds
- Speed-filter setting
- Detect level
- Phase-angle setting

Additional Parameters You May Want to Set Up

Listed below are additional parameters you may want to set up to get your particular pipeline application running to your satisfaction.

Suppression-Time and Suppression-Amplitude Functions

These functions are used to prevent vibration from the diverter valve interfering with the search head. For more details, see page 130.

Reject-Confirm Function

If your diverter valve is equipped with a position detector, this function allows the detector to confirm that, during a reject cycle, the diverter valve has properly completed both the “open” and “close” phases of the reject cycle. In addition, if the diverter valve fails, the detector can stop the flow of product, or notify you that a failure has occurred—for example, because the air supply to the valve has failed, or miscellaneous residue has clogged the valve. For more details, see page 137.

Warnings, Alarms, and Faults (WAFs)

Many of the detector’s functions provide a warning, alarm, or fault when a condition needing your attention occurs. This menu—in conjunction with the appropriate hardwired external device—allows this to happen. For more details, see page 214.

Copying and Pasting Product Parameters

This function is particularly useful when you are testing multiple products. You can save considerable amounts of time and effort using the copy and paste functions, because you do not need to re-enter the product parameters for each product, re-run the calibrations, and so on. For more details, see page 173.

Setting Up Pharmaceutical (Rx) Applications

This section assumes you have already completed the electrical and mechanical installations for your detector. If not, see pages 283 (for electrical set-up instructions) and 299 (for mechanical set-up instructions).

The purpose of this section is to present you with a brief tutorial, allowing you to get your pharmaceutical application up and running as quickly as possible. Here is an outline of what you will be learning. If you are already familiar with some of the information covered, you can always skip ahead to the next section.

Understanding Your Detector

In this section you will learn how to...

- Use the detector's display panel.
- Navigate the detector's menus and sub-menus.
- Set up global parameters for the detector.
- Key in a name for your product.

Setting Reject Parameters

In this section you will learn how to...

- Key in the reject-delay time.
- Key in the reject-duration time.

Setting Contaminant-Detection Parameters

In this section you will learn how to...

- Establish a noise threshold with no product present in the chute.
- Select the appropriate setting for the speed filter.
- Establish basic product parameters (detect level and phase-angle).

Understanding Technical Terms

If you encounter a technical term you do not understand in these sections, please refer to the Glossary on page 393. For example, the word "product" means anything the detector is testing for the presence of metal contaminants, and is a word you will encounter often in this manual.

Let's get started!

Understanding Your Detector

In order to minimize the length of this already lengthy manual, we are not going to repeat information here that has already been covered elsewhere in the manual—and we hope you agree this is a wise choice.

Please start at page 1 of the “Getting Started” section and read all the way through to the end of the “Naming the Product” section on page 26. When you have finished reading these sections you will know how to do the following.

- Use the detector’s display panel.
- Navigate the detector’s menus and sub-menus.
- Set up global parameters for the detector.
- Key in a name for your product.

The Next Step

Now that detour is over, welcome back! You are now ready to set up the specific parameters you will need to run your pharmaceutical application. Read on for more details.

Setting Reject Parameters

This section tells you how to set reject parameters for a typical pharmaceutical application.

Reject Totals					
P001		001			
→→	246.0	0	40	0	0
0	0	0	90.00	0	0
0	0	0	6	0	0

Understanding Reject-Delay and Reject-Duration Timing

In a pharmaceutical application, the detector's search head surrounds a chute where product is falling vertically under the influence of gravity. When the search head detects metallic contaminants in the product, the product continues down the chute, and is diverted into a secondary bin by a reject gate. The gate stays closed for a set period of time (usually about 0.50 seconds) to divert the contaminated product, then opens again to allow uncontaminated product to again flow freely. Thus, for the reject process to work properly, two critical time parameters must be set.

- *Reject-Delay Time*

In most pharmaceutical applications, where the gate is located close to the search head, the reject-delay time is usually set to 0.00 seconds. Thus, when the search head detects contaminants, the gate closes immediately.

However, in applications where the gate is located some way from the search head, a time delay is needed, because the product takes a finite time to move from the search head to the vicinity of the gate. Clearly, the reject-delay time should be set to make sure that the gate closes *before* the contaminated product actually reaches the gate. Reject-delay times, when needed, are set in seconds and hundredths of a second.

- *Reject-Duration Time*


This is the time (in seconds and hundredths of a second) that the gate remains closed to divert contaminated product into the reject bin. A typical time for a normal pharmaceutical application is 0.50 seconds.

Once you have set the reject-delay time and reject-duration time parameters, you must test the reject process.


Setting the Reject-Delay Time

To set the reject-delay time, do the following.


- 1) From the Main Menu navigate to the rejects menu.




- 2) Press the Go button and page 1 of the rejects menu appears.



- 3) Navigate to the reject-1 distance/delay menu shown below.



- 4) Press the Go button and the reject-1 distance/delay input screen appears. Key in an appropriate value for reject-1 distance/delay. For a typical pharmaceutical application, key in a value of 0.00 seconds. This allows the reject gate to close immediately, when metallic contaminants are detected.




- 5) Press the Go button to save your setting.
- 6) Press the Back button repeatedly to return to the Main Menu.


Setting the Reject-Duration Time

To set the reject-duration time, do the following.


- 1) From the Main Menu navigate to the rejects menu.



- 2) Press the Go button and page 1 of the rejects menu appears.




- 3) Navigate to the reject-1 duration menu shown below.



(continued...)

- 4) Press the Go button and the reject-1 duration input screen appears.



- 5) Key in a value for the reject-1 duration parameter. For a typical pharmaceutical application, key in a value of 0.50.
- 6) Press the Go button to save your setting.
- 7) Press the Back button repeatedly to return to the Main Menu.

Setting Contaminant-Detection Parameters

This section assumes you have followed all the instructions from the start of the “Setting Up Pharmaceutical Applications” to this point. The reason for this is that, before you can calibrate your detector, the parameters described above must already have been set.

This section tells you how to do the following.


- Set up a monitoring baseline for the detector by calibrating the *X* and *R* noise thresholds, which must be done when *no* product is present in the chute.
- Select the appropriate value for the speed filter.
- Establish basic product parameters (detect level and phase-angle).

Once you have finished this section, your detector will be set up and ready to go to work monitoring your product stream for the presence of metallic contaminants.


Establishing a Baseline with No Product Present

Before you can establish a monitoring baseline (that is, establish a background-noise level) for the *X* and *R* thresholds (the parameters that allow the detector to identify metal contaminants), you *must* make sure no product is falling through the chute.


- 1) Make sure the Main Menu is displayed.




- 2) Navigate to the frequency and gain menu.




3) Press the Go button and page 1 of the "Frequency, Gain & Inhibit" menu appears.



4) Press the down-navigation key to select page 2 of the frequency and gain menu.




5) Navigate to the "Calibrate Noise Thresholds" menu. (Note: The *background* of the calibrate function is now highlighted in black.)



(continued...)


- 6) Press the Go button. The detector immediately starts measuring (calibrating) the background *X* and *R* noise thresholds, and the monitor screen (below) presents a bar graph of the progress of the calibration process. The calibration takes roughly 20 seconds to complete.



When finished, the monitor screen disappears and the “Calibrate Noise Threshold” menu (shown in step 5) reappears. The screen now displays the calibrated (measured) values for the *X* and *R* noise thresholds and, because these are *background* values, the numbers should be low. If the numbers are high, it may be difficult to detect small metal contaminants over the background noise.

- *Reducing High X Noise Thresholds*
An *X*-threshold in excess of 1,000 usually indicates there is a problem with excessive vibration in your application. As a general rule, as the severity of the vibration increases, the *X*-threshold also increases. Possible remedies include making sure the detector is completely isolated mechanically from the surrounding chute, and/or installing shock mounts for the detector.
- *Reducing High R Noise Thresholds*
An *R*-threshold in excess of 200 usually indicates that one (or more) of the following conditions is present.
 - Excessive noise from electro-magnetic currents (EMCs) and variable frequency drives (VFDs). Rectify by installing an isolation transformer and/or line reactors.
 - Metal in the detector’s metal-free zone. Rectify by removing the metal.


- 7) If you want to manually key in a different value for either the *X* or *R* noise threshold, make sure the “Calibrate Noise Thresholds” menu (shown in step 5) is displayed. Navigate to the appropriate menu (*X* or *R*) and press the Go button. An input screen appears, allowing you to manually enter a value.



Choosing the Correct Speed-Filter Settings for the Rx


For the Rx, the default speed-filter setting is the wide-band speed filter #2 (medium), which works well for most Rx applications where products flow at a medium angle of 35°.

- *Speed filter #2—Medium (the default Rx setting)*
This is used typically for products flowing at a medium angle (35°).




However, if you have products flowing at other standard angles (25° or 45°), you should use a different speed filter, as shown below.

- *Speed filter #1—Slow*
This is used typically for products flowing at a shallow angle (25°)



- *Speed filter #3—Fast*
This is used typically for products flowing at a steep angle (45°).



- *Custom speed*
This setting is used when your product is flowing through the chute either very fast or very slowly, or because you are using a non-standard angle (that is, an angle different from the standard angles of 25°, 35°, and 45°). For help setting up a custom speed-filter setting, please contact Thermo Fisher Scientific—as described in the “Contacting Thermo Fisher Scientific” section at the end of the manual.

Establishing Basic Product Parameters


Before putting your detector into service, you must have it learn how to identify your uncontaminated product. This is done using the detector’s full-product calibration function, which sets the following basic parameters for your product.

- Phase-angle setting
- Detect level


Doing a Full-Product Calibration

To do a full-product calibration, follow the instructions below.


- 1) Make sure product is falling through the chute.
- 2) Highlight your product name in the Main Menu.



- 3) Press the Go button and page 1 of the product menu appears.



4) Press the right-navigation button to highlight the “Full Product Calibration” menu.



The detector's auto-calibration function (as shown by the symbols and check marks in the screen above) is now ready to do the following.

- Learn the phase angle




- Learn the detect level



- Conduct an AuditCheck, if this optional hardware is installed on your APEX.




5) Press the Go button and the “Performing Full Learn” monitor screen appears.



(continued...)

- 6) When the auto-calibration function is finished, the detector displays the Main Menu screen, which should now look something like this.



Notice that, in our example, the auto-calibration function has learned the following basic parameters for our uncontaminated product.

- Detect level  = 64
- Phase angle  = 91.23

What the Main Menu Screen Is Telling You

The Main Menu screen is now telling you that, once the detector is monitoring your product stream, any contaminated product that exceeds the detect level of 64, will be rejected. And, because the phase angle is 91.23 degrees, the detector is monitoring a dry product.

Set-Up Check List for Pharmaceutical Applications

This section lists the parameters you have already set (by following the instructions from the start of the “Setting Up Pharmaceutical Applications” section up to this point in the manual). This section also lists additional parameters you may want to set up to get your particular pharmaceutical application running to your satisfaction.

Parameters You Have Already Set Up

Listed below are the parameters you have already set up for a typical pharmaceutical application.

Product Parameters

- Product name

Reject Parameters

- Reject-delay time
- Reject-duration time

Contaminant-Detection Parameters (Set by the Detector’s Calibrate Functions)

- X and R noise thresholds
- Speed-filter setting
- Detect level
- Phase-angle setting

Additional Parameters You May Want to Set Up

Listed below are additional parameters you may want to set up to get your particular pharmaceutical application running to your satisfaction.

Reject-Confirm Function

If your gate is equipped with a position detector, this function allows the detector to confirm that, during a reject cycle, the gate has properly completed both the “open” and “close” phases of the reject cycle. In addition, if a gate failure occurs, the detector can stop the flow of product, or notify you that a gate failure has occurred—for example, because the air supply to the gate has failed, or product has built up on the gate or surrounding duct-work. For more details, see page 137.

Warnings, Alarms, and Faults (WAFs)

Many of the detector’s functions provide a warning, alarm, or fault when a condition needing your attention occurs. This menu—in conjunction with the appropriate hardwired external device—allows this to happen. For more details, see page 214.

Copying and Pasting Product Parameters

This function is particularly useful when you are testing multiple products. You can save considerable amounts of time and effort using the copy and paste functions, because you do not need to re-enter the product parameters for each product, re-run the calibrations, and so on. For more details, see page 173.

APEX Menu Structure


The following pages provide a summary of the detector's complete menu structure, using screen shots as a visual guide. The screen shots are listed in the order in which they appear in the detector's menus and sub-menus. If you encounter any unfamiliar terms in this section, please refer to the Glossary on page 393 for an explanation.

Main Menu—Page 1

This is the starting point from which all the detector's menus and functions are accessed.


Product Name

See page 24.



Product Speed

See page 27.



Reject-Totals Menu

The reject-totals menu allows you to assess at a glance, how many products have been screened and how many rejects of all kinds (P+A+Q) have been made. In addition, the reject-total function tells you how many rejects have been made in the following three categories. (You may not be using the Quality Test and AuditCheck options, especially if you are running a gravity-feed or pipeline application.)

- Number of contaminated products (P) rejected by the detector.
- Number of rejects (A) made by the AuditCheck function.
- Number of rejects (Q) made by the Quality Test function.

Reject Totals					
P001			001		
→→	30.5	0/0	40	90.00	3
0	X	X			

Understanding the Reject-Totals Menu

The icons shown in this menu are as follows. (Note: The Xs show that both the AuditCheck and Quality Test functions are disabled. In a real application, where the AuditCheck and Quality Test functions have been enabled, the Xs shown here are replaced by numbers—representing the number of rejects.)



Number of contaminated products (P) rejected by the detector.



Number of rejects (A) made by the AuditCheck function.



Top-left-side number = Total number of rejects (P+A+Q).




Top-right-side number = Total number of products assessed.



Bottom number = Number of rejects (Q) made by the Quality Test function.

Detect Level

The detect-level function is part of the Main Menu, as shown below. (Your screen will look different if IXR is enabled.)



Overview of the Detect-Level Function

The detect level can be set in two ways: using the detector's auto-calibration function or by keying in a value. During the auto-calibration procedure, the detector first monitors the background noise level and assigns it a value, say 15. Then, after you have passed a test sample of contaminated product three times through the search head, the detector sets the minimum detect level to 2–3 times the background level. In our example, the detector has assigned a value of 40 to the detect level. As a result, any product that gives a reading in excess of 40—the detect level—will be rejected.

In summary, by keying in values for the detect level, you can fine-tune which products are rejected. For example, if the contaminant signal is strong and the background noise varies widely during the working day in your particular operating environment, you may see a number of *false* rejects. You could remedy this situation by keying in a larger value for the detect level (for example, 100).


Setting the Detect Level

The detect level can be set using the detector's auto-calibration function or by keying in a value.

- If you want the auto-calibration function to set the detect level, see page 55 (conveyor), page 73 (gravity-feed), page 90 (pipeline), or page 105 (Rx).
- If you want to key in a value for the detect level, make sure the detect level function is highlighted (as shown above). Press the Go button and an input screen appears. Key in a value for detect level. Press the Back button to save your setting and exit the menu.


Phase-Angle Menu

See page 150.



Peak Signal

The peak-signal function is a display function, meaning there are no parameters you can set for it. In other words, the peak-signal function acts purely as a gauge, and displays the highest signal seen by the search head since this function was last reset. In our example, the peak signal reading is 3, and is the highest signal produced by a series of contaminated products that passed through the search head since it was last reset.



The peak-signal value can be reset in the following ways.

- If photo registration is enabled, the peak-signal value will automatically reset before each pack enters the search head or when each pack crosses the photo-eye.
- Pressing the Go button, while the peak-signal icon is highlighted, will reset the peak-signal value.


Uses of the Peak-Signal Function

The peak-signal function can be used to do the following.

- Establish the level of background noise over an entire day, week, or other extended time period.
- Monitor the maximum signal produced by contaminants during a specified time period—for example, the morning shift, a 24-hour day, a week, and so on.
- Monitor the long-term trends in the detector's signal-to-noise ratio.


Frequency and Gain Menu

See page 160.




System and Tools Menu

See page 168.



Security Menu


See page 249.




Main Sub-Menu—Page 1

Page 1 of the Main Menu allows you to do a full product calibration and give the product you are testing a name.

- 1) Start at the Main Menu.




- 2) Press the Go button and navigate to page 1 of the detector's main sub-menu.



Starting a Complete Product Calibration


For more information about doing a full product calibration, see the relevant section for your particular application.

- Conveyor applications—see page 55.
- Gravity-feed applications—see page 73.
- Pipeline applications—see page 90.
- Pharmaceutical applications—see page 105.




Editing the Product Name

See page 24.




Main Sub-Menu—Page 2

1) Start at the Main Menu.








2) Press the Go button.

3) Navigate to page 2 of the detector's main sub-menu.








Setting the Pack Length

See page 35. (This is used only in conveyor applications with a product photo eye, and in pharmaceutical applications.)

Pack Length	
P001	001
	 0.100m
	 100%
2/2	 0.100m






Setting the Pack Gap

See page 40. (This is used only in conveyor applications with a product photo eye, and in pharmaceutical applications.)

Pack Gap	
P001	001
	 0.100m
	 100%
2/2	 0.100m

Setting the No-Pack Distance

See page 37. (This is used only in conveyor applications with a product photo eye, and in pharmaceutical applications.)

Detection no-Pack distance	
P001	001
	 0.100m
	 100%
2/2	 0.100m

Rejects Menu—Page 1

1) From the Main Menu, navigate the rejects menu.

Reject Totals			
P001			001
↔	30.5	40	
0/0		90.00	
0			3

2) Press the Go button and page 1 of the rejects menu appears.

Reject 1 Distance and Duration			
P001			001
0/0		0/0?	
1	0.300m	m→s	×
1/6	1.50s		×

Resetting the Counts for Reject 1

The appearance of the reject-counts menu depends on whether you are using a photo eye (PE) to control the reject process. As a general rule, conveyor applications use photo eyes to control the reject process (PE enabled), but gravity-feed, pipeline, and pharmaceutical applications do not (PE disabled). Please refer to the appropriated section listed below.


Resetting the Counts with the PE Enabled

See page 119. (This function is used only in conveyor applications with a product photo eye.)

Reject Counts Reset			
P001			001
0/0		0/0?	
1	0.300m	m→s	×
1/6	1.50s		×

Resetting the Counts with the PE Disabled


This function allows you to reset the current reject count to zero. Note: When you reset the reject count in this menu, the reject count in the Main Menu is also reset to zero.



- 1) Make sure the reset menu is highlighted.
- 2) Press the Go button and the counts are reset.


Setting the Distance to the Reject-1 Device

See page 44.




Changing the Units of Measure

See the small screen shot at the top of page 45 and the text at the bottom of page 44.



Setting the Signal Duration for the Reject-1 Device

See page 46.



Displaying the Number of Quality Test Rejects

This display function shows the number of rejects made by the Quality Test function. (Note: In a real application, when the Quality Test function has been enabled, the X shown below is replaced by a number.)

To learn more about the Quality Test function, see page 196.

Quality Test Rejects				
P001		001		
0/0	0/0	0/0 → 0/0?		
1	0.300m	m→s	000	X
1/6	1.50s		00	X

Displaying the Number of AuditCheck Rejects


This display function shows the number of rejects made the AuditCheck function. (Note: In a real application, when the AuditCheck function has been enabled, the X shown below is replaced by a number.)

To learn more about the AuditCheck function, see page 206.


AuditCheck Rejects				
P001		001		
0/0	0/0	0/0 → 0/0?		
1	0.300m	m→s	000	X
1/6	1.50s		00	X

Rejects Menu—Page 2


1) From the Main Menu, navigate to the rejects menu.



2) Press the Go button and page 1 of the rejects menu appears.




3) Navigate to page 2.




Setting the Type of Photo Registration Used

See page 32. (This function is used only in conveyor applications with a product photo eye.)



Setting the Latching-Reject Function (Reject 1)

This function can only be used to latch your reject-1 device. The default setting for the latching-reject function is "off," as shown by the X next to the padlock icon in the screen below.




Example of Using the Latching-Reject Function

The latching-reject function is normally used only in conveyor applications, where shop-floor personnel are responsible for manually removing contaminated product from the conveyor. When contaminants are detected, the detector sends a signal, which remains *on* ("latched") until manually reset. The output signal to the conveyor or buzzer remains latched on, until manually reset by the operator.

Enabling the Latching-Reject Function

To enable the latching-reject function, do the following.


- 1) Make sure the latching-reject function is highlighted, as shown above.
- 2) Press the Go button and a check mark appears. The latching-reject function is now active.



- 3) Press the Back button to exit the function.

Resetting the Latching-Reject Function


- 1) When the latching-reject function is enabled and the APEX detects a contaminated unit of product that must be manually removed from the conveyor, the following screen appears in the detector's display panel.



- 2) Remove the contaminated product from the conveyor.
- 3) Clear the warning screen by pressing the Go button. The detector is now ready to start analyzing your products.

Inverting the Reject Function (Reject 1)

In most APEX set-ups, products are rejected whenever metal is detected. The inverting-reject function, however, allows you to reject a product whenever metal is *not* detected. You must have a photo eye installed for this function to work.




Example

Imagine you are a breakfast-cereal manufacturer running a conveyor application, and every packet of cereal must go out containing a small plastic children's toy. The toy manufacturer has hidden a small strip of (child-safe, non-toxic) metal inside each toy, allowing you to set the inverting-reject function, so that packets of cereal *not* containing metal are rejected. (In this example, as a precaution, the packets of cereal were tested for the presence of metallic contaminants immediately up-stream, that is, just before the toy was added to the product.)

Setting the Inverting-Reject Function

To enable the inverting-reject function, do the following.


- 1) Make sure the inverting-reject function is highlighted, as shown above.
- 2) Press the Go button and a check mark appears. The inverting-reject function is now active.



- 3) Press the Back button to exit the function.

Calibrating the Speed-Encoder Function

This function is used only in conveyor applications. A speed encoder must be attached to your conveyor and hardwired to the detector. In addition, the detector's speed-encoder function must be calibrated.



Advantages of Using the Speed-Encoder Function

There are many advantages of enabling the speed-encoder function. First, whenever you change conveyor speed, the detector automatically displays the correct, updated product speed in the main menu. Second, any other detector parameters that rely on product speed—such as reject delay, reject duration, and speed filtering—are automatically recalibrated to account for the change in product speed. This is particularly useful if you monitor multiple products at different product speeds, or inspect other products by manually passing them through the search head. Thus, you can monitor Product 1 with the speed-encoder parameter enabled, and Product 2 with the parameter disabled. The speed-encoder function is a product-specific parameter.

Overview of Set Up

Some conveyor systems, especially those that can be set to run at variable speeds, have a built-in speed encoder. A typical speed encoder is constructed using a disk-shaped gear with teeth around the periphery, and is attached to a roller on the conveyor. The teeth of the gear pass in front of a photo eye, giving a square signal (as shown in the figure below) whose frequency is proportional to the speed of the conveyor. In a typical conveyor set up, the signal from the speed encoder is hard wired to Input 1 on the detector's wiring board. Input 1 on the APEX is the dedicated physical input for the speed-encoder signal. For wiring details, see page 289.

In order for the speed-encoder function to work optimally, the speed-encoder gear should be large and have a large number of teeth, so that the maximum conveyor speed produces a signal of at least 500 Hz but no greater than 2,000 Hz. In addition, any signal from the speed encoder should not fluctuate or have missing pulses. A nice steady signal is required. A fluctuating signal will cause large changes in the speed display and will adversely affect all speed-related parameters.

Acceptable Values for Inputs from the Speed-Encoder

The following table shows the resolution at the calibrated frequency.


Frequency (Hz)	Resolution (f/m)
50 / 55	98.4–108.3
100 / 105	98.4–103.3
200 / 205	99.7–102.2
500 / 505	99.9–100.9
750 / 755	99.9–100.6
1000 / 1005	99.9–100.4
1500 / 1505	99.8–100.2
2000 / 2005	99.8–100.1

f/m = feet per minute


Calibrating the Speed-Encoder Function

You must calibrate the speed-encoder function before you can use it.


- 1) Turn on the conveyor and set the belt speed to maximum. Use a tachometer to record the speed.
- 2) Go to the product-speed function in the Main Menu, as described on page 27, and key in the reading for maximum belt speed. (We keyed in 100 feet per minute.)




- 3) Navigate (as described in the above sections) to the speed-encoder function, and make sure the speed-encoder function is highlighted, as shown below.



- 4) Press the Go button, and the monitor screen (below) shows a bar graph of the progress of the calibration process. During the calibration, the detector's speed-encoder function automatically matches the pulses from the conveyor's speed encoder to the speed you entered in the product-speed function.




- 5) When the calibration is completed, the detector displays the following screen. (The value shown in your screen, however, may be different.)



- 6) Press the Back button repeatedly to return to the Main Menu.


- 7) Notice that now, when you vary the speed of the conveyor, the speed changes are automatically registered by product-speed function. (Ours is set to 50 fpm.)



Understanding the Photo-Queue Pack Count


This display function is used only in conveyor applications. The photo-eye queue-pack function displays the number of packs between the photo-eye and the reject device. This function is used when your reject device is located a long way downstream of your photo eye.

This menu is useful because it shows the number of individual units of product between the photo eye and your reject device. This allows you to verify that the photo eye is working properly. For example, when product passes the photo eye, the queue-size increases and, as product passes the reject device, the queue-size decreases.




Rejects Menu—Page 3


1) From the Main Menu, navigate to the rejects menu.



2) Press the Go button and page 1 of the rejects menu appears.



3) Navigate to page 3.




Suppressing Rejection Using an External Trigger (Reject 1)


When the suppress-rejection function is enabled, you can *manually* suppress the reject device. This is useful when you are conducting a Quality Test or other manual test of the detector's ability to detect contamination. For this function to work, you must do *both* of the following.

- Hardwire the button or other triggering device to one of the inputs (Input 3–6) on the detector's wiring board (the physical set-up), see page 289.
- Tell the detector which input is being used (the logical set-up). For more information, about assigning inputs and logical set-up procedures, see page 222.

1) Make sure the suppression external trigger menu is highlighted.




2) Press the Go button and a check mark appears. The suppress-rejection external trigger function is now enabled.



3) Press the Back button to exit the menu.

Activating Reject Suppression (Reject 1)

See page 131. (This function is normally used only in gravity-feed and pipeline applications.)



Understanding Reject Suppression (Reject 1)

This function is normally used only in gravity-feed and pipeline applications. Before you can set parameters for the reject-suppression function, you must first *activate* the detector's suppression capabilities. To help you understand why suppression is useful and how it works, here is some theory and a real-world example of the suppression function in action.

Theory Behind the Amplitude-Suppression Function

In a typical gravity-feed or pipeline application that diverts contaminated product for only one second and where vibration resulting from gate opening and closing lasts for three seconds, there is a two-second window where product continues to flow, but where product may be erroneously tagged by the detector as contaminated. This, clearly, is undesirable for a number of reasons: first, the product now flowing is *not* (in all likelihood) contaminated; and second, allowing the vibration signal to affect the detector would produce a fatal feed-back loop. This problem is resolved by suppressing the vibration signal just enough to prevent the detector from interpreting the vibration signal as contamination.

For example, if you apply an amplitude-suppression value of 75% to the vibration-plus-product signal from the search head, 75% of the signal goes to the detector's circuits for evaluation (meaning the signal is analyzed to see whether it looks like a contaminated product is currently passing through the search head). In this example, by a process of trial and error (by starting at 100% and working down in 5% increments), we have discovered that 75% amplitude suppression prevents vibration being tagged as contamination.


Example of How Gate Vibration Can Affect the Search Head

Let's look at an example. (Looking at the figure on page 304 will help you understand the explanation that follows). A milling company is monitoring the inflow of grain from their suppliers. The grain falls down a duct under the influence of gravity and passes through the search head, which surrounds the duct. Whenever contamination is detected, a gate immediately downstream of the detector slams closed in 50 milliseconds, diverting the contaminated product to the reject bin. After one second, the gate slams open in 50 milliseconds, allowing the product to again flow normally. Unfortunately, the vibration in the duct caused by the gate slamming open and closed is communicated to the search head, which interprets the vibration as the passage of contaminated product. To prevent this occurring, any reject signal from the detector is suppressed for a period of time—in our example, 3.0 seconds—after contamination is first detected.


Activating Reject Suppression (Reject 1)

This function is normally used only in gravity-feed and pipeline applications. To activate—or trigger—the reject-suppression process, do the following.


- 1) From the Main Menu navigate to the rejects menu.




- 2) Press the Go button and page 1 of the rejects menu appears.



- 3) Navigate to page 3 of the rejects menu.




- 4) Navigate to the reject-trigger function.




(continued...)

- 5) Make sure the reject-trigger function is highlighted and press the Go button. The X changes to a check mark.



Setting Suppression Time (Reject 1)


This function is normally used only in gravity-feed and pipeline applications, and allows you to prevent vibration from the gate that diverts contaminated product from interfering with the search head.




Keying In a Value for the Suppression-Time Function

To enable the suppression-time function, do the following.

- 1) From the Main Menu navigate to the rejects menu.




- 2) Press the Go button and page 1 of the rejects menu appears.




(continued...)


3) Press the down-navigation button twice and page 3 of the rejects menu appears.



4) Navigate to the suppression-time menu.




5) Press the Go button and an input screen appears. Key in the desired suppression time (in seconds and hundredths of a second). In our example, we accepted the current suppression time of 3.00 seconds.



6) Press the Go button to save your setting and exit the menu.

Setting Amplitude Suppression (Reject 1)


This function is normally used only in gravity-feed and pipeline applications, and is used in conjunction with the suppression-time function described above. The amplitude-suppression function is used to tell the detector how much amplitude suppression to apply to the vibration signal affecting the search head. This is important because vibrations generate a vibration signal in the search head, and these may have the same characteristics as a contaminated product signal. As a result, the detector may interpret vibration as contamination.




Keying In a Value for Amplitude Suppression

To key in a value for amplitude suppression, do the following.

- 1) Follow steps 1–3 in the section above to get to page 3 of the rejects menu.




- 2) Navigate to the amplitude-suppression function and make sure it is highlighted.




(continued...)

- 3) Press the Go button and an input screen appears (showing the default value of 100%).




- 4) Key in a value (in percent) for amplitude suppression. Start at 95% and test the detector's response to the gate's vibration in your particular operating environment. If needed, reduce in the value in increments of 5% until the appropriate value is determined. (In the example below, we settled on a value of 75% after several tests under normal operating conditions at our facility.)




- 5) Press the Go button to save your setting and exit the menu.

Rejects Menu—Page 4


1) From the Main Menu, navigate to the rejects menu.



2) Press the Go button and page 1 of the rejects menu appears.



3) Navigate to page 4.



Calibrating Reject-Confirm Times

This calibration menu has two sub-functions—the “Reject-1 Confirm Sensor” function and the “Reject-1 Complete Sensor” function. Both are currently disabled, as shown by the X across the eye icons in the screens below. In addition, each sub-function is used only by a particular type of application.

- *Reject-1 Confirm Sensor*
The default values for “reject-1 confirm sensor” function looks like this.



- *Reject-1 Complete Sensor*
The default values for “reject-1 complete sensor” function looks like this.



What the Confirm Functions Do


In conveyor applications, the “reject-1 confirm sensor” function confirms that rejected product has, indeed, gone into the reject bin. In gravity-feed and pipeline applications, the “reject-1 confirm sensor” and the “reject-1 complete sensor” functions confirm that the gate (which diverts contaminated product into the reject bin) has both opened and closed.

Calibrating the Two (Confirm/Complete) Reject-1 Sensor Functions

The calibrate menu allows you to calibrate the reject-confirmation process by passing a contaminated test product through the search head and having it rejected. For these functions to work, you must 1) place a photo eye at the mouth of the reject bin (for conveyor applications), or 2) have a gate-open and gate-closed sensor installed on the reject gate (for gravity-feed, pipeline, and pharmaceutical applications). In addition, the photo eye or gate-open and gate-closed sensor must be hard wired to the detector’s input wiring board. The auto calibration, however, works whether you have one or two reject-confirmation sensors active.

To calibrate the reject-confirmation process, do the following.

- 1) Make sure the calibration menu is highlighted.



2) Press the Go button and the following screen appears.



3) Pass a contaminated test product. The reject-confirm process will be calibrated as soon as the package is rejected and activates the reject-confirmation sensor or sensors.


Reject Timing Is Application-Specific

Please refer to the two options that follow, and chose the function that is appropriate to your particular conveyor, gravity-feed, pipeline, or pharmaceutical application.

Manually Setting the Timing for a Reject-1 Confirm

This function (the single-reject-confirmation function) is used to confirm that a reject has, indeed, taken place. For this function to work in conveyor applications, you must place a photo eye at the mouth of the reject bin. For this function to work in gravity-feed, pipeline, and pharmaceutical applications, you must 1) have a sensor installed on the reject gate, and 2) hardwire the sensor to Input 3 on the detector's wiring board.


More specifically, this function allows you to fine tune the reject-confirmation time by keying in a time (a time window) in which the reject must occur and, thus, be confirmed. If a reject does *not* occur within this time window, the detector issues a warning, alarm, or fault that notifies you an error has occurred during the reject process.



1) Make sure the reject-confirm function is highlighted, as shown above.

(continued...)

- 2) Press the Go button and an input screen appears.




- 3) Key in an appropriate time window (in seconds and hundredths of a second) in which the reject must occur. Typically the calibration function will set the appropriate value and no manual adjustment is necessary.
- 4) Press the Go button to save your setting and exit the menu.

Manually Setting the Timing for a Reject-1 Complete

This function is normally used in gravity-feed and pipeline applications, and is used to confirm that the gate (the reject device) has properly completed both phases (the “open” and “closed” phases) of the reject cycle. This capability is useful because it allows you to hardwire the detector to shut down the flow of product, and alert you when a gate failure occurs—for example, because the air-supply to the gate has failed or the gate has stuck half-way open, which may occur when product builds up on the gate or the surrounding duct work.

This function allows you to fine tune the reject-confirmation time by keying in a time (a time window) in which the reject must occur and, thus, be confirmed. If a reject does *not* occur within this time window, the detector issues a warning, alarm, or fault that notifies you an error has occurred during the reject process.



A Gate-Open and Gate-Closed Detector Must Be Installed


For this function to work, you must have a gate-open and gate-closed detector installed on the gate (or diverter valve), and this must be hardwired to the detector. The gate detector works by confirming that the gate is indeed in one of two positions—the open or closed position (not stuck halfway open or closed). During a normal reject cycle, the gate first opens, then closes—actions that the reject-complete function verifies has occurred. However, if the gate gets stuck half-way open or closed during the reject

cycle, the reject will *not* be confirmed, and the flow of product can be stopped and an alarm triggered notifying you of the problem.

Keying In a Value for the Reject 1 Complete

To enable the “reject-1 complete” function for gravity-feed, pipeline, and pharmaceutical applications, do as follows.

- 1) Make sure that your “reject-1 confirm” and “reject-1 complete” inputs have been enabled and the sensors hardwired to the appropriate input on the detector’s wiring board.
- 2) Make sure the “reject-1 confirm” function is highlighted (as shown above).
- 3) Press the Go button and an input screen appears.




- 4) Key in an appropriate time window (in seconds and hundredths of a second) in which the reject must occur. Typically the calibration function will set the appropriate value and no manual adjustment is necessary.
- 5) Press the Go button to save your setting and exit the menu.


Rejects Menu—Page 5

Page 5 of the rejects menu is used to set up parameters for your reject-2 device. Please note, however, that the photo-registration function cannot be used with a reject-2 device.


- 1) From the Main Menu, navigate to the rejects menu.



- 2) Press the Go button and page 1 of the rejects menu appears.



- 3) Navigate to page 5.




Keying In the Distance to the Reject-2 Device

There are two parts to this menu, as shown below.


Part 1—Keying In the Distance or Delay

This is set up in exactly the same way as the reject-1 device. See page 44.




Part 2—Setting the Units of Measure

This is set up in exactly the same way as the reject-1 device. See the small screen shot at the top of page 45 and the text at the bottom of page 44.



Keying In the Signal Duration for the Reject-2 Device

This is set up in exactly the same way as the reject-1 device. See page 46.




Assigning Tasks to the Reject-2 Device

This function makes your reject-2 device responsible for the following tasks.

- Rejecting contaminated products.
- AuditCheck rejects.
- Quality Test rejects.

Note: You must previously have enabled the AuditCheck and Quality Test functions for these functions to be accessible in this menu.



Understanding the Reject-2 Icons

Currently the reject-2 device is *not* responsible for product, AuditCheck, or Quality Test rejects—as shown by the X against the appropriate icon.



Product rejects (currently not enabled for the reject-2 device)



AuditCheck rejects (currently not enabled for the reject-2 device)



Quality Test rejects (currently not enabled for the reject-2 device)

Enabling Product Rejects Using the Reject-2 Device

To enable product rejects using the reject-2 device, do the following.


- 1) Make sure the reject-2 function is highlighted, as shown above.
- 2) Press the Go button to change the X into a check mark.
- 3) Press the Back button to activate your reject-2 device and exit the menu.

Enabling AuditCheck and Quality Test Rejects Using the Reject-2 Device

For more details, see the AuditCheck section (page 206) and the Quality Test section (page 196).


Setting the Latching-Reject Function for Reject 2

This is set up in exactly the same way as the reject-1 device. See page 122.



Inverting the Reject Function for Reject 2


This is set up in exactly the same way as the reject-1 device. See page 123.



Rejects Menu—Page 6

This menu allows you to set up a time (a time interval, in seconds) during which a package rejected by your reject-2 device must pass the photo eye monitoring your reject-2 bin, allowing the reject to be confirmed. Thus, in order for this function to work you must do the following.

- Make sure that your reject-2 device is *downstream* of your reject-1 device. In a typical conveyor application, this means the reject-1 device is used to reject contaminated packages and the reject-2 device is used for AuditCheck and/or OAT rejects.
- Set up a photo eye to monitor packages entering the reject-2 bin.
- Physically attach the photo eye to one of the detector's input terminals (Inputs 1–6). For detailed instructions on doing this, see the "Inputs" section of the manual.
- Tell the APEX which Input (1–6) is being used (that is, make the logical assignment) and set up the appropriate polarity for the signal from the reject-2 photo eye. For detailed instructions on doing this, see the "Inputs" section of the manual. The example below shows that we have assigned our reject-2 photo eye to Input 5 with a positive polarity.




- Enter a reject-confirm time for your reject-2 device. (Described below.)
- Calibrate the system. (Described below.)

Entering a Reject-Confirm Time for the Reject-2 Device


To enter a reject-confirm time for your reject-2 device, do the following.

- 1) From the Main Menu, navigate to the rejects menu.




(continued...)


2) Press the Go button and page 1 of the rejects menu appears.




3) Navigate to page 6.



4) Navigate to the "Reject 2 Confirm Time" function and make sure it is highlighted.



5) Press the Go button and an input screen appears. Enter the appropriate time interval. In the example below, we entered 0.5 seconds.




6) Press the Go button to save your setting and exit the menu.

Calibrating the Reject-2 Confirm Time


In order to calibrate the reject 2 confirm time, that is, have the APEX set the appropriate time for you, you must do the following.

- Turn off your reject-1 device by going to the Outputs menu and setting the logically assigned value to *X* (off), as shown below. For detailed instructions on doing this, see the “Output” section of the manual.

So, change the reject-1 output from this:



To this:




- Set your reject-2 device to reject contaminants during the calibration process. (Described below.)
- Pass a contaminated package, so the reject-2 device can reject it, allowing the APEX to set the reject-2 confirm time. (Described below.)
- Turn your reject-1 device back on, which is a *critical* step! (Described below.)

Calibration Procedure


To calibrate the reject-2 confirm time, do the following.

- 1) Navigate to page 5 of the rejects menu, and highlight the “Reject 2 Contaminant” menu.




(continued...)

- 2) Press the Go button, and a checkmark appears next to the contaminant icon, which tells the reject-2 device to reject any contaminated packages.



- 3) Press the Back button to save your setting and exit the menu.
- 4) Navigate to page 6 of the rejects menu and make sure the calibration function is highlighted.











- 5) Press the Go button, and the following screen appears.



- 6) Pass a contaminated package, so the reject-2 device can reject it, allowing the APEX to set the reject-2 confirm time. When the calibration is complete the APEX closes this screen and displays the appropriate reject-2 confirm time.

(continued...)

- 7) Reactivate your reject-1 device by going to the Outputs menu and assigning Output 1 to your reject-1 device, as shown below. For detailed instructions on doing this, see the “Output” section of the manual.

Output 1 Function						
	+1	+2	+3	+4	+5	+6
						

Troubleshooting Procedure Should the Calibration Fail

If you see the following warning screen during the reject-2 confirm-time calibration procedure, check the following.



- If this warning screen appears *before* you pass a contaminated package, check the polarity of the reject-2 confirmation input. The reject confirmation can only be learned, if the input is not active until the reject-2 device fires.

For example, if the reject-2 confirm input is set to –3, the voltage on the input *cannot* be zero volts until after the reject-2 device has fired.

- So, change the polarity, highlight the reject-2 confirm-time calibrate icon, then press the Go button to redo the calibration.

Phase Angle—Page 1


For a brief overview of what phase-angle is and its importance to the art and science of metal detection, see page 278. As a general rule, the following phase angles are representative of the following types of contaminants and non-contaminated products.

Degrees	Contaminant or non-contaminated product
+ 130	Metallic (ferrous) conductive contaminants, such as iron.
+ 90	Dry, non-conductive products, such as cereals and grains.
+ 65	Non-ferrous metallic contaminants, such as brass and aluminum.
+ 20–30	Metallic contaminants, such as 300-series stainless steel.
0	Wet, conductive products, such as fresh meats and breads.


Accessing the Phase Angle Menu

To access the phase-angle menu, do the following.

- 1) From the Main Menu, use the navigation buttons to select the phase-angle menu.



- 2) Press the Go button and page 1 of the phase-angle menu appears.



Calibrating the Phase-Angle Setting

The phase angle (and detect level and AuditCheck settings) of the product is learned by the detector during its auto-calibration procedure. For auto-calibration procedures for your specific application, consult the list below.


- Conveyor applications—see page 55.
- Gravity-feed applications—see page 73.
- Pipeline applications—see page 90.
- Pharmaceutical applications—see page 105.

Recalibrating the Phase Angle


This calibration menu allows you to recalibrate the phase angle setting by running product through the search head.

To recalibrate the phase angle, do the following

- 1) Make sure the calibration function is highlighted.




- 2) Press the Go button and a calibrate monitoring screen appears.



- 3) Pass the product through the search head. When the green indicator light in the control panel flashes or stays on, the phase-angle setting in the screen above has been updated.

Locking the Phase-Angle Setting


This function is used during the recalibration process described above, and is used to lock the phase angle setting so it is *not* relearned during the auto-calibration process. This is useful when you have already established the appropriate phase-angle setting for your application, but are interested in recalibrating *only* the detect level or AuditCheck setting.



Locking the Phase-Angle Setting

To lock the phase-angle setting, do the following.










- 1) Make sure the padlock icon is highlighted.
- 2) Press the Go button and the X changes to a check mark—indicating the phase-angle setting is now locked.



- 3) Press the Back button to exit the menu.

Enabling the Detector's Phase-Tracking Function

The phase-tracking function allows the detector to account for the small changes ("drift") that occur in phase angle during a daily (or other long) production run.

Phase Tracking			
P001		001	
	CAL →	 90.00°	 X
			 0.30°
1/2	X		 10.00°

Thermal Variations in the Product Can Affect Phase Angle

For example, when testing a hot, wet product, such as jars of spaghetti sauce moving along a conveyor, the temperature of the product as it reaches the search head can affect the phase angle. In many production environments, the ambient temperature of the building changes throughout the day—for example, by becoming hotter in the afternoon as the sun heats the sides and roof of the building. This, in turn, causes the air temperature in the building to rise and the rate of cooling of the product to decrease during the afternoon. Thus, product entering the search head will be cooler in the morning and warmer in the afternoon, and this gradual change in temperature throughout the day can cause the phase angle to gradually change, or drift, during the daily production runs.

How Phase Tracking Works


By enabling phase tracking, the detector allows the phase-tracking setting to drift over time, as long as the phase-angle setting stays within certain predetermined limits—and these limits can be either the default limits or the user-defined limits you have keyed in.

The detector tracks the drift in phase angle over time by keeping a running average of the phase angles recorded since the last reset, and comparing the most-recent phase-angle value against this running average. If the new value falls within the prescribed limits (the default or user-defined "acceptable change" limit), it accepts the value and updates the running average. However, if the running average exceeds the phase-tracking fault limits, the detector notifies you a fault has occurred.


Enabling Phase Tracking

To enable phase tracking, do the following.

- 1) Highlight the phase-tracking function.



- 2) Press the Go button and a check mark appears, verifying phase tracking is now enabled.




- 3) To set "acceptable change" and "unacceptable change" limits for the phase-tracking function, see the next two sections.

Setting Acceptable Limits for Phase Tracking

For this function to work, you must already have enabled phase tracking.


When the “acceptable limit for phase tracking” function has been set, as each package passes through the search head, the package’s phase angle is measured and then compared with the current running average for phase angle. Then, assuming that the phase angle measurement for the package does *not* exceed the current running average by ± 0.30 degrees (the limit, in the screen below, for an *acceptable* change), this package is passed as showing an “acceptable change” for phase angle, and the running average updated (that is, before the next package enters the search head).

For example, if the current running average is 89.78 degrees and the limit for an “acceptable change” is ± 0.30 degrees, the phase angle of the next package passing through the search head *must* fall in the range 89.48–90.08 degrees to be accepted and the running average updated.



To set a limit for an “acceptable change” in phase angle, do the following.


- 1) Highlight the “acceptable change” menu shown above.
- 2) Press the Go button and an input screen appears.



- 3) Key in your new setting for an acceptable change in phase angle (in degrees and hundredths of a degree).
- 4) Press the Go button to save your setting and exit the menu.

Setting Limits for a Phase-Tracking Fault Notification

Use this menu to have the detector give you a fault notification when the phase angle of the product exceeds the default or user-defined “unacceptable change” notification limit.




In the example above, the current phase-angle setting is 90 degrees and the “unacceptable change” notification limit is a change in phase angle plus or minus 10 degrees. Thus, if the most-recent value for phase angle is larger than 100 degrees or smaller than 80 degrees, the detector will notify you that a fault has occurred.

Modifying the “Unacceptable Change” Limits

To modify the “unacceptable change” notification limits, do the following.


- 1) Make sure the phase-tracking fault-limit function is highlighted (as shown above).
- 2) Press the Go button and an input screen appears.




- 3) Key in a value (in degrees and hundredths of a degree) for an “unacceptable change” fault notification to occur.
- 4) Press the Go button to save your setting.
- 5) Press the Back button to exit the menu.

Phase Angle—Page 2

- 1) From the Main Menu, use the navigation buttons to select phase-angle menu.




- 2) Press the Go button and page 1 of the phase-angle menu appears. Press the down-navigation button to get to page 2.



Selecting the Wet-Product Noise Filter

The clip-X filter (CLX) filter is used when testing wet products (such as spaghetti sauce, milk, and so on), and reduces the number of uncontaminated units of product that are erroneously rejected as contaminated. The CLX filter caps the X signal at 1, 2, or 3 times the detect-level setting. This is dependent on the current CLX setting. This can help in reducing the occurrences of false detections due to conveyor vibration, when inspecting a wet product. The CLX filter can be used in conjunction with the PNR and QNR filters, if needed.


Use this filter *only* for wet products!




Please note the “0x” notation in the screen above. This tells you that, currently, the CLX filter is not active.

Activating the CLX Filter

- 1) Make sure the CLX filter menu is highlighted.




- 2) Press the Go button twice and the 2x notation appears in the CLX menu, as shown below.



- 3) Press the Back button to activate the CLX filter, save the 2x setting, and exit the menu.

Selecting the Phased-Noise Reduction Filter

The default setting for the phased-noise reduction (PNR) filter is on (as indicated by the check mark in the PNR menu below), and is used in all applications (conveyor applications and gravity-feed and pipeline applications) to reduce background noise and increase the ability of the search head to detect metals. In addition, the PNR filter reduces the number of uncontaminated units of product that are erroneously rejected as contaminated. The PNR filter can be used in conjunction with the CLX and QNR filters, if needed.




Inactivating the PNR Filter

This is not recommended. However, if you need to inactivate the PNR filter, do the following.

- 1) Make sure the PNR filter menu is highlighted.
- 2) Press the Go button and the check mark changes to an X.
- 3) Press the Back button to exit the menu. The PNR filter is now inactivated.


Selecting the Quadrature Noise-Reduction Filter

The default setting for the quadrature noise-reduction (QNR) filter is off, as indicated by the X in the QNR menu below. The QNR filter is often used when testing wet products, where it reduces 1) the background noise, and 2) the number of uncontaminated units of product that are erroneously rejected as contaminated due to vibration. Occasionally the QNR filter is used when testing dry products, where it lowers the detect level and increases the ability of the search head to detect metals. The QNR filter can be used in conjunction with the CLX and PNR filters, if needed.



Activating the QNR Filter

- 1) Make sure the QNR filter menu is highlighted, as shown above.
- 2) Press the Go button and the X changes to a check mark.



- 3) Press the Back button to exit the menu. The QNR filter is now on.

Frequency and Gain—Page 1

When testing products, setting the appropriate frequency and gain settings will maximize the detector's ability to detect metallic contaminants.

Choosing the Optimal Settings for Frequency and Gain

When testing any product for the presence of metallic contaminants, it is best to run the detector at high frequency (300 KHz) and high gain, because this combination gives the best sensitivity. However, if your product has a significant product effect, as shown by the flashing of the red indicator light on the detector's control panel when product passes through the search head, using the high-frequency and *low*-gain setting will likely remedy the situation—because the low-gain setting cuts the signal produced by the product by a factor of 4.5.


If the high frequency/low gain setting still causes saturation, move to the low frequency/high gain setting, and so on.

Frequency	Gain	Ability to detect contaminants
300 KHz—High	High	Excellent
300 KHz—High	Low	Very good
100 KHz—Low	High	Good
100 KHz—Low	Low	Fairly good

Accessing the Frequency and Gain Menu


To access the frequency and gain menu, do the following.

- 1) From the Main Menu, use the navigation buttons to select the frequency and gain menu.



(continued...)

2) Press the Go button and page 1 of the frequency and gain menu appears.



The frequency and gain icons shown in this menu are as follows.



High frequency



Low frequency



High gain




Low gain


Currently, the detector (as shown in the figure above) is set on high frequency and high gain—the default setting.

Setting High or Low Frequency

As indicated in the figure below, the detector is currently set on high frequency.




1) To change to *low* frequency, press the Go button and a check mark appears next to the low-frequency icon (and an *X* appears next to the high-frequency icon).



- 2) Press the Back button to save the low-frequency setting and exit the menu. Please that if you chance the frequency, the APEX must relearn the *X* and *R* noise thresholds for optimal performance.

Setting High or Low Gain

As indicated in the figure below, the detector is currently set on high gain.




- 1) To change to *low* gain, press the Go button and a check mark appears next to the low-gain icon (and an *X* appears next to the high-gain icon).



- 2) Press the Back button to save the low-gain setting and exit the menu.

Inhibiting Detection


As indicated in the figure below, when the APEX detects metallic contaminants passing through the search head, it sends a signal to the reject device. In other words, the normal reject signal is *not* being inhibited.




- 1) To *inhibit* the reject signal, press the Go button and the *X* changes to a check mark.
- 2) Press the Back button to save your setting and exit the menu.

Frequency and Gain—Page 2

- 1) From the Main Menu, use the navigation buttons to select the frequency and gain menu.




- 2) Press the Go button and page 1 of the frequency and gain menu appears. Press the down-navigation button to get to page 2.



Calibrating the Detect Level

This function allows you to calibrate *only* the detect level (rather than having the detect level set by the Main Menu's auto-calibration function, which simultaneously calibrates the phase angle, detect level, and AuditCheck settings).




Calibrating Only the Detect Level

To calibrate only the detect level (typically used in a conveyor application), do the following.

- 1) Turn the conveyor on and have some samples of *uncontaminated* (metal-free) product ready to pass through the search head.

(continued...)


- 2) Make sure the calibrate-detect-level function is highlighted, as shown above.
- 3) Press the Go button and a monitor screen appears.



- 4) Place the uncontaminated product samples on the conveyor, so they pass through the search head.
- 5) Wait for the calibration function to finish. (The detector will close the menu and assign a value for the detect level.)

Changing the Detect Level


The detect level is usually set by running the detect-level calibration function or by running the Main Menu's auto-calibration function. This menu allows you to key in a new value for the detect level.



- 1) Make sure the detect-level menu is highlighted, as shown above.

(continued...)


- 2) Press the Go button and an input screen appears.



- 3) Key in a new setting for the detect level.
- 4) Press the Go button to save your setting.
- 5) Press the Back button to exit the menu.

Setting Multi-Zone Detection

Typically, when a metallic contaminant passes through the search head, it produces a signal having a positive peak followed by a negative peak (because the metal passes through the two opposing search (or input) coils located in the search head. When the detector analyzes this signal from the search head, it looks for *two* peaks (one positive, the other negative). Only when *two* peaks are detected will the APEX “tag” this as contamination by sending a signal to the reject device. This “two peaks to verify contamination” set-up is the default, multi-zone setting. In the figure below, the check mark by the letters, MZ, indicates the APEX is currently using multi-zone (two peak) detection.



Enabling One-Peak Detection


This function is typically used in applications running large cases of product that fill 80–90 percent of the search head. To enable one-peak detection, do the following.

- 1) To allow the detector to tag contamination using only *one* peak, press the Go button and an X appears next to the letters, MZ.
- 2) Press the Back button to save this “one peak to verify contamination” setting and exit the menu.

Locking the Detect Level


This function locks the current detect-level setting so that it cannot be changed—for example by running the auto-calibration function. In the screen below, the detect-level setting (40) is *not* currently locked.

To lock the detect-level setting, press the Go button and the X changes to a check mark—indicating the detect-level setting is now locked (in our example at 40).



Calibrating the X and R Noise Thresholds

This function allows you to calibrate the X and R noise thresholds for background noise, and is typically used in applications where vibration from the conveyor creates background noise that the detector may interpret as a contaminant passing through the search head. Vibration—it is important to note—usually shows up in the X threshold (where it increases the value).




Calibrating the X and R Thresholds for Background Noise

To calibrate the X and R thresholds for background noise in a conveyor application, do the following.

- 1) Turn the conveyor on (making sure *no* product, test samples, and so on are on the conveyor or near the search head).
- 2) Make sure the “Calibrate Noise Thresholds” function is highlighted, as shown above.
- 3) Press the Go button and a monitor screen appears.
- 4) Wait for the calibration function to finish. (The detector will close the menu and assign values for the X and R noise thresholds.)

Changing the Noise Threshold for *X*


In conveyor applications, the noise threshold for *X* is often increased to prevent the detector interpreting vibration as contamination.



To change the noise threshold for *X*, do the following.

- 1) Make sure the *X*-threshold menu is highlighted.
- 2) Press the Go button and an input screen appears.
- 3) Key in a new setting for the *X* noise threshold.
- 4) Press the Go button to save your setting
- 5) Press the Back button to exit the menu.

Changing the Noise Threshold for *R*




To change the noise threshold for *R*, do the following.


- 1) Make sure the *R*-threshold menu is highlighted.
- 2) Press the Go button and an input screen appears.
- 3) Key in a new setting for the *R* noise threshold.
- 4) Press the Go button to save your setting.
- 5) Press the Back button to exit the menu.

System and Tools—Page 1

1) From the Main Menu navigate to the system and tools menu.




2) Press the Go button and page 1 of the system and tools menu appears.




Quality Test

See page 196.




AuditCheck

See page 206.



Error Messages (WAFs)


See page 214.



Manual Print


Before you can use the manual-print function, you must first enable the printer. To activate the printer, see page 242. In addition, if you need a password to access the detector, you will need to enter your password to do a manual print.

- 1) To start a manual print, press the Go button. (If passwords are enabled, the keyboard screen appears. Enter your password. Then highlight the exit-and-save key, press the Go button, and printing starts.)




Bar-Graph/Help-Text Set-Up for the Display Panel

See page 20.




IntelliTrack (IXR)

See page 367.




System and Tools—Page 2

- 1) From the Main Menu navigate to the system and tools menu.




- 2) Press the Go button and page 1 of the system and tools menu appears. Navigate to page 2 by pressing the down-navigation button.



Viewing Your Speed-Filter Settings


The type of speed filter (narrow-band or wide-band) used by the APEX is set at the factory, and depends on the type of application you are running—conveyor, gravity-feed, pipeline, or pharmaceutical. The screen below shows the narrow-band filter, which is used by conveyor and gravity-feed applications, and is the default setting. Please note that if you are running a pipeline or pharmaceutical application, this screen will show the wide-band filter (the default setting).




Calibrating the Speed Filter

The speed-filter calibration process differs, depending on which type of application you are running—conveyor, gravity-feed, pipeline, or pharmaceutical.


- 1) Make sure the speed-filter menu is highlighted.



2) Press the Go button and page 1 of the speed-filter menu appears.




3) Press the right-navigation button to highlight the calibrate function.



- To calibrate the speed filter for conveyor applications, see page 50.
- For gravity-feed applications, see page 72.
- For pipeline applications, see page 88.
- For pharmaceutical applications, see page 104.


Speed Filter Frequency

Shown below is a typical narrow-band filter screen. Your screen, however, may look different, depending on the type of application you are running—conveyor, gravity-feed, pipeline, or pharmaceutical.




Product Speed

Your screen may look different, depending on the type of application you are running—conveyor, gravity-feed, pipeline, or pharmaceutical. To change product speed, press the Go button and key in the new product speed.



Speed-Filter Factory Menu

For more information about these filters, please contact Thermo Fisher Scientific—as described in the “Contacting Thermo Fisher Scientific” section at the end of the manual.




The speed-filter factory menu gives qualified personnel access to the following (application-specific) speed-filter settings.

- One narrow-band speed filter.
- Three preset wide-band speed filters (SF-WB bands #1, #2, and #3), which are typically used in pipeline and pharmaceutical applications.
- One customizable wide-band speed filter (SF-WB band #4).
- A finite impulse-response (FIR) filter.
- Access to all other speed-filter settings.


Inputs and Outputs Menu

See page 220.



Copying and Pasting Product Parameters

The copy-product function (highlighted below) allows you to copy the detector's current product settings (such as phase angle, detect level, and so on) to another similar product. This is a very useful feature if you are testing a series of identical products, but need to keep track of different production runs, shifts, days, and so on for quality-assurance purposes.




Example

Imagine you are a supervisor at a dairy where milk is pasteurized, cooled, and poured into half-gallon plastic containers. The milk is tested for metallic contaminants before leaving the dairy (because metal screens are used to filter the milk as it comes in from the local farms in order to remove insects and other particulate matter). For quality-assurance reasons, you need to test the output of the morning (a.m.) shift separately from the output of the afternoon (p.m.) shift.


1) You have already named two products, as follows. (For more information about naming a product, see page 24).

- MILK—A.M. SHIFT
- MILK—P.M. SHIFT


2) Currently you are testing the output from the morning (a.m.) shift, so your Main Menu and detector settings look like this.



3) Navigate to the copy-product function and make sure it is highlighted.




- 4) Press the Go button to copy the current product settings. (If passwords are enabled, the keyboard screen appears. Enter your password. Then highlight the exit-and-save key and press the Go button.)
- 5) Press the Back button repeatedly to return to the Main Menu, and make sure the product name ("MILK—A.M. SHIFT") is highlighted, as show in step 2 above.
- 6) Press the right-navigation button to bring up the (Product 2) screen you previously named "MILK—P.M. SHIFT," as shown below. The product name with be flashing on and off. To select the "MILK—P.M. SHIFT," press the Go button.




Notice that the detect-level and phase-angle settings are currently set to their default values of 40 and 90.

- 7) Navigate to the paste-product function.




- 8) Press the Go button and the following confirmation screen appears.




(continued...)

- 9) Press the left-navigation button to select the “Accept” check mark.



- 10) Press the Go button. (The detector pastes in the product parameters and closes the confirmation screen.)
- 11) Press the Back button repeatedly to return to the Main Menu, which should now look like this.



Notice that the initial setting for detect level and phase angle for the “MILK—P.M. SHIFT” (shown in step 6, where the settings were 40 and 90, respectively) have changed, and now match those for the “MILK—A.M. SHIFT” (25 and 2, respectively, as shown in the screen in step 2 above).


Summary

All “MILK—A.M. SHIFT” parameters have now been copied to the “MILK—P.M. SHIFT.” Clearly, by using copy and paste, you have made a substantial saving in time and effort in comparison to the alternative—re-entering the product parameters, re-running the calibrations, and so on.


Setting the Time and Date

Setting the correct time and date is useful, especially if you use the detector's print function. When the time and date are current, your printed reports are stamped with the correct date and time, allowing you to keep proper records for future reference.

- 1) Navigate to the time and date menu on page 2 of the system and tools menu.




- 2) Press the Go button and page 1 of the time and date menu appears.




Setting the Correct Time

- 1) Press the right-navigation button to highlight the time function. (The figures in your display panel will differ from the example shown below.)



(continued...)


- 2) To set the correct time, press the Go button and an input screen appears.



- 3) Use the navigation buttons to key in the correct time using the 24-hour format, keying in appropriate values for the hours, minutes, and seconds. (Currently the clock reads 13 hours, 40 minutes, and 24 seconds.)
- 4) Press the Go button to save your setting and exit the menu.


Setting the Correct Date

- 1) Follow the instructions above to navigate to the date function.



(continued...)

- 2) Press the Go button and an input screen appears.




- 3) Use the navigation buttons to key in the correct date. Make sure you key in four digits for the year (YYYY), two digits for the number of the month (MM) and two digits for the day (DD)—carefully following the convention of year/month/day.

In the example above, we set the following date: February 28, 2008. If you are used to expressing dates using a different convention—such as 28 February, 2008—please be careful keying in these numbers.

- 4) Press the Go button to save your setting and exit the menu.


Setting Metric or Imperial Units

See page 22.




System and Tools—Page 3

- 1) From the Main Menu navigate to the system and tools menu.




- 2) Press the Go button and page 1 of the system and tools menu appears. Press the down-navigation button to get to page 3.



Setting the Photo-Eye-to-Detector Distance

See page 28. (This function is used only in conveyor applications.)




Setting Reject Duration (Time or Distance) for Your Reject Devices

When a contaminant is detected, the reject devices will fire, after their respective delays have expired. The outputs assigned to the reject devices will remain active for the reject duration assigned to each device. This gives the reject device sufficient time to blast or push the contaminated product into the reject bin. The reject durations can be based on time or distance units.

- Time-based reject durations will keep the reject device active until a specified time interval has passed.
- Distance-based reject durations will keep the reject device active, while the product moves a specified distance. The distance travelled is determined by the encoder pulses.


Please note that, in a conveyor system that is setup to stop the conveyor if there is a reject, this will never expire using a distance-based reject duration, because the belt is stopped and there are no encoder pulses.




Setting Time or Distance Units

To set time or distance units for your reject-1 and/or reject-2 devices, do the following.

- 1) Make sure the reject-settings menu is highlighted.




- 2) Press the Go button and the following menu appears.




The top part of this menu is used to manage your reject-1 device and the bottom part to manage your reject-2 device. The part on the right is used (when enabled) to reject all packages when calibrating your reject-1 device—as described in the following section. In addition note that, currently, you and the detector are managing the durations of both reject-devices (reject-1 and reject-2) using *time* units, as shown by the check mark beside the clock icons.

- 3) Highlight the reject-1 menu or the reject-2 menu—as appropriate to your situation. (In the screen below, the reject-1 menu is highlighted.)



(continued...)

- 4) Press the Go button, and the check mark moves to the distance (ruler) icon.




- 5) Press the Back button to exit the menu and save your distance preference for managing the reject-1 device. The APEX will now use distance settings in all relevant reject-1 (or, if selected in step 3 above, reject-2) menus.


Setting the “Reject Packs During Learn” Function

If you want all packages to be rejected during a calibration learn, you need to enable the “Reject Packs During Learn” function. To enable this function, do the following.

- 1) Highlight the “Reject Packs During Learn” menu.




- 2) Press the Go button. A checkmark appears, showing this function is now enabled.



- 3) Press the Back button to save your setting and exit the menu.


Resetting the Counts When Products Change

When analyzing a particular product (for example, Product 001), the reject-totals menu displays the total number of rejects made for that particular product. In addition, in conveyor applications, the reject-totals menu displays the total number of units of product that have been analyzed. The statistics settings menu allows you to reset both counts for a particular product (for example, Product 001), before you start analyzing another product (for example, Product 002).




Resetting the Total-Reject and Total-Product Counts

- 1) Make sure the statistics settings menu is highlighted, as shown above.
- 2) Press the Go button and the following menu appears.




- 3) Press the right-navigation button to highlight the reset-counts menu.




(continued...)

- 4) Press the Go button and the X changed to a check mark.




- 5) Press the Back button repeatedly to return to the Main Menu. The total-reject count is now reset to zero. In addition, for conveyor applications, the total-product count is also reset to zero, as shown below.



Resetting Product Parameters to the Default Settings

This function allows you to reset the product-related parameters for a *particular* product. In other words, the product parameters for all other products remain *unchanged*.




Example


Imagine you are a supervisor at a dairy where you test salted butter, ice cream, and milk for the presence of metallic contaminants. You have been testing three products recently (named "SALTED BUTTER", "ICE CREAM", and "MILK"), and now want to reset the product parameters for "MILK" to the detector's defaults settings.

(continued...)


- 1) In the Main Menu make sure the product named "MILK" (Product 003) is highlighted. (Notice in our example that the detect level is currently set to 25, and the phase angle to 2.)



- 2) Navigate to the reset-product-parameters function and make sure it is highlighted.
- 3) Press the Go button and a confirmation screen appears.




- 4) Press the left-navigation button to select the "Accept" check mark.



(continued...)


- 5) Press the Go button. The detector resets the product parameters—including deleting the name “MILK”—and returns you to the Main Menu.



Notice that all parameters for Product 003 have now been reset to their factory defaults. The detect level, for example, has been reset to 40 and phase angle to 90.

Resetting the NVRAM Parameters to the Default Settings

This function resets virtually everything in the detector to its factory-default settings. Only supervisors can enter this function. However, do *not* enter this function unless you are firmly resolved to delete *all* your product and other settings and start afresh. This function clears everything from the detector’s memory—except the model of APEX (500, 300, or 100) and type of application (conveyor application, gravity-feed, pipeline or pharmaceutical) you are using. You have been warned! Proceed with caution.




Resetting the NVRAM

- 1) Make sure the NVRAM function is highlighted, as shown above.
- 2) Press the Go button and the keyboard screen appears.
- 3) Type in your supervisor password. If you have not assigned a unique password to yourself, you should use the default password “SUPE” here (that is, enter *only* the four upper-case letters, SUPE).
- 4) In the keyboard screen, highlight the exit-and-save key.


(continued...)

- 5) Press the Go button and a confirmation screen appears. (To see what a confirmation screen looks like, see step 3 on page 185.)
- 6) Press the left-navigation button to highlight the "Accept" check mark. (Refer to step 4 on page 185.)
- 7) Think very carefully! The next step *cannot*—repeat, cannot—be undone.
- 8) If you are absolutely sure you want to reset the detector, press the Go button. The detector resets virtually everything and returns you to the start-up Main Menu screen, which now looks like this.




Oscilloscope

The oscilloscope function allows you to see every signal generated by the detector—from the initial product/contaminant signals seen by the search head to the final signal produced by the detector after the search-head signals have been clipped, filtered, and analyzed for the presence of a metallic "fingerprint." In this section, the path from the search head to the final signal in the detector is known as the "signal path."




Navigating to the Oscilloscope Function

- 1) From the Main Menu navigate to the system and tools menu.




(continued...)

2) Press the Go button and navigate to page 3 of the system and tools menu.



3) Navigate to the oscilloscope function.



4) Press the Go button and the start-up oscilloscope screen appears.



Understanding the Signal Path

When products or contaminants pass through the search head they generate a pair of signals (known as the *X*-input signal and the *R*-input signal). These two signals are then passed through a series of filters, where the signals are clipped, filtered, and analyzed, as shown in the signal path diagram at the end of this section. You can use the oscilloscope function to view the *X* and *R* signals (or the combined signal) at any point along the signal path.

For example, in the start-up oscilloscope screen above, notice that there are two (analog) signal channels, Channel 1 and Channel 2. (Note, however, that the oscilloscope function also has two *digital* channels available for use.) Currently, neither analog signal channel has been assigned but, in the example below, you will learn how to assign the *X*-input signal to Channel 1 and the *R*-input signal to Channel 2.


Accessing the Scope-Configuration Menu

The scope-configuration menu allows you to control how the oscilloscope functions and how it displays the signals you are interested in. To access the scope-configuration menu, do the following.


- 1) Make sure the scope-configuration function is highlighted in the start-up oscilloscope screen.



- 2) Press the Go button and page 1 of the scope-configuration menu appears.



- 3) Press the down-navigation button repeated until page 2 of the scope-configuration menu appears, as shown below.



Assigning Signals to Channels

In this example you are going to assign the *X*-input signal to Channel 1 and the *R*-input signal to Channel 2. However, as you become more familiar with the oscilloscope, you can assign a variety of signals to Channels 1 and 2.

- 1) Make sure page 1 of the scope-configuration menu is displayed and the analog channel-1 menu is highlighted.

Scope Configuration 1/2	
ANALOG CH1	OFF
ANALOG CH2	OFF
TIMEBASE	2 S
AMPLITUDE	100
OFFSET	-40
TRIG SOURCE	OFF
TRIG REF	CENTER

- 2) Press the right-navigation button to scroll through the analog channel-1 menu options, then use the left-navigation button to scroll *back* through the options. Highlight the "X:INPUT" option, which assigns the *X*-input signal to the oscilloscope's analog Channel 1.
- 3) Press the down-navigation button to exit the analog channel-1 menu and save your setting. The analog channel 2 menu should now be highlighted, as shown below.

Scope Configuration 1/2	
ANALOG CH1	X:INPUT
ANALOG CH2	OFF
TIMEBASE	2 S
AMPLITUDE	100
OFFSET	-40
TRIG SOURCE	OFF
TRIG REF	CENTER

- 4) Follow the instructions in step 2 to assign the *R*-input signal ("R:INPUT") to the oscilloscope's analog Channel 2.
- 5) Press the Back button to exit the scope-configuration menu and return to the start-up oscilloscope screen.

Further Exploring the Scope-Configuration Menu

Now that you know how to navigate the scope-configuration menu, we'll leave you to explore the remaining functions on your own. However, if you need additional help understanding or using any of the oscilloscope's functions, please contact Thermo Fisher Scientific—as described in the "Contacting Thermo Fisher Scientific" section at the end of the manual.

Here are a few tips on using the scope-configuration functions.

- If you cannot see a signal trace on the oscilloscope screen, go to the amplitude menu (on page 1 of the scope-configuration menu) and enter a higher or lower value to bring the signal within range.
- If the signal trace is either very compressed or very spread out along the horizontal (time) axis, go to the time-base menu (on page 1 of the scope-configuration menu) and enter a higher or lower value to get the signal "spread" you want.
- If you cannot get the Channel 1 and Channel 2 signals to display together along the oscilloscope screen's horizontal center-line, go to the offset function (on page 1 of the scope-configuration menu) and enter a higher or lower value to display the signals to your satisfaction.


Using the Oscilloscope's Trigger Functions

There are three settings for the oscilloscope's trigger function, as follows. (These functions are accessed from the lower-right corner of the start-up oscilloscope screen.)


- *No Trigger*
This function is abbreviated in the start-up oscilloscope screen as "TRIG: FREE" and tells the oscilloscope to continuously process signal at the rate specified in the time-base menu. Thus, when using this function, the screen scrolls continuously.
- *Wait-for-Detection Trigger*
This function is abbreviated in the start-up oscilloscope screen as "TRIG: WAIT DETECTION" and tells the oscilloscope to wait until a signal is detected, and then display it at the rate specified in the time-base menu. Thus, when using this function, the screen scrolls continuously.
- *Hold-After-Detection Trigger*
This function is abbreviated in the start-up oscilloscope screen as "TRIG: HOLD DETECTION" and tells the oscilloscope to wait until a signal is detected, and then freeze the display, so the signal does not scroll off the screen. Thus, when using this function, the screen is static, making captured signals easy to see and study.

System and Tools—Page 4

1) From the Main Menu navigate to the system and tools menu.




2) Press the Go button and page 1 of the system and tools menu appears. Press the down-navigation button to get to page 4.




Selecting the Language for the Display Panel's Help Text

See page 17.




System and Tools—Page 5

- 1) From the Main Menu navigate to the system and tools menu.




- 2) Press the Go button and page 1 of the system and tools menu appears. Press the down-navigation button to get to page 5.




Displaying Your Software Version

This screen displays the current version of the software you are using.




Displaying Your APEX Model Type

This screen displays the model number of the detector you are currently using. If the information in this screen is incorrect or needs to be changed, please contact Thermo Fisher Scientific—as described in the “Contacting Thermo Fisher Scientific” section at the end of the manual.



Displaying Your System Set-Up Code


Use this function when contacting Thermo Fisher Scientific’s technical-support personnel—as described in the “Contacting Thermo Fisher Scientific” section at the end of the manual. The system set-up code displays a string of characters that allows technical-support personnel at Thermo Fisher Scientific (with the aid of a decoder program) to see the current settings of your *system* (but not product) parameters. (Product parameters are accessed as described in the following section.)



Displaying Your System Set-Up Code

To display your system set-up code, do the following.


- 1) Make sure the system set-up code function is highlighted.
- 2) Press the Go button, and a display screen appears showing a code similar to the example below.



- 3) Make a note of the character stream, then press the Back button to exit the screen.

Displaying Your Product Set-Up Code


Use this function when contacting Thermo Fisher Scientific's technical-support personnel—as described in the "Contacting Thermo Fisher Scientific" section at the end of the manual. The product set-up code displays a string of characters that allows technical-support personnel at Thermo Fisher Scientific (with the aid of a decoder program) to see the current settings of your *product* (but not system) parameters. (System parameters are accessed as described in the previous section.)



Displaying Your Product Set-Up Code

To display your product set-up code, do the following.

- 1) Make sure the system set-up code function is highlighted.
- 2) Press the Go button, and a display screen appears showing a code similar to the example below.




- 3) Make a note of the character stream, then press the Back button to exit the screen.

Quality Test


(System and Tools—Page 1)

The detector's Quality Test function allows you to conduct *manual* tests of the detector's ability to detect contaminants—in contrast to the detector's AuditCheck function, which does much the same thing, only automatically and with a significantly greater degree of accuracy. Either function, however, allows you to verify—as part of your overall quality-assurance program—that the detector is working properly during long production runs lasting several hours, several days, a week, and so on.




Navigating to the Quality Test Function


- 1) From the Main Menu navigate to the system and tools menu.



- 2) Press the Go button and page 1 of the system and tools menu appears.



- 3) Navigate to the Quality Test function and make sure it is highlighted.



Overview of How the Quality Test Function Works

The most commonly used types of test to verify the detector's response are as follows.

- *Three-Metal Test*
This test uses three different types of metal placed in the center of three separate packets of product. Clearly, which metals you use depends on what contaminants you are interested in. In a typical work environment, this test is conducted using application-specific (conveyor, gravity-feed, or pharmaceutical) ferrous, non-ferrous, or stainless-steel balls. This is the most frequently used of the three types of tests.
- *Positional Test*
This test uses a single contaminant of uniform size (for example the application-specific ferrous test ball) placed in three different positions—usually in the leading, middle, and trailing edge of three separate packets of product.
- *Size Test*
This test uses a single type of metal (for example, ferrous balls), but uses three different sizes ranging through small, medium, and large. Clearly, how small, medium, and large are defined depends on your particular work environment and the size-range of the contaminants you are interested in. In a typical application, the test balls are placed in the center of three separate packets of product.

Managing the QA Test

During long production runs, it is a good idea to test the detector's performance every two hours or thereabouts, and the Quality Test function allows you to manage this process. Here, in outline, is what the Quality Test function does.

- Alerts your shift supervisor—for example by flashing a light—that two hours (or other time interval) has elapsed, and the detector needs to be tested.
- Gives your shift supervisor a 10-minute time window (or other time interval) in which to start testing.
- Shuts down the conveyor automatically, sounds a siren, or takes other action you specify, if your shift supervisor does not start testing within 10 minutes of the "start testing" signal being activated.
- Monitors peak signal and phase angle during the testing process, and provides a warning, alarm, or fault if the peak-signal or phase-angle values are not within the limits you specify.
- Assign the reject device (Reject 1 or Reject 2) used to remove contaminated test products from the conveyor during the QA test. The default setting is to use the Reject-1 device.

Learning the QA Test


In our example, during the testing phase, the shift supervisor uses three different test samples of a contaminated test product (in our example, rectangular packets that mimic the shape and size of salted butter), as follows.

- *Sample A*
A ferrous contaminant (test ball) in the *leading edge* of the packet.
- *Sample B*
A ferrous contaminant (test ball) in the *middle* of the packet.
- *Sample C*
A ferrous contaminant (test ball) in the *trailing edge* of the packet.


Each sample is passed through the search head three times, for two reasons. First, this allows the detector to average the three peak-signal and phase-angle values, increasing accuracy and precision; and second, if the APEX detects contaminants three times in a row, you can be confident it is working properly.

Testing the Detector Using QA Test Samples

- 1) Make sure no *real* product is on the conveyor. If it is not running already, start the conveyor. Make sure the Quality Test function is highlighted.




- 2) Press the Go button and page 1 of the quality-assurance-test (QAT) menu appears.




This screen shows icons representing the three test samples (Sample A, Sample B, and Sample C) that you will use during the testing process.

(continued...)


- Press the right-navigation button to highlight Sample A function (also called the "Pack A" function).



- Press the Go button and a monitor screen with a flashing-hand/sample-A icon appears.




- Place sample A on the conveyor, allow it to pass through the search head, and *manually* catch it on the other side, or allow it to be rejected by your reject-1 device (the default reject device for the Quality Test function).



Note: As you pass the contaminated test sample through the search head, the monitor screen will update and show you the number of passes made (in this example = 1). In addition, the average peak-signal value is also updated (in this example = 1150) as well as the average phase-angle value (in this example = 65.00).

(continued...)

- Repeat step 5 two more times. Press the Go button, and the Sample-A screen reappears showing the average peak-signal and phase-angle values of the three passes you made.




- Press the Go button to exit the learn function.
- Repeat steps 3–6 for contaminated test samples B and C.

Setting the Time Interval Between QA Tests


This function allows you to set the time interval between QA tests (in minutes).

- Make sure page 1 of the quality-test menu is highlighted.




Note: The detector's display panel will show *actual* values, not zeros.

- Press the down-navigation button and page 2 of the quality-test menu appears.



(continued...)

- 3) Navigate to the time-interval menu.




- 4) Press the Go button and an input screen appears. Key in the time interval you want between tests in minutes (maximum = 999 minutes; equivalent to 16 hours, 39 minutes).
- 5) Press the Go button to save your setting and exit the menu.
- 6) When the time interval times out, pass the three test samples in succession to perform the QA Test.

Setting the Time Window for Doing a QA Test

This function allows you to set the time window the operator has to perform the QA test after the warning device—such as a flashing light—alerts him or her that a QA test needs to be done.

- 1) Navigate to the fault time-out function.




- 2) Press the Go button and an input screen appears. Key in the time in minutes (maximum = 99) that the operator has to start performing the QA test. If he or she does *not* perform the test within this time window, a fault will occur—something that could, for example, stop the conveyor or sound a siren.
- 3) Press the Go button to save your setting and exit the menu.

Setting the Reject Device Used for the QA Test

This function sets the reject device used during the QA test. The default setting is to assign Reject 1 to the Quality Test function.

- 1) Navigate to the reject device menu and make sure it is highlighted.




Note: The X indicates that, currently, *no* reject device is assigned to the Quality Test function.

- 2) Press the Go button repeatedly to scroll through the reject-device options, which are as follows.

Icon	Meaning
	No reject device is assigned
	Assign reject-device number 1 (Reject 1)
	Assign reject-device number 2 (Reject 2)


Note: For your reject device to work, it must be connected to the detector's wiring board and be assigned to a specific output (Output 1–6). For more details, see pages 290 and 232.

- 3) When the option you want is shown in the screen, press the Back button to save your selection and exit the menu. (We have chosen to use our reject-1 device for our quality testing.)




Doing a Manual QA Test

This function allows you to do a manual quality test. However, for this manual-test function to work, you must already have calibrated the detector, following the instructions in the “Testing the Detector Using QA Test Samples” section above. In addition, you must have three quality test samples ready to pass through the search head.



- 1) Highlight the manual-test function.
- 2) Press the Go button and the following screen appears.




- 3) Pass your quality test samples through the search head.
- 4) The detector will exit the menu when the test is complete.


Setting Limits for Peak Signal and Phase Angle

This function allows you to set limits for the peak-signal and phase-angle values during QA testing, and, when these test values exceed your prescribed limits, have the detector provide a warning, alarm, or fault.

- 1) Make sure page 2 of the quality-test menu is highlighted.



- 2) Press the down-navigation button and page 3 of the quality-test menu appears.



The icons in this screen are as follows.

Icon	Description
	Peak-signal icon
	Phase-angle icon
	Warning icon
	Alarm icon
	Fault icon

For more information on warnings, alarms, and faults (WAFs), see page 214.


Keying In Limits for Peak-Signal and Phase-Angle Values

This menu allows you to key in limits for the peak-signal and phase-angle values obtained when running the QA test. Limits are set as percent change above (+) or below (-) the previous average test value. The function allows you to have the detector give you a warning, alarm, or fault when these limits are exceeded by the current test values. Thus, you should set a small limit (for example, a 20% change) for a warning, a medium-sized limit (for example, a 40% change) for an alarm, and a large limit (for example an 80% change) for a fault to occur.


Example

In the example below, we are going to change the peak-signal limit for a warning from the default of 20% to 10%.

- 1) Navigate to the peak-signal warning-tolerance function.



- 2) Press the Go button, and an input screen appears—showing the warning icon and the current setting of 20%.



- 3) Key in a new percent value ("10") and press the Go button to save your setting and exit the input screen.
- 4) Follow the basic outline in steps 1–3 above to change all other values in this screen. Note that for a warning, alarm, or fault (WAF) to occur, the appropriate external devices must be connected to the detector's wiring board, and the WAF devices assigned to the appropriate output (Output 1–6). For more information, see pages 232 and 290.


AuditCheck

(System and Tools—Page 1)

The detector's AuditCheck function allows you to test the detector's ability to detect contaminants at the same time that product is passing through the search head. The AuditCheck function typically is used only in conveyor applications, and is used as part of your overall quality-assurance program—in particular, during long production runs lasting several hours, several days, a week, and so on.


The main advantage of using AuditCheck is that it is able to detect very small changes over time in the sensitivity of the search head and alert you well *before* contaminated products are likely to pass unnoticed. In comparison to manual testing (which is described in the Quality Test section above), using the AuditCheck function is *significantly* more accurate and precise, and is virtually foolproof—meaning, if AuditCheck is used regularly, there is little chance of contaminated product passing unnoticed.

This section assumes you have already completed the mechanical installation of the AuditCheck components, and have matched the speed of the test shuttle to the speed of the product moving on your conveyor.



Navigating to the AuditCheck Function


- 1) From the Main Menu navigate to the system and tools menu.




- 2) Press the Go button and page 1 of the system and tools menu appears.



3) Navigate to the AuditCheck function and make sure it is highlighted.




4) Press the Go button and page 1 of the AuditCheck menu appears.



Performing an AuditCheck Test

To perform an AuditCheck test, do the following.

- 1) Make sure the conveyor is running and that product is passing normally through the search head.
- 2) Navigate to the test-1 function.



- 3) Press the Go button and, if the photo-registration function is disabled, the shuttle will fire immediately. However, if the photo-registration function is enabled, the shuttle will wait until the next package enters the search head, then fire.

Displaying the Average Phase Angle

This function displays the average phase angle recorded during the AuditCheck test. It is a display function, meaning it cannot be changed by users.

Average Phase Angle			
P001		001	
<input type="checkbox"/>	→ <input type="checkbox"/> #1	→ <input type="checkbox"/> #2	→ <input type="checkbox"/> #3
AUDIT	1150	0	0
CHECK	13.26°	0.00°	0.00°
1/4	∠ 13.26°	∧ 1150	⊗ X

Displaying the Average Peak Signal

This function displays the average peak signal recorded during the AuditCheck test. It is a display function, meaning it cannot be changed by users.

Average Peak			
P001		001	
<input type="checkbox"/>	→ <input type="checkbox"/> #1	→ <input type="checkbox"/> #2	→ <input type="checkbox"/> #3
AUDIT	1150	0	0
CHECK	13.26°	0.00°	0.00°
1/4	∠ 13.26°	∧ 1150	⊗ X

Setting the Lock-Values Function

This function locks the AuditCheck phase-angle and peak-signal values, so they cannot be changed when running the detector's auto-calibration function.

AuditCheck Lock			
P001		001	
<input type="checkbox"/>	→ <input type="checkbox"/> #1	→ <input type="checkbox"/> #2	→ <input type="checkbox"/> #3
AUDIT	1150	0	0
CHECK	13.26°	0.00°	0.00°
1/4	∠ 13.26°	∧ 1150	⊗ X

(continued...)

Why Locking the AuditCheck Values Is Useful


Locking the AuditCheck values for phase angle and peak signal is useful, because it prevents the less-accurate auto-calibration values over-writing the more-accurate AuditCheck values. Auto-calibration values are inherently more variable, because the response of the search head to the passage of a contaminant is dependent on position—for the simple reason that the *edge* of the head is significantly more responsive than the center. As a result, the AuditCheck values are significantly more accurate than the auto-calibration values for the following reasons. First, the AuditCheck sample always passes through the head in *exactly* the same position; and second, the AuditCheck sample passes through the *edge* of the search head, where its response to metallic contaminants is greatest.

Locking the AuditCheck Values

- 1) To lock the AuditCheck values for phase angle and peak signal, highlight the padlock function.
- 2) Press the Go button and the X changes to a check mark.
- 3) Press the Back button to lock these values and exit the function.

Setting Manual-Start, Timing-Limits, and Reject-Device Parameters


These functions have already been described in detail for the Quality Test function in the Quality Test section, starting on page 196—so please refer to the appropriate sections in the Quality Test write-up for detailed instructions, as the Timing-Limits, and Reject Device Parameters are very similar for AuditCheck and the Quality Test function.



(continued...)

To start a manual AuditCheck, do the following.


- 1) Make sure the manual AuditCheck menu is highlighted, as shown below.



- 2) Press the Go button to start the AuditCheck.

Setting Limits for Peak Signal and Phase Angle


These functions have already been described in detail for the Quality Test function in the Quality Test section, starting on page 196—so please refer to the appropriate sections in the Quality Test write-up for detailed instructions, as the Peak Signal and Phase Angle Parameters are very similar for AuditCheck and the Quality Test function.




Setting the AuditCheck Overhang Distance

This function allows the filter delay to be accurately tracked, when an AuditCheck test is performed.


- 1) Navigate to page 4 of the AuditCheck menu.



- 2) Press the right-navigate button to highlight the overhang function.



- 3) Press the Go button and an input screen appears.



- 4) Key in your overhang distance in meters or inches (if you set inches as your preferred units of measure).
- 5) Press the Go button to save your setting and exit the function.

Setting the AuditCheck Pulse Length

The AuditCheck pulse length is the time it takes your product to travel the length of the AuditCheck tube.

The detector automatically calculates a value for pulse length using other parameters that have been set up—such as the model of APEX you are using, the type of application you are running (conveyor, gravity-feed, or pipeline), and the values you have set for other functions. However, if the internally generated pulse—for some reason—does not give the exact result you want, you can manually enter a value.

How the Detector Calculates Pulse Length

When the value for AuditCheck pulse length is set to zero, the detector automatically calculates the value using the following formula.


$$\text{Pulse Length (ms)} = \frac{(60 * \text{Search-Head Width}) + (2 * \text{Overhang Distance})}{\text{Product Speed}}$$

Where: Search-Head Width is in mm, Overhang Distance is in mm, and Product Speed is in m/min.


Keying In a Value for Pulse Length

To key in a value for pulse length, do the following.


- 1) Navigate to page 4 of the AuditCheck menu.



- 2) Navigate to the pulse-length function and make sure it is highlighted.



- 3) Press the Go button and an input screen appears.



- 4) Key in your pulse length (in milliseconds).
- 5) Press the Go button to save your setting and exit the function.

Setting the AuditCheck Signal Time-Out

When the AuditCheck solenoid fires, a time-out commences during which the detector waits for the AuditCheck signal. Thus, the AuditCheck time-out signal is the length of time it takes the shuttle to travel the length of the AuditCheck tube, plus the speed-filter delay. However, if the internally generated signal time-out pulse—for some reason—does not give the exact result you want, you can manually enter a value.

How the Detector Calculates the AuditCheck Signal Time-Out

When the AuditCheck signal time-out is set to zero, the detector automatically calculates the value using the following formula.


$$\text{Signal Time-Out (ms)} = \frac{60 * 1.75 * [\text{SHW} + (2 * \text{OD})]}{\text{Product Speed}} + \text{Filter Delay}$$

Where: Search-Head Width (SHW) is in mm, Overhang Distance (OD) is in mm, Filter Delay is in ms, and Product Speed is in m/min.


Keying In a Value for Signal Time-Out

To key in a value for the signal time-out, do the following.


- 1) Navigate to page 4 of the AuditCheck menu.



- 2) Navigate to the signal time-out function and make sure it is highlighted.



- 3) Press the Go button and an input screen appears.




- 4) Key in your signal time-out in milliseconds.
- 5) Press the Go button to save your setting and exit the function.

Error Messages (WAFs)

(System and Tools—Page 1)

The detector has three types of error messages: a warning, an alarm, and a fault (WAF). Warnings are the least serious, alarms are more serious, and faults are the most serious type of error message. To be notified when a warning, alarm, or fault occurs, you must hardwire one or more external error-notification devices (lamp, buzzer, siren, and so on) to the detector's wiring board.




Error notification devices are normally connected to detector's wiring board using the following default outputs. (For more information, see page 290.)

- Warning device—Output 4
- Alarm device—Output 5
- Fault device—Output 6


For more information about assigning the detector's outputs, see page 232.

Defining Warnings, Alarms, and Faults (WAFs)


1) From the Main Menu, navigate to the system and tools menu.






2) Press the Go button and page 1 of the systems and tools menu appears.



3) Navigate to the WAF menu.



The icons in this screen are as follows.

Icon	Description
	Warning
	Alarm
	Fault

WAFs Are Not Mutually Exclusive

The WAF menu contains many functions that can trigger a warning, alarm, or fault—but the categories are *not* mutually exclusive. This means that for each function shown in the four pages of this menu, the detector can provide any of the following.

- A warning only.
- An alarm only.
- A fault only.
- A warning *and* an alarm.
- A warning *and* a fault.
- A fault *and* an alarm.
- A warning *and* an alarm *and* a fault.
- None of the above. (No icon is shown next to the function in the menu screen.)


Setting a WAF for a Particular Function

In this example, you are going to tell the detector to give you an alarm, when the reject bin is full. (Currently the detector gives you a fault.) We are assuming you have already hardwired a small red lamp (or other error-notification device of your choice) to the default alarm output—Output 5—on the detector's output-wiring board.


1) Make sure the WAF menu is highlighted.



- 2) Press the Go button and page 1 of the WAF menu appears.



- 3) Navigate to the bin-full event menu.




- 4) The bin-full error message currently triggers a fault notification. To change the bin-full error message to an alarm, press the Go button repeatedly to scroll through the error-message options (described above). When you reach the *single* alarm icon (no other icons are present in the menu), press the Back button to save your setting and exit the menu.
- 5) Now, in our example, when the reject bin is full, the detector lights the small red lamp you connected to Output 5. This alarm notifies you the reject bin is full.

Learning About Other WAFs

Please explore the remaining functions in the WAF menu using the navigation buttons to familiarize yourself with the types of problem that can trigger a WAF. These include the following types of problems, which are listed under the relevant page of the WAF menu.


WAF—Page 1

Page 1 of the WAFs menu looks like this.



The following WAFs are accessed from page 1.


- The reject has not been confirmed.
- The reject bin is full.
- The in-feed photo-eye is blocked.
- Excessive number of consecutive rejects.



This function allows you to set up a WAF (in this example, an alarm), when an excessive number of consecutive rejects occur. (To key in parameters for the excess rejects function, see page 4 of the WAF menu below.)

WAF—Page 2

Page 2 of the WAFs menu looks like this.




The following WAFs are accessed from page 2.

- In a conveyor application, the belt has stopped.
- In a conveyor application, there are no products on the conveyor but a contaminant has been detected.
- The product phase angle used to reject product has drifted beyond the limits you prescribed.
- There is a problem in the search head or oscillator. In most instances, this fault occurs because the head balance is out of the auto-balance range and needs to be readjusted. For further assistance, please contact Thermo Fisher Scientific—as described in the “Contacting Thermo Fisher Scientific” section at the end of the manual.

WAF—Page 3

Page 3 of the WAFs menu looks like this.




The following WAFs are accessed from page 3.

- There was a problem when you ran the Quality Test function.
- There was a problem when you ran the AuditCheck function.
- The battery attached to the detector’s CPU is getting low and needs to be replaced.
- The detector’s CPU memory has been corrupted and should be reset to its factory defaults. See page 186 for details.


WAF—Page 4

Page 4 of the WAFs menu looks like this.



The following WAFs are accessed from page 4.

- Excessive number of consecutive rejects in a conveyor application.



Using this menu, you can key in values to warn you when a specified number of rejects occurs in a specified number of units of product passing through the search head.


Navigate to the relevant number in this menu, press the Go button, and an input screen appears. Key in your new setting and press the Back button to save your setting and exit.

Inputs and Outputs

(System and Tools—Page 2)


The inputs and outputs menu allows you to manage the detector's physical and logical inputs and outputs. The detector's *physical* inputs and outputs are found on the detector's wiring board, where there are six input connectors (labeled Input 1–6) and six output connectors (labeled Output 1–6). In contrast, the detector's *logical* inputs and outputs are controlled using the detector's functions, meaning you (the user) set what you want the detector's inputs and outputs to operate.

Let's look at an example. In a conveyor application, you have physically connected your main (Reject 1) device to Output 1 on the detector's wiring board, and the reject device operates whenever it receives a voltage signal. You decide you want to move your Reject-1 device to Output 6, so you move the wires from Output 1 to Output 6 on the detector's wiring board, which is a *physical* change. Next, you access the detector's output function (described in this section) and tell the detector your reject device is now connected to Output 6, which is a *logical* (software-based) change.



Navigating to the Inputs and Outputs Menu


- 1) From the Main Menu navigate to the system and tools menu.




- 2) Press the Go button and page 1 of the systems and tools menu appears.







3) Navigate to page 2 and highlight the inputs and outputs menu.



4) Press the Go button and a more detailed inputs and outputs menu appears.




The icons shown in this menu are as follows.

Icon	Description	For more information
	Inputs—	See the section following this one (page 222)
	Outputs—	See page 232
	Printer set-up—	See page 238
	Communications set-up—	See page 319 (Icon only appears, if the communications option is installed.)

Inputs—Page 1

The inputs menu allows you to manage the detector's physical and logical inputs. The detector's *physical* inputs are found on the detector's wiring board, where there are six input connectors (labeled Input 1–6). In contrast, the detector's *logical* inputs are controlled using the input menu, which allows you (the user) to tell the detector which external input device is assigned to which input.

In addition, the inputs menu is used to assign a polarity (+ or –) to the voltage signal received from your external input device, such as an in-feed photo eye. Assigning the correct polarity is important, because an in-feed photo eye sends a positive or negative voltage signal depending upon whether the photo eye is light or dark activated.




Example

Let's look at an example. In a conveyor application, you have physically connected your in-feed photo eye to Input 2 (the default set-up) on the detector's wiring board. You decide you want to move your in-feed photo eye to Input 6, so you move the wires from Input 2 to Input 6 on the detector's wiring board, which is a *physical* change. Next, you access the detector's input function (described in this section) and tell the detector your in-feed photo eye is now connected to Output 6, which is a *logical* (software-based) change.

Navigating to Page 1 of the Inputs Menu


To navigate to page 1 of the inputs menu, do the following.

- 1) Follow steps 1–4 in the "Inputs and Outputs" section above (pages 220–21).
- 2) Press the right-navigation button to highlight the inputs menu.




(continued...)

3) Press the Go button and page 1 of the input set-up menu appears.




Viewing the Speed-Encoder Input

This function is used only in conveyor applications and is a display function, meaning you cannot make changes to the input assigned to the speed encoder. The speed encoder *must* be wired to Input 1 and is permanently assigned to Input 1 with a positive (+) polarity.



Assigning the Input for the In-Feed Photo Eye


This function is used only in conveyor applications and assigns the input for the in-feed photo eye.



- 1) Press the Go button and an input screen appears.
- 2) Make the appropriate assignments for input (Input 1–6) and polarity (+ or –).
- 3) Press the Go button to save your settings.
- 4) Press the Back button to exit the menu.

Assigning the Input for the Reject-Confirm-1 Photo Eye (Reject 1)


This function assigns the input for the reject-confirm-1 photo eye. In a conveyor application, for example, the reject-confirm-1 photo eye monitors reject-bin number 1, and verifies that the reject has actually occurred.



- 1) Press the Go button and an input screen appears.
- 2) Make the appropriate assignments for input (Input 1–6) and polarity (+ or –).
- 3) Press the Go button to save your settings.
- 4) Press the Back button to exit the menu.

Assigning the Input for the Bin-Full Photo Eye (Reject 1)

This function is used only in conveyor applications and assigns the input for the bin-full photo eye. This photo eye can be installed half-way up or three-quarters of the way up the bin, giving you some warning before the bin is completely full. (In our example, both the reject-confirm and bin-full photo eyes are assigned to Output 3, which is a common set-up in conveyor applications.)




- 1) Press the Go button and an input screen appears.
- 2) Make the appropriate assignments for input (Input 1–6) and polarity (+ or –).
- 3) Press the Go button to save your settings.
- 4) Press the Back button to exit the menu.


Inputs—Page 2

To navigate to page 2 of the inputs menu, do the following.


- 1) Follow steps 1–4 in the “Inputs and Outputs” section above (pages 220–21).
- 2) Press the right-navigation button to highlight the inputs menu.



- 3) Press the Go button and page 1 of the inputs menu appears.



- 4) Press the down-navigation button and page 2 appears.



Note: The zeros in the screen above indicate that, currently, no inputs have been assigned for any of these functions.

Using an External Device to Switch Products

This function allows an external device—such as a programmable logic controller (PLC)—to tell the detector to change the running product to one of the first three products.

Example

You are a supervisor at a dairy. In the morning you use your APEX and a conveyor application to analyze milk, but at noon every day, you need to start analyzing salted butter. You have installed a PLC that changes the configuration of your conveyor every day at noon, and need to alert the APEX when this change occurs. This is done by having the PLC send signals to the detector's Inputs (Inputs assigned to Product Select One and Product Select Two). When input signal voltage changes due to the PLC, the APEX can immediately stop analyzing milk (Product 1), and load all the product parameters you have set for salted butter (Product 2). The detector is now ready to start analyzing salted butter (Product 2).

- 1) Make sure appropriate menu is highlighted.
- 2) Press the Go button and an input screen appears.
- 3) Make the appropriate assignments for input (Input 1–6) and polarity (+ or –).
- 4) Press the Go button to save your settings.
- 5) Press the Back button to exit the menu.


The APEX can automatically switch to any of the first three products, as shown by the parameters in the table below.

New running product	Product select 1 input	Product select 2 input
No change	False	False
Product 1	True	False
Product 2	False	True
Product 3	True	True


Note: A product-select input that is not assigned (input = 0), will always be treated as false.

Setting the Product-Select Inputs

Setting the following two input functions allow you to select any of the first three products as the current running product, using an external device.



or




In summary, you set up a physical input (as described in the “Using an External Device to Switch Products” section above), then use this function set up the *logical* input for switching among the first three products. Then, when a signal is received from an external device such as a PLC, the detector stops analyzing whichever product it is set to and switches to one of the first three products using the table on the previous page.

Select an input number and a polarity for these inputs. The polarity will determine whether the input is true when the input voltage is positive.

Locking the Detector's Key Pad


This function inactivates (locks out) the Go, Back, and navigation buttons on the detector's control panel, when a signal is received on the input you assign to this function (Input 1–6). When used in conjunction with a key switch for example, it prevents unauthorized use of the detector.



- 1) Press the Go button and an input screen appears.
- 2) Make the appropriate assignments for input (Input 1–6) and polarity (+ or –).
- 3) Press the Go button to save your settings.
- 4) Press the Back button to exit the menu.

Starting the Reject-Suppression Cycle

This function is used only in gravity-feed applications. When an input is received on the input you assign, the detector starts the reject-suppression cycle.




- 1) Press the Go button and an input screen appears.
- 2) Make the appropriate assignments for input (Input 1–6) and polarity (+ or –).
- 3) Press the Go button to save your settings.
- 4) Press the Back button to exit the menu.


Inputs—Page 3

To navigate to page 3 of the inputs menu, do the following.


- 1) Follow steps 1–4 in the “Inputs and Outputs” section above (pages 220–21).
- 2) Press the right-navigation button to highlight the inputs menu.



- 3) Press the Go button and page 1 of the inputs menu appears.




- 4) Press the down-navigation button twice and page 3 appears.



Assigning the Input for Verification of a Reject Using Photo-Eye 2


This function is used most-often in gravity-feed and pipeline applications. The function assigns the input (Input 1–6) for photo-eye number 2, and is used to verify that the reject process has ceased. For example, in a pipeline application where a contaminated raw material (such as canola oil) is diverted to a waste tank, this function is used to confirm that normal flow has resumed to your manufacturing process.



- 1) Press the Go button and an input screen appears.
- 2) Make the appropriate assignments for input (Input 1–6) and polarity (+ or –).
- 3) Press the Go button to save your settings.
- 4) Press the Back button to exit the menu.

Assigning the Reject-2 Confirm Input


This function assigns the input for the “reject-2 confirm” photo eye. In a conveyor application, for example, the “reject-2 confirm” photo eye monitors reject-bin number 2, and verifies that the reject has actually occurred. It is often used in conveyor applications fitted with two reject devices, one that handles contaminated products and the other that handles AuditCheck and Quality Test rejects.



- 1) Press the Go button and an input screen appears.
- 2) Make the appropriate assignments for input (Input 1–6) and polarity (+ or –).
- 3) Press the Go button to save your settings.
- 4) Press the Back button to exit the menu.

Clearing All WAF Inputs

This input can only be set to positive values. When this input is closed (that is, is positive), the APEX clears all resettable warnings, alarms, and faults (WAFs). Please note, however, that system failure faults are *not* cleared.




- 1) Press the Go button and an input screen appears.
- 2) Make the appropriate positive (+) assignments for the input (Input 1–6).
- 3) Press the Go button to save your settings.
- 4) Press the Back button to exit the menu.

Outputs

The outputs menu allows you to manage the detector's physical and logical outputs. The detector's *physical* outputs are found on the detector's wiring board, where there are six output connectors (labeled Output 1–6). (For more details about the detector's output-wiring board, see page 290.) In contrast, the detector's *logical* outputs are controlled using the output menu, meaning you (the user) assign what you want the detector's outputs to operate. In addition, the outputs menu allows you to assign a polarity (+ or –) to the voltage signal sent by the detector to your output devices.


Let's look at an example. In a conveyor application, you have physically connected your main (Reject 1) device to Output 1 on the detector's wiring board, and the reject device operates whenever it receives a voltage signal. You decide you want to move your Reject-1 device to Output 6, so you move the wires from Output 1 to Output 6 on the detector's wiring board, which is a *physical* change. Next, you access the detector's output function (described in this section) and tell the detector your reject device is now connected to Output 6, which is a *logical* (software-based) change.



Navigating to the Outputs Menu


To navigate to the outputs menu, do the following.

- 1) Follow steps 1–4 in the "Inputs and Outputs" section above (pages 220–21).
- 2) Press the right-navigation button to highlight the outputs menu.



(continued...)

3) Press the Go button the output set-up menu appears.



Description of the Icons

The icons in the output set-up menu are as follows.

Output	Icon	Logical (software) output-device assignments
1		Main (Reject 1) device (Used in conveyor applications)
2		AuditCheck reject device (Used in conveyor applications)
3		Quality-Assurance Test reject device (Used mostly in conveyor applications)
4		Warning device (This device is activated when one of the detector's functions issues a warning. Usually connected to a light.)
5		Alarm device (This device is activated when one of the detector's functions issues an alarm. Usually connected to a buzzer.)
6		Fault device (This device is activated when one of the detector's functions issues a fault. Usually connected to a shut-off switch.)


What the Output Set-Up Screen Is Telling You

In the output set-up screen above, Outputs 1–6 are listed at the top of the screen (where all polarities are currently set to plus), and below are shown the default *logical* (software-based) assignments for these output devices. Because all of these assignments (polarity/device) are logical, they can be changed by you, the user. How you do this is described in the following section.


Additional Output Screens

Additional screens that may appear in the output set-up menu are as follows.

- *Output Unassigned*
This screen warns you that no output has been assigned.




- *Reject-2 Screen*
This screen allows you to assign a physical output (Output 1–6) for the logical output, reject-2.




Changing the Assignment of an Output Device

In the following example, you are running a conveyor application, where the main reject device is currently assigned to Output 1. You want to change the reject device to Output 4. You would do this as follows.


- 1) Navigate to the output set-up menu (as described in steps 1–3 on pages 232–33).




- 2) Navigate to the reject-device output icon, which is highlighted below.




- 3) Press the Go button and a select-option screen appears.



- 4) Press the left-navigation button to select the X (to un-assign the reject device from Output 1), and press the Go button. The detector returns you to the original output screen, which now looks like this.



- 5) Navigate to the warning icon currently assigned to Output 4 and press the Go button. The select-options screen reappears. Highlight the reject-1 icon and press the Go button. The detector closes the menu and your reject device is now assigned to Output 4, as shown by the updated output screen below.




- 6) Finally—and do not forget this key step!—disconnect your reject device from Output 1 on the detector's wiring board and reconnect it to Output 4, being careful not to switch the original polarity. (If you do, you can always use this menu to change the polarity to minus.) For more details about the detector's output-wiring board, see page 290.

Changing the Polarity of an Output Device

You use this function to tell the detector to send a positive (+) or negative (–) voltage signal to a particular output (Output 1–6). The screen below currently shows the following.

- Your reject device is currently assigned to Output 1. (For your application to work, your reject device must also be physically connected to Output 1 on the detector's wiring board.)
- To trigger the reject device, the detector sends a positive (+) voltage signal to the reject device.




(continued...)


Example of Changing the Polarity for an Output Device

To continue our example from the section above, having moved your reject device to Output 4, you now want to change its polarity from positive (+) to negative (-).

- 1) Navigate to the "+4" icon in the outputs menu.



- 2) Press the Go button and the icon changes to "-4," indicating the polarity of Output 4 is now negative (-).



- 3) Press the Back button to save your changes and exit the menu.

Printer Set-Up—Page 1

Before using the detector's print functions, you must first do the following.


- Attach a printer to the detector's COM port.
- Activate the printer.

It is also useful to do the following.

- Set the detector's time and date function.

Attaching a Printer to the Detector

Make sure the power to both your printer and the APEX is *turned off*. Then, connect your printer to the detector's serial printer (COM) port—see the wiring diagram below.




COM Port Settings for Attaching a Printer

When attaching a printer to the detector's COM port, please use the following communication parameters.

Parameter	Setting
Bits per second	9600
Data bits	8
Parity	None
Stop bits	1
Flow control	None

Navigating to the Printer Set-Up Menu


- 1) From the Main Menu navigate to the system and tools menu.



- 2) Press the Go button and page 1 of the systems and tools menu appears.




- 3) Press the down-navigation button to get to page 2 and highlight the inputs and outputs menu.




(continued...)


4) Press the Go button and the inputs and outputs menu appears.



5) Navigate to the printer icon.



6) Press the Go button and page 1 of the printer set-up menu appears.



Setting the Detector's Time and Date Functions


Setting the detector's time and date functions is useful, for two reasons. First, any reports you print will have a time and date stamp (which helps you keep proper records as part of your quality-assurance program). And second, the detector's end-of-day print-out function will only work if the time function is set for the detector.

For instructions on how to set the detector's time and date function, see page 176.


Activating the Printer

Once the printer is attached to the detector, before you can print, you must first activate the printer. Note that, once you have activated the printer, whenever you change products or change various functions, a print will occur.

- 1) Follow steps 1–6 in the section above to reach page 1 of the printer set-up menu.



- 2) Navigate to the activate-printer function.




Note: The X shows that the printer is currently inactivated.

- 3) Press the Go button and the X changes to a check mark. The printer is now activated and ready to print.
- 4) Press the Back button to exit the menu.

Manual Printing

Only supervisors can do a manual print. To use this function, you must first activate the printer, as described above.




- 1) Make sure the manual-print function is highlighted, as shown above.
- 2) Press the Go button and the keyboard screen appears.
- 3) Key in your supervisor password, then highlight the exit-and-save key (in the keyboard screen).
- 4) Press the Go button and the printer will start. Shown below is an example print-out.


```
*****
APEX THERMO BATCH REPORT
*****
MACHINE ID:      DG DAIRY
BATCH CODE:      BIG PRINT
FROM:            2008/11/02/ 07:31:18
TO:              2008/11/02/ 11:56:34
PRODUCT:         ICECREAM
PHASE:           2.28
DETECT LEVEL     40
REJECT COUNT:    0
*****
QUALITY TEST RESULTS
*****
DATE             TIME             RESULT
*****
AUDITCHECK TEST RESULTS
*****
DATE             TIME             RESULT
*****
FAULTS ALARMS WARNINGS
*****
DATE             TIME             TYPE
```

Naming Your Detector

This function allows you to name your detector and have that name added to your printed reports. This is useful if you have more than one APEX working in your facility. Before the detector's name is added to your printed reports, you must first activate the printer, as described above.




- 1) Highlight the detector icon, press the Go button, and the keyboard screen appears.
- 2) Enter a name for your detector. (Limit = 9 alpha-numeric characters.)
- 3) Highlight the exit-and-save key in the keyboard screen.
- 4) Press the Go button and the name of your detector appears in the menu, as shown in the example below. (Our APEX is working at the DG DAIRY.)




Naming Your Product Batches

This function allows you to add the name of the batch of products you are testing to your printed reports. To use this function, you must first activate the printer, as described above.



- 1) Highlight the batch-code icon, press the Go button, and the keyboard screen appears.
- 2) Enter a name for your batch of products. (Limit = 9 alpha-numeric characters.)
- 3) Highlight the exit-and-save key in the keyboard screen.
- 4) Press the Go button and your batch code appears in the menu, as shown in the example below. (We are testing batch 01-123456.)




Printer Set-Up—Page 2

This menu allows you to set up end-of-day, reject, and power-up print-outs.

- 1) To reach page 1 of the printer set-up menu (shown below), follow steps 1–6 in the “Navigating to the Printer Set-Up Menu” section above (pages 239–40).




- 2) Press the down-navigation button and page 2 of the printer set-up menu appears.



Activating an End-of-Day Print-Out

This function allows you to print an end-of-day report. For this function to work, you must first have done the following.

- Activated the printer (described above on page 241).
- Set the detector's time and date function (see page 176).



- 1) Make sure the end-of-day function is highlighted.
- 2) Press the Go button and the X is replaced by a check mark. End-of-day printing is now activated.
- 3) Press the Back button to exit the function.


Example of an End-of-Day Print-Out

A typical end-of-day print-out looks like this.

```
*****
APEX THERMO BATCH REPORT
*****
MACHINE ID:      DG DAIRY
BATCH CODE:     01-123456
FROM:           2008/05/21/ 13:30:45
TO:             2008/05/21/ 12:59:59
PRODUCT:        MILK--P.M. SHIFT
PHASE:          2.18
DETECT LEVEL    40
REJECT COUNT:   1
*****
QUALITY TEST RESULTS
*****
DATE            TIME            RESULT
*****
AUDITCHECK TEST RESULTS
*****
DATE            TIME            RESULT
*****
FAULTS ALARMS WARNINGS
*****
DATE            TIME            TYPE
```

Activating a Reject Print-Out

This function prints a brief report every time the detector rejects a product. For this function to work, you must first have activated the printer.



- 1) Make sure the reject function is highlighted.
- 2) Press the Go button and the X is replaced by a check mark. Reject printing is now activated.
- 3) Press the Back button to exit the function.

Example of a Reject Print-Out

A typical reject print-out looks like this.

```
REJECT 2008/05/21 15:50:00 4/789
```


This print-out tells you that, when you printed on May 21, 2008 at exactly 3:50 p.m., four products out of a total of 789 products examined were rejected since the reject totals were reset.

Thus, when you activate a reject print-out, the printer simply prints the current total (or totals) displayed in the reject-totals menu in the Main Menu—as shown in the example below.

Product Name	
P001	801
→→ 100.0	40
90.00	
0	0

Activating a Print-Out on Power-Up

This prints a standard report whenever the detector is powered up. For this function to work, you must first have activated the printer.



- 1) Make sure the power-up function is highlighted.
- 2) Press the Go button and the X is replaced by a check mark. Power-up printing is now activated.
- 3) Press the Back button to exit the function.

Example of a Power-Up Print-Out

A typical power-up print-out looks like this.

```
*****
APEX THERMO BATCH REPORT
*****
MACHINE ID:      DG DAIRY
BATCH CODE:     12-345678
FROM:           2008/05/21/ 05:55:57
TO:             2008/05/21/ 11:32:19
PRODUCT:        MILK--A.M. SHIFT
PHASE:          2.13
DETECT LEVEL    40
REJECT COUNT:   0
*****
QUALITY TEST RESULTS
*****
DATE            TIME            RESULT
*****
AUDITCHECK TEST RESULTS
*****
DATE            TIME            RESULT
*****
FAULTS ALARMS WARNINGS
*****
DATE            TIME            TYPE
2008/05/21     11:47:23     INFO
    POWER OFF
2008/05/21     13:12:52     INFO
    POWER ON
```

Security Level


If you wish to restrict access to your APEX detector, you (as a supervisor) must assign passwords to operators, engineers, and yourself. The following table shows the access privileges of operators, engineers, and supervisors as well as their default passwords. Use the default passwords, when entering this menu for the first time to set up security levels for yourself and your coworkers. Unlike a personal computer, no names are used—only passwords. Thus, all supervisors, engineers, and operators are recognized only by their passwords.

Access Level	User Name	Default Password	Available to this Access Level	Not Available to this Access Level
0	Read/Lock	(None)	View everything Clear peak Language	(N/A)
1	Operator 1	OPR1	AutoLearn Learn detect level Change products	Adjust— Phase angle Detect level
2	Operator 2	OPR2	Manual AuditCheck Manual QAT Manual print Learn and adjust— Phase angle Detect level Learn IXR Edit pack length Learn reject confirmations Reset reject counts	Pack gap Detect no-pack distance Machine settings Reject settings I/O settings Phase and IXR tracking AuditCheck settings QAT settings
3	Engineer	ENGI	Everything except password changes	Passwords NVRAM reset
4	Supervisor	SUPE	Everything	Set APEX model or machine type SF factory menu
5	Factory	—	Model/machine SF factory menu	Password required for every change

Accessing the Security Menu

To access the security menu, do the following.

- 1) In the Main Menu screen, navigate to the security menu.




Notice there is an X beside the key icon. This tells you that no passwords have been set, and that, currently, all personnel have full access to all of the detector's functions.

- 2) To restrict access, you must first set a password for yourself (as supervisor), and then set passwords for other users—such as engineers and operators. Each person can be given a unique password and assigned an appropriate security level (Level 1, Level 2, or Level 3).


Entering a Supervisor Password

To set up a password for yourself as a supervisor, do the following.


- 1) Make sure the security level menu is highlighted, as shown above. Press the Go button and page 2 of the security menu appears.




- 2) Press the right-navigation button to highlight the passwords menu.




- 3) Press the Go button and a password-needed mini-screen appears.



- 4) Press the Go button and the keyboard screen appears—complete with a key icon in the entry field as a reminder you are now entering a password.




- 5) Key in your default supervisor password ("SUPE") and navigate to the exit-and-save key. Your screen should now look like this. (If you are not sure how to use the keyboard screen, see page 25.)




(continued...)

- 6) Press the Go button and the following screen appears. Notice that a check mark has appeared in the passwords menu, which tells you that passwords have now been activated for the detector.



- 7) Navigate to the Level 4 supervisor password-entry icon.



- 8) Press the Go button and the keyboard screen reappears.
- 9) Key in a *new* supervisor password for yourself (anything but "SUPE"). You must key in your new password *twice*, as follows.
- Key in your new password, navigate to the exit-and-save key, and press the Go button. (The display panel still shows the keyboard screen, but a *second* key icon has appeared in the entry field.)
 - Key in your new password *again*, navigate to the exit-and-save key, and press the Go button. The screen shown in step 7 above reappears.

Setting Engineer and Operator Passwords


"Engineer," "Operator 1," and "Operator 2" passwords are set in the same way as described above for supervisors.

- 1) Go to the screen shown in step 7 in the "Entering a Supervisor Password" section above.
- 2) Highlight the level (Level 1, Level 2, or Level 3) for which you want to enter a password.
- 3) Press the Go button and the keyboard screen reappears.
- 4) Key in a *new* password for the level. You must key in the new password *twice*, as follows.
 - a. Key in the new password, navigate to the exit-and-save key, and press the Go button. (The display panel still shows the keyboard screen, but a *second* key icon has appeared in the entry field.)
 - b. Key in the new password *again*, navigate to the exit-and-save key, and press the Go button.
- 5) Now that you (as supervisor) have set up passwords for all personnel using the detector, you need to log out.
- 6) See page 256 for log-out instructions.

Retrieving a Forgotten Password


This can *only* be done by a supervisor.

- 1) Log in and navigate to the screen below.



(continued...)

- 2) Press the Go button and a screen similar to the one below appears.




- 3) Make a note of the information in the screen. Contact Thermo Fisher Scientific's technical-support personnel—as described in the “Contacting Thermo Fisher Scientific” section at the end of the manual.


Undoing the Need for Passwords

Once you have set passwords but decide *not* to use them (for all personnel—supervisors, engineers, and operators), you can *undo* the need for passwords (and, thus, the need for any log-in procedures) as follows.

- 1) Log in as a supervisor and navigate to the screen shown below, which you can reach by following steps 1–6 in the “Entering a Supervisor Password” section above.




- 2) Press the Go button and the check mark in the passwords menu changes to an X. Passwords are now no longer required, and all personnel have full access to all of the detector's functions.
- 3) Press the Back button to exit the menu. The X next to the key icon tells you passwords are no longer required.



Logging In


If passwords have been set for the detector, you must first log in.

- 1) In the Main Menu screen, navigate to the security menu.




Note: The zero next to the key icon tells you that, currently, no one is logged in to the detector.

- 2) Press the Go button and the log-in screen appears.




- 3) Press the Go button and the keyboard screen appears—complete with a key icon in the entry field as a reminder you are now entering a password.



(continued..)


- 4) Key in your password, navigate to the exit-and-save key, and press the Go button. (If you are not sure how to use the keyboard screen, see page 25.) The Main Menu re-appears, showing your security level (Level 1, Level 2, Level 3, or Level 4) next to the key icon. The screen looks like this for Operator 1, who has just logged in (as shown by the 1 next to the key icon).




Logging Out

Always log out, when you have finished using the detector, because this prevents unauthorized personnel from accessing the APEX.

- 1) In the Main Menu screen, navigate to the security menu.




- 2) Press the Go button and the log screen appears.



(continued...)

3) Press the right-navigation button to highlight the log-out menu.



4) Press the Go button. The detector returns you to the Main Menu, which indicates you are now logged out.



Maintenance and Troubleshooting

This section describes how to maintain and test your APEX detector, and provides a troubleshooting guide to help you resolve problems should a fault occur.

Maintenance

You should regularly clean the APEX, if you want it to provide long-term, trouble-free operation. Please note that certain cleaning agents could affect the integrity and appearance of the plastics used on the search head. Read the labels on all cleaning agents to make sure they do not adversely affect polycarbonate- and polyester-plastic materials. If you have any questions about cleaning procedures, please contact Thermo Fisher Scientific—as described in the “Contacting Thermo Fisher Scientific” section at the end of the manual.

Cleaning

Please make sure that your cleaning procedures do not leave residues on the detector’s surfaces, because these might attract dust particles. In addition, please dry all surfaces after cleaning. In addition, please consult the suppliers of your cleaning agents to make sure they are suitable for use on conveyors and ancillary equipment, and use the appropriate dilution levels when cleaning

Do not use high-pressure hoses to clean the APEX as these may damage the APEX or cause breaches in the integrity of the unit. In addition, using high-pressure cleaning equipment may compromise safety and lead to problems with contamination.

Checking for Corrosion

Although the APEX is made from corrosion-resistant materials, corrosion may occur. For example, stainless steel prevents surface corrosion by rapidly producing a strong and inert oxide layer. Damage to this protective oxide layer may result if you rest iron objects on the detector’s surfaces. Please check for signs of corrosion on a regular basis and take preventative measures to stop corrosion occurring. Any sign of corrosion should be investigated. Please report any incidents of corrosion to Thermo Fisher Scientific.

Recommended Test Procedures

You should thoroughly test the detector and all reject devices when these are first installed, and whenever a major component of the system is changed or altered—for example, when any part is serviced or repaired. In addition, when setting up the test procedures for your particular working environment, please take note of the following considerations and recommendations.

Pass Test Samples Through the Center of the Search Head

The least sensitive part of the search head is along the centerline of the opening. As a result, it is best run test sample passes through the centerline of the opening. If the test sample is run at the side of the aperture or product tube, this will produce a larger signal than through the centerline. The test procedure should consider this for consistent results.

Choose Appropriately-Sized Test Samples

Sensitivity capabilities of different detectors used in different applications will vary. Smaller aperture is capable of detecting smaller pieces of metal. Product effect may also alter the detection capability. It is inadvisable to rely on a corporate standard to determine and test the detector's operation. Ideally, each detector should have its own standards of operation and a corporate outline should be used only as a maximum allowable guide. Sample sizes should be selected so that they are clearly detectable when compared to the signal produced by the product or other interfering signals. If samples are established which are very close to the product signal, frustration on the part of operators can lead to a lack of confidence in the detector's operation.

Use the Normal Product Flow-Rate During Testing

The detector should be tested at its normal operating speed. Test samples should be placed on conveyors so that they will pass through the detector at normal speed. On pipelines, test samples should be inserted so that they travel through the search-head at the product's normal flow. On gravity-feed and tablet/pharmaceutical applications, test samples should be placed so they fall from same point as the product.

Ferrous Metals Are Easier to Detect than Stainless Steel

The detector is not equally sensitive to all types of metal. Depending on the type of product and application there can be three typical metal groups which will produce three different levels of detection. Ferrous metals are the easiest to detect, and non-magnetic stainless steels are the most difficult to detect.

- Ferrous metals—any iron derivative.
- Non-ferrous metals—any good electricity-conducting metals such as aluminum, copper, brass, and so forth.
- Stainless steel—any of the 300-series stainless steels, which are non-magnetic. These are often the most difficult metals to detect.

Always Use Spherical Test Samples

Your test samples should contain spherical metal contaminants. Any other shape produces a different size signal, depending on its orientation as it passes through the search head. As a result, miscellaneous-shaped test samples can lead to inconsistent results.

Test the Entire Reject Process

In most applications, when the reject process fails, the reject device is to blame. So, always test the *entire* reject process to verify your reject device is working properly. In addition, make sure that, if the reject device fails, you can safely recover your test samples. If you have safety concerns about your reject process, please contact Thermo Fisher Scientific—as described in the “Contacting Thermo Fisher Scientific” section at the end of the manual.

Keep Things Simple So Testing Is Done Frequently

If the test procedures you implement are simple, you and your operators are more likely to do them on a regular basis. As a general rule, the detector should be tested once per shift, or—at a minimum—on a daily basis.

Keep Written Records of All Tests

You should keep detailed written records, as part of your overall quality-assurance program, of all tests done on the detector. Good records allow you to build up a historical record of the performance of the detector and its associated components over time, and will help you head off current problems and identify problems in the future.

Carefully Examine All Rejected Products

All rejected products should be carefully examined to determine exactly what type of contamination they contain, and—most important of all—to allow you to identify the exact *source* of the contamination. Rejected products, for example, should be examined as soon as the shift ends (or, at a minimum, on a daily basis), to ensure that problems upstream of your detector are identified and corrected in a timely manner.

Enable the Detector’s QA Test Function

Use the detector’s QA Test function to ensure that its performance will be tested on a regular basis by you or your operators.

Enable the Detector’s AuditCheck Function

If the optional AuditCheck hardware is installed on your detector, set up the AuditCheck function. When the AuditCheck function is enabled, the detector’s performance is automatically tested at regular intervals—without the need for operator intervention.

Troubleshooting Guide

When a fault is displayed in the detector's display panel, this troubleshooting guide will help you identify what problem has occurred and how to correct it. If the APEX detects a fault, the red LED indicator on the control panel turns on and stays lighted. In addition, the display panel will show a fault message. These are described in more detail below.

Search-Head Faults

Problem	Solution
The search-head cable connection is broken.	Examine the cable connections at both ends to make sure all wires are connected correctly.
The search-head balance is out of range.	This sometimes occurs when the APEX is moved. Please have the APEX reinstalled by a Thermo Fisher Scientific technician.
Other search-head problems.	Contact Thermo Fisher Scientific—as described in the “Contacting Thermo Fisher Scientific” section at the end of the manual.

Battery Low Fault

Problem	Solution
The battery powering the memory is becoming discharged when the main AC power to the detector is off.	Replace the battery and/or control panel. However, if the main AC power is not turned off, operation of the detector will not be affected.

Product Memory Fault

This fault indicates the product memory has been lost or damaged.

Problem	Solution
Low battery could cause memory to be lost when the unit is not powered.	Check the battery.
Detector has been subjected to high static discharges or lightning.	Erase the memory.

Speed-Encoder Fault

This type of fault only occurs in conveyor applications using an external speed encoder.

Problem	Solution
The detector is not getting a signal or a properly pulsed signal from the external speed encoder.	Retest APEX using a test sample and with the belt running. This may clear the fault. If not, check the functioning of the external speed encoder.

Reject-Confirm Fault

The faults may occur when the reject-confirm function has been enabled and the confirmation signal fails to return within the prescribed time limit.

Problem	Solution
The reject device has failed.	Check the action of your reject device and make sure it is working properly. Check the reject-confirm switch. Increase the reject-confirm time using the detector's reject-confirm function.
The reject device acted too slowly.	
The switch has failed on your reject-confirm device.	

Excessive Rejects Fault

Problem	Solution
This fault only occurs when the excess-reject-fault function has been activated, and indicates that an excessive number of rejects have occurred within the specified time window.	Press Clear Fault. Please note that this fault may be caused by excessive contamination in the product—so please examine the rejected product to see whether it is heavily contaminated.

Photo-Reject Fault

This type of fault only occurs in conveyor applications using a photo eye.

Problem	Solution
This fault occurs when the photo-reject function has been enabled, contaminated product has been detected, but the photo eye did not see the product.	Check the alignment of the photo eye. Make sure the product is breaking the beam, and check for reasons for false triggering such as metal in the belt. Perform a complete test of the detector including the reject device.

Photo-Eye Blocked Fault

This type of fault only occurs in conveyor applications using a photo eye.

Problem	Solution
This fault indicates that the photo eye has been blocked for an excessive amount of time.	Check the photo-eye for proper operation and alignment.

Phase-Limit Fault

Problem	Solution
This fault occurs when a phase limit has been reached during a learn phase or automatic phase period. It may be caused by contaminated product or metal elsewhere in the system.	If necessary, check and adjust the phase limits. Check for contaminated product and metal elsewhere in the system.

QA Test Response Fault

This type of fault only occurs in conveyor applications.

Problem	Solution
The QA test light has been ignored and the interval timer has expired.	Perform a QA test.

QA Test Result Fault

Problem	Solution
During the QA test, the required number of detections of a specific peak size did not occur.	Repeat the QA test so the required number of detections are achieved.

AuditCheck Fault

This fault only occurs if the optional AuditCheck hardware is installed on your APEX and you are using the detector's AuditCheck capabilities to monitor performance.

Problem	Solution
This fault occurs during an AuditCheck timed calibration and indicates that there is problem with the signal produced by the AuditCheck metal ball as it passes through the search head with your product.	Make sure that you have set up appropriate fault limits for the AuditCheck function, because the signal produced by your product will vary. Also, verify that the Alarm Limit and Fault Limit have not been inadvertently misapplied.

Service, Repair, and Replacement Parts

Listed below is information about how to get help servicing, repairing, and obtaining replacement parts for your APEX. In addition, Thermo Fisher Scientific provides experienced, on-site service technicians, who can assist you installing, setting up, calibrating, maintaining, and repairing your APEX. They can also help you train your operators and solve virtually any APEX-related problem.

Parts List Is Provided

For a detailed list of the spare parts available for your APEX, please refer to the Parts List in the “Supplemental Information” section at the end of the manual.

Forms Needed for Repairs or Returns

Before returning any equipment to Thermo Fisher Scientific, you *must* contact your nearest Thermo Fisher Scientific Office for an RMA number, which will authorize you to make the return. In addition, you will need to complete the appropriate Return Material Authorization (RMA) form, Product Information Sheet, and Decontamination Declaration Form, which are shown on the following pages, before returning any equipment to Thermo Fisher Scientific.

Contacting Thermo Fisher Scientific

Please refer to the “Contacting Thermo Fisher Scientific” section on page 399 of the manual.

Dear Customer,

Thank you for using our in-house repair service. To expedite your repair, control costs, and ensure that safety requirements are met, please follow these simple steps.

1. Send in a copy of this completed form with a copy of your purchase order (PO) to the fax number or email address in the "Contacting Thermo Fisher Scientific" section under "Obtaining an RMA Number" at the end of the manual. A return material authorization (RMA) number will not be issued without a hard-copy PO on file.
2. Once an RMA has been issued, you will be sent a shipping label noting your RMA number and the address to which to ship the parts. The assigned RMA number is valid for 30 days from the date of issuance. If your part or parts are not received within 30 days (45 days for international shipments), your PO will be cancelled and a new RMA will be required. All parts for repair *must* reference a valid RMA number, or the part will be returned at your cost.
3. Please do not ship partial shipments; your return must be complete. Any parts received separately will require a separate RMA. Return only those products that are authorized by the RMA. Additional products that are sent without approval, may not be returned to you.
4. If no defects are found in a product you return, an evaluation fee of \$250.00 per part (\$500.00 per full system) will be charged.

Return Material Authorization (RMA) Form

Thermo Fisher Scientific's safety policy requires a decontamination form for any package received into our building.

Contact Information

Contact Name _____ Email _____
Fax number _____ Phone number _____

Shipping Information

Company name _____
Address _____
City _____
State _____ ZIP _____

Billing Information (if different from above)

Company name _____
Address _____
City _____
State _____ ZIP _____

Tax exempt? Yes No

Payment Information (choose one)

- Credit card**—If you wish to pay by credit card, please contact Thermo Fisher Scientific (see the "Contacting Thermo Fisher Scientific" section at the end of the manual). Please note that in order to protect our customers from accidental data compromise, Thermo Ramsey Inc. does not accept credit-card numbers via email or fax.
- Purchase order**—If you wish to pay via PO, please send an official hard copy with this form.
- Warranty**

Product Information Sheet

Problem Part #1

APEX serial number _____

Part number _____

Description of part _____

Description of problem _____

Problem Part #2

APEX serial number _____

Part number _____

Description of part _____

Description of problem _____

Problem Part #3

APEX serial number _____

Part number _____

Description of part _____

Description of problem _____

Decontamination Declaration Form

Please complete all parts of the decontamination declaration form. In addition, please note the following.

- Orders without a completed decontamination declaration form will *not* be processed, and the equipment will be returned to the sender via collect freight.
- Please send this decontamination declaration form with a hard copy of your purchase order (PO) to the fax number or email address in the "Contacting Thermo Fisher Scientific" section at the end of the manual. Please retain a copy of this decontamination declaration form for your records.

System Description

Please provide a detailed description of your system, equipment, and the type of product analyzed.

Decontamination Procedures Already Performed

Please describe all cleaning and other decontamination procedures already performed on the equipment you are returning.

Check All That Apply

- Out-of-box failure Non-hazardous materials only Hazardous material (see below)

Hazardous Materials

- Carcinogen/pathogen Fungus/virus/bacteria Toxic/radioactive

- Corrosive/flammable/reactive chemical hazard

- Animal/plant/mineral

Explain _____

- Other

Explain _____

To the best of my knowledge, this equipment is free of harmful or hazardous chemical, biological, or radioactive contamination. I understand that if the equipment is found to be contaminated, regardless of the signature on this document, the equipment will be returned at my company's expense or may be subject to an additional decontamination fee of \$300.

Signature _____

Title _____ Date _____

Ordering Parts

For the fastest service when ordering parts, please telephone or fax the nearest Thermo Fisher Scientific office. For the office nearest you, please see the “Contacting Thermo Fisher Scientific” section at the end of the manual.

The quickest way to get the parts you need is to do the following.

- 1) Identify the broken or faulty parts.
- 2) Locate the parts in the Parts List (in the supplemental information section at the end of the manual).
- 3) Find the part numbers for the items you need.
- 4) Before you contact Thermo Fisher Scientific for your parts, make sure you have the following information.
 - Your APEX model and serial number.
 - Your company’s purchase order (PO) number.
 - The date the parts are needed.
 - Your preferred shipping method.
 - A list of all the part numbers—together with descriptions and the quantities needed.
- 5) Contact Thermo Fisher Scientific by telephone or fax—as described in the “Contacting Thermo Fisher Scientific” section at the end of the manual.

Please Note

Modifications and repairs should only be performed under the supervision of a Thermo Fisher Scientific Service Engineer and with written consent from Thermo Fisher Scientific.

List of Commonly Required APEX Spare Parts

Listed below are the commonly required spare parts and fuses used by your APEX. Please only use spare parts as directed by Thermo Fisher Scientific or one of the company’s authorized agents. In addition, please note that PCB’s *must* be sourced from Thermo Fisher Scientific. Fuses, however, can be sourced from any reputable supplier, providing their rating is identical to the following.

- F1 (PSU PCB)—250 v AC, 3.15 A, 35 A breaking capacity. Typically, the following types of fuses are recommended.
 - Bussmann 3.15 A Radial lead micro fuse BK/ETF type
 - Bussmann 3.15 A Fast acting BK/EFF type
 - Wickmann 3.15 A Anti-surge TR5 type
 - Wickmann 3.15 A Fast acting TR5 type
 - Bussmann PC-Tron 3A type
- F1 to F6 (Relay PCB) 250v AC, 2A.

Installing Your APEX Detector

The first thing to do is unpack and inspect your detector and then familiarize yourself with its basic operating, environmental, safety, installation, and wiring requirements.

Please read the “Theory of Operation” section, because this will help you properly install the detector as well as operate it successfully. You should also note that one of the keys to making a successful installation is minimizing two types of interference. For example, installing the detector near electric motors (which are a *major* source of radio-frequency interference) or close to large metal objects will negatively affect its performance.

Once you’ve covered the theory part, you’ll move on to the practical “nuts and bolts” details about how to hard wire your detector as described on page 283. Thereafter, you may need to set up and wire in additional components such a product reject device and so on. Please go to page 291 (the “Mechanical Set-Up” section) for more details.

For now, let’s get on with unpacking the detector. Your APEX is a sensitive instrument and should not be handled in rough manner. Doing so may affect the integrity of the equipment and cause failure or compromise safety.

Unpacking Your APEX

Your APEX metal detector has been properly packaged for shipment. Inspect all packages before opening. If there is any evidence of shipping damage, notify the shipping carrier immediately, because the carrier may be responsible for the damage.

Check the contents of the shipment against the order or packing slip. Be sure to look for any accessories, such as reject devices or product tubes ordered and shipped with the detector. Some of the component pieces are small and may be inadvertently discarded with the packaging.

Check the equipment for any signs of damage in shipment. If there is any evidence of shipping damage, notify the shipping carrier immediately. Included with each APEX metal detector are the following.

- APEX Metal Detector User’s Guide—the manual you are currently reading.
- Quick-Start manual.
- Installation and mounting parts.
- Metal test samples.

List of Included Components

Your metal detector comprises the following components.

- *Search-Head Case and Coils*
Products are passed through the aperture of this case.
Note: If remote mounting has been specified, there is a separate control unit/PSU (2 m [7 ft] standard cable to 30 m (98 ft) maximum).
- *Search-Head PCB*
The search-head PCB is the interface to the coils in the search head. It drives the oscillator coils with a radio-frequency signal to produce an alternating magnetic field in the aperture.
- *Control Panel*
The control panel houses the power supply, the I/O PCB, and all processing and display functions.

Safe Storage Conditions for Your APEX

Your APEX metal detector and associated equipment can be safely stored in ambient temperatures of -10 to 50° C (14 to 122° F) with a non-condensing humidity of 80%.

APEX Specifications

There are three models of APEX—the APEX 500, APEX 300, and APEX 100. The principal difference between the three models has to do with aperture size—the size of the opening through which the product passes to be analyzed for metallic contaminants.

Specifications for the APEX 500, 300, and 100

Listed below are the technical specifications for the APEX 500.

Product Speed

Depends on product dimension and belt speed

Outputs

Six NO relays (All available as solid-state open-collector, if required. Contact Thermo Fisher Scientific—as described in the “Contacting Thermo Fisher Scientific” section at the end of the manual—for details.)

- Relays
 - 250 volt AC 1 amp max
 - 50 volt DC 1 amp max
- FET
 - 30 VDC, 1 amp max (NO compatible)
 - Output Allocation (Menu selectable)
 - Reject 1, Reject 2, AuditCheck™, Fault, Alarm, Warning, and QA Lamp

Inputs (Menu Selectable)

Six Inputs, Active 12v DC + 12 volt auxiliary supply for input sensors for the following.

- Belt Speed Sensor (uses 5v auxiliary supply provided)
- Keylock
- Product Select 1
- Product Select 2
- Infeed photo-eye
- Reject Confirmation 1 (bin full)
- Reject Confirmation 2
- External Suppression

Electrical Supply

85 to 260 VAC, 47 to 65 Hz, 100 watts maximum

Product Speed

0.5 m/min (1.7 ft/min) to 1000 m/min (3,300 ft/min)

Air Supply (AuditCheck™)

5.5 bar (80 psi)

Environmental

- Operating Temperature
 - -10° C to + 40° C (+14° F to +104° F)
- Relative Humidity
 - 0% to 80% non-condensing
 - 80% to temperatures to 31° C (87° F) decreasing linearly to 50% relative humidity at 40° C (104° F)

Maximum Surface Temperature

60° C (140° F)

Altitude

Up to 2000 m (1.2 miles)

Location

Indoor or outdoor use. Direct sunlight on the aperture could cause problems. Protect the equipment from direct sunlight.

Environmental Protection

IEC60529: IP66
NEMA 4X

Ventilation

None required

Front Panel

Manufacturers: GE Plastics, Chi Mei

Material reference: Cicolac, Polylac 757

Surface treatments: None

Operating temperature: Continuous at 80° C (176° F)

Battery

Approved type according to Table 3 of IEC 60086-1 Type E.

Battery type: Sonnenschein SL-350 PCRN

Nominal voltage: 3.6 V

Electrochemical system: Lithium thionyl-chloride

Rated capacity: 1000 mA-hours

Standard Features and Options

Listed below are the standard features and options available for your APEX 500, 300, and 100 detector.

Standard Features

Your APEX included the following standard features.

- Patented multi-coil design
- Ease of operation.
- Reject confirmation.
- Product capacity of 100.
- Variable speed operation.
- Dual frequency/dual gain.
- Epoxy-lined head rated to IP66.
- Two independent reject outputs.
- Quality test on consecutive units of product.
- Icons with help text in ten languages.
- Sensitivity performance enhancement.
- Reject inhibit to prove reject verification system.
- AuditCheck™ and quality-assurance rejects to a separate reject bin.
- A bright display with a wide viewing-angle.

Statistics and Information

Your APEX provides the following user information and statistics.

- Current product name.
- Total number of rejected units of product.
- Number of units of product rejected by the quality test.
- Number of units of product rejected by AuditCheck™.
- Number of units of product passed (when in package mode).
- Error messages using LEDs and warning screens.

Options

Optional features of your APEX are as follows.


- Remote control panel located up to 30 meters away.
- Certified test spheres.
- White polypropylene aperture liner.
- AuditCheck™ performance validation system.
- Conversion kits to change a DSP3 to an APEX.
- Field compression flanges, which reduce the metal-free zone.

Printer Options

A local rewind or remote printer option is available. In addition, the printer is able to print batch reports. Printouts are available in one of ten languages.

Theory of Operation

Your APEX operates on the balanced coil full-loop detection system. Traditionally, three equally spaced coils surround the aperture or opening through which inspected material passes. The central coil connects to an oscillator circuit to produce a magnetic field. The coils on either side of the central coil receive this signal. These are the receiving or input coils.



Since the input coils are equally spaced from the oscillator, they receive equal amounts of signal. The coils are wound in such a way that their signals oppose each other so the net signal across them is zero. When a piece of metal enters the magnetic field, it alters the field strength around it. As this metal passes through the aperture, it changes the balance of the receiving coils so that the net signal is no longer zero.

The APEX uses more than three coils in its design. Up to three pairs of oscillator coils provide higher levels of sensitivity over traditional methods. Parallel and series arrangements of coils are used. These new coil arrangements are patented. The APEX still uses two receive coils to produce the metal signal.

A digital signal processor (DSP) processes this signal. The DSP performs the product compensation, phasing, residual compensation filtering, and produces a reject signal. Your APEX detector is a high performance, measuring instrument. The quality of the installation has a direct effect upon performance and reliability. Please read the installation instructions completely prior to installing the unit.

Definition of Various Product Effects

Metal detectors are capable of detecting metal by measuring two effects: resistive and reactive effects.

Resistive Effect

Electrically conductive materials and many food products by nature are electrically conductive. Salt and moisture content combine to produce resistive effects that must be overcome in order to detect small metal contaminants.

Reactive Effect

Ferro-magnetic and electrically conductive materials produce reactive effects. Iron is both electrically conductive and ferro-magnetic. The effect for small iron particles is ferro-magnetic, which is largely opposite that of a metal such as copper. Copper is a strong electrical conductor.

Dry Products

Dry products produce very little, or zero product effect. Examples of dry products are some tablets, cookies, candy, chocolate, dry powders, oil-based products such as peanut butter, and cereals.

Wet Products

Wet products produce a larger product effect. Examples of wet products are bread, buns, cakes, meat, and dairy products.


Metal Film Products

Products packaged using metallic wrappers usually require a low search-head frequency such as 50 kHz.

Product Phase Angle

The APEX measures magnetic field changes and derives reactive and resistive components. A “clean” product changes both components proportionately and this proportionality allows the APEX to discriminate between product characteristic and metal. When metal is present, the ratio of resistive to reactive components is not constant.

When the APEX learns the product, it converts the ratio between reactive and resistive components to a phase angle. Once this angle is known, a clean product passing through the aperture can be largely ignored.



As a general rule, the following phase angles are representative of the following types of contaminants and non-contaminated products.

Degrees	Contaminant or non-contaminated product
+ 130	Metallic (ferrous) contaminants, such as iron.
+ 90	Dry, non-conductive products, such as grains and cereals.
+ 65	Non-ferrous metallic contaminants, such as copper.
+ 20–30	Metallic contaminants, such as stainless steel.
0	Wet, conductive products, such as fresh meats and breads.

Table Showing How Type of Metal, Size of Metal, and Frequency Affect Phase Angle

Metal/Size		300KHz	200KHz	150KHz	100KHz
Ferrous	—1.0mm	98°	96°	96°	94°
	—4.0mm	130°	120°	114°	108°
Non-ferrous	—1.0mm	42°	30°	25°	20°
	—4.0mm	82°	78°	72°	64°
316 stainless	—2.0mm	10°	8°	6°	5°
	—4.0mm	48°	34°	26°	16°

Understanding Some Basic Detector Vocabulary

Listed below are definitions to help you understand some of the terms that will be used while setting up and operating your detector. In addition, many of these terms are defined in the manual's Glossary on page 393.

Phase

The phase angle of the product effect.

Locked

Locked parameters are not automatically updated during a product learn. The detect level and phase angle can be individually "locked" during a product learn, indicating their previous value is not re-learned. A padlock symbol on the screen indicates a parameter is "locked."

Frequency

The operating frequency of search head is as follows: 50 kHz, 100 kHz, 150 Hz, 200 kHz, 300 kHz, and 500 kHz. The APEX is capable of switching between two frequencies, typically 50 kHz and 300 kHz, or 100 kHz and equal to or above 300 kHz.

Head Gain

Head gain is the signal amplification of the search-head hardware. Gain is controlled via the detector's main menu and can be high or low.

Thresholds

Thresholds are maintained for resistive and reactive effects and, if exceeded, usually indicate a product is present.

Detect level

If the signal from metal or noise exceeds the detect level, then the reject output activates.

Safety Precautions

Listed below are the safety precautions for your APEX detector. Please read them *carefully*, because this information is important—for your own personal safety and the safety of others.

General Safety Precautions

Do not install, operate, or perform any maintenance procedures until you have read the safety precautions listed below.

Warning

Failure to follow safe installation and servicing procedures could result in **death or serious injury**.

- Make certain only qualified personnel perform installation and maintenance procedures in accordance with the instruction in this manual.
- Allow only qualified electricians to open and work in the electronics cabinets, power supply cabinet, control cabinet, or switch boxes.
- Covers over the electronics and rotating parts must always remain in place during normal operation. Remove only for maintenance, with the machine's power OFF. Replace all covers before resuming operation.
- During maintenance, a safety tag (not supplied by the factory) to be displayed in the ON/OFF switch areas instructing others not to operate the unit (ANSI: B157.1).

Warning

High voltage that may be present on leads could cause **electrical shock**.

- All switches must be OFF when checking input AC electrical connections, removing or inserting printed circuit boards, or attaching voltmeters to the system.
- Use extreme caution when testing in, on, or around the electronics cabinet, PC boards, or modules. There are voltages in excess of 115 V or 230 V in these areas.

Warning

Use only the procedures and new parts specifically referenced in this manual to ensure specification performance and certification compliance. Unauthorized procedures or parts can render the instrument **dangerous to life, limb, or property**.

Warning

Keep hands and clothing away from all moving or rotating parts.

Warning

Do not place or store objects of any kind on the machine.

Warning

This machine should not be operated at more than the production rate stated on your Equipment Specification sheet, used in applications other than those stated in the original order, or in a manner not specified by Thermo Fisher Scientific. To do so may impair the protection provided by the machine.

Warning

The APEX is cCSAus and CE approved and can be used in environments containing combustible dusts. All modifications to the APEX must be approved in writing from Thermo Fisher Scientific. This is to prevent any possibility of a modification causing a breach of the integrity of the equipment, which might lead to the ignition of dust or other safety infringement.

Specific Safety Precautions

The precautions listed below are specific to the APEX. Read them carefully before using the machine.

Warning

Humidity can cause surfaces of the detector to become damp, which in turn can attract deposits of dust. Dust layers may be regarded as unhygienic and can be an explosion hazard. Please ensure the APEX surfaces are regularly checked for build-up of dust and any dust layers that form should be removed.

Warning

The ambient temperature for the APEX operation is -10°C to $+40^{\circ}\text{C}$ (14°F to 104°F). The APEX will not produce surface temperatures greater than $+60^{\circ}\text{C}$ (140°F) at an ambient temperature of $+40^{\circ}\text{C}$ (104°F). If APEX is used in a Zone 22 combustible dust environment, ensure the ambient temperature does not exceed $+40^{\circ}\text{C}$ (104°F).

Warning

The aperture is normally sealed with resin epoxy having a thermal stability adequate for the temperature of most products on conveyor belts under all operational conditions. However, some products may be "hot" when passing through the aperture and this may eventually degrade the resin epoxy. Ensure "hot" products passing through the aperture do not raise the surface temperature of the resin above $+60^{\circ}\text{C}$ (140°F). An aperture liner that protects the resin may be required if the product temperature is too high.

Electrical Set-Up

All wiring, except as noted, is the responsibility of the customer. Detailed below are the general electrical requirements and the types of supply voltage and connections needed when installing your APEX detector. Please follow these requirements *carefully*—for your own personal safety and the safety of others. In the following instructions, the acronym “PSU” refers to the detector’s power supply unit, “PCB” refers to a printed circuit-board, and “PCB–A” refers to a printed circuit board assembly.

Potential Causes of Interference

The detector is a balanced alternating-current magnetic sensor, and—as a result—is subject to interference from a variety of external mechanical, electrical, and magnetic sources. These potential sources of interference are described in more detail below.

Mechanical Vibration

Mechanical vibration induces alternating-current eddy patterns in the detector’s metal case, which may interfere with the detector’s *X*-channel. If the vibration is severe, the *R*-channel may also be affected.

Electro-Magnetic Induction

When electro-magnetic currents are induced in external hardware and cables, this may cause three types of interference, as follows.

- *“Dirty” Power Lines*
This type of interference may occur when several pieces of equipment are connected to the same power line. In most cases, variable-frequency drive motors are the culprits. In general, any equipment that utilizes switching technology is a potential source of contamination. Both the *X*- and *R*-channel may be affected.
- *Magnetic Fields Caused by High Currents in Wires and Cables (Near-Fields)*
When high electrical currents pass through wires and cables they create magnetic fields, known as “near-fields.” These near-fields may interfere with the detector’s *X*- and *R*-channels, especially when high-current cables lie in close proximity to the detector.
- *Electromagnetic Waves*
This source of interference is less common, but is still a valid concern—especially when the external wave interferes with a vital internal frequency in the detector’s circuitry. Both the *X*- and *R*-channel may be affected.

Alternating Conducting Loops

Alternating conducting loops (known as “loop effects”) may create noise in the detector. A loop effect may be created when a conductive path that varies in time, lies in close proximity to the detector. When a loop effect is created, the *X*-channel is the one most likely to be affected.

Static Electricity

Sometimes, in conveyor applications, static electricity is generated when the belt and slider-bed rub against each other. Because a moving or static charge is a form of electrical current, moving or static charges may produce a magnetic field that randomly interferes with the magnetic field produced by the search head. This type of interference creates noise in the detector and may affect both the *X*- and *R*-channel.

Moving Metal

When metal moves through a magnetic field, it creates a current. Thus, any metal that moves near the detector may cause interference in the detector—interference that is easily confused with the effects of vibration.

Permanent Magnets and Electro-Magnets

If permanent magnets and electro-magnets are allowed near the detector, they can cause interference—especially those that move or are situated very close to the detector. Interference from these sources may affect with the detector's *X*- and *R*-channels.

General Electrical Requirements

When choosing the AC power line for the detector, note that starting heavy electrical machinery creates momentary volt-drops in the line. Such spikes can cause the detector to trigger.

- When the control unit is mounted remotely from the search head, the cable connecting it to the search head is of a specific type. Do not substitute or splice on extra cable. Cable can be cut to length and is not sensitive to movement. If required, contact Thermo Fisher Scientific—as described in the “Contacting Thermo Fisher Scientific” section at the end of the manual—for extra cable or cable information.
- Be sure to observe the following critical wiring conditions to ensure proper connection of your detector
- Ensure main power is OFF.
- Earth all enclosures and conduits. An earth connection between all metal conduits is required.
- Connect the shields only where shown.
- Check that all wires are tight in their connections.
- Never use a “megger” to check the wiring.
- All conduits should enter the bottom of the enclosure. Do not run conduit through the top or sides of the enclosure.

Caution

Externally connected appliances shall comply with their relevant safety requirements. Please ensure appliances (such as solenoids and photo-eyes) are rated for the voltage they will be connected to and the field wiring into the search head is appropriately rated in terms of current and insulation.

Caution

Ensure that AC power (mains) supply fluctuations do not exceed $\pm 10\%$ of the nominal voltage.

Caution

Do not install the APEX in a position that makes it hard to use the AC mains isolator.

Note: The normal level of transient over voltages is impulse withstand (over voltage) category II of IEC 60364-4-443.

Note: Elsewhere in this manual are instructions for correct termination of cables. The APEX does not use plugs and sockets for connection of external field wiring. If such a method is required, contact Thermo Fisher Scientific—as described in the “Contacting Thermo Fisher Scientific” section at the end of the manual—for recommended methods.

Supply Voltage and Connections

Given below are the requirements for the voltage supply and connections to your APEX detector.

- Input supply voltage range should not be outside the range 85VAC to 264VAC.
- We recommend the APEX be fed from a clean AC supply and left powered.
- Connections are made inside the control panel on the PSU PCB. Do not “tee” off with wiring for other external electrical equipment (even other metal detectors).
- When choosing the AC power line for the detector, note that starting heavy electrical machinery can create considerable (though momentary) volt-drops in the line. This can cause the detector to trigger. Since detector power consumption is only 35 watts, it is recommended that a lighting circuit be used rather than machinery power circuit. Where this is not possible and line noise triggers the detector, contact Thermo Fisher Scientific—as described in the “Contacting Thermo Fisher Scientific” section at the end of the manual—for recommendations about a suitable isolation transformer or power-line filter.

Note: *Do not* use loads requiring power sources not generated or used by the APEX, unless approved by Thermo Fisher Scientific.

System Grounding

On all metal detection systems, it is important for safety and performance to implement good grounding techniques. This should be made at the appropriate point at the PSU PCB. Care must also be taken to ensure that the head or frame does not carry earth fault or operating currents from other systems. Earth ground connections should be made at one point in the system, and this point is the PSU PCB.

Use waterproof cable glands at all cable entries. Recommended cable entries are listed in this manual on page 288.

Caution

All wiring must be done in accordance with field wiring diagrams, the National Electrical Code, and all local electrical codes. Do not route coil cables through the same conduit with power cables or any large source of electrical noise.

Removing the Control Panel

Before removing the control panel, make sure the AC power supply is off. The control panel is held in place with eight mounting bolts. Remove these bolts to gain access to the search-head power supply unit (PSU) and relay printed circuit boards (PCBs).

Remote search heads have a separate control panel to access the PSU and relay PCBs.

Note: The control panel also has internal PCBs for the operator display, keypad, and signal processing. If any of these items need replacing, disconnect the PSU and search-head cables that connect to them.

Caution: When removing or working with the control panel be careful when tightening the screws. Do not tighten them too tight or breakage will occur.

Caution: When removing the PSU PCB, ensure that star (crinkle) washers are used on the two PCB-mounting pillars adjacent to J1 (mains AC power in) and J2. Additionally, ensure that pillars between relay PCB and PSU PCB are properly tightened and secured.


AC Power Wiring

The detector power consumption is only 35 watts. It is recommended a lighting circuit be used rather than a machinery power circuit. If this is not possible, and the line noise triggers the detector, contact Thermo Fisher Scientific—as described in the “Contacting Thermo Fisher Scientific” section at the end of the manual—for recommendations of a suitable isolation transformer or power-line filter.

Wiring AC Power into the PSU PCB–A

We recommend using an AC power source that is not connected to heavy-duty loads or loads that might cause interference or dropouts in the supply. We do not recommend sharing an AC power source that feeds powerful motor invertors, because they can cause interference problems. Use a light circuit and supply the detector with an isolator switch.

J1 has a removable receptacle. Remove it and connect AC power (85 VAC to 264 VAC). Ensure a good earth ground to J1. See the figure below for the location of J1.



Caution

Do not wire outputs directly from the PSU PCB–A. There are six open collector outputs provided on the PCB that may be connected to solenoids powered from DC voltages not exceeding 24 VDC nominal. Do not use these outputs unless you have specialized knowledge.

If you need volt-free relay outputs, please use the PCB–A mounted on the PSU.

Installing Cable and Conduit to Your APEX

There are six cable/conduit entry points on the APEX. These are located beneath the plastic front panel. The APEX is supplied with a number of entries containing blanking plugs. The remainder contain cable/conduit entries. Use only the correct type of cable entry. Below is a table listing the suitable parts.

Supplier	Parts (long threads required)	Cable Sizes
Hummel	1.291.2000.30 (Grey) 1.291.2001.30 (Black) 1.291.2002.30 (Blue) 1.291.200x.31 (same as above) 1.295.200x.30 (same as above) 1.295.200x.31 (same as above)	6.5mm to 12mm diameter 6.5mm to 12mm diameter 6.5mm to 12mm diameter 5.0mm to 9.0mm diameter 10 mm to 14mm diameter 7.0mm to 12mm diameter
Jacob	50.620PASWL/EX (Black) 50.620PABL/L/EX (Blue) 50.620PASWL/EXSI (Black) 50.620PABL/L/EXSI (Blue)	5.5mm to 13mm diameter 5.5mm to 13mm diameter 5.5mm to 13mm diameter 5.5mm to 13mm diameter
Rolec	570.803.M20 (Black) 570.804.M20 (Blue)	8.0mm to 13mm diameter 8.0mm to 13mm diameter
Mencom	PCGEX-M20L (Grey) PCGEX-M20L-B (Black)	5.0mm to 13mm diameter 5.0mm to 13mm diameter
ATX	095605 (Black)	
All suppliers provide blanking plugs that replace the part above or fit into the part above. Suitable parts for use with conduit are also available from some of these suppliers.		

When installing cables into the APEX there is a possibility of external cable twists being transmitted into the internal connections. Avoid this by using 1) external grips, 2) suitably designed cable entries, or 3) conduit. The APEX has been designed to accept plastic flexible conduit. Metal conduit of any type should *not* be used.

The APEX accommodates the use of cable entries by providing six oversized M20 plain holes. This feature requires a locking nut sufficiently tightened on the inside of the front panel. Ensure that cable entry manufacturer's guidelines are followed when mounting these parts. Pay particular attention to maintaining a high-integrity seal.

Input-Wiring Board—Pin Assignments

This section describes the wiring inputs to the detector's PSU PCB-A. Typical inputs include a photo eye, micro-switch, or key lock. There are six inputs, as shown in the table below.

Connector	Name	Application
J3 pin 1	12v	12v feed to power a photo-eye
J3 pin 2	Input 2	Input, internal pull-up—connect to 0v to activate
J3 pin 3	0v	Ground/ return connection for photo-eye
J3 pin 4	12v	12v feed to power a photo-eye
J3 pin 5	Input 3	Input, internal pull-up—connect to 0v to activate
J3 pin 6	0v	Ground/ return connection for photo-eye
J3 pin 7	12v	12v feed to power a photo-eye
J3 pin 8	Input 4	Input, internal pull-up—connect to 0v to activate
J3 pin 9	0v	Ground/ return connection for photo-eye
J3 pin 10	12v	12v feed to power a photo-eye
J3 pin 11	Input 5	Input, internal pull-up—connect to 0v to activate
J3 pin 12	0v	Ground/ return connection for photo-eye
J4 pin 1	12v	12v feed to power a photo-eye
J4 pin 2	Input 6	Input, internal pull-up—connect to 0v to activate
J4 pin 3	0v	Ground/ return connection for photo-eye
J4 pin 4	5v	5v feed to speed sensor LED incorporating current limit
J4 pin 5	LED	Current limited feed to speed sensor LED only
J4 pin 6	Input 1	Speed sensor input—exclusively used on this input
J4 pin 7	0v	Ground/ return connection for speed sensor

Caution

Do not use these inputs for connection to any system or unit having signal voltages outside the range ground to 12 V, because damage may occur.

Inputs


Given below are the default applications for Inputs 1–6.

Input	Default Application
Input 1	Speed sensor
Input 2	In-feed photo eye
Input 3	Reject Confirm/Bin Full
Input 4	Not assigned
Input 5	Not assigned
Input 6	Not assigned

Note: Inputs can also be assigned to Bin Full, Product Select 1, Product Select 2, Key Lock, and Reject Suppression.

Output-Wiring Board—Relay Settings and Fuses

This PCB is mounted above on the PSU PCB. When removing this PCB or refitting it (service action), ensure connectors J4 and J5 line up correctly with their mating halves on the PSU PCB.



Replacing Fuses

All fuses, F1–F6, are 2 Amp, 250-volt, fast-acting fuses. When replacing a fuse on Relays 1–6, use only this type of fuse.

Fuse	Rating	Relay Number
F1	2 amp, 250 volt, fast-acting fuse	Relay 1
F2	2 amp, 250 volt, fast-acting fuse	Relay 2
F3	2 amp, 250 volt, fast-acting fuse	Relay 3
F4	2 amp, 250 volt, fast-acting fuse	Relay 4
F5	2 amp, 250 volt, fast-acting fuse	Relay 5
F6	2 amp, 250 volt, fast-acting fuse	Relay 6

Mechanical Set-Up Instructions for Specific Applications

Now that you have completed the electrical installation of your APEX detector, the next step is to complete the mechanical installation. The type of mechanical set-up required depends on which type of application you are installing—a conveyor, a gravity-feed, a pipeline, or pharmaceutical application. Find the relevant mechanical set-up instructions as follows.

- Conveyor applications—Go to the page that follows this one (page 292).
- Gravity-feed and pharmaceutical applications—Go to page 299.
- Pipeline applications—Go to page 307.

Mechanical Set-Up for Conveyor Applications

The APEX with options is easily integrated into most conveyor line systems and requires a minimal amount of adjustment. Correctly installed, the metal detector will operate reliably for long periods without attention.

The customer is responsible for initial inspection of the equipment and site preparation. It is essential that the customer place the equipment in the production line in accordance with the guidelines below. The customer must assure that qualified service personnel are available to make interconnections with other production equipment and perform work at the installation site. A Thermo Fisher Scientific Products Customer Service Representative is available to supervise installation and verify operation, as well as train personnel assigned to operate and maintain the equipment.

APEX Installation Considerations

Customers who intend to install the APEX on an existing conveyor or a Thermo Fisher Scientific-supplied conveyor, should study the following factors that can influence the detector's performance. The importance of studying this section and taking note of the information given is very important. It has been proven that faulty metal detector operation, such as random false alarm signals and undue sensitivity to vibration, are usually due to incorrect installation of the metal detector or some other factors external to the metal detector itself.

Location of the Detector

The APEX should be located to give easy access to the front panel. The installation location of the display and/or electronics box should be considered.

Mounting the APEX

For trouble free and reliable operation, it is very important that the APEX be correctly mounted. The support structure for mounting the APEX must transmit a minimum amount of vibration to the metal detector. This structure must be flat and parallel, thereby minimizing possible twisting torques to the metal detector case, which can distort the electromagnetic field and cause false triggering. While the APEX and the support structure may remain in contact, nothing, including the product, must be allowed to touch any part of the aperture, as this could cause wear of the aperture lining and give random false alarms. Any pressure, torque, or electrical ground will cause the APEX to misfire. Any support platform, guide rails, or conveyor belt (including the joint in the belt) which passes through the aperture must be completely free of all metal, and must not touch any part of the aperture at any time. The packaging on any product to be inspected must be completely free of any metal such as clips, aluminum foil, metallic labels, staples, and lids.

Metal-Free Area

For optimum performance, non-moving metal should be allowed no closer to the aperture opening than 1.5 times the smallest aperture height, measured outward from the center of the aperture. Moving metal should be allowed no closer to the aperture opening than 2.0 times the smallest aperture height, measured outward from the center

of the aperture. When a complete conveyor system has been supplied by Thermo Fisher Scientific, these considerations have already been factored in to the design of the system.

Factors That Can Influence the Operation of the Detector

It has been proven that causes external to the APEX, are the main reasons for faulty operation or random false triggering. When installing the APEX on an existing or custom-built conveyor system, this information below should be carefully studied. Only when correctly installed will the equipment perform optimally. The APEX may have been installed correctly initially, but conditions change and these may cause intermittent problems with the metal detector. If the APEX develops fault symptoms such as intermittent triggering, the factors below should be carefully studied before any electronic servicing is contemplated.

Conveyor Belt

Any conveyor belt passing through the APEX must be totally metal free. Sometimes metal particles or grease that has become loaded with metallic dust, becomes embedded in the conveyor belt during use. Spilled product may also become embedded in the belting. This generally occurs with woven belts and the contamination will trigger the APEX each time it passes through the aperture. Plastic, plastic-covered, or rubber belts should be used whenever possible. The joint in the belt must be made of a non-metallic fastener or vulcanized.

Carbon-loaded anti-static belts can cause random alarm signals, especially when the APEX is operating at a high sensitivity.

Aperture Clearances

The conveyor belt, product guides, and the product must be completely free of all metal and must not touch the aperture in any way, whether on the top, bottom, or sides of the aperture. The belt must not be allowed to wander from side to side and rub on the inside of the aperture, because this could damage the aperture lining or cause false tripping. Before fitting product guide-rails, check that they are completely metal free by passing them through the APEX (if possible) before installation. Suitable guide-rail materials include polyethylene, polypropylene, PBVC, wood, and wood laminates.

Metal in the Packaging Material

Packaging material must be totally free from metal clips, fasteners, labels, metallic ink, and foil. Certain types of low-grade cardboard, especially recycled cardboard, may contain pieces of metal or metallic foil that may be detected when operating at high sensitivity.

Mounting

The support structure used for mounting the APEX to the conveyor, should be constructed in a way that minimizes the amount of vibration transmitted to the APEX. This structure must be flat and parallel. This minimizes possible twisting torques to the case of the detector, which will distort the electromagnetic field and cause false triggering.

Vibration and Mechanical Shocks

Some level of vibration is present in most industrial environments, and the APEX is designed to operate satisfactorily under these conditions. However, false triggering may be caused by sudden bumps or by dumping heavy loads onto the conveyor belt, particularly when working at very high detection sensitivities. The APEX or its conveyor should not be fixed directly to a vibrating packaging or processing machine.

Electrical Loops

Intermittent electrical loops are the largest single cause of faulty metal detector operation. The search field in the metal detector sets up a high-frequency electrical field in the aperture. The metal case of the search head acts as a screen to prevent metal outside the detector head affecting the search field. Some of the high-frequency electrical field from the search coils does escape from the aperture through which the product passes. This field can cause very small electrical currents to flow in nearby metal structures. This causes no problem if the loops are completely closed, but, if the electrical path is intermittent, then false triggering of the detector is likely.

Typical causes of intermittent electrical loops include loose bolts on the conveyor or on the detector's mounting, corrosion of metal work, broken welds, open hinged doors, conveyor idler rollers, and broken or rubbing contacts.

Interference can be overcome by opening the conductive path with an insulating pad or closing the path by welding or tightening the bolts so that it cannot become intermittent.

Loop problems in rollers can usually be overcome by mounting the idler rollers closest to the APEX on an insulating block. The metal bolts joining the roller to the insulating block should not make metal-to-metal contact with the conveyor or APEX.

An intermittent closed loop on a conveyor may also be due to lubricated bearings whose balls act as electrical contacts, and whose resistance therefore varies as they move through the lubricant. The source of such loop interference can be very elusive and difficult to locate. The larger the aperture in the APEX the greater the high-frequency leakage out of the aperture and the greater the possibility of trouble from loops.

Metal Objects Near the Search Head

The metal detector is very efficiently screened, and metal near the top, bottom, and ends will not significantly affect the detector performance. However, metal positioned close to the aperture can cause interference problems if it moves or vibrates. The area close to the aperture, which should be kept metal free, is known as the metal-free zone. This metal-free zone is dependent upon the aperture dimensions and the sensitivity setting of the detector.

The metal detector is sensitive to moving metal. It is not always possible to discriminate if the metal is passing through the head or moving outside the head. Metal in the metal-free zone may cause the detector to be sensitive to vibration.

If the APEX vibrates or is accidentally bumped, it will cause relative movement between the detector and the offending metal, which could trigger the detector.

Electrical Interference

It is always good practice to suppress electrical interference at its source and, if trouble is experienced, the offending source should be located and suppressed. If this is not possible, it may be necessary to operate the APEX at a reduced sensitivity.

A relay in the metal detector is often used to control solenoid valves, power contractors, and similar electrical devices. When these devices are switched off, the collapsing field of the winding generates a wide- band interference, which may be picked up by the search coils in the detector head and cause false triggering.

A capacitor of suitable capacity and working voltage connected across the offending device and grounded as close to the device as possible will often provide satisfactory suppression.

Pneumatic Air

Connect incoming air to the detector's air-regulator fittings using a coiled copper tube or air hose. Adjust the incoming air pressure to 30–40 PSI (2.1–2.5 kg/cm²) for pneumatic devices, or 40–80 PSI (2.8–5.6 kg/cm²) for air rejects.

Head Balancing

Metal detectors are sensitive instruments and, after they have been shipped or moved, we recommend the head be re-commissioned by a suitable certified Thermo Fisher Scientific field-service representative.


Photo-Eye Installation and Connection

A photo eye is used for conveyor systems inspecting discrete products or packages. Refer to the specific photo-eye installation manual for installation procedures. A photo-eye is necessary to use the following APEX features.

- Automatic product tracking
- Reverse detection
- Photo-registered reject timing

Conveyor Separation

If there is a separate conveyor for the metal detector system, be certain this conveyor does not make contact with the in-feed and discharge conveyors. Fastening them with a non-metallic material is the recommended method, as shown below.




Loop Effects and Roller Isolation

Besides observing rules for metal-free areas, precautions must be taken to prevent the occurrence of loop effects. A loop effect is caused by an electrical loop in the conveyor, making intermittent contact.


Loop effect is caused by an electrical loop in the conveyor, making intermittent contact. This loop, when closed, can produce large electromagnetic fields. When the loop opens, the field collapses very rapidly, causing the detector's field to be disturbed. This results in false detection.

The following can cause loops.

- Rollers whose bearings make an intermittent connection.
- Any metal that crosses the conveyor frame and is not securely fastened—such as the transfer plate, loose cross members, electrical conduit, and retracting-reject or flap-gate reject devices.



Note: A loop effect becomes greater in detectors having an aperture height greater than five inches (125 mm) and a width greater than 12 inches (300 mm), as shown in the figure below.



Loops as far as 3 ft (1 m) away may affect the operation of the detector, depending on roller, bearing, frame materials, and on the quality of the contact. To avoid loop effects due to these causes, the following steps are recommended.

- All cross members and transfer plates should be welded or securely fastened.
- Rollers cannot be secured, but should be isolated from making electrical contact.

Note: Only one side of each roller assembly needs to be isolated. Do *not* isolate both ends.


Roller Isolation Methods

The materials generally used to isolate rollers are plastic and phenolic. Care should be taken to ensure raw products do not come into direct contact with phenolic materials. Listed below are several methods for isolating rollers to prevent loop effects.

Stub Shaft Method


With this design, the roller shaft does not continue through the roller. This separation removes the electrical loop within the roller, as shown below.

Note: The roller must be non-metallic.




End Cap Method

Placing a closed-ended plastic cap on one end of the roller shaft breaks the electrical connection between the shaft and bearing assembly, as shown below.



Roller Bearing Isolation Method

Isolating the bearing assembly requires isolation of the housing and mounting bolts. An insulating sleeve is used to electrically isolate the bearing housing from the conveyor frame. Plastic inserts are used to isolate the mounting bolts from the bearing assembly, as shown below.



Plastic Bearing Roller

The plastic bearing assembly is one of the easiest designs to implement. Most plastic bearings are available in standard mount designs. However, some plastic bearings contain a metal sleeve in the mounting holes, which is internally connected to the bearing raceway. With this bearing, plastic inserts should be used to create the electrical isolation.

The Next Step

Now that you have completed the electrical and mechanical set up for your conveyor application, please go to the "Getting Started" section on page 11 to learn how to operate your newly installed APEX detector.

Mechanical Set-Up for Gravity-Feed and Rx Applications

The APEX detector is designed specifically for use in gravity-feed and pharmaceutical (Rx) applications. If this system was supplied complete, with a framework, non-metallic throughput tube, and automatic divert valve, it will require a minimal amount of installation and adjustment. When a search head only is provided, proper installation is critical. Correctly installed, the metal detector will operate reliably for long periods without attention.

The customer is responsible for initial inspection of the equipment and site preparation. It is essential that the customer place the equipment in the production or process line, in accordance with the guidelines below. The customer must assure that qualified service personnel are available to make interconnections with other production equipment and perform work at the installation site. A Thermo Fisher Scientific Products Customer Service Representative is available to supervise installation and verify operation, as well as train personnel assigned to operate and maintain the equipment.

APEX Installation Considerations

Customers who intend to install the APEX metal detector, should study the following factors that can influence the detector's performance. The importance of studying this section and taking note of the information given is very important. It has been proven that faulty metal detector operation, such as random false alarm signals and undue sensitivity to vibration, are usually due to incorrect installation of the metal detector or some other factors external to the metal detector itself.

Location of the Detector

The APEX controls should be located to give easy access to the front panel. The installation location of the display and/or electronics box should be the first consideration.

Mounting the APEX

For trouble free and reliable operation, it is very important that the APEX be correctly mounted. The support structure for mounting the APEX must transmit a minimum amount of vibration to the metal detector. This structure must be flat and parallel, thereby minimizing possible twisting torques to the metal detector case which can distort the electromagnetic field and cause false triggering. While the APEX and the support structure may remain in contact, nothing including the product, must be allowed to touch any part of the aperture as this could cause wear of the aperture lining and give random false alarms. Any pressure, torque, or electrical ground will cause the APEX to misfire. Any support platform, or throughput pipe that passes through the aperture must be completely free of all metal and must not touch any part of the aperture at any time.

Metal-Free Area

For optimum performance, non-moving metal should be allowed no closer to the aperture opening than 1.5 times the smallest aperture height, measured outward from the center of the aperture. Moving metal should be allowed no closer to the aperture opening than 2.0 times the smallest aperture height, measured outward from the center

of the aperture. When a complete system with frame and throughput tube has been supplied by Thermo Fisher Scientific, these considerations have already been factored in to the design of the system.

Factors That Can Influence the Operation of the Detector

It has been proven that causes external to the APEX, are the main reasons for faulty operation or random false triggering. When installing the APEX on an existing or custom-built gravity system, follow the instructions below. Only when correctly installed, will the equipment perform optimally. The APEX may have been installed correctly initially, but conditions change and these may cause intermittent problems with the metal detector. If the APEX develops fault symptoms such as intermittent triggering, the factors in this section should be carefully studied before any electronic servicing is contemplated.

Throughput Tubes

Any tube material passing through the APEX must be totally metal free. Sometimes metal particles or grease that has become loaded with metallic dust, becomes embedded in the tube due to static cling.

Plastic throughput materials supplied by Thermo Fisher Scientific use a unique anti-static compound to help dissipate static. These materials will not disrupt the metal detector and provide superior performance in static-prone areas.

Aperture Clearances

The plastic throughput must not touch the aperture in any way at any time. Touching the inside of the aperture can cause nuisance rejects.

Mounting

The support structure used for mounting the APEX, should be constructed in a way that minimizes the amount of vibration transmitted to the APEX. This structure must be flat and parallel. This minimizes possible twisting torques to the case of the detector, which will distort the electromagnetic field and cause false triggering.

Vibration and Mechanical Shocks

Some level of vibration is present in most industrial environments, and the APEX is designed to operate satisfactorily under these conditions. However, false triggering may be caused by sudden bumps or dumping heavy loads, particularly when working at very high detection sensitivities. The APEX should not be fixed directly to a vibrating packaging or processing machine.

Electrical Loops

Intermittent electrical loops are the largest single cause of faulty metal detector operation. The search field in the metal detector sets up a high frequency electrical field in the aperture. The metal case of the search head acts as a screen to prevent metal outside the detector head affecting the search field. Some of the high-frequency electrical field from the search coils does escape from the aperture through which the product passes. This field can cause very small electrical currents to flow in nearby metal structures. This causes no problem if the loops are completely closed, but, if the electrical path is intermittent, then false triggering of the detector is likely.

Typical causes of intermittent electrical loops include loose bolts on the framework or on the detector's mounting, corrosion of metal work, broken welds, open hinged doors, and broken or rubbing contacts.

Interference can be overcome by opening the conductive path with an insulating pad or closing the path by welding or tightening the bolts so that it cannot become intermittent.

The source of such loop interference can be very elusive and difficult to locate. The larger the aperture in the APEX, the greater the high-frequency leakage out of the aperture and the greater the possibility of trouble from loops.

Metal Objects Near the Search Head

The metal detector is very efficiently screened and metal near the top, bottom, and ends will not significantly affect the detector performance. However, metal positioned close to the aperture can cause interference problems, if it moves or vibrates. The area close to the aperture, which should be kept metal free, is known as the metal-free zone. This metal-free zone is dependent on the aperture dimensions and the sensitivity setting of the detector. The search head is sensitive to moving metal. It is not always possible to discriminate if the metal is passing through the head or moving outside the head. Metal in the metal-free zone may cause the detector to be sensitive to vibration.

If the APEX vibrates or is accidentally bumped, it will cause relative movement between the detector and the offending metal, which could trigger the detector.

Electrical Interference

It is always good practice to suppress electrical interference at its source and, if trouble is experienced, the offending source should be located and suppressed. If this is not possible, it may be necessary to operate the APEX at a reduced sensitivity.

A relay in the metal detector is often used to control solenoid valves, power contractors, and similar electrical devices. When these devices are switched off, the collapsing field of the winding generates a wide-band interference, which may be picked up by the search coils in the head and cause false triggering.

A capacitor of suitable capacity and working voltage connected across the offending device and grounded as close to the device as possible, will often provide satisfactory suppression.

Pneumatic Air

Connect incoming air to the detector's air-regulator fittings using a coiled copper tube or air hose. Adjust the incoming air pressure to 30–40 PSI (2.1–2.5 kg/cm²) for pneumatic devices, or 40–80 PSI (2.8–5.6 kg/cm²) for air rejects.

Components of a Gravity-Feed Application

The gravity-feed system must only be lifted and installed using the support frame. At no time must the metal detector be used for lifting. The ideal way to maneuver the equipment is to use support straps from the frame and lift into position. The frame must be bolted into position ensuring a good earth connection. The chute/pipe section may then be bolted in position. Care must be taken to avoid any weight or undo strains on the chute.

A gravity-feed system consists of the following three major components.


- *Search Head*
The search head contains the search-head board and the inspection coils the material passes through.
- *Control Unit and Integral Power Supply*
The control unit contains the user interface controls, processing electronics, and should always be mounted remotely. The power supply unit, which houses power supplies, input/output devices and the connection terminal strip, should always be mounted remotely.
- *Reject Valve and Support Structure*
The reject valve and support structure are used on gravity applications. The structure supports the metal detector; reject valve and product inspection tube. The control unit and power supply may be mounted directly to the structure.

Mounting Methods

The typical mounting method is to suspend the system with a threaded rod. The threaded rod should support the complete load of the system. When securing the threaded rod to the frame, the isolation bushing should be used on all four mounting holes. This electrically isolates the frame from any support structure.

The system is designed to support the metal detector, reject assembly, and associated parts. Discharge and reject piping should have their own support structures. Hanging piping from these ports may distort the reject body and render the reject inoperable. It is equally important that input piping should be independently supported and not supported by the metal detector's product tube.


It is necessary to electrically isolate the support from the hanging rods. Use nylon bushings to do this. Two bushings are needed on each mounting hole to isolate both the upper and lower mounting nuts, as shown in the figure below.



If you have any questions about installation requirements and restrictions, please contact Thermo Fisher Scientific—as described in the “Contacting Thermo Fisher Scientific” section at the end of the manual.

Testing a Gravity-Feed System

When testing a gravity-feed system it is important to test both the sensitivity of the detector and the response of the reject valve. To accomplish this a metal test sample must be inserted at or near the zero velocity point of the product. Also a means for retrieving the test sample after it goes through the system should be incorporated in case the reject device fails to operate.



Test Procedures for Gravity-Feed and Rx Systems

A complete and thorough test of the metal detector system must be done upon initial installation and whenever a major component of the system has been changed or altered. A complete check of the metal detector must include the reject device. Any test procedure designed for your application should take into account the following.

Pass the Product Through the Detector's Centerline

The metal detector's least sensitive point in the aperture is along the centerline of the opening. Any testing should be done so that the test sample passes approximately through the centerline of the opening. If the test sample is run at the side of the product tube or between the product tube and the detector, this will produce a larger signal than through the centerline.

Factors Affecting the Sensitivity of the Detector

Sensitivity capabilities of different detectors used in different applications will vary. A smaller aperture is capable of detecting smaller pieces of metal. Product effect may also interfere with the detection capability. It is dangerous to rely on a corporate standard to determine and test the detector's operation.

Ideally, each detector should have its own standards of operation and a corporate outline should be used only as a maximum allowable guide. Sample sizes should be selected so that they are clearly detectable (peak signal size of approximately double the detect level), when compared to the signal produced by the product or other interfering signals. If samples are established which are very close to the product signal, frustration on the part of operators can lead to a lack of confidence in the detector's operation.

The detector should be tested at its normal operating speed. Test pieces should be inserted so that they travel through the detectors at the product's normal rate of flow. This ensures that the detector and reject device responses are accurately tested.

The detector is not equally sensitive to all types of metal. Depending on the type of product and application, there can be three typical metal groups, which will produce three different levels of detection, as follows.

- Ferrous—typically, any magnetic metal is the easiest to detect.
- Non-ferrous—any good electrical conducting metal such as aluminum, copper, brass, and so forth.
- Stainless steel—the 300-series stainless steels, which are non-magnetic, tend to be the most difficult metals to detect.

Test samples used should contain spherical metal contaminants. Any other shape will produce a different size signal depending on its orientation as it passes through the detector. This can lead to inconsistent results. In addition, any test procedure established must allow for the test product to be completely rejected by the reject device. The reject device will tend to be the most likely point of failure in any detector system.

Care must be taken so that if the detector or reject device fails to operate correctly, the test sample can still be recovered. This can be achieved by the use of a second valve or a removable catch grid, which can operate as a fail-safe device, catching the test sample and allowing product to flow through. Contact Thermo Fisher Scientific for assistance—as described in the “Contacting Thermo Fisher Scientific” section at the end of the manual.

Note: If insertion testing is difficult to achieve, “side of the pipe” method may be used for frequent sensitivity testing. Adjustment to the test sample size should be made to compensate for the increase in sensitivity of the metal detector as you near the side of the aperture. Under most circumstances the metal detection will be approximately 0.5 to 1.0 mm more sensitive as you reach the edge of the aperture. If this method is used it is highly recommended that you use reject confirmation to ensure the correct performance of the system.

Testing Schedule

The user must decide how often the detector should be tested. If the test procedure can be designed to be simple, it will help ensure that the test will be performed more

frequently. As a guide it must be decided how much product would have to be put on hold for re-inspection, if a detector fails the test. Typically the minimum frequency is once per shift, while other applications require hourly tests be performed.

Rejected Product Examination

If possible, product, which has been rejected by the detector during production, should be examined to establish the source and type of contamination. This may lead to an improvement in the process equipment upstream from the detector. It is also useful to display these contaminants so that all employees can see the benefit of the metal detector.

Tube Size

Use the following formula to calculate the approximate duct/chute dimensions for the system.

$$\text{In}^2 = \frac{\text{Flow Rate (lbs/hr)}}{\text{Bulk Density (lbs/ft}^3\text{)}} \times 0.024$$

Choose the duct/chute size so the product fills no more than 80% of the product tube.

Here is an example. If the product to be inspected has a bulk density of 30 lbs/cubic ft, and a flow rate of 15,000 lbs/hr, the result would be 12 square inches. With 80% fill, the chute should be sized to 15 square inches. The dimensions of the metal detector should be kept to the smallest size possible for the best sensitivity. It is then a matter of choosing a product tube with the same square inches that is best suited for the application. In the above example you could use a chute dimension as follows.

- 127 mm (5") x 76 mm (3").
- 203 mm (8") x 51 mm (2"), or 129 mm (4.75") diameter.

By choosing the 203 mm (8") x 51 mm (2") chute there will be a smaller stroke on the reject valve and a faster reaction time. The metal detector will be approximately 25 mm (1") larger on both the length and width (rounded up to the next available size), giving an aperture of 250 mm (9.8") x 75 mm (3"). If the product is prone to bridging, the 127 mm (5") x 76 mm (3") or 120 mm (4.75") diameter units would be preferable. Contact Thermo Fisher Scientific—as described in the “Contacting Thermo Fisher Scientific” section at the end of the manual—for further assistance.

The Next Step

Now that you have completed the electrical and mechanical set up for your gravity-feed application, please go to the “Getting Started” section on page 11 to learn how to operate your newly installed APEX detector.

Mechanical Set-Up for Pipeline Applications

The APEX detector is designed specifically for use in a pipeline application. If this system was supplied complete with a framework, non-metallic throughput tube, and automatic divert valve, it will require a minimal amount of adjustment. When a search head only is provided, proper installation is critical. Correctly installed, the metal detector will operate reliably for long periods without attention.

The customer is responsible for initial inspection of the equipment and site preparation. It is essential that the customer place the equipment in the production or process line in accordance with the guidelines below. The customer must assure that qualified service personnel are available to make interconnections with other production equipment and perform work at the installation site. A Thermo Fisher Scientific Products Customer Service Representative is available to supervise installation and verify operation, as well as train personnel assigned to operate and maintain the equipment.

APEX Installation Considerations

Customers who intend to install the APEX metal detector, should study the following factors that can influence the detector's performance. The importance of studying this section and taking note of the information given is very important. It has been proven that faulty metal detector operation, such as random false alarm signals and undue sensitivity to vibration, are usually due to incorrect installation of the metal detector or some other factors external to the metal detector itself.

Location of the Detector

The APEX controls should be located to give easy access to the front panel. The installation location of the display and/or electronics box should be the first consideration.

Mounting the APEX

For trouble-free and reliable operation, it is very important that the APEX be correctly mounted. The support structure for mounting the APEX must transmit a minimum amount of vibration to the metal detector. This structure must be flat and parallel, thereby minimizing possible twisting torques to the metal detector case, which can distort the electromagnetic field and cause false triggering. While the APEX and the support structure may remain in contact, nothing, including the product, must be allowed to touch any part of the aperture, as this could cause wear of the aperture lining and give random false alarms. Any pressure, torque, or electrical ground will cause the APEX to misfire. Any support platform, or throughput pipe that passes through the aperture must be completely free of all metal, and must not touch any part of the aperture at any time.

Metal-Free Area

For optimum performance, non-moving metal should be allowed no closer to the aperture opening than 1.5 times the smallest aperture height, measured outward from the center of the aperture. Moving metal should be allowed no closer to the aperture opening than 2.0 times the smallest aperture height, measured outward from the center

of the aperture. When a complete system with frame and throughput tube has been supplied by Thermo Fisher Scientific, these considerations have already been factored in to the design of the system.

Factors That Can Influence the Operation of the Detector

It has been proven that causes external to the APEX, are the main reasons for faulty operation or random false triggering. When installing the APEX on an existing or custom-built pipeline system, the instructions below should be carefully studied. Only when correctly installed will the equipment perform optimally. The APEX may have been installed correctly initially, but conditions change that may cause intermittent problems with the metal detector. If the APEX develops fault symptoms such as intermittent triggering, the factors in this section should be carefully studied before any electronic servicing is contemplated.

Throughput Tubes

Any tube material passing through the APEX must be totally metal free. Sometimes metal particles or grease that has become loaded with metallic dust, becomes embedded in the tube.

Aperture Clearances

The plastic throughput must not touch the aperture in any way at any time. Touching the inside of the aperture can cause nuisance rejects.

Mounting

The support structure used for mounting the APEX, should be constructed in a way that minimizes the amount of vibration transmitted to the APEX. This structure must be flat and parallel. This minimizes possible twisting torques to the case of the detector, which will distort the electromagnetic field and cause false triggering.

Vibration and Mechanical Shocks

Some level of vibration is present in most industrial environments and the APEX is designed to operate satisfactorily under these conditions. However, false triggering may be caused by sudden bumps or dumping of heavy loads nearby, particularly when working at very high detection sensitivities. The APEX should not be fixed directly to a vibrating packaging or processing machine.

Electrical Loops

Intermittent electrical loops are the largest single cause of faulty metal detector operation. The search field in the metal detector sets up a high-frequency electrical field in the aperture. The metal case of the detector head acts as a screen to prevent metal outside the detector head affecting the search field. Some of the high-frequency electrical field from the search coils does escape from the aperture through which the product passes. This field can cause very small electrical currents to flow in nearby metal structures. This causes no problem if the loops are completely closed, but, if the electrical path is intermittent, then false triggering of the detector is likely.

Typical causes of intermittent electrical loops include loose bolts on the framework or on the detector's mounting, corrosion of metal work, broken welds, open hinged doors, and broken or rubbing contacts.

Interference can be overcome by opening the conductive path with an insulating pad or closing the path by welding or tightening the bolts so that it cannot become intermittent.

The source of such loop interference can be very elusive and difficult to locate. The larger the aperture in the APEX, the greater the high-frequency leakage out of the aperture and the greater the possibility of trouble from loops.

Metal Objects Near the Search Head

The metal detector is very efficiently screened and metal near the top, bottom, and ends will not significantly affect the detector performance. However, metal positioned close to the aperture can cause interference problems, if it moves or vibrates. The area close to the aperture which should be kept metal free is known as the metal-free zone. This metal-free zone is dependent upon the aperture dimensions and the sensitivity setting of the detector.

The metal detector is sensitive to moving metal. It is not always possible to discriminate if the metal is passing through the head or moving outside the head. Metal in the metal-free zone may cause the detector to be sensitive to vibration.

If the APEX vibrates or is accidentally bumped, it will cause relative movement between the detector and the offending metal, which could trigger the detector.

Electrical Interference

It is always good practice to suppress electrical interference at its source and, if trouble is experienced, the offending source should be located and suppressed. If this is not possible, it may be necessary to operate the APEX at a reduced sensitivity.

A relay in the metal detector is often used to control solenoid valves, power contractors, and similar electrical devices. When these devices are switched off, the collapsing field of the winding generates a wide-band interference, which may be picked up by the search coils in the detector head and cause false triggering.

A capacitor of suitable capacity and working voltage connected across the offending device and grounded as close to the device as possible, will often provide satisfactory suppression.

Pneumatic Air

Connect incoming air to the detector's air-regulator fittings using a coiled copper tube or air hose. Adjust the incoming air pressure to 30–40 PSI (2.1–2.5 kg/cm²) for pneumatic devices, or 40–80 PSI (2.8–5.6 kg/cm²) for air rejects.

The Next Step

Now that you have completed the electrical and mechanical set up for your pipeline application, please go to the "Getting Started" section on page 11 to learn how to operate your newly installed APEX detector.

Safety and Warranty Information

Please read this section carefully, because it contains important safety and warranty information for which you are responsible.

Software License

This document is confidential and is the property of Thermo Fisher Scientific Inc. It may not be copied or reproduced in any way without the express written consent of Thermo Fisher Scientific. This document also is an unpublished work of Thermo Fisher Scientific. Thermo Fisher Scientific intends to, and is maintaining the work as confidential information. Thermo Fisher Scientific also may seek to protect this work as an unpublished copyright. In the event of either inadvertent or deliberate publication, Thermo Fisher Scientific intends to enforce its rights to this work under the copyright laws as a published work. Those having access to this work may not copy, use, or disclose the information in this work unless expressly authorized by Thermo Fisher Scientific.

“Microsoft” and “Windows” are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries.

All other trademarks are the property of Thermo Fisher Scientific Inc. and its subsidiaries.

Terms of the Software License

The software program is licensed, not sold. Thermo Fisher Scientific Inc. grants you a license for the software program only in the country where you acquired the equipment, as defined below. You obtain no rights other than those granted you under this license.

The term “equipment” means the equipment with which the software program is used. The term “software program” means the original and all whole or partial copies of the software program used in connection with equipment sold by Thermo Fisher Scientific to the user, including modified copies or portions of the software program. Thermo Fisher Scientific retains title to the software program, as well as all improvements, modifications and enhancements to the software program, whether made by Thermo Fisher Scientific or any other party. Thermo Fisher Scientific owns, or has licensed from the owner, copyrights in the software program.

You are responsible for the selection of the equipment.

Following the commissioning of the equipment, any change made by the user to the software program will terminate all warranties with respect to the equipment and software program.

All other trademarks are the property of Thermo Fisher Scientific Inc. and its subsidiaries.

Allowed Uses Under the License

Under this license, you may do the following.

Use the software program on only one piece of equipment at any one time, unless the license information specifies otherwise.

Copy the software program for backup or in order to modify it.

Modify the software program and/or merge it into another software program.

Subject to the following limitations, transfer the possession of the software program to another party, but only in connection with a transfer of the equipment.

If you transfer the software program, you must transfer a copy of these license terms, all other documentation and at least one complete, unaltered copy of the software program to the other party. Unless you have other copies of the software program to be used in connection with other equipment purchased from Thermo Fisher Scientific, or one of its divisions, you must, at the same time, either transfer all your other copies of the software program to the transferee of the equipment or destroy them. Your license is then terminated. The other party agrees to these terms and conditions by its first use of the software program.

You must reproduce the copyright notices(s) on each copy of the software program.

You may not do the following.

Use, copy, modify, merge, or transfer copies of the software program except as provided in this license.

Reverse engineer, decompile, or disassemble the software program.

Sub-license, rent, lease, or assign the software program.

Limitation of Remedies

Thermo Fisher Scientific's liability under this license is as follows.

Thermo Fisher Scientific will: (a) replace defective media, or (b) make a warranted software program operate or (c) replace the software program with a functionally equivalent software program, as warranted.

For any claim (including breach), in any form, related in any way to this license, Thermo Fisher Scientific's liability will be for the actual value of the software program.

Thermo Fisher Scientific will not be liable for any lost profits, lost savings, any incidental damages, or other economic consequential damages, even if Thermo Fisher Scientific, or its authorized supplier, has been advised of the possibility of such damages. Thermo Fisher Scientific will not be liable for any damages claimed by you based on any third party claim.

General Conditions of the License

Thermo Fisher Scientific may terminate your license if you fail to comply with the terms and conditions of this license. In such event, you must destroy all your copies of the

software program. You are responsible for payment of any taxes, including personal property taxes, resulting from this license.

Using the APEX in USA and Europe

Please note the following.

Occupational Safety and Health Act (OSHA)

The Occupational Safety and Health Act clearly places the burden of compliance on the user of the equipment and the act is generalized to the extent that determination of compliance is a judgment decision on the part of the local inspection. Hence, Thermo Fisher Scientific will not be responsible for meeting the full requirements of OSHA in respect to the equipment supplied or for any penalty assessed for failure to meet the requirements, in respect to the equipment supplied, as interpreted by an authorized inspector. Thermo Fisher Scientific will use their best efforts to remedy such violation at a reasonable cost to the buyer.

European Directives

Thermo Fisher Scientific products sold in Europe are compliant with European Directives relating to CE marking and all heads or systems (head, product transport, and rejecting mechanisms) are labeled in accordance with the directives. Product labeling is affixed securely, visible to the user, and contains the following information.

Warnings of any residual risk (nip points, reject mechanisms, inside PSU areas).

Name and address of Thermo Fisher Scientific.

Year of manufacture.

Product type.

Serial number.

Supply voltage and frequency.

Maximum rated current.

Identification of the protective earth terminal.

CE mark on machines.

Other Certifications

The APEX is designed to operate in all parts of the world and, as such, is marked with a label bearing CE and cCSAus marks. In addition, the APEX is designed to be used in atmospheres where combustible dust may sometimes be present. An explanation is given on the marking label.

The APEX is designed to operate in a Zone 22 hazardous area and complies with the following standards.

- IEC 61242 Electrical Apparatus for Use in the Presence of Combustible Dust—Part 0 (General Requirements)
- IEC 61241 Electrical Apparatus for Use in the Presence of Combustible Dust—Part 1 (Protection by Enclosures “tD”)

Important Safety Notices about Using the APEX

Please note carefully the following safety warnings and notices.

Intended Uses for the Detector

Your metal detector is intended to be used in food, pharmaceutical, and other applications where the presence of metal contaminants is undesirable. It must not be used for any other purpose. Your metal detector runs automatically and does not require constant operator presence. During calibration, the operator's presence will be required for up to five minutes typically. He/she will manually feed calibrated metal test sticks onto the product transport mechanism and verify that reject mechanisms associated with the installation operate successfully. Product transport mechanisms are usually located at waist height, as are reject mechanisms and user controls. We recommend to customers that metal detector systems be sited within their premises conveniently for setting up and calibration.

Safety in Transportation and Handling

Metal detector heads and systems form an integral part of your plant and when transporting, handling, and installing the unit, your own plant safety instructions must be applied. Because your metal detector and systems are tailored to application requirements, it is impossible to be precise about product mass/weight. If precise values are required, the shipping crate will be marked with the overall shipping mass of the product and this may be used as a reasonable guideline.

Ensuring User Safety

Metal detector systems are usually incorporated into a customer product line. If the metal detection system is fitted with product guards, there may be mechanical hazards present. The customer must ensure that upstream or downstream areas do not allow access to the mechanical hazards. Typically, some reject mechanisms are powerful and could cause non-minor damage to personnel if guarding is not in place. Because the reject mechanism is usually at the downstream end of the equipment, the customer must ensure that sufficient guards are fitted downstream to prevent operator access into these areas.

Safe Practices During Use, Maintenance, and Repair

This manual contains details as appropriate including the appropriate tools. However, because of its importance, the warning contained in the maintenance section is repeated here.

TO GUARANTEE PERSONAL SAFETY, CARE MUST BE TAKEN WHEN WORKING ON OR AROUND CONVEYORS, REJECT MECHANISMS, OR PRODUCT TUBES. AS WITH ALL SUCH DEVICES THE MAIN SUPPLIES (ELECTRICAL AND AIR) TO THE SYSTEM MUST BE LOCKED OFF WHEN PERFORMING REPAIR OR MAINTENANCE WORK. AFTER DISCONNECTING THE AIR SUPPLY TO THE SYSTEM, CYCLE ANY REJECT MECHANISMS TO EVACUATE ANY AIR LEFT IN THE SYSTEM. THEN SWITCH OFF AND LOCK THE ELECTRICAL SUPPLY.

Safe Disposal of the Detector

See Safety in Transportation, Handling and Installation for procedures. There are no hazardous materials used on the metal detector head or system.

Training Needs of Users

We offer all customers full training for operations and maintenance staff.

Electrical Safety of the Detector

Please note the following.

Earth Ground

For more information, see page 286.

Supply-Voltage Requirements and Connections

For more information, see pages 285 and 288.

Other Wiring During Installation

For more information, see page 284.

Electro-Magnetic Environment

Loss of sensitivity and false rejecting can occur under the following conditions. Your metal detector is located close to equipment using variable speed controllers or high frequency heating equipment.

Your metal detector is located close to another metal detector operating at similar frequencies.

Walkie-talkie, hand-held or radio frequency devices are operated close to the metal detector.

Loss of sensitivity may go unnoticed due to radio-frequency (RF) signal “swamping” the input circuits. If there is any doubt, check calibration of the search head under these circumstances. For assistance in finding solutions to your EM problems, contact Thermo Fisher Scientific—as described in the “Contacting Thermo Fisher Scientific” section at the end of the manual.

Low Voltage Directives

All of the recommendations for EMC apply to the prevention of electrical shock. If access to the PSU area is required, the incoming AC power supply should be isolated remotely and locked-off. Access to the PSU area by untrained personnel is not recommended.

Circuit Breaker

The APEX should be permanently connected to its AC supply. Please ensure that when installing the APEX, a switch or circuit breaker is used and is positioned close to the metal detector in easy reach of the operator. The switch or circuit breaker shall be marked as the disconnecting device for the metal detector.

DO NOT install the APEX in a position that makes it hard to use the AC mains isolator.

Thermo Fisher Scientific Warranty

The seller agrees, represents, and warrants that the equipment delivered hereunder shall be free from defects in material and workmanship. Such warranty shall not apply to accessories, parts, or material purchased by the seller unless they are manufactured pursuant to seller's design, but shall apply to the workmanship incorporated in the installation of such items in the complete equipment. To the extent, purchased parts or accessories are covered by the manufacturer's warranty; seller shall extend such warranty to buyer.

Seller's obligation under said warranty is conditioned upon the return of the defective equipment, transportation charges prepaid, to the seller's factory in Minneapolis, Minnesota, and the submission of reasonable proof to seller prior to return of the equipment that the defect is due to a matter embraced within seller's warranty hereunder. Any such defect in material and workmanship shall be presented to seller as soon as such alleged errors or defects are discovered by purchaser and seller is given opportunity to investigate and correct alleged errors or defects and in all cases, buyer must have notified seller thereof within one (1) year after delivery, or one (1) year after installation if the installation was accomplished by the seller.

Said warranty shall not apply if the equipment shall not have been operated and maintained in accordance with seller's written instructions applicable to such equipment, or if such equipment shall have been repaired or altered or modified without seller's approval; provided, however, that the foregoing limitation of warranty insofar as it relates to repairs, alterations, or modifications, shall not be applicable to routine preventive and corrective maintenance which normally occur in the operation of the equipment.

"EXCEPT FOR THOSE WARRANTIES SPECIFICALLY CONTAINED HEREIN, SELLER DISCLAIMS ANY AND ALL WARRANTIES WITH RESPECT TO THE EQUIPMENT DELIVERED HEREUNDER, INCLUDING THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR USE. THE SOLE LIABILITY OF SELLER ARISING OUT OF THE WARRANTY CONTAINED HEREIN SHALL BE EXCLUSIVELY LIMITED TO BREACH OF THOSE WARRANTIES. THE SOLE AND EXCLUSIVE REMEDY FOR BREACH OF THE WARRANTIES SET OUT ABOVE SHALL BE LIMITED TO THE REPAIR OR REPLACEMENT OF ANY DEFECTIVE ACCESSORY, PART OR MATERIAL WITH A SIMILAR ITEM FREE FROM DEFECT, AND THE CORRECTION OF ANY DEFECT IN WORKMANSHIP. IN NO EVENT SHALL SELLER BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES."

Purchaser agrees to underwrite the cost of any labor required for replacement; including time, travel, and living expenses of a Thermo Fisher Scientific Field Service Engineer at the closest factory base.

Thermo Fisher Scientific
501 90th Avenue NW
Minneapolis, MN 55433
Phone: (800) 227-8891
Fax: (763) 783-2525

Disclaimer

Though the information provided herein is believed to be accurate, be advised that the information contained herein is not a guarantee for satisfactory results. Specifically, this information is neither a warranty nor guarantee, expressed or implied, regarding performance, merchantability, fitness, or any other matter with respect to the products, and recommendation for use of the product/process information in conflict with any patent. Please note that Thermo Fisher Scientific reserves the right to change and/or improve the product design and specifications without notice.

Revision History

Listed below is the revision history of the *APEX User's Guide*.

Revision number	Date released	ECO #	Details of the release
Revision A	July 2006	1054	First release of documents and software, version 1.0.0.
Revision B	January 2007	1322	Updated name to Thermo Fisher Scientific and APEX 500. New specifications and operating instructions added for APEX 500.
Revision C	March 2007	1369	Added specifications and operating instructions for APEX 100. Added information about using the APEX oscilloscope software.
Revision D	July 2007		Updated to include APEX 300 and gravity-feed and pipeline applications.
Revision E	August 2008		Updated the entire manual to make it more user-friendly.
Revision F	February 2009	2077	Added Appendix A describing the optional Modbus Communications Card.
Revision G	March 2009	2163	Made minor changes to <i>APEX User's Guide</i> .
Revision H	October 2009	2205	Added Appendix B describing the IntelliTrack XR (IXR) option.
Revision J	June 2010	2624	Added information about using the wide-band speed filter in the Rx.


Appendix A—Modbus Communications Card

Overview

The optional APEX Modbus Communications Card is a hardware add-on that allows the APEX to communicate with your company's Ethernet, intranet, or other internal network. The APEX Modbus Communications Card comes in two versions, as follows. Which one you need depends on the communications protocol used by your existing network.

- *Modbus TCP/IP Communications Card*—This card allows your APEX to communicate with Ethernet and other networks using the transmission control protocol/internet protocol (TCP/IP).
- *Modbus RTU Communications Card*—This card, which you can configure either as an RS-232 or RS-485 card, allows your APEX to communicate with networks using the remote terminal unit (RTU) communications protocol.

Please note that version 3.0 or higher of the detector's operating software is needed for the Modbus Communications Card to work. If you are not sure which version of the software is currently installed on your APEX, please navigate to page 5 of the detector's system and tools menu, which is shown below. (This screen shows that version 3.0 of the detector's operating software is currently installed.)



For more information about how to navigate to the Software Version screen, please see page 193.

What the Modbus Communications Card Does

The Modbus Communications Card allows you to do the following.

- Use your network to remotely access APEX parameters.
- Change products remotely.
- Get real-time statistics—such as current reject count—from the APEX.
- Back up critical APEX settings.

These are described in more detail in the following sections.

Get Remote Access to APEX Parameters

One of the main advantages of the Modbus Communications Card is that it allows you to set up many APEX parameters remotely using Modbus protocols. To do this, you will need a desk-top computer (linked via your network to the Modbus card) running an application such as Modscan, PC Master, or other similar program. Please note the following minor limitations.

- You cannot access the communications menu remotely. All communication parameters (such as IP address, baud rate, and so forth) must be changed using the APEX display panel.
- Some parameters cannot be set remotely for safety or other reasons, because a *person* must be present—for example, to pass a test package through the APEX.

Change Products Remotely

The Modbus Communications Card allows you to change products remotely. By changing a single Modbus register (number 41045) and the parameter-change-notification coil (register 16385) to one (1), all APEX settings for the designated product are immediately updated.

Get Real-Time Statistics from the APEX

The Modbus Communications Card also allows you to get *real-time* operating and other statistics from the APEX. In other words, you can monitor the detector's performance remotely, without going down on to the factory floor, allowing you to monitor current reject totals, detect level, and so on.

Back Up Critical APEX Settings

And finally, the Modbus Communications Card allows you to back-up (externally, using your pre-existing database software) all of the detector's critical settings—including performance statistics, specific product settings, detect levels, reject counts, and so on. Thus, in the event of a catastrophic failure, you can quickly and easily restore all the APEX settings—the ones you have spent so much time, money, and effort perfecting.

Regular back-ups are also useful for checking that all APEX parameters are set correctly, and are very helpful, should you ever need to contact Thermo Fisher Scientific's technical-support personnel—as described in the "Contacting Thermo Fisher Scientific" section at the end of the manual—for troubleshooting assistance.

Engineering Details

The Modbus Communications Card is a microprocessor card that handles all field-bus communications. All data read and written from the field bus is held internally in the card's dual-port random-access memory (RAM). Various registers are defined, and these map data held in the APEX onto the Modbus' RAM. Because the Modbus Communications Card does not support fully bi-directional data transfer through the same memory position, it implements a handshaking scheme, so that higher layers can identify when something has changed. This handshaking scheme is only implemented for registers that are written from the field bus, and is not used when registers are read from the field bus. As a result, the Modbus uses different read and write registers for the same parameter.

Expert Knowledge Is Required to Modify Settings

As a general rule, *only* engineers, programmers, and others who have *extensive* experience managing network communication parameters and registers should attempt to change any configurations described in this appendix. If you are not sure what you are doing, please contact Thermo Fisher Scientific—as described in the “Contacting Thermo Fisher Scientific” section at the end of the manual. In addition, having a list of current Modbus register values, is very helpful, when contacting Thermo Fisher Scientific.

Overview of the Installation Process

This appendix assumes that a Thermo Fisher Scientific technician has already done the following to get the communication functions of the Modbus up and running.

- Installed the appropriate (TCP/IP or RTU) Modbus Communications Card and made the appropriate hardware configurations (by setting the card’s DIP switches to the correct positions).
- Installed version 3.0 or higher of the detector’s operating software in your APEX metal detector.
- Set up (“configured”) the appropriate communication parameters (using the APEX software) so that the APEX is recognized by your network.

Modifying the Modbus Settings

Clearly, if you want to upgrade from an RTU to a TCP/IP network (or vice versa), you will have to purchase a new Modbus Communications Card. However, if you are currently using an RTU Communications Card that has been configured as an RS-232 device, and want to upgrade its capabilities to an RS485 device (or vice versa), all you have to do is change one of the DIP switches on your existing card (as described in the appropriate RS-232 or RS-485 section of the “Configuring the Modbus hardware” section of this appendix).

Most other configuration changes for both a TCP/IP and RTU Communications Card are made using the APEX operating software, specifically by accessing the Modbus configuration menu. These are described in detail in the “Configuring Network Parameters with the APEX Software” section of this appendix.

If you have questions or need additional help, please contact Thermo Fisher Scientific—as described in the “Contacting Thermo Fisher Scientific” section at the end of the manual.

Configuring Network Parameters with the APEX Software

This section tells you how to use the detector's built-in operating software to configure your network using the detector's communications menu and functions. This section—please note—does *not* tell you how to reconfigure the *hardware* settings for your Modbus Communications Card. This is covered in the "Configuring the Modbus Hardware" section on page 341.

Please verify which type of Modbus Communications Card is installed in your APEX, and make sure that it matches the type of network (TCP/IP or RTU) are configuring. Then go to the appropriate section for detailed instructions about configuring your particular type of network.

- For a TCP/IP network, go to the next section (below).
- For an RTU network, see the instructions on page 335.

Configuring a TCP/IP Network


This section tells you how to use the APEX software to modify the communication parameters for a TCP/IP network. You can set the following parameters using the APEX communications menu.

- Dynamic host-control protocol (on or off)
- IP address
- Subnet-mask address
- Gateway address


Accessing the TCP/IP Communications Menu

To access the detector's TCP/IP communications menu, do the following.


- 1) Make sure the detector's Main Menu is displayed.




- 2) Navigate to the system and tools menu.




- 3) Press the Go button and page 1 of the system and tools menu appears.




- 4) Navigate to page 2 of the system and tools menu.




5) Navigate to the inputs and outputs menu.



6) Press the Go button and the detailed inputs and outputs menu appears.




7) Navigate to the communications menu.



(continued...)

- 8) Press the Go button and the “Modbus TCP/IP Configuration” screen appears. In most instances, the IP, subnet-mask, gateway, and MAC addresses are set automatically by the network and the appropriate addresses will be shown in the detector’s display panel. (In the example below, we have entered all zeros in this screen, so we can show you how to change the communication parameters—except the MAC address, which cannot be edited.)



Here is a list of the communications parameters found in this menu. Please note that all parameters are editable, except the MAC address.

Parameters	Description	Editable?
DHCP	Dynamic host-control protocol	Yes—you can set DHCP to either “on” or “off.” On is the default setting.
IP	IP address	Yes
SN	Subnet-mask address	Yes
GW	Gateway address	Yes
MAC	MAC address	No

Changing the DHCP Default Setting During Installation

The default setting for DHCP is “on” (as shown by the check mark next to the function). Because the DHCP setting is set—by default—to “on,” a network host-device will set the IP, subnet-mask, gateway, and MAC addresses for you when you do either of the following.


- Scenario 1—Powering up the APEX for the *first* time after installing the Modbus card.
- Scenario 2—Powering down the APEX (for example, by turning it off at night) and powering it up again (for example, by restarting the APEX in the morning).

It is scenario 2 that sometimes causes a problem, because the network may assign *new* addresses to the APEX, leading to network problems. Thus, if you constantly power down and power up the APEX, it is best to let the network assign the addresses when you first install the Modbus card (scenario 1), and then change the DHCP setting to “off” to lock in these addresses. Then, during subsequent power ups and downs (scenario 2), a network device cannot change these addresses, eliminating potential network problems for the APEX.

Changing DHCP to “Off”


To change the DHCP setting to “off” (and lock in your current IP, subnet-mask, and gateway addresses), do the following.

- 1) Make sure the DHCP function is highlighted. (The check mark indicates that DHCP is currently set to its default value, “on.”)



(continued...)

- 2) Press the Go button. The check mark changes to an X, indicating that DHCP is now "off." (The flashing asterisk tells you the DHCP setting has been modified.)

Dynamic Host Control Protocol				
 1/1	SAVE	DHCP: X *		
	IP:	0.	0.	0.
	SN:	0.	0.	0.
	GW:	0.	0.	0.
	MAC:00_30_11_03_48_2A			

- 3) Press the Back button to exit the function.

Manually Changing Communication Parameters

If you wish to manually change the IP, subnet-mask, and gateway addresses, please note the following.


- The DHCP setting *must* be set to "off."
- For your changes to take effect, you must *save* your settings.

How to change the IP, subnet-mask, and gateway addresses as well as save your TCP/IP settings, is described in the following sections.

Changing the IP Address


In order to change the IP address, DHCP must be set to "off."

- 1) Make sure the IP address function is highlighted.


IP Address				
 1/1	SAVE	DHCP: X		
	IP:	0.	0.	0.
	SN:	0.	0.	0.
	GW:	0.	0.	0.
	MAC:00_30_11_03_48_2A			

(continued...)

- 2) Press the Go button, and an input screen appears.



- 3) Use the navigation buttons to enter the IP address, then press the Go button to close the input screen. The flashing asterisk indicates the IP address has been changed.




- 4) If you are finished, go to the “Saving Your TCP/IP Settings” section—this is *important!* Or continue the set-up as described below.

Changing the Subnet-Mask Address

In order to change the subnet-mask address, DHCP must be set to “off.”

- 1) Make sure the subnet mask function is highlighted.
- 2) Press the Go button, and an input screen appears.
- 3) Use the navigation buttons to enter the subnet-mask address, then press the Go button to close the input screen. The flashing asterisk indicates the subnet-mask address has been changed.




- 4) If you are finished, go to the "Saving Your TCP/IP Settings" section—this is *important!* Or continue the set-up as described below.

Changing the Gateway Address

In order to change the gateway address, DHCP must be set to "off."

- 1) Make sure the gateway function is highlighted.
- 2) Press the Go button, and an input screen appears.
- 3) Use the navigation buttons to enter the gateway address, then press the Go button to close the input screen. The flashing asterisk indicates the gateway address has been changed.



- 4) Go to the "Saving Your TCP/IP Settings" section—this is *important!*


MAC Addresses

Please note that the MAC address cannot be changed using the APEX software, because it is set directly by the hardware.

Saving Your TCP/IP Settings


Your settings will *not* be activated until you save your settings using the “Save” function.

- 1) Navigate to the save function and make sure it is highlighted.



The flashing asterisks in the screen above indicate that, in this example, we have changed the IP, subnet-mask, and gateway addresses.

- 2) Press the Go button. There is a one second software pause, during which time the Modbus card is reset. The following screen then appears.




Notice that the flashing asterisks have disappeared, indicating that all your TCP/IP communication settings have been saved and are now active.

- 3) Press the Back button repeatedly to return to the Main Menu screen.


Changing DHCP to “On”

To change the DHCP setting to “on,” do the following. Please note that, if changes have been made to the IP, subnet-mask, or gateway address, both screens (shown below) may display a flashing asterisk next to the DHCP function.)

- 1) Make sure the DHCP function is highlighted.

Dynamic Host Control Protocol	
	SAVE DHCP: X
	IP: 0. 0. 0. 0
	SN: 0. 0. 0. 0
	GW: 0. 0. 0. 0
1/1	MAC:00_30_11_03_48_2A

- 2) Press the Go button. The X changes to a check mark, indicating that DHCP is now “on” and the network will configure the IP, subnet-mask, and gateway addresses.

Dynamic Host Control Protocol	
	SAVE DHCP: ✓
	IP: 0. 0. 0. 0
	SN: 0. 0. 0. 0
	GW: 0. 0. 0. 0
1/1	MAC:00_30_11_03_48_2A

- 3) Press the Back button to exit the function.

Configuring an RTU Network


This section tells you how to use the APEX software to modify the communication parameters for an RTU network. You can set the following parameters using the APEX communications menu.

- Slave address (1 through 247)
- Baud rate (1200, 2400, 4800, 9600, 19200, 38400, and 57600 bits per second)
- Parity (none, odd, or even)


Accessing the RTU Communications Menu

To access the RTU communications menu, do the following.

- 1) Follow steps 1–7 in the “Accessing the TCP/IP Communications Functions” section above to reach the screen shown below.




- 2) Press the Go button and the “Modbus RTU Configuration” menu appears.



Changing the Slave Address

To change the slave address, do the following.


- 1) In the “Modbus RTU Configuration” screen, highlight the slave-address function.



- 2) Press the Go button and the following input screen appears.



- 3) Enter the slave address using the navigation buttons. (We entered 007 as the new slave address.)
- 4) Press the Go button. The flashing asterisk tells you the slave address has been changed.




- 5) If you are finished, go to the “Saving Your RTU Settings” section—this is *important!* Or continue the set-up as described below.


Changing the Baud Rate

You can set the following baud rates: 1200, 2400, 4800, 9600, 19200, 38400, or 57600 bits/second. To change the baud rate, do the following.

- 1) Make sure the baud-rate function is highlighted.



- 2) Press the Go button repeatedly to scroll through the options for baud rate, and highlight the one you want. (We selected 57600.)
- 3) Press the Back button to return to the RTU configuration screen. The flashing asterisk tells you the baud rate has been changed.




- 4) If you are finished, go to the "Saving Your RTU Settings" section—this is *important!* Or continue the set-up as described below.


Changing the Parity

To change the parity, do the following.

- 1) Make sure the parity function is highlighted.



- 2) Press the Go button repeatedly to scroll through the options for parity (none, odd, or even), and select the one you want. (We selected "odd".)
- 3) Press the Back button to return to the RTU configuration screen. The flashing asterisk tells you the parity has been changed.




- 4) Go to the "Saving Your RTU Settings" section—this is *important!*


Saving Your RTU Settings

Your RTU settings will *not* be activated until you save your settings using the “Save” function.

- 1) Navigate to the save function and make sure it is highlighted. The flashing asterisks in the screen above indicate that, in this example, we changed all three communication parameters (slave address, baud rate, and parity).



- 2) Press the Go button to return to the RTU configuration screen. The flashing asterisks have disappeared, indicating that all your RTU communication settings have been saved.



- 3) Press the Back button repeatedly to return to the Main Menu

Configuring the Modbus Hardware

This section tells you how to configure (and install) the Modbus Communications Card. Please go to the appropriate section for detailed instructions.


- *Modbus TCP/IP Communications Card*—Go to the following section (page 342).
- *Modbus RTU Communications Card* that you want to configure as an RS-485 device—Go to page 345.
- *Modbus RTU Communications Card* that you want to configure as an RS-232 device—Go to page 349.

Configuring the TCP/IP Card

This section tells you how to install and configure your TCP/IP Modbus Communications Card, and how to interpret the four status LEDs on the card.

Card Schematic

For most applications, here are the relevant parts of the Modbus TCP/IP Communications Card.



Installing the TCP/IP Card

To mount your TCP/IP card on the APEX motherboard, do the following.

- 1) On the APEX motherboard, remove the HMI CPU (human-machine interface, central processing unit) card.
- 2) Install the TCP/IP card on the APEX motherboard by connecting the card's application connector to the detector's COMMS1 connector. Use the APEX Communication Module Mounting Kit to secure the card to the APEX motherboard.
- 3) Reinstall the HMI CPU on the motherboard.


Setting the Configuration Switches

All switches should be set to the zero or "off" position, which allows you to configure all of the card's communications parameters, except the MAC address, using the APEX software.

Pin Assignments for the Ethernet (RJ45) Connector

Here are the pin assignments for the Ethernet (RJ45) connector.


Pin	Signal	Notes
1	TD+	
2	TD-	
3	RD+	
4		Normally left unused. To insure signal integrity, these pins are tied together and terminated to the PE via a filter circuit in the module.
5		
6	RD-	
7		Normally left unused. To insure signal integrity, these pins are tied together and terminated to the PE via a filter circuit in the module.
8		



(Front view)

Understanding the Status LEDs

The Modbus TCP/IP Communications Card is equipped with four status LEDs, as shown below.



Here is what the LEDs on a TCP/IP card are telling you.


LED #	Status	What the lights are telling you
1	Link activity	<i>Off</i> = Link not sensed <i>Green</i> = Link sensed
2	Module status	<i>Off</i> = No power <i>Green (1Hz)</i> = IP address not set using configuration switch <i>Red (1Hz)</i> = Invalid MAC address (internal error) <i>Red (2Hz)</i> = Failed to load Ethernet configuration Flash <i>Red (4Hz)</i> = Fatal internal error <i>Red</i> = Duplicate IP address detected
3	Network status	The number of flashes equals the number of connections made to the Modbus
4	Activity	The LED flashes each time a packet is received or transmitted

Configuring the RTU RS-485 Card

This section tells you how to install and configure your RTU RS-485 Modbus Communications Card, and how to interpret the four status LEDs on the card. Please note that your particular card will be equipped with either a DB-9 connector or a screw connector.

Card Schematic

For most applications, here are the relevant parts of the Modbus RS-485 card. (The figure shows an RS-485 card equipped with a DB-9 connector.)



Installing the Card


To mount your RS-485 card on the APEX motherboard, do the following.

- 1) On the APEX motherboard, remove the HMI CPU (human-machine interface, central processing unit) card.
- 2) Install the RS-485 card on the APEX motherboard by connecting the card's application connector to the detector's COMMS1 connector. Use the APEX Communication Module Mounting Kit to secure the card to the APEX motherboard.
- 3) Reinstall the HMI CPU on the motherboard.


Setting the Configuration Switches

To configure your Modbus card as an RS-485 termination node, do the following.


- 1) Locate the termination, node ID/ baud rate, and parity switches (diagrammed below) on the Modbus card. Set *all* the switches to the zero or "off" position. This allows the APEX software to set all of the communication parameters for your RS-485 card.



- 2) Please *check* that DIP-switch number 5 in the parity block is set to the zero or "off" position (as diagrammed below), because this is the switch that actually sets the Modbus card to the RS-485 configuration. (If this switch is on, the card will be configured as an RS-232 card.)



- 3) To configure the Modbus card as an *end node* in your network, set the termination switch to the one (1) or "on" position (as diagrammed below).



When the termination switch is on, the Modbus' internal termination resistor network is activated, which eliminates reflections on the bus line.

Configuring a Non-Terminated Node

To configure the Modbus card as a non-terminated node, or when using an external terminator, set the termination switch to the zero or "off" position.


Pin Assignments for a DB-9 Connector

Here are the pin assignments for an RTU card equipped with a DB-9 connector.

Pin	Name	Function
1		Not connected
2	RS232-TX	Transmit signal
3	RS232-RX	Receive signal
4		Not connected
5	GND	Signal ground
6	+5V	Power supply
7	RS485 A (-)	Two-wire TX/RX lines
8	RS485 B (+)	Two-wire TX/RX lines
9		Not connected

Pin Assignments for a Screw Connector


Here are the pin assignments for an RTU card equipped with a screw connector.



Pin	Name	Function
1	RS232-TX	Transmit signal
2	GND	Signal ground
3	RS485 B (+)	Two-wire TX/RX lines
4	RS485 A (-)	Two-wire TX/RX lines
5	RS232-RX	Receive signal
6	Shield	Cable shield

Understanding the Status LEDs

An RTU card is equipped with four status LEDs, as shown below.



Here is what the LEDs on an RTU card are telling you.

LED #	Status	What the lights are telling you
1	Processing	<i>Flashing green</i> = Processing. <i>Off</i> = Not currently processing.
2	Bus error	<i>Off</i> = Normal (or card not initialized). <i>Solid red</i> = Bus error.
3	Bus ready	<i>Solid green</i> = Bus is ready. <i>Solid red</i> = Bus time-out error. <i>Off</i> = Card not initialized correctly.
4	DIP switches	<i>Off</i> = DIP switches are in use and the settings are good. <i>Solid green</i> = DIP-switch settings have been modified by mailbox message. <i>Solid red</i> = DIP switches set to non-active status—that is, all are off or set to illegal values.

Configuring the RTU RS-232 Card

This section tells you how to install and configure your RS-232 Modbus Communications Card, and how to interpret the four status LEDs on the card.

Installing the Card


To mount your RS-232 card on the APEX motherboard, do the following.

- 1) On the APEX motherboard, remove the HMI CPU (human-machine interface, central processing unit) card.
- 2) Install the RS-232 card on the APEX motherboard by connecting the card's application connector to the detector's COMMS1 connector. Use the APEX Communication Module Mounting Kit to secure the card to the APEX motherboard.
- 3) Reinstall the HMI CPU on the motherboard.


Setting the Configuration Switches

To configure your Modbus card as an RS-232 termination node, do the following.

- 1) Locate the termination, node ID/ baud rate, and parity switches (diagrammed below) on the Modbus card. Set *all* the switches to the zero or "off" position.



- 2) Set DIP-switch number 5 in the parity block to the one (1) or "on" position (as diagrammed below), because this is the switch that actually sets the Modbus card to the RS-232 configuration. (If this switch is off, the card will be configured as an RS-485 card.)



Pin Assignments for a DB-9 Connector

See the RS-485 section, because the pin assignments are identical.

Pin Assignments for a Screw Connector

See the RS-485 section, because the pin assignments are identical.

Understanding the Status LEDs

See the RTU RS-485, because the way the LEDs operate is identical.

Understanding Registers

The first part of this section gives you a quick overview of way the Modbus Communications Card uses registers to control and/or monitor APEX functions. The second part gives you step-by-step instructions about how to use the Modbus registers to change products, get summary statistics (such as the total reject count), and back up all your important APEX settings. And the final part, which is presented in the form of table, gives you a complete summary of all Modbus registers used by the APEX.

Data Handling

This section gives you a quick overview of way the Modbus Communications Card uses registers to control and/or monitor APEX functions, and how to interpret register values.

Supported Operation Codes

Here is a list of the operation codes supported by the Modbus.

Modbus function	Function code
Read coil	1
Read input discretes	2
Read multiple registers	3
Read input registers	4
Write coil	5
Write single register	6
Force multiple coils	15
Force multiple registers	16
Mask write register	22
Read/write registers	23

Exception code	Name
0x01	Illegal function
0x02	Illegal data address
0x03	Illegal data value

Read Data

When the master wants to read a parameter, it simply reads the appropriate register or registers. Using the standard commands of the Modbus TCP, it is possible to read all the data of the table.

Write Data

Each parameter that can be modified by the master, has two control bits to perform the handshaking operation, which are implemented as coils. These two control bits are named as follows.

Control bit	Description
Parameter-change notification	Used to notify the APEX that the master has modified a parameter.
Parameter-change acknowledge	Used to acknowledge that the APEX has processed the parameter change.

If the master wants to change a parameter, it first updates the appropriate registers and then notifies the APEX by toggling the corresponding “parameter-change notification” coil. When the APEX has processed this change, it toggles the corresponding “parameter-change acknowledge” coil to signal that the parameter change has been processed.

If the parameter written by the master is outside the range of acceptable values, then the APEX will not use it and will continue to use the previous value. In this case the Read and Write registers will contain different values, but the Read register will always contain the current value being used by the APEX. Note that the “parameter-change acknowledge” coil will still be toggled, indicating that the APEX has processed it.

Register Details for Commonly Used APEX Functions

The section gives you step-by-step instructions about how to use the Modbus registers to change products, get summary statistics (such as total reject count), and back up all your important APEX settings.

Changing Products


In order to change products remotely, all you need to do is enter the product number (using a program such as Modscan, PC Master, or other similar program) into Modbus register number 41045 and set parameter-change coil number 16385 to one (1). When you enter the product number in this register, all APEX settings for this product are automatically updated, and the APEX is now ready to start analyzing the new product you specified.

Example

Imagine you are a supervisor at a food-packaging company. During the morning shift, your equipment packages milk (product "001"), and during the afternoon shift it packages ice cream (product "002"). In this example, the number "001" was automatically assigned by the APEX software to milk, because this was the first product you set up. Similarly, the number "002" was automatically assigned to ice cream, because it was the second product you set up.


To view the list of currently set-up products (and to access their product numbers), do the following.

- 1) Go to the APEX Main Menu to display the currently running product (in our example this is product 001, milk).



(continued...)

- 2) Press the right-navigation button to display the next product (product n+1, which in our example is product 002, ice cream).



- 3) Continue pressing the right-navigation button to review all other products.

Retrieving Statistical Information

In any production environment, good record keeping is important because it allows you to monitor the detector's performance, keep careful quality-control records, and predict when future problems—such as a wet product giving false rejects—are likely to occur.

The following registers allow you to retrieve real-time values for the following APEX statistics.

Description	Read register	No. of registers	Data type
Current product number	30020	1	unsigned short
Total reject count	30021	2	unsigned long
Contaminant count	30023	2	unsigned long
Quality Test count	30025	2	unsigned long
AuditCheck count	30027	2	unsigned long
Total pack count	30029	2	unsigned long
Detect level	30031	1	unsigned short
Current peak value	30032	1	unsigned short

Understanding Register Formats

All Modbus registers use the "Big Endian" format, which means that the most significant byte (MSB) is received first when reading register addresses. Thus, when values are stored in multiple registers (for example, the values for total reject count), the following rules apply.

- The MSB is received first when reading the starting address of the value.
- The least significant byte is received last when reading the highest address of the value.

For example, if register 30021 contains the value "0x0123" and register 30022 contains the value "0x4567", the total reject count is calculated as follows.

Register value	Mathematical expression	Numeric value
0x0123	$0 \times 16^7 =$	0
0x4567	$+1 \times 16^6 =$	16,777,216
	$+2 \times 16^5 =$	2,097,152
	$+3 \times 16^4 =$	196,608
	$+4 \times 16^3 =$	16,384
	$+5 \times 16^2 =$	1,280
	$+6 \times 16^1 =$	96
	$+7 \times 16^0 =$	7
Total =		19,088,743

This, clearly, is an unrealistically high total reject count, but illustrates how register values are used to assign a numeric value for the total number of rejects.

Resetting Statistics

To reset the following APEX statistics, set parameter-change coil 16386 to one (1). This resets the following APEX statistics—and the appropriate Modbus registers listed below—to zero (0).

- Total reject count
- Quality Assurance Test count
- AuditCheck count
- Total pack count

Resetting Peak Values

To reset the APEX peak values, set parameter-change coil 16388 to one (1). This resets the current peak value to zero (0).

Backing Up Critical APEX Settings

Backing up critical APEX data is important, because it provides insurance against catastrophic system failures. Backing up your data does not take up a lot of space. The amount of disk space needed to back up a single product, for example, is only 808 bytes, as shown in the table below.

NVRAM allocation	Space used (bytes)
DSP configuration	96
HMI configuration	388
Single-product configuration	324
Total =	808

See glossary for explanation of acronyms

In addition, backing up subsequent products (after the first product has been backed up), only uses 324 additional bytes, because all of the detector's global parameters (such as model type, language setting, preferred units of measure, and so forth) have already been backed up.

Overview of Backing Up/Restoring Your APEX Settings

The instructions given below are meant solely to provide you with an overview about how to set up an automated process for backing up and restoring your critical APEX settings. As a result, specific data-storage details are not included. In addition, please note that the product parameters are only assessable for the *currently selected* APEX product. This means that, in order to do a complete product back-up, you must back up the settings for each product *separately* (using the appropriate product number).

Backing Up Your APEX Settings

- 1) Read all machine settings and store them to a data file. All machine settings are labeled with an *M* in the "Data Type" column in the detailed list of Modbus registers (see pages 357–365).
- 2) Write product number 001 to register 41045, and set parameter-change coil 16385 to one (1).
- 3) Read all product settings and store to a data file. These product settings—please note—relate *only* to product 001. All product settings are labeled with a *P* in the "Data Type" column in the table of registers.
- 4) Write product number 002 to register 41045, and set parameter-change coil 16385 to one (1).
- 5) Read all product settings and store to a data file. These product settings—please note—relate *only* to product 002.
- 6) Continue until all your products are backed up.

Restoring Your APEX Settings

- 1) Write all machine settings from a data file to the corresponding registers.
- 2) Write product number 001 to register 41045, and set parameter-change coil 16385 to one (1).
- 3) Write all product settings for product 001 from a data file to the corresponding registers.
- 4) Write product number 002 to register 41045, and set parameter-change coil 16385 to one (1).
- 5) Write all product settings for product 002 from a data file to the corresponding registers.
- 6) Continue until all your products are restored.

Detailed List of Modbus Registers

Here is a detailed list of all registers used by the Modbus Communications Card. Please see Key on page 366 and the Glossary on page 393 for a description of the acronyms and other terms used in this table.

Read Register	Write Register	Number of Registers	PCC Notification	PCC Acknowledge	Access	Data Type	Parameter Type	Description	Parameters
30020	41045	1	16385	1	R/W	unsigned short	P	Current Product Number	1-100
30021	n/a	2		n/a	RO	unsigned long	P	Total Reject Count	0 - 4 Billion
30023	n/a	2		n/a	RO	unsigned long	P	Contaminant Count	0 - 4 Billion
30025	n/a	2		n/a	RO	unsigned long	P	Quality Test Count	0 - 4 Billion
30027	n/a	2		n/a	RO	unsigned long	P	AuditCheck Count	0 - 4 Billion
30029	n/a	2		n/a	RO	unsigned long	P	Total Pack Count	0 - 4 Billion
									Only updates if there is photo registration
n/a	n/a	n/a	16386	2	n/a	n/a	P	Reset Statistics	Resets all Counts
30031	41046	1	16387	3	R/W	unsigned short	P	Detect Level	0-65535
30032	n/a	1		n/a	RO	unsigned short	P	Current Peak Value	0-65535
n/a	n/a	n/a	16388	4	n/a	n/a	P	Reset Current Peak Value	Reset Current Peak Value
30033	n/a	1		n/a	RO	enum	M	Operational Status	0 = Normal
									1 = Learning Phase
									2 = Learning Detect Level
									3 = Learning Noise Threshold
									4 = Learning AuditCheck
									5 = Performing AuditCheck
									6 = Learning Quality Test
									7 = Performing Quality Test
									8 = Learning Reject Confirm Time
									9 = Learning DSV Filter Frequency
									10 = Calibrating Speed Sensor

Read Register	Write Register	Number of Registers	PCC Notification	PCC Acknowledge	Access	Data Type	Parameter Type	Description	Parameters
30034	n/a	1		n/a	RO	bitmap	M	Fault Status	bit 0: Reject Confirmation Error bit 1: Reject Bin Full bit 2: Infeed Photo-eye blocked bit 3: Detection with a stopped belt bit 4: Detection outside of a pack bit 5: Phase tracking limit exceeded bit 6: Search Head Problem bit 7: QAT timeout bit 8: QAT failed bit 9: AuditCheck timeout bit 10: AuditCheck failed bit 11: NVRAM battery low bit 12: Excess Rejects bit 13: Memory Corruption bits 14-31: <reserved> bit set if fault active
30035	n/a	1		n/a	RO	bitmap	M	Alarm Status	Parameters are the same as Fault Status
30036	41047	1	16389	5	R/W	enum	P	Product Speed Encoder	0 = Disabled 1 = Enabled Note: A Speed Learn must be performed for encoder to provide valid speed. This is done by enabling the encoder using the controls at the front panel.
30037	41048	2	16390	6	R/W	float	P	Product Speed	0.1 to 999.0 m/min Note: Speed Encoder must be disabled to change speed remotely.
30039	41050	2	16391	7	R/W	float		Speed Filter Speed	0.1 to 999.0 Hz Note: If Speed Filter Ratio is Learned, updating Product Speed will update Speed Filter.
30041	41052	2	16392	8	R/W	float	P	Phase Angle	-45.00 to 135.00 degrees
30043	41054	2	16393	9	R/W	float	P	Phase Tracking Limit	0.00 to 135.00 degrees
30045	41056	2	16394	10	R/W	float	P	Phase Tracking Fault Limit	0.00 to 135.00 degrees
30047	41058	1	16395	11	R/W	enum	P	Phase Tracking	0 = Disabled 1 = Enabled
30048	41059	9	16396	12	R/W	string	P	Product Name	18 chars in length
30057	41068	1	16397	13	R/W	enum	P	Detection Type	0 = Amplitude 1 = Multi-Zone

Read Register	Write Register	Number of Registers	PCC Notification	PCC Acknowledge	Access	Data Type	Parameter Type	Description	Parameters
30058	41069	1	16398	14	R/W	enum	P	Detection Inhibited	0 = Disabled 1 = Enabled
30059	41070	1	16399	15	R/W	enum	P	Photo Registration	Setting the Photo Registration will also reset the statistics. 0 = No Photo Eye 1 = Leading Edge 2 = Middle 3 = Length
30060	41071	1	16400	16	R/W	unsigned short	P	Package Length	0 to 5,000 mm
30061	41072	1	16401	17	R/W	unsigned short	P	Package Gap	0 to 100%
30062	41073	1	16402	18	R/W	unsigned short	P	Detection No-pack Distance	0 to 5,000 mm
30063	41074	1	16403	19	R/W	bitmap		Rejecter Configuration	Bit 0: Reject 1 - (0) Normal or (1) Latching Bit 1: Reject 1 - (0) Non-inverted or (1) Inverted Bit 2: Reject 2- Contaminant Reject
30064	41075	1	16404	20	R/W	unsigned short	P	Rejecter 1 Delay	0 to 5,000 mm
30065	41076	1	16405	21	R/W	unsigned short	P	Rejecter 1 Duration Distance	0 to 20,000 mm
30066	41077	1	16406	22	R/W	unsigned short	P	Rejecter 1 Duration Time	0 to 9990 ms
30067	41078	1	16407	23	R/W	unsigned short	P	Reject Confirm 1 Time	0 to 9990 ms
30068	41079	1	16408	24	R/W	unsigned short	P	Reject Confirm 2 Time	0 to 9990 ms
30069	41080	1	16409	25	R/W	unsigned short	P	Rejecter 2 Delay	0 to 5,000 mm
30070	41081	1	16410	26	R/W	unsigned short	P	Rejecter 2 Duration Distance	0 to 20,000 mm
30071	41082	1	16411	27	R/W	unsigned short	P	Rejecter 2 Duration Time	0 to 9990 ms
30072	41083	1	16412	28	R/W	unsigned short	P	Reject Suppression Time	0 to 9990 ms
30073	41084	1	16413	29	R/W	unsigned short	P	Reject Suppression Attenuation	0 to 100%
30074	41085	1	16414	30	R/W	bitmap	P	Reject Suppression Trigger Source	Bit 0: External Trigger Bit 1: Reject Output
30075	41086	1	16415	31	R/W	enum	P	PNR Filter	0 = Disabled 1 = Enabled
30076	41087	1	16416	32	R/W	enum	P	QNR Filter	0 = Disabled 1 = Enabled
30077	41088	1	16417	33	R/W	enum	P	CLX Filter	0 = Disabled 256 = CLX Ratio of 1 512 = CLX Ratio of 2 768 = CLX Ratio of 3

Read Register	Write Register	Number of Registers	PCC Notification	PCC Acknowledge	Access	Data Type	Parameter Type	Description	Parameters
30078	41089	1	16418	34	R/W	enum	P	Search Head Frequency	0 = Low Frequency 1 = High Frequency
30079	41090	1	16419	35	R/W	enum	P	Search Head Gain	0 = Low Gain 1 = High Gain
30080	41091	1	16420	36	R/W	unsigned short	P	Resistive (R) Threshold	0 to 65535
30081	41092	1	16421	37	R/W	unsigned short	P	Reactive (X) Threshold	0 to 65535
30082	41093	1	16422	38	R/W	bitmap	P	Auto Learn Behavior	Each Bit Locks out a particular stage of the Auto Learn Bit 0: Enable Phase Lock Bit 1: Enable Detect Level Lock Bit 2: Enable AuditCheck Lock
30083	41094	1	16423	39	R/W	unsigned short	P	AuditCheck Time Interval	0 to 999 minutes
30084	41095	1	16424	40	R/W	unsigned short	P	AuditCheck Fault Timeout	0 to 99 minutes
30085	41096	1	16425	41	R/W	enum	P	AuditCheck Reject Device	0 = None 1 - Rejecter 1 2 = Rejecter 2
30086	41097	1	16426	42	R/W	unsigned short	P	AuditCheck Peak Warning Tolerance	0 to 99%
30087	41098	1	16427	43	R/W	unsigned short	P	AuditCheck Peak Alarm Tolerance	0 to 99%
30088	41099	1	16428	44	R/W	unsigned short	P	AuditCheck Peak Fault Tolerance	0 to 99%
30089	41100	1	16429	45	R/W	unsigned short	P	AuditCheck Phase Warning Tolerance	0 to 99 degrees
30090	41101	1	16430	46	R/W	unsigned short	P	AuditCheck Phase Alarm Tolerance	0 to 99 degrees
30091	41102	1	16431	47	R/W	unsigned short	P	AuditCheck Phase Fault Tolerance	0 to 99 degrees
30092	n/a	1	n/a	n/a	RO	unsigned short	P	AuditCheck Learned Peak Average	0 to 65535
30093	n/a	1	n/a	n/a	RO	unsigned short	P	AuditCheck Learned Peak - Test 1	0 to 65535
30094	n/a	1	n/a	n/a	RO	unsigned short	P	AuditCheck Learned Peak - Test 2	0 to 65535
30095	n/a	1	n/a	n/a	RO	unsigned short	P	AuditCheck Learned Peak - Test 3	0 to 65535
30096	n/a	2	n/a	n/a	RO	float	P	AuditCheck Learned Phase Average	-45.00 to 135.00 degrees
30098	n/a	2	n/a	n/a	RO	float	P	AuditCheck Learned Speed Average	0.1 to 999.0 m/min
30100	n/a	2	n/a	n/a	RO	float	P	AuditCheck Learned Phase Angle - Test 1	-45.00 to 135.00 degrees
30102	n/a	2	n/a	n/a	RO	float	P	AuditCheck Learned Speed - Test 1	0.1 to 999.0 m/min
30104	n/a	2	n/a	n/a	RO	float	P	AuditCheck Learned Phase Angle - Test 2	-45.00 to 135.00 degrees
30106	n/a	2	n/a	n/a	RO	float	P	AuditCheck Learned Speed - Test 2	0.1 to 999.0 m/min

Read Register	Write Register	Number of Registers	PCC Notification	PCC Acknowledge	Access	Data Type	Parameter Type	Description	Parameters
30133	n/a	1	n/a	n/a	RO	bitmap	M	Speed Filter Status	Bits (0-1) Wideband Mode 00 = Slow 01 = Medium 10 = Fast 11 = Custom Bit 2: Speed Filter Type 0 = Narrow Band 1 = Wideband Bit 3: Speed Filter Learn Enabled 0 = Disabled 1 = Enabled Bit 4: Factory Speed Filter Ratio Locked 0 = Disabled 1 = Enabled
30134	n/a	1	n/a	n/a	RO	bitmap	M	Speed Filter Learned Flags	Bit 4: (0) Conveyor Not Learned or (1) Conveyor Learned Bit5: (0) Pipe or Drop through Not Learned or (1) Pipe or Drop through Learned
30135	n/a	2	n/a	n/a	RO	float	M	Speed Filter Factory Speed Frequency Ratio	Used to Update Speed Filter when Speed is changed Ratio = Speed(M/Min) / Speed Filter Frequency(Hz)
30137	41116	1	16445	61	R/W	bitmap	M	Warning Configuration	Each Bit refers to a particular type: Bit 0: Reject Confirmation Error Bit 1: Reject Bin Full Bit 2: Infeed Photo-eye Blocked Bit 3: Detection With Stopped Belt Bit 4: Detection with no infeed photo-eye signal Bit 5: Phase Tracking Limit Exceeded Bit 6: Search Head Problem Bit 7: QAT Problem Bit 8: AuditCheck Problem Bit 9: NVRAM Battery Low Bit 10: Excess Rejects Bit 11: Memory Corruption Bits 12- 15 unused
30138	41117	1	16446	62	R/W	bitmap	M	Alarm Configuration	Same as for Warning Configuration
30139	41118	1	16447	63	R/W	bitmap	M	Fault Configuration	Same as for Warning Configuration

Read Register	Write Register	Number of Registers	PCC Notification	PCC Acknowledge	Access	Data Type	Parameter Type	Description	Parameters
30140	41119	5	16448	64	R/W	string	M	Machine Identifier	9 chars in length
30145	41124	5	16449	65	R/W	string	M	Printer Batch Code	9 chars in length
30150	41129	1	16450	66	R/W	bitmap	M	Printer Setup	Bit 0: Enable Printer Bit 1: Enable End of Day Printout Bit 2: Enable Print Rejects Bit 3: Enable Printout on Power On
30151	n/a	1	n/a	n/a	RO	unsigned short	M	Current Password Level	-1 = Passwords Disabled 0 = Not logged in 1 = Operator 2 = Engineer 3 = Supervisor
30152	41130	1	16451	67	R/W	signed short	M	Infeed Photo Eye Sensor Input	Values range from -6 to +6 The number (0-6) specifies the output port 0 = disabled the sign (+ or -) indicates the input polarity if negative input port is inverted
30153	41131	1	16452	68	R/W	signed short	M	Reject Confirm 1 Input	Same as For Infeed Photo Eye Sensor
30154	41132	1	16453	69	R/W	signed short	M	Reject Confirm 2 Input	Same as For Infeed Photo Eye Sensor
30155	41133	1	16454	70	R/W	signed short	M	Bin Full Input	Same as For Infeed Photo Eye Sensor
30156	41134	1	16455	71	R/W	signed short	M	Product Select 1 Input	Same as For Infeed Photo Eye Sensor
30157	41135	1	16456	72	R/W	signed short	M	Product Select 2 Input	Same as For Infeed Photo Eye Sensor
30158	41136	1	16457	73	R/W	signed short	M	Reject Suppression Input	Same as For Infeed Photo Eye Sensor
30159	41137	1	16458	74	R/W	signed short	M	Keylock Input	Same as For Infeed Photo Eye Sensor
30160	41138	1	16459	75	R/W	unsigned short	M	Excess Reject Count	1-200 Note in order to update Excess Reject Count Excess Span must also be updated
30161	41139	1	16459	75	R/W	unsigned short	M	Excess Reject Span	1-200 Span must be less than Count Note in order to update Excess Reject Span Excess Count must also be updated

Read Register	Write Register	Number of Registers	PCC Notification	PCC Acknowledge	Access	Data Type	Parameter Type	Description	Parameters
30162	41140	1	16460	76	R/W	signed short	M	Output Relay 1	Specifies function assigned to output If value is negative, the output is inverted
									0 = Disabled 1 = Reject 1 2 = Reject 2 3 = AuditCheck 4 = QAT 5 = Warning 6 = Alarm 7 = Fault
30163	41141	1	16461	77	R/W	signed short	M	Output Relay 2	Same as for Output Relay 1
30164	41142	1	16462	78	R/W	signed short	M	Output Relay 3	Same as for Output Relay 1
30165	41143	1	16463	79	R/W	signed short	M	Output Relay 4	Same as for Output Relay 1
30166	41144	1	16464	80	R/W	signed short	M	Output Relay 5	Same as for Output Relay 1
30167	41145	1	16465	81	R/W	signed short	M	Output Relay 6	Same as for Output Relay 1
30168	41146	1	n/a	n/a	RO	bitmap		IXR Active Type	Bits (0-1) IXR Type 0: = X Only 1: = R Only 2: = X and R Bit 2 = PSC Enabled 0: = Disabled 1: = Enabled
30169	41147	1	16467	83	R/W	unsigned short	P	R Detect Level	0-65535
30170	n/a	1	n/a	n/a	RO	unsigned short	M	R Current Peak	0-65535
30171	n/a	1	n/a	n/a	RO	unsigned short	P	R Capture Delay	Time From Opto Break Until IXR Signal starts Value * 4 = time in ms.
30172	n/a	1	n/a	n/a	RO	unsigned short	P	R Capture Length	Time From Opto Break Until IXR Signal starts Value * 4 = time in ms.
30173	41148	1	16468	84	R/W	unsigned short	P	X Detect Level	0-65535
30174	n/a	1	n/a	n/a	RO	unsigned short	M	X Current Peak	0-65535
30175	n/a	1	n/a	n/a	RO	unsigned short	P	X Capture Delay	Time From Opto Break Until IXR Signal starts Value * 4 = time in ms.
30176	n/a	1	n/a	n/a	RO	unsigned short	P	X Capture Length	Time From Opto Break Until IXR Signal starts Value * 4 = time in ms.

Read Register	Write Register	Number of Registers	PCC Notification	PCC Acknowledge	Access	Data Type	Parameter Type	Description	Parameters
30177	n/a	1	n/a	n/a	RO	enum	M	APEX Model	0 = Model type not set 1 = APEX 100 2 = APEX 300 3 = APEX 500 4 = APEX 500 Upgrade
30178	n/a	1	n/a	n/a	RO	enum	M	Machine Type	0 = Conveyor 1 = Pipeline 2 = Drop Through
30179		1			RO	unsigned short	M	Search Head Width	0-5000mm
30180	n/a	1	n/a	n/a	RO	unsigned short	M	Aperture Width	0-250mm Does not apply to conveyors
30181	n/a	1	n/a	n/a	RO	unsigned short	M	Aperture Height	0-250mm Does not apply to conveyors
30182	n/a	1	n/a	n/a	RO	packed bytes	M	Software Version	1st Byte = Major # 2nd Byte = Minor #
30183	n/a	1	n/a	n/a	RO	packed bytes	M	Software Revision / Beta	1st Byte = Revision # 2nd Byte = Beta #
30184	41149	1	16469	85	R/W	unsigned short	M	Current Year	2000-2099 Note: In order to change date Current Month / Day of Month must also be updated
30185	41150	1	16469	85	R/W	packed bytes	M	Current Month / Day of Month	1st Byte = Month 2nd Byte = Day of Month Note: In order to change date Current Year must also be updated
30186	41151	1	16470	86	R/W	packed bytes	M	Current Time	1st Byte = Hour 2nd Byte = Minute

Key

- M = Machine parameter. A global parameter that defines the underlying operation of the detector—such as model type (100, 300, 500), application used (conveyor, gravity-feed, pipeline, or Rx), and the preferred units of measure (feet or meters).
- P = Product parameter. Any product-related parameter—such as product name, phase angle, and so on.
- RO Read-only register
- R/W Read/write register

For other abbreviations and acronyms, see the Glossary at the end of the manual.

Appendix B— IntelliTrack™ XR

Overview

The IntelliTrack™ XR (IXR) function is an intelligent software-driven solution to two common problems that occur when trying to detect contaminants.

- Wet products where you are trying to detect non-magnetic stainless steel.
- Products that produce inconsistent phase angles from package to package, or within a single pack itself.

Before proceeding, please make sure the APEX and its associated operating environment and the product you are running, meet the following requirements.

System Requirements

The APEX and its associated operating environment must meet the following requirements.

- An in-feed product photo eye is installed.
- The in-feed product photo eye is positioned as follows;
 - at least 1x (one times) the smallest dimension of the search head's aperture, and,
 - no more than 5x this dimension from the in-feed edge of the aperture.
- In-feed guide rails are installed to prevent the packaged product from skewing.
- The conveyors are *always* run at a *constant speed* during your normal production runs and during the IXR calibration process. (Please note that, if—at a later date—you change the speed of the conveyor on your normal production runs, the IXR function *must* be recalibrated.)
- Version 4.0.0 (or later) of the detector's operating software is installed.

Product Requirements

The product you are running must meet the following requirements.

- The product must be in package form. Please note, the IXR function should *not* be used for bulk products on conveyors (for example, apples, grapes, and so on) or on liquids in pipelines.
- The leading edge of the packed product must consistently block the in-feed photo eye. This requirement is critical for the IXR function to work properly.
- The packaged product must not skew as it passes through the search head. This requirement is also critical for the IXR function to work properly.
- When using the IXR calibration functions, a minimum gap between the packages equal to the width of the search head is required.
- During normal production runs, a minimum gap of 25 mm between packages must be maintained. (Please note that if the APEX detects no gap between the packages, the IXR function will use the package length you entered, but false rejects may occur as a result.)

Discussion of Product Requirements

The IXR function may overcome some of the common pitfalls of phasing, but it requires that products are fairly consistent as far as the signal they produce while travelling through the search-head aperture. The products themselves also need to be consistent in content, volume, and presentation (orientation). For example, a product that has varying fat- or salt-contents, may not produce the consistent signal the IXR function requires to detect very small amounts of metallic contamination.

The volume of the product is also important, because a larger volume of product will produce a larger signal. As a result, the volume of the product should be consistent to get the best performance from the IXR function. Product presentation is another factor that is crucial to IXR function. Presentation includes the shape and orientation of the product as it passes through the aperture. For example a product that is cube-shaped should have guide rails to insure that it passes through the aperture parallel to belt and through the same part of the aperture each time. Similarly, a rectangular box must pass through the aperture with the same orientation as used when calibrating the product.

The IXR function requires a photo eye and a constant speed for each product for the real-time product signal to match the one that is stored in memory during calibration. A variable-speed conveyor can be used, but changing the speed means the IXR function must be recalibrated. Please note, however, that the APEX has an IXR tracking feature that allows small and gradual speed changes over time to be accommodated. In addition, the IXR-tracking feature allows the APEX to accommodate gradual changes in the product signal over time that occur due to slight variations in temperature, belt speed, or other non-contaminant factors. This feature often eliminates false rejects due to this type of variation in the product signal.

The Next Step

Before you can start using the IXR function, you must do the following.

- 1) Set the proper pack length, “detection no-pack” distance, photo-eye distance, and photo-eye registration. These four parameter *must* be set for the IXR function to work properly.
- 2) Enable the IXR function.
- 3) Calibrate the system.

If you encounter problems while setting up the IXR function, please see the “Troubleshooting” section in this appendix, or contact Thermo Fisher Scientific—as described in the “Contacting Thermo Fisher Scientific” section at the end of the manual.

Setting Up Related Functions

For the IXR function to work properly, you *must* set the following parameters.


- Pack length
- "Detection no-pack" distance
- In-feed photo-eye distance
- Photo-eye registration

The following sections tell you how to set up these four parameters.


Keying In the Pack Length

The pack length *must* be set for the IXR function to work properly. To set the pack length, do the following.


- 1) Make sure the Main Menu is displayed.




- 2) Press the Go button and page 1 of the product menu appears.




- 3) Press the down-navigation button to highlight page 2 of the product menu.




- 4) Press the right-navigation button to highlight the pack-length function.



- 5) Press the Go button, and the pack-length input screen appears.



- 6) Key in the length of the packages you are testing. In the example below, we keyed in 12.4 centimeters using the detector's navigation buttons.




- 7) Press the Go button to save your pack-length setting and exit the input screen.


Keying In the “Detection No-Pack” Distance

The “detection no-pack” distance should also be set, as described below.


- 1) Follow steps 1–3 in the “Keying In the Pack Length” section above to reach this screen.




- 2) Navigate to the “Detection no-Pack Distance” function and make sure it is highlighted.



- 3) Press the Go button, and an input screen appears.



- 4) Key in the length of the packages you are testing—that is, key in the *same* value you entered for pack length in the “Keying In the Pack Length” section above. (We keyed in 12.4 centimeters, the same value we entered above for pack length.)




- 5) Press the Go button to save your setting and exit the input screen.


Keying In the In-Feed Photo-Eye Distance

The in-feed photo-eye-to-detector distance *must* be set for the IXR function to work properly. To set the in-feed photo-eye distance, do the following.


- 1) Take a tape measure and note the distance from the photo-eye (on the upstream or “in-feed” side of the detector) to the in-feed side of the detector’s search head.
- 2) Make sure the Main Menu is displayed.




- 3) Navigate to the system and tools menu.




- 4) Press the Go button and navigate to page 3 of the system and tools menu.




- 5) Navigate to the photo-eye set-up menu.




- 6) Press the Go button, and page 1 of the “Photo-Eye Distance and Head Width” menu appears.



- 7) Press the right-navigation button to select the “In-Feed Photo-Eye Distance” menu.



- 8) Press the Go button, and an input screen appears. (The figures in your screen, however, may be different, because the screen displays the last setting used.)




- 9) Use the navigation buttons to input the distance from the photo-eye to the in-feed side of the detector head. (In our example, we would enter a distance in millimeters.)
- 10) Press the Go button to save your setting and exit the input screen.

Enabling Photo-Eye Registration


We recommend that you set the photo-eye registration function to detect the *middle* of your product, but the IXR function will work when the photo-eye registration is set to detect the leading edge or entire length of your product. The key point is, the IXR function will *not* work if photo-eye registration is set to "Off."

To set photo-eye registration, do the following.


- 1) Make sure the detector's Main Menu is displayed.



- 2) Navigate to the reject-totals menu.




- 3) Press the Go button and navigate to page 2 of the rejects-totals menu.




(continued...)

- 4) Press the right-navigation button to select the photo-eye registration menu. (The screen below shows that currently the photo-eye registration is set to detect the leading edge of the product.)



- 5) Press the Go button repeatedly until the check mark is displayed next to the "detect the middle of the package" icon, as shown below.




- 6) Press the Back button to save your setting and exit the menu.


Enabling the IXR Function

To enable the IXR function, do the following.


- 1) Make sure the Main Menu is displayed.




- 2) Navigate to the system and tools menu.



- 3) Press the Go button, and page 1 of the system and tools menu appears.




- 4) Navigate to the IXR menu and make sure it is highlighted.




(continued...)


5) Press the Go button, and the following screen appears.



6) Press the right-navigation button to highlight the IXR menu.




7) Make sure the IXR icon is highlighted and press the Go button. The following screen appears showing the IXR function is now enabled (because a checkmark is displayed next to the IXR icon). In addition, the screen shows additional IXR options that are now available. (These additional functions are described in the sections that follow.)



(continued...)

- 8) Press the Back button repeatedly to return to the Main Menu. Please note that, now the IXR function is active, additional displays have been added to the Main Menu, as shown below. (Please see the “Understanding the IXR Display” section on page 388 for more information about these additional displays.)



Calibrating the IXR Function

There are two basic steps to calibrating the IXR function, as follows.

- Learn the *X* and *R* noise thresholds.
- Learn the detect levels (for both the *X* and *R* signals).


In addition, if you are going to use the IXR function for long production runs lasting several hours or days, you should make sure the IXR tracking function is set to “On” (the default value).

Learn the *X* and *R* Noise Thresholds

Please note it is very important that, while calibrating the *X* and *R* noise thresholds, you run the conveyor at *exactly the same speed* you will use during your normal production runs. Thus, if you decide at a later date, to change the speed of the conveyor during your normal production runs, you *must* recalibrate the *X* and *R* noise thresholds.


To calibrate the *X* and *R* noise thresholds, do the following.

- 1) Make sure the Main Menu is displayed.




(continued...)


2) Navigate to the frequency and gain menu.



3) Press the Go button and page 1 of the frequency and gain menu appears. Navigate to page 2, as shown below.




4) Navigate to the "Calibrate Noise Thresholds" function and make sure it is highlighted, as shown below.




(continued...)

- 5) Make sure that the conveyor is running at the speed you will use for normal production runs and no product is moving through the search head, then press the Go button. The detector immediately starts measuring the *X* and *R* noise thresholds. The monitor screen (shown below) presents a bar graph of the progress of the calibration, which takes approximately 20 seconds to complete.



- 6) When the calibration is finished, the "Calibrate Noise Threshold" menu reappears.



This screen tells you the following about the IXR function.

X: 500 The noise threshold for the *X* signal is 500.

R: 500 The noise threshold for the *R* signal is 500.

- 7) Press the Back button repeatedly to exit the menu and return to the Main Menu.

Using the Auto-Calibration Function


To have your products properly calibrated during the IXR auto-calibration procedure, you should already have installed the appropriate guides to make sure each package passes through exactly the same spot in the search head and in the exact same orientation. In other words, the necessary guides are in place to handle "problem" packages (such as rectangular packages) that could otherwise pass through the search head in a variety of locations and orientations. In addition during the calibration process, you must run the conveyor at *exactly the same speed* you will use during your normal production runs. Before starting, have about 30–50 uncontaminated packages ready.

When running the calibration procedure, please make sure that the gap between your packages—the pack gap—is equal-to-or-greater-than the width of the search head. (For example, if your search head is 30 cm wide, the gap between your packages should be


at least 30 cm.) Maintaining the appropriate pack gap is *critical* to the success of the calibration procedure.

To auto-calibrate the IXR function, do the following.


- 1) Make sure the detector's Main Menu is displayed.




- 2) Press the Go button and page 1 of the "Product Calibrate and Name" menu appears.




- 3) Navigate to the "Full Product Calibration" menu and make sure it is highlighted.




- 4) Make sure the conveyor is running at the speed you will use during normal production runs, and press the Go button to start the IXR calibration. The following screen appears.




- 5) Place your packages on the conveyor and let them to pass through the search head, making sure the appropriate pack gap is maintained between all the packages. The bar graph in the screen monitors progress. Currently, the screen shows that four packages have been passed and the noise threshold for both the *X* and *R* signal is 500. The IXR icon flashes telling you the APEX is currently learning the IXR signal.



- 6) After at least nine packages have been passed, the preliminary IXR-signal learn is complete, as shown by the check mark below the IXR icon in the screen below.




- 7) Continue passing packages so the detector can now start learning the detect level. The detect-level icon flashes telling you the APEX is currently learning the detect levels. The values for the detect levels update every 10 seconds, and the entire learning process takes approximately 60 seconds to complete. You may, however, *stop* the detect-level calibration at any time by pressing the Go button—for example when you are satisfied with the current detect levels for the *X* and *R* signals.
- 8) When the auto-calibration procedure is complete, the Main Menu reappears. Currently (as shown in the screen below) the detect level is 554 for the *X* signal and 488 for the *R* signal.




Using the IXR Calibration Function

This function calibrates only the IXR function. To use this function, make sure the same prerequisites and similar procedures are followed as described in the “Using the Auto-Calibration Function” section on page 382. To start the IXR calibration process, do the following.

- 1) Navigate to the IXR menu.



- 2) Navigate to the calibrate icon and make sure it is highlighted.




- 3) Press the Go button.

Using the IXR Detect-Level Calibration Function


This function calibrates only the IXR's detect levels. To calibrate the IXR detect levels, make sure the same prerequisites and similar procedures are followed as described in the “Using the Auto-Calibration Function” section on page 382. To start the IXR detect-level calibration, do the following.

- 1) Make sure the Main Menu is displayed.




(continued...)


2) Navigate to the detect-level menu.



3) Press the Go button and page 2 of the "Detection Level and Noise Threshold" menu appears.



4) Navigate to the calibrate-detect-level icon and make sure it is highlighted.




5) Press the Go button.

IXR Tracking


The default value for IXR tracking is "On" and is a useful feature during long production runs lasting many hours or several days. When IXR tracking is on, the detector tracks small changes in the *X* and *R* signals that may occur because of small hourly or daily temperature changes in your product or production environment. In addition please note that, for tracking to work, there *must be a gap* between individual packages. The minimum pack gap is 25 mm and the optimum pack gap is equal-to-or-greater-than half of the width of the aperture of the search head.

To verify IXR tracking is on, do the following.

- 1) Navigate to the IXR menu (as described in steps 1–4 in the "Enabling the IXR Function" section on page 378).



- 2) Press the Go button and navigate to the "Enable IXR Tracking" menu.



The default value for IXR tracking in "On," as shown by the checkmark next to the tracking icon in the above screen. If tracking is set to "Off" (as shown by an *X* next to the icon), press the Go button and a checkmark appears.

- 3) Press the Back button repeatedly to exit the menu and return to the Main Menu.


Understanding the IXR Display

Once the IXR function has been enabled, the detector's Main Menu displays additional information that helps you monitor how the IXR function is operating—specifically by displaying the following.

- Detect levels for both the *X* and *R* channels.
- Peak-signal values for both the *X* and *R* channels.
- A display showing the above information in an easy-to-read graphical format.

Dual Display for Detect Levels


The dual display for the *X*- and *R*-detect level looks like this. (The actual values in your screen—almost certainly—will be different.)




Thus, when the APEX detects a signal in either the *X* or *R* channel that exceeds the displayed thresholds, the package will be rejected. Please note that when the display is highlighted (as shown in the screen above), pressing the Go button takes you directly to the "Detection Level and Noise Threshold" menu (that is, page 2 of the frequency and gain menu, where these values can be changed if needed).

Dual Display for Peak Signals

The dual display showing the peak signals detected on the *X* and *R* channels looks like this. (The actual values in your screen—almost certainly—will be different.)




Please note when a package is rejected because of the presence of metallic contaminants, the channel or channels (*X* or *R*, or both) that was responsible, is highlighted. In the example below, the *X* channel detected the contaminant, causing the package to be rejected.



Dual Bar-Graph Display


The dual bar graph display is only available if the heading text feature is disabled. If the heading text feature is currently enabled (as shown in the screen below), do the following to change the detector's display to a graphical format.

- 1) Make sure the Main Menu is displayed.




(continued...)


2) Navigate to the system and tools menu.




3) Press the Go button and navigate to the "Bargraph and Help Setup" menu.



4) Press the Go button, and the "Toggle Help Text" screen appears.



5) Press the Go button and the heading text changes to a *dual* bar-graph. The top part of the graph displays detect-level data for the *X* channel, and the lower part of the graph for the *R* channel, as shown below. Please note that the scales of the *X* and *R* channels may not be identical.



- 6) Press the Back button repeatedly to return to the Main Menu, allowing you to view IXR data in a graphical as well as numeric format.

Troubleshooting


If any pop-up information boxes (shown below) appear while you are setting up the IXR function, here are the causes and suggested solutions. All information boxes are marked with the following symbol.



Please note that when the heading text display is active (as opposed to the IXR dual bar-graph display), a textual description of the problem is also displayed.

Photo Registration Not Set


The following information box appears when the photo registration has not been set.



Solution: Go to the “Enabling Leading-Edge Photo Registration” section above for instructions about setting the proper photo registration.

Photo-Eye Distance Is Set to Zero


If the photo-eye distance is set to zero (an invalid setting for the IXR function), the following information box appears.



Solution: Go to the “Keying In the In-Feed Photo-Eye Distance” section above for instructions about setting the appropriate photo-eye distance.

The Six Product Maximum Has Been Reached

If you attempt to set up more than six products (the maximum allowed by the IXR function), the following information box appears.



Solution: Delete one of the previously set up products.

Signal Saturation Has Occurred

If signal saturation occurs while you are calibrating the IXR function, the following warning box appears.



Solution: Go to the “Frequency and Gain” menu and adjust these settings to a lower level. If the problem persists, please contact Thermo Fisher Scientific—as described in the “Contacting Thermo Fisher Scientific” section at the end of the manual.

Glossary

In this glossary, any term in *italics*, refers to a technical term that is defined elsewhere in the glossary.

Glossary

<u>Term</u>	<u>Definition</u>
Alarm	See <i>WAF</i>
Application	There are four types of applications: conveyor, gravity-feed, pipeline, and pharmaceutical. The term describes how <i>product</i> is passed through the detector's <i>search head</i> .
Application-specific parameter	Parameters that must be set, when using a particular <i>application</i> .
Auto-calibration	A <i>function</i> that allows the detector to set the phase angle, <i>detect level</i> , and AuditCheck settings using test contaminants.
Back button	The red button on the detector's <i>control panel</i> .
CAL	Calibrate. An abbreviation used in the detector's <i>function</i> menus.
CLX	The clip-X filter, which reduces noise when wet-products are being tested.
Control keys	The four icons in the (software-driven) <i>keyboard screen</i> that allow you to move the cursor left and right, delete a character, and exit from the <i>keyboard screen</i> .
Control Panel	This comprises the navigation, Go, and Back buttons; the <i>indicator lights</i> ; and the <i>display panel</i> .
CPU	Central processing unit
Detect level	During the <i>auto-calibration</i> procedure, the detector measures the level of background noise (the amount of background signal in the <i>search head</i>) and multiplies this by a factor of 2–3 to set the detect level. Any signal (excessive noise/contamination) that exceeds the detect level is tagged as contamination. However, when the detect level is properly set, metals—and only metals—will be tagged as contamination.
DHCP	Dynamic host-control protocol

Glossary

<u>Term</u>	<u>Definition</u>
DIP switch	Dual in-line package switch
Display function	A display <i>function</i> does just that, it displays the current setting of a specific <i>function</i> and is, in effect, just a gauge. No changes can be made to the function using the display-function screen (but the displayed values can often be changed by accessing other <i>menus</i> and <i>functions</i>).
Display panel	The <i>LED</i> screen that shows the detector's <i>Main Menu</i> and related <i>sub-menus</i> .
DSP	Digital signal processor
EMI	Electro-magnetic interference
Enum	enumerator
Fault	See <i>WAF</i>
FIR	Finite impulse-response filter
Function	Functions are accessed using the detector's <i>Main Menu</i> and are the software routines that control everything the detector does. Most have parameters that can be set by you, the user.
Global parameter	Parameter you set infrequently and which affect how data is shown in the <i>display panel</i> . Global parameters include the language shown in the <i>Main Menu</i> , the preferred units of measure (meters/feet) used by the detector, and whether <i>Help Text</i> is shown in the <i>Main Menu</i> .
Go button	The green button on the detector's <i>control panel</i> .
GW	Gateway address
Help Text	The top part of the <i>Main Menu</i> that shows a brief description of the <i>function</i> you are currently using.
HMI	Human-machine interface
ID	Identity
IEC	International Electrotechnical Commission
Indicator lights	The indicator lights in the <i>control panel</i> show the current status of the <i>search head</i> . There are three indicator lights—red, green, and yellow.

Glossary

<u>Term</u>	<u>Definition</u>
Input screen	An input screen is used for keying in values for a specific detector <i>function</i> . The right-hand number in the input screen is marked with a small triangle above and below—indicating <i>all</i> the numbers in the screen can be changed using the <i>navigation buttons</i> .
IP	Internet protocol
Keyboard screen	A screen that appears in the <i>display panel</i> and looks like a computer keyboard. The keyboard screen allows you to enter letters, numbers, and other characters for naming <i>products</i> , setting passwords, and so on.
LED	Light-emitting diode
LSB	Least-significant byte
M	In the Modbus registers, a machine setting—one of the detector's <i>global parameters</i> .
MAC	Media access control address
Main Menu	The initial menu shown in the detector's <i>display panel</i> . The Main Menu is the starting point for accessing all of the detector's many <i>functions</i> .
Monitor screen	A screen that incorporates a progress bar allowing you to monitor the progress of a <i>function</i> —for example, the detector's <i>auto-calibration</i> function.
MSB	Most-significant byte
MZ	Multi-zone detection, meaning the <i>search head</i> must see two peaks (not one) to tag the signal as contamination.
n/a	Not applicable
Navigate	In this manual, the term "Navigate to..." means "Use the four <i>navigation buttons</i> on the detector's <i>control panel</i> to move to and highlight the particular <i>function</i> you are interested in."
Navigation buttons	The four blue triangular buttons on the detector's <i>control panel</i> that allow you to move to a particular <i>function</i> or change the numbers in an <i>input screen</i> .
NVRAM	Non-volatile random-access memory
P	In the Modbus registers, a <i>product</i> setting (for example, product 001).

Glossary

<u>Term</u>	<u>Definition</u>
Pack gap	This <i>function</i> allows you control whether one or both of two sequential units of <i>product</i> are rejected, when there is uncertainty about which one is contaminated. The pack-gap function is expressed as a percentage and, for a typical conveyor <i>application</i> , should be set to 100%.
Pack length	The length of the individual units of <i>product</i> (for example, packets of salted butter) placed on a conveyor.
Parameters	
—Application-specific	See <i>Application-specific parameter</i>
—Global	See <i>Global parameter</i>
—Product	See <i>Product parameter</i>
—Product-rejection	See <i>Product-rejection parameter</i>
PCB	Printed circuit board
PCB–A	Printed circuit board assembly
PCC	Parameter-change coil
PE	Photo eye (a photo-electric cell).
Peak signal	The maximum signal produced when a metallic contaminant passes through the <i>search head</i> .
PLC	Programmable logic controller
PNR	Phased noise-reduction filter
PO	Purchase order
Product	Any finished product, incoming raw material, and so on that is being checked for metal contaminants by the detector.
Product parameter	Parameters you set to control how <i>product</i> is controlled and identified in your particular <i>application</i> and operating environment.
Product-rejection parameter	Parameters you set to control how contaminated <i>products</i> (or test samples) are rejected in your particular <i>application</i> and operating environment.
PSC	Product signal compensation
PSU	Power supply unit
QA	Quality assurance

Glossary

<u>Term</u>	<u>Definition</u>
QAT	The Quality Assurance test—one of the detector's quality-control <i>functions</i> .
QNR	Quadrature noise-reduction filter
RAM	Random-access memory
Reject device	Any mechanical device downstream of the <i>search head</i> that allows contaminated <i>products</i> to be separated from uncontaminated <i>products</i> . In a typical conveyor <i>application</i> , "Reject 1" is the main reject device and "Reject 2" the secondary reject device.
RFI	Radiated frequency interference
RO	In the Modbus registers, a read-only register.
R threshold	Electrically conductive materials and many food products, by nature, are electrically conductive. Salt- and moisture-content combine to produce resistive effects that must be overcome in order to detect small metallic contaminants. The R threshold is a noise threshold for resistive signals. Signals above the threshold usually indicate <i>product</i> or metal contaminant signals. Excessive resistive signals could indicate external noise (such as <i>VFD</i> and <i>EMI</i> noise), ground loops, static, and so on is present in the area around the metal detector.
RTU	Remote terminal unit
R/W	In the Modbus registers, a read/write register.
Rx	Pharmaceutical application
Search head	The large rectangular box with a hole in the middle through which <i>products</i> are passed to be tested for the presence of metallic contaminants. Inside, the magnetic field created by a pair of balanced coils is disturbed by the passage of metal, allowing the detector's circuitry to tag the product as contaminated.
SF-NB	<i>Speed filter</i> —narrow band
SF-WB	<i>Speed filter</i> —wide band
Speed filter	The speed filter is a narrow-band pass filter that rejects most background noise, but still allows a maximum metal signal from the search head to be processed by the detector.

Glossary

<u>Term</u>	<u>Definition</u>
Sub-menu	Additional <i>functions</i> that are accessed from the detector's <i>Main Menu</i> .
Thresholds	Thresholds are maintained for resistive and reactive effects and, if exceeded, usually indicate a <i>product</i> is present. High threshold values may indicate external noise is present. See <i>X threshold</i> and <i>R threshold</i> .
VFD	Variable frequency drive
Warning	See <i>WAF</i>
WAF	Warning, alarm, or fault. Many of the detector's <i>functions</i> use WAFs—in conjunction with a hardwired external device—to notify you when some condition occurs that needs your attention (a warning), to alert you to something more urgent has happened (an alarm), and to automatically take action (a fault) if something more serious occurs. Warnings often activate a light; an alarm, a buzzer; and a fault, a <i>PLC</i> that shuts something down—such as the conveyor in a conveyor <i>application</i> , or the flow of product a gravity-feed or pipeline <i>application</i> .
X threshold	Ferro-magnetic and electrically conductive materials produce reactive effects. Iron is both electrically conductive and is ferro-magnetic. As a result, the properties of iron is different from a metal such as copper, which is a strong electrical conductor. The X threshold is a noise threshold for reactive signals. Signals above the threshold usually indicate <i>product</i> or metal contaminant signals. Excessive reactive signal could indicate external noise (such as the presence of VFD, EMI, and vibration), ground loops, static, and so on is present in the area around the metal detector.

Contacting Thermo Fisher Scientific

If you are located in North America (United States or Canada), please use the information below to contact Thermo Fisher Scientific. If you are located elsewhere in the world, please see the list of Thermo Fisher Scientific offices worldwide on the page that follows this one.

Getting Technical Support

Here is the contact information for getting technical support for your APEX.

- *Telephone—1-800-227-8891 (Select option 3 in the voice menu)*
Please follow the prompts for “Technical Support” and have your APEX serial number ready.
- *Fax—1-763-780-1537*
Use this number to get technical support.
- *Email*
Please email us at Service.W&I.Mpls@thermofisher.com. Please include your APEX serial number in your message.

Ordering Parts

Here is the contact information for ordering parts for your APEX.

- *Telephone—1-800-227-8891 (Select option 4 in the voice menu)*
Please ask for the “Parts Department” and have your APEX serial number ready.
- *Fax—1-763-780-2548*
Use this number for ordering parts. Please include the serial number of your APEX.
- *Email*
Please email us at Parts.W&I.Mpls@thermofisher.com.
- *Street Address*
Please write to us for parts at the following address.

Thermo Fisher Scientific
Attn: Parts Department
501 90th Ave NW
Minneapolis, MN 55433

Obtaining a Return Materials Authorization Number

Here is the contact information for getting an RMA number.

- *Telephone—1-800-227-8891*
Please press Option 3 (or state you need an “RMA number”).
- *Fax—1-763-780-1537*
Please complete the Return Material Authorization (RMA) form on page 266 of the manual. Then, fax it to us to get an RMA number.
- *Email*
Please email the Service Department at Service.W&I.Mpls@thermofisher.com and ask for an RMA number.

List of Thermo Fisher Scientific Offices Worldwide

Asia/Pacific

+86 21 6865 4588
+86 21 6445 1101 fax

China

+86 (800) 810 5118
+86 21 6445 1101 fax

France

+33 (0) 1 60 92 48 00
+33 (0) 1 60 92 49 00 fax

Germany

+49 (0) 208-824930
+49 (0) 208-852310 fax

Italy

+39 02-0521 78861
+39 02-0521 272914 fax

Mexico/Latin America

+52 (01) 55 5639 2360
+52 (01) 55 5639 2227 fax

Netherlands

+31 (0) 31 76 579 5555
+31 (0) 31 76 571 4958 fax

South Africa

+27 (0) 11-609-3101
+27 (0) 11-609-3110 fax

Spain

+34 914 845 965
+34 914 843 597 fax

United Kingdom

+44 (0) 1788-820300
+44 (0) 1788-820301 fax

United States/Canada

+1 (800) 227-8891
+1 (763) 780-1537 fax

Supplemental Information

The following supplemental information is included to help you install, operate, and maintain your APEX.

Description	Document
APEX Spare Parts List	REC-F-90
APEX Quick Reference Guide—English	REC-F-58
APEX 500/100 Outline and Mounting	B07387M-B001
Electronics Upgrade, DSP2/3 Metal Eliminator to APEX	B07387M-B002
APEX 300 Outline and Mounting	B07387M-B300
APEX 300D Outline and Mounting Gravity-Feed System/Ceiling Mount	B07387M-B301
APEX 300P Outline and Mounting Pipeline System/Ceiling Mount	B07387M-B302
APEX 300P Outline and Mounting Pipeline System/Floor Stand	D07387M-B303
APEX 500 Rx System Outline and Mounting	D07404M-B005
APEX 500 Rx Head and Electronics Outline and Mounting	D07404M-B002
APEX 500 Rx Head, Electronics, and Reject Outline and Mounting	D07404M-B006
APEX Conveyor Field-Wiring Diagram	D07387M-W001
APEX Gravity-Feed and Pipeline Field-Wiring Diagram	D07387M-W002
APEX 500 Rx Pneumatic Reject Field-Wiring Diagram	D07387M-W004

This page intentionally left blank



APEX Spare Parts List

Customer _____

C# _____

Prepared By _____

Date ___/___/___

<u>Description</u>	<u>Part no.</u>	<u>QTY</u>
<input checked="" type="checkbox"/> SP1: Always provided Spares		
-Fuse (Main power supply)	089973	1
-Fuse (Output relays)	086214	1
-Test Spheres	TBD	
-Ferrous, Non-ferrous and 316 SST		1 of each type
<input type="checkbox"/> SP2: Spare Parts Kit – Apex 100		
-CONTROL PANEL ASSY, APEX 100	090586	1
-PSU TO CPU M/B CABLE	268264	1
-CPU M/B TO S/H BOARD CABLE	268265	1
-PCBA,POWER SUPPLY UNIT,APEX	268392	1
-PCBA,RELAY BOARD,APEX	268393	1
-PCBA,SEARCH HEAD,DSP3	079073	1
<input type="checkbox"/> SP2: Spare Parts Kit – Apex 300		
-CONTROL PANEL ASSY, APEX 300	095297	1
-PSU TO CPU M/B CABLE	268264	1
-CPU M/B TO S/H BOARD CABLE	268265	1
-PCBA,POWER SUPPLY UNIT,APEX	268392	1
-PCBA,RELAY BOARD,APEX	268393	1
-PCBA,SEARCH HEAD,DSP3	079073	1
<input type="checkbox"/> SP2: Spare Parts Kit – Apex 500		
-CONTROL PANEL ASSY, APEX 500	089275	1
-PSU TO CPU M/B CABLE	268264	1
-CPU M/B TO S/H BOARD CABLE	268265	1
-PCBA,POWER SUPPLY UNIT,APEX	268392	1
-PCBA,RELAY BOARD,APEX	268393	1
-PCBA,SEARCH HEAD,DSP3	079073	1

All changes to this document must be approved by the product engineer. New revisions must be given to the ECO coordinator and distributed to all relevant global manufacturing affiliates.


This page intentionally left blank

APEX Metal Detector Quick- Start Guide

Control Panel

The main components of the detector's control panel are as follows.

- The display panel.
- The three (red, green, and yellow) indicator lights.
- The green Go button.
- The red Back button.
- The four blue triangular-shaped navigation buttons.



The Indicator Lights

These give you a quick overview of how the detector is functioning.

- Red—Flashing once indicates excess product effect; steady indicates a fault.
- Green—Indicates a product is present in the detector's search head.
- Yellow—Indicates a contaminant has been detected in the product.

The Navigation Buttons

These allow you to navigate around the detector's menus and sub-menus and are used to increase or decrease numbers and

select characters and settings in various menus and input screens.

The Go Button


Press the Go button to select or start one of the detector's functions.

The Back Button


Press the Back button to stop one of the detector's functions or to return to the previous menu screen. Press repeatedly to return to the Main Menu.

Main Menu

The APEX's Main Menu normally looks like this.



However, if you have enabled the IXR function (see page 8), the Main Menu looks like this.



Naming the Product

This allows you to name the product you are testing.

- 1) Make sure the Main Menu is displayed.
- 2) Press the Go button and the product-calibration menu appears.
- 3) Press the down-navigation button to highlight the "Edit Product Name" function.



- 4) Press the Go button and the keyboard screen appears.
- 5) Key in a name for the product you are testing using the keyboard screen.
- 6) Highlight the keyboard's exit-and-save key (in the bottom right corner) and press the Go button to exit the keyboard screen.

Changing Applications

The APEX can be configured to handle four basic types of applications.

- Conveyor applications
- Gravity-feed applications
- Pipeline applications
- Pharmaceutical (Rx) applications

When you received your APEX, it was configured at the factory to meet your particular working environment (for example, a conveyor application). However, if you now wish to use your APEX for a *different* application (for example, an Rx application), please contact Thermo (see "Contact Information" below) for instructions on how to configure the APEX to handle your new application.

Contact Information

You can telephone technical support at USA 1-800-227-8891 (press option 3), or see page 399 of the *APEX User's Guide* for more contact options.

Conveyor Applications

Listed below are the most commonly used functions for setting up a typical conveyor application.


Pack Length

This is the length (mm or inches) of the product you are testing.

- 1) Make sure the Main Menu is displayed.
- 2) Press the Go button and the full product calibration screen appears.
- 3) Navigate to page 2 of this menu.

(continued...)

- 4) Highlight the pack-length function.




- 5) Press the Go button and an input screen appears.
- 6) Key in the pack length (mm or inches).

No-Pack Distance

In most conveyor applications it is best to enter identical values for the pack length and no-pack distance (mm or inches).

- 1) Make sure the screen shown in the Pack Length section above is displayed.
- 2) Highlight the no-pack distance function.




- 3) Press the Go button and an input screen appears.
- 4) Key in the no-pack distance (mm or inches).

Pack Gap

The pack gap is expressed as a percentage of the no-pack distance and is best set to 100%. Changing the pack gap allows you to fine-tune whether the detector rejects only one or *both* units of product based on product spacing, when there is uncertainty about which of the packs is contaminated.

- 1) Make sure the screen shown in the Pack Length section is displayed.
- 2) Highlight the pack-gap function.




- 3) Press the Go button and an input screen appears.
- 4) Key in the pack gap (as a percentage).

Product Speed

This function is used to enter the speed of your conveyor (for conveyor applications) and the flow rate of your product in the duct or pipe (for gravity-feed and pipeline applications).

- 1) Make sure the Main Menu is displayed.
- 2) Highlight the product-speed menu.



- 3) Press the Go button and an input screen appears.
- 4) Key in the belt speed (meters/minute or feet/minute).


Photo-Eye-to-Detector Distance

This is the distance from the photo eye (on the upstream or “in-feed” side of the detector) to the in-feed side of the search head.

- 1) Make sure the Main Menu is displayed.
- 2) Navigate to the system and tools menu.
- 3) Press the Go button.
- 4) Navigate to page 3 of the menu.
- 5) Highlight the photo-eye set-up menu.
- 6) Press the Go button and the “photo-eye distance and head width” menu appears.

(continued...)

- 7) Highlight the “in-feed photo-eye distance” function.




- 8) Press the Go button and an input screen appears.
- 9) Key in the photo-eye-to-detector distance (mm or inches).

Polarity of the Photo-Eye Input

Because photo-eyes are either dark or light activated, this function tells the detector how to interpret the signals from your particular photo eye.

- 1) Make sure the Main Menu is displayed.
- 2) Navigate to the system and tools menu.
- 3) Press the Go button.
- 4) Navigate to page 2 of the menu.
- 5) Highlight the inputs and outputs menu.
- 6) Press the Go button.
- 7) Highlight the inputs menu.
- 8) Press the Go button and the inputs set-up menu appears.
- 9) On page 1 of the menu, highlight the “In-feed Photo Eye Input” menu. The “+2” notation tells you that the photo eye is connected to Input 2 on the wiring board and has a positive polarity.



- 10) To change these settings, press the Go button and an input screen appears.
- 11) Use the navigation buttons to select the appropriate input (1–6) and polarity.

Photo Registration for Product Rejects

This function allows you to select which part of the product triggers your reject device. This function is usually used for products that exceed six inches in length. Rejects are triggered in three different ways, as follows.

- By the leading-edge of the product.




- By the center of the product.



- By the entire length of the product.



- 1) Make sure the Main Menu is displayed.
- 2) Highlight the rejects menu.
- 3) Press the Go button.
- 4) Navigate to page 2 of the menu.
- 5) Press the right-navigation button to select the photo-registration menu.



- 6) To change this setting, press the Go button repeatedly until a check mark appears beside the part of the product that will trigger your reject device.


Distance to the Reject Device

This function allows you to input the distance (mm or inches) from the *downstream* edge of the search head to the *center* of your main (Reject 1) device.

- 1) Make sure the Main Menu is displayed.
- 2) Highlight the rejects menu.
- 3) Press the Go button.

(continued...)

- 4) On page 1 of the rejects menu, highlight the "Reject 1 Distance/Delay" function.




- 5) Press the Go button an input-screen appears.
- 6) Key in the appropriate distance (mm or inches). If you want to set a delay *time*, first highlight the "m→s" (or "ft→s") function, and press the Go button to select "delay" (a time parameter), which you will set in minutes and seconds in step 5 above.

Signal Duration for the Reject Device

This function allows you to set the duration of the signal needed (expressed in seconds and hundredths of a second) to activate your Reject-1 device.

- 1) Make sure the screen shown in the "Distance to the Reject Device" section above is displayed.
- 2) Highlight the "Reject 1 Duration" function.




- 3) Press the Go button and an input screen appears.
- 4) Key in the appropriate duration time (minutes and seconds). If you want to set the duration parameter as a *distance*, highlight the "s→m" (or "s→ft") function, press the Go button to select a distance parameter, then go to step 3 above and key in a distance (mm or inches).

Calibrate *X* and *R* Noise Thresholds

This calibration establishes a noise baseline for the detector, and must be done with the conveyor running and *no* product present in the search head.

- 1) Make sure the Main Menu is displayed.
- 2) Highlight the frequency and gain menu.
- 3) Press the Go button.
- 4) Navigate to page 2 of the menu.
- 5) Navigate to the "Calibrate Noise Thresholds" menu. (Note: The *background* of the calibrate function should now be highlighted in black, as shown below.)




- 6) Press the Go button and a monitor screen appears. The calibration is complete when the screen above reappears showing the calibrated values for the *X* and *R* thresholds. Typical values for these thresholds are as follows.
 - *X* threshold < 300
 - *R* threshold < 100

Full-Product Calibration

A full-product calibration allows the detector to learn how to identify your *uncontaminated* product, and sets the following basic parameters for your product.

- Phase-angle setting
- Detection level

- 1) Make sure the product name is highlighted in the Main Menu.
- 2) Press the Go button and the "Full Product Calibration" function is automatically highlighted.



- 3) Make sure the conveyor is running and uncontaminated product is passing through the search head.
- 4) Press the Go button and a monitor screen appears. During the calibration process a series of frequency/gain mini-screens may appear, which halts the calibration process as the detector searches for the optimum frequency/gain settings for your product. When this occurs, press the Go button to restart the calibration process. The Main Menu screen is displayed when the calibration is complete.


Gravity-Feed Applications

Listed below are the most commonly used functions for setting up a typical gravity-feed application.

Reject-Delay Time

This function is usually set to 0.00 seconds, and tells the gate to close immediately when contaminants are detected. If your gate is a long way from the search head, you may need to set a longer delay time.

- 1) Make sure the Main Menu is displayed.
- 2) Navigate to the rejects menu.
- 3) Press the Go button.
- 4) On page 1 of the rejects menu, highlight the "Reject 1 Distance/Delay" function.




- 5) Press the Go button and an input screen appears.
- 6) Key in an appropriate value (in seconds and hundredths of a second) for the reject-delay time.

Reject Duration Time

This is the time that the gate remains closed to divert contaminated product, and is usually set to one second.

- 1) Navigate to the screen shown in the “Reject-Delay Time” section.
- 2) Highlight the “Reject 1 Duration” function.



- 3) Press the Go button and an input screen appears.
- 4) Key in the appropriate value (in seconds and hundredths of a second) for the reject-duration time.

Calibrate X and R Noise Thresholds

See the instructions on page 5.

Full-Product Calibration

See the instructions on page 5.

Pipeline Applications

Listed below are the most commonly used functions for setting up a typical pipeline application.


Reject-Delay Time

This function is usually set to 0.00 seconds, and tells the diverter valve to close immediately when contaminants are detected. If your diverter valve is a long way from the search head, you may need to set a longer delay time.

- 1) Make sure the Main Menu is displayed.
- 2) Navigate to the rejects menu.
- 3) Press the Go button.

(continued...)

- 4) On page 1 of the rejects menu, highlight the “Reject 1 Distance/Delay” function.




- 5) Press the Go button and an input screen appears.
- 6) Key in an appropriate value (in seconds and hundredths of a second) for the reject-delay time.

Reject Duration Time

This is the time that the diverter valve remains closed to divert contaminated product to the waste tank, and is usually set to 3.00 seconds.

- 1) Navigate to the screen shown in the “Reject-Delay Time” section.
- 2) Highlight the “Reject 1 Duration” function.



- 3) Press the Go button and an input screen appears.
- 4) Key in the appropriate value (in seconds and hundredths of a second) for the reject-duration time.

Calibrate X and R Noise Thresholds

See the instructions on page 5.

Full-Product Calibration

See the instructions on page 5.


Rx Applications

Listed below are the most commonly used functions for setting up a typical pharmaceutical application.

Reject-Delay Time

This function is usually set to 0.00 seconds, and tells the chute to close immediately when contaminants are detected. If your chute is a long way from the search head, you may need to set a longer delay time.

- 1) Make sure the Main Menu is displayed.
- 2) Navigate to the rejects menu.
- 3) Press the Go button.
- 4) On page 1 of the rejects menu, highlight the "Reject 1 Distance/Delay" function.




- 5) Press the Go button and an input screen appears.
- 6) Key in an appropriate value (in seconds and hundredths of a second) for the reject-delay time.

Reject Duration Time

This is the time that the chute remains closed to divert contaminated product, and is usually set to 0.15 seconds.

- 1) Navigate to the screen shown in the "Reject-Delay Time" section.
- 2) Highlight the "Reject 1 Duration" function.



- 3) Press the Go button and an input screen appears.

(continued...)

- 4) Key in the appropriate value (in seconds and hundredths of a second) for the reject-duration time.

Calibrate X and R Noise Thresholds

See the instructions on page 5.

Full-Product Calibration

See the instructions on page 5.

IntelliTrack XR™ (IXR)

The IXR function allows you to detect stainless steel in wet products, and metallic contaminants in wet and dry products having phase angles that vary from pack to pack. IXR is used, typically, in conveyor applications and is not available for pipeline applications.

Please note that you *must* have an in-feed photo-eye (or other triggering device) installed for the IXR function to work. IXR is not available for gravity-feed or Rx applications.

Before using the IXR function, you *must* set the following parameters.

- Pack length
- "Detection no-pack" distance
- In-feed photo-eye distance
- Photo-eye registration

Pack Length

See the instructions on page 2.

No-Pack Distance

See the instructions on page 2.


In-Feed Photo-Eye Distance

See the instructions on page 3.

Photo Registration

For optimum performance, the photo registration should be set to detect the *middle* of your product.


- 1) Follow steps 1–5 of the “Photo Registration for Product Rejects” section on page 4.
- 2) Press the Go button to select “middle” for photo registration.




Enabling IXR

To enable the IXR function, do the following.

- 1) Make sure the Main Menu is displayed.
- 2) Highlight the system and tools menu.
- 3) Press the Go button.
- 4) Highlight the IXR menu.
- 5) Press the Go button.
- 6) Highlight the “Enable IXR” function.
- 7) Press the Go button. A checkmark appears (as well as other IXR options), indicating IXR is now enabled.



- 8) Press the Back button repeatedly to return to the Main Menu, which now looks like this.




Calibrating the IXR Function

During the calibration, you *must* run the conveyor at the same speed used in normal production runs.

There are two parts to the calibration process.

- Learn the *X* and *R* noise thresholds.
- Learn the detect levels (for both the *X* and *R* signals).

- 1) Make sure the Main Menu is displayed.
- 2) Highlight the frequency and gain menu.
- 3) Press the Go button and navigate to page 2 of the menu.
- 4) Highlight the “Calibrate Noise Thresholds” function.



- 5) Make sure the conveyor is running at normal production speed. Press the Go button, and a monitor screen appears (for about 20 seconds) while the APEX measures the *X* and *R* noise thresholds.

Auto-Calibrating the IXR Function

To optimize the auto-calibration procedure you should do the following.

- Run the conveyor at your normal production speed.
- Have a gap between packages that is at least as wide as the width of the search head.
- Pass about 30–50 uncontaminated packages through the search head.

- 1) Make sure the Main Menu is displayed and that “Product Name” (or the product name you entered previously) is highlighted.
- 2) Press the Go button and page 1 of the “Full Product Calibration” menu appears.
- 3) Highlight the auto-calibration function and start passing packages through the search head. Press the Go button and wait until the Main Menu reappears.



4

3


2

1

AVAILABLE CABLE LENGTHS ²	
METERS	FEET
2	6.6
3	9.8
4	13.1
5	16.4
6	19.7
8	26.2
10	32.8
12	39.4
15	49.2
20	65.6
25	82.0
30	98.4



WITH OPTIONAL REMOTE CONTROL PANEL



NOTES:

- 1. STANDARD ISOLATOR FOOT LENGTH IS 25.4[1.00].
- 2. REMOTE CABLES LONGER THAN 30M [98.4 FT] AVAILABLE AS A SPECIAL ORDER (UP TO 90M [295 FT]).

TOLERANCE UNLESS SPECIFIED:
ALL DIMENSIONS ARE IN MILLIMETERS AND (INCHES)

X ±
 X.X ±
 X.XX ±
 ANGLES ± °

REMOVE ALL BURRS & UNNECESSARY SHARP EDGES

This document is confidential and is the property of Thermo Fisher Scientific ("Thermo"). It may not be copied or reproduced in any manner without the expressed written consent of Thermo. This document also is an unpublished work of Thermo. Thermo intends to and is maintaining the work as confidential information. Thermo also may seek to protect this work as an unpublished copyright. In the event of either inadvertent or deliberate publication, Thermo intends to enforce its rights to this work under the copyright laws as a published work. Those having access to this work may not copy, use or disclose the information in this work unless expressly authorized by Thermo.

ENGINEER: DMG
 DATE: 5/11/06

DRAWN BY: SD&P-KW
 DATE: 5/11/06

CHECKED BY: DMG
 DATE: 5/11/06

PART NUMBER:
 810109/810107

PROJECTION
 SCALE 1:4

ThermoFisher
 SCIENTIFIC

APEX 500/100 OUTLINE & MOUNTING
 (APEX 500 GRAPHICS SHOWN)

SIZE B	DRAWING NUMBER 07387M-B001	REV C	SHEET 1 of 3
--------	----------------------------	-------	--------------

D

C

B

A

D

C

B

A

4





3

2

1

Derived From:

© 2006, by Thermo Fisher Scientific



HEAD WIDTH (C) TABLE		
SMALLEST APERTURE DIMENSION (A OR B) mm [INCH]	C (HEAD WIDTH) mm [INCH]	
	APEX 500	APEX 100
50 [1.97]	295 [11.61]	295 [11.61]
75 [2.95]	295 [11.61]	295 [11.61]
100 [3.94]	295 [11.61]	295 [11.61]
125 [4.92]	295 [11.61]	295 [11.61]
150 [5.91]	330 [12.99]	295 [11.61]
175 [6.89]	330 [12.99]	295 [11.61]
200 [7.87]	380 [14.96]	295 [11.61]
250 [9.84]	380 [14.96]	330 [12.99]
300 [11.81]	380 [14.96]	330 [12.99]
350 [13.78]	480 [18.90]	380 [14.96]
400 [15.75]	480 [18.90]	380 [14.96]
450 [17.72]	480 [18.90]	380 [14.96]
500 [19.69]	680 [26.77]	480 [18.90]
550 [21.65]	680 [26.77]	480 [18.90]
600 [23.62]	680 [26.77]	480 [18.90]

TOLERANCE UNLESS SPECIFIED:
ALL DIMENSIONS ARE IN MILLIMETERS AND [INCHES]

X ±
X.X ±
X.XX ±
ANGLES ± °

REMOVE ALL BURRS & UNNECESSARY SHARP EDGES

This document is confidential and is the property of Thermo Fisher Scientific ("Thermo"). It may not be copied or reproduced in any manner without the expressed written consent of Thermo. This document also is an unpublished work of Thermo. Thermo intends to and is maintaining the work as confidential information. Thermo also may seek to protect this work as an unpublished copyright. In the event of either inadvertent or deliberate publication, Thermo intends to enforce its rights to this work under the copyright laws as a published work. Those having access to this work may not copy, use or disclose the information in this work unless expressly authorized by Thermo.

ENGINEER: DMG DATE: 5/11/06

DRAWN BY: SD&P-KW DATE: 5/11/06

CHECKED BY: DMG DATE: 5/11/06

PART NUMBER: 810109/810107

SCALE: 1:5

PROJECTION

Thermo Fisher SCIENTIFIC

APEX 500/100 OUTLINE & MOUNTING (APEX 500 GRAPHICS SHOWN)

SIZE B	DRAWING NUMBER 07387M-B001	REV C	SHEET 2 of 3
--------	----------------------------	-------	--------------

REV	ECO	SEE SHEET 1 FOR REVISION INFORMATION	DESCRIPTION	BY	APP	DATE
-----	-----	--------------------------------------	-------------	----	-----	------

4

3

2

1

D

D

C

C

B

B

A

A

191 [7.53]
3 [.12]
63 [2.49]

4X Ø28 [1.11]
4X Ø6.6 [.26] THRU
284 [11.18]
284 [11.18]
2X 184 [7.24]
2X 50 [1.97]
2X 304 [11.97]
2X 10 [.39]

63 [2.49]
Thermo SCIENTIFIC APEX 500 Metal Detector

TOLERANCE UNLESS SPECIFIED:
ALL DIMENSIONS ARE IN MILLIMETERS AND [INCHES]

X ±
X.X ±
X.XX ±
ANGLES ± °

REMOVE ALL BURRS & UNNECESSARY SHARP EDGES

This document is confidential and is the property of Thermo Fisher Scientific ("Thermo"). It may not be copied or reproduced in any manner without the expressed written consent of Thermo. This document also is an unpublished work of Thermo. Thermo intends to and is maintaining the work as confidential information. Thermo also may seek to protect this work as an unpublished copyright. In the event of either inadvertent or deliberate publication, Thermo intends to enforce its rights to this work under the copyright laws as a published work. Those having access to this work may not copy, use or disclose the information in this work unless expressly authorized by Thermo.

ENGINEER: DMG
DATE: 5/11/06

DRAWN BY: SD&P-KW
DATE: 5/11/06

CHECKED BY: DMG
DATE: 5/11/06

PART NUMBER:
810109/810107

PROJECTION

SCALE
1:3

ThermoFisher
SCIENTIFIC

APEX 500/100 OUTLINE & MOUNTING
(APEX 500 GRAPHICS SHOWN)

SIZE B	DRAWING NUMBER 07387M-B001	REV C	SHEET 3 of 3
------------------	-------------------------------	----------	-----------------

SEE SHEET 1 FOR REVISION INFORMATION

REV	ECO	DESCRIPTION	BY	APP	DATE
-----	-----	-------------	----	-----	------

4

3

2

1

Derived From:




© 2006, by Thermo Fisher Scientific

4

3

2

1



INTEGRAL VERSION

NOTES:

- 1. ELECTRICAL ACCESS HOLES ARE SIZED FOR M20 CONDUIT FITTINGS OR CORD GRIPS (5 CORD GRIPS SUPPLIED). 1/2 NPT FITTINGS WILL NOT FIT INTO HOLES AND THEREFORE REQUIRE THE USE OF THE SUPPLIED ADAPTER.
- 2. REMOTE VERSIONS: A NEW REMOTE CABLE IS OPTIONAL FOR DSP3 AND METAL ELIMINATOR MODELS (STANDARD UPGRADE UTILIZES EXISTING REMOTE CABLE). DSP2 MODELS REQUIRE THE PURCHASE OF A NEW REMOTE CABLE, AVAILABLE IN 12 STANDARD LENGTHS. CABLES LONGER THAN 30M [98.4 FT] ARE AVAILABLE AS A SPECIAL ORDER (UP TO 90M [295 FT]).

TOLERANCE UNLESS SPECIFIED:
ALL DIMENSIONS ARE IN MILLIMETERS AND [INCHES]

X ± .8 [.03]
X.X ± .3 [.01]
X.XX ± .13 [.005]
ANGLES ± .5°

REMOVE ALL BURRS & UNNECESSARY SHARP EDGES

This document is confidential and is the property of Thermo Fisher Scientific ("Thermo"). It may not be copied or reproduced in any manner without the expressed written consent of Thermo. This document also is an unpublished work of Thermo. Thermo intends to and is maintaining the work as confidential information. Thermo also may seek to protect this work as an unpublished copyright. In the event of either inadvertent or deliberate publication, Thermo intends to enforce its rights to this work under the copyright laws as a published work. Those having access to this work may not copy, use or disclose the information in this work unless expressly authorized by Thermo.

ENGINEER: DMG DATE: 2/15/07

DRAWN BY: DMG DATE: 2/15/07

CHECKED BY: DMG DATE: 2/15/07

PART NUMBER: 810106

PROJECTION SCALE 1:4

ThermoFisher SCIENTIFIC

ELECTRONICS UPGRADE, DSP2/3/METAL ELIMINATOR TO APEX

SIZE B	DRAWING NUMBER 07387M-B002	REV B	SHEET 1 of 2
--------	----------------------------	-------	--------------

REV	ECO	DESCRIPTION	BY	APP	DATE
B	1393	ADDED DSP2 NOTATION, CHANGED NOTES	DG	RLK	3/28/07
A	1338	RELEASED	DG	RLK	3/12/07

Derived From:

© 2007, by Thermo Fisher Scientific

4

3

2

1

AVAILABLE CABLE LENGTHS ²	
METERS	FEET
2	6.6
3	9.8
4	13.1
5	16.4
6	19.7
8	26.2
10	32.8
12	39.4
15	49.2
20	65.6
25	82.0
30	98.4

D

C

B

A

MINITEK CABLE ADAPTER, M16 (SUPPLIED WITH NEW CABLE)

1/2 NPT INPUT POWER CONDUIT ADAPTER ¹

REMOTE CABLE ²

3 [.12]

191 [7.53]

284 [11.18]

2X 184 [7.24]

4X Ø28 [1.11]

4X Ø6.6 [.26] THRU

284 [11.18]

2X 304 [11.97]

D

C

B

A

REMOTE VERSION

TOLERANCE UNLESS SPECIFIED:
ALL DIMENSIONS ARE IN MILLIMETERS AND [INCHES]

X ± .8 [.03]
X.X ± .3 [.01]
X.XX ± .13 [.005]
ANGLES ± .5°

REMOVE ALL BURRS & UNNECESSARY SHARP EDGES

This document is confidential and is the property of Thermo Fisher Scientific ("Thermo"). It may not be copied or reproduced in any manner without the expressed written consent of Thermo. This document also is an unpublished work of Thermo. Thermo intends to and is maintaining the work as confidential information. Thermo also may seek to protect this work as an unpublished copyright. In the event of either inadvertent or deliberate publication, Thermo intends to enforce its rights to this work under the copyright laws as a published work. Those having access to this work may not copy, use or disclose the information in this work unless expressly authorized by Thermo.

ENGINEER: DMG
DATE: 2/15/07

DRAWN BY: DMG
DATE: 2/15/07

CHECKED BY: DMG
DATE: 2/15/07

PART NUMBER: 810106

PROJECTION

SCALE
1:3

ThermoFisher SCIENTIFIC

ELECTRONICS UPGRADE,
DSP2/3/METAL ELIMINATOR TO APEX

SIZE	DRAWING NUMBER	REV	SHEET
B	07387M-B002	B	2 of 2

SEE SHEET 1 FOR REVISION INFORMATION

REV	ECO	DESCRIPTION	BY	APP	DATE

4

3

2

1

Derived From:

© 2007, by Thermo Fisher Scientific


4

3

2

1

AVAILABLE CABLE LENGTHS ¹	
METERS	FEET
.5	1.6
2	6.6
3	9.8
4	13.1
5	16.4
6	19.7
8	26.2
10	32.8
12	39.4
15	49.2
20	65.6
25	82.0
30	98.4



NOTES:

- ¹. CABLES LONGER THAN 30M [98.4 FT] AVAILABLE AS A SPECIAL ORDER (UP TO 90M [295 FT]).
- ². STANDARD ISOLATOR FOOT LENGTH IS 25.4[1.00].

TOLERANCE UNLESS SPECIFIED:
ALL DIMENSIONS ARE IN MILLIMETERS AND [INCHES]

X ±
X.X ±
X.XX ±
ANGLES ± °

REMOVE ALL BURRS & UNNECESSARY SHARP EDGES

This document is confidential and is the property of Thermo Fisher Scientific ("Thermo"). It may not be copied or reproduced in any manner without the expressed written consent of Thermo. This document also is an unpublished work of Thermo. Thermo intends to and is maintaining the work as confidential information. Thermo also may seek to protect this work as an unpublished copyright. In the event of either inadvertent or deliberate publication, Thermo intends to enforce its rights to this work under the copyright laws as a published work. Those having access to this work may not copy, use or disclose the information in this work unless expressly authorized by Thermo.

ENGINEER: DMG DATE: 5/31/07

DRAWN BY: DMG DATE: 5/31/07

CHECKED BY: DMG DATE: 5/31/07

PART NUMBER: 810108

PROJECTION SCALE 1:3

ThermoFisher
SCIENTIFIC

APEX 300 OUTLINE AND MOUNTING

A	1423	RELEASED		DG	RLK	12/21/07
REV	ECO	DESCRIPTION		BY	APP	DATE

SIZE B	DRAWING NUMBER 07387M-B300	REV A	SHEET 1 of 5
--------	----------------------------	-------	--------------

Derived From:

© 2007, by Thermo Fisher Scientific

4

3

2

1

D

D

C

C

B

B

A

A

4

3

2

1

RECTANGULAR APERTURE HEADS: C (HEAD WIDTH, mm)

B (APERTURE HEIGHT, mm)	A (APERTURE WIDTH, mm)									
	100	150	200	250	300	350	400	450	500	550
50	145	145	145	145	145	145	145	145	145	145
75	145	145	145	145	145	145	145	145	145	145
100		145	145	145	145	145	145	145	145	145
125		145	145	145	145	145	145	145	145	145
150			145 OR 250	145 OR 250	145 OR 250	145 OR 250	145 OR 250	145 OR 250	145 OR 250	145 OR 250
175			145 OR 250	145 OR 250	145 OR 250	145 OR 250	145 OR 250	145 OR 250	145 OR 250	145 OR 250
200				145 OR 250	145 OR 250	145 OR 250	145 OR 250	145 OR 250	145 OR 250	145 OR 250
225				145 OR 250	145 OR 250	145 OR 250	145 OR 250	145 OR 250	145 OR 250	145 OR 250
250					145 OR 250	145 OR 250	145 OR 250	145 OR 250	145 OR 250	145 OR 250

SQUARE APERTURE HEADS	
A & B (mm)	C (mm)
75	145 OR 250
100	145 OR 250
125	145 OR 250
150	145 OR 250
175	145 OR 250
200	145 OR 250
225	145 OR 250
250	145 OR 250

FOOT DIMENSION TABLE		
C mm [INCH]	D mm [INCH]	E mm [INCH]
145 [5.71]	100 [3.94]	22.5 [.89]
250 [9.84]	200 [7.87]	25 [.98]

HORIZONTAL APERTURE
HORIZONTAL PRODUCT FLOW

TOLERANCE UNLESS SPECIFIED:
ALL DIMENSIONS ARE IN MILLIMETERS AND (INCHES)

X ±
X.X ±
X.XX ±
ANGLES ± °

REMOVE ALL BURRS & UNNECESSARY SHARP EDGES

This document is confidential and is the property of Thermo Fisher Scientific ("Thermo"). It may not be copied or reproduced in any manner without the expressed written consent of Thermo. This document also is an unpublished work of Thermo. Thermo intends to and is maintaining the work as confidential information. Thermo also may seek to protect this work as an unpublished copyright. In the event of either inadvertent or deliberate publication, Thermo intends to enforce its rights to this work under the copyright laws as a published work. Those having access to this work may not copy, use or disclose the information in this work unless expressly authorized by Thermo.

ENGINEER:
DMG

DATE:
5/31/07

DRAWN BY:
DMG

DATE:
5/31/07

CHECKED BY:
DMG

DATE:
5/31/07

PART NUMBER:
810108

PROJECTION

SCALE
1:3

ThermoFisher
SCIENTIFIC

APEX 300 OUTLINE AND MOUNTING

SIZE	DRAWING NUMBER	REV	SHEET
B	07387M-B300	A	2 of 5

SEE SHEET 1 FOR REVISION INFORMATION

REV	ECO	DESCRIPTION	BY	APP	DATE

4

3

2

1

Derived From:

© 2007, by Thermo Fisher Scientific

4



3

2


1

RECTANGULAR APERTURE HEADS: C (HEAD WIDTH, mm)						
B (APERTURE HEIGHT, mm)	A (APERTURE WIDTH, mm)					
	75	100	125	150	175	200
100	145					
150	145	145	145			
200	145	145	145	145 OR 250	145 OR 250	
250	145	145	145	145 OR 250	145 OR 250	145 OR 250
300	145	145	145	145 OR 250	145 OR 250	145 OR 250
350	145	145	145	145 OR 250	145 OR 250	145 OR 250
400	145	145	145	145 OR 250	145 OR 250	145 OR 250

FOOT DIMENSION TABLE		
C mm[INCH]	D mm[INCH]	E mm[INCH]
145[5.71]	100[3.94]	22.5[.89]
250[9.84]	200[7.87]	25[.98]



AUDIT CHECK (OPTIONAL) PORT



VERTICAL APERTURE
HORIZONTAL PRODUCT FLOW

TOLERANCE UNLESS SPECIFIED:
ALL DIMENSIONS ARE IN MILLIMETERS AND [INCHES]

X ±
X.X ±
X.XX ±
ANGLES ± °

REMOVE ALL BURRS & UNNECESSARY SHARP EDGES


This document is confidential and is the property of Thermo Fisher Scientific ("Thermo"). It may not be copied or reproduced in any manner without the expressed written consent of Thermo. This document also is an unpublished work of Thermo. Thermo intends to and is maintaining the work as confidential information. Thermo also may seek to protect this work as an unpublished copyright. In the event of either inadvertent or deliberate publication, Thermo intends to enforce its rights to this work under the copyright laws as a published work. Those having access to this work may not copy, use or disclose the information in this work unless expressly authorized by Thermo.

ENGINEER: DMG
DATE: 5/31/07

DRAWN BY: DMG
DATE: 5/31/07

CHECKED BY: DMG
DATE: 5/31/07

PART NUMBER: 810108



SCALE: 1:3

ThermoFisher
SCIENTIFIC

APEX 300 OUTLINE AND MOUNTING

SIZE	DRAWING NUMBER	REV	SHEET
B	07387M-B300	A	3 of 5

SEE SHEET 1 FOR REVISION INFORMATION

REV	ECO	DESCRIPTION	BY	APP	DATE

Derived From:

© 2007, by Thermo Fisher Scientific

4

3

2

1

4

3


2

1


RECTANGULAR APERTURE HEADS: C (HEAD WIDTH, mm)										
B (APERTURE HEIGHT, mm)	A (APERTURE WIDTH, mm)									
	100	150	200	250	300	350	400	450	500	550
75	145	145	145	145	145	145	145	145	145	145
100		145	145	145	145	145	145	145	145	145
125		145	145	145	145	145	145	145	145	145
150			145 OR 250	145 OR 250	145 OR 250	145 OR 250	145 OR 250	145 OR 250	145 OR 250	145 OR 250

D

D




SQUARE APERTURE HEADS	
A & B (mm)	C (mm)
75	145 OR 250
100	145 OR 250
125	145 OR 250
150	145 OR 250
175	145 OR 250
200	145 OR 250
225	145 OR 250
250	145 OR 250



C

C



DROP-THROUGH PRODUCT FLOW

B

B

A

A

TOLERANCE UNLESS SPECIFIED:
 ALL DIMENSIONS ARE IN MILLIMETERS AND [INCHES]

X ±
 X.X ±
 X.XX ±
 ANGLES ± °

REMOVE ALL BURRS & UNNECESSARY SHARP EDGES

ENGINEER: DMG DATE: 5/31/07
 DRAWN BY: DMG DATE: 5/31/07
 CHECKED BY: DMG DATE: 5/31/07
 PART NUMBER: 810108



APEX 300 OUTLINE AND MOUNTING

SEE SHEET 1 FOR REVISION INFORMATION

REV	ECO	DESCRIPTION	BY	APP	DATE



SCALE 1:3

SIZE B	DRAWING NUMBER 07387M-B300	REV A	SHEET 4 of 5
--------	----------------------------	-------	--------------

4

3

2

1

Derived From:

© 2007, by Thermo Fisher Scientific

4

3

2

1

D

D

C

C

B

B

A

A

4X $\phi 6.6$ [.26] THRU

4X $\phi 28$ [1.11]

284 [11.18]

2X 184 [7.24]

2X 50 [1.97]

3 [.12]

191 [7.53]

284 [11.18]

10 [.39]

2X 304 [11.97]

REMOTE CONTROL PANEL

TOLERANCE UNLESS SPECIFIED:
ALL DIMENSIONS ARE IN MILLIMETERS AND [INCHES]

X \pm
X.X \pm
X.XX \pm
ANGLES \pm °

REMOVE ALL BURRS & UNNECESSARY
SHARP EDGES

This document is confidential and is the property of Thermo Fisher Scientific ("Thermo"). It may not be copied or reproduced in any manner without the expressed written consent of Thermo. This document also is an unpublished work of Thermo. Thermo intends to and is maintaining the work as confidential information. Thermo also may seek to protect this work as an unpublished copyright. In the event of either inadvertent or deliberate publication, Thermo intends to enforce its rights to this work under the copyright laws as a published work. Those having access to this work may not copy, use or disclose the information in this work unless expressly authorized by Thermo.

ENGINEER: DMG DATE: 5/31/07

DRAWN BY: DMG DATE: 5/31/07

CHECKED BY: DMG DATE: 5/31/07

PART NUMBER: 810108

PROJECTION

SCALE
1:3

ThermoFisher
SCIENTIFIC

APEX 300 OUTLINE AND MOUNTING

SEE SHEET 1 FOR REVISION INFORMATION

REV	ECO	DESCRIPTION	BY	APP	DATE

4

3

2

1

Derived From:

© 2007, by Thermo Fisher Scientific

SIZE	DRAWING NUMBER	REV	SHEET
B	07387M-B300	A	5 of 5

4

3

2

1

AVAILABLE CABLE LENGTHS ¹	
FEET	METERS
1.6	.5
6.6	2
9.8	3
13.1	4
16.4	5
19.7	6
26.2	8
32.8	10
39.4	12
49.2	15
65.6	20
82.0	25
98.4	30

NOTES:

- ¹ CABLES LONGER THAN 98.4 FT [30m] AVAILABLE AS A SPECIAL ORDER (UP TO 295 FT [90m]).
- PRODUCT TUBES AVAILABLE IN WHITE, BLACK ANTI-STATIC , OR WHITE WRAPPED WITH ANTI-STATIC FIBERGLASS WITH BLACK ANTI-STATIC FLANGES.
- FLAP GATE REJECT DIVERTER AVAILABLE WITH OPTIONAL RUBBER FLAP SEAL .

TOLERANCE UNLESS SPECIFIED:
ALL DIMENSIONS ARE IN INCHES AND [MILLIMETERS]

X.X ± .06 [1.5]
 X.XX ± .03 [.8]
 X.XXX ± .010 [.25]
 ANGLES ± .5°

REMOVE ALL BURRS & UNNECESSARY SHARP EDGES

This document is confidential and is the property of Thermo Fisher Scientific ("Thermo"). It may not be copied or reproduced in any manner without the expressed written consent of Thermo. This document also is an unpublished work of Thermo. Thermo intends to and is maintaining the work as confidential information. Thermo also may seek to protect this work as an unpublished copyright. In the event of either inadvertent or deliberate publication, Thermo intends to enforce its rights to this work under the copyright laws as a published work. Those having access to this work may not copy, use or disclose the information in this work unless expressly authorized by Thermo.

ENGINEER: DMG DATE: 2/14/08

DRAWN BY: DMG DATE: 2/14/08

CHECKED BY: DMG DATE: 2/14/08

PART NUMBER: TBD

SCALE 1:6

ThermoFisher

SCIENTIFIC

APEX 300D OUTLINE AND MOUNTING (DROP-THROUGH/GRAVITY SYSTEM) CEILING MOUNT

SIZE B	DRAWING NUMBER 07387M-B301-XX	REV C	SHEET 1 of 3
---------------	-------------------------------	-------	--------------

D

D

C

C

B

B

A

A

REV	ECO	DESCRIPTION	BY	APP	DATE
C	2133	ADDED SHEET3 & CHG'D TABLE	RLK	RLK	1-29-09
B	2020	CHG'D "G" .5 TO 2.5 FOR 6" & 8"	RLK	RLK	9-26-08
A	1787	SEE SHEET 1 FOR REVISION HISTORY	DG	RLK	6-12-08

Derived From:

© 2008, by Thermo Fisher Scientific

4

3

2



1

4



3

2

1



OUTLET FLANGE DETAIL



DETAIL A

TOLERANCE UNLESS SPECIFIED:
ALL DIMENSIONS ARE IN INCHES AND [MILLIMETERS]

X.X ± .06 [1.5]
X.XX ± .03 [.8]
X.XXX ± .010 [.25]
ANGLES ± .5°

REMOVE ALL BURRS & UNNECESSARY SHARP EDGES


This document is confidential and is the property of Thermo Fisher Scientific ("Thermo"). It may not be copied or reproduced in any manner without the expressed written consent of Thermo. This document also is an unpublished work of Thermo. Thermo intends to and is maintaining the work as confidential information. Thermo also may seek to protect this work as an unpublished copyright. In the event of either inadvertent or deliberate publication, Thermo intends to enforce its rights to this work under the copyright laws as a published work. Those having access to this work may not copy, use or disclose the information in this work unless expressly authorized by Thermo.

ENGINEER: DMG DATE: 2/14/08

DRAWN BY: DMG DATE: 2/14/08

CHECKED BY: DMG DATE: 2/14/08

PART NUMBER: TBD



SCALE 1:9

ThermoFisher
SCIENTIFIC

APEX 300D OUTLINE AND MOUNTING
(DROP-THROUGH/GRAVITY SYSTEM)
CEILING MOUNT

SIZE B	DRAWING NUMBER 07387M-B301-XX	REV C	SHEET 2 of 3
--------	-------------------------------	-------	--------------

SEE SHEET 1 FOR REVISION INFORMATION

REV	ECO	DESCRIPTION	BY	APP	DATE

Derived From:

© 2008, by Thermo Fisher Scientific

4

3

2

1

TAB CHART

I.D. PRODUCT TUBE		METAL DETECTOR APERTURE (mm)	FIELD COMPRESSION FLANGES		B.C. (BOLT CIRCLE ϕ)		F (FLANGE ϕ)		G		H (OVERALL HEIGHT)		M		N (# FLANGE HOLES)	P		R (REJECTER HEIGHT)		S		T (TUBE HEIGHT)		V		Z	
inch	mm		C=145mm	C=250mm	inch	mm	inch	mm	inch	mm	inch	mm	inch	mm		inch	mm	inch	mm	inch	mm	inch	mm	inch	mm	inch	mm
3.00	76.2	100 x 100	NO	NO	5.00	127.0	6.0	152	.5	13	36.20	919.5	16.5	419	4	20	508	9.20	233.7	3.26	82.8	27	685.8	7	178	23	584
4.00	101.6	125 x 125	NO	NO	6.50	165.1	7.5	191	1.5	38	39.21	995.9	17.5	445	4	20	508	11.21	284.7	4.26	108.2	28	711.2	8	203	22	559
4.75	120.6	150 x 150	YES	NO	7.75	196.9	9.0	229	2.5	64	42.24	1072.9	18.5	470	8	20	508	13.24	336.3	5.30	134.6	29	736.6	9	229	21	533
5.75	146.0	175 x 175, C = 145	YES	---	9.25	235.0	10.5	267	2.5	13	50.27	1276.9	19.5	495	8	26	660	15.27	387.9	6.36	161.5	35	889	9	229	21	533
5.75	146.0	175 x 175, C = 250	---	YES												11	279							19	483		
7.87	200.0	225 x 225, C = 145	YES	---	12.00	304.8	13.5	343	2.5	13	54.31	1379.5	21.5	546	8	26	660	19.31	490.5	8.36	212.3	35	889	9	229	21	533
7.87	200.0	225 x 225, C = 250	---	YES												11	279							19	483		

TOLERANCE UNLESS SPECIFIED:
ALL DIMENSIONS ARE IN INCHES AND [MILLIMETERS]

X.X \pm .06 [1.5]
X.XX \pm .03 [.8]
X.XXX \pm .010 [.25]
ANGLES \pm .5°

REMOVE ALL BURRS & UNNECESSARY SHARP EDGES

This document is confidential and is the property of Thermo Fisher Scientific ("Thermo"). It may not be copied or reproduced in any manner without the expressed written consent of Thermo. This document also is an unpublished work of Thermo. Thermo intends to and is maintaining the work as confidential information. Thermo also may seek to protect this work as an unpublished copyright. In the event of either inadvertent or deliberate publication, Thermo intends to enforce its rights to this work under the copyright laws as a published work. Those having access to this work may not copy, use or disclose the information in this work unless expressly authorized by Thermo.

ENGINEER: DMG DATE: 2/14/08

DRAWN BY: DMG DATE: 2/14/08

CHECKED BY: DMG DATE: 2/14/08

PART NUMBER: TBD



SCALE 1:9

ThermoFisher
SCIENTIFIC

APEX 300D OUTLINE AND MOUNTING
(DROP-THROUGH/GRAVITY SYSTEM)
CEILING MOUNT

SIZE B DRAWING NUMBER 07387M-B301-XX REV C SHEET 3 of 3

SEE SHEET 1 FOR REVISION INFORMATION

REV	ECO	DESCRIPTION	BY	APP	DATE

4

3

2

1

Derived From:

© 2008, by Thermo Fisher Scientific

4

3

2

1

D	PRODUCT TUBE		T (TUBE LENGTH)		METAL DETECTOR APERTURE SIZE	S (SPOOL PIECE WITH GASKET)		CENTER SUPPORT/CLAMP	V (VALVE WITH GASKET)		L (OVERALL SYSTEM TUBE LENGTH)		A		B		C		H			
	NOMINAL SIZE	TYPE	inch	mm		inch	mm		inch	mm	inch	mm	inch	mm	inch	mm	inch	mm	inch	mm	inch	mm
	inch		inch	mm		mm	inch		mm	inch	mm	inch	mm	inch	mm	inch	mm	inch	mm	inch	mm	inch
D	2	PIPE	24	610	75	-	-	NO	6.87	174.5	30.87	784.1	32.00	812.8	7.00	177.8	15.47	392.9	8.40	213.4		
						12.06	306.3	YES			42.93	1090.4	44.00	1117.6			27.53	699.3				
						24.06	611.1	YES			54.93	1395.2	56.00	1422.4			39.53	1004.1				
	HOSE	36	914	100	-	-	NO	6.87	174.5	42.87	1088.9	38.00	965.2	7.00	177.8	21.47	426.2	8.40	213.4			
					12.06	306.3	YES			54.93	1395.2	50.00	1270.0			33.53	732.5					
					24.06	611.1	YES			66.93	1700.0	62.00	1574.8			45.53	1037.3					
C	2.5 or 3	PIPE	24	610	100	-	-	NO	9.50	241.3	33.50	850.9	33.00	838.2	8.00	203.2	16.78	472.2	8.89	225.9		
						12.06	306.3	YES			45.56	1157.2	45.00	1143.0			28.84	778.5				
						24.06	611.1	YES			57.56	1462.0	57.00	1447.8			40.84	1083.3				
	2.5	HOSE	36	914	100	-	-	NO	9.50	241.3	45.50	1155.7	39.00	990.6	8.00	203.2	22.78	545.3	8.89	225.9		
						12.06	306.3	YES			57.56	1462.0	51.00	1295.4			34.84	851.7				
						24.06	611.1	YES			69.56	1766.8	63.00	1600.2			46.84	1156.5				
C	3	HOSE	36	914	125	-	-	NO	9.50	241.3	45.50	1155.7	39.00	990.6	9.00	228.6	22.78	578.6	9.39	238.4		
						12.06	306.3	YES			57.56	1462.0	51.00	1295.4			34.84	884.9				
						24.06	611.1	YES			69.56	1766.8	63.00	1600.2			46.84	1189.7				
	4	PIPE	24	610	125	-	-	NO	13.12	333.2	37.12	942.8	35.00	889.0	9.00	228.6	18.59	578.6	9.39	238.4		
						12.06	306.3	YES			49.18	1249.2	47.00	1193.8			30.65	884.9				
						24.06	611.1	YES			61.18	1554.0	59.00	1498.6			42.65	1189.7				
HOSE	36	914	150	-	-	NO	13.12	333.2	49.12	1247.6	41.00	1041.4	10.00	254.0	24.59	624.6	9.88	250.9				
				12.06	306.3	YES			61.18	1554.0	53.00	1346.2			36.65	930.9						
				24.06	611.1	YES			73.18	1858.8	65.00	1651.0			48.65	1235.7						

NOTES:

1. CABLES LONGER THAN 98.4 FT [30m] AVAILABLE AS A SPECIAL ORDER (UP TO 295 FT [90m]).
2. PIPES AVAILABLE IN NYLON OR FIBERGLASS WRAPPED PTFE.

TOLERANCE UNLESS SPECIFIED:
ALL DIMENSIONS ARE IN INCHES AND [MILLIMETERS]

X.X ± .06 [1.5]
 X.XX ± .03 [.8]
 X.XXX ± .010 [.25]
 ANGLES ± .5°

REMOVE ALL BURRS & UNNECESSARY SHARP EDGES

This document is confidential and is the property of Thermo Fisher Scientific ("Thermo"). It may not be copied or reproduced in any manner without the expressed written consent of Thermo. This document also is an unpublished work of Thermo. Thermo intends to and is maintaining the work as confidential information. Thermo also may seek to protect this work as an unpublished copyright. In the event of either inadvertent or deliberate publication, Thermo intends to enforce its rights to this work under the copyright laws as a published work. Those having access to this work may not copy, use or disclose the information in this work unless expressly authorized by Thermo.

ENGINEER: DMG DATE: 4/23/08

DRAWN BY: DMG DATE: 4/23/08

CHECKED BY: DMG DATE: 4/23/08

PART NUMBER: TBD

SCALE 1:8

ThermoFisher

SCIENTIFIC

APEX 300P OUTLINE AND MOUNTING (PIPELINE SYSTEM) CEILING MOUNT

A 1787 RELEASED

REV ECO DESCRIPTION

RLK RLK 5-14-08

BY APP DATE

Derived From:

© 2008, by Thermo Fisher Scientific

4

3

2


1

4

3

2

1



TOLERANCE UNLESS SPECIFIED:
ALL DIMENSIONS ARE IN INCHES AND [MILLIMETERS]

X.X ± .06 [1.5]
X.XX ± .03 [.8]
X.XXX ± .010 [.25]
ANGLES ± .5°

REMOVE ALL BURRS & UNNECESSARY SHARP EDGES

This document is confidential and is the property of Thermo Fisher Scientific ("Thermo"). It may not be copied or reproduced in any manner without the expressed written consent of Thermo. This document also is an unpublished work of Thermo. Thermo intends to and is maintaining the work as confidential information. Thermo also may seek to protect this work as an unpublished copyright. In the event of either inadvertent or deliberate publication, Thermo intends to enforce its rights to this work under the copyright laws as a published work. Those having access to this work may not copy, use or disclose the information in this work unless expressly authorized by Thermo.

ENGINEER: DMG DATE: 4/23/08

DRAWN BY: DMG DATE: 4/23/08

CHECKED BY: DMG DATE: 4/23/08


PART NUMBER: TBD

ThermoFisher
SCIENTIFIC

APEX 300P OUTLINE AND MOUNTING
(PIPELINE SYSTEM)
CEILING MOUNT

SEE SHEET 1 FOR REVISION INFORMATION

REV	ECO	DESCRIPTION	BY	APP	DATE



SCALE
1:8

SIZE B	DRAWING NUMBER 07387M-B302-XX	REV A	SHEET 2 of 2
------------------	----------------------------------	----------	-----------------

4

3


2

1


Derived From:

© 2008, by Thermo Fisher Scientific


ITEM	PART NO	QTY	DESCRIPTION	DWG NO/SPEC
------	---------	-----	-------------	-------------



← FLOW



SST CASTER (OPTIONAL)



CADD DATABASE: AUTOCAD

DO NOT SCALE DWG		SCALE	
REMOVE ALL BURRS AND UNNECESSARY SHARP EDGES		JOB NO	
TOLERANCE UNLESS SPECIFIED	ENG	RLK	DATE
.X ± .06	DWN	RLK	7-3-08
.XX ± .03	RLK	RLK	7-3-08
.XXX ± .01	CHK	RLK	DATE
FRACT ± 1/16			7-3-08
ANGLES ± 1/2°			

This document is confidential and is the property of Thermo Fisher Scientific. It may not be copied or reproduced in any way without the expressed written consent of Thermo Fisher Scientific. This document also is an unpublished work of Thermo Fisher Scientific. Thermo Fisher Scientific intends to and is maintaining the work as confidential information. Thermo Fisher Scientific also may seek to protect this work as an unpublished copyright. In the event of either incidental or deliberate publication, Thermo Fisher Scientific intends to enforce its right to the work under the copyright laws as a published work. Those having access to this work may not copy, use or disclose the information in this work unless expressly authorized by Thermo Fisher Scientific.

Thermo Fisher SCIENTIFIC

NEXT ASS'Y	
CUST ORDER NO	
CUSTOMER LOCATION	
USER LOCATION	

APEX 300P OUTLINE & MOUNTING PIPELINE SYSTEM FLOOR STAND SHEET 1 OF 2

A	1787	RELEASED	7-3-08	RLK	RLK
REV	ECO NO	MICRO	DATE	BY	APPD
		DESCRIPTION			

PART NO	DRAWING NUMBER	REV
	D07387M-B303-XX	A

PRODUCT TUBE		"T" (TUBE LENGTH)		METAL DETECTOR APERTURE SIZE mm	"S" (SPOOL PIECE WITH GASKET)		CENTER SUPPORT/ CLAMP	"V" (VALVE WITH GASKET)		"L" (OVERALL SYSTEM TUBE LENGTH)		"A"		"B"	
NOMINAL SIZE	TYPE	inch	mm		inch	mm		inch	mm	inch	mm	inch	mm	inch	mm
2	PIPE	24	610	75	---	---	NO	6.87	174.5	30.87	784.1	29.00	736.6	15.47	392.9
					12.06	306.3	YES			42.93	1090.4	41.00	1041.4	27.53	699.3
					24.06	611.1	YES			54.93	1395.2	53.00	1346.2	39.53	1004.1
	HOSE	36	914	100	---	---	NO			42.87	1088.9	35.00	889.0	21.47	426.2
					12.06	306.3	YES			54.93	1395.2	47.00	1193.8	33.53	732.5
					24.06	611.1	YES			66.93	1700.0	59.00	1498.6	45.53	1037.3
2.5 OR 3	PIPE	24	610	100	---	---	NO	9.50	241.3	33.50	850.9	30.00	762.0	16.78	472.2
					12.06	306.3	YES			45.56	1157.5	42.00	1066.8	28.84	778.5
					24.06	611.1	YES			57.56	1462.0	54.00	1371.6	40.84	1083.3
2.5	HOSE	36	914	100	---	---	NO			45.50	1155.7	36.00	914.4	22.78	545.3
					12.06	306.3	YES			57.56	1462.0	48.00	1219.2	34.84	851.7
					24.06	611.1	YES			69.56	1766.8	60.00	1524.0	46.84	1156.5
3	HOSE	36	914	125	---	---	NO	45.50	1155.7	36.00	914.4	22.78	578.6		
					12.06	306.3	YES	57.56	1462.0	48.00	1219.2	34.84	884.9		
					24.06	611.1	YES	69.56	1766.8	60.00	1524.0	46.84	1189.7		
4	PIPE	24	610	125	---	---	NO	13.12	333.2	37.12	942.8	32.00	812.8	18.59	578.6
					12.06	306.3	YES			49.18	1249.2	44.00	1117.6	30.65	884.9
					24.06	611.1	YES			61.18	1554.0	56.00	1422.4	42.65	1189.7
	HOSE	36	914	150	---	---	NO			49.12	1247.6	38.00	965.2	24.59	624.6
					12.06	306.3	YES			61.18	1554.0	50.00	1270.0	36.65	930.9
					24.06	611.1	YES			73.18	1858.8	62.00	1574.8	48.65	1235.7

CADD DATABASE: AUTOCAD

DO NOT SCALE DWG		SCALE	
REMOVE ALL BURRS AND UNNECESSARY SHARP EDGES		JOB NO	
TOLERANCE UNLESS SPECIFIED		ENG	DATE
± .06	---	RLK	7-3-08
± .03	---	DWN	DATE
± .01	---	RLK	7-3-08
FRACT ± 1/16	---	CHK	DATE
ANGLES ± 1/2°	---	RLK	7-3-08
NEXT ASS'Y			
CUST ORDER NO			
CUSTOMER LOCATION			
USER LOCATION			

This document is confidential and is the property of Thermo Fisher Scientific. It may not be copied or reproduced in any way without the expressed written consent of Thermo Fisher Scientific. This document also is an unpublished work of Thermo Fisher Scientific. Thermo Fisher Scientific intends to and is maintaining the work as confidential information. Thermo Fisher Scientific does not intend to publish this work as an unpublished copyright. In the event of other isolated or deliberate publications, Thermo Fisher Scientific intends to enforce its right to this work under the copyright laws as a published work. Those having access to this work may not copy, use or disclose the information in this work unless expressly authorized by Thermo Fisher Scientific.




Thermo Fisher SCIENTIFIC

APEX 300P OUTLINE & MOUNTING PIPELINE SYSTEM FLOOR STAND SHEET 2 OF 2

PART NO	DRAWING NUMBER	REV
D07387M-B303-XX		A

SEE SHEET 1	DATE	BY	APPD
REV	ECO NO	MICRO	DESCRIPTION

RECTANGULAR PORT ACCEPT STREAM
WITH REJECT BIN



APEX 500 Rx PHARMACEUTICAL METAL DETECTOR SYSTEM	
ELECTRICAL SUPPLY:	85 - 260 VOLT AC, SINGLE PHASE, 47 - 65Hz
TYPE OF REJECT:	AIR CYLINDER ACTIVATED CHUTE
CONSTRUCTION:	STAINLESS STEEL 304, PLASTIC CONTROL PANEL, PRODUCT CHUTE (ALL PLASTIC PARTS FDA APPROVED MATERIAL)
FINISH:	STRAIGHTLINE (STANDARD) HIGH POLISH (OPTIONAL)
STANDARD FEATURES:	FULLY ADJUSTABLE MOBILE STAND WITH LOCKABLE CASTERS REJECT VERIFICATION FAILSAFE TOUCH PANEL KEYPAD
OPTIONS:	AUDITCHECK ALARM/FAULT OUTPUT REJECT COLLECTION BIN VALIDATION IQ/OQ/PQ
AIR SUPPLY:	5.5 BAR (80PSI)
APPROVALS:	CE CERTIFIED cCSAus
QUALITY:	ISO 9001 CERTIFIED


APERTURE SIZES	CHUTE ID WIDTH & HEIGHT
100mm WIDE X 25mm HIGH	3.38 [85.9] X .61 [15.5]
100mm WIDE X 35mm HIGH	3.38 [85.9] X 1.00 [25.4]
100mm WIDE X 50mm HIGH	3.38 [85.9] X 1.59 [40.4]

*** DIMENSIONS ARE IN INCHES WITH [MILLIMETERS] ***



CADD DATABASE: AUTOCAD

DO NOT SCALE DWG REMOVE ALL BURRS AND UNNECESSARY SHARP EDGES	SCALE JOB NO	<small>This document is copyrighted and is the property of Thermo Fisher Scientific. It may not be copied or reproduced in any way without the expressed written consent of Thermo Fisher Scientific. This document also is an important part of Thermo Fisher Scientific. Thermo Fisher Scientific intends to and is reserving the right to make changes to this document without notice. Thermo Fisher Scientific does not intend to provide this work as an equivalent to the work of other independent or alternate publications. Thermo Fisher Scientific intends to reserve its right to this work under the copyright law as a published work. Those having access to this work may not copy, use or distribute the information in this work unless expressly authorized by Thermo Fisher Scientific.</small>						
TOLERANCE UNLESS SPECIFIED	ENG RLK DATE 2-25-10 DWN RLK DATE 2-25-10 CHK RLK DATE 2-25-10							
.X ± .06 .XX ± .03 .XXX ± .01 FRACT ± 1/16 ANGLES ± 1/2°		ThermoFisher SCIENTIFIC OUTLINE AND MOUNTING PNEUMATIC REJECT APEX 500 Rx SYSTEM SHEET 1 OF 3						
NEXT ASS'Y								
CUST ORDER NO								
CUSTOMER LOCATION								
USER LOCATION		<table border="1"> <tr> <th>PART NO</th> <th>DRAWING NUMBER</th> <th>REV</th> </tr> <tr> <td>D 07404M</td> <td>B005</td> <td>B</td> </tr> </table>	PART NO	DRAWING NUMBER	REV	D 07404M	B005	B
PART NO	DRAWING NUMBER	REV						
D 07404M	B005	B						

REV	ECO NO	MICRO	DESCRIPTION	DATE	BY	APPD
B	2585		UPDTAED PIVOT ARM & ELEC'S PLATE	6-5-10	RLK	RLK
A	2497		RELEASED	2-25-10	RLK	RLK



ROUND PORT ACCEPT AND REJECT STREAM



*** DIMENSIONS ARE IN INCHES WITH [MILLIMETERS] ***

CADD DATABASE: AUTOCAD

DO NOT SCALE DWG		SCALE		JOB NO	
REMOVE ALL BURRS AND UNNECESSARY SHARP EDGES		ENG	RLK	DATE	2-25-10
TOLERANCE UNLESS SPECIFIED		DWN	RLK	DATE	2-25-10
.X	± .06	CHK	RLK	DATE	2-25-10
.XX	± .03			DATE	2-25-10
.XXX	± .01			DATE	2-25-10
FRACT.	± 1/16			DATE	2-25-10
ANGLES	± 1/2°			DATE	2-25-10
NEXT ASS'Y					
CUST ORDER NO					
CUSTOMER LOCATION					
USER LOCATION					
PART NO		DRAWING NUMBER		REV	
D 07404M-B005		D 07404M-B005		B	



ThermoFisher SCIENTIFIC

OUTLINE AND MOUNTING
PNEUMATIC REJECT
APEX 500 Rx SYSTEM
SHEET 2 OF 3

REV	ECO NO	MICRO	DESCRIPTION	DATE	BY	APPD
			SEE SHEET 1			

ITEM	PART NO	QTY	DESCRIPTION	DWG NO/SPEC
------	---------	-----	-------------	-------------

ROUND PORT ACCEPT STREAM
WITH REJECT BIN



*** DIMENSIONS ARE IN INCHES WITH [MILLIMETERS] ***

CADD DATABASE: AUTOCAD


DO NOT SCALE DWG	SCALE	<small>This document is copyrighted and is the property of Thermo Fisher Scientific. It may not be copied or reproduced in any way without the expressed written consent of Thermo Fisher Scientific. This document also is an important part of Thermo Fisher Scientific. Thermo Fisher Scientific intends to and is reserving the right to make any changes or modifications to this document or software publication. Thermo Fisher Scientific retains all rights in this work under the copyright law as a published work. These being reserved to this work may not copy or distribute the information in this work unless expressly authorized by Thermo Fisher Scientific.</small>
REMOVE ALL BURRS AND UNNECESSARY SHARP EDGES	JOB NO	
TOLERANCE UNLESS SPECIFIED	ENG	DATE
.X ± .06	RLK	2-25-10
.XX ± .03	DWN	DATE
.XXX ± .01	RLK	2-25-10
FRACT. ± 1/16	CHK	DATE
ANGLES ± 1/2°	RLK	2-25-10
NEXT ASS'Y		
CUST ORDER NO		
CUSTOMER LOCATION		
USER LOCATION		

ThermoFisher SCIENTIFIC

OUTLINE AND MOUNTING
PNEUMATIC REJECT
APEX 500 Rx SYSTEM
SHEET 3 OF 3

PART NO	DRAWING NUMBER	REV
D 07404M-B005		B


REV	ECO NO	MICRO	DESCRIPTION	DATE	BY	APPD
			SEE SHEET 1			




SEARCH HEAD

APERTURE SIZES	
100mm WIDE X 25mm HIGH	
100mm WIDE X 35mm HIGH	
100mm WIDE X 50mm HIGH	


APERTURE	"A"
100 X 25	21.84 [.86]
100 X 35	31.75 [1.25]
100 X 50	46.73 [1.84]



PRODUCT CHUTE (OPTIONAL)



CONTROL & POWER SUPPLY



APEX 500 Rx PHARMACEUTICAL METAL DETECTOR	
ELECTRICAL SUPPLY:	85 - 260 VOLT AC, SINGLE PHASE, 47 - 65Hz
CONSTRUCTION:	STAINLESS STEEL 304, ABS PLASTIC CONTROL PANEL (FDA APPROVED)
FINISH:	STRAIGHTLINE (STANDARD) HIGH POLISH (OPTIONAL)
CABLE LENGTHS:	2/3/4/5/6/8/10/12/15/20/25/30 METER
OPTIONS:	AUDITCHECK ALARM/FAULT OUTPUT VALIDATION IQ/OQ/PQ PRODUCT CHUTE (BOTTOM FDA APVD POLYPROPYLENE, TOP POLYCARBONATE)
APPROVALS:	CE CERTIFIED cCSAus
QUALITY:	ISO 9001 CERTIFIED

*** DIMENSIONS ARE IN MILLIMETERS WITH [INCHES] ***

CADD DATABASE: AUTOCAD

DO NOT SCALE DWG	SCALE
REMOVE ALL BURRS AND UNNECESSARY SHARP EDGES	JOB NO
TOLERANCE UNLESS SPECIFIED	ENG DATE 7-22-09
.X ± .06	RLK
.XX ± .03	DWN DATE 7-22-09
.XXX ± .01	RLK
FRACT. ± 1/16	CHK DATE 7-22-09
ANGLES ± 1/2°	RLK



This document is confidential and is the property of Thermo Fisher Scientific. It may not be copied or reproduced in any way without the expressed written consent of Thermo Fisher Scientific. This document also is an important part of Thermo Fisher Scientific. Thermo Fisher Scientific intends to use in maintaining the work or confidential information. Thermo Fisher Scientific also may use to protect this work as an intellectual property in the work of other business or scientific publication. Thermo Fisher Scientific intends to enforce its right to this work under the copyright law as a published work. Those having access to this work may not copy, use or distribute the information in this work unless expressly authorized by Thermo Fisher Scientific.

ThermoFisher
SCIENTIFIC
APEX 500 Rx
HEAD & ELECTRONICS

REV	ECO NO	MICRO	DESCRIPTION	DATE	BY	APPD
B	2497		CHG'D "A" VALUES	2-23-10	RLK	RLK
A	2232		RELEASED	7-22-09	RLK	RLK



NEXT ASS'Y	
CUST ORDER NO	
CUSTOMER LOCATION	
USER LOCATION	
PART NO	D07404M-B002
DRAWING NUMBER	
REV	B

ITEM	PART NO	QTY	DESCRIPTION	DWG NO/SPEC
------	---------	-----	-------------	-------------



CONTROL & POWER SUPPLY

RECTANGULAR PORT ACCEPT STREAM WITH REJECT BIN



APEX 500 Rx PHARMACEUTICAL METAL DETECTOR	
ELECTRICAL SUPPLY:	85 - 260 VOLT AC, SINGLE PHASE, 47 - 65Hz
CONSTRUCTION:	STAINLESS STEEL 304, ABS PLASTIC CONTROL PANEL (FDA APPROVED)
FINISH:	STRAIGHTLINE (STANDARD) HIGH POLISH (OPTIONAL)
CABLE LENGTHS:	2/3/4/5/6/8/10/12/15/20/25/30 METER
OPTIONS:	AUDITCHECK ALARM/FAULT OUTPUT VALIDATION IQ/OQ/PQ PRODUCT CHUTE (FDA APVD POLYPROPYLENE)
APPROVALS:	CE CERTIFIED cCSAus
QUALITY:	ISO 9001 CERTIFIED



*** DIMENSIONS ARE IN INCHES WITH [MILLIMETERS] ***

CADD DATABASE: AUTOCAD



DO NOT SCALE DWG REMOVE ALL BURRS AND UNNECESSARY SHARP EDGES	SCALE JOB NO	<small>This document is confidential and is the property of Thermo Fisher Scientific. It may not be copied or reproduced in any way without the expressed written consent of Thermo Fisher Scientific. This document also is or constitutes work of Thermo Fisher Scientific. Thermo Fisher Scientific intends to and in maintaining the work as confidential information. Thermo Fisher Scientific also may seek to protect this work as or unpatented copyright. In the event of either inadvertent or deliberate publication, Thermo Fisher Scientific intends to enforce its right to this work under the copyright laws as a published work. Those having access to this work may not copy, use or disclose the information in this work unless expressly authorized by Thermo Fisher Scientific.</small>											
TOLERANCE UNLESS SPECIFIED	<table border="1"> <tr> <td>ENG</td> <td>DATE</td> </tr> <tr> <td>RLK</td> <td>2-25-10</td> </tr> <tr> <td>DWN</td> <td>DATE</td> </tr> <tr> <td>RLK</td> <td>2-25-10</td> </tr> <tr> <td>CHK</td> <td>DATE</td> </tr> <tr> <td>RLK</td> <td>2-25-10</td> </tr> </table>		ENG	DATE	RLK	2-25-10	DWN	DATE	RLK	2-25-10	CHK	DATE	RLK
ENG	DATE												
RLK	2-25-10												
DWN	DATE												
RLK	2-25-10												
CHK	DATE												
RLK	2-25-10												
.X ± .06		<p>OUTLINE & MOUNTING APEX 500 Rx HEAD & PNEUMATIC REJECT SHEET 1 OF 4</p>											
.XX ± .03													
.XXX ± .01													
FRACT. ± 1/16													
ANGLES ± 1/2°													
NEXT ASS'Y		<table border="1"> <tr> <td>PART NO</td> <td>DRAWING NUMBER</td> <td>REV</td> </tr> <tr> <td>D 07404M</td> <td>B006</td> <td>A</td> </tr> </table>	PART NO	DRAWING NUMBER	REV	D 07404M	B006	A					
PART NO	DRAWING NUMBER		REV										
D 07404M	B006	A											
CUST ORDER NO													
CUSTOMER LOCATION													
USER LOCATION													

REV	ECO NO	MICRO	DESCRIPTION	DATE	BY	APPD
A	2497		RELEASED	2-25-10	RLK	RLK

ITEM	PART NO	QTY	DESCRIPTION	DWG NO/SPEC
------	---------	-----	-------------	-------------



CONTROL & POWER SUPPLY



ROUND PORT ACCEPT AND REJECT STREAM

*** DIMENSIONS ARE IN INCHES WITH [MILLIMETERS] ***

CADD DATABASE: AUTOCAD

DO NOT SCALE DWG		SCALE		JOB NO	
REMOVE ALL BURRS AND UNNECESSARY SHARP EDGES		ENG	RLK	DATE	2-25-10
TOLERANCE UNLESS SPECIFIED		DWN	RLK	DATE	2-25-10
.X	± .06	CHK	RLK	DATE	2-25-10
.XX	± .03				
.XXX	± .01				
FRACT.	± 1/16				
ANGLES	± 1/2°				
NEXT ASS'Y					
CUST ORDER NO					
CUSTOMER LOCATION					
USER LOCATION					
PART NO		DRAWING NUMBER		REV	
D 07404M-B006		D 07404M-B006		A	

ThermoFisher SCIENTIFIC





OUTLINE & MOUNTING
APEX 500 Rx
HEAD & PNEUMATIC REJECT
SHEET 2 OF 4

REV	ECO NO	MICRO	DESCRIPTION	DATE	BY	APPD
A	2497		RELEASED	2-25-10	RLK	RLK

Derived From: D07404M-B003

© 2010 by Thermo Fisher Scientific

ITEM	PART NO	QTY	DESCRIPTION	DWG NO/SPEC
------	---------	-----	-------------	-------------



ROUND PORT ACCEPT STREAM WITH REJECT BIN

*** DIMENSIONS ARE IN INCHES WITH [MILLIMETERS] ***

CADD DATABASE: AUTOCAD

DO NOT SCALE DWG	SCALE	This document is confidential and is the property of Thermo Fisher Scientific. It may not be copied or reproduced in any way without the expressed written consent of Thermo Fisher Scientific. This document also is or constitutes work of Thermo Fisher Scientific. Thermo Fisher Scientific intends to and is maintaining the work as confidential information. Thermo Fisher Scientific also may seek to protect this work as or equivalent copyright. In the event of either inadvertent or deliberate publication, Thermo Fisher Scientific intends to enforce its right to this work under the copyright laws as a published work. Those having access to this work may not copy, use or disclose the information in this work unless expressly authorized by Thermo Fisher Scientific.
REMOVE ALL BURRS AND UNNECESSARY SHARP EDGES	JOB NO	
TOLERANCE UNLESS SPECIFIED	ENG	DATE
.X ± .06	RLK	2-25-10
.XX ± .03	DWN	DATE
.XXX ± .01	RLK	2-25-10
FRACT ± 1/16	CHK	DATE
ANGLES ± 1/2°	RLK	2-25-10
NEXT ASS'Y		
CUST ORDER NO		
CUSTOMER LOCATION		
USER LOCATION		


ThermoFisher SCIENTIFIC

OUTLINE & MOUNTING
APEX 500 Rx
HEAD & PNEUMATIC REJECT
SHEET 3 OF 4


PART NO	DRAWING NUMBER	REV
D07404M	B006	A

REV	ECO NO	MICRO	DESCRIPTION	DATE	BY	APPD
A	2497		RELEASED	2-25-10	RLK	RLK

ITEM	PART NO	QTY	DESCRIPTION	DWG NO/SPEC
------	---------	-----	-------------	-------------




SEARCH HEAD
PIVOT ARM



PRODUCT CHUTE
(OPTIONAL)

APERTURE SIZES	CHUTE ID WIDTH & HEIGHT
100mm WIDE X 25mm HIGH	3.38 [85.9] X .61 [15.5]
100mm WIDE X 35mm HIGH	3.38 [85.9] X 1.00 [25.4]
100mm WIDE X 50mm HIGH	3.38 [85.9] X 1.59 [40.4]



CADD DATABASE: AUTOCAD


DO NOT SCALE DWG REMOVE ALL BURRS AND UNNECESSARY SHARP EDGES		SCALE		JOB NO	
TOLERANCE UNLESS SPECIFIED		ENG	RLK	DATE	2-25-10
.X	± .06	DWN	RLK	DATE	2-25-10
.XX	± .03	CHK	RLK	DATE	2-25-10
.XXX	± .01				
FRACT.	± 1/16				
ANGLES	± 1/2°				
NEXT ASS'Y					
CUST ORDER NO					
CUSTOMER LOCATION					
USER LOCATION					
PART NO		DRAWING NUMBER		REV	
D 07404M-B006		A		A	

ThermoFisher
SCIENTIFIC

OUTLINE & MOUNTING
APEX 500 Rx
HEAD & PNEUMATIC REJECT
SHEET 4 OF 4

REV	ECO NO	MICRO	DESCRIPTION	DATE	BY	APPD
			SEE SHEET 1			

APEX 100/300/500 CONVEYOR PSU AND RELAY ASSEMBLY



85 TO 264 VAC
50/60 HZ 1-PHASE
100 VA

DISCONNECT AND WIRE
OVERCURRENT PROTECTION
BY CUSTOMER

WIRING SHOWN SUPPLIES LINE VOLTAGE
TO THE OUTPUT RELAYS

NOTE:

TERMINAL NC1 IS THE NORMALLY CLOSED RELAY CONTACT OF RELAY RL1.

TERMINALS NC2, NC3, NC4, NC5 AND NC6 ARE NEUTRAL COMMON CONNECTION WHEN WHITE JUMPER WIRE IS ADDED BETWEEN PSU J1-N AND RELAY J2 NC6.

NOTES:

- ALL WIRING MUST BE IN ACCORDANCE WITH THE NATIONAL ELECTRICAL CODE AND ALL LOCAL CODES.
- WIRE GAGE REQUIREMENTS: (MINIMUM WIRE SIZE)
 - A. POWER, AC 120/240V - 16AWG
 - B. INTERLOCKS - 22AWG (SUPPLIED W/INTERLOCK)
 - C. SPEED PICK-UPS - 22AWG
 - D. DIVERTER/REJECT - 18AWG

- RELAY PCBA J1 AND J2 CONTACT RATINGS:
10A 125VAC
- RELAY PCBA J1/J2 OUTPUTS ARE FUSED AT 2AMP, 250V COOPER/BUSSMANN PC-TRON FUSE OR EQUIVALENT.


REV	ECO NO	MICRO	DESCRIPTION	DATE	BY	APPD
C	2225		ADDED RELAY OUTPUT CONTACT RATINGS	07-02-06	GJB	GJB
B	1906		ADDED APEX 300 CONVEYOR	07-10-06	GJB	GJB
A	1054		RELEASED	06-27-06	GJB	GJB

CADD DATABASE: AUTOCAD

DO NOT SCALE DWG REMOVE ALL BURRS AND UNNECESSARY SHARP EDGES	SCALE JOB NO	ENG GJB DATE 06-22-06
TOLERANCE UNLESS SPECIFIED	DWN GJB DATE 06-22-06	CHK GJB DATE 06-22-06
.X XX .XXX FRACT ANGLES	± .06 ± .03 ± .01 ± 1/16 ± 1/32	
NEXT ASS'Y	CUSTOMER LOCATION	USER LOCATION
CUST ORDER NO		
ThermoFisher SCIENTIFIC		
FIELD WIRING DIAGRAM APEX 100/300/500 METAL DETECTOR CONVEYOR		
PART NO	DRAWING NUMBER	REV
	D07387M-0001	C

© 2006 Jy Thermo Fisher Scientific

APEX 300 GRAVITY FEED/PIPELINE PSU AND RELAY ASSEMBLY



WIRING SHOWN SUPPLIES LINE VOLTAGE TO THE OUTPUT RELAYS

NOTE:
 TERMINAL NC1 IS THE NORMALLY CLOSED RELAY CONTACT OF RELAY RL1.
 TERMINALS NC2, NC3, NC4, NC5 AND NC6 ARE NEUTRAL COMMON CONNECTION WHEN WHITE JUMPER WIRE IS ADDED BETWEEN PSU J1-N AND RELAY J2 NC6.

- NOTES:**
- ALL WIRING MUST BE IN ACCORDANCE WITH THE NATIONAL ELECTRICAL CODE AND ALL LOCAL CODES.
 - WIRE GAGE REQUIREMENTS: (MINIMUM WIRE SIZE)
 - A. POWER, AC 120/240V - 16AWG
 - B. SENSORS - 22AWG (SUPPLIED W/SENSOR)
 - C. DIVERter/REJECT - 18AWG

- RELAY PCBA J1 AND J2 CONTACT RATINGS: 10A 125VAC
- USE SOLID STATE FET Q2 OUTPUT (PSU J2 #1) WHEN HIGH SPEED +12VDC REJECT COIL IS REQUIRED.
- REJECT VERIFY #2 SENSOR IS OPTIONAL.

- USE MECHANICAL RELAY RL1 OUTPUT (RELAY J2 C1) WHEN LOW SPEED LINE VOLTAGE REJECT COIL IS REQUIRED.
- RELAY PCBA J1/J2 OUTPUTS ARE FUSED AT 2AMP, 250V COOPER/BUSSMANN PC-TRON FUSE OR EQUIVALENT.

REV	ECO NO	MICRO	DESCRIPTION	DATE	BY	APPD
B	2225		ADDED RELAY OUTPUT CONTACT RATINGS	07-02-08	GJB	GJB
A	1906		RELEASED	07-10-08	GJB	GJB


CADD DATABASE: AUTOCAD

DO NOT SCALE DWG REMOVE ALL BURRS AND UNNECESSARY SHARP EDGES	SCALE JOB NO	<p style="font-size: small;">This document is copyrighted and is the property of Thermo Fisher Scientific. It may not be copied or reproduced in any way without the expressed written consent of Thermo Fisher Scientific. This document also is an intellectual property of Thermo Fisher Scientific. Thermo Fisher Scientific retains the right to modify the contents of this document without notice. Thermo Fisher Scientific also may use the information contained herein for other purposes or in other publications. Thermo Fisher Scientific hereby grants to you a limited license to use this information in your work only for the purpose of the work you are performing and you may not copy or distribute this information in any way other than as expressly authorized by Thermo Fisher Scientific.</p> <h2 style="text-align: center;">ThermoFisher SCIENTIFIC</h2> <p style="text-align: center;">FIELD WIRING DIAGRAM APEX 300 METAL DETECTOR GRAVITY FEED AND PIPELINE</p>
TOLERANCE UNLESS SPECIFIED	ENG GJB DATE 07-10-08	
.X ± .06	DWG GJB DATE 07-10-08	
.XX ± .03	CHK GJB DATE 07-10-08	
.XXX ± .01		
FRACT ± 1/16		
ANGLES ± 1/2°		
NEXT ASS'Y		
CUSTOMER LOCATION		
USER LOCATION		

PART NO	DRAWING NUMBER	REV
	D07387M-0002	B

© 2007 Jy Thermo Fisher Scientific

APEX 500 RX PSU AND RELAY ASSEMBLY



FAILSAFE OPERATION:

THE WIRING DIAGRAM SHOWN WILL ALLOW THE APEX RX METAL DETECTOR TO OPERATE IN FAILSAFE MODE.


THE APEX RX REJECT GATE WILL ONLY BE SET TO THE ACCEPT STREAM IF THE APEX RX HAS POWER APPLIED, HAS AIR SUPPLIED TO THE REJECT AND THERE ARE NO ACTIVE FAULTS.

WITH POWER OR AIR REMOVED, OR AN ACTIVE FAULT IS PRESENT, THE APEX RX REJECT GATE WILL BE HELD IN THE REJECT STREAM BY THE SPRING ON THE PNEUMATIC VALVE ASSEMBLY.

SET OUTPUT 1 (REJECT) AND OUTPUT 5 (FAULT) TO INVERT MODE OF OPERATION.

CONNECT THE WIRING AND AIR LINES AS SHOWN.

ONLY THE CORRECT WIRING AND AIR CONNECTIONS WILL RESULT IN THE APEX RX OPERATING IN FAILSAFE MODE.



- NOTES:**
- ALL WIRING MUST BE IN ACCORDANCE WITH THE NATIONAL ELECTRICAL CODE AND ALL LOCAL CODES.
 - WIRE GAGE REQUIREMENTS: (MINIMUM WIRE SIZE)
 - A. POWER, AC 120/240V - 16AWG
 - B. SENSORS - 22AWG (SUPPLIED W/SENSOR)
 - C. DIVERTER/REJECT - 18AWG
 - RELAY PCBA J1 AND J2 CONTACT RATINGS:
10A 125VAC
 - RELAY PCBA J1/J2 OUTPUTS ARE FUSED AT 2AMP, 250V COOPER/BUSSMANN PC-TRON FUSE OR EQUIVALENT.
 - SET OUTPUT 1 (REJECT) AND OUTPUT 5 (FAULT) TO INVERT MODE OF OPERATION.

NOTE:

TERMINAL NC1 IS THE NORMALLY CLOSED RELAY CONTACT OF RELAY RL1.

TERMINALS NC2, NC3, NC4, NC5 AND NC6 ARE COMMON CONNECTION.

RS485 BIAS/TERMINATION SWITCH S1

S2-1 ON	= 485RX-	TERMINATION
S2-2 ON	= 485RX+	TERMINATION
S2-3 ON	= 485RX-	BIAS
S2-4 ON	= 485RX+	BIAS

SELECTABLE JUMPERS

JP1 = CPU RX INVERT
POSITION 1-2 NON INVERT
POSITION 2-3 INVERT
JP2 = RS232 OR RS485
POSITION 1-2 RS232
POSITION 2-3 RS485

6. BOND WIRE SHOWN FROM APEX CONTROL TO ISOLATED REJECT ASSEMBLY TOP COVER PLATE.

CADD DATABASE: AUTOCAD

DO NOT SCALE DWG	SCALE	<small>This document is copyrighted and is the property of Thermo Fisher Scientific. It may not be copied or reproduced in any way without the express written consent of Thermo Fisher Scientific. This document also is an unpatented work of Thermo Fisher Scientific. Thermo Fisher Scientific intends to use in manufacturing the work as described herein. Thermo Fisher Scientific also may use in patent this work as an unpatented copyright in the work of other inventors or otherwise published. Thermo Fisher Scientific intends to enforce its right to this work under the copyright law as a published work. These being records for this work may not copy or distribute the copyright in this work unless expressly authorized by Thermo Fisher Scientific.</small>
REMOVE ALL BURRS AND UNNECESSARY SHARP EDGES	JOB NO	
TOLERANCE UNLESS SPECIFIED	ENG GJB DATE 01-14-10	
.X ± .05	DWN GJB DATE 01-14-10	
.XX ± .03	CHK GJB DATE 01-14-10	
.XXX ± .01		
FRACT. ± 1/16		FIELD WIRING DIAGRAM APEX 500 RX PNEUMATIC REJECT DEVICE APEX METAL DETECTOR
ANGLES ± 1/2°		PART NO DRAWING NUMBER REV
NEXT ASS'Y		USER LOCATION DATE BY APPD
CUST ORDER NO		Derived From 2
CUSTOMER LOCATION		©2010 Jy Thermo Fisher Scientific

REV	ECO NO	MICRO	DESCRIPTION	DATE	BY	APPD
A	2497		RELEASED	02-17-10	GJB	GJB