

licensed physician.





Danger: Do not smoke when using oxygen or when near this device.

CONTENTS				
GLOSSARY OF SYMBOLS1	IV. USEFUL INFORMATION			
GENERAL SAFETY GUIDELINES2	IV.1. Accessories and spare parts4			
I. DESCRIPTION	IV.2. Materials in direct or indirect contact with patient4 IV.3. Operating principles4			
I.1.     Front panel (Fig. I. 1)	IV.3.   Operating principles     IV.4.   Alarms - Safety devices     IV.5.   Indicator light function			
II. STARTING-UP/INSTALLATION	IV.6. Technical characteristics5			
II.1. Use in direct oxygen therapy	IV.7.Standards			
III. CLEANING-MAINTENANCE4	IV.9. Method for disposing of device			
III.1. Cleaning4III.2. Everyday disinfection4III.3. Maintenance4	IV.10. Troubleshooting7 APPENDIX A EMC INFORMATION			
	OF SYMBOLS			
: ON (power switched on)	• Do not use oil or grease.			
O : Off (power switched off).	: Technical information.			
: Type B device	: Consult the accompanying documents.			

- : Keep in the vertical position.
- : Fragile handle with care.

Class II protection

Do not expose to open flames.

## **GENERAL SAFETY GUIDELINES**

### Only persons who have read and understood this entire manual should be allowed to operate the MARK 5 Nuvo LITE.

#### USE OF OXYGEN



Oxygen is not a flammable gas, but it accelerates the combustion of materials. To avoid all risks of fire, the *MARK 5 Nuvo LITE* should be kept away from all flames, incandescent sources and sources of heat (cigarettes), as well as any combustible products such as oil, grease, solvents, aerosols, etc.



Do not use in an explosive atmosphere.



Avoid letting oxygen accumulate on an upholstered seat or other fabrics. If the concentrator is operating while not supplying oxygen to a patient, position it so that the gas flow is diluted in the surrounding air.



Place the device in a ventilated area free from smoke and atmospheric pollution; (be sure the cabinet air filter is not obstructed).



The MARK 5 Nuvo LITE must only be used for oxygen therapy and only on medical prescription. **CAUTION** The indicated daily duration and flow must be followed, otherwise it may present a risk to the health of the patient.

CAUTION

Do not use in a specifically magnetic environment such as (MRI, X-ray, etc.)

#### **USE AND MAINTENANCE OF DEVICE**



Do not open the device while in operation: risk of electrical shock.

Use the power cord provided, and check that the electrical characteristics of the power socket used match those indicated on the manufacturer's plate on the rear panel of the machine.



We recommend against the use of extension cords or adapters, as they are potential sources of sparks and fire.



The *MARK 5 Nuvo LITE* has an audible alarm to warn the user of problems. In order that the alarm CAUTION may be heard, the maximum distance that the user can move away from it must be determined to suit the surrounding noise level.

#### **CONFORMITY WITH IEC60601-1 (§ 6.8.2 B):**

"The manufacturer, assembler, installer or distributor are not considered to be responsible themselves for the consequences on the safety, reliability and characteristics of a device unless:

• The assembly, fitting, extensions, adjustments, modifications or repairs have been performed by persons authorized by the party in question,

• The electrical installation of the corresponding premises complies with local electrical codes. (e.g. IEC / NEC).

• The device is used in accordance with the instructions for use."

If the replacement parts used for the periodic servicing by an approved technician do not comply with the manufacturer's specifications, the manufacturer is not responsible in the event of an accident.

This device complies with the requirements of the FDA Quality System Regulation but its operation may be affected by other devices being used near by, such as diathermy and high frequency electro-surgical equipment, defibrillators, short wave therapy equipment, mobile telephones, CB and other portable devices, microwave ovens, television, induction plates or even remote control toys or any other electromagnetic interferences which exceed the levels specified by the EN 60601-1-2 standard. (See Pgs 8 & 9)

#### **I. DESCRIPTION**

The MARK 5 Nuvo LITE is intended to supply supplemental oxygen to persons requiring low flow oxygen therapy. It is not intended to be life supporting or life sustaining. It produces an oxygen enriched product by concentrating the oxygen contained in room air by removing most of the nitrogen. It can be used either to administer oxygen with nasal cannulas or another probe or mask type of device.

#### The MARK 5 Nuvo LITE is easy to use.

The single flow adjustment knob allows:

•the device to be easily adjusted to the prescribed flow rate, •the equipment supplier or medical staff to limit flows to a specific flow rate with a built-in locking device.

It has a power failure alarm and an operating fault alarm.


Note: the performances described pertain to the use of the MARK 5 Nuvo LITE with the accessories recommended by Nidek Medical Products, Inc.

2



#### I. 1. Front panel (Fig. I. 1)

- 1 I/O (ON/OFF) Switch
- 2 Indicator Lights
- **3** Oxygen product outlet
- 4 Flow adjustment knob (l/min.)
- 5 Circuit Breaker



#### I. 2. Rear panel (Fig. I. 2 )

- 6 Humidifier
- 7 Filter
- 8 Power Cord
- 9 Elapsed Time Meter
- **10** Technical Label
- **11** Humidifier Tube
- 12 Humidifier Bottle Velcro Strap
- **13 -** Power Cord Retainer

#### **II. STARTING UP / INSTALLATION**

#### II. 1. Use in direct oxygen therapy

- a Ensure that the switch (1) is in the O/(OFF) position.
- b If used with a humidifier:



Unscrew the flask and fill it with water up to the line (see humidifier instructions). Then screw the lid on the humidifier flask until there are no leaks.

c - Connect the oxygen tube to the humidifier outlet nozzle or to the concentrator outlet if a humidifier has not been prescribed. The tube between the cannula and the *MARK 5 Nuvo LITE* should be limited to 60 feet (20 meters) long, in order to ensure that the oxygen flow rate remains within specification values.

d - Ensure that all of the parts are connected correctly so as to avoid leaks.

e -Plug the power cable into a power outlet of the correct



voltage and frequency as defined on the manufacturer's technical label (Fig I2-10).

f - Press the power switch (I/O) to the ON position (I). The red indicator will light and the audible alarm will sound for a few seconds until system pressure rises to the accepted level.

g - Turn the flow adjustment knob (4) to the prescribed value. This knob may have already been locked in the medically prescribed position. In this case, do not force it. Only the technician or medical personnel are authorized to release it.

h - Check that the oxygen flows out of the administration device (nasal cannulas or other) by placing the orifice(s) on the surface of a glass of water. The flow should disturb the surface of the water.

i - Adjust the nasal cannula to suit your face.

**Note**: the required oxygen concentration is normally obtained within five minutes after the unit is started.

At the end of the treatment, press the I/O switch to place it in the (O) [OFF] position to stop the device. The oxygen enriched air flow continues for approximately 1 minute after the device is stopped.

#### For the equipment supplier or medical staff:


The flow adjustment knob may be locked to limit it to a specific predetermined value.

#### **III. CLEANING - MAINTENANCE**

#### **III.1.** Cleaning

Only the outside of the *MARK 5 Nuvo LITE* is to be cleaned, with a soft, dry cloth or, if necessary, a damp sponge, then thoroughly dried with wipes and an alcohol based solution. Acetone, solvents or any other inflammable products **must not be used**. Do not use abrasive powders.

The removable Cabinet Air (dust) filter (2) must be cleaned weekly in warm water and household detergent or after approximately 100 hours of use. More frequent cleaning is recommended in dusty environments. Dry before reinstalling.



Filter (5 μm)/Silencer
Cabinet Air (dust) filter
Ventilation grill

#### **III.2.** Daily disinfection

Due to the presence of the final product filter  $<0.3 \ \mu m$  inside the device, everyday disinfection concerns only the external oxygen therapy accessories: humidifier, probes, nasal cannulas (refer to the respective instructions for use).

# The device must be switched off when alcohol based solutions are used.

# a. The following minimum guidelines should be observed:

#### • Humidifier: (If prescribed by a physician)

Clean according to the manufacturer's instructions. If no instructions are provided, do the following: *Daily:* 

- Empty the water from the humidifier.

- Rinse the humidifier flask under running water.

- Fill humidifier up to the mark with distilled water. *Regularly:* 

- Disinfect the humidifier parts by immersing them in a disinfectant solution (in general, we recommend using a solution of 1 part vinegar diluted with 10 parts water).

- Rinse and dry.

- Check that the humidifier lid seal is in good condition.

• Oxygen tubing and nasal cannula:

Follow the manufacturer's instructions.

#### b. For each new patient:

Follow the instructions from the humidifier manufacturer.

The *MARK 5 Nuvo LITE* cabinet should be cleaned and disinfected as per the above instructions. The cabinet air filter should be washed or replaced. The entire oxygen administration circuit (oxygen therapy nasal cannulas, etc.) must be changed.

#### **III.3.** Maintenance

**No special maintenance needs to be carried out by the patient.** Your equipment supplier performs periodic maintenance operations to assure continued reliable service from the *MARK 5 Nuvo LITE*.

#### **IV. USEFUL INFORMATION**

#### **IV.1.** Accessories and spare parts

The accessories used with the MARK 5 Nuvo LITE must:

- be oxygen compatible,
- be biocompatible,

• comply with the general requirements of the FDA Quality System Regulation.

The connectors, tubes and nasal cannulas must be designed and approved for oxygen therapy usage.

The accessories with a **Nidek Medical** part number reference, or included in the set of accessories supplied with the device, comply with these requirements.

Contact your equipment provider to obtain these accessories.

**Note:** The use of certain administration accessories which are not specified for use with this concentrator may reduce its performance and void the manufacturer's responsibility.

#### AVAILABLE ACCESSORIES IF PRESCRIBED BY A PHYSICIAN

Humidifier:	P/N 9012-8774
Cannula with 2 m (7 ft) tubing:	P/N 9012-8780
Extension Tubing 7.7 m (25ft):	P/N 9012-8781
Tubing Adapter:	P/N 9012-8783

The above items are available from Nidek Medical Products, Inc.

# IV.2. Materials in direct or indirect contact with the patient

Concentrator casing	ABS/Polycarbonate
Mains cable	PVC
Dust filter	Polyester
ON/OFF switch	Nylon
Casters	Nylon
Flow adjustment knob	ABS
Oxygen Product outlet	
Printed labels	Polycarbonate
Pipe/TubingAluminium, PVC,poly	yurethane or silicone
Humidifier	Polypropylene
Humidifier Tubing	PVC
Filter	

4

2010-8400 Rev F

#### **IV.3.** Operating Principle

The compressor sends filtered room air to a solenoid valve, which allows compressed air to pass to the column in production. The columns contain a molecular sieve material that functions to adsorb the nitrogen from the room air and thus allow oxygen to pass through.

The oxygen enriched product is then directed to a pressure reducing valve through the adjustable flow control to the oxygen product outlet fitting.

During this time, the other column being "regenerated" is connected to the ambient air and a flow of oxygen enriched product is passed through it (from the column "in production"). In this way, when one column is in production, the other is in a nitrogen desorption or "regeneration" phase. The oxygen enriched product finally passes through a final product filter located prior to the oxygen outlet fitting.

#### **IV.4. Alarms - Safety Devices**

#### IV.4.1 Alarm:

#### • No voltage detection:

In the event of a loss of mains power, an intermittent audible alarm is activated. Test alarm by activating the **I/O [On/Off]** switch with power cable unplugged from wall outlet.

#### • Power Quality:

A rapidly pulsing alarm is indicative of a power quality problem that normally will not affect the machines output, if the problem persists contact your power provider.

#### • Process fault:

In the case of a process fault, a visible and audible alarm is activated (continuous red light and audible alarm, see p. 7).

#### • No Oxygen Flow Alarm (If supplied with unit):

The Nuvo Lite Concentrator has a no flow alarm option. This device provides a continuous audible alarm in the event the oxygen flow to the patient becomes blocked.

#### IV.4. 2. Safety devices

#### • Compressor motor:

Thermal safety is ensured by a thermal switch situated in the motor winding  $(145 \pm 5 \text{ °C})$ .

#### • Electrical Protection:

A 5A circuit breaker is incorporated into the front cabinet of all 230V models. A 10 A circuit breaker is included with 115V models.

Class II device with insulated casings (EN60601-1 standard).

#### • Pressure:

A safety relief valve calibrated to 2.7 bar (40 psig) is fitted on the compressor outlet.

#### **IV.5. Indicator Light Function**

#### IV. 5.1 Green Indicator

The green (LED) indicator light indicates that power is applied to the concentrator and that it is ready to provide oxygen enriched air to the patient. To be lighted, it is necessary that the concentrator power plug be inserted into the wall outlet and that the ON/OFF (I/O) switch be actuated.

#### **IV. 5.2 Red Indicator**

The red (LED) indicator light is utilized to warn the patient of a system fault. The two events that can cause the red (LED) indicator to be lighted are abnormal system pressure and loss of mains power. The abnormal system pressure warning red (LED) will light and an audible alarm will sound when product pressure is outside of normal operating range. The audible alarm will sound intermittently on loss of mains power. The red (LED) will also illuminate on some models. Call the equipment supplier to service the device.

#### IV. 5.3. Maintenance of the system alarms:

• No special maintenance is required.

• The equipment supplier checks that the unit is still operating correctly when the routine checks are performed on the *MARK 5 Nuvo LITE*.

#### **IV. 6. Technical characteristics**

Dimensions: L x W x H:36x23x58.5cm (14 x 9 x 23 in.) Caster diameter: 5.0 cm (2.0 in.). Tilt angle (transport with humidifier fitted):  $30^{\circ}$ . Weight: 13 kg. 30 lbs (depends on model) Noise level: 45 to < 40 dBA (depends on model)

#### Flow values:

12 postion adjustable flow valve 0.125-5 liters/minute. (Some models may have other values)

#### Accuracy of flow supplied:

The flow supplied is equal to the flow set on the flow meter, accurate to within  $\pm 10$  % or 200 ml/min, whichever is the larger of the two.

#### **Oxygen Concentration:**

- at 2 l/min: >90%.
- at 5 l/min: 90%. (+6.5%/-3%)

(Values at 21°C and at one atmosphere pressure).

Max. recommended flow: 5 l/min.

The variation of the maximum recommended flow does not exceed  $\pm 10$  % of the indicated value when a back pressure of 7 kPa (1 psig) is applied to the output of the device. The maximum outlet pressure is 50 kPa (7 psig).

#### **Electrical power supply:**

	115 V Units	230 V Units
Frequency:	60Hz	50 & 60Hz
Average Power:	330 W (avg)	300 W (avg)
Protection Class:	Class II	Class II
Mains Protection:	10A	5A

#### Filters:

At the rear of the device: a cabinet air (dust) filter.

At the compressor input: an inlet air filter, 5  $\mu$ m, behind the cabinet filter.

Before the oxygen outlet: a final product filter  $<0.3 \mu m$ . (technician only).

#### Air circulation:

A tubeaxial fan cools the compressor compartment.

#### Environmental limit conditions:

The performances of the device (especially the oxygen concentration) are quoted at 21°C (70°F) and one atmosphere. They may change with temperature and altitude. For further information, please consult the maintenance manual.

• The device must be stored, transported and used in the vertical position only.

• Ambient temperature of between 5°C and 40 °C (40°F and 104 °F) (operation).

• Storage temperature range -20 °C to  $60^{\circ}$ C. (-4°F to140°F).

• Relative humidity of between 15 % and 95 % operation and less than 95% storage, both non-condensing.

• Altitude(21°C): Up to 2,286 m (7,500 ft) without degradation;

Consult your equipment provider for further information regarding 2,286 m to 4000 m (7,500 to 13000 ft).

• Complies with EN60601-1 standard; spilling of a glass of water.

#### IV. 7. Standards

EN 60601-1[UL60601-1:2003],CAN/CSA-C22.2 No.601.1-M90 w/A1&A2: Electrical Safety- Medical Devices.

EN60601-1-2:2001 Electromagnetic Compatibility

#### IV. 8. Method for disposing of waste

All waste from the *MARK 5 Nuvo LITE* (patient circuit, filter, etc.) must be disposed of using the methods appropriate to the civil authority of the location where disposed.

#### IV. 9. Method for disposing of the device

In order to preserve the environment, the concentrator must only be disposed of using the appropriate methods. All materials of construction are recyclable. MARK 5 Nuvo LITE Serial No. \_\_\_\_\_

Date first used: \_\_\_\_\_

Maintained by: \_\_\_\_\_

Your equipment supplier: \_\_\_\_\_

Address : \_\_\_\_\_

Telephone : \_\_\_\_\_

#### **PREVENTIVE MAINTENANCE:**

- a. Wash cabinet filter weekly.
- b. Inspect inlet air filter at each patient visit. Replace filter every 2 years, or more often depending on environment.
- c. Check oxygen concentration every 5,000 hours or 1 year.

The manufacturer's instructions for the **preventive maintenance** of the devices are defined in the maintenance manual. Check with your service provider for any updates to the recommended schedules.

The work must be carried out by suitably trained technicians certified by the manufacturer.

#### Use original spare parts only (see Pg. 7).

Upon request, the supplier can provide circuit diagrams, spare parts lists, technical details or any other information of use to qualified technical personnel for parts of the device which are designated as being the manufacturer's responsibility or by the manufacturer as repairable.

Medical Device Regulations require users and service providers to report to the manufacturer any incident that could, if repeated, result in injury to any person.

#### IV. 10. Troubleshooting.

Observations	Possible Causes	Solutions		
The I-O (ON/OFF) button is in the ON position but the device does not operate.	Power cable is not correctly plugged in.	Check the cable connection. Check the circuit breaker on the front of the unit under the flowme-		
The intermittent alarm sounds.	Power failure.	ter.		
Red light remains lighted.	Product pressure is too low or too high.	Contact your equipment supplier.		
A rapidly pulsing alarm.	Power Quality	If the problem persist contact your power provider.		
The alarm test does not work. See IV. 4.1	Capacitor is not charged Internal electrical fault.	Backup Capacitor has discharged; operate unit for approximately 10 minutes and retest. Contact your equipment supplier.		
The compressor operates and the I-O (ON/OFF) button is in the ON position but the green light is not lighted.	Faulty indicator.	Contact your equipment supplier.		
The I-O (ON/OFF) button is ON and the compressor is operating but there is no flow. The audible alarm sounds (continuously).	Pneumatic connection broken or other pressure problem.	Stop the device by pressing the I-O (ON/OFF) button and contact your equipment supplier.		
The I-O (ON/OFF) button is ON, the compressor is operating, there is a flow but the audible alarm sounds continuously.	Internal electrical fault. Pneumatic circuit fault.	Stop the device and contact your equipment supplier.		
	Compressor thermal safety device has been activated.	Stop the device and wait for it to cool down. Clean cabinet filter.Start up again. Reset the circuit breaker.		
The compressor stops in mid-cycle, then starts again after a few minutes.	Fan is not working.	Contact your equipment supplier.		
	Dirty Filters.	If the device does not start, contact your equipment supplier.		
The oxygen enriched product flow is interrupted at the nasal cannula outlet.	Tube disconnected or humidifier not tight.	Check that tubing connections are secure and that the tubing is not kinked.		
The flow at the nasal cannula outlet is irregular.	Cannula tubing is kinked.	Straighten the tubing ; contact your equipment supplier if damaged.		

### **Maintenance Items**

Cabinet Air Filter-Humidifier Tubing-Inlet Air Filter-Part Ref: 8400-1025; Part Ref: 8400-8409; Part Ref: 8400-1180; Wash weekly; Replace as needed.

Wash in warm water; Replace as needed.

et Air Filter- Part Ref: 8400-1180; Inspect at each patient visit, Replace every 2 years. Please record all maintenance activity on the Maintenance Log found in the Service Manual and online at www.nidekmedical.com under the 'Maintenance Log' tab.

### APPENDIX A: EMC Information

Important: Failure to follow these guidelines listed may result in increased emissions and/or decreased immunity of the Mark 5 Nuvo Lite concentrator.

- \* Medical Electrical Equipment needs special precautions regarding EMC and needs to be installed and put into service according to the EMC information provided in this manual.
- \* Portable and mobile RF communications equipment can affect Medical Electrical Equipment
- \* The use of Accessories, transducers, and cables other than those specified by the manufacturer, may result in increased Emissions or decreased Immunity of the *Mark 5 Nuvo Lite*.
- \* The Mark 5 Nuvo Lite should not be used adjacent to or stacked with other equipment and that if adjacent or stacked use is necessary, the Mark 5 Nuvo Lite should be observed to verify normal operation in the configuration in which it will be used.
- \* Use only Nidek replacement electrical parts.

Guidance and Manufacturer's Declaration – Electromagnetic Emissions: The MARK 5 Nuvo LITE is intended for use in the electromagnetic environment specified below. The user of the MARK 5 Nuvo LITE should assure that it is used in such an environment.

••••••			
Emission tests	Compliance	Electromagnetic environment - guidance	
RF emissions	Group 1	The MARK 5 Nuvo LITE uses RF energy only for its internal function.	
CISPR 11		Therefore, its RF emissions are very low and are not likely to cause	
		any interference in nearby electronic equipment	
RF emissions	Class B	The MARK 5 Nuvo LITE is suitable for use in all establishments,	
CISPR 11		including domestic establishments and those directly connected to the	
Harmonic emissions	Class A	public low - voltage power supply network, that supplies buildings used	
IEC 61000-3-2		or domestic purposes.	
Voltage fluctuations/Flicker emissions	Complies		
IEC 61000-3-3			

Guidance and manufacturer's declaration – electromagnetic immunity: The Mark 5 Nuvo Lite is intended for use in the electromagnetic environment specified below. The user of the Mark 5 Nuvo Lite should make sure that it is used in such an environment.

Immunity Test	IEC 60601 Test Levels	Compliance Level	Electromagnetic Environment - Guidance
Electrostatic Discharge (ESD)	±6kV contact	±6kV contact	Floors should be wood, concrete or ceramic
IEC 61000-4-2	±8kV air	±8kV air	tile. If floors are covered with synthetic
			material, the relative humidity should be at
			least 30%
Electrical Fast Transient/Burst	±2kV for power supply lines	±2kV for power supply lines	Mains power quality should be that of a
IEC 61000-4-4	±1kV for input/output lines	Not applicable. No I /O lines	typical commercial or hospital environment.
Surge	±2kV for power supply lines	±2kV for power supply lines	Mains power quality should be that of a
IEC 61000-4-5	±1kV for input/output lines	±1kV for input/output lines	typical commercial or hospital environment.
Voltage dips,short	<5% U <sub>T</sub>	<5% U <sub>T</sub>	Mains power quality should be that of a
interruptions and voltage	(>95% dip in $U_{\rm T})$ for 0.5 cycle	(>95% dip in $U_T$ ) for 0.5 cycle	typical commercial or hospital environment.
variations on power supply	40% U <sub>T</sub>	40% U <sub>T</sub>	If the user of the Mark 5 Nuvo Lite requires
input lines.	(60% dip in $U_T$ ) for 5	(60% dip in $U_T$ ) for 5	continued operation during power mains
IEC 61000-4-11	70% U <sub>T</sub>	70% U <sub>T</sub>	interruptions, It is recommended that the
	(30% dip in $U_{\rm T})$ for 25 cycles	(30% dip in $U_{\rm T}$ for 25 cycles	Mark 5 Nuvo Lite be powered from an
	<5% U <sub>T</sub>	<5% U <sub>T</sub>	uninterruptible power supply or a battery.
	(>95% dip in $U_T$ ) for 5 sec	(>95% dip in $U_T$ ) for 5 sec	
Power frequency (50/60 Hz)	3 A/m	3 A/m	Power frequency magnetic fields should be
magnetic field			at levels characteristic of a typical location in
IEC 61000-4-8			a typical commercial or hospital environment.
NOTE: $U_T$ is the a.c. mains volta	ge prior to application of the test	level	

Guidance and manufacturer's declaration – electromagnetic immunity: This MARK 5 Nuvo LITE is intended for use in the electromagnetic environment specified below. The user of this MARK 5 Nuvo LITE should make sure it is used in such an environment.

environment.			
Immunity Test	IEC 60601 Test Levels	Compliance Level	Electromagnetic Environment-Guidance
			Portable and mobile RF communications equipment should be
			used no closer to any part of the Mark 5 Nuvo Lite, including
			cables, than the recommended separation distance
			calculated from the equation applicable to the frequency of
			the transmitter.
			Recommended separation distance
Conducted RF	3 Vrms	3 Vrms	d =1.2 v <i>P</i>
IEC 61000-4-6	150 kHz to 80 MHz		
Radiated RF	3 V/m	3 V/m	d =1.2 v P 80 MHz to 800 MHz
IEC 61000-4-3	80 MHz to 2.5 GHz		d =2.3 vP 800 MHz to 2.5 GHz
			w here P is the maximum output pow er rating of the trans-
			mitter in watts (W) according to the transmitter manufacturer
			and d is the recommended separation distance in meters (m).
			Field strengths from fixed RF transmitters, as determined
			by an electromagnetic site survey a, should be less than the
			compliance level in each frequency range b.
			Interference may occur in the vicinity of equipment
			marked with the following symbol:
NOTE 1: At 80 MHz	and 800 MHz, the higher freque	ency range applies .:	
NOTE 2: These guide	elines may not apply in all situa	tions. Electromagnetic p	ropagation is affected by absorption and reflection from structures,
objects and people.			
a: Field strengths fro	om fixed transmitters, such as	base stations for radio (	cellular/cordless) telephones and land mobile radios, amateur radio, AM
and FM radio broado	ast and TV broadcast cannot	be predicted theoretical	y with accuracy. To assess the electro-magnetic environment due to
fixed RF transmitters	s, an electromagnetic site surve	ey should be considered	d. If the measured field strength in the location in which the MARK 5
Nuvo LITE is used	exceeds the applicable RF cor	mpliance level above, the	MARK 5 Nuvo LITE should be observed to verify normal operation.
If abnormal performa	ance is observed, additional me	easures may be necess	ary, such as re-orienting or relocationg the MARK 5 Nuvo LITE.
h: Over the frequence	ov range 150 kHz to 80 MHz fi	ald strangths should be	less than 3 1/m

b: Over the frequency range 150 kHz to 80 MHz, field strengths should be less than 3 V/m.

Recommended separation distances between portable and mobile RF communications equipment and the MARK 5 Nuvo LITE device: The MARK 5 Nuvo LITE is intended for use in an electromagnetic environment in which radiated RF disturbances are controlled. The customer or the user of the MARK 5 Nuvo LITE can help prevent electromagnetic interference by maintaining a minimum distance between portable and mobile RF communications equipment (transmitters) and the MARK 5 Nuvo LITE as recommended below, according to the maximum output power of the communications equipment.

Rated maximum outpu power of transmitter	ut Separatio	Separation distance according to frequency of transmitter (M)				
(W)	150 kHz to 80 MHz					
	d = 1.2 vP	d = 1.2 vP	d = 2.3 vP			
0.01	0.12	0.12	0.23			
0.1	0.38	0.38	0.73			
1	1.2	1.2	2.3			
10	3.8	3.8	7.3			
100	12	12	23			
For transmitters rated at a maximum output power not listed above, the recommended separation distance d in meters (m) can						
be estimated using the equation applicable to the frequency of the transmitter, where P is the maximum output power rating						
of the transmitter in watts (W) according to the transmitter manufacturer.						
Note 1: At 80 MHz and 800 MHz, the separation distance for the higher frequency range applies.						
Note 2: These guidelines may not apply in all situations. Electromagnetic propagation is affected by absorption and reflection						
from structures, objects and people.						

# NOTES

· · · · · · · · · · · · · · · · · · ·	· · · · · · · · · · · · · · · · · · ·
<u> </u>	
<u> </u>	

# NOTES