




BA 041D/06/en/01.99
No. 50093115
CV 5.0

Valid as of software version
V 4.00.XX (amplifier)

promag 31 F (Model '99) Electromagnetic Flow Measuring System

For custody transfer with cold water
(wastewater)


Operating Manual



Endress + Hauser
Nothing beats know-how




Operating summary / Operating matrix



- 1 Access the operating matrix
- 2 Select function group
- 3 Select function
- 4 Select and store parameter settings
- 5 Leave operating matrix ($\text{E} > 3 \text{ s}$) or Select next function

Display of numerical values



Actual value = $G \times M$

Example:

$9.700 \text{ E } 2$
 $= 9.700 \times 10^{+2} = 970.0 \text{ [m}^3/\text{h]}$
 $9.700 \text{ E } -2$
 $= 9.700 \times 10^{-2} = 0.097 \text{ [m}^3/\text{h]}$

Function group "Gr00 / SurFACE"		
Fu01 / PRGECODE	Function code	ALPHA = Text code nbr = Number code
Fu02 / u_RAtE	Flow rate unit	unit_1 = l/s; unit_2 = m³/h; unit_3 = USgpm
Fu03 / u_tOtAL	Totalizer unit	unit_4 = USgal x 1000; unit_5 = USgal; unit_6 = m³; unit_7 = l (Litre)
Function group "Gr10 / Curr_oUt"		
Fu11 / F_SCALE	Full scale current value	Numeric entry: x.xxx E ± x
Fu12 / t_ConSt	Time constant	Numeric entry: xx.x (in steps of 0.5 seconds)
Fu13 / I_rAnGE	Current range	0-20 (mA); 4-20 (mA)
Function group "Gr20 / Puls_oUt"		
Fu21 / P_FRctOr	Pulse value	Numeric entry: x.xxx E ± x
Function group "Gr30 / StAt_oUt"		
Fu31 / StAt_Fct	Status output function *	Error = System and process error indication Flow_dir = Flow direction indication
Function group "Gr40 / InPvt"		
Fu41 / InP_Fct	Auxiliary input function *	SupPRess = Positive zero return rES_tOt = Totalizer reset to "0"
Function group "Gr50 / dISPLAy"		
Fu51 / rES_tOt	Totalizer reset	cAnCEL rES_yES = Totalizer reset to "0"
Fu52 / dISP_oPt	Display mode	rAtE = Flow rate display; tOtAL = Totalizer display; ALtErnAt = Alternating display of flow rate and totalizer tEst = Display test function
Fu53 / dISP_dA	Display damping	Numeric entry: xx.x (in steps of 0.5 seconds)
Fu54 / tOt_oFL	Totalizer overflows	Display of totalizer overflows
Function group "Gr60 / PrOCESS"		
Fu61 / LFC	Creep suppression *	LFC_oFF = Suppression off LFC_on = Suppression on
Fu62 / EPD	Empty Pipe Detection (EPD)	EPD_oFF = off; EPD_on = on; EPD_Ad_E = Empty pipe adjust EPD_Ad_F = Full pipe adjust
Fu63 / ECC	Electrode cleaning (ECC) *, optional	ECC_oFF = off ECC_on = on
rEtUrN	$\text{E} \rightarrow$	Return to the Function group (or HOME Position)

* Configurations and selections in **custody transfer mode** → see page 33

Contents

1	Safety Instructions	5	8	Trouble-shooting, Maintenance and Repairs	51
1.1	Correct usage	5	8.1	Response of the measuring system on faults or alarm	51
1.2	Dangers and notes	5	8.2	Trouble-shooting and remedy	52
1.3	Personnel for installation, start-up and operation	6	8.3	Replacing the measuring electrodes	54
1.4	Repairs and dangerous substances	6	8.4	Replacing the transmitter electronics	56
1.5	Technical improvements	6	8.5	Replacing the fuse	57
2	Instrument Identification	7	8.6	Repairs	57
3	Mounting and Installation	9	8.7	Spare parts	57
3.1	Transport instructions (DN ≥ 350/14")	9	8.8	Maintenance	57
3.2	Mounting location	10	9	Dimensions	59
3.3	Mounting position	12	9.1	Dimensions Promag 31 F (DN 15...300)	59
3.4	Nominal diameter and flow rate	13	9.2	Dimensions Promag 31 F (DN 350...2000)	60
3.5	Adapters	14	10	Technical Data	61
3.6	Mounting Promag F sensor	15	Index	71	
3.7	Turning the transmitter housing and local display	17			
3.8	Mounting the transmitter (remote version)	18			
4	Electrical Connection	19			
4.1	Degree of protection	19			
4.2	Connecting the transmitter	20			
4.3	Connecting the cable of the remote version	24			
4.4	Cable specifications	26			
4.5	Potential equalisation	27			
4.6	Commissioning	29			
5	Display and Operation	31			
5.1	Display and operating elements	31			
5.2	Operation (operating matrix)	32			
5.3	Operating example	34			
6	Custody Transfer Measurement	35			
6.1	Suitability for custody transfer, custody transfer approval, reapproval	35			
6.2	Special features of custody transfer measurement	36			
6.3	Definitions	37			
7	Description of Functions	39			

Registered Trademarks

KALREZ[®], VITON[®] and TEFLON[®]

Registered trademark of E.I. Du Pont de Nemours & Co., Wilmington, USA

TRI-CLAMP[®], HASTELLOY[®]

Registered trademark of Ladish & Co., Inc., Kenosha, USA

1 Safety Instructions

1.1 Correct usage

- The measuring system Promag 31 is PTB certified for custody transfer with cold water (wastewater) and may only be used for measuring the flow of freshwater having a min. conductivity of $\geq 5 \mu\text{S}/\text{cm}$. The Promag 31 F is operated exclusively with a totalizer display suitable for custody transfer.
The measuring system operates within a temperature range of 0...30 °C and can be deployed for the following uses in the supply of drinking water:
 - Internal monitoring of delivery pipe network (local water network)
 - Calculation of the bill from the main supply pipe (junctions)
 - Monitoring of the water source. For example, the amount of ground water (tank inlet points, incl. pump stations).
 - Certification for the amount supplied to the delivery network (tank outlet points).
 - Monitoring of the withdrawal and supply of different water works in a supply pipe (Overland supply pipe of a water network).
- The manufacturer assumes no liability for damage caused by incorrect use of the instrument.
- Instruments which are used in the explosion hazardous area are supplied with a separate "Ex documentation", which is an integral part of this Operating Manual. The instructions and connected loads provided in this supplement must absolutely be observed. An appropriate icon is shown on the front of this document according to the approval given and the test center.



1.2 Dangers and notes

All instruments are designed to meet state-of-the-art safety requirements, have been tested, and have left the factory in an operational perfectly safe condition. The devices were developed according to EN 61010 "Protection Measures for Electronic Equipment for Measurement, Control, Regulation and Laboratory Procedures".

A hazardous situation may occur if the flowmeter is not used for the purpose it was designed for or is used incorrectly.

Please carefully note the information provided in this Operating Manual indicated by the following pictograms:

Warning!

A "warning" indicates actions or procedures which, if not performed correctly, may lead to personal injury or a safety hazard.

Please strictly observe the instructions supplied and proceed carefully.



Warning!

Caution!

A "caution" indicates actions or procedures which, if not performed correctly, may lead to faulty operations or the destruction of the instrument.

Please strictly observe the respective instructions.



Caution!

Note!

A "note" indicates actions or procedures which, if not performed correctly, may indirectly affect operations or lead to an unexpected instrument response.



Note!

1.3 Personnel for installation, start-up and operation

- A calibrated Promag 31 measuring system is protected by seals on the transmitter or the sensor connection housing from manipulation of calibration parameters such as pulse weighting (see page 35). As a rule, these seals may only be broken by a representative of the appropriate approval authorities.
- Mounting, electrical installation, start-up and maintenance of the instrument may only be carried out by trained personnel authorized by the operator of the facility. Personnel must absolutely and without fail read and understand this Operating Manual before carrying out its instructions.
- The instrument may only be operated by personnel who are authorized and trained by the operator of the facility. All instructions in this manual are to be observed without fail.
- With special fluids, incl. those used for cleaning, E+H will be pleased to supply information concerning the chemical resistance properties of wetted parts.
- When welding the piping, the welding machinery must not be grounded through the Promag.
- The installer has to make sure that the measuring system is correctly wired up according to the wiring diagrams. The measuring system is to be grounded.
- Please observe all provisions valid for your country and pertaining to the opening and repairing of electrical devices.



Danger of electrical shock!

With the housing cover removed, protection against accidental contact is no longer present. Components with high voltages are exposed below the local display. When programming according to section 5.1–5.3, avoid any contact with the electronic components which lie below the local display, and do not use any electrically conductive object to depress the operating keys.

1.4 Repairs and dangerous substances

The following procedures must be carried out before a Promag 31 is sent to Endress+Hauser for repair:

- A note must always be enclosed with the instrument, containing a description of the fault, the application, and the chemical and physical properties of the product being measured.
- Remove all residue which may be present. Pay special attention to the gasket grooves and crevices where fluid may be present. This is especially important if the fluid is dangerous to health, e.g. corrosive, carcinogenic, radioactive, etc.
- No instrument should be returned without all dangerous material being removed first (e.g. in scratches or diffused through plastic).

Incomplete cleaning of the instrument may result in waste disposal or cause harm to personnel (burns, etc). Any costs arising from this will be charged to the owner of the instrument.


1.5 Technical improvements

The manufacturer reserves the right to modify technical data without prior notice. Your local E+H Sales Office will supply you with all current information and any updates to this Operating Manual.


2 Instrument Identification

An overview of the complete Promag 31 measuring system is shown below. The technical specifications are stamped on the nameplate and contain the following information:


Promag 31 (Model '99) transmitter



Compact version




Remote version



Sensors
(see next page)

Promag F
DN 15...300

Promag F
DN 350...2000



Order code / Serial number
Definition code: see specifications on order confirmation

Identification number ("3") for Promag 31 (Model '99)

Power consumption
15 VA / W

Ingress protection (IP 67)

Power supply / frequency
85...260 V AC (50...60 Hz)

Additional information

- FS: remote version "FS"
- EPD/MSÜ: with Empty Pipe Detection
- 0.5: with 0.5% accuracy
- 3P-CAL: 3-point calibration
- I-OUT: with current output
- PULSE-OUT: with pulse output
- Additional information for special products

Specifications for custody transfer mode

- Nominal flow rate (Qn) = 15.0 m³/h
- Metrological Class A
- Year of manufacture 1998

Approval markings
for custody transfer instruments

Fig. 1
Promag 31 transmitter
Typical nameplate specifications
(example)




Fig. 2
Promag F sensor
Typical nameplate specifications
(example)

ba041y04

3 Mounting and Installation

Warning!

- The instructions given in this section are to be observed at all times in order to ensure safe and reliable operation of the measuring system.
- For explosion protected instruments the mounting regulations and the technical data may differ from those stated here. Please refer to the Ex supplement of this Operating Manual for additional information.



3.1 Transport instructions (DN ≥ 350/14")

The pipe lining on the flanges is protected by disks to prevent damage when transporting to the measuring point. These are to be removed when installing. Instruments are to be transported in the containers they are delivered in.

Transporting to the measuring point

- The sensor must not be lifted by the transmitter housing!
- Use only the grips on the flange for lifting out and mounting the sensor in the piping (from DN 350 or 14").

Caution!

The sensor must not be lifted by the metal casing using a fork lift truck! This can buckle the casing and so damage the internal magnetic coils.




Fig. 3
Transport instructions for large diameter sensors (DN ≥ 350)

Base and supports

The sensor is to be mounted on a base which is sufficiently strong enough to withstand its weight.

Caution!

Do not support the sensor by the sheet casing. The casing may be dented and so damage the magnetic coils inside the sensor.




Fig. 4
The proper way to support large diameter sensors (DN ≥ 350)

3.2 Mounting location




Fig. 5
Mounting location

Correct measurement is only possible when the pipe is full. The following locations should therefore be avoided:

- No installation at the highest point (air accumulation).
- No installation immediately before an open pipe outlet in a downward line.

The alternative installation, however, permits a correct measurement.




Fig. 6
Mounting with a partly filled pipe

Partly filled pipes

For inclines a mounting similar to a drain should be adopted. Added security is offered by Empty Pipe Detection in order to detect empty or partly filled pipes (see page 48).

Note!
Danger of solids accumulation!
Do not mount the sensor at the lowest point of the drain. A cleaning valve should also be installed.




Fig. 7
Installation downward pipe

Downward pipe

With the installation suggested opposite, partial vacuum is avoided even with a downward pipe > 5 m long (siphon, vent valve downstream of the sensor).

Installation of pumps

Do not mount the sensors on the suction side of pumps. This prevents low pressure and therefore possible damage to the lining of the measuring tube.

Information on the resistance to vacuum of the flowmeter lining can be found on page 70.

Pulse dampers should be installed when using reciprocal, diaphragm or peristaltic pumps.




Fig. 8
Installation of pumps

Vibration

The piping before and after the sensor should be securely fastened if there is excessive vibration.

Information on shock and vibration resistance is found on page 63.

Caution!

Excessive vibration necessitates separate mounting of the sensor and transmitter (see pages 18, 63).

Mechanical support of the sensor is recommended for free runs of piping over 10 m long.




Fig. 9
Remedies to avoid vibrations

3.3 Mounting position




Fig. 10
Mounting position
(horizontal, vertical)

Vertical mounting:

This is the recommended position with the flow upwards. Entrained solid particles sink and fatty components in the stationary fluid rise away from the measuring electrodes. This is the optimal position in empty pipe system and when using Empty Pipe Detection (see page 48).

Horizontal mounting:

The axis of the electrodes must be horizontal, thus preventing brief insulation of the electrodes by entrained air bubbles.

ba041y09

ba041y10




Fig. 11
Inlet and outlet sections

Inlet and outlet sections

The sensor should be mounted away from fittings such as valves, T-pieces, elbows, etc.

Inlet section: $\geq 5 \times DN$

Outlet section: $\geq 2 \times DN$

The inlet and outlet sections must be observed in order to maintain accuracy.

ba041y12


3.4 Nominal diameter and flow rate

The diameter of the pipe usually governs the nominal diameter of the sensor. The plant should be designed so that under "normal" operating conditions, the optimum flow rate lies between 2...3 m/s.

If it is necessary to increase the flow velocity, this can be done by reducing the nominal diameter of the sensor (see following chapter).

Nominal flow rate Q_n [m ³ /h]						
Diameter DN [mm]	Metrological class A		Metrological class B			
	Q _n (min)	Q _n (max)	Q _n (min)	Q _n (max)		
15	0.8	Q _{min} : Q _n = 1 : 25	3.0	1.6	Q _{min} : Q _n = 1 : 50	3.0
25	2.2		8.8	4.4		8.8
32	3.6		14.0	7.2		14.0
40	5.6		22.6	11.3		22.6
50	9.0		35.0	15.0 *		35.0
65	15.0	Q _{min} : Q _n = 1 : 12.5	60.0	20.0	Q _{min} : Q _n = 1 : 33	60.0
80	15.0 *		90.0	30.0		90.0
100	18.0		140.0	46.0		140.0
125	28.0		220.0	73.0		220.0
150	40.0		320.0	105.0		320.0
200	70.0		550.0	190.0		550.0
250	110.0		880.0	290.0		880.0
300	160.0		1250	420.0		1250
350	215.0		1700	570.0		1700
400	280.0		2200	750.0		2200
500	440.0	3500	1170	3500		
600	640.0	5000	1700	5000		
700...2000	Diameters DN 700...2000 are also approved. However, measuring points with these diameters are not normally subject to inspection requirements ($Q_{max} = 2 \times Q_n > 2000 \text{ m}^3/\text{h}$).					
<p>* Limit range $Q \geq 15 \text{ m}^3/\text{h}$</p> <p>Q_n (min): lowest nominal flow rate with reference to $Q_{(min)}$, $v = 0.05 \text{ m/s}$ Q_n (max): highest nominal flow rate with reference to $Q_{(max)}$, $v = 5 \text{ m/s}$</p> <p>Designations → see page 37</p>						

3.5 Adapters



Note!



Note!

Fig. 12
Pressure loss when using
adapters

The sensor can also be mounted in a pipe with a larger nominal diameter when suitable adapters (reducers and expanders) to DIN 28545 are fitted. The resultant increase in the rate of flow increases the accuracy of measurement with slowly moving fluids.

Note!

The inlet section (5 x DN) and the outlet section (2 x DN) must have the same nominal width as the flowmeter!

The adjacent nomogram can be used to determine the pressure loss caused.

Procedure:

1. Determine the ratio of the diameter d/D .
2. From the nomogram read off the pressure loss at the flow velocity and d/D ratio.

Note!

The nomogram applies to fluids with a viscosity similar to that of water.

ba041y17

3.6 Mounting Promag F sensor

The sensor is mounted between the flanges of the piping (Fig. 13). Since the lining of the measuring tube also covers the sensor flange, it also performs as a seal.

Caution!

The Teflon (PTFE) lined Promag F is fitted with protective discs to guard the lining which is turned over the flanges. These discs are to be removed just before mounting the sensor. Ensure that the lining on the flange is not damaged or removed. These discs must remain in position during storage.



Caution!




Fig. 13
Mounting Promag 31 F

Seals

- If the measuring tube liner is made of soft rubber or Teflon (PTFE), a flange seal is not required.
- With soft rubber lining the mating flange should have a thin film of non-conductive sealing grease applied.
- Use a seal according to DIN 2690.
- Mounted seals must not protrude into the piping section.

Caution!

Danger of short-circuit! Do not use sealing materials that are electrically conductive, e.g. graphite. This could result in an electrically conductive layer forming on the inside of the measuring tube and therefore short-circuiting the measuring signal.



Caution!

Screw tightening torques → see following page!

Length and dimensions → see pages 59, 60

Screw tightening torques (Promag F)

The tightening torques listed apply to greased threads.

Screws tightened up too tightly deform the sealing surface. Special attention should be paid to soft rubber linings.

Note!

The tightening torques given here apply only to those pipes which are not subject to mechanical stress.




Note!

Diameter		Pressure ratings				Screws	Max. tightening torques [Nm]			
[mm]	[inch]	DIN [bar]	ANSI [lbs]	AWWA	JIS		Hard rubber	Soft rubber (EPDM)	PTFE (Teflon)	
15	1/2"	PN 40	Class 150	-	20K	4 x M 12	-	-	15	
25	1"					20K	4 x M 12	25	5	33
32	-					20K	4 x M 12	40	8	53
40	1 1/2"					20K	4 x M 16	50	11	67
50	2"					10K	4 x M 16	64	15	84
65	-	PN 16	Class 150	-	10K	4 x M 16	87	22	114	
80	3"					10K	8 x M 16	53	14	70
100	4"					10K	8 x M 16	65	22	85
125	-					10K	8 x M 16	80	30	103
150	6"					10K	8 x M 20	110	48	140
200	8"	PN 10	Class 150	-	10K	8 x M 20	108	53	137	
250	10"					10K	12 x M 20	104	29	139
300	12"					10K	12 x M 20	119	39	159
350	14"	PN 10/16	Class 150	-		16 x M 20	141/193	39/79	188/258	
400	16"					16 x M 24	191/245	59/111	255/326	
500	20"					20 x M 24	197/347	70/152	262/463	
600	24"					20 x M 27	261/529	107/236	348/706	
700	28"	PN 10/16	-	Class D		24 x M 27	312/355	122/235	-	
800	30"					24 x M 30	417/471	173/330	-	
900	32"					28 x M 30	399/451	183/349	-	
1000	36"					28 x M 33	513/644	245/470	-	
1200	48"	PN 6	-	Class D		32 x M 36	720	328	-	
1400	-					36 x M 39	840	432	-	
1600	-					40 x M 45	1217	592	-	
1800	72"					44 x M 45	1238	667	-	
2000	-					48 x M 45	1347	749	-	

3.7 Turning the transmitter housing and local display


The transmitter housing and local display can be rotated in steps of 90°. This enables the unit to be adapted to different mounting positions in the piping and so simplifying reading and operation.



Turning the transmitter housing

1. Loosen the two fixing screws of the transmitter bayonet catch (approx. two turns)
2. Turn the bayonet catch of the transmitter as far as the screw slits (approx. 15 mm).
3. Carefully lift the transmitter housing to the stop.


Caution!
Do not damage the cable between the transmitter and sensor!



4. Turn the transmitter housing to the desired position.
5. Lower the housing and engage the bayonet catch.
6. Retighten the two screws.


ba041y22

Fig. 14
Turning the transmitter housing



Turning the local display

Warning!
Danger from electric shock! Switch off the power supply before opening the instrument.



1. Loosen the Allen screw of the safety grip (3 mm Allen key).
2. Unscrew the cover of the electronics area of the transmitter housing.
3. Unscrew the two Phillips screws of the front panel display.
4. Turn the display module to the required position.
5. Securely tighten the Phillips screws.
6. Replace and screw down securely the cover of the electronics area of the transmitter housing.
7. Securely tighten the Allen screw of the safety grip.

ba041y23

Fig. 15
Turning the local display

3.8 Mounting the transmitter (remote version)

The transmitter has to be mounted remote from the sensor when:

- access is difficult,
- space is restricted,
- extreme process and ambient temperatures prevail (for temperature ranges: see page 63 ff.) or if
- there is severe vibration ($> 2 \text{ g}/2 \text{ h}$ per day; 10...100 Hz).




Fig. 16
Wall and post mounting




Fig. 17
Fluid conductivity and cable
length with the remote version

Wall and post mounting

The remote mounted version is delivered with a wall bracket as standard.

A special mounting set can be supplied for post mounting: Order No. 50076905.

Connecting cable

Two different versions are available for remote versions:

FS version:

- The permissible length of cable L_{\max} of more than 10 m is governed by the conductivity of the fluid (see Fig. 17).
- The maximum possible cable length is limited to 10 meter for instruments with Empty Pipe Detection (EPD). This function is only available with the FS version.
- The FS cable is recommended only for distances smaller than 20 m.

FL version:

- All fluids with a minimum conductivity of $\geq 5 \mu\text{S}/\text{cm}$ (demineralised water $\geq 20 \mu\text{S}/\text{cm}$) can be measured. This is not dependent on the distance between transmitter and sensor (see Fig. 17).
- Empty Pipe Detection (EPD) is *not* available with this version.
- The maximum cable length is limited to 200 meters.

Please also note the following for obtaining correct readings:

- Fasten the cable gland or lay it in a conduit. When the fluid conductivity is low, cable movements can cause serious changes in capacitance and thereby falsify the measuring signal.
- Do not run the cable in the vicinity of electrical machines or switching elements.
- Ensure potential equalization between the transmitter and the sensor.

4 Electrical Connection

Warning!

When connecting Ex-approved instruments, please observe all instructions and wiring diagrams given in the Ex supplement to this Operating Manual. Your E+H representative will be pleased to provide you with more information.



4.1 Degree of protection

The instruments fulfil all the requirements for IP 67. After successful installation in the field or after servicing, the following points must always be observed in order to ensure the degree of protection IP 67:

- Housing gaskets must be clean and undamaged when inserted in the gasket groove. The gaskets may need to be dried, cleaned or replaced.
- All housing screws and the housing cover must be tightened firmly.
- The cables used for connecting must have the correct outer diameter (see page 26).
- The cable gland must be tightened firmly (see Fig. 18).
- The cable must loop down before entering the cable gland to ensure that no moisture can enter it (see Fig. 18).
Install the sensor so that the cable glands first hang down and do not first go upwards.
- Any cable gland not used must be replaced with a blind plug.
- The protective bushing should not be removed from the cable gland.




Fig. 18
Mounting cable entries

Caution!

The screws of the Promag sensor housing must not be loosened or the degree of protection guaranteed by E+H is no longer valid.



Note!

The Promag F sensor can optionally be supplied with the IP 68 degree of protection (permanently under water to a depth of 3 m). In this case the transmitter (IP 67) has to be mounted remote from the sensor.



4.2 Connecting the transmitter

Warning!

- Risk of electric shock! Switch off the power supply before opening the instrument. Do not install or wire the unit while connected to the power supply. Failure to comply may also result in damage of electronic components.
- Connect the protective conductor to the ground terminal on the housing before the power supply is switched on.
- Check that local power supply and frequency agree with the information on the nameplate. All relevant national regulations for mounting must also be observed.



Warning!




Fig. 19
Connecting the transmitter

1. Loosen the Allen screw of the safety grip using a 3 mm Allen key.
2. Unscrew the wiring compartment cover.
3. Feed the power and signal cables into the appropriate cable glands.
4. Wire up according to the wiring diagrams:
 - see Fig. 20
 - Wiring diagram in the screw cover
 - Power supply is connected to terminal 1 (L1, L+), terminal 2 (N, L-) and the ground terminal (3).
 - Fine-wire leads: max. 4 mm²; put sleeve on the end of the cores. Single-core lead: max. 6 mm².
5. Having made the connection, screw the cover tightly again on the transmitter housing.
6. Tighten the Allen screw of the safety grip securely.

Connection diagram (Promag 31 transmitter)





Fig. 20
Terminal compartment
Promag 31

Examples for electrical connections (inputs and outputs)



Caution!

Fig. 21
Examples of electrical connections (Promag 31)

ba041y51




Fig. 22
Examples of electrical connections (Promag 31)




Fig. 23
Different wiring versions for connecting a “reset” key: (alarms can be reset and the display test activated using this key).

Version 1:
This version should be chosen if there is a 24 V power supply near to the display. The alarm instrument has to be supplied by the customer. The key can be ordered from Endress+Hauser.

Version 2:
This version should be used if the 24 V power supply is **not** in the near of the display. The cable entry for the power supply (y-PG) can be ordered from Endress+Hauser.

4.3 Connecting the cable of the remote version



Warning!
Danger from electric shock! Switch off the power supply before opening the instrument.

1. Loosen the safety grip and remove the cover of the *transmitter housing*.
2. Loosen the safety grip and remove the cover of the *sensor connection housing*.
3. Feed both signal and coil-current cable into the appropriate cable entries of the connection housings.



Caution!
Danger of destroying the coil current control! Only connect or disconnect the coil cable once the power supply to the instrument has been switched off.

4. Connect the sensor / transmitter cable according to the wiring diagrams (see Fig. 25).
5. Securely retighten the connection housing covers and the Allen screws of the safety grips.




Fig. 24
Connecting the transmitter /
sensor cable

ba041y31

Wiring diagrams for the remote version (FS/FL)




Fig. 25
Wiring diagrams for the remote version "FS" and "FL"

4.4 Cable specifications

Remote version "FS"

Coil cable:	2 x 0.75 mm ² PVC cable with common screen *	
	Conductor resistance	≤ 37 Ω/km
	Capacitance: core/core, screen grounded	≤ 120 pF/m
Signal cable:	3 x 0.38 mm ² PVC cable with common screen * and separately screened cores	
	With EPD (Empty Pipe Detection)	4 x 0.38 mm ² PVC cable
	Conductor resistance	≤ 50 Ω/km
	Capacitance: core/screen	≤ 420 pF/m

Permanent operation temperature: -20...+70 °C

* braided copper screening: Ø ~ 7 mm

Remote version "FL"

Coil cable:	2 x 0.75 mm ² PVC cable with common screen *	
	Conductor resistance	≤ 37 Ω/km
	Capacitance: core/core, screen grounded	≤ 120 pF/m
Signal cable:	5 x 0.5 mm ² PVC cable with common screen *	
	Conductor resistance	≤ 37 Ω/km
	Capacitance: core/core, screen grounded	≤ 120 pF/m

Permanent operation temperature: -20...+70 °C

* braided copper screening (coil cable Ø ~ 7 mm; signal cable Ø ~ 9 mm)

Operation in areas with severe electrical interference

The Promag 31 measuring system fulfils all general safety requirements according to EN 61010 and electromagnetic compatibility (EMC) according to EN 50081 Part 1 and 2 / EN 50082 Part 1 and 2 when installed in accordance with the NAMUR recommendations.



Note!

Note!

To observe the statement of conformity for the remote version, the signal and coil cables should be screened and grounded at both ends.

4.5 Potential equalisation

The sensor and the fluid must have roughly the same electrical potential to ensure that measurement is accurate and no galvanic corrosion takes place at the electrode. Normally the reference electrode in the sensor or the metal pipe ensures that the potentials are equalized.

If the reference electrode is correctly grounded and the fluid flows through metallic, unlined and grounded piping, then it is sufficient to connect the grounding terminal of the Promag 31 transmitter housing to the potential equalisation line in order to prevent corrosion. The connection with the remote-mounted version is made at the ground terminal of the connection housing.




Fig. 26
 Position of different electrodes in the measuring tube

Caution!

Danger of permanent damage to the instrument! If the fluid cannot be grounded for operational reasons, ground disks are to be used.



Potential equalisation for some special cases is described below:

Potential equalisation for lined pipes with cathodic protection

When the fluid cannot be earthed for operational reasons, the measuring unit must be installed that it is potential-free (Fig. 27). Ensure that components of the piping are connected to one another (copper wire, 6 mm²).

All national regulations regarding potential free installation are to be observed (e.g. VDE 0100). Ensure that the mounting material used does not result in a conductive bond with the measuring unit and that the material can withstand the tightening torque used.




Fig. 27
 Potential equalisation for lined pipes with cathodic protection


Plastic or lined piping

Fig. 28
Potential equalisation with plastic
or lined pipings



Caution!

Caution!

Danger from damage due to electrochemical corrosion!

- Note the corrosion resistance of the ground disks!
- Note the electrochemical potential series in cases where the ground disks and the measuring electrodes are made of different material.


**Equalising currents in unearthed metal pipes /
Earthing in an area with severe interference**

Fig. 29
Potential equalisation with
– equalising currents,
– in areas with severe
interference

Ground disks must always be used with non-conductive piping materials if compensation currents flow through the fluid. They can irreparably damage the reference electrode within a short time due to electrochemical corrosion.

Such conditions occur especially if:

- the piping is insulated with electrically non-conductive materials and
- the piping is made of fibreglass or PVC through which flow highly concentrated acids and alkalis.

The fluid may be earthed. In order to make the most of the electromagnetic compatibility (EMC) of the Promag 31, it is advisable to provide two flange-to-flange links and to connect them jointly with the transmitter housing to earth potential.

4.6 Commissioning

Before switching on the measuring system, the following checks should be carried out again:

- Check the electrical connections and terminal assignments.
- Compare the data on the nameplate with the local mains voltage and frequency.
- Does the direction of the arrow on the nameplate (sensor) agree with the actual direction of flow in the piping?

If the results of these checks are satisfactory, switch on the supply voltage. The unit is now ready for operation.

After switching on, the system performs various self-test routines. During this procedure the following sequence of messages appears on the display:

P r o - 3 _ ' Promag 31 (Model '99)

The actual set display mode is then shown (3 possibilities):

- *r R t E* Flow rate (not permissible for certified instruments)
- *t o t R L* Totalizer
- *R L t E r o n R t* Alternating display of flow rate / totalizer
(display changes approx. every 10 seconds)

After successful start-up, normal measurement mode is assumed. Depending on the display mode set, it now shows flow rate and/or totalizer value as well as the actual units ("HOME position").




Fig. 30:
Examples of the display
(HOME position)

5 Display and Operation

5.1 Display and operating elements

With Promag 31 important variables can be directly read off at the measuring point.

Note!

Promag 31 transmitters can no longer be configured when given a leaded seal.



Note!


Warning!

Danger of electrical shock! With the housing cover removed, protection against accidental contact is no longer present. Components with high voltages are exposed below the local display. When programming avoid any contact with the electronic components which lie below the local display, and do not use any electrically conductive object to depress the operating keys!



Warning!

1. Loosen the Allen screw (3 mm) of the safety grip.
2. Unscrew the cover of the electronics compartment.
3. The keys may now be operated by pressing with a thin (non-conductive) pin. A switching cycle takes about 0.5...0.8 seconds.
4. Firmly screw back the cover of the electronics compartment to the transmitter housing once the settings have been entered. Firmly tighten the Allen screw of the safety grip.



ba041y32


Fig. 31
Display and operating elements

5.2 Operation (operating matrix)



Warning!
 Danger of electrical shock! With the housing cover removed, protection against accidental contact is no longer present.

1. Access the operating matrix
2. Select function group
3. Select functions
4. Select and store parameters (operating example: see page 34)
5. Leave operating matrix → HOME position (from any matrix position) or Select other functions



- Note!
- An automatic return to the HOME position will be made if the operating keys are not actuated for 60 seconds (although not from an opened function).
 - “rEtURN” + Enter → Return to the next higher operating level (function group, HOME)
 - “CAnCEL” + Enter → Return to the function level *without* storing the changed parameter

Fig. 32
 Select functions in the E+H operating matrix

ba041v33

Operating matrix / Summary of functions

<p>SURFACE Gr00</p> <p><i>Interactive surface</i> → page 39</p>	<p>PAGECODE / Fu01 <i>Function code</i></p> <p>ALPHA text code * nbr number code</p> <p>CANCEL</p>	<p>u_RATE / Fu02 <i>Flow rate units</i></p> <p>unit_1 [l/s]* unit_2 [m³/h] unit_3 [USgpm] CANCEL</p>	<p>u_TOTAL / Fu03 <i>Totalizer units</i></p> <p>unit_4 [USgal × 1000] unit_5 [USgal] unit_6 [m³] unit_7 [l]* CANCEL</p>	<p>rEturn</p>	
<p>Curr_out Gr10</p> <p><i>Current output</i> → page 40</p>	<p>F_SCALE / Fu11 <i>Full scale value (current output)</i></p> <p>Numeric entry: x.xxx E±x Factory setting: page 68</p>	<p>t_Const / Fu12 <i>Time constant</i></p> <p>Numeric entry: xx.x (in steps of 0.5 s) Factory setting = 1.0 s</p>	<p>I_Range / Fu13 <i>Current range</i></p> <p>0-20 (mA) 4-20 (mA)* CANCEL</p>	<p>rEturn</p>	
<p>PULS_out Gr20</p> <p><i>Pulse output</i> → page 42</p>	<p>P_FACTOR / Fu21 <i>Pulse value</i></p> <p>Numeric entry: x.xxx E±x Factory setting: page 68</p>	<p>rEturn</p>			
<p>Stat_out Gr30</p> <p><i>Status output</i> → page 44</p>	<p>Stat_Fct / Fu31 <i>Status output function</i></p> <p>Error System/process error indication * Flow_dir Flow direction indication CANCEL</p> <p>Custody transfer mode: The status output is permanently configured to Error.</p>		<p>rEturn</p>		
<p>Input Gr40</p> <p><i>Auxiliary input</i> → page 45</p>	<p>INP_Fct / Fu41 <i>Auxiliary input function</i></p> <p>SUPPRESS Positive zero return RES_tot Reset totalizer * CANCEL</p> <p>Custody transfer mode: The above parameters are not effective! In custody transfer mode the auxiliary input is used exclusive for resetting the error messages.</p>		<p>rEturn</p>		
<p>DISPLAY Gr50</p> <p><i>Display</i> → page 45</p>	<p>RES_tot / Fu51 <i>Totalizer reset</i></p> <p>CANCEL RES_YES reset</p>	<p>DISP_oPt / Fu52 <i>Display mode</i></p> <p>rATE Flow rate * totAL Totalizer</p> <p>RLtErnAt Flow rate & Totalizer</p> <p>tEst Display test function CANCEL</p>	<p>DISP_dR / Fu53 <i>Display damping</i></p> <p>Numeric entry: xx.x (in steps of 0.5 s) Factory setting = 1.0 s</p>	<p>tot_oFl / Fu54 <i>Number of totalizer overflows</i></p> <p>Display: xxxxxxxx (max. 8 characters)</p>	<p>rEturn</p>
<p>Process Gr60</p> <p><i>Process parameters</i> → page 46</p>	<p>LFC / Fu61 <i>Creep suppression</i></p> <p>LFC_oFF off LFC_on on*</p> <p>CANCEL</p> <p>Custody transfer mode: Low flow cut-off is always activated in custody transfer mode (LFC_on)!</p>	<p>EPD / Fu62 <i>Empty Pipe Detection</i></p> <p>EPd_oFF off * EPd_on on</p> <p>EPd_Ad_E Empty pipe adjustment</p> <p>EPd_Ad_F Full pipe adjustment CANCEL</p>	<p>ECC / Fu63 <i>Electrode cleaning (optional)</i></p> <p>ECC_oFF off ECC_on on*</p> <p>CANCEL</p> <p>Custody transfer mode: This function is not available in custody transfer mode!</p>	<p>rEturn</p>	
<p>rEturn</p>	<p>* Factory setting (can be different for instruments with customer specific parameterisation)</p>				


5.3 Operating example




Warning!

Danger of electrical shock! With the housing cover removed, protection against accidental contact is no longer present. Components with high voltages are exposed below the local display. When programming avoid any contact with the electronic components which lie below the local display, and do not use any electrically conductive object to depress the operating keys!

You would like to set the full scale value for the current output to 600.0 m³/h.
Proceed as follows:



HOME position
(display during normal operation)



Change flashing number with **+** and store with **E**. The next number to be changed will then flash automatically.

Remarks:

- Selecting units → see page 39
- Display of numerical values: → see page 2
- If the value entered is too high or too low, then the message "t o o _ H I" or "t o o _ L o" is displayed for approx. 2 seconds. The maximum or minimum possible full scale value (depending on nominal diameter) will then be shown → see page 41.

Fig. 33:
Operating example
(E+H operating matrix)

ba041y70

6 Custody Transfer Measurement

The Promag 31 flowmeter is suitable for custody transfer measurement with cold water (wastewater). The measuring system operates within a temperature range of 0...30 °C and can be used, for example, in drinking water supplies. Examples are given on page 5. The Promag 31 F is operated exclusively with a totalizer display suitable for custody transfer.

6.1 Suitability for custody transfer, custody transfer approval, reappraisal

With flowmeters *suitable* for custody transfer, approval by the standards authorities has not yet been carried out. Flowmeters suitable for custody transfer may not be used for custody transfer procedures until approved. However, such flowmeters can either be approved at a later date by a test centre or, with the agreement of the authorities, *calibrated for custody transfer* on site. The leaded seal of the certified instruments confirms this status.

The operator of an approved Promag 31 measuring system is required to apply for *reapproval* and to comply with current regulations set by the standards authorities.




Fig. 34
Sealing of a certified Promag 31
by standards authorities

Note!

- Flowmeters suitable for custody transfer are technically identical to flowmeters approved for “custody transfer”.
- In contrast to mechanical counters, magnetic flowmeters approved by the standards authorities may be in continuous operation at Q_{\max} (= 100%).
- Flowmeters with a flow rate of $Q > 2000 \text{ m}^3/\text{h}$ are exempted from custody transfer approval. Such instruments are not approved but however can still be used as suitable for custody transfer measurement.

Caution!

Only flowmeters approved by the standard authorities may be used for regulatory fiscal metering.



Note!



Caution!

6.2 Special features of custody transfer measurement

Approved Promag 31 flowmeters differ from non-approved flowmeters as follows:

- After official approval or leaded sealing, configuration can no longer be carried out using the local display.
- Approved flowmeters totalize bidirectional flow, while the pulse and current outputs only supply values when flow is in a positive (forwards) direction.
- The electrode cleaning circuitry (ECC) is not available during custody transfer measurements.
- The wiring of the status output and auxiliary input must be done by the user of the system.
- Diameters DN 700...2000 are also approved. However, measuring points with these diameters are not normally subject to inspection requirements ($Q_{\max} = 2 \times Q_n > 2000 \text{ m}^3/\text{h}$).

Function settings:

Certain function settings are to be stated when ordering a Promag 31 flowmeter:

- Nominal flow rate Q_n → see page 13 *
- Metrological class → see page 37 *
- Full scale value (current output) → see page 40 **
- Current range: 0/4...20 mA **
- Pulse value → see page 42 **
- Display mode ($E R R O R$ or $R L E E R n R E$) → see page 45
- Totalizer units: litres [l] or cubic meters [m^3/h]

* These parameters must be stated when ordering!

** Values otherwise specified, the instrument will be delivered with factory settings.

For custody transfer measurement, settings for the functions below are fixed:

- Status output → $E R R O R$ (totalizer measures bidirectional flow; current/pulse output measures unidirectional flow, forwards)
- Low flow cut-off → always activated ($L F C _ o n$)
- In contrast to “normal” operation, the auxiliary input is only configured for resetting alarm messages on the display (see below) or else for activating the display test function. Creep suppression or resetting the totalizer via the auxiliary input is not possible in custody transfer mode.

Error messages on the display

System and process errors are signalled via the status output during custody transfer measurement. On the display, both the corresponding segment bars for system error (Error) and/or process errors (Overflow, Empty Pipe) are shown. The following cases differ from one another:

System error

Display segment “Error” is visible.

The error can possibly be corrected by switching off and then switching on the power supply again. If the measuring system does not start-up (or again shows an error display), then please contact the Endress+Hauser Service organisation.

Process error

Display segments for “Error” and “overflow / Empty Pipe” are both visible.

If the error is corrected then the display segment for the process error goes out and the “Error” segment begins to flash. The instrument now assumes normal operation. The flashing “Error” segment still indicates a corrected error but can be reset via the auxiliary input.

Switching on the power supply

Every time the power supply is switched on or on first start-up, the “Error” display segment flashes to indicate a power failure. The instrument still measures normally despite this display, i.e. the status output issues no error.

The flashing “Error” segment can be reset via the auxiliary input.

6.3 Definitions

Cold water (wastewater)

Fluid temperature between 0...30 °C

Flow ranges

- Q_{max} Maximum flow without damaging the flowmeter and without exceeding the maximum permissible error.
- Q_n Nominal flow rate is half the value of the maximum flow rate Q_{max} and characterises the flowmeter (see page 13, "Nominal diameter and flow rate").
- Q_{min} Minimum flow rate above which the totalizer is within the error limits. It is dependent on the nominal flow rate (Q_n) and the metrological class.
- Q_t "Transitional flow rate", which separates the lower from the upper maximum permissible range. Lower or upper range differ from each other by the permitted error limits for custody transfer measurements (see Fig. 35):
 - Lower range ($Q_{min}...Q_t$) → Error limits $\pm 5\%$
 - Upper range ($Q_t...Q_{max}$) → Error limits $\pm 2\%$




Fig. 35
Flow ranges and error limits
in custody transfer mode for
cold water

Metrological Classes

Metrological classes A / B indicate the range in which the approved custody transfer flowmeter can measure, from full scale value (Q_{max}) down to Q_{min} . The error limits within this range are set by the standards authorities and must not be exceeded.






	Nominal flow rate (Q_n)	
	< 15 m ³ /h	> 15 m ³ /h
Class A	$Q_{min} = Q_n \times 0.04$ $Q_t = Q_n \times 0.10$	$Q_{min} = Q_n \times 0.08$ $Q_t = Q_n \times 0.30$
Class B	$Q_{min} = Q_n \times 0.02$ $Q_t = Q_n \times 0.08$	$Q_{min} = Q_n \times 0.03$ $Q_t = Q_n \times 0.20$

7 Description of Functions

This section describes in detail, along with specifications, the individual functions of the Promag 31. The function designation in the following table shows the two versions available – as well as the text and number codes used (see function “PAGECODE / Fu01”).

Function groups

Interactive surface	(SURFACE / Gr00)	→ page 39
Current output	(CURR_out / Gr10)	→ page 40
Pulse output	(PULS_out / Gr20)	→ page 42
Status output	(STAT_out / Gr30)	→ page 44
Auxiliary input	(INPuT / Gr40)	→ page 45
Display	(DISPLAy / Gr50)	→ page 45
Process parameter	(PROCESS / Gr60)	→ page 46

Function group INTERACTIVE SURFACE – SURFACE / Gr00	
<p>PAGECODE Fu 01</p> <p>Function code</p>	<p>All functions of the operating matrix can be shown on the display in two different ways – with a function number or a text code.</p> <p> ALPHA Type of display → text code e.g. F_SCALE for function “full scale value current output”</p> <p>nbr Type of display → number code e.g. Fu 11 for function “full scale value current output”</p> <p>CANCEL</p>
<p>u_RATE Fu 02</p> <p>Flow rate</p>	<p>Select the units required for flow rate (volume/time). The units selected here also define those for:</p> <ul style="list-style-type: none"> • creepage (see LFC / Fu 61 function) • full scale value (current output) <p> unit_1 Display segment “l/s” unit_2 Display segment “m³/h” unit_3 Display segment “USgpm” CANCEL</p>  <p style="text-align: right; font-size: small;">ba041y71</p>
<p>u_TOTAL Fu 03</p> <p>Volume unit</p>	<p>Select the units required for flow volume (totalizer). The units selected here also define those for:</p> <ul style="list-style-type: none"> • pulse value (volume/pulse) • totalizer (counter) <p> unit_4 Display segment “USgal × 1000” unit_5 Display segment “USgal” unit_6 Display segment “m³” unit_7 Display segment “l” CANCEL</p>  <p style="text-align: right; font-size: small;">ba041y72</p>

Function group
CURRENT OUTPUT - Curr_out / Gr 10

F_SCALE
Fu 11

Full scale value

Enter the desired full scale value for the volume flow (in the appropriate units selected). When exceeding the max. possible full scale value, the current output is limited to a maximum of 20.5 mA.

* Min. full scale at v = 0,3 m/s
* Max. full scale at v = 10 m/s

Note!

The minimum or maximum possible full scale value is given for every nominal diameter in the table on page 41. If the value entered is too high or too low then the display reacts as follows:

1. The value entered is *not* stored.
2. The message "too_HI" (value entered is too high) or "too_LO" (value entered is too low) is shown on the display.
3. The minimum or maximum possible values are then shown on the display which may be entered for the full scale (see table).

Display of numerical values:
Due to the limited size of the display, values are shown in a special way.

Basic value

→

Multiplication factor

E 5	=	10 ⁺⁵	=	100000
E 4	=	10 ⁺⁴	=	10000
E 3	=	10 ⁺³	=	1000
E 2	=	10 ⁺²	=	100
E 1	=	10 ⁺¹	=	10
E 0	=	10 ⁰	=	1
E-1	=	10 ⁻¹	=	0.1
E-2	=	10 ⁻²	=	0.01
E-3	=	10 ⁻³	=	0.001
E-4	=	10 ⁻⁴	=	0.0001
E-5	=	10 ⁻⁵	=	0.00001

Examples:

9.700 E 2 = 9.700 × 10⁺² = 970.0 [m³/h]
 9.700 E-2 = 9.700 × 10⁻² = 0.097 [m³/h]

ba041y61

Display limits / Full scale values (current output)				
DN	l/s		m ³ /h	
	Min.	Max.	Min.	Max.
2	9.424 E-4	3.141 E-2	3.392 E-3	1.130 E-1
4	3.769 E-3	1.256 E-1	1.357 E-2	4.523 E-1
8	1.507 E-2	5.026 E-1	5.428 E-2	1.809 E 0
15	5.301 E-2	1.767 E 0	1.908 E-1	6.361 E 0
25	1.472 E-1	4.908 E 0	5.301 E-1	1.767 E 1
32	2.412 E-1	8.042 E 0	8.685 E-1	2.895 E 1
40	3.769 E-1	1.256 E 1	1.357 E 0	4.523 E 1
50	5.890 E-1	1.963 E 1	2.120 E 0	7.068 E 1
65	9.954 E-1	3.318 E 1	3.583 E 0	1.194 E 2
80	1.507 E 0	5.026 E 1	5.428 E 0	1.809 E 2
100	2.356 E 0	7.853 E 1	8.482 E 0	2.827 E 2
125	3.681 E 0	1.227 E 2	1.325 E 1	4.417 E 2
150	5.301 E 0	1.767 E 2	1.908 E 1	6.361 E 2
200	9.424 E 0	3.141 E 2	3.392 E 1	1.130 E 3
250	1.473 E 1	4.908 E 2	5.301 E 1	1.767 E 3
300	2.120 E 1	7.068 E 2	7.634 E 1	2.544 E 3
350	2.886 E 1	9.621 E 2	1.039 E 2	3.463 E 3
400	3.769 E 1	1.256 E 3	1.357 E 2	4.523 E 3
500	5.890 E 1	1.963 E 3	2.120 E 2	7.068 E 3
600	8.482 E 1	2.827 E 3	3.053 E 2	1.017 E 4
700	1.154 E 2	3.848 E 3	4.156 E 2	1.385 E 4
800	1.507 E 2	5.026 E 3	5.428 E 2	1.809 E 4
900	1.908 E 2	6.361 E 3	6.870 E 2	2.290 E 4
1000	2.356 E 2	7.853 E 3	8.482 E 2	2.827 E 4
1200	3.392 E 2	1.130 E 4	1.221 E 3	4.071 E 4
1400	4.618 E 2	1.539 E 4	1.662 E 3	5.541 E 4
1600	6.031 E 2	2.010 E 4	2.171 E 3	7.238 E 4
1800	7.634 E 2	2.544 E 4	2.748 E 3	9.160 E 4
2000	9.424 E 2	3.141 E 4	3.392 E 3	1.130 E 5

The last figure of the above values can differ by ± 1 from the value shown in the display (error in rounding off)!

Minimum full scale → flow rate = 0.3 m/s
Maximum full scale → flow rate = 10 m/s

Factory settings → see page 68



Function group CURRENT OUTPUT - Curr_out / Gr10	
<p>t_Const Fu 12</p> <p>Time constant</p>	<p>Selecting the time constant determines whether the current output signal reacts very quickly to rapidly changing flows (small time constant) or slowly (large time constant).</p> <p>Note! The time constant does not affect the behaviour of the display!</p> <p> Numeric entry: 0.5...95 [s] in steps of 0.5 s</p>
<p>I_Range Fu 13</p> <p>Current range</p>	<p>Set the current range. The current for the scaled full scale value is always 20 mA (see page 40).</p> <p> 0-20 (mA) 4-20 (mA)</p>








Function group PULSE OUTPUT - Puls_out / Gr20	
<p>P_Factor Fu 21</p> <p>Pulse value</p>	<p>Enter that flow quantity for which an output pulse is supplied (pulse width: max. 1s, pulse/pause ratio up to 0.5 Hz approx. 1:1; with pulse frequencies less than 0.5 Hz the pulse width is limited to 1 s; $f_{max} = 400$ Hz). With external totalizers these pulses can be totalized and thus determine the total flow quantity since the start of measurement.</p> <p> Numeric entry: Change flashing number with and store with . The next number to be changed will then flash automatically. After the last number has been changed and stored, the instrument returns back to the function level (all display segments flash).</p> <p>Note! The minimum or maximum possible full scale value is given for every nominal diameter in the table on page 43. If the value entered is too high or too low then the display reacts as follows: 1. The value entered is <i>not</i> stored. 2. The message "too_HI" (value entered is too high) or "too_Lo" (value entered is too low) is shown on the display. 3. The minimum or maximum possible values are then shown on the display which can be entered for the pulse value (see table).</p> <p><i>Display of numerical values:</i> Due to the limited size of the display, values are shown in a special way.</p> <div style="display: flex; justify-content: space-around; align-items: flex-start;"> <div style="text-align: center;"> <p>Basic value</p> </div> <div style="text-align: left;"> <p>Multiplication factor</p> <p>E 9 = 10^9 = 1000000000 E 3 = 10^3 = 1000 E 2 = 10^2 = 100 E 1 = 10^1 = 10 E 0 = 10^0 = 1 E-1 = 10^{-1} = 0.1 E-2 = 10^{-2} = 0.01 E-3 = 10^{-3} = 0.001 E-9 = 10^{-9} = 0.000000001</p> </div> </div> <p>Examples:</p> <div style="background-color: #f0f0f0; padding: 5px; margin-top: 10px;"> <p>$4.600\ E-2 = 4.600 \times 10^{-2} = 0.046\ [m^3/pulse]$ $4.600\ E\ 2 = 4.600 \times 10^{+2} = 460.0\ [m^3/pulse]$</p> </div>







Display limits / Pulse value				
DN	Litre		m ³	
	Min.	Max.	Min.	Max.
2	7.853 E-5	9.999 E 9	7.853 E-8	9.999 E 6
4	3.141 E-4	9.999 E 9	3.141 E-7	9.999 E 6
8	1.256 E-3	9.999 E 9	1.256 E-6	9.999 E 6
15	4.417 E-3	9.999 E 9	4.417 E-6	9.999 E 6
25	1.227 E-2	9.999 E 9	1.227 E-5	9.999 E 6
32	2.010 E-2	9.999 E 9	2.010 E-5	9.999 E 6
40	3.141 E-2	9.999 E 9	3.141 E-5	9.999 E 6
50	4.908 E-2	9.999 E 9	4.908 E-5	9.999 E 6
65	8.295 E-2	9.999 E 9	8.295 E-5	9.999 E 6
80	1.256 E-1	9.999 E 9	1.256 E-4	9.999 E 6
100	1.963 E-1	9.999 E 9	1.963 E-4	9.999 E 6
125	3.067 E-1	9.999 E 9	3.067 E-4	9.999 E 6
150	4.417 E-1	9.999 E 9	4.417 E-4	9.999 E 6
200	7.853 E-1	9.999 E 9	7.853 E-4	9.999 E 6
250	1.227 E 0	9.999 E 9	1.227 E-3	9.999 E 6
300	1.767 E 0	9.999 E 9	1.767 E-3	9.999 E 6
350	2.405 E 0	9.999 E 9	2.405 E-3	9.999 E 6
400	3.141 E 0	9.999 E 9	3.141 E-3	9.999 E 6
500	4.908 E 0	9.999 E 9	4.908 E-3	9.999 E 6
600	7.068 E 0	9.999 E 9	7.068 E-3	9.999 E 6
700	9.621 E 0	9.999 E 9	9.621 E-3	9.999 E 6
800	1.256 E 1	9.999 E 9	1.256 E-2	9.999 E 6
900	1.590 E 1	9.999 E 9	1.590 E-2	9.999 E 6
1000	1.963 E 1	9.999 E 9	1.963 E-2	9.999 E 6
1200	2.827 E 1	9.999 E 9	2.827 E-2	9.999 E 6
1400	3.848 E 1	9.999 E 9	3.848 E-2	9.999 E 6
1600	5.026 E 1	9.999 E 9	5.026 E-2	9.999 E 6
1800	6.361 E 1	9.999 E 9	6.361 E-2	9.999 E 6
2000	7.853 E 1	9.999 E 9	7.853 E-2	9.999 E 6

The last figure of the above values can differ by ± 1 from the value shown in the display (error in rounding off)!

Min. pulse value at $v = 10$ m/s and $f = 400$ Hz
 Factory settings → see page 68

Function group AUXILIARY INPUT – <i>INPuT / Gr40</i>	
<p><i>INP_Fct</i> <i>Fu 41</i></p> <p>Auxiliary input function</p>	<p>Select or assign the auxiliary input function. The appropriate function is actuated by applying an external voltage (3...30 V DC) at the auxiliary input.</p> <p>Note! The following selection parameters are not available in custody transfer mode (SuPPrESS, res_tot). The auxiliary input is only used in custody transfer mode for resetting the error message (flashing display segment) or for testing the display.</p> <p> SuPPrESS Measured value suppression (Positive Zero Return): By activating the Positive Zero Return, the measuring mode is interrupted and all output signals are reset to defined values (~zero flow). <i>Example:</i> Interruption of measurement to clean the piping.</p> <p>Response of display with active suppression: "rRE" → Display with 8 vertical bars. "tOTAL" → Display segment "Low flow cutoff" is shown (if creep suppression is activated).</p> <p>res_tot Totalizer is reset to "0". (The totalizer can also be reset by using the function "res_tot" resp. "Fu51").</p> <p>CANCEL</p>
Function group DISPLAY – <i>DISPLAy / Gr50</i>	
<p><i>res_tot</i> <i>Fu 51</i></p> <p>Reset totalizer</p>	<p>Reset the totalizer to '0'.</p> <p>Notes!</p> <ul style="list-style-type: none"> The totalizer and its overruns are set to zero with this function. The totalizer can also be reset using the auxiliary input (see function <i>INP_Fct / Fu 41</i>). <p> CANCEL Cancel</p> <p> res_YES Reset totalizer (press [E])</p>
<p><i>DISP_opt</i> <i>Fu 52</i></p> <p>Display mode</p>	<p>Select the display mode (e.g. display of flow rate or display of totalizer, etc.).</p> <p>Note! For custody transfer measurement only the parameters <i>ALtErnAt</i> or <i>tOTAL</i> can be selected.</p> <p> rRE Display flow</p> <p> tOTAL Display totalizer (counter status)</p> <p>ALtErnAt Display flow <i>and</i> totalizer (alternating)</p> <p>tEST Display test function *</p> <p>CANCEL</p> <p>* An automatic test of all display elements is carried out with this function (Start with [E]). The following displays are shown one after the other: 1. *8.8.8.8.8.8.8.8. (all display segments visible) 2. -0 0 0 0 0 0 0 0 (no display segments visible) 3. No display elements visible at all.</p>



Function group DISPLAY - DISPLAY / Gr 50	
<p><i>DISP_dR</i> Fu 53</p> <p>Display damping (Flow rate)</p> <p> Note!</p>	<p>Selecting the time constant determines whether the current output signal reacts very quickly to rapidly changing flows or is dampened:</p> <ul style="list-style-type: none"> • small time constant → display with quick reaction • large time constant → display with dampened reaction <p>Note! The display damping does not affect the response of the current output.</p> <p> Numeric entry: 0.5...20 [s] in steps of 0.5 s</p>
<p><i>tot_ofL</i> Fu 54</p> <p>Totalizer overflows</p>	<p>Display of totalizer overflows (arithmetic sign flashes on the display!) On the display the totalized flow is shown as a max. 8-digit number. Larger numerical values (> 99999999) can be read off in this function as overflows. The effective amount is therefore calculated from the sum of overflows and the actual displayed counter status (display mode → <i>totARL</i>).</p> <p><i>Example:</i> Display of 2 overflows: 2 Actual displayed value for totalized sum: 00004321 [m³] Total amount: 200004321 [m³]</p>
Function group PROCESS PARAMETERS - PROCESS / Gr 60	
<p>LFC Fu 61</p> <p>Creep suppression</p> <p> Note!</p>	<p>Switching on or off the creep suppression (Low flow cutoff). The creep suppression prevents the flow in the lowest measuring range from being detected e.g. with varying liquid head at standstill. With variations in flow in the lower part of the measuring range, the hysteresis (50% of creepage) prevents continual switching on and off of the creep suppression function.</p> <p>Note! This function is always activated in custody transfer mode (<i>LFC_on</i>)</p> <p>Switch-on point (1) When the velocity of the fluid is less than 0.02 m/s creep suppression is then <i>activated</i> and all output signals such as pulse and analogue signals, are set to the fall back value (0/4 mA, logical '0'). The segment for "Low flow cutoff" is then immediately visible on the LC display.</p> <p>Switch-off point (2) When the velocity of the fluid again exceeds $v = 0.04$ m/s, then creep suppression is <i>deactivated</i>.</p> <p> LFC_off Switch off creep suppression  LFC_on Switch on creep suppression CRNCEL</p> <p></p>

ba041y38

Switch-on and switch-off points (creepage)				
Diameter	On	Off	On	Off
DIN	[l/s]		[m ³ /h]	
2	0.00006	0.0001	0.0002	0.0005
4	0.0003	0.0005	0.0009	0.0018
8	0.001	0.002	0.004	0.007
15	0.003	0.007	0.013	0.025
25	0.010	0.020	0.035	0.071
32	0.016	0.032	0.058	0.116
40	0.025	0.050	0.090	0.181
50	0.039	0.079	0.141	0.283
65	0.066	0.132	0.239	0.478
80	0.101	0.201	0.362	0.724
100	0.157	0.314	0.565	1.131
125	0.245	0.491	0.884	1.767
150	0.353	0.707	1.272	2.545
200	0.628	1.257	2.262	4.524
250	0.982	1.963	3.534	7.069
300	1.413	2.827	5.089	10.179
350	1.924	3.848	6.927	13.854
400	2.513	5.026	9.048	18.096
500	3.926	7.854	14.137	28.274
600	5.654	11.310	20.358	40.715
700	7.696	15.394	27.709	55.418
800	10.053	20.106	36.191	72.382
900	12.723	25.447	45.804	91.609
1000	15.708	31.416	56.549	113.097
1200	22.619	45.239	81.443	162.860
1400	30.788	61.575	110.836	221.672
1600	40.212	80.425	144.764	289.528
1800	50.894	101.788	183.218	366.436
2000	62.832	125.664	226.194	452.388

On and off switch points are fixed values:
 Switch-on point → at v = 0.02 m/s
 Switch-off point → at v = 0.04 m/s

Function group
PROCESS PARAMETERS – PROCESSES / GROSS

EPD
F 62

Empty Pipe
Detection



Note!

With this function (EPD = Empty Pipe Detection), two procedures can always be activated:

- Carrying out the empty and full pipe adjustment for Empty Pipe Detection
- Switching on/off Empty Pipe Detection (EPD).

Note!

- This function is available only if the sensor is fitted with an extra EPD electrode (see "Technical Data", page 65).
- The EPD function is not available with the remote "FL" version.
- The connection cable with the remote "FS" version may only be a maximum of 10 m long. Only then can correct functioning of the EPD be guaranteed!
- The EPD function is switched off when the flowmeter is delivered and must be switched on manually when required.



EPd_oFF EPD switched off

EPd_on EPD switched on

(This selection is only displayed if the EPD adjustment has already been carried out successfully.

If the adjustment is incorrect then the message "Adj_Err" is shown instead)


EPd_Ad_E Start empty pipe adjustment (confirm with **[E]**)

EPd_Ad_F Start full pipe adjustment (confirm with **[E]**)

CRCEL

Remarks on Empty Pipe Detection (EPD)

Only a completely full measuring tube enables correct readings to be obtained. This can be continuously checked by Empty Pipe Detection. EPD is based on measuring the resistance between reference and EPD electrode (see Figure).



Response when partially full

If the EPD is active and responds due to a partially filled or empty pipe, the display segment "Empty Pipe" is shown on the display. The outputs respond in such cases as described on page 51.

When the pipe is partially filled and the EPD is not active, then the response may be different for identical plants:

- varying flow display
- zero flow
- excess flow values

(continued next page)






Function group PROCESS PARAMETERS – P r o C E S S / G r 6 0	
EPD F u 6 2	<p>Procedure (Empty pipe / full pipe adjustment)</p> <p>Notes!</p> <ul style="list-style-type: none"> • If Promag 31 is fitted with an EPD electrode, then the unit is already calibrated in the factory with drinking water (500 µS/cm). A new empty pipe or full pipe adjustment is to be carried out on site when liquids having different conductivities are used. • Every (new) adjustment automatically switches off the EPD function. • The EPD function can only be switched on (again) if empty or full pipe adjustment has been successfully carried out. <ol style="list-style-type: none"> 1. Empty the piping. For the empty pipe adjustment to be carried out now, the walls of the measuring tube should be wetted with fluid. 2. Start the empty pipe adjustment: Select EPd_Ad_E and confirm with [E]. – Display during adjustment: Adj_bu5y – Display after adjustment: Adj_done 3. Fill the piping with fluid. 4. Start the full pipe adjustment with the fluid stationary: Select EPd_Ad_F and confirm with [E]. – Display during adjustment: Adj_bu5y – Display after adjustment: Adj_done 5. Switch on the Empty Pipe Detection after the adjustment → Select EPd_on and confirm with [E]. <p>Note!</p> <p>The EPD function can only be switched on (again) if empty or full pipe adjustment has been successfully carried out. If the adjustment is not successful then the message Adj_Err is shown instead of “EPd_on”. In such cases the empty or full pipe adjustment must again be carried out.</p> <p><i>Possible sources of error:</i></p> <ul style="list-style-type: none"> – Empty pipe adjustment has been carried out when the pipe was full. – Full pipe adjustment was carried out when the pipe was empty or partially filled.



Note!



Note!


Function group PROCESS PARAMETERS – P r o C E S S / G r 6 0	
<p>ECC F u 6 3</p> <p>Electrode cleaning</p> <p> Note!</p> <p> Note!</p> <p> Caution!</p>	<p>Switching on and off the electrode cleaning circuitry (ECC). This function is not available in custody transfer mode!</p> <p>Note!</p> <ul style="list-style-type: none"> • This function is only available if the Promag 31 is fitted with an electrode cleaning function (optional). • The ECC function is not available with the remote "FL" version. • The ECC is always switched on when first delivered from the factory. <p> ECC_oFF ECC switched off  ECC_on ECC switched on CRnCEL</p> <p>Remarks on ECC: Conductive build-up on the electrodes and the measuring tube walls (e.g. magnetite) can cause measurement errors. The Electrode Cleaning Circuitry (ECC) has been developed in order to prevent build-up occurring. The cleaning cycle repeats itself every 30 minutes for approx. 3 seconds. The ECC works in the way described for all electrode materials available except tantalum. If the electrode material is tantalum then the ECC only protects the electrode surface from oxidation.</p> <p>Note! After the electrode cleaning procedure is completed, the signal outputs may be unsteady for a little while. This is due to electrochemical potentials caused by electrostatic charging of the fluid during the cleaning cycle. The set recovery time of approx. 2 seconds is generally sufficient to stabilise the signal output after the cleaning phase. During the recovery time the last value registered before cleaning is given.</p> <p>Caution! If the ECC is switched off for a long period of time in an application where there is a conductive build-up in the measuring tube, then this can lead to errors. If there is a large concentration of build-up at one point, then, under certain circumstances, switching on the ECC may not remove it. In such cases the flowmeter is to be cleaned and the build-up removed.</p>

8 Trouble-shooting, Maintenance and Repairs

8.1 Response of the measuring system on faults or alarm

The Promag 31 distinguishes between two kinds of error:

- System error: instrument failure, power failure (Error)
- Process error: partially filled pipe (Empty Pipe), measuring range exceeded (Overflow)



Errors which occur during normal operation are indicated on the display by appropriate *segment bars* ("Error, Empty Pipe, Overflow").

Special features with custody transfer measurement are given on page 36.

The error response of the outputs is described in the following table.

Positive Zero Return <i>not</i> activated					
	Current output		Pulse output	Status output (transistor)	
	"0-20"	"4-20"		"Error"	"FLo_dIr" (not available in custody transfer mode!)
No System / process error present	measurement OK (signal for flow)	measurement OK (signal for flow)	measurement OK (signal for flow)	conductive (closed)	<i>forward</i> : non-conductive (open) <i>reverse</i> : conductive (closed)
System or process error present	0 mA	2 mA	no signal output (0 Hz) non-conductive (open)	non-conductive (open)	Status kept before error occurred: <i>forward</i> : non-conductive (open) <i>reverse</i> : conductive (closed)

Positive Zero Return <i>activated</i> (not available in custody transfer mode!)					
	Current output		Pulse output	Status output (transistor)	
	"0-20"	"4-20"		"Error"	"FLo_dIr"
No System and process errors present	0 mA	4 mA	no signal output (0 Hz) non-conductive (open)	conductive (closed)	conductive (closed)
System error only present	0 mA	2 mA		non-conductive (open)	
Process error only present	0 mA	4 mA		conductive (closed)	
System and process error present	0 mA	2 mA		non-conductive (open)	

8.2 Trouble-shooting and remedy

All instruments undergo various stages of quality control during production. The last of these stages is the wet calibration carried out on state-of-the-art calibration rigs.

The following summary helps to identify possible causes of error during normal measurement. An LED on the amplifier board is lit as long as the measuring system is operating normally.



Note!

Note!

For approved instruments, errors can only be corrected by breaking the seal. After repair, the appropriate standards authorities are to be informed (for resealing with lead).



Warning!

Warning!

This error diagnosis cannot be carried out with Ex instruments as they must be opened and thus the ignition protection type is no longer present.

Type of error	Remedy (Steps 1 → 2 → 3)
↓ – No display – No output signal – LED on amplifier board is not lit	→ <ol style="list-style-type: none"> 1 Check the power supply → terminals 1, 2 2 Check fuse → see page 21 85...260 V AC: 1 A slow-blow 20...55 V AC and 16...62 V DC: 2.5 slow-blow 3 Replace electronics → see page 56
↓ The display is blank, with outputs still functioning.	→ <ol style="list-style-type: none"> 1 Check the ribbon cable connector of the display module → see page 56 (No. 3b) 2 Replace display module → see page 56 3 Replace electronics → see page 56
↓ No signal (current or pulse output) despite display showing value?	→ <ol style="list-style-type: none"> 1 Check the ribbon cable connector to the terminal compartment → see page 56 (No. 8) 2 Replace electronics → see page 56
↓ Is the message " Overflow " shown on the display?	→ <ol style="list-style-type: none"> 1 Is the measuring tube empty? If yes → fill measuring tube 2 Check ground and potential equalisation → see page 27 3 Is the flow velocity > 12.5 m/s? If yes → reduce flow
↓ Is the message " Empty Pipe " shown on the display although the measuring tube is full?	→ <ol style="list-style-type: none"> 1 Carry out an empty or full pipe adjustment and then switch on Empty Pipe Detection → see page 48 ff. 2 Check the following connections: <ul style="list-style-type: none"> • Electronics: EPD cable → see page 56 (No. 5c) • Remote version: EPD cable → see page 25 (terminals 36 and 37) 3 If the measuring tube is always full (pressure line): → Switch off function EPD / Full → see page 48
↓ Continued next page	

Type of error	Remedy (Steps 1 → 2 → 3)
<p>Is the message "Error" shown on the display?</p>	<p>1 Check the following connections on the amplifier board → see page 56:</p> <ul style="list-style-type: none"> • Electrode signal cable → No. 5a • DAT module → No. 5b • Coil current cable → No. 7 <p>2 Replace electronics → see page 56</p>
<p>Does the instrument show negative flow values although the fluid in the piping is flowing forwards?</p>	<p>1 Remote version → switch off power supply and change round terminals 41 and 42.</p> <p>2 Set status output (function <i>S t A t _ F C t</i>) to "<i>F L o _ d i r</i>" → see page 44</p>
<p>Is the display unsettled despite continuous flow?</p>	<p>1 Check ground and potential equalisation → see page 27</p> <p>2 Check to see if air bubbles are in the fluid.</p> <p>3 Increase the time constant for the current output → see page 42 Increase the display damping for flow → see page 46</p>
<p>Is a low flow indicated despite standstill of the fluid and filled measuring tube?</p>	<p>1 Check ground and potential equalisation → see page 27</p> <p>2 Check to see if air bubbles are in the fluid.</p> <p>3 Activate creep suppression (function <i>L F C / F u 5 1</i>) → see page 46</p>
<p>The error cannot be remedied or else there is another type of error.</p> <p>In such cases please contact your local E+H Service organisation.</p>	<p>The following solutions are possible:</p> <p>Request an E+H service technician The following information is required when contacting a customer service technician:</p> <ul style="list-style-type: none"> – brief description of the error – order code given on the nameplate → see page 7, 8 <p>Repair Note the procedures on page 57 "Repairs" before returning the instrument for repair. Please state a brief description of the error on the delivery note.</p>

8.3 Replacing the measuring electrodes

The Promag F (DN 350...2000) is available with replacement electrodes as an option. This version enables the measuring electrodes to be cleaned or replaced under process conditions.




Fig. 36
Replacement unit for changing
electrodes

Dismantling the electrode

1. Loosen the Allen screw (a) and remove the cover.
2. Unscrew the electrode cable (c) attached to the rotary arm (b).
3. Undo the knurled nut (d) by hand. This nut is used as a counter nut.
4. Remove the electrode (e) using the rotary arm (b). This can now be taken out from the holder (g) as far as the stop allows.

Warning!

Danger of injury! Under process condition (piping under pressure) the electrode can spring back to the stop. Keep pressing against while loosening.



Warning!

5. Close the shut-off valve (f) after the electrode has been taken out as far as the stop.

Warning!

Do not attempt to open the shut-off valve. Keeping it shut prevents fluid from escaping.



Warning!

6. Unscrew the entire electrode along with the holding cylinder (g).
7. Remove the rotary arm (b) from the electrode (e), while pressing to remove the locking pin (h). Take care not to lose the coil spring (k).
8. Replace the old electrode with a new electrode.
A set of replacement electrodes can be ordered from Endress+Hauser.

Assembling the electrode

1. Slide the new electrode (e) into the holding cylinder (g) from below. Ensure that gaskets at the tip of the electrode are clean.
2. Put the rotary arm (b) on the electrode and secure with the locking pin (h).

Caution!

Ensure that the coil spring (k) is in place. This ensures close electrical contact and thus reliable measuring signals.



Caution!

3. Pull back the electrode as far as possible so that the tip does not protrude out from the holding cylinder (g).
4. Screw the holding cylinder onto the shut-off unit (i) and tighten by hand. Gasket (j) on the holding cylinder must be in place and clean.

Note!

Ensure that the rubber tubes on the holding cylinder (g) and shut-off valve (f) have the same colour (red or blue)



Note!

5. Open the shut-off valve (f) and screw in the electrode using the rotary arm (b) until the stop.
6. Screw the knurled nut (d) onto the holding cylinder. This clamps the electrode tight.
7. Screw the electrode cable (c) to the rotary arm (b) using the Allen screw.

Caution!

Ensure that the Allen screw of the electrode cable is tight. This ensures close electrical contact and thus reliable measuring signals.



Caution!

8. Replace the cover and tighten the Allen screw (a).

8.4 Replacing the transmitter electronics



Warning!

Warning!

- Danger from electric shock! Switch off the power supply before opening the transmitter housing.
- When using Ex instruments, they must first cool down for at least 10 minutes before opening.
- The local power supply voltage and frequency must be the same as the technical specifications of the power supply boards.
- Ensure that the new electronics board is the same as the old one before replacing it (power supply, version of amplifier and software).

1. Loosen the Allen screws of the safety grip (3-mm Allen key).
2. Unscrew the cover of the electronics area of the transmitter housing.
3. Remove the local display as follows:
 - a. Loosen the mounting screws of the display module.
 - b. Unplug the ribbon cable of the display from the amplifier board.
4. Unplug the 2-pole plug of the power supply cable (by pressing down the catch) from the power supply board.
5. Remove the electrode signal cable from the amplifier board:
 - a. Remove the cable board.
 - b. Remove the blue DAT module.
 - c. Loosen the EPD cable from the screw terminals.



Note!

6. Loosen the two Phillips screws of the board support plate. Carefully remove the support plate approx. 4...5 cm out of the transmitter housing.
7. Remove the coil current cable plug from the power supply board.
8. Remove the ribbon cable plug (connection cable to the terminal area) from the amplifier board.
9. The entire transmitter electronics, together with the board support plate, can now be completely removed from the housing.
10. Replace the old transmitter electronics with new transmitter electronics.
11. Reassemble in reverse sequence.

Replacing the DAT module (see 5b):

- Procedure for replacing the transmitter electronics → plug the old DAT onto the new amplifier board.
- Procedure for replacing a defective DAT → plug the new DAT onto the old amplifier board.

DAT = Replaceable data memory in which the basic data of the sensor are stored (see page 65).

Note!

Replacing transmitter electronics on approved flowmeters can only be done by breaking the seal. After replacement, the appropriate standards authorities are to be informed (for resealing with lead).




Fig. 37
Replacing the transmitter electronics:

A Power supply board
B Amplifier board

8.5 Replacing the fuse

Warning!

Danger from electric shock! Switch off the power supply before unscrewing the cover of the terminal compartment from the transmitter housing.



The instrument fuse can be found in the terminal compartment → see page 21

Exclusively use the following types of fuses:

- Power supply 20...55 V AC / 16...62 V DC → 2.5 A slow-blow / 250 V; 5.2 × 20 mm
- Power supply 85...260 V AC → 1 A slow-blow / 250 V; 5.2 × 20 mm

8.6 Repairs

Please carry out the following procedure before returning the Promag 31 for repair to Endress+Hauser:

- A note must always be enclosed with the instrument, giving the following information:
 - Brief description of the error
 - Description of the application
 - Chemical and physical properties of the fluid
- Remove all residue which may be present. Pay special attention to the gasket grooves and crevices where fluid may be present. This is especially important if the fluid is dangerous to health, e.g. corrosive, carcinogenic, radioactive, etc.

Warning!

We must request you not to return a unit if it is not completely certain that harmful substances can be removed e.g. cracks have been penetrated or substances have diffused through plastics.

Incomplete cleaning of the instrument may result in waste disposal or cause harm to personnel (burns, etc.). Any costs arising from this will be charged to the operator of the instrument.



8.7 Spare parts


The electronics plug-in module of the Promag 31 can be ordered separately as a spare part by E+H Service technicians (Replacement → see page 56).

8.8 Maintenance

No special maintenance is necessary for the Promag 31 measuring system.

9 Dimensions

9.1 Dimensions Promag 31 F (DN 15...300)



ba041y47

Fig. 38
Dimensions
Promag 31 F (DN 15...300)

DN		PN			L ¹⁾	A	B	C	K	E	F		B1	Weight ²⁾	
[mm]	[inch]	DIN	ANSI Class	JIS	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	DIN [mm]	ANSI [mm]	[mm]	[kg]	
15	1/2"	40	150	20K	200	340.5	256.5	84	120	94	14	11.2	286	202	6.5
25	1"	40	150	20K	200	340.5	256.5	84	120	94	16	14.2	286	202	7.3
32	-	40	-	20K	200	340.5	256.5	84	120	94	18	-	286	202	8.0
40	1 1/2"	40	150	20K	200	340.5	256.5	84	120	94	18	17.5	286	202	9.4
50	2"	40	150	10K	200	340.5	256.5	84	120	94	20	19.1	286	202	10.6
65	-	16	-	10K	200	390.5	281.5	109	180	94	18	-	336	227	12.0
80	3"	16	150	10K	200	390.5	281.5	109	180	94	20	23.9	336	227	14.0
100	4"	16	150	10K	250	390.5	281.5	109	180	94	22	23.9	336	227	16.0
125	-	16	-	10K	250	471.5	321.5	150	260	140	24	-	417	267	21.5
150	6"	16	150	10K	300	471.5	321.5	150	260	140	24	25.4	417	267	25.5
200	8"	10	150	10K	350	526.5	346.5	180	324	156	26	28.4	472	292	35.3
250	10"	10	150	10K	450	576.5	371.5	205	400	156	28	30.2	522	317	48.5
300	12"	10	150	10K	500	626.5	396.5	230	460	166	28	31.8	572	342	57.5

¹⁾ The length is always identical independently of the chosen pressure rating.

Weight:

Compact version ²⁾ see table above
 Promag 31 transmitter 3 kg (5 kg for wall mounted version)
 Sensor connection housing approx. 1 kg

9.2 Dimensions Promag 31 F (DN 350...2000)




Fig. 39
Dimensions
Promag 31 F (DN 350...2000)

DN		PN			L ¹⁾	A	B	C	K	E	F			H	B1	Weight ²⁾
[mm]	[inch]	DIN [bar]	ANSI [Class]	AWWA [Class]							DIN [mm]	ANSI [mm]	AWWA [mm]			
350	14"	10	150	-	550	738	456.0	282.0	564	276	26	34.9	-	683.5	401.5	110
400	16"	10	150	-	600	790	482.0	308.0	616	276	26	36.5	-	735.5	427.5	130
450	18"	-	150	-	650	840	507.0	333.0	666	292	-	39.7	-	785.5	452.5	240
500	20"	10	150	-	650	891	532.5	358.5	717	292	28	42.9	-	836.5	478.0	170
600	24"	10	150	-	780	995	584.5	410.5	821	402	28	47.6	-	940.5	530.0	230
700	28"	10	-	D	910	1198	686.0	512.0	1024	589	30	-	33.3	1143.5	631.5	350
750	30"	-	-	D	975	1198	686.0	512.0	1024	626	-	-	34.9	1143.5	631.5	450
800	32"	10	-	D	1040	1241	707.5	533.5	1067	647	32	-	38.1	1186.5	653.0	450
900	36"	10	-	D	1170	1394	784.0	610.0	1220	785	34	-	41.3	1339.5	729.5	600
1000	40"	10	-	D	1300	1546	860.0	686.0	1372	862	34	-	41.3	1491.5	805.5	720
1050	42"	-	-	D	1365	1598	886.0	712.0	1424	912	-	-	44.5	1543.5	831.5	1050
1200	48"	6	-	D	1560	1796	985.0	811.0	1622	992	28	-	44.5	1741.5	930.5	1200
1350	54"	-	-	D	1755	1998	1086.0	912.0	1824	1252	-	-	54.0	1943.5	1031.5	2150
1400	-	6	-	-	1820	2148	1161.0	987.0	1974	1252	32	-	-	2093.5	1106.5	1800
1500	60"	-	-	D	1950	2196	1185.0	1011.0	2022	1392	-	-	57.2	2141.5	1130.5	2600
1600	-	6	-	-	2080	2286	1230.0	1056.0	2112	1482	34	-	-	2231.5	1175.5	2500
1650	66"	-	-	D	2145	2360	1267.0	1093.0	2186	1482	-	-	63.5	2305.5	1212.5	3700
1800	72"	6	-	D	2340	2550	1362.0	1188.0	2376	1632	36	-	66.7	2495.5	1307.5	3300
2000	78"	6	-	D	2600	2650	1412.0	1238.0	2476	1732	38	-	69.9	2595.5	1357.5	4100

1) Thickness of the flange face includes sealing strip. The length is always identical independently of the chosen pressure rating.




2) Weights of compact version
Weights for transmitter: see page 59

10 Technical Data

Application	
<i>Instrument name</i>	Flow measuring system "Promag 31 F (Model '99)" for custody transfer measurement.
<i>Instrument function</i>	Flow measurement of liquids for custody transfer with cold water (wastewater) in closed piping. Fields of Applications → see page 5.
Function and system design	
<i>Measuring principle</i>	Electromagnetic flow measurement according to Faraday's law (Generation of a voltage by induction in a magnetic field).
<i>Measuring system</i>	Instrument family "Promag 31 F (Model '99)" consisting of: <ul style="list-style-type: none"> • Transmitter: Promag 31 • Sensor: Promag F (DN 15...2000) Two versions are available: <ul style="list-style-type: none"> • Compact version • Remote version (FS or FL version)
Input variables	
<i>Measuring variable</i>	Flow velocity (proportional to induced voltage. Measured by two electrodes in the measuring tube)
<i>Measuring range</i>	Measuring range of electronics within $v = 0...12.5$ m/s The full scale values for the current output can be selected within the following limits (see also page 41): <ul style="list-style-type: none"> – Minimum full scale value at $v = 0.3$ m/s – Maximum full scale value at $v = 10$ m/s
<i>Operable flow range</i>	Over 1000 : 1 When the flow is pulsating, the amplifier is not overloaded above its set full scale value even with peak velocities of 12.5 m/s. Flow is measured between 0.01...>10 m/s at the stated accuracy.
<i>Auxiliary input</i>	$U = 3...30$ V DC, $R_i = 1.8$ k Ω , galvanically isolated Configurable for positive zero return or totalizer reset. With custody transfer measurement, error messages can only be reset and a display test function activated via the auxiliary input!
Output variables	
<i>Output signal</i>	<ul style="list-style-type: none"> • <i>Current output:</i> 0/4...20 mA, galvanically isolated, $R_L < 700$ Ω, time constant selectable (0.5...95 s), full scale value freely selectable temperature coefficient: typical 0.01% o.r./$^{\circ}$C; resolution: 10 μA • <i>Pulse output (transistor output):</i> passive, $f_{max} = 400$ Hz, $U_{max} = 30$ V, $I_{max} = 250$ mA, galvanically isolated, pulse value selectable, pulse/pause ratio up to 0.5 Hz approx. 1:1 (the pulse width is limited to 1 s for pulse frequencies < 0.5 Hz) • <i>Status output (transistor output):</i> passive, $U_{max} = 30$ V, $I_{max} = 250$ mA Can be configured for: <ul style="list-style-type: none"> – indicating system errors (error), process errors (overflow, Empty Pipe) – flow direction indication

Output variables (continued)	
<i>Signal on alarm</i>	<ul style="list-style-type: none"> • Current output: The current is set to a defined value (see page 51) • Pulse output: no signal supplied • Status output: on "Error" → not conducting (open) on "Flow direction" → last status held (forward → not conducting; backward → conducting) <p>Error response of the outputs (detailed description) → see page 51 Display response on errors → see page 36</p>
<i>Load</i>	$R_L < 700 \Omega$ (current output)
<i>Creep suppression</i>	<p>Switch-on point at $v = 0.02$ m/s Switch-off point at $v = 0.04$ m/s</p> <p>Further information → see page 46</p>
Accuracy	
<i>Reference conditions</i>	<p>According to DIN 19200 and VDI/VDE 2641:</p> <p>Fluid temperature +28 °C ± 2 K Ambient temperature +22 °C ± 2 K Warm up period 30 minutes</p> <p>Mounting</p> <ul style="list-style-type: none"> - Inlet run > 10 x DN - Outlet run > 5 x DN - Transmitter and sensor are grounded. - The sensor is build-in centered into the piping.
<i>Measured error</i>	<p>Pulse output: ± 0.5% o.r. ± 0.01% o.f.s. (full scale value = 10 m/s) Current output: additionally ± 10 µA (typical)</p> <div style="text-align: center;"> <p>Measured error [% o.r.]</p> <p>— 0.5 % - - - 0.2 % (Option)</p> <p>Fluid velocity [m/s]</p> </div> <p><i>Option:</i> Promag 31 F: ± 0.2% o.r. ± 0.005% of Q_k Q_k = desired reference flow quantity for calibration ($v = 2...10$ m/s). Q_k has to be noted for ordering.</p> <p>Deviations in power supply voltage have no influence on the specified ranges.</p>
<i>Repeatability</i>	<p>± 0.1% o.r. ± 0.005% o.f.s.</p> <p>o.r. = of reading o.f.s. = of max. full scale value (see table on page 41)</p>

ba041v63

Operating conditions	
Installation conditions	
<i>Installation instructions</i>	Orientation: vertical or horizontal Restrictions and other recommendations → see page 10 ff.
<i>Inlet and outlet sections</i>	The inlet and outlet sections must have the same nominal width as the flowmeter: Inlet section: ≥ 5 x DN Outlet section: ≥ 2 x DN
<i>Connection cable length for remote version</i>	<p><i>FS version:</i> 0... 10 m → min. conductivity ≥ 5 μS/cm 10...200 m → min. conductivity = f (L_{max})</p> <p><i>FL version:</i> 0...200 m → min. conductivity ≥ 5 μS/cm</p> <p><i>Instrument equipped with empty pipe detection (EPD):</i> max. cable length = 10 m</p> <p>Minimum conductivity for demineralised water: generally ≥ 20 μS/cm</p> <div style="display: flex; align-items: center; justify-content: center;">  <div style="text-align: center;">  </div> <div style="margin-left: 20px; font-size: small;"> ba041y76 </div> </div>
Ambient conditions	
<i>Ambient temperature</i>	<p>−20...+60 °C (Transmitter and sensor)</p> <ul style="list-style-type: none"> • An all-weather cover should be used to protect the housing from direct sunlight when mounting in the open. This is especially important in warmer climates and with high ambient temperatures. • Due to the danger of the transmitter electronics overheating, the transmitter and sensor are to be mounted separately with high ambient and fluid temperatures (see Figure). <div style="display: flex; align-items: center; justify-content: center;">  <div style="margin-left: 20px; font-size: small;"> ba041y54 </div> </div>
<i>Storage temperature</i>	−10...+50 °C (preferably at +20 °C)
<i>Degree of protection (EN 60529)</i>	IP 67 (NEMA 4X) Option: IP 68 (NEMA 6P) for Promag F sensor
<i>Shock and vibration resistance</i>	Acceleration up to 2 g / 2 h per day; 10...100 Hz
<i>Electromagnetic compatibility (EMC)</i>	According to EN 50081 Part 1 and 2 (interference emission) / EN 50082 Part 1 and 2 (interference immunity) as well as to NAMUR recommendations

Operating conditions (continued)	
Process conditions	
<i>Fluid temperature</i>	<p><i>"Custody transfer certifiable" instruments:</i> Fluid temperature range depends on the sensor lining (see also Figure on page 63):</p> <p>–40...+130 °C PTFE (Teflon), DN 15...600 –20...+120 °C Soft rubber (EPDM), DN 25...2000 0...+ 80 °C Hard rubber, DN 65...2000</p> <p><i>Certified instruments:</i> 0...30 °C (Cold water)</p>
<i>Nominal pressure</i>	<p>DIN PN 6 (DN 1200...2000) PN 10 (DN 200...1000) PN 16 (DN 65...150) PN 40 (DN 15...50) PN 16/25 (DN 200...300) PN 40 (DN 65...100, optional)</p> <p>ANSI Class 150 (1/2...24") Class 300 (1/2...6", optional)</p> <p>The material load curves (p-T-load diagrams) for all process connections can be found in the Technical Information TI 043D/06/en "Promag 30 (Model '99)"</p>
<i>Conductivity</i>	<p>Minimum conductivity: ≥ 5 µS/cm (for liquids in general) ≥ 20 µS/cm (for demineralised water)</p> <p>With the "FS" remote version the conductivity required also depends on the length of the cable → see page 63 "<i>Connection cable length</i>"</p>
<i>Pressure loss</i>	<ul style="list-style-type: none"> • No pressure loss if sensor and piping have the same nominal diameter. • Pressure loss specifications when using adapters e.g. reducers or expanders → see page 14. • Vacuum resistance of measuring tube lining → see page 70
Mechanical construction	
<i>Design / Dimensions</i>	<p>Dimensions → see pages 59–60 Internal diameter of measuring tube → see page 69</p>
<i>Weight</i>	See pages 59–60
<i>Materials</i>	<p><i>Process connections (flanges):</i> DIN: Stainless steel 1.4571, St. 37-2</p> <p><i>Electrodes:</i> 1.4435; Platinum/Rhodium 80/20; Hastelloy C-22; Tantalum</p> <p><i>Seal material:</i> no seals (Lining = 'seal')</p> <p><i>Transmitter housing:</i> Powder-coated die-cast aluminium</p> <p><i>Sensor housing:</i> DN 15...300: Powder-coated die-cast aluminium DN 350...2000: Coated steel</p>

Mechanical construction (continued)	
<i>Electrodes fitted</i>	Measuring, reference and empty pipe detection electrodes As standard with 1.4435, Hastelloy C-22, Tantalum
<i>CIP cleanable</i>	Yes (observe maximum temperature)
<i>SIP cleanable</i>	No
<i>Process connections</i>	Flange connection (DIN)
<i>Electrical connection</i>	<ul style="list-style-type: none"> • Wiring diagrams: see page 21 ff. • Cable specifications: see page 26 • Galvanic isolation: All circuits for inputs, outputs, power supply and sensors are galvanically isolated from one another.
<i>Cable entries</i>	<p><i>Power supply and signal cable (output):</i> Cable glands PG 13.5 (5...15 mm) or threads for cable glands M20 x 1.5 (8...15 mm)</p> <p><i>Coil current cable and signal cable (remote version)</i> Cable glands PG 13.5 (5...15 mm) or threads for cable glands M20 x 1.5 (8...15 mm)</p>
User interface	
<i>Operation</i>	On-site operation: All functions of the E+H operating matrix can be selected and changed using three keys (E, -, +).
<i>Display</i>	<ul style="list-style-type: none"> – Eight character LC display – 11 display segments for indicating units and instrument status. – Damping of flow display can be adjusted: 0.5...20 s
<i>Communication</i>	none
Power supply	
<i>Supply voltage / Frequency</i>	85...260 V AC, 45...65 Hz 20... 55 V AC, 45...65 Hz 16... 62 V DC
<i>Power consumption</i>	AC: < 15 VA (incl. sensor) DC: < 15 W (incl. sensor) Current at make (Promag 31 X / 24 V DC): – max. 13.5 A (< 100 µs) – max. 6 A (< 5 ms)
<i>Power supply failure</i>	<p>Bridges minimum 1 power cycle (22 ms)</p> <ul style="list-style-type: none"> • EEPROM saves measuring system data on power failure (no batteries required). • DAT = replaceable data memory in which basic data of the sensor are stored: nominal diameter, SAPS (actual values), serial number, calibration factor, zero point, status EPD (yes/no), EPD calibration values.

Certificates and approvals	
<i>Ex approvals</i>	Information on Ex versions (e.g. CENELEC, SEV, FM, CSA) can be supplied by your E+H sales center on request. All explosion protection data are given in separate documentation available on request.
<i>Custody transfer</i>	PTB approval for custody transfer with cold water and wastewater (either for approval or approved for custody transfer).
<i>CE mark</i>	By attaching the CE mark, Endress+Hauser confirms that the Promag 31 measurement system has been successfully tested and fulfils all legal requirements of the relevant CE directives.
Order information	
<i>Accessories</i>	<ul style="list-style-type: none"> • Post mounting set for transmitter (remote version): Order No. 50076905 • Wall mounting kit for Promag A sensor: Order No. 50064550
<i>Supplementary documentation</i>	System Information Promag (SI 010D/06/en) Technical Information Promag 30 (TI 043D/06/en) * Operating Manual Promag 30 (BA 039D/06/en) * Supplementary Ex documentation: CENELEC, SEV, FM, CSA * Model '99
Other standards and guidelines	
EN 60529 Degree of protection by housing (IP code) EN 61010 Protection Measures for Electronic Equipment for Measurement, Control, Regulation and Laboratory Procedures EN 50081 Part 1 and 2 (interference emission) EN 50082 Part 1 and 2 (interference immunity) NAMUR Association of Standards for Control and Regulation in the Chemical Industry	

Physikalisch-Technische Bundesanstalt

Braunschweig und Berlin



Zulassungsschein

Innerstaatliche Bauartzulassung

Nr. 1.32-96000089

Auf Grund des § 9 des Eichgesetzes vom 11. Juli 1969 (BGBl. I S. 759) in Verbindung mit § 26 des Eichgesetzes in der Fassung vom 23. März 1992 (BGBl. I S. 711) sowie den §§ 16 Abs. 1-3 und 17 Abs. 1 der Eichordnung vom 12. August 1988 (BGBl. I S. 1657) in ihren derzeit gültigen Fassungen wird der Firma:

Endress + Hauser Flowtec AG
Reinach, Schweiz

folgende Bauart zur innerstaatlichen Eichung zugelassen:

Magnetisch-induktiver Volumendurchflußintegrator
mit elektrischem Zählwerk

Die Bauart erhält folgendes Zulassungszeichen:

6.221

96.18

Die wesentlichen Merkmale und gegebenenfalls die Zulassungsaufgaben, Befristungen und Bedingungen sowie inhaltlichen Beschränkungen sind in der Anlage festgelegt. Sie ist Bestandteil der Zulassung und umfaßt -05-Seite(n).

Physikalisch-Technische Bundesanstalt

Braunschweig, 27. Juni 1996

Im Auftrag


Dr. M. Rinker

Dienststempel



- Hinweise und Rechtsbehelfsbelehrung auf der Rückseite -

Zulassungsscheine ohne Unterschrift und ohne Dienststempel haben keine Gültigkeit.
Die Zulassungsscheine dürfen nur unverändert weiterverbreitet werden.
Auszüge oder Änderungen bedürfen der Genehmigung der Physikalisch-Technischen Bundesanstalt.

Factory settings (full scale value, pulse values)

DN		Factory settings			
		Full scale value (current output) (I = 20 mA; at v ~ 2.5 m/s)		Pulse value (Imp _{out} = 1 Hz; at v ~ 2.5 m/s)	
[mm]	[inch]	[l/s]	[USgpm]	[l/pulse]	[USgal/pulse]
2	1/12"	0.008	0.1	0.008	0.0020
4	5/32"	0.03	0.5	0.03	0.0085
8	5/16"	0.10	2.0	0.10	0.035
15	1/2"	0.45	7.0	0.45	0.10
25	1"	1.0	20.0	1.0	0.30
32	1 1/4"	2.0	30.0	2.0	0.55
40	1 1/2"	3.0	50.0	3.0	0.85
50	2"	5.0	80.0	5.0	1.0
65	2 1/2"	8.0	150.0	8.0	2.0
80	3"	10.0	200.0	10.0	3.5
100	4"	20.0	300.0	20.0	5.0
125	5"	30.0	500.0	30.0	8.0
150	6"	45.0	700.0	45.0	10.0
200	8"	80.0	1000.0	80.0	20.0
250	10"	100.0	2000.0	100.0	30.0
300	12"	150.0	3000.0	150.0	50.0
350	14"	250.0	4000.0	250.0	65.0
400	16"	300.0	5000.0	300.0	85.0
500	20"	500.0	8000.0	500.0	150.0
600	24"	700.0	10000.0	700.0	200.0
700	28"	950.0	15000.0	950.0	250.0
800	32"	1000.0	20000.0	1000.0	350.0
900	36"	1500.0	25000.0	1500.0	400.0
1000	40"	2000.0	30000.0	2000.0	500.0
1200	48"	3000.0	50000.0	3000.0	750.0
1400	56"	4000.0	60000.0	4000.0	1000.0
1600	64"	5000.0	80000.0	5000.0	1500.0
1800	72"	6500.0	100000.0	6500.0	1500.0
2000	78"	8000.0	100000.0	8000.0	2000.0

Internal diameter of the measuring tube

DN		DIN [bar]	PN		AWWA	Internal diameter		
[mm]	[inch]		ANSI [lbs]	JIS		PFA	PTFE (Teflon)	Hard rubber Soft rubber (EPDM)
15	1/2"	40	Class 150	20K		-	15	-
25	1"	40	Class 150	20K		-	26	-
32	-	40	Class 150	20K		-	35	-
40	1 1/2"	40	Class 150	20K		-	41	-
50	2"	40	Class 150	10K		-	52	-
65	-	16	Class 150	10K		-	68	65
80	3"	16	Class 150	10K		-	80	78
100	4"	16	Class 150	10K		-	105	100
125	-	16	Class 150	10K		-	130	126
150	6"	16	Class 150	10K		-	156	154
200	8"	10	Class 150	10K		-	207	205
250	10"	10	Class 150	10K		-	259	259
300	12"	10	Class 150	10K		-	309	310
350	14"	10	Class 150			-	337	341
400	16"	10	Class 150			-	387	391
500	20"	10	Class 150			-	487	491
600	24"	10	Class 150			-	593	593
700	28"	10		Class D		-	-	692
800	32"	10		Class D		-	-	794
900	36"	10		Class D		-	-	893
1000	40"	10		Class D		-	-	995
1200	48"	6		Class D		-	-	1195
1400	-	6		-		-	-	1401
1600	-	6		Class D		-	-	1599
1800	72"	6		Class D		-	-	1799
2000	-	6		-		-	-	1995

Resistance of the lining to vacuum (standard version)

DN		Measuring tube lining	Limits for vacuum [mbar] at different fluid temperatures				
[mm]	[inch]		25 °C	80 °C	100 °C	120 °C	130 °C
65...2000 25...2000	3...78" 1...78"	Hard rubber Soft rubber (EPDM)	0 0	0 0	0	0	
15...50 65...80 100 125...150 200 250 300 350 400	1/2...2" 3" 4" 6" 8" 10" 12" 14" 16"	PTFE (Teflon)	0 0 0 135 200 330 400 470 540	0 * * * * * * * *	0 40 135 240 290 400 500 600 670	* * * * * * * * *	100 130 170 385 410 530 630 730 800
500...600	20...24"		Vacuum not permitted!				

* No value available

Index

A

Accuracy	
Measured error	62
Reference conditions	62
Repeatability	62
Adapters	14
Ambient temperature	63
Auxiliary input	
Electrical connection	21
Example for electrical connections	23
Functions	45
General technical data	61

B

Bidirectional measurement (flow direction)	44
Build-up (measuring tube, electrodes) see ECC	

C

Cable glands	19, 65
Cable specifications	26
Calibration factor (name plate)	7
Cathodic protection	27
CE mark	66
CIP (cleaning in place)	65
Commissioning	29
Conductivity (minimum) of the fluid	64
Connection (electrical) see Electrical connections	
Connection cable length (remote version)	18, 63
Correct usage	5
Creep suppression	46
Current output	
Current range	42
Electrical connection	23
Factory settings (full scale)	68
Full scale value function	40, 41
Technical data	61
Time constant	42
Custody transfer measurement	
Approval by the Standards Authorities	35
Flow ranges (definitions)	37
Metrological class A, B	13, 37
Nominal flow rate (Q _n)	13, 37
Reapproval	35
Sealing of certified instruments	35
Special features	35
Suitability for custody transfer	35

D

Dangerous substances	6
DAT (data storage module)	56, 65
Degree of protection	19, 63
Dimensions	
Measuring tube (internal diameter)	69
Promag 31 F (DN 15...300)	59
Promag 31 F (DN 350...2000)	60

Display

Display and operating elements	31
Display damping (flow rate)	46
Display mode (displayed variables)	45
Display of numerical values	40
Function code	39
Operation (E+H operating matrix)	32
Rotating (4 x 90°)	17
Test function	45
Documentation, supplementary	66
Downward pipe	10

E

ECC (Electrode cleaning circuitry)	50
Electrical connection	
Cable specifications	26
Degree of protection (IP code)	19
Example connection diagrams (inputs / outputs)	22
Potential equalisation	27
Remote version (connection cable)	24
Transmitter	20
Electrode cleaning circuitry (ECC)	50
Electrodes fitted	65
Electromagnetic compatibility (EMC)	26, 28
Empty pipe adjustment	49
Empty pipe detection (EPD)	48
Engineering units see Unit selection	
EPD (Empty pipe detection)	48
Error correction (remedies)	52
Error limits see Accuracy	
Error response (measuring system, outputs)	51
Ex approvals	66
Ex instruments (documentation)	5

F

Factory settings (full scale, pulse value)	68
Flow direction indication (status output)	44
Flow range, operable	61
Flow rate / Nominal diameter	13
Fluid conductivity	64
Fluid temperature	64
Full pipe adjustment	49
Full scale value (current output)	40, 41
Function description	39
Functions at a glance	33
Fuse replacing	21, 57

G

Galvanic isolation	65
Gasket see Seals	
Grounding disks	27, 28
Grounding, ground terminal	27

I	
Inlet section	12
Input variables	61
Installation see Mounting	
Instrument functions (description)	39
L	
Length see Dimensions	
Load (current output)	62
Local display see Display	
M	
Maintenance	57
Material load curves	64
Materials	64
Matrix (operating matrix)	33
Measured error (error limits)	62
Measuring electrodes Positioning	12
Replacement	54
Measuring principle	61
Measuring range	61
Measuring system Promag 31 F	7
Measuring tube Internal diameter	69
Lining	64
Measuring variable	61
Metrological class (nominal flow rate)	13, 37
Mounting in the pipe Adapters	14
Base and supports	9
Downward pipe	10
Inlet and outlet sections	12
Installation of pumps	11
Mounting location	10
Mounting position	12
Partly filled pipes	10
Vibration	11
Mounting of the sensor Base and supports (from DN 350)	9
Mounting Promag F	15
Mounting of the transmitter (remote version) Connection cable length	18
Wall and post mounting	18
N	
Name plates Sensor Promag F	8
Transmitter Promag 31	7
NAMUR recommendations	26
Nominal diameter / Flow rate	13
Nominal flow rate Qn (metrological class)	13, 37
Nominal pressure (material load)	64

O	
Operating and display elements	31
Operating conditions	63
Operating example	34
Operating matrix	33
Operation (E+H operating matrix)	31, 32
Order code	8
Outlet section	12
Output signals	61
Output variables	61
P	
Positive zero return (via auxiliary input)	45
Post mounting (transmitter)	18
Potential equalisation	27
Power consumption	65
Power supply	65
Pressure loss Adapters (reducers, expanders)	14
General information	64
Vacuum resistance (lining)	70
Process error (empty pipe, meas. range exceeded)	51
Pulse output Electrical connection	21
Examples for electrical connection	22
Factory settings (pulse value)	68
Pulse value function	42
Technical data	61
Pumps (mounting location)	11
R	
Reapproval	35
Reference electrode	27
Remote versions FL version	18
FS version	18
Repairs	6, 57
Repeatability (accuracy)	62
Replacement of DAT module	56
Instrument fuse	57
Measuring electrodes	54
Transmitter electronics	56
Reset key (for error messages)	23
S	
Safety instructions	5
Screw tightening torque see Mounting (sensor)	
Seals (sensor) Materials	64
Promag F	15
Temperature ranges	64
Sensor mounting see Mounting	
Serial number	7, 8
Shock resistance	63
Signal on alarm see Error response	

SIP cleanable	65
Spare parts	57
Status output	
Electrical connection	21
Example for electrical connections	22
Functions	44
Technical data	61
Storage temperature	63
System error (instrument fault, supply failure)	51

T

Technical data	61
Temperature ranges	
Ambient temperature	63
Fluid temperature	64
Storage temperature	63
Time constant (current output)	42
Totalizer	
Connection of external totalizers	22
Display example	46
Overflow	46
Totalizer reset	
Via auxiliary input	45
Via reset key (auxiliary input)	23
Transmitter	
Connection cable length (remote version)	18
Electrical connection	20
Replacement of the electronics	56
Rotating the housing (4 x 90°)	17
Wall and post mounting	18
Transport of the sensor (from DN 350)	9
Trouble-shooting instructions	52

U

Unidirectional measurement (flow direction)	44
Unit selection	39

V

Vacuum resistance (lining)	70
Vibrational resistance	63
Vibrations	11, 63

W

Wall mounting (transmitter)	18
Weather cover	63
Weight	64

Europe

- Austria**
□ Endress+Hauser GmbH
Wien
Tel. (01) 88 05 60, Fax (01) 88 05 635
- Belarus**
Belorgsintez
Minsk
Tel. (0172) 26 31 66, Fax (0172) 26 31 11
- Belgium / Luxembourg**
□ Endress+Hauser S.A./N.V.
Bruxelles
Tel. (02) 2 48 06 00, Fax (02) 2 48 05 53
- Bulgaria**
INTERTECH-Automation
Sofia
Tel. (02) 62 48 34, Fax (02) 68 81 86
- Croatia**
□ Endress+Hauser GmbH+Co.
Zagreb
Tel. (01) 660 14 18, Fax (01) 660 14 18
- Cyprus**
I+G Electrical Services Co. Ltd.
Nicosia
Tel. (02) 48 47 88, Fax (02) 48 46 90
- Czech Republic**
□ Endress+Hauser GmbH+Co.
Praha
Tel. (02) 66 78 42 00, Fax (02) 66 78 41 79
- Denmark**
□ Endress+Hauser A/S
Søborg
Tel. 70 13 11 32, Fax 70 13 21 33
- Estonia**
Elvi-Aqua
Tartu
Tel. (7) 42 27 26, Fax (7) 42 27 27
- Finland**
□ Endress+Hauser Oy
Espoo
Tel. (9) 8 59 61 55, Fax (9) 8 59 60 55
- France**
□ Endress+Hauser S.A.
Huningue
Tel. (0389) 69 67 68, Fax (0389) 69 48 02
- Germany**
□ Endress+Hauser Messtechnik GmbH+Co.
Weil am Rhein
Tel. (07621) 9 75 01, Fax (07621) 9 75 55 5
- Greece**
I & G Building Services Automation S.A.
Athens
Tel. (01) 924 15 00, Fax (01) 922 17 14
- Hungary**
MILE Ipari-Elektro
Budapest
Tel. (01) 261 55 35, Fax (01) 261 55 35
- Iceland**
Vatnshreinsun HF
Reykjavik
Tel. (05) 61 96 16, Fax (05) 61 96 17
- Ireland**
Flomeaco Company Ltd.
Kildare
Tel. (045) 86 86 15, Fax (045) 86 81 82
- Italy**
□ Endress+Hauser S.p.A.
Cernusco s/N Milano
Tel. (02) 92 10 64 21, Fax (02) 92 10 71 53
- Latvia**
Raita Ltd.
Riga
Tel. (02) 25 47 95, Fax (02) 25 89 33
- Lithuania**
Agava Ltd.
Kaunas
Tel. (07) 20 24 10, Fax (07) 20 74 14
- Netherlands**
□ Endress+Hauser B.V.
Naarden
Tel. (035) 6 95 86 11, Fax (035) 6 95 88 25
- Norway**
□ Endress+Hauser A/S
Lierskogen
Tel. (032) 85 98 50, Fax (032) 85 98 51

- Poland**
□ Endress+Hauser Polska Sp. z o.o.
Warsaw
Tel. (022) 7 20 10 90, Fax (022) 7 20 10 85
- Portugal**
Tecnisis - Tecnica de Sistemas Industriais
Linda a Velha
Tel. (01) 4 17 26 37, Fax (01) 4 18 52 78
- Romania**
Romconseng S.R.L.
Bucharest
Tel. (01) 4 10 16 34, Fax (01) 4 10 16 34
- Russia**
□ Endress+Hauser GmbH+Co
Moscow
Tel. + Fax see E+H Instruments International
- Slovak Republic**
Transcom Technik s.r.o.
Bratislava
Tel. (07) 44 88 86 84, Fax (07) 44 88 71 12
- Slovenia**
□ Endress+Hauser D.O.O.
Ljubljana
Tel. (061) 1 59 22 17, Fax (061) 1 59 22 98

- Spain**
□ Endress+Hauser S.A.
Sant Just Desvern
Tel. (93) 4 80 33 66, Fax (93) 4 73 38 39
- Sweden**
□ Endress+Hauser AB
Sollentuna
Tel. (08) 6 26 16 00, Fax (08) 6 26 94 77
- Switzerland**
□ Endress+Hauser AG
Reinach/BL 1
Tel. (061) 7 15 62 22, Fax (061) 7 11 16 50
- Turkey**
Intek Endüstriyel Ölçü Ve Kontrol Sistemleri
Levent/Istanbul
Tel. (0212) 2 75 13 55, Fax (02 12) 2 66 27 75

- Ukraine**
Industria Ukraïna
Kiev
Tel. (44) 2 68 52 13, Fax (44) 2 68 52 13
- United Kingdom**
□ Endress+Hauser Ltd.
Manchester
Tel. (0161) 2 86 50 00, Fax (0161) 9 98 18 41
- Yugoslavia Republic**
Meris d.o.o.
Beograd
Tel. (11) 4 44 29 66, Fax (11) 4 30 04 3

Africa

- Egypt**
Anasia
Cairo
Tel. (02) 4 17 90 07, Fax (02) 4 17 90 08
- Morocco**
Oussama S.A.
Casablanca
Tel. (02) 24 13 38, Fax (02) 40 26 57
- Nigeria**
J F Technical Invest. Nig. Ltd.
Lagos
Tel. (1) 62 23 45 46, Fax (1) 62 23 45 48
- Rep. South Africa**
□ Endress+Hauser (Pty.) Ltd.
Sandton
Tel. (011) 4 44 13 86, Fax (011) 4 44 19 77
- Tunisia**
Controle, Maintenance et Regulation
Tunis
Tel. (01) 79 30 77, Fax (01) 78 85 95

America

- Argentina**
□ Endress+Hauser Argentina S.A.
Buenos Aires
Tel. (01) 5 22 79 70, Fax (01) 5 22 79 09
- Bolivia**
Tritec
Cochabamba
Tel. (042) 5 69 93, Fax (042) 5 09 81

- Brazil**
□ Samson Endress+Hauser Ltda.
Sao Paulo
Tel. (011) 5 36 34 55, Fax (011) 5 36 30 67
- Canada**
□ Endress+Hauser (Canada) Ltd.
Burlington / Ontario
Tel. (905) 6 81 92 92, Fax (905) 6 81 94 44
- Chile**
DIN Instrumentos Ltda.
Santiago
Tel. (02) 2 05 01 00, Fax (02) 2 25 81 39
- Colombia**
Colsein Ltd.
Bogota D.C.
Tel. (01) 2 36 76 59, Fax (01) 6 10 78 68

- Costa Rica**
EURO-TEC S.A.
San Jose
Tel. 2 96 15 42, Fax 2 96 15 42
- Ecuador**
INSETEC Cia. Ltda.
Quito
Tel. (02) 25 12 42, Fax (02) 46 18 33

- Guatemala**
ACISA Automatizacion y Control
Industrial S.A.
Guatemala
Tel. (03) 34 59 85, Fax (03) 32 74 31

- Mexico**
□ Endress+Hauser GmbH+Co.,
Instruments International, Mexico City Office,
Mexico City
Tel. (5) 5 68 96 58, Fax (5) 5 68 41 83

- Paraguay**
Incoel S.R.L.
Asuncion
Tel. (021) 21 39 89, Fax (021) 2 12 65 83

- Peru**
Esim S.A.
Lima
Tel. (1) 4 71 46 61, Fax (1) 4 71 09 93

- Uruguay**
Circular S.A.
Montevideo
Tel. (02) 92 57 85, Fax (02) 92 91 51

- USA**
□ Endress+Hauser Inc.
Greenwood, Indiana
Tel. (317) 5 35 71 38, Fax (317) 5 35 84 98

- Venezuela**
H. Z. Instrumentos C.A.
Caracas
Tel. (02) 9 79 88 13, Fax (02) 9 79 96 08

Asia

- Brunei**
American International Industries (B)
Sdn Bhd
Lorong Tengah
Tel. (3) 22 37 37, Fax (3) 22 54 58
- China**
□ Endress+Hauser Shanghai
Shanghai
Tel. (021) 64 64 67 00, Fax (021) 64 74 78 60
- Hong Kong**
□ Endress+Hauser (H.K.) Ltd.
Hong Kong
Tel. 25 28 31 20, Fax 28 65 41 71

- India**
□ Endress+Hauser India Branch Office
Mumbai
Tel. (022) 8 52 14 58, Fax (022) 8 52 19 27

- Indonesia**
PT Grama Bazita
Jakarta
Tel. (21) 7 97 50 83, Fax (21) 7 97 50 89

- Japan**
□ Sakura Endress Co. Ltd.
Tokyo
Tel. (0422) 54 06 11, Fax (0422) 55 02 75

- Malaysia**
□ Endress+Hauser (M) Sdn. Bhd.
Petaling Jaya, Selangor Darul Ehsan
Tel. (03) 7 33 48 48, Fax (03) 7 33 88 00

- Myanmar**
Sein Pyinsayupa Gen. Trading & Agency
Co-op. Soc. Ltd.
Myanmar
Tel. (1) 24 23 25, Fax (1) 25 05 94
- Pakistan**
Speedy Automation
Karachi
Tel. (021) 7 72 29 53, Fax (021) 7 73 68 84

- Papua-Neuguinea**
SBS Electrical Pty Ltd.
PNG Port Moresby
Tel. 3 25 11 88, Fax 3 25 95 56

- Philippines**
□ Endress+Hauser Philippines Inc.
Manila
Tel. (2) 6 38 80 41, Fax (2) 6 38 80 42

- Singapore**
□ Endress+Hauser (S.E.A.) Pte. Ltd.
Singapore
Tel. 5 66 82 22, Fax 5 66 68 48

- Korea**
□ Endress+Hauser (Korea) Co. Ltd.
Seoul
Tel. (02) 6 58 72 00, Fax (02) 6 59 28 38

- Taiwan**
Kingjarl Corporation
Taipei
Tel. (02) 27 18 39 38, Fax (02) 27 13 41 90

- Thailand**
□ Endress+Hauser (Thailand) Ltd.
Bangkok
Tel. (2) 9 96 78 11-20, Fax (2) 9 96 78 10

- Vietnam**
Tan Viet Bao Co. Ltd.
Ho Chi Minh City
Tel. (08) 8 33 52 25, Fax (08) 8 33 52 27

- Iran**
Telephone Technical Services Co. Ltd. (TTS)
Tehran
Tel. (021) 8 74 67 50, Fax (021) 8 73 72 95

- Israel**
Instrumetrics Industrial Control Ltd.
Tel Aviv
Tel. (03) 6 48 02 05, Fax (03) 6 47 19 92

- Jordan**
A.P. Parpas Engineering S.A.
Amman
Tel. (06) 5 53 92 83, Fax (06) 5 53 92 05

- Kuwait**
Kuwait Maritime & Mercantile Co. K.S.C.
Safat
Tel. 2 43 47 52, Fax 2 44 14 86

- Lebanon**
Network Engineering Co.
Jbeil
Tel. 3 25 40 51, Fax 9 94 40 80

- Sultanate of Oman**
Mustafa & Jawad Sience & Industry Co. LLC
Ruwi
Tel. 60 20 09, Fax 60 70 66

- United Arab Emirates**
Descon Trading Est.
Dubai
Tel. (04) 65 36 51, Fax (04) 65 32 64

- Yemen**
Yemen Company for Ghee and Soap Industry
Taiz
Tel. (04) 23 06 64, Fax (04) 21 23 38

Australia + New Zealand

- Australia**
ALSTOM Australia Ltd.
Villawood N.S.W.
Tel. (02) 97 22 47 77, Fax (02) 97 22 48 83

- New Zealand**
Electric Measurement+Control Ltd.
Auckland
Tel. (09) 4 44 92 29, Fax (09) 4 44 11 45

All other countries

- Endress+Hauser GmbH+Co.
Instruments International
Weil am Rhein, Germany
Tel. (07621) 9 75 02, Fax (07621) 9 75 34 5

