

DRAGON

Electric piston pump



This manual is to be considered as an English language translation of the original manual in Italian. The manufacturer shall bear no responsibility for any damages or inconveniences that may arise due to the incorrect translation of the instructions contained within the original manual in Italian.

Due to a constant product improvement programme, the factory reserves the right to modify technical details mentioned in this manual without prior notice.



DRAGON

Electric piston pump

INDEX

| | | |
|--------------------|---|----|
| A | WARNINGS | 2 |
| B | WORKING PRINCIPLE | 3 |
| C | TECHNICAL DATA | 4 |
| D | DESCRIPTION OF THE EQUIPMENT | 5 |
| E | TRANSPORT AND UNPACKING | 8 |
| F | CONDITIONS OF GUARANTEE | 9 |
| G | SAFETY RULES..... | 9 |
| H | SETTING-UP | 10 |
| I | WORKING | 14 |
| J | CLEANING AT THE END OF THE WORK | 17 |
| K | ROUTINE MAINTENANCE | 21 |
| L | PROBLEMS AND SOLUTIONS | 23 |
| M | CORRECT PROCEDURE OF DECOMPRESSION | 24 |
| N | REPLACEMENT OF THE PUMPING GROUP'S GASKETS..... | 25 |
| SPARE PARTS | | |
| O | COMPLETE ELECTRO-MECHANICAL UNIT | 32 |
| P | COMPLETE RIGID PUMPING ELEMENT | 34 |
| Q | COMPLETE SHORT PUMPING ELEMENT | 36 |
| R | COMPLETE LONG ELEMENT | 38 |
| S | BASIC HYDRAULIC BLOCK REF. 30400 | 40 |
| T | CIRCULATION SYSTEM UNIT | 42 |
| U | CARRIAGE..... | 43 |
| V | ELECTRICAL CONTROL - EXPLODED VIEW | 44 |
| W | LINER MACHINE TYPE | 45 |
| X | PETROL-POWERED DRAGON | 48 |
| Y | 100L TANK..... | 52 |
| Z | ELECTRIC MOTOR | 54 |
| AA | ELECTRICAL DIAGRAM..... | 55 |
| | DECLARATION OF CONFORMITY | 57 |

**WE ADVISE THE USE OF THIS EQUIPMENT ONLY BY PROFESSIONAL OPERATORS.
ONLY USE THIS MACHINE FOR USAGE SPECIFICALLY MENTIONED IN THIS MANUAL.**

Thank you for choosing a **LARIUS S.R.L.** product.
As well as the product purchased, you will receive a range of support services
enabling you to achieve the results desired, quickly and professionally.



A WARNINGS

The table below provides the meaning of the symbols used in this manual in relation to using, earthing, operating, maintaining, and repairing of this equipment.

| | |
|--|---|
| | <ul style="list-style-type: none"> • Read this operator's manual carefully before using the equipment. • An improper use of this machine can cause injuries to people or things. • Do not use this machine when under the influence of drugs or alcohol. • Do not modify the equipment under any circumstances. • Use products and solvents that are compatible with the various parts of the equipment, and read the manufacturer's warnings carefully. • See the Technical Details for the equipment given in the Manual. • Check the equipment for worn parts once a day. If any worn parts are found, replace them using ONLY original spare parts. • Keep children and animals away from work area. • Comply with all safety standards. |
| | <ul style="list-style-type: none"> • It indicates an accident risk or serious damage to equipment if this warning is not followed. |
| | <p>FIRE AND EXPLOSION HAZARD</p> |
| | <ul style="list-style-type: none"> • Solvent and paint fumes in work area can ignite or explode. • To help prevent fire and explosion: <ul style="list-style-type: none"> - Use equipment ONLY in well ventilated area. - Eliminate all ignition sources, such as pilot lights, cigarettes and plastic drop cloths (potential static arc). - Ground equipment and conductive objects. - Use only grounded hoses. • Do not use trichloroethane, methylene chloride, other halogenated hydrocarbon solvents or fluids containing such solvents in pressurized aluminium equipment. Such use can cause serious chemical reaction and equipment rupture, and result in death, serious injury, and property damage. • Do not form connections or switch light switches on or off if the air contains inflammable fumes. • If electrical shocks or discharges are encountered the operation being carried out using the equipment must be stopped immediately. • Keep a fire extinguisher at hand in the immediate vicinity of the work area. |
| | |
| | |
| | <ul style="list-style-type: none"> • It indicates wound and finger squashing risk due to movable parts in the equipment. • Keep away from moving parts. • Do not use the equipment without the proper protection. • Before any inspection or maintenance of the equipment, carry out the decompression procedure explained in this manual, and prevent any risk of the equipment starting unexpectedly. |
| | <ul style="list-style-type: none"> • Report any risk of chemical reaction or explosion if this warning has not been given. • (IF PROVIDED) There is a risk of injury or serious lesion related to contact with the jet from the spray gun. If this should occur, IMMEDIATELY contact a doctor, indicating the type of product injected. • (IF PROVIDED) Do not spray before the guard has been placed over the nozzle and the trigger on the spray gun. • (IF PROVIDED) Do not put your fingers in the spray gun nozzle. • Once work has been completed, before carrying out any maintenance, complete the decompression procedure. |
| | |
| | <ul style="list-style-type: none"> • It indicates important recommendations about disposal and recycling process of products in accordance with the environmental regulations. |
| | <ul style="list-style-type: none"> • Mark any clamps attached to earth cables. • Use ONLY 3-wire extension cords and grounded electrical outlets. • Before starting work make sure that the electrical system is grounded and that it complies with safety standards. • High-pressure fluid from gun, hose leaks, or ruptured components will pierce skin. • To help prevent injection, always: <ul style="list-style-type: none"> - (IF PROVIDED) Engage trigger lock when not spraying. - (IF PROVIDED) Do not put your hand over the spray tip. Do not stop or deflect leaks with your hand, body or other. - (IF PROVIDED) Do not point gun at anyone or at any part of the body. - (IF PROVIDED) Never spray without tip guard. - Do pressure relief if you stop spraying or being servicing sprayer and before any maintenance operations. - Do not use components rated less than sprayer Maximum Working Pressure. - Never allow children to use this unit - (IF PROVIDED) Brace yourself; gun may recoil when triggered. |
| | |
| | |
| | |
| | <p>If high pressure fluid pierces your skin, the injury might look like "just a cut", but it is a serious wound! Get immediate medical attention.</p> |
| | <ul style="list-style-type: none"> • It is obligatory to wear suitable clothing as gloves, goggles and face shield. • Wear clothing that complies with the safety standards in force in the country in which the equipment is used. • Do not wear bracelets, earrings, rings, chains, or anything else that may hinder the operator's work. • Do not wear clothing with wide sleeves, scarves, ties, or any other piece of clothing that could get tangled up in moving parts of the equipment during the work, inspection, or maintenance cycles. |
| | |
| | |
| | |



B WORKING PRINCIPLE

The **DRAGON** unit is defined “electric piston pump”. An electric piston pump is used for high pressure painting without air (from this process derives the term “airless”). The pump is controlled by an electric motor coupled with a reduction gear. A cam shaft and a connecting rod allow to obtain the reciprocating motion necessary to the working of the “pumping group” piston. The piston movement produces a “vacuum”.

The product is sucked, pushed towards the pump outlet and then sent to the gun through the flexible hose. An electronic device located next to the reduction box, is used to regulate and control the pressure of the material leaving the pump. When the pump reaches the set value, the motor stops and starts again when the value decreases. A safety valve avoiding overpressure, guarantees the total reliability of the equipment.



Fig. 1B

| Fields of application | Application materials | |
|--------------------------|---------------------------------------|-------------------------|
| Indoor | Top-coat plaster | Intumescent |
| Outdoor | Self-levelling plasters | Encapsulators |
| Industrial buildings | Fillers | Insulation |
| Industrial constructions | Stuccos | Water proofing |
| Redeveloping | Plasters | Elastomers |
| Roofing | Pre-mixed plasters (granulometry 0,0) | Epoxi resins Bitumen |

| COD. | MOTOR | HOSE | GUN |
|----------|-------|------|------------|
| 30182 | 110 V | | |
| K30182/1 | 110 V | • | Cod. 11134 |
| 30180/1 | 220 V | | |
| K30180/1 | 220 V | • | Cod. 11134 |



C TECHNICAL DATA

| | DRAGON |
|-----------------------|---------------|
| Version | Trolley |
| Max. delivery | 5 l/m |
| Max. working pressure | 220 bar |
| Motor power | 2,4 Kw |
| Voltage | 110 VAC |
| | 220 VAC |
| Weight | 66 Kg |
| Max. nozzle size | 0,037" Paint |
| | 0,039" Stucco |

| | DRAGON |
|-------------------------|-------------------|
| Power generation | 5 Kw single phase |
| Material outlet | 3/8" NPT-NPSM |
| Sound pressure level | ≤60 dB (A) |
| Length (A) | 560 mm |
| Width (B) | 945 mm |
| Height (C) | 1040 mm |
| Minimum encumbrance (D) | 790 mm |

PARTS OF THE PUMP IN CONTACT WITH THE MATERIAL:
Stainless Steel AISI 420B, PTFE; Aluminium, Galvanised steel




Fig. 1C

D DESCRIPTION OF THE EQUIPMENT




Fig. 1D

| Pos. | Description |
|------|---|
| 1 | Electric motor |
| 2 | Pressure transmitter |
| 3 | Pumping group |
| 4 | High pressure flexible pipe of compensation Ø3/8" |

| Pos. | Description |
|------|------------------------------|
| 5 | Recirculation tube |
| 6 | Recirculation - safety valve |
| 7 | Line filter (optional) |
| 8 | Earth cable |




Fig. 2D

| Pos. | Description |
|------|---------------------------|
| 9 | Suction filter |
| 10 | Pressure gauge |
| 11 | Airless manual gun AT 300 |
| 12 | Trigger safety clamp |

| Pos. | Description |
|------|--------------------------|
| 13 | Earth cable with clamp |
| 14 | Control equipment |
| 15 | ON/OFF switch |
| 16 | Flexible pipe connection |



ALARM MESSAGES

When the product to be applied is finished the pump “sucks air” and automatically switches to the minimum number of cycles. The alarm messages function is described on the area sign (6).

Each time key (8) is pushed, the messages are displayed on the screen (7).



When an alarm message has been indicated the machine has to be switched off and on again using switch (1).

Each time the machine is switched off, the condensers remain charged for about 5 minutes. To avoid risk of shock, when removing the electrical box wait until the condensers have discharged altogether.



Fig. 3D

| Pos. | Description |
|------|-------------------------------|
| 1 | ON/OFF switch |
| 2 | Work pressure adjustment knob |
| 3 | Maximum pressure |
| 4 | Minimum pressure |

| Pos. | Description |
|------|---|
| 5 | Material circulation and machine washing position |
| 6 | Alarms |
| 7 | Message screen |
| 8 | Function keys |

TABELLA FUNZIONI

| Function symbol | Type of function | Description of function |
|-----------------|------------------------|--|
| P | Working pressure (bar) | Indicates the real time pressure used during the work cycle |
| J | Motor current (A) | Indicates the real time amperage on the equipment's motor during the work cycle |
| Pd | Pressure setting (bar) | Indicates the pressure set before the work cycle begins |
| c | Dissipator temp. (°C) | Indicates the dissipator temperature (in degrees Centigrade) during the work cycle |
| h | Working hours (h) | Indicates the total number of hours the equipment has worked |

ALARM MESSAGE TABLE

| Alarm symbol | Type of alarm | Cause | Solution |
|--------------|--|--|---|
| F1 | Maximum current | The motor's current absorption is too high | Check the mechanical and hydraulic condition of the equipment. If necessary, take action |
| F2 | Dissipator temp. | The dissipator temperature is too high | Check that the dissipator surfaces are clean and that the dissipator is properly ventilated |
| F3 | Motor temp. | The motor temperature is too high | Check that the motor's heat dissipation surfaces are clean. Check that cooling ventilation is correct |
| F4 | Maximum voltage | The voltage is too high | Check the connection to the electrical line and reinstate the correct nominal voltage |
| F5 | Minimum voltage | The voltage is too low | Check the connection to the electrical line and reinstate the correct nominal voltage |
| F6 | Earth connection | The earth connection is disconnected or non-existent | Check the earth cable and, if necessary, replace it. Make sure that the machine is earthed |
| F7 | Pressure sensor missing | The pressure sensor is damaged or not fitted | Replace it |
| F8 | Automatic switch-off during circulation phase (15 minutes) | The equipment is in cleaning mode | Wait until the equipment has stopped completely before using it for a new job |

E TRANSPORT AND UNPACKING

- The packed parts should be handled as indicated in the symbols and markings on the outside of the packing.
- Before installing the equipment, ensure that the area to be used is large enough for such purposes, is properly lit and has a clean, smooth floor surface.
- The user is responsible for the operations of unloading and handling and should use the maximum care so as not to damage the individual parts or injure anyone. To perform the unloading operation, use only qualified and trained personnel (truck and crane operators, etc.) and also suitable hoisting equipment for the weight of the installation or its parts. Follow carefully all the safety rules. The personnel must be equipped with the necessary safety clothing.
- The manufacturer will not be responsible for the unloading operations and transport to the workplace of the machine.
- Check the packing is undamaged on receipt of the equipment. Unpack the machine and verify if there has been any damage due to transportation.

LIFTING POINTS

There are no precise lifting points for the machine in its entirety. In order to determine the most appropriate lifting points, refer to the geometric characteristics of the machine itself (*proceed as shown*).



Fig. 1E



In case of damage, call immediately LARIUS and the Shipping Agent. All the notices about possible damage or anomalies must arrive timely within 8 days at least from the date of receipt of the plant through Registered Letter to the Shipping Agent and to LARIUS.



The disposal of packaging materials is a customer's competence and must be performed in accordance with the regulations in force in the country where the plant is installed and used. It is nevertheless sound practice to recycle packaging materials in an environment-friendly manner as much as possible.

F CONDITIONS OF GUARANTEE



The conditions of guarantee do not apply in the following situations:

- improper washing and cleaning of components causing malfunction, wear or damage to the equipment or any of its parts;
- improper use of the equipment;
- use that does not conform with applicable national legislation;
- incorrect or faulty installation;
- modifications, interventions and maintenance that have not been authorised by the manufacturer;
- use of non-original spare parts or parts that do not correspond to the specific model;
- total or partial non-compliance with the instructions provided.

G SAFETY RULES



Read carefully and entirely the following instructions before using the product. Please save these instructions in a safe place.



The unauthorised tampering/replacement of one or more parts composing the machine, the use of accessories, tools, expendable materials other than those recommended by the manufacturer can be a danger of accident.



The manufacturer will be relieved from tort and criminal liability.

- THE EMPLOYER SHALL TRAIN ITS EMPLOYEES ABOUT ALL THOSE RISKS STEMMING FROM ACCIDENTS, ABOUT THE USE OF SAFETY DEVICES FOR THEIR OWN SAFETY AND ABOUT THE GENERAL RULES FOR ACCIDENT PREVENTION IN COMPLIANCE WITH INTERNATIONAL REGULATIONS AND WITH THE LAWS OF THE COUNTRY WHERE THE PLANT IS USED.

- THE BEHAVIOUR OF THE EMPLOYEES SHALL STRICTLY COMPLY WITH THE ACCIDENT PREVENTION AND ALSO ENVIRONMENTAL REGULATIONS IN FORCE IN THE COUNTRY WHERE THE PLANT IS INSTALLED AND USED.
- KEEP YOUR WORK PLACE CLEAN AND TIDY. DISORDER WHERE YOU ARE WORKING CREATES A POTENTIAL RISK OF ACCIDENTS.
- ALWAYS KEEP PROPER BALANCE AVOIDING UNUSUAL STANCE.
- BEFORE USING THE TOOL, ENSURE THERE ARE NOT DAMAGED PARTS AND THE MACHINE CAN WORK PROPERLY.
- ALWAYS FOLLOW THE INSTRUCTIONS ABOUT SAFETY AND THE REGULATIONS IN FORCE.
- KEEP THOSE WHO ARE NOT RESPONSIBLE FOR THE EQUIPMENT OUT OF THE WORK AREA.
- **NEVER** EXCEED THE MAXIMUM WORKING PRESSURE INDICATED.
- (IF PROVIDED) **NEVER** POINT THE SPRAY GUN AT YOURSELVES OR AT OTHER PEOPLE. THE CONTACT WITH THE CASTING CAN CAUSE SERIOUS INJURIES.
- IN CASE OF INJURIES CAUSED BY THE GUN CASTING, SEEK IMMEDIATE MEDICAL ADVICE SPECIFYING THE TYPE OF THE PRODUCT INJECTED. **NEVER** UNDERVALUE A WOUND CAUSED BY THE INJECTION OF A FLUID.
- ALWAYS DISCONNECT THE SUPPLY AND RELEASE THE PRESSURE IN THE CIRCUIT BEFORE PERFORMING ANY CHECK OR PART REPLACEMENT OF THE EQUIPMENT.
- NEVER MODIFY ANY PART IN THE EQUIPMENT. CHECK REGULARLY THE COMPONENTS OF THE SYSTEM. REPLACE THE PARTS DAMAGED OR WORN.
- (IF PROVIDED) TIGHTEN AND CHECK ALL THE FITTINGS FOR CONNECTION BETWEEN PUMP, FLEXIBLE HOSE AND SPRAY GUN BEFORE USING THE EQUIPMENT.
- ALWAYS USE THE FLEXIBLE HOSE SUPPLIED WITH STANDARD KIT.
- THE USE OF ANY ACCESSORIES OR TOOLING OTHER THAN THOSE RECOMMENDED IN THIS MANUAL, MAY CAUSE DAMAGE OR INJURE THE OPERATOR.
- THE FLUID CONTAINED IN THE FLEXIBLE HOSE CAN BE VERY DANGEROUS. HANDLE THE FLEXIBLE HOSE CAREFULLY. DO NOT PULL THE FLEXIBLE HOSE TO MOVE THE EQUIPMENT. NEVER USE A DAMAGED OR A REPAIRED FLEXIBLE HOSE.



The high speed of travel of the product in the hose can create static electricity through discharges and sparks. It is suggested to earth the equipment. The pump is earthed through the earth cable of the supply.



The gun is earthed through the high pressure flexible hose. All the conductors near the work area must be earthed.

Never spray over flammable products or solvents in closed places.



Never use the tooling in presence of potentially explosive gas.



Always check that the product is compatible with the materials composing the equipment (*pump, spray gun, flexible hose and accessories*) with which it can come into contact. Never use paints or solvents containing Halogen Hydrocarbons (as the *Methylene Chloride*). If these products come into contact with aluminium parts can provoke dangerous chemical reactions with risk of corrosion and explosion.



Avoid approaching too much to the pump piston rod when the pump is working or under pressure. A sudden movement of the piston rod can cause wounds or finger squashing.



ELECTRICAL SAFETY PRECAUTIONS

- Check the switch is on the "OFF" position before connecting the cable to the mains.
- Never carry a plugged-in equipment.
- Disconnect the equipment before storing it and before performing any maintenance operation or replacing of accessories.
- Do not carry the equipment neither unplug it by pulling the electric cable.
- Protect the cable from heat, oil and sharp edges.
- When the tool is used outdoors, use only an extension cable suited for outdoor use and so marked.



Never attempt to tamper with the calibre of instruments.

- Take care when the pumping rod is moving. Stop the machine whenever someone is within its vicinity.
- Repairs of the electrical equipment should only be carried out by skilled personnel, otherwise considerable danger to the user may result.

H SETTING-UP

CONNECTION OF THE FLEXIBLE HOSE TO THE GUN

- Connect the high pressure flexible hose (H1) to the pump (H2) and to the gun (H3), ensuring to tighten the fittings (*the use of two wrenches is suggested*). **NEVER** use sealants on fittings' threads. It is **ADVISED** to mount a high pressure manometer at the pump outlet (*see on page "Accessories"*) to read the product pressure.
- It is recommended to use the hose provided with the standard kit (ref. 18036). **NEVER** use a damaged or a repaired flexible hose.



Fig. 1H

CHECK ON POWER SUPPLY



Make sure that the electrical system is earthed and complies with regulations.




Fig. 2H

- Check the mains voltage corresponds to the equipment's rating.
- The supply cable is provided without plug. Use a plug which guarantees the plant earthing. Only a technician or a skilled person should perform the connection of the plug to the electric cable.





Fig. 3H

 Should anyone use an extension cable between the tooling and the socket, it must have the same characteristics as the cable supplied (*minimum diameter of the wire 4 mm²*) with a maximum length of 50 mt. Higher lengths and lower diameters can provoke excessive voltage falls and also an anomalous working of the equipment.

DRAGON equipment is fitted with an additional external earth cable that is connected to the stem on the pump unit by means of a specific clamp (H4), in order to protect the operator against any risk of static or electric shock.






Fig. 4H

To avoid electric shock when disassembling or checking the electronic equipment, wait 5 minutes after having disconnected the power supply cable, so that the electricity stored in the condensers while working can be dissipated.

Also check the condition of the earth cable to avoid any risk of shock.


 Before carrying out any checks on the machine (*maintenance, cleaning, or replacing parts*) switch off the machine and wait until it has stopped altogether.


 While checking stay away from electrical or moving parts to avoid any risk of shock or crushing of hands.

WARNING :

- **DO NOT** modify the plug for the earth socket in any way.
- **ONLY** use electrical connections that are earthed.
- Make sure that any earth extension cords are in good condition.
- **ONLY** use three-core extension cables.
- Avoid direct contact with the rain. Keep the equipment in a dry place.

CONNECTION OF THE TOOLING TO THE POWER SUPPLY

 Before connection up the power supply to the equipment, make sure that the electrical system is earthed and complies with regulations.

 Make sure that the clamp (H4) provided is positioned correctly, in order to earth the pump unit in the equipment properly.

- Check the switch (H5) is on the “OFF” (0) position before connecting the cable to the mains.
- Place the pressure control knob (H6) on the “MIN” position (turn counterclockwise).




Fig. 5H

WASHING OF THE NEW EQUIPMENT

- The equipment has already been adjusted at our factory with light mineral oil left inside the pumping group as protection. Therefore, wash with diluent before sucking the product.

- Lift the suction unit and immerse it in the bucket that contains the washing liquid.
- Connect the clamp to an earthing point.



Fig. 6H

- Ensure the gun is without nozzle (H3).



Fig. 7H

- Press the switch (H5) of the equipment “ON” (I).



Fig. 8H

- Turn the pressure setting knob (H6) clockwise to the “CIRCULATION & WASHING” position (drop symbol).




Fig. 9H



Hold the spray gun against the edge of the metal contained (H7).

- Point the spray gun into the collection container (H7) and hold the trigger down (in order to expel the oil contained) until clean liquid flows out. Now, release the trigger.



Use a metal container (H7). To avoid any risk of electric shock connect the collection container to a surface that is earthed (e.g. concrete) and not to surfaces that will insulate the container from the earth.



- Remove the suction hose and remove the bucket of cleaning liquid.
- Now point the spray gun (H8) into the container (H7) and press the trigger to recover any cleaning liquid left.
- As the pump idles, press the “OFF” (0) switch (H5) to stop the tooling. When this is complete, release the trigger.



Fig. 10H



Absolutely avoid to spray solvents indoors. In addition, it is recommended to keep away from the pump in order to avoid the contact between the solvent fumes and the electric motor.



For disposing of the washing liquid, see the requirements laid down in the Standards in force in the country in which the equipment is used and act accordingly.

The Client is solely responsible for any irregular action taken before, during, or after disposing of washing liquid, or in interpreting and applying the current Standards in this regard.

- Now the machine is ready. When water-based paint has been used, in addition to washing using the cleaning liquid, we recommend washing with soapy water and then clean water.

PREPARING THE PRODUCT



MAKE SURE THE PRODUCT IS SUITABLE TO BE USED WITH AN AIRLESS SPRAY GUN.

- Mix and filter the product before using it.



Make sure the product to be used is compatible with the materials employed for manufacturing the equipment (stainless steel and aluminium). Because of that, please contact the supplier of the product.



Never use products containing halogen hydrocarbons (as *methylene chloride*). If these products come into contact with aluminium parts of the equipment, can provoke dangerous chemical reactions with risk of explosion.



REMOVE THE FILTER (H9) FOR DENSE PRODUCTS.



Fig. 11H

I WORKING

START OF THE WORKING OPERATIONS



Make sure that the electrical system is earthed and complies with regulations.
Make sure that the earth clamp is positioned correctly to ensure a safe earth on the pump unit.

- Use the tooling after performing all the **SETTING UP** operations above described.
- Dip the suction pipe (**I1**) into the product tank.



Fig. 11

- Open the recirculation - safety valve (12).



Fig. 21

- Press the switch (13) of the equipment "ON" (1).




Fig. 31

- Turn the pressure setting knob (14) clockwise to the "CIRCULATION & WASHING" position (drop symbol).




Fig. 41

- Make sure that the product circulates regularly from the circulation hose (15).
- Close the recirculation - safety valve (12).




Fig. 51

- The machine continues to suck up product until it has filled the hose as far as the spray gun, after which it will automatically stop when the set pressure is reached.



SPRAY ADJUSTMENT

- Slowly turn clockwise the pressure control knob (14) to reach the pressure value in order to ensure a good atomization of the product.



Fig. 6l

- An irregular and marked spray on the sides indicates a low working pressure. On the contrary, a too high pressure causes a high fog (“overspray”) and waste of product.
- In order to avoid overthickness of paint, let the gun advance sideways (*right-left*) when spraying.
- Always paint with regular parallel bands coats.
- Keep a safety and constant distance between the gun and the support to be painted and also keep yourselves perpendicular to it.

NEVER point the spray gun at yourselves or at other people. The contact with the casting can cause serious injuries.

In case of injuries caused by the gun casting, seek immediate medical advice specifying the type of the product injected.

Safety valve: when working at the maximum pressure available, releasing the gun trigger sudden increases of pressure can occur. In this case, the safety valve (15) opens automatically eliminating part of the product from the recirculating tube (16). Then it closes so as to go back to the first working conditions.

The valve (15) serves two purposes:

- Safety: It opens the passage at pressure peaks exceeding 280-300 bar;
- Regulation: It returns the working pressure to 230 bar and levels out the hydraulic operating hysteresis.



Fig. 7l

J CLEANING AT THE END OF THE WORK

CLEANING FOR SOLVENT-BASED PRODUCTS



Make sure that the electrical system is earthed and complies with regulations.

- Reduce pressure to the minimum (turn counterclockwise the pressure control knob (J1)).
- Press the switch (J2) "OFF (0)" placed on the box of the electric motor, to stop the equipment.



Fig. 1J

- Hold the spray gun trigger down.
- Open the recirculation - safety valve (J3) to release the pressure in the circuit.



Fig. 2J

- Lift the suction hose and replace the bucket containing the product with a bucket of cleaning liquid (make sure it is compatible with the product you are using).
- Unscrew the nozzle on the spray gun (remember to clean it with cleaning liquid).
- Press the switch (J2) "ON" (I) of the equipment.



Fig. 3J

- Turn the pressure setting knob (J1) clockwise to the “CIRCULATION & WASHING” position (drop symbol).
- Close the recirculation - safety valve (J3).





Fig. 4J

- Make sure that the product circulates through the circulation hose.

 Make sure that the machine sucks in clean washing liquid. Allow the cleaning liquid to discharge into another container and do not mix it with the cleaning liquid still to be used. We recommend circulating the cleaning liquid for at least 15 minutes.




 For disposing of the washing liquid, see the requirements laid down in the Standards in force in the country in which the equipment is used and act accordingly. The Client is solely responsible for any irregular action taken before, during, or after disposing of washing liquid, or in interpreting and applying the current Standards in this regard.




Fig. 5J

- Point the spray gun (J4) into the container (J5) used to collect the cleaning liquid and hold the trigger down to expel any product remaining, until clean liquid flows out. Now, release the trigger.

 Hold the spray gun against the edge of the metal contained (J5).

 Use a metal container (J5). To avoid any risk of electric shock connect the collection container to a surface that is earthed (e.g. concrete) and not to surfaces that will insulate the container from the earth.






Fig. 6J

- Lift the suction hose and remove the bucket of cleaning liquid.
- Now point the spray gun (J4) into the container (J5) and press the trigger to recover any cleaning liquid left.




Fig. 7J

- As the pump idles, press the “OFF” (0) switch (J2) to stop the tooling.




Fig. 8J

- In case of long storage, we recommend you to suck and to leave light mineral oil inside the pumping group and the flexible hose.



Follow the washing procedure before using again the equipment.

- Take the cleaning liquid and store it in suitable containers.



Make sure that the machine sucks in clean washing liquid. Allow the cleaning liquid to discharge into another container and do not mix it with the cleaning liquid still to be used. We recommend circulating the cleaning liquid for at least 15 minutes.

CLEANING FOR WATER-BASED PRODUCTS



Make sure that the electrical system is earthed and complies with regulations.

- Reduce pressure to the minimum (turn counterclockwise the pressure control knob (J1)).



Fig. 9J

- Press the switch (J2) “OFF (0)” placed on the box of the electric motor, to stop the equipment.




Fig. 10J

- Hold the spray gun trigger down.
- Open the circulation - safety valve (J3) to discharge the pressure in the circuit.



Fig. 11J

- Lift the suction hose and replace the bucket of product with an empty bucket (J6).
- Connect a rubber hose (J7) to a water tap (J8) and fill the bucket (J6).
- Position an empty bucket to collect the water (J9) under the circulation hose (J10).



Fig. 12J

- Press the switch (J2) su ON (I) and turn a little the pressure control knob (J1) clockwise so as the machine works till the motor starts.




Fig. 13J

- Run the pump's washing cycle until clean water flows out of the circulation hose (J10).
- Close the recirculation - safety valve (J3).



Fig. 14J

- Remove the suction hose and the rubber hose (J7) and take away the bucket of water (J6).
- Now point the spray gun (J4) into the container (J5) and press the trigger to recover any cleaning liquid left.



Fig. 15J

- As the pump idles, press the "OFF" (0) switch (J2) to stop the tooling.




Fig. 16J

- In case of long storage, we recommend you to suck and to leave light mineral oil inside the pumping group and the flexible hose.



Follow the washing procedure before using again the equipment.



If the equipment is to be stopped for a lengthy period of time, carry out the cleaning operations described previously, according to the type of product used. In case of short stoppages, suck in some water and leave the pump unit in the bucket (J6) for a few minutes.

K ROUTINE MAINTENANCE

CHECK ON THE PACKING NUT

The gaskets do not need adjusting. The ring nut is only used to fit and remove gaskets and for topping up the oil.



Always disconnect the electrical supply and discharge the pressure in the pump unit (*open the discharge valve*) before carrying out any maintenance.

Wait 30 seconds before proceeding with maintenance operations to allow any residual electricity to be discharged.

- Use the lubricant (K1) provided (*ref. 16340*) to make it easier to slide the piston inside the seal pack and to substitute the air with oil.



At the start of each working day check that the ring nut is full of hydraulic oil (Ref. 16340). This oil makes it easier for the piston to slide and prevents any material that escapes via the seal gasket drying when the equipment is stopped.



Fig. 1K



- The ring nut (**K2**) must be tightened all the way. Every 100 working hours, with the pressure at 0 bar, check that it is tightened all the way.
- The supplied pin (**K3** - ref. 20144) also serves the purpose of closing and opening the pump unit's locking ring-nut (**K4**). This ring nut must always be closed in order to act as a locking counter-nut.




Fig. 2K

CHECKING THE HEAT EXCHANGE RADIATOR

Always keep the heat exchange radiator (**K5**) on the electronic control box clean, in order to guarantee correct heat exchange with the ambient air.

We suggest cleaning using a jet of compressed air.




Fig. 3K

PRESSURE SWITCH SEAL CHECK

Check that no material is escaping from the safety hole (**K6**) at the bottom of the protective container.

If necessary, replace the O-Ring for the pressure sensor (**K7**).




Fig. 4K




Fig. 5K



L PROBLEMS AND SOLUTIONS

| Problem | Cause | Solution |
|--|--|---|
| The equipment does not start | Lack of voltage; | Check the correct connection to the power supply; |
| | Considerable drops in mains voltage; | Check the extension cable; |
| | On/Off switch disconnected; | Ensure the On/Off switch is on the “on” position and turn clockwise the pressure control knob; |
| | Breakdown of pressure transmitter; | Verify and replace it, if necessary; |
| | Breakdown of motor electric control box; | Verify and replace it, if necessary; |
| | The line of material coming out of the pump is already under pressure; | Open the drain valve to release pressure in the circuit; |
| | The product is solidified inside the pump; | Open the drain valve to release pressure in the circuit and stop the machine. Disassemble the pumping group and the pressure transmitter and clean; |
| The equipment does not suck the product | Suction filter clogged; | Clean or replace it; |
| | Suction filter too fine; | Replace it with a larger-mesh filter (with very dense products, remove the filter); |
| | The equipment sucks air; | Check the suction pipe; |
| The equipment sucks but does not reach the pressure desired | Lack of product; | Add the product; |
| | The equipment sucks air; | Check the suction pipe; |
| | The drain valve is open; | Close the drain valve; |
| | The gaskets of the pumping group are worn; | Replace the gaskets; |
| | Suction or delivery valve dirty; | Disassemble the pumping group; |
| When pressing the trigger, the pressure lowers considerably | Nozzle too big or worn; | Replace it with a smaller one; |
| | The product is too dense; | Dilute the product, if possible; |
| | The filter of the gun-but is too fine; | Replace it with a larger-mesh filter; |
| The pressure is normal but the product is not atomized | The nozzle is partially clogged; | Clean or replace it; |
| | The product is too dense; | Dilute the product, if possible; |
| | The filter of the gun-but is too fine; | Replace it with a larger-mesh filter; |
| The atomization is imperfect | The nozzle is worn; | Replace it; |



| Problem | Cause | Solution |
|--|--|--|
| When releasing the trigger of the gun, the equipment does not stop (the motor runs slowly and the piston rod keeps on going up and down) | The gaskets of the pumping group are worn; | Replace the gaskets; |
| | Suction or delivery valve dirty; | Disassemble the pumping group and clean; |
| | Drain valve defective; | Verify and replace it, if necessary; |
| Material escaping from the cap | Material leaking from the O-Ring. | Replace the O-Ring. |



Always close the air compressed supply and unload the plant pressure before performing any check or replacement of pump parts (see "correct procedure of decompression").

M CORRECT PROCEDURE OF DECOMPRESSION



Make sure that the electrical system is earthed and complies with regulations.

- Zero the pressure regulator knob.
- Move the switch (M1) to the OFF (0) position to stop the equipment.




Fig. 1M

- Open the circulation - safety valve (M2) to discharge the residual pressure, always turning it anticlockwise.



Fig. 2M

- Point the gun at the tank (M3) of the product and press the trigger to release pressure. At the end of the operation, insert the gun clamp (M4).



Fig. 3M




Fig. 4M



WARNING :

If the equipment is still under pressure after performing the operations above described because of the nozzle or the flexible hose clogged, proceed as follows:

- Loosen very slowly the gun nozzle.
- Release the clamp.
- Point the gun at the container of the product and press the trigger to release pressure.
- Loosen very slowly the fitting of connection from the flexible hose to the gun.
- Clean or replace the flexible hose and the nozzle.

N REPLACEMENT OF THE PUMPING GROUP'S GASKETS

Each time you use the machine, check for material leaking from the top of the ring nut.

If any material leaks out when the pump is working at the set pressure, proceed as follows:

- Carry out this operation after cleaning the tooling.



Always disconnect the power supply and release pressure before going on with the operations (follow the "correct procedure of decompression").



The gaskets are self-adjusting. If a leak occurs they must be replaced.

- Disconnect the product feed hose (N1) from the pump unit by unscrewing the nut (N2).
- Unscrew the fixing ring nut (N3) using the relevant closing pin (Ref. 20144).




Fig. 1N

- Release the plastic cover (N4).




Fig. 2N

- Turn the motor (N6) with a screwdriver (N5) until the piston rod has moved to the lowest point of its stroke.




Fig. 3N

- Screw the appropriate supplied tool (N7 – ref- 20213) into the threaded hole on the holding pin (N8).




Fig. 4N

- Remove the pin (L8) from its seating.



Fig. 5N

- Unscrew the pump unit (N9) from the frontal flange (N10).



Fig. 6N

PIT STOP MAINTENANCE

Replacement of upper and lower gaskets 20 minutes.

- Lock the pump unit into a vice and unscrew it with a 50mm wrench;
- Release the pump unit from the body of the suction valve;




Fig. 7N

Lower seal

- Remove the piston stem (N11) and remove the pump unit sleeve (N12);




Fig. 8N

- Grip the stem valve (N13) in a vice;



Fig. 9N

- Use a size 24 spanner to unscrew the lower stem (N14);




Fig. 10N

- Use a screwdriver to remove the two open-ring guide bands (N15) and replace them;




Fig. 11N




Fig. 12N

- Unscrew the stem valve (N16) altogether, check the surface of the ball seating (N17) that comes into contact with the ball (N18). If worn, replace them;



Fig. 13N

- Use a screwdriver to remove the O-Ring (N19) and replace it making sure it is aligned correctly (as illustrated);



Fig. 14N

- Screw the valve stem (N16) (Ref. 20139) on again and tighten fully, gripping the valve in a vice. To tighten, use a 22 mm spanner; the use of a thread paste is recommended;




Fig. 15N

Upper seal

- Remove the ring nut (N20);




Fig. 16N

- Remove the ring (N21);



Fig. 17N

- Remove the guide band (N22) with a screwdriver and replace it with a new one;



Fig. 18N

- Remove the seal (N23) with a screwdriver;



Fig. 19N

- Using a screwdriver, remove the second band (N24) located below the seal (N23) and insert a new band in the same position;



Fig. 20N



The positioning of the seal (N23) requires special care during assembly.

- Assist insertion by applying leverage to the outside of the ring (N23), pushing from the outside inwards and helping the ring to lodge in the seating, while being careful not to damage the ring's contact surfaces.



Lubricate with grease before fitting.



Fig. 21N

- Remove the OR (N25-N26-N28) from the body of the foot valve (N29) and from the ball seat holder (N27) and, if necessary, replace them. Reassemble the components in their proper order (as indicated in the diagram);




Fig. 22N



To facilitate fitting the O-ring (N28) it is advisable to warm it slightly with a blast of hot air.



Fig. 23N



The ball seating (N17) is countersunk on one side, where the ball (N18) must sit.

- Screw the locking ring nut (N20) back onto the body of the pump unit until it makes contact, then loosen it by one turn;



Fig. 24N

- Remove the sleeve/cylinder seal (N30) and replace it with a new one;



Fig. 25N

- Check the wear status of the surfaces inside the jacket. Replace it if necessary;
- Grease the sleeve (N31) using a paintbrush;




Fig. 26N

- Insert the sleeve (N31) into the lower pump unit (N32);



Fig. 27N



Insert the complete piston stem (N33) after greasing the gaskets (N34);




Fig. 28N



- Screw on the complete foot valve (N29) with the sleeve assembly (N30);



In order to guarantee a proper seal, tighten the foot valve (N29) fully, using a 50 mm spanner.




Fig. 29N

- When refitting the pump unit on the machine, the stem must be at its highest point possible.
- Insert the stem into the connecting rod and insert the fixing pin (N8).




Fig. 30N

- Tighten the pump casing all the way and, if the delivery pipe is not correctly aligned, unscrew the pump casing until the connection is in the correct position before tightening by using the ring nut (N35) and the pin (N36) supplied (Ref. 20144).



Fig. 31N

- Close the seal ring nut (N37) all the way.



Fig. 32N

- Lubricate the upper crown (N38) using oil (N39) (Ref. 16340);



Fig. 33N

- Refit the inspection barrier (N40);




Fig. 34N


- To assemble all the parts in the correct sequence, see the exploded diagram on page 34.

SPARE PARTS

Z Electric motor
pag. 54



O Complete electro-mechanical Unit
Page 32



S Basic hydraulic block
ref. 30400
Page 40



V Electrical control - exploded view
Page 44





W Liner type machines
Page 45


X Petrol-powered
Dragon Page 48

Y Tank 100L
Page 52


U Carriage
page 43




P Complete rigid pumping element
Page 34



Q Complete short pumping element
Page 36



R Complete long pumping element
Page 38



T Circulation system unit
Page 42





0 COMPLETE ELECTRO-MECHANICAL UNIT




Fig. 10

| Pos. | Code | Description | Q. ty |
|------|-------|---|-------|
| | 30200 | Complete electromechanical unit model 220V 50Hz | 1 |
| | 30199 | Complete electromechanical unit model 110V 60Hz | 1 |
| 1 | 30242 | Electric motor 110V 50Hz | 1 |
| | 30241 | Electric motor 220V 60Hz | 1 |
| 2 | 30669 | Screws | 4 |
| 3 | 34009 | Washer | 9 |
| 4 | 20250 | Bearing | 2 |
| 5 | 20253 | Roller bearing | 2 |
| 6 | 30254 | Thrust bearing | 2 |
| 7 | 30257 | Roller bearing | 2 |
| 8 | 30271 | Screw | 2 |
| 9 | 20258 | Toothed driving assembly | 1 |
| 10 | 30259 | Cam assembly | 1 |
| 11 | 30262 | Complete connecting rod | 1 |
| 12 | 30263 | Positioning spring | 1 |
| 13 | 30210 | Pump unit pivot | 1 |
| 14 | 20264 | Centring pin | 2 |
| 15 | 30665 | Guide bushing | 1 |
| 16 | 30266 | Scraper | 1 |
| 17 | 5378 | Screw | 2 |

| Pos. | Code | Description | Q. ty |
|------|---------|----------------------|-------|
| 18 | 30211 | Inspection hatch | 1 |
| 19 | 30212 | Tin plate door | 1 |
| 20 | 69011 | Screw | 2 |
| 21 | 30202 | Reduction unit cover | 1 |
| 22 | 30267 | Cover assembly | 1 |
| 23 | 30270 | Eyebolt | 1 |
| 24 | 30214 | Fixing ring | 1 |
| 25 | 30215 | Front sticker | 1 |
| 26 | 34020 | Rivet | 6 |
| 27 | 82005/3 | Rubber washer | 1 |
| 28 | 20245 | Screws | 2 |
| 29 | 30245 | Screws | 4 |
| 30 | 96211 | Screws | 1 |
| 31 | 30271 | Warning label | 1 |
| 32 | 30216 | Protection plate | 1 |
| 33 | 8385 | Screws | 1 |
| 34 | 18478 | Threaded spacer | 1 |
| 35 | 18479 | Plate spacer | 1 |
| 36 | 30666 | Tightening ring | 1 |
| 37 | 30345 | Screw | 1 |
| 38 | 30225 | Fixing ring | 1 |
| 39 | 20278 | Pin | 1 |

| Pos. | Code | Description | Q. ty |
|------|-------|----------------------|-------|
| 4 | 30250 | Bearing | 2 |
| 5 | | Roller bearing | 2 |
| 6 | | Thrust bearing | 2 |
| 7 | | Roller bearing | 2 |
| 15 | | Guide bushing | 1 |
| 16 | | Scraper | 1 |
| 17 | | Screw | 2 |
| 21 | | Reduction unit cover | 1 |
| 25 | | Front sticker | 1 |
| 26 | | Rivet | 6 |
| 38 | | Fixing ring | 1 |




Fig. 20

P COMPLETE RIGID PUMPING ELEMENT

WARNING: Always indicate code and quantity for each part required.




Fig. 1P



| Pos. | Code | Description | Q. ty |
|------|-------|--------------------------------|-------|
| 1 | 30190 | Complete rigid pumping element | 1 |
| 2 | 30113 | Stuffing nut | 1 |
| 3 | 30114 | Tightening ring nut | 1 |
| 4 | 30138 | Upper guide band | 1 |
| 5 | 30139 | Upper gasket | 1 |
| 6 | 30142 | Upper guide band | 1 |
| 7 | 30112 | Upper pump unit casing | 1 |
| 8 | 95230 | Adapter | 1 |
| 9 | 30109 | Sleeve-cylinder seal | 1 |
| 10 | 30120 | Sleeve | 1 |
| 11 | 30107 | Upper stem | 1 |
| 12 | 18482 | O-Ring | 1 |
| 13 | 30121 | Short stem | 1 |
| 14 | 30165 | Lower seal bands | 2 |
| 15 | 30166 | Lower gasket | 1 |
| 16 | 16120 | Ball | 1 |
| 17 | 30158 | Stem valve assembly | 1 |
| 18 | 30132 | OR | 2 |
| 19 | 30144 | OR | 1 |

| Pos. | Code | Description | Q. ty |
|------|-------|--|-------|
| 20 | 30273 | Ball guide | 1 |
| | 30273 | Ball guide - vers. with 7/8" ball | 1 |
| 21 | 20148 | Closing ball | 1 |
| | 20148 | Closing ball - vers. with 7/8" ball | 1 |
| 22 | 30131 | Ball seat holder | 1 |
| | 65150 | Ball seat holder - vers. with 7/8" ball | 1 |
| 24 | 30155 | Assembled valve | 1 |
| | 30130 | Assembled valve - vers. with 7/8" ball | 1 |
| 25 | 30672 | Suction connector for solvent-based paint | 1 |
| 26 | 30673 | Rigid suction tube for solvent-based paint | 1 |
| 27 | 37216 | Suction filter for solvent-based paint | 1 |
| 28 | 30147 | Jacket unit | - |
| 29 | 30137 | Rod unit | - |
| 30 | 30249 | Suction kit for solvent-based paint | - |
| 31 | 30243 | Suction connector for water-based paint | - |
| 32 | 30244 | Rigid suction tube for water-based paint | 1 |
| 33 | 20101 | Suction filter for water-based paint | 1 |
| 34 | 30248 | Suction kit for water-based paint | 1 |
| 35 | 30122 | Ring | - |

**KIT COMPLETE PUMP REPAIR
 COD. 40108**

| Pos. | Description |
|------|----------------------|
| 4 | Upper guide band |
| 5 | Upper gasket |
| 6 | Upper guide band |
| 9 | Sleeve-cylinder seal |
| 10 | Sleeve |
| 11 | Upper stem |
| 12 | O-Ring |
| 14 | Lower seal bands |
| 15 | Lower gasket |
| 16 | Ball |
| 17 | Stem valve assembly |
| 18 | OR |
| 19 | OR |
| 21 | Closing ball |
| 22 | Ball seat holder |

**KIT COMPLETE GASKET
 COD. 30173**

| Pos. | Description |
|------|----------------------|
| 4 | Upper guide band |
| 5 | Upper gasket |
| 6 | Upper guide band |
| 9 | Sleeve-cylinder seal |
| 14 | Lower seal bands |
| 15 | Lower gasket |
| 16 | Ball |
| 17 | Stem valve assembly |
| 18 | OR |
| 19 | OR |
| 21 | Closing ball |
| 22 | Ball seat holder |

**KIT LOWER AND UPPER
 GASKETS COD. 35081**

| Pos. | Description |
|------|------------------|
| 4 | Upper guide band |
| 5 | Upper gasket |
| 6 | Upper guide band |
| 14 | Lower seal bands |
| 15 | Lower gasket |



Q COMPLETE SHORT PUMPING ELEMENT

WARNING: Always indicate code and quantity for each part required.




Fig. 1Q



| Pos. | Codice | Descrizione | Q. tà |
|------|--------|---|-------|
| 1 | 30150 | Complete short pumping element | 1 |
| 2 | 30113 | Stuffing nut | 1 |
| 3 | 30114 | Tightening ring nut | 1 |
| 4 | 30138 | Upper guide band | 1 |
| 5 | 30139 | Upper gasket | 1 |
| 6 | 30142 | Upper guide band | 1 |
| 7 | 30112 | Upper pump unit casing | 1 |
| 8 | 95230 | Adapter | 1 |
| 9 | 30109 | Sleeve-cylinder seal | 1 |
| 10 | 30120 | Sleeve | 1 |
| 11 | 30107 | Upper stem | 1 |
| 12 | 18482 | O-Ring | 1 |
| 13 | 30121 | Short stem | 1 |
| 14 | 30165 | Lower seal bands | 2 |
| 15 | 30166 | Lower gasket | 1 |
| 16 | 16120 | Ball | 1 |
| 17 | 30158 | Stem valve assembly | 1 |
| 18 | 30132 | OR | 2 |
| 19 | 30144 | OR | 1 |
| 20 | 30273 | Ball guide | 1 |
| | 30273 | Ball guide - Vers. with 7/8" ball | 1 |
| 21 | 20148 | Closing ball | 1 |
| | 20148 | Closing ball - Vers. with 7/8" ball | 1 |
| 22 | 30131 | Ball seat holder | 1 |
| | 65150 | Ball seat holder - Vers. with 7/8" ball | 1 |
| 24 | 30155 | Assembled valve | 1 |
| | 30130 | Assembled valve - Vers. with 7/8" ball | 1 |
| 25 | 20172 | 90° bend | 1 |
| 26 | 19295 | Suction pipefitting | 1 |
| 27 | 96099 | Seal sleeve | 1 |
| 28 | 30147 | Jacket assembly | - |
| 29 | 30137 | Stem assembly | - |
| 30 | 30176 | Foot valve unit | - |
| - | 30170 | Foot valve seal kit | - |
| - | 30173 | Complete seal kit | - |
| - | 30174 | Jacket+piston kit | - |
| - | 30175 | Suction+circulation hose kit | - |

R COMPLETE LONG PUMP UNIT

WARNING: Always indicate code and quantity for each part required.




Fig. 1R



| Pos. | Code | Description | Q. ty |
|------|-------|---|-------|
| 1 | 30100 | Complete long pump unit | 1 |
| 2 | 20101 | Suction filter | 1 |
| 3 | 30155 | Assembled valve | 1 |
| | 30130 | Assembled valve - Vers. with 7/8" ball | 1 |
| 4 | 30131 | Ball seat holder | 1 |
| | 65150 | Ball seat holder - Vers. with 7/8" ball | 1 |
| 5 | 20148 | Closing ball | 1 |
| | 20148 | Closing ball - Vers. with 7/8" ball | 1 |
| 6 | 30273 | Ball guide | 1 |
| | 30273 | Ball guide - Vers. with 7/8" ball | 1 |
| 7 | 30132 | O-ring | 2 |
| 8 | 30133 | Foot valve assembly for heavy products | 1 |
| 9 | 30158 | Stem valve assembly | 1 |
| 10 | 16120 | Ball | 1 |
| 11 | 30165 | Lower seal bands | 2 |
| 12 | 30166 | Lower gasket | 1 |
| 13 | 30119 | Lower stem | 1 |
| 14 | 18482 | O-Ring | 1 |
| 15 | 30107 | Upper stem | 1 |
| 16 | 30146 | Long pump assembly | 1 |
| 17 | 30120 | Sleeve | 1 |
| 18 | 30109 | Sleeve-cylinder seal | 1 |
| 19 | 30110 | Lower pump unit casing | 1 |
| 20 | 30111 | Seal | 1 |
| 21 | 30112 | Upper pump unit casing | 1 |
| 22 | 30138 | Upper guide band | 1 |
| 23 | 30139 | Upper gasket | 1 |
| 24 | 30114 | Tightening ring nut | 1 |
| 25 | 30113 | Stuffing nut | 1 |
| 26 | 30140 | Long jacket assembly | 1 |
| 27 | 95230 | Adapter | 1 |
| 28 | 30144 | OR | 1 |
| 29 | 30142 | Upper guide band | 1 |
| - | 30170 | Foot valve seal kit | - |
| - | 30173 | Complete seal kit | - |
| - | 30174 | Sleeve+piston kit | - |

COMPLETE SUBSTITUTION RECOMMENDED COD. 65150

| Pos. | Description |
|------|--|
| 8 | Foot valve assembly for heavy products |
| 9 | Stem valve assembly |



S BASIC HYDRAULIC BLOCK REF. 30400 (DWG. XL33SW)

WARNING: Always indicate code and quantity for each part required.




Fig. 1S



| Pos. | Code | Description | Q. ty |
|------|--------|------------------------------|-------|
| 1 | 30401 | Block base | 1 |
| 3 | 20457 | Digital pressure switch | 1 |
| 4 | 20402 | Protection | 1 |
| 5 | 20450 | Cable fastener | 1 |
| 8 | 33010 | Sealing washer | 1 |
| 9 | 33006 | Nipple | 1 |
| 10 | 33005 | Washer | 2 |
| 11 | 95068 | Screw | 2 |
| 12 | 32005 | Washer | 3 |
| 13 | 20436 | Screw | 3 |
| 14 | 96255 | Union M-M | 1 |
| 15 | 20451 | Elbow M-F | 1 |
| 36 | 20455 | Delivery pipe assembly | |
| 37 | 37261 | Rubber hose | 1 |
| 38 | 18511 | Bush for pipe 3/8 | 2 |
| 39 | 18509 | Pipe 3/8 | 1 m |
| 40 | 18211 | Tube coupling Gj 3/8 | 1 |
| 41 | 37440 | Complete recirculation valve | 1 |
| 42 | 8402 | OR 2087 | 1 |
| 43 | 37447 | Complete valve body | 1 |
| 44 | 301013 | OR 2025 | 1 |
| 45 | 37284 | Ring BK2021 | 1 |
| 46 | 37446 | Complete rod | 1 |
| 47 | 37281 | Spring | 1 |
| 48 | 37449 | Bush | 1 |
| 49 | 8026/1 | Hex socket set screw | 1 |

| Pos. | Code | Description | Q. ty |
|------|-------|-----------------------------|-------|
| 50 | 37444 | Positioning pin | 1 |
| 51 | 16405 | Knob | 1 |
| 52 | 30450 | Warning stickers | 1 |
| 53 | 37283 | Sealing washer | 1 |
| 54 | 7154 | Ball seat | 1 |
| 55 | 37441 | Valve bdy | 1 |
| 56 | 4050 | Ball Ø 6 | 1 |
| 57 | 37445 | Rod stem | 1 |
| 58 | 96205 | Hex socket set screw | 2 |
| 59 | 96206 | Nipple M-M 1/4" - M16 x 1.5 | 1 |
| 60 | 96204 | Filter base | 1 |
| 61 | 37453 | Nose union | 2 |
| 62 | 96203 | Or | 1 |
| 63 | 96207 | Sieve holder | 1 |
| 64 | 95218 | Filter sieve | 1 |
| 65 | 96202 | Sieve spring | 1 |
| 66 | 96201 | Filter tank | 1 |
| 67 | 37452 | Coupling | 1 |
| 68 | 37454 | Gasket | 1 |
| 69 | 53011 | Manometer | 1 |
| 70 | 147 | Complete pressure gauge | 1 |
| 71 | 30439 | Warning sticker | 1 |
| 72 | 30469 | Filter assembly | 1 |
| 75 | 34109 | Coupling M-M Gc-Gj 3/8 | 1 |
| 76 | 33007 | Washer 22 x 16,2 sp. 1.5 | 3 |
| 77 | 20421 | O-Ring | 1 |



T CIRCULATION SYSTEM UNIT (DWG. XL33SW)

WARNING: Always indicate code and quantity for each part required.




Fig. 1T

| Pos. | Code | Description | Q. ty |
|------|-------|-----------------------------|-------|
| 8 | 33010 | Sealing washer | 1 |
| 16 | 30430 | Cylindrical reduction piece | 1 |
| 17 | 3387 | Nipple | 1 |
| 18 | 20557 | Recirculation tube | 1 |
| 19 | 18350 | Splash bell | 1 |
| 20 | 18351 | Bell | 1 |
| 21 | 18352 | Dispersion pin | 1 |
| 22 | 8071 | Sealing washer | 2 |
| 23 | 30411 | Coupling F-F | 1 |
| 24 | 20403 | Jointed fitting | 1 |
| 25 | 20422 | Tube coupling | 1 |
| 26 | 20420 | Tube | 1 |

| Pos. | Code | Description | Q. ty |
|------|-------|--------------|-------|
| 27 | 20408 | Locking nut | 1 |
| 28 | 20405 | Gasket | 3 |
| 29 | 20404 | Pin | 1 |
| 30 | 20406 | Elbow | 1 |
| 31 | 20407 | Fitting | 1 |
| 32 | 7230 | OR 2058 | 1 |
| 33 | 20409 | O-ring | 1 |
| 34 | 20410 | Sleeve | 1 |
| 35 | 20411 | Coupling | 1 |
| 73 | 20556 | Suction tube | 1 |
| 74 | 37216 | Drum filter | 1 |

U CARRIAGE

WARNING: Always indicate code and quantity for each part required.




Fig. 1U

| Pos. | Code | Description | Q. ty |
|------|-------|-------------------|-------|
| - | 30300 | Complete carriage | - |
| 1 | 30301 | Carrying handle | 1 |
| 2 | 95159 | Pipe cap | 2 |
| 3 | 18914 | Bushing | 2 |
| 4 | 30302 | Carriage | 1 |

| Pos. | Code | Description | Q. ty |
|------|-------|-------------------|-------|
| 5 | 18902 | Split pin | 2 |
| 6 | 20305 | Wheel stop washer | 2 |
| 7 | 37238 | Wheel Ø260 mm | 2 |
| 8 | 30304 | Pipe cap | 2 |



V ELECTRICAL CONTROL - EXPLODED VIEW

WARNING: Always indicate code and quantity for each part required.




Fig. 1V

| Pos. | Code | Description | Q. ty |
|------|-------|---------------------|-------|
| | | Electronic box A C. | |
| - | 30350 | Model 220V - 50Hz | - |
| - | 30357 | Model 110V - 60Hz | - |
| 1 | 5933 | Switch | 1 |
| 2 | 20355 | Panel | 1 |
| 3 | 20354 | Electronic box | 1 |
| 4 | 96028 | Screw | 6 |
| 5 | 20365 | Electronic board | 1 |
| 6 | 18483 | Short rubber seal | 2 |

| Pos. | Code | Description | Q. ty |
|------|-------|------------------------|-------|
| 7 | 18493 | Tightening plate | 1 |
| 8 | 20352 | Dissipator | 1 |
| 9 | 8011 | Anti-vibration washers | 3 |
| 10 | 34009 | Washer | 3 |
| 11 | 34008 | Screw | 3 |
| 12 | 20340 | Transparent sheet | 1 |
| 13 | 20349 | Knob | 1 |
| 14 | 30280 | Technical data label | 1 |

W LINER TYPE MACHINES

NOTES ON THE ASSEMBLY OF THE CLUTCH UNIT




Fig. 1W



ATTENTION
Check for proper clearance ($0,5 \pm 0,05\text{mm}$) between the anchor and the rotor when assembling the clutch unit.



| Pos. | Code | Description | Q. ty |
|------|-------|-----------------------|-------|
| 1A | 18186 | Motor | 1 |
| 1B | 18187 | Motor | 1 |
| 2 | 18473 | Motor pulley-joint | 1 |
| 3 | 81038 | Flexible coupling | 1 |
| 4 | 18474 | Clutch-joint | 1 |
| 5 | 34008 | Screw | 10 |
| 6 | 18192 | Screw | 1 |
| 7 | 18189 | Shaft tab | 1 |
| 8 | 81009 | Hex socket set screw | 1 |
| 9 | 30656 | Tab | 1 |
| 10 | 30657 | Bearing | 1 |
| 11 | 7112 | Screw | 2 |
| 12 | 18477 | Flange motor | 1 |
| 13 | 18476 | Guard | 1 |
| 14 | 54003 | Washer | 13 |
| 15 | 8042 | Self-tightening nut | 12 |
| 16 | 16064 | Screw | 4 |
| 17 | 54004 | Screw | 7 |
| 18 | 18491 | Complete clutch | 1 |
| 19 | 18490 | Spacer ring | 1 |
| 20 | 30659 | Bearing | 1 |
| 21 | 30686 | Locking ring | 1 |
| 22 | 18475 | Tie-rods | 4 |
| 23 | 95066 | Washer | 12 |
| 24 | 5756 | Self-tightening nut | 12 |
| 25 | 96030 | Washer | 6 |
| 26 | 20510 | Reduction gear flange | 1 |
| 27 | 20531 | Fan | 1 |
| 28 | 18492 | Pinion | 1 |
| 29 | 18467 | Safety shields | 2 |
| 30 | 83004 | Screw | 5 |

| Pos. | Code | Description | Q. ty |
|------|---------|-----------------------|-------|
| 31 | 18469 | Guard | 1 |
| 32 | 95096 | Washer | 14 |
| 33 | 96080 | Self-tightening nut | 6 |
| 34 | 4752 | Alternator belt | 1 |
| 35 | 4409 | Screw | 12 |
| 36 | 4777/1 | Alternator pulley | 1 |
| 37 | 4758 | Alternator | 1 |
| 38 | 8371 | Screw | 2 |
| 39 | 4771 | Alternator fulcrum | 1 |
| 40 | 4776 | Alternator plate | 1 |
| 41 | 30667 | Safety shields | 2 |
| 42 | 30690 | Drain pipe | 1 |
| 43 | 1000506 | 1" collar | 2 |
| 44 | 510068 | Washer | 2 |
| 45 | 95153 | Washer | 2 |
| 46 | 30691 | Safety cover | 1 |
| 47 | 18471 | Support plate | 1 |
| 48 | 30451 | Screw | 2 |
| 49 | 18472 | Support plate | 1 |
| 50 | 95096 | Washer | 6 |
| 51 | 20537 | Vibration-damping pad | 4 |
| 52 | 18459 | Support bush | 1 |
| 53 | 18470 | Dragon Liner support | 1 |
| 54 | 53002/4 | Self-tightening nut | 14 |
| 55 | 6151 | Screw | 4 |
| 56 | 20534 | Snap ring for holes | 1 |
| 57 | 20535 | Radial bearing | 1 |
| 58 | 18452 | Fifth wheel | 2 |
| 59 | 18453 | Axial roller cage | 1 |
| 60 | 18454 | R.S. bearing unit | 1 |



X PETROL-POWERED DRAGON

WARNING: Always indicate code and quantity for each part required.




Fig. 1X



| Pos. | Code | Description | Q. ty |
|------|-------|---------------------|-------|
| 1 | 18186 | Motor | 1 |
| 2 | 3637 | Self-tightening nut | 16 |
| 3 | 34009 | Washer | 22 |
| 4 | 54004 | Screw | 7 |
| 5 | 32005 | Washer | 7 |
| 6 | 18491 | Complete clutch | 1 |
| 6A | . | Anchor | 1 |
| 6B | . | Coil | 1 |
| 6C | . | Rotor | 1 |
| 7 | 18492 | Pinion | 1 |
| 8 | 20531 | Fan | 1 |
| 9 | 30682 | Flange motor | 1 |
| 10 | 30683 | Cover spacers | 6 |
| 11 | 18463 | Spacers | 4 |
| 12 | 18935 | Screw | 4 |
| 13 | 30656 | Tab | 1 |
| 14 | 30684 | Bush | 1 |
| 15 | 18490 | Spacer | 1 |
| 16 | 30659 | Bearing | 1 |
| 17 | 30686 | Tightening washer | 1 |

| Pos. | Code | Description | Q. ty |
|------|--------|---------------------------|-------|
| 18 | 18192 | Screw | 1 |
| 19 | 20508 | Tie-rods | 4 |
| 20 | 95114 | Washer | 4 |
| 21 | 81010 | Nut | 8 |
| 22 | 20509 | Guard | 1 |
| 23 | 34008 | Screw | 14 |
| 24 | 18189 | Motor tongue | 1 |
| 25 | 69016 | Screw | 4 |
| 26 | 20510 | Reduction gear flange | 1 |
| 27 | 20534 | Snap ring for holes | 1 |
| 28 | 20535 | Radial bearing | 1 |
| 29 | 20536 | Hydraulic buffer assembly | 2 |
| 30 | 30685 | Support plate | 1 |
| 31 | 33005 | Washer | 4 |
| 32 | 96080 | Self-tightening nut | 4 |
| 33 | 20514 | Spacer | 4 |
| 34 | 69107 | Screw | 4 |
| 35 | 4470/2 | Box | 1 |
| 36 | 30688 | Spacer | 2 |



WARNING: Always indicate code and quantity for each part required.




Fig. 2X

| Pos. | Code | Description | Q. ty |
|------|-------|------------------|-------|
| 1 | 81010 | Nut | 8 |
| 2 | 95114 | Washer | 4 |
| 3 | 30451 | Screw | 2 |
| 4 | 20115 | Extension cables | 1 |
| 5 | 20101 | Filter | 1 |

| Pos. | Code | Description | Q. ty |
|------|-------|---------------|-------|
| 6 | 20513 | Support plate | 1 |
| 7 | 3637 | Nut | 16 |
| 8 | 20514 | Spacer | 4 |
| 9 | 34009 | Washer | 22 |
| 10 | 69107 | Screw | 4 |

NOTES ON THE ASSEMBLY OF THE CLUTCH UNIT




Fig. 3X



ATTENTION
Check for proper clearance ($0,5 \pm 0,05\text{mm}$) between the anchor and the rotor when assembling the clutch unit.



Y 100 L TANK

WARNING: Always indicate code and quantity for each part required.




Fig. 1Y



| Pos. | Code | Description | Q. ty |
|------|-------|-----------------------|-------|
| A | 20326 | 100 l Tank assembly | 1 |
| 1 | | Tank | 1 |
| 2 | | Cover | 1 |
| 3 | 32003 | Carrying handle | 1 |
| 4 | 20321 | Male plug | 1 |
| 5 | 20330 | Gasket | 1 |
| 6 | 20322 | Female plug | 1 |
| 7 | 20327 | Trolley | 1 |
| 8 | 69011 | Screw | 2 |
| 9 | 34024 | Washer | 2 |
| 10 | 20303 | Wheel | 2 |
| 11 | 20305 | Wheel stop washer | 2 |
| 12 | 95159 | Cap | 2 |
| 13 | 20328 | Bag support bar | 1 |
| 14 | 20325 | Bag pressing assembly | 1 |
| 15 | 20331 | Right shoulder | 1 |
| 16 | 20343 | Bushing | 2 |
| 17 | 20323 | Bushing | 2 |
| 18 | 20336 | Spacer | 1 |
| 19 | 20333 | Idle roller | 1 |
| 20 | 20334 | Motor roller | 1 |
| 21 | 20332 | Left shoulder | 1 |
| 22 | 91062 | Screw | 1 |
| 23 | 20337 | Bushing | 1 |
| 24 | 21683 | Split pin | 1 |
| 25 | 20335 | Lever | 1 |
| 26 | 20339 | Bushing | 1 |
| 27 | 20338 | Crank handle | 1 |
| 28 | 20319 | Crank handle assembly | 1 |

| Pos. | Code | Description | Q. ty |
|------|-------|--|--------|
| 29 | 20324 | Cover cap | 1 |
| 30 | 19295 | Union | 1 |
| 31 | 96099 | Seal | 1 |
| 32 | 18244 | Package pressing kit | 1 |
| 33 | 18243 | Complete tank 100Lt | 1 |
| 34 | 20341 | O-ring | 1 |
| 35 | 20358 | Lower cap seal | 1 |
| 36 | 52017 | Nut | 2 |
| 37 | 91564 | Chain | 0,5 mt |
| 38 | 18257 | Ring | 2 |
| 39 | 18256 | Cap holding chain | 1 |
| 40 | 20344 | Adjustment cylinder | 2 |
| 41 | 11814 | Adjustment spring | 2 |
| 42 | 95067 | Cap | 2 |
| 43 | 85500 | Complete tank | 1 |
| 44 | 20371 | Cleaning spatula | 1 |
| 45 | 21545 | Screw | 4 |
| 46 | 4492 | Spacers | . |
| 47 | 8385 | Screw | . |
| 48 | 3063 | Clamp | . |
| 49 | 8042 | Self-tightening nut | . |
| 50 | 18288 | Complete cap/coupling kit | . |
| 51 | 20372 | Fixing plate | . |
| 52 | 20373 | Wing nut | . |
| 53 | 20348 | Circulation hose complete with couplings and dispersion bell | . |
| 54 | 18223 | Suction tube | . |
| 55 | 18390 | Complete accessory kit | . |
| 56 | 20325 | Bag-wringing kit | . |




Z ELECTRIC MOTOR

WARNING: Always indicate code and quantity for each part required.

- Periodically check on the wear of the pinion (*at least every 1000 working hours*).
- Periodically check the perfect connection among all the electrical components (*at least every 200 working hours*).
- The length of the brush contact must be higher than 9 mm to guarantee a good working of the rotary group.




DISCONNECT THE POWER SUPPLY BEFORE CHECKING OR REPLACING THE BRUSHES.



| Code | Description | Q. ty |
|-------|-------------------|-------|
| 20280 | Brush 220V 50Hz | 4 |
| 20281 | Brush 110V 60Hz | 4 |
| 20282 | Brush holder plug | 4 |

Fig. 1Z



*Length of new brush

**Minimum length of the brush - Replace

Fig. 2Z

AA ELECTRICAL DIAGRAM




Fig. 1AA

Intentionally blank page

**CE DECLARATION OF CONFORMITY****Company**

LARIUS srl
Via Antonio Stoppani 21 - 23801 Calolziocorte (LC) ITALY
Tel: +39 0341 621152
Fax: +39 0341 621243
E-mail: larius@larius.com

Declares under his owns responsibility that the product:

DRAGON
Electric piston pump

complies with the directives:

- EC Directive 2006/42 Machinery Directive
- EU Directive 2014/30 Electromagnetic Compatibility (EMC)
- EU Directive 2014/35 Low Voltage (LVD)

furthermore to the
harmonized standards:

- UNI EN ISO 12100-1/-2
Machinery safety, basic concepts, general principles of design. Basic terminology, methodology. Technical principles.

This declaration relates exclusively to the product in the state in which it was placed on the market, and excludes components or modifications which are added or carried out subsequently by end user.

Signature

Pierangelo Castagna
Managing Director

Location / Date



LARIUS srl

Via Antonio Stoppani 21 - 23801 Calolziocorte (LC) ITALY
TEL. +39 0341 621152 - Fax +39 0341 621243 - larius@larius.com

www.larius.com

