

























































































## Simple blending example

- 1975 CI2 Contact chamber has a 5 Hp top entering mixer with drip feed lines
- Opt A ) Convert to larger HE-3 impeller
- Opt B ) Change to same size A 310 turbine
- Opt C ) Convert to aspirating wet mixer
- Opt D ) Add static inline mixer before tank
- Opt E ) Use jet reactor mixer tube instead
- Opt F ) Go to contract operations retire

45















































