

IMPORTANT INFORMATION

- Illustrations are for reference only. Styles may vary from actual contents.
- Georgie™ is not intended for use by children under 6 years of age.
- Keep hands, hair and loose clothing items (like shoelaces) away from the moving parts during use.
- Do not pick up Georgie™ during a command to avoid getting hair or loose items caught in the spinning paws.
- Always turn Georgie™ OFF after use to conserve battery power.
- Keep Georgie™ in sight during play.
- Check the USB cord before each use to ensure there is no damage. If the cord is damaged, do not attempt to charge the battery.
- The USB cord is intended to be used solely with Georgie™. Do not use the cord with other products.
- Never put another cord or object in the USB charging port.
- Only use Georgie™ on the floor away from stairs. Falls from high surfaces may cause irreparable damage.
- Only use Georgie™ indoors on a clean surface.
- It is recommended that you play with Georgie™ on low pile carpet.
- Keep Georgie™ away from water.
- To clean, wipe with a damp cloth. Air dry only. Thoroughly dry before storing Georgie™.



'Let's care for the environment!'

The wheellie bin symbol indicates that the product must not be disposed of with other household waste. Please use designated collection points or recycling facilities when disposing of the item. Do not treat old batteries as household waste. Take them to a designated recycling facility.

Please keep this manual as it contains important information.



0416-0-E/INT
0416-0-UK

www.georgie.com
© 2016 MGA Entertainment, Inc.
GEORGIE™ is a trademark of MGA
in the U.S. and other countries.
All logos, names, characters,
likenesses, images, slogans, and
packaging appearance are the
property of MGA.
16300 Roscoe Blvd.
Van Nuys, CA 91406 U.S.A.
(800) 222-4685
Printed in China

MGA Entertainment UK Ltd.
50 Presley Way
Crownhill
Milton Keynes, MK8 0ES
Bucks, UK
+ 0800 521 558



The preferred method of contact for
Customer Service is through our e-mail
contact form at www.mgae.com



Loves to cuddle & get into trouble™

PUPPY Training Guide



Age
6+
years

SKU: 540175, 540175UK
ADULT SUPERVISION RECOMMENDED



CERTIFICATE OF ADOPTION

THIS CERTIFIES THAT

_____ HAS OFFICIALLY ADOPTED

Georgie™



SIGNATURE

DATE



LiPo BATTERY SAFETY INFORMATION

- Never leave the battery unattended while charging and charge in an isolated area.
- Keep away from flammable materials.
- Do not drop or subject to strong impact.
- Do not immerse the battery in water, and keep the battery in a cool, dry place.
- Only charge the battery with the specified included USB cable and do not over-charge.
- Only use the battery included in the device.
- There is a risk of the battery exploding, overheating or igniting. Do not disassemble, modify, heat or short circuit the battery. Do not place it in fire or leave it in extreme heat.
- In the unlikely event of leakage or explosion, use sand or a chemical fire extinguisher for the battery.
- Battery must be recycled or disposed of properly.

NOTE: Under the environment with electrostatic discharge, the toy may malfunction and require the user to reset the toy. To reset the product, turn it off completely, then turn it back on. To ensure normal performance, recharge the battery, as low battery may not allow full function.

PRODUCT BATTERY REMOVAL INSTRUCTIONS:

Internal battery is factory installed. Product disassembly and battery removal must be performed by an adult. Open the product. When battery is completely visible, use scissors to cut a single battery wire. Immediately wrap the cut wire end with tape to isolate it. Repeat until all battery wires are cut and isolated and the battery is free from the rest of the product. Dispose of the battery in accordance with your local battery recycling or disposal laws. NOTE: Opening of the product and/or removal of the battery will render the product inoperative and voids manufacturer warranties. Dispose of the remaining product components in accordance with local laws.

FCC COMPLIANCE

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.


Caution: Modifications not authorized by the manufacturer may void users authority to operate this device.

CAN ICES-3 (B)/NMB-3(B).

DOG COLLAR

The handle from Georgie's crate can be removed and turned into a sweet dog collar!


1. Ask an adult to cut both sides of the handle.
2. Write your name on the back of Georgie's name tag.
3. Slide the collar through the loop on the name tag.
4. Wrap the collar around Georgie's neck and tape it together.



Getting Started

Georgie™ is charged and ready to play right out of the box. If Georgie™ seems sluggish, try recharging the battery by following the charging directions on page 21.

1. Open the hook and loop fastener under Georgie's belly.
2. Turn Georgie™ ON (I).
3. Secure the hook and loop fastener.
4. Georgie™ is ready to play!



“Hey Georgie!”

Once Georgie™ has been turned ON (I), he is ready to play! When Georgie™ stops moving and waits for command, say **“HEY GEORGIE!”** then say one of the **BLUE** commands in this puppy training guide. Then, watch and listen as Georgie™ responds! **Always say “HEY GEORGIE!” and wait until Georgie™ responds with yipping before giving a command.** Georgie™ can only respond to one command at a time. Let Georgie™ finish a command before saying another.

Example:

“Hey Georgie!”

- Georgie™ yips to acknowledge your voice.

“Let's Dance!”

- Georgie™ plays music and dances.

- | | | |
|------------------------------|------------------|-----------------------|
| 1. “Sit Down” | 5. “Stand Up” | 9. “Let's Dance!” |
| 2. “Speak” | 6. “Shake” | 10. “Selfie!” |
| 3. “Good Boy” or “Good Girl” | 7. “High Five” | 11. “Bath Time!” |
| 4. “Wanna Go For A Walk?” | 8. “I Love You!” | 12. “Are you Hungry?” |


Remember to always speak loudly and clearly when playing with Georgie™. **Georgie™ is a puppy and gets distracted easily, he will need a quiet place to listen to commands.** Sit or stand close when speaking to Georgie™ so he can hear and respond.




Charging Information

If Georgie™ seems sluggish or is not properly responding to commands, the battery may need recharging. An adult should recharge the LiPo battery. Here's how:


1. Open the hook and loop fastener under Georgie's belly to locate the battery box.
2. Turn Georgie™ OFF/CHARGING (O/⚡).
3. Let the battery cool for 10 minutes after use.



4. Insert the mini USB cable into the battery box.
5. Insert the larger end of the USB into a wall adapter (not included) or computer (not included) that is turned on. The LED indicator will light up in **RED** while charging.
6. Charge Georgie™ for 1 - 1 1/2 hours. The LED will turn **GREEN** when charging is complete. A full charge will lend about 1 1/2 hours of play time. Note: Wall adapters will lessen the charge time.



7. Unplug the USB cable from Georgie™ and the charging unit.
8. Turn Georgie™ ON (I) when you are ready to play.
9. Close the hook and loop fastener under the belly.



BODILY FUNCTIONS

Like a real puppy, Georgie™ is full of funny surprises and will frequently need to fart and burp. Georgie™ even makes peeing sounds when it's time to go!



TROUBLESHOOTING

Georgie™ doesn't respond to your voice commands:

- 🐾 Georgie™ only responds to English. Speak loudly and clearly to give commands.
- 🐾 Georgie™ may have a low battery. See the next page for charging information.
- 🐾 Georgie™ can only respond to one command at a time. Let Georgie™ finish moving, barking or performing one command before saying "HEY GEORGIE!" and giving another command.
- 🐾 Georgie may not recognize the tone of your voice. Speak in a higher or lower tone of voice to see if Georgie responds better.

Georgie™ isn't walking forward or backward:

- 🐾 Puppies are clumsy and often slip when they move. Georgie™ plays well on most surfaces, but plays best on low pile carpet.
- 🐾 Georgie™ may be sleeping. Pet Georgie's head to wake him up.

Georgie™ is sluggish or not moving at all:

- 🐾 Check Georgie™ thoroughly to make sure nothing is stuck in his paws and preventing movement.
- 🐾 Georgie™ may have a low battery. Fully recharge Georgie's battery. See the next page for charging information.

“HEY GEORGIE!
SIT DOWN”



“Hey Georgie! Speak”

WOOF!
WOOF!



Idle

After 3 minutes of inactivity, Georgie™ will yawn and go to sleep. When you are ready to play again, say “HEY, GEORGIE!” or pet Georgie’s head.

If you are finished playing, turn the switch on the battery compartment to the OFF/CHARGING (O/P) position to conserve battery power.



Snuggle

Pet Georgie's head to hear barking, yipping and panting. If you pet Georgie's head four times, Georgie™ will lay down.

Georgie™ will yawn, say "I Love You" and go to sleep.

NOTE: Georgie™ will have to be turned off and then back on to wake up again.



Blanket not included

“Hey Georgie! Good Boy”

OR

“Hey Georgie! Good Girl”



“Hey Georgie!
Wanna GO
FOR A WALK?”



Leash not included

TUG-O-WAR

Open Georgie's mouth and place the rope all the way at the back of the tongue. Pull gently to play tug-o-war until Georgie™ stops and is ready for the next command.



“Hey Georgie!
Are You Hungry?”

WOOF!
WOOF!



WOOF!

“Hey Georgie!
Stand UP”



“Hey Georgie!
Shake”



“Hey Georgie!
Bath Time!”



“Hey Georgie!
Selfie!”



Phone/ camera not included

“Hey Georgie!
High Five”



“Hey Georgie!
I Love You!”



“Hey Georgie!
Lets Dance!”

