

All-Wheel Steer Loader	Air Filter (Inner)	Air Filter (Outer)	Engine Oil Filter	Fuel Filter	Hydraulic Filter	Case Drain Filter	Hydraulic Fill/Breather Cap	Charge Filter	Heater Filter	Recir. Filter
A220	6666376	6666375	6665603	6667352	6661248	6661807 w/ 6661022	6577785		6677983	6678207
A300 SN: 5211 11001 & above	6666376	6666375	6665603	6667352	6661248	6661807 w/ 6661022	6727475	6686926 - Aluminum 6692337 - Cast Iron	6677983	6678207
A300 SN: 5234 11001 & above, 5264 11001 & above, 5265 11001 & above	6681475	6681474	6678233		6661248 Stand. Flow 6668819 High Flow					
A300 SN: 5399 11001 & above, 5400 11001 & above										
A300 SN: A5GW 11001 & above, A5GY 11001 & above	6698058	6698057								
A770 A3P611001 & Above A3P711001 & Above ASRW11001 & Above	7010031	7286652	6678233	6667352	7012314 w/7015308		6727475	6692337 - Canister 6686926 - Spin-on	7176099	7193354
A770 ATDW11001 & Above ATDY11001 & Above				7023589						
A770 B3BU11001 & Above				7248874						
A770 AT5J11001 & Above										

Compact Track Loader	Air Filter (Inner)	Air Filter (Outer)	Engine Oil Filter	Fuel Filter	Hydraulic Filter	Case Drain Filter	Hydraulic Fill/Breather Cap	Charge Filter	Heater Filter	Recir. Filter
T110	7020361	6690907	6675517	6667352	6661248 - Primary 6681012 - In-Line	6661022	6727475		6677983	6678207
T140	6598362	6598492	6675517	6667352	6661248 - Primary 6661807 - In-Line	6661022	6727475		6677983	6678207
T180 SN: 5242 11001 & above, 5275 11001 & above, 5276 11001 & above, 531411001 & above, 5315 11001 & above	6598362	6598492	6675517	6667352	6661248 - Primary 6661807 - In-Line	6661022	6717827	6686926	6677983	6678207
T180 SN: A3LL 11001 & above	6698058	6698057			6661248 - Primary 6686926 - Secondary		6727475	6692337		
T190 SN: 519311001 & abv, 519411001 & above, 527011001 & above, 527911001 & above	6598362	6598492	6675517	6667352	6661248 - Primary 6661807 - In-Line	6661022	6717827		6677983	6678207
T190 SN: 527711001 & abv, 527811001 & above, 531611001 & above, 531711001 & above								6686926		
T190 SN: A3LN 11001 & abv, A3LP 11001 & abv								6698058		
T200	6666376	6666375	6665603	6667352	6661248 6661807 - In-Line	6661022	6727475		6677983	6678207
T250 SN: 5230 11001 & abv, 5231 11001 & abv, 5256 11001 & abv, 5257 11001 & abv	6681475	6681474	6678233	6667352	6661248 Stand Flow 6668819 High Flow 6661807 - In-Line	6661022	6727475		6677983	6678207
T250 SN: 5318 11001 & abv, 5319 11001 & abv								6686926 - Aluminum 6692337 - Cast Iron		
T250 SN: A5GS11001 & abv, A5GT11001 & abv								6698058		
T300 SN: 5219 11001 & abv 5220 11001 & abv, 5254 11001 & abv, 5255 11001 & abv	6681475	6681474	6678233	6667352	6661248 6661807 - In-Line	6661022	6727475		6677983	6678207
T300 SN: 5320 11001 & abv, 5321 11001 & abv					6661248 Stand Flow 6668819 High Flow 6661807 - In-Line			6686926 - Aluminum 6692337 - Cast Iron		
T300 SN: A5GU11001 & abv, A5GV11001 & abv					6698058			6690857		
T320 SN: A7MP11001 to A7MP60090	6681475	6681474	6678233	6667352	6661248 Stand Flow 6668819 High Flow	6661022	6727475	6686926 - Aluminum 6692337 - Cast Iron	6677983	6678207
T320 SN: A7MP60091 to AAKZ11001 & abv	6698058	6690857								

Compact Track Loader	Air Filter (Inner)	Air Filter (Outer)	Engine Oil Filter	Fuel Filter	Hydraulic Filter	Case Drain Filter	Hydraulic Fill/Breather Cap	Charge Filter	Heater Filter	Recir. Filter
T450 AUV11001 & Above B1EM11001 & Above	7221934	7286322	7012303	7023589	7024037		6727475	6686926 - Spin-on 6692337 - Canister	7176099	7193354
T550 A7UJ11001 & Above	6666376	6666375	6675517	6667352	7024037		6727475	6686926 - Spin-on 6692337 - Canister	7176099	7193354
T550 AJZV11001 & Above	7221934	7286322	7012303	7023589						
T590 A3NR11001 & Above; A3NS11001 & Above	6666376	6666375	6675517	6667352	7024037		6727475	6686926 - Spin-on 6692337 - Canister	7176099	7193354
T590 ALJU11001 & Above	7221934	7286322	7012303	7023589						
T590 B37811001 & Above					7012314 w/7015308			6686926		
T630 A7PU11001 & Above	7008044	7008043	6678233	6667352	7002734 (A7PU11001-11325) 7012314 w/7015308 (A7PU11326 & abv.)		6727475	6686926 - Spin-on 6692337 - Canister	7176099	6698096 (metal housing) 7193354 (plastic housing)
T630 AJDT11001 & Above	7221934	7286322	7012303	7023589	7012314 w/7015308				7176099	7193354
T650 A3P011001 & Above; A3P111001 & Above; 1MLT11001 & Above	7008044	7008043	6678233	6667352	7002734 (A3P011001-11190, A3P111001-11100) 7012314 w/7015308 (A3P011191 & abv., A3P111101 & abv., 1MLT11001 & abv.)		6727475	6686926 - Spin-on 6692337 - Canister	7176099	6698096 (metal housing) 7193354 (plastic housing)
T650 ALJG11001 & Above	7221934	7286322	7012303	7023589	7024037					7193354
T650 T1ML11001 & Above; B2KZ11001 & Above					7012314 w/7015308					

Compact Track Loader	Air Filter (Inner)	Air Filter (Outer)	Engine Oil Filter	Fuel Filter	Hydraulic Filter	Case Drain Filter	Hydraulic Fill/Breather Cap	Charge Filter	Heater Filter	Recir. Filter
T740 B3CA11001 & Above	7010031	7286652	7012303	7023589	7248874		6727475	6686926	7176099	7193354
T750 ANKA11001 & Above	7010031	7286652	6678233	6667352	7248874		6727475	6686926 - Spin-on 6692337 - Canister	7176099	7193354
T750 ATF611001 & Above				7023589	7012314 w/7015308					
T770 A3P811001 & Above; A3P911001 & Above; AUYB11001 & Above	7010031	7286652	6678233	6667352	7012314 w/7015308		6727475	6686926 - Spin-on 6692337 - Canister	7176099	7193354
T770 AN8T11001 & Above; ATF711001 & Above				7023589						
T770 B3BW11001 & Above; AT6311001 & Above				7012303	7248874 (add 7248873 for AT6311001 & abv.)			6686926		
T870 A3PG11001 & Above; A3PH11001 & Above	7010031	7286652	6678233	6667352	7012314 w/7015308		6727475	6686926 - Spin-on 6692337 - Canister	7176099	6698096 (metal housing)
T870 AN8L11001 & Above; ATF811001 & Above				7023589						7193354 (plastic housing)
T870 B3BZ11001 & Above; ASWT11001 & Above			7012303	7248874 (add 7248873 for ASWT11001 & abv.)	6686926			7193354		

Skid-Steer Loader	Air Filter (Inner)	Air Filter (Outer)	Engine Oil Filter	Fuel Filter	Hydraulic Filter	Case Drain Filter	Hydraulic Fill/Breather Cap	Cooling/Charge Filter	Heater Filter	Recir. Filter
S70	6672468	6672467	6657635	6667352	6677652	6732215	7025626			
S100	7020361	6690907	6657635	6667352	6661248 6681012	6661022	6727475		6677983	6678207
S130 524611001 & Above, 524711001 & Above, 527311001 & Above; 527411001 & Above; A00E11001 & Above.	6598362	6598492	6675517	6667352	6661248 6661807	6661022	6728149 (with 6727475 for 527311001 & Above; 527411001 & Above; A00E11001 & Above)		6677983	6678207
S130 529211001 & Above; 529611001 & Above; A1Z711001 & Above; A84W11001 & Above; A8KA11001 & Above; A811001 & Above; A3KY11001 & Above; AU4Y11001 & Above.							6728149	6686926		
S150 523811001 & Abv, 523911001 & Abv, 524011001 & Abv.	6598362	6598492	6675517	6667352	6661248 6661807	6661022	7025626		6677983	6678207
S150 526611001 & Abv, 526711001 & Abv, 526811001 & Abv, 526911001 & Abv, 539711001 & Abv, 539811001 & Abv								6686926		
S150 529711001 & Abv, 529811001 & Abv, A8M011001 & Abv, AC3011001 & Abv								6661248		
S150 A3L111001 & Above								6661248 6661807		
S160 S/N: 5238 11001 & abv, 5239 11001 & abv, 5240 11001 & abv.	6598362	6598492	6675517	6667352	6661248 6661807	6661022	7025626		6677983	6678207
S160 5266 11001 & abv, 5267 11001 & abv, 5268 11001 & abv, 5269 11001 & abv, 5397 11001 & abv, 5398 11001 & abv, 5299 11001 & abv, 5300 11001 & abv, A151 11001 & abv, AHWA 11001 & abv, S/N: A3L3 11001 & abv, A3L4 11001 & abv, AEYN 11001 & abv.								6686926		
S175 S/N: 5176 25001 & abv, 5181 15001 & abv, 5190 28001 & abv, 5192 15001 & abv.	6598362	6598492	6675517	6667352	6661248 6661807	6661022	7025626		6677983	6678207
S175 5250 11001 & abv, 5251 11001 & abv, 5252 11001 & abv, 5253 11001 & abv, 5301 11001 & Abv, 5302 11001 & Abv, A8M4 11001 & Abv, A8NY 11001 & Abv, A8NZ 11001 & Abv, A3L5 11001 & Abv.								6686926		

Skid-Steer Loader	Air Filter (Inner)	Air Filter (Outer)	Engine Oil Filter	Fuel Filter	Hydraulic Filter	Case Drain Filter	Hydraulic Fill/Breather Cap	Cooling/Charge Filter	Heater Filter	Recir. Filter
S185 S/N: 5176 25001 & abv, 5181 15001 & abv, 5190 28001 & abv, 5192 15001 & abv.	6598362	6598492	6675517	6667352	6661248 6661807	6661022	7025626	6686926	6677983	6678207
S185 5250 11001 & abv, 5251 11001 & abv, 5252 11001 & abv, 5253 11001 & abv,										
S185 5303 11001 & abv, 5304 11001 & abv, ABRT 11001 & abv										
S185 S/N: A3L9 11001 & abv, A3LH 11001 & abv, AEYU 11001 & abv										
S205 S/N: 5284 11001 & abv, 5285 11001 & abv, 5305 11001 & abv, 530611001 & abv	6598362	6598492	6675517	6667352	6661248 6661807	6661022	7025626	6686926	6677983	6678207
S205 S/N: A3LJ 11001 & abv, A3LK 11001 & abv, AMVU 11001 & abv, ANLP 11001 & abv	6698058	6698057			6661248			6686926 6692337		
S220 S/N: 5232 11001 & abv 5233 11001 & abv, 5262 11001 & abv, 5263 11001 & abv	6681475	6681474	6678233	6667352	6661248 Stand Flow 6668819 High Flow 6661807 - In-Line	6661022	6727475	6686926 - Aluminum 6692337 - Cast Iron	6677983	6678207
S220 S/N: 5307 11001 & above, 5308 11001 & above										
S220 S/N: A5GK11001 & Above, A5GL11001 & Above										
S250 S/N: 5207 11001 & above	6666376	6666375	6665603	6667352	6661248 6661807 - In-Line	6661022	6727475 w/ 6700631	6686926 - Aluminum 6692337 - Cast Iron	6677983	6678207
S250 S/N: 5213 11001 & abv, 5214 11001 & abv, 5215 11001 & abv, 5216 11001 & abv, 5258 11001 & abv, 5259 11001 & abv, 5260 11001 & abv, 5261 11001 & abv.	6681475	6681474	6678233		6661248 Stand Flow 6668819 High Flow 6661807 - In-Line		6727475			
S250 S/N: 5309 11001 & above, 5310 11001 & above										
S250 S/N: A5GM11001 & Above, A5GN11001 & Above	6698058	6698057								

The Bobcat Filter Reference Guide is subject to change. Consult your Operation & Maintenance Manual for maintenance intervals and additional maintenance items.

Skid-Steer Loader	Air Filter (Inner)	Air Filter (Outer)	Engine Oil Filter	Fuel Filter	Hydraulic Filter	Case Drain Filter	Hydraulic Fill/Breather Cap	Charge Filter	Heater Filter	Recir. Filter
S300 S/N: 5213 11001 & abv, 5214 11001 & abv, 5215 11001 & abv, 5216 11001 & abv, 5258 11001 & abv, 5259 11001 & abv, 5260 11001 & abv, 5261 11001 & abv.	6681475	6681474	6678233	6667352	6661248 Stand Flow 6668819 High Flow 6661807 - In-Line	6661022	6727475	6686926 - Spin-on 6692337 - Canister	6677983	6678207
S300 S/N: 5311 11001 & above, 5312 11001 & above, AJ4M 11001 & above										
S300 S/N: A5GP11001 & Above, A5GR11001 & Above										
S330 S/N: A5HA11001 & Above, AAKM11001 & Above	6698058	6698057	6678233	6667352	6661248 Stand Flow 6668819 High Flow 6661807 - In-Line	6661022	6727475	6686926 - Spin-on 6692337 - Canister	6677983	6678207
S330 S/N: A020 11001 & above, A021 11001 & above	6681475	6681474								
S450 AUVB11001 & Above	7221934	7286322	7012303	7023589	7024037		6727475	6686926 - Spin-on 6692337 - Canister	7176099	7193354
S450 AV9V11001 & Above , B1E611001 & Above	6666376	6666375	6675517	6667352						
S450 B1ED11001 & Above										
S510 A3NJ11001 & Above A3NK11001 & Above ATZC11001 & Above AZN411001 & Above AZN511001 & Above	6666334	6666333	6675517	6667352	7024037		6727475	6686926 - Spin-on 6692337 - Canister	7176099	7193354
S510 ALNW11001 & Above, B42S11001 & Above	7221934	7286322	7012303	7023589						
S530 A7TV11001 & Above A7TW11001 & Above ATZD11001 & Above AZN611001 & Above AZN711001 & Above	6666334	6666333	6675517	6667352	7024037		6727475	6686926 - Spin-on 6692337 - Canister	7176099	7193354
S530 ALR811001 & Above, B42T11001 & Above	7221934	7286322	7012303	7023589						
S550 A3NL11001 & Above, A3NM11001 & Above, AZN911001 & Above, AZN811001 & Above	6666376	6666375	6675517	6667352	7024037		6727475	6686926 - Spin-on 6692337 - Canister	7176099	7193354
S550 AHGM11001 & Above,	7221934	7286322	7012303	7023589						
S550 B3GY11001 & Above								6686926		
S570 A7U711001 & Above A7U811001 & Above AZNB11001 & Above AZNC11001 & Above	6666376	6666375	6675517	6667352	7024037		6727475	6686926 - Spin-on 6692337 - Canister	7176099	7193354
S570 ALM411001 & Above	7221934	7286322	7012303	7023589						
S570 B3GZ11001					7024035	6686926				

The Bobcat Filter Reference Guide is subject to change. Consult your Operation & Maintenance Manual for maintenance intervals and additional maintenance items.

Skid-Steer Loader	Air Filter (Inner)	Air Filter (Outer)	Engine Oil Filter	Fuel Filter	Hydraulic Filter	Case Drain Filter	Hydraulic Fill/Breather Cap	Charge Filter	Heater Filter	Recir. Filter
S590 ANMN11001 & Above ANMP11001 & Above, AZNE11001 & Above AZND11001 & Above	6666376	6666375	6675517	6667352	7024037		6727475	6686926 - Spin-on 6692337 - Canister	7176099	7193354
S590 AR9R11001 & Above	7221934	7286322	7012303	7023589						
S590 B3H111001 & Above					7024035			6686926		
S630 A3NT11001 - 11547; A3NU11001 - 11003	7008044	7008043	6678233	6667352	7002734		6727475	6686926 - Spin-on 6692337 - Canister	7176099	7193354
S630 A3NT11548 & Above; A3NU11004 & Above					7012314 w/7015308					
S630 AHGL11001 & Above, B2L511001 & Above	7221934	7286322	7012303	7023589						
S650 A3NV11001 - 11444; A3NW11001 - 11098	7008044	7008043	6678233	6667352	7002734		6727475	6686926 - Spin-on 6692337 - Canister	7176099	7193354
S650 A3NV11445 & Above, A3NW11099 & Above, 1MLS11001 & Above					7012314 w/7015308					
S650 ALJ811001 & Above, S1ML11001 & Above B2LA11001 & Above	7221934	7286322	7012303	7023589						
S740 B3BT11001 & Above	7010031	7286652	7012303	7023589	7248874		6727475	6686926	7176099	7193354
S750 A3P211001 & Above	7010031	7286652	6678233	6667352	7012314 w/7015308		6727475	6686926 - Spin-on 6692337 - Canister	7176099	7193354
S750 ATDZ11001 & Above			7023589							
S750 AT5211001 & Above			7012303	7248874 w/7248873		6686926				
S770 A3P411001 & Above; A3P511001 & Above ASRV11001 & Above	7010031	7286652		6667352	7012314 w/7015308		6727475	6686926 - Spin-on 6692337 - Canister	7176099	7193354
S770 ATF211001 & Above ATF311001 & Above			7023589							
S770 A3P411001 & Above; A3P511001 & Above ASRV11001 & Above			7012303	7248874		6686926				
S850 ACST711001 & Above; ACSL11001 & Above ATF411001 & Above; ATF511001 & Above,	7010031	7286652	6678233	6667352	7012314 w/7015308		6727475	6686926 - Spin-on 6692337 - Canister	7176099	7193354
S850 B3BY11001 & Above AJ9C11001	7010031	7286652	7012303	7023589	7248874 (w/7248873 for AJ9C11001 & Abv)		6727475	6686926	7176099	7193354

The Bobcat Filter Reference Guide is subject to change. Consult your Operation & Maintenance Manual for maintenance intervals and additional maintenance items.

Skid-Steer Loader	Air Filter (Inner)	Air Filter (Outer)	Engine Oil Filter	Fuel Filter	Fuel Filter - In-Line	Hydraulic Filter
310 4996 11001-13695		897064	6518896		6511393	6515541
310 13696 & above		897064	6518896		6511393	6516722
313		897064	3974113	4121609	6511393	6515541
371	6518241		6518896		6511393	6516722
440 SN: 502811001 & Above		897064			6511393	6661248
440 SN: 5038 13001 & Above	6632071		6652366		6511393	6661248
443 SN: 502911001 & Above SN: 511211001 & Above		897064	3974113		3885315	6661248
444M		6646494	854571B			946865
450	6632071		6652366		6511393	6661248
453 SN: 515011001 above, 515111001 & above	6673753	6673752	6671057		6667352	6599543
453 SN: 561811001, 561911001 & above	6673753	897064	3974113		3885315	6599543
463 SN: 519911001 & Above, 520011001 & Above	6673753	6673752	6671057		6667352	6677652
463 SN: 522111001 & Above, 522211001 & Above, 538911001 & Above, 539011001 & Above	6672468	6672467	6657635		6667352	6677652
500 - Kohler Gas		6646494	854571		6511393	946865
500 - 310 Deutz Diesel		6646494	854571			946865
520 / 530		6646494	6512143	6512106		6515541
533 Isuzu		6646494	6555779	4121609		6515541
540 SN: 501011999 & below		6646494	6512143	6512106		6515541

The Bobcat Filter Reference Guide is subject to change. Consult your Operation & Maintenance Manual for maintenance intervals and additional maintenance items.

Skid-Steer Loader	Air Filter (Inner)	Air Filter (Outer)	Engine Oil Filter	Fuel Filter	Fuel Filter - In-Line	Hydraulic Filter	Heater Filter
540 SN: 501012001 - 13111		6646494	6512143		6511393	6661248	
540 SN: 501012001 - 13112 & above		6646494	6512143				
540 SN: 5010 13006 & below		6646494	6512143		6511393	6661248	
540 SN: 5010 13007 & above		6646494	6512143	6512106		6661248	
542		897064	6647672		6511393	6630494	
543 SN: 501111999 & Below		6646494	6555779		4121609	6515541	
543 SN: 501113235 & Above SN: 511111999 & Below SN: 502412001 & Above	6598222	6646494	3974113	6560348		6630494	
543 SN: 501112001 - 501113234	6598222	6646494	3974113	6560348		6661248	
553 SN: 513011001 & above	6598222	6646494	3974113	3885315		6630494	6660880
553 SN: 516311001 & Above, 516411001 & Above, 520311001 & Above, 520411001 & Above, 528011001 & Above, 528111001 & Above, 539111001 & Above, 539411001 & Above	6672468	6672467	6657635	6667352		6661248	
600 SN: 49501001 & Above, 49511001 & Above, 49521001 & Above, 49561001 & Above, 49601001 & Above, 49891001 & Above		6646494	6513641 854571		6511393	946865	
600 SN: 49541001 & Above, 49551001 & Above, 49741001 & Above, 49751001 & Above, 49761001 & Above, 49771001 & Above, 49781001 & Above						946865	
600 - Wisconsin Engine (VF4D)			6513641		6511393	946865	
600 - Wisconsin Engine w/ (LPG)			6513641			946865	
600 - Petters Engine		6646494			6511393	946865	

Skid-Steer Loader	Air Filter (Inner)	Air Filter (Outer)	Engine Oil Filter	Fuel Filter	Fuel Filter - In-Line	Hydraulic Filter	Hydraulic Filter (In-Line)
600 - Duetz 410 Engine		6646494	4119775	4121609		946865	
610		6646494	6513641 Lube: P550154		6511393	946865	
611		6598491	6511793		6511393	946865	
620		6646494	6513641		6511393	6515541 (10 micron)	6552507 (25 micron)
630 SN: 499511001 & Above		6646494	6513641 Lube: P550154		6512106	6515541 (10 micron)	
630 SN: 12999 & below		6646494	6513641		6512106	6515541 (10 micron)	6557991
630 SN: 13001 & above		6646494	6513641		6512106	6515541 (10 micron)	6558357 (40 Micron)
630 SN: 5984979 & below			6513641				
630 SN: 5984980 & above			6599587				
631 SN: 4977M11001 & Above, 5005M11001 & Above	6598222	6598491	6511793		4121609 3885315	6515541 10 micron	
631 Deutz 411		6598491	6511793		4121609	6515541 10 micron	6558357
631 SN: 13002 & below, Deutz 511		6598491	6511793		3885315	6515541 10 micron	6558357
631 SN: 13003 & above, Deutz 511	6598222	6598491	6511793		3885315	6515541 10 micron	6558357
632 SN: 12999 & below		6646494	6513601		6512106	6515541 10 micron	6557991
632 SN: 13001 & above		6646494	6513601		6512106	6515541 10 micron	6558357
641 SN: 13208 & below	6598362	6598492	6511793		3885315	6515541 10 micron	6563995
641 SN: 13209 & above, below 20607	6598362	6598492	6511793		3885315	6668819	
642 SN: 13523 & below, below 20607		6646494	6513601		6512106	6515541	

Skid-Steer Loader	Air Filter (Inner)	Air Filter (Outer)	Engine Oil Filter	Fuel Filter	Fuel Filter In-Line	Hydraulic Filter	Hydraulic Filter (In-Line)	Heater Filter
642 SN: 13524 & above		6646494	6513601		6512106	6668819	6563995	
642 SN: 20608 & above		6646494	6513601		6511393	6668819	6563995	
642B SN: 504025001 & above		6646494	6632745		6511393	6668819		
642 SN: 13523 & below, below 20607		6646494	6513601		6512106	6515541		
642 SN: 13524 & above		6646494	6513601		6512106	6668819	6563995	
642 SN: 20608 & above		6646494	6513601		6511393	6668819	6563995	
642B SN: 504025001 & above		6646494	6632745		6511393	6668819		
643 SN: 13405 & below	6598362	6598492	6675517		3885315	6515541	6563995	
643 SN: 13525 & above	6598362	6598492	6675517		3885315	6668819		
645	6598362	6598492	6675517		3885315	6668819	6661807	
653	6666334	6666333	6661011		6667352	6661248	6661807	6660880
700 SN: 4957M13001 & Above, 4957MA1001 & Above		6646494			6511393	6515541 10 micron 6552507 25 micron		
720 SN: 4957M13001 & Above, 4957MA1001 & Above		6646494			6511393	6515541 10 micron 6552507 25 micron		
721		6598491	6511793	4121609	6511393	6515541 10 micron 6552507 25 micron		
722		6646494	6513601		6511393	6515541 10 micron 6552507 25 micron		
730 SN: 4998M11001 & Above		6646494	6513641 Lube: P550154		6512106	6515541 10 micron	6558357	

Skid-Steer Loader	Air Filter (Inner)	Air Filter (Outer)	Engine Oil Filter	Fuel Filter	Fuel Filter In-Line	Hydraulic Filter	Hydraulic Filter (In-Line)	Heater Filter	Recir. Filter
731 (411)		6598491	6511793	4121609		6515541 10 micron	6558357		
			Engine Oil Filter						
731 (511) SN: 5006M 11001-13181		6598491	6511793		3885315	6515541 10 micron	6558357		
731 (511) SN: 5006M 13182 & above	6598222	6598491	6511793		3885315	6515541 10 micron	6558357		
732		6646494	6513601		6512106	6515541 10 micron	6558357		
741 SN: 14999 & below	6597362	6598492	6511793		3885315	6515541 10 micron	6563995 (Bronze)		
741 SN: 15001 & above	6597362	6598492	6511793		3885315	6598903			
742 SN: 14999 & below		6646494	6513601 FORD 6632745 Mitsubishi		6512106	6515541 10 micron	6563995 (Bronze)		
742 SN: 15001 & above SN: 20571 & below		6646494	6513601 FORD 6632745 Mitsubishi		6512106	6598903			
742 SN: 20572 & above		6646494	6513601 FORD 6632745 Mitsubishi		6511393	6598903			
742 B		6646494	6632745		6511393	6598903			
743 SN: 14999 & below	6598362	6598492	6675517		3885315	6515541 10 micron	6563995 (Bronze)		
743 SN: 15001 & above 743B 743DS	6598362	6598492	6675517		3885315	6598903			
743B SN: 18001 & above	6598362	6598492	6675517		3885315	6598903	6661807		
			Engine Oil Filter	Fuel Filter					
751 SN: 5147 11001 & above, 5149 11001 & above	6666334	6666333	6661011	6667352		6661248	6661807	6660880	
751 SN: 515611001 & above, 515711001 & above, 751G	6598362	6598492	6675517	6667352		6661248	6661807	6660880 6727140 6677983	6678207

Skid-Steer Loader	Air Filter (Inner)	Air Filter (Outer)	Engine Oil Filter	Fuel Filter	Fuel Filter In-Line	Hydraulic Filter	Hydraulic Filter (In-Line)	Heater Filter	Recir. Filter
753 753 BICS 763 773 7753	6598362	6598492	6675517	6667352		6661248	6661807	6660880	
753G 763G 773G 773G TURBO	6598362	6598492	6675517	6667352		6661248	6661807	6727140 6677983	6678207
825		6646494	6511766		3885315	6591038 10 mic. 6552507 25 mic.			
843 SN: 12999 & below	6598362	6598492	960698		3885315	6559458	6563995 (Bronze)		
843 SN: 13001-13315	6598362	6598492	960698		6599194	6668819	6563920 (Bronze)		
843 SN: 13316-14999	6598362	6598492	960698		3885315	6668819	6563920 (Bronze)		
843 SN: 15001-23999	6598362	6598492	960698		3885315	6668819			
843 SN: 24001 & Above, 843B	6598362	6598492	6659329		3885315	6661248 6668819			
843 High Horsepower	6598362	6598492	6659329		3885315	6630977			
853 SN: 512811001-15999; 5102 50001 & above; 510375001 & above; 508415001-17999; 509715001-17999; 510125001 & above, 853 BICS SN: 512816001 & above; 508418001 & above; 509718001 & above	6598362	6598492	6659329		6667352	6661248	6661807		
853 SN: 5084 11001 & above, 5097 11001 - 14999	6598362	6598492	6659329		6667352	6661248		6660880	
863, 863G 864, 864G 873, 873G 883	6666376	6666375	6665603		6667352	6661248	6661807	6660880 6727140 6677983	6678207
943 SN: 11999 & below	6630940	6630939	6511766		3885315 6511393	6661248	6630977		

Skid-Steer Loader	Air Filter (Inner)	Air Filter (Outer)	Engine Oil Filter	Fuel Filter	Fuel Filter - In-Line	Hydraulic Filter	Hydraulic Filter (In-Line)	Heater Filter	Recir. Filter
943 SN: 12001 & above	6630940	6630939	6511766		3885315 6511393	6668819	6516722 25 MICRON		
953 SN: 11188 & below, 15030 & below	6630940	6630939	6511766		6669033 (Water Trap)	6668819	6516722 25 MICRON	6660880	
953 SN: 11559 & below				6511393					
953 SN: 11189 & above, 15031 & above	6630940	6630939	6511766		3885315 6669033 (Water Trap)	6661248	6516722 25 MICRON	6660880	
963	6681474	6681475	6511766	6670996	6671649 (Water Trap)	6668819			
963G	6681474	6681475	6511766	6670996	6671649 (Water Trap)	6668819	6516722	6727140 6677983	6678207
970 (Gasoline)		6519066	854571 P550154 (Spin-on)	6511393		6511197 6548064(Screen)			
970 (Diesel)		6519066	6511766	6515756	3885315	6511197 6548064(Screen)			
974 SN: 12703 & below		6519066 Old Style 6666333 New Style	6511766		3885315 3551883 (Water Trap)	6511197 Primary 6515541 Secondary 6548064 Screen			
974 - Engine Spec. LD 22557 (Twin Filters)				961048					
974 SN: 12704 & above	6598898	4280099	6511766		3885315 3551883 (Water Trap)	6511197 Primary 6515541 Secondary 6548064 Screen			
975 SN: 12596 & below		6519066 6666333	P550020	6511550		6511197 Primary 6515541 Secondary 6548064 Screen			
975 SN: 12597 & above, 421306 & below	6598898	4280099	P550020	6511550		6511197 Primary 6515541 Secondary 6548064 Screen			
975 SN: 12597 & above, 421307 & above	6598898	4280099	P550020	6668784		6511197 Primary 6515541 Secondary 6548064 Screen			
980	6598898	4280099	1992368	1992366 Primary 1992367 Secondary	6631011	6511197 Primary 6515541 Secondary 6548064 Screen			

Mini-Track Loader	Air Filter (Inner)	Air Filter (Outer)	Engine Oil Filter	Fuel Filter	Hydraulic Filter	Hydraulic Fill/ Breather Cap
MT50	6673753	6673752	6671057	6667352	6653336	6727475
MT52 5236 11001 & above, 5237 11001 & above	6673753	6673752	6671057	6667352	6677652	6728149/ 7025626
MT52 5287 11001 & above, 5288 11001 & above A3WR 11001 & above, A3WS11001 & above, B38R 11001 & above	6687263	6687262				
MT55	6687263	6687262	6671057	6667352	6677652	6728149/ 7025626

Compact Excavator	Air Filter (Inner)	Air Filter (Outer)	Engine Oil Filter	Fuel Filter	Fuel Filter - In-Line	Hydraulic Filter	Hydraulic Filter (In-Line)
56		6636539	6636472(NLA)	6636614(NLA)		6638052(PND NLA)	
76 SN: 11999 & below		6640958	6636670(PND NLA)	6636518(NLA) 6636310(PND NLA) O-Ring	6636757(PND NLA) 6636310(PND NLA) O-Ring (If So Equipped)	6637477(PND NLA) Filter 6637364(NLA) O-Ring	6638413 Strainer 6637349(PND NLA) O-Ring
76 SN: 12001 & above		6640958			6636757(PND NLA) 6636310(PND NLA) O-Ring (If So Equipped)	6649825(PND NLA) Filter	6638413 Strainer 6637349(PND NLA) O-Ring
100		6640708		6636614		6637477(PND NLA) Filter 6637364(NLA) O-Ring	
116 SN: 505011001 thru 505011999		6598491	6639918		6639924 (PND NLA)	6637477(PND NLA) Filter 6637364(NLA) O-Ring 6639870 Strainer 6637351 O-Ring	
116 SN: 505012001 & Above	6673117 (NLA)	6598491	6639918 (NLA)		6639922 (PND NLA)	6637477(PND NLA) Filter 6637364(NLA) O-Ring 6639870 Strainer 6637351 O-Ring	
130		6639912 (PND NLA)	6639919 (NLA)		6639922(PND NLA)	6637477 (PND NLA) Filter 6637352 (PND NLA) O-Ring	
220 SN: 11500 & below		897064	3974113 6675517	6640801	6633977	6653336 10 micron 6661248	
220 SN: 11501 & above		897064	3974113 6685833	6667352	6633977	6653336 10 micron 6661248	
225 SN: 11999 & below		6646494	6675517	6667352 Filter 6682493 Element	6633977	6653336 6661248 6655066 Secondary	6681012
225 SN: 12001 & above		6646494	6675517	6667352 Filter 6682493 Element	6633977	6653336 10micron 6661248	6681012
231 SN: 11999 & below		6598492	6675517	6667352	6633977	6653336 10micron 6661248	6681012
231 SN: 12001 & above		6598492	6675517	6667352	6633977	6653336 10micron 6661248	6681012
316		6988081	3974113	6693354 6698069	NTS2-22001 (Suction)	6653336 10micron	
319	6673753	6673752	6671057	6667352		6653336	

The Bobcat Filter Reference Guide is subject to change. Consult your Operation & Maintenance Manual for maintenance intervals and additional maintenance items.

Compact Excavator	Air Filter (Inner)	Air Filter (Outer)	Engine Oil Filter	Fuel Filter	Hydraulic Filter	Hydraulic In-Line	Hydraulic Breather Cap	HVAC Filter
320 SN: 511720001 & Above		897064	3974113	6667352	6653336			
320 SN: 5117 21116 & above 322 SN: 5178 11001 & above		897064	3974113	6667773	6653336			
320 D SN: 5178 11001 & above, 2245 11001 & above 321 322 D & G Series SN: 2235 11001 & above 323, 324, 418	6673753	6673752	6671057	6667352	6653336		6692836	7010687
325 SN: 5118 20001 - 5118 21999		6646494	6675517	6667352	6653336		6692836	
325 SN: 5140 11001 - 51401 2999 331 SN: 5119 20001 & above, 5129 11001 - 5129 12999	6598362	6598492	6675517	6667352	6653336	6516722	6692836	
325 SN: 5140 13001 & above 328 SN: 5140 13001 & above, 5166 11001 & above	6672468	6672467	6675517	6667352	6653336	6516722	6692836	
325 SN: 2323 11001 & above, 2324 11001 & above, 2341 11001 & above, 2342 11001 & above, A9K0 11001 & above, A9K1 11001 & above, AAC5 11001 & above 328 SN: 2323 11001 & above, 2324 11001 & above, A9K0 11001 & above, A9K1 11001 & above, AAC5 11001 & above 329	6672468	6672467	6675517	6667352	6516722 6661248	6516722	6692836	6691530
331 SN: 5129 13001 & above, 5167 11001 & above, 5177 11001 & above 334 SN: 5129 13001 & above, 5167 11001 & above, 5177 11001 & above	6666334	6666333	6675517	6667352	6653336	6516722	6692836	
331 SN: 2325 11001 & above, 5290 11001 & above, A00B 11001 - A00B 11029, A9K5 11001 & above, AACS 11001 & above 334 SN: 2325 11001 & above, 5290 11001 & above, A00B 11001 - A00B 11029, A9K5 11001 & above, AACS 11001 & above 335	6666334	6666333	6675517	6667352	6516722 6661248	6516722	6692836	6691530

The Bobcat Filter Reference Guide is subject to change. Consult your Operation & Maintenance Manual for maintenance intervals and additional maintenance items.

Compact Excavator	Air Filter (Inner)	Air Filter (Outer)	Engine Oil Filter	Fuel Filter	Hydraulic Filter	Hydraulic In-Line	Hydraulic Breather Cap	HVAC Filter
337 SN: 2306 11001 & above, 5154 11001 & above	6666334	6666333	6675517	6667352	6516722 6670207	6516722	6692836	
341 SN: 2306 11001 & above, 5141 11001 & above								
337 SN: 2332 11001 & above, 5295 11001 & above, A00C 11001 & above, A9W7 11001 & above, AAC8 11001 & above	6666376	6666375	6675517	6667352	6516722 6670207	6516722	6692836	6691530
341 SN: 2332 11001 & above, 5295 11001 & above, A00C 11001 & above, A9W7 11001 & above, AAC8 11001 & above								
418	6673753	6673752	6670373	6667352	6653336		6727475	
425 428	6672468	6672467	6657635	6667352	6661248	6661022	6692836	6691530
430	6666334	6666333	6675517	6667352	6668819	6681012	6692836	6691530
435	6666376	6666375	6675517	6667352	6668819	6681012	6692836	6691530
E08, E10	6673753	6673752	6670373	6667352	6653336		6727475	
E14, E16	6673753	6673752	6671057	6667352	6653336		6692836	6979515 7010687
E20	6673753	6673752	6670373 (AWRH11001 & abv.) 7000507 (B3BL11001 & abv.)	6667352	6661248	7009365	6692836	7176099
E25	6673753	6673752	6657635	6667352	6661248	7009365	6692836	7010331, 7010332 AB8B11001 - 11999 7176099, 7222791 AB8B12001 & Above
E26 AJRY11001 & Above	6672468	6672467	6657635	6667352	6661248	7009365	6692836	7010331, 7010332
E26 ACRA11001 & Above	6673753	6673752						7010331, 7010332 ACRA11001 - 13001 7176099, 7222791 ACRA13002 & Above
E26 B33211001 & Above	6672468	6672467						7010331, 7010332 B33211001 - 11999 7176099, 7222791 B33212001 & Above
E26 B3JE11001 & Above								7176099 7222791
E32 A94H11001 & Above; ACN11001 & Above	6672468	6672467						6675517
E32 B2VV11001 & Above	7020361	6690907	7012303	7023589				
E32 B3K911001 & Above B3CS11001	6672468	6672467	6675517	6667352	7176099 7222791			
E32i AUYJ11001 & Above								

The Bobcat Filter Reference Guide is subject to change. Consult your Operation & Maintenance Manual for maintenance intervals and additional maintenance items.

Compact Excavator	Air Filter (Inner)	Air Filter (Outer)	Engine Oil Filter	Fuel Filter	Hydraulic Filter	Hydraulic In-Line	Hydraulic Breather Cap	HVAC Filter
E35 AR1K11001 & Above	7020361	6690907	7012303	7023589				7176099 7222791
E35 A93K11001 - 17999; AC2P1100 -14999	6672468	6672467	6675517	6667352	6668819	7009365	6692836	7010331 7010332
E35, E35i A93K18001 & Above; AC2P15001 & Above, B3K811001 & Above, B3GR11001 & Above, AUYM11001 & Above (E35i)								7176099 7222791
E42 AG3411001 - 13999	6666376	6666375	6675517	6667352	6668819	6516722	6692836	7010331 7010332
E42 AG3414001 & Above								7176099 7222791
E42 B2VW11001 & Above								7025561
E45 AG3G11001 - 13999, AHHC11001 - 12999	6666376	6666375	6675517	6667352	6668819	6516722	6692836	7010331 7010332
E45 AG3G14001 & Above; AHHC13001 & Above								7176099 7222791
E45 B2VY11001 & Above								7012303
E50 AG3N11001 - 13999; AHHE11001 - 13999	6666376	6666375	6675517	6667352	6670207	6516722	6692836	7010331 7010332
E50 AG3N14001 & Above; AHHE14001 & Above								7176099 7222791
E50 AJ1811001 & Above								7012303
E55 ARWM11001 - 11999; ASW311001 - 11999	6666376	6666375	6675517	6667352	6670207	6516722	6692836	7010331 7010332
E55 ARWM12001 & Above; ASW312001 & Above								7176099 7222791
E55 AJ1911001 & Above								7012303

Compact Excavator	Air Filter (Inner)	Air Filter (Outer)	Engine Oil Filter	Fuel Filter	Hydraulic Filter	Cab Filter	Fuel In-line:	HVAC Filter
442 SN: 5223 11001 & above	5501660914	5501660912	5411316400	5411656567	5380658088	5501661034	5445100004	5501661034
442 SN: 528611001 - 11476, 528911001 - 11484	5501660914	5501660912	5411642211	5411656301	5368632568	5501661034	6687016	5501661034
442 SN: 528611477 & Above, 528911485 & Above	5501660914	5501660912	5411642211	5411656301	5368632568	5501661034	6688168	5501661034
442 SN: ADBR11001 & Above, ADBS11001 & Above	5501660914	5501660912	5411642211	5411656301	5368632568	5501661034		5501661034
444	5501660924	5501660922	5411656298	5411656493	5380658088	5501661034	5445100004	5501661034

Compact Excavator	Air Filter (Inner)	Air Filter (Outer)	Engine Oil Filter	Fuel Filter	Fuel Separator Filter	Brake Hydraulic Filter	Hydraulic Breather Filter	Hydraulic Return Filter	Hydraulic Strainer/Suction Filter	HVAC Filter
E55W	6666334	6666333	7025590	7010351	7013148	7011915 (AEFB10001-1216) 7275347 (AEFB11217 & abv)	7006806 (AEFB10001 - 11229) 7276395 (AEFB11230 & Above)	7004883	7005889	7006085
E60 AET810001-11749, AGSZ10001-11749	6666334	6666333	7025590	7010351	7013148	7011915	7006806	7004883	7006810	7006085
E60 AET811750 & abv., AGSZ11750 & abv.							7276395			
E62 B34P1001 - 1103	6666334	6666333	7025590	7010351	7013148	7011915	7006806	7004883	7006810	7006085
E62 B34P1104 & Above							7276395			
E63 B34R1001-1184	6666334	6666333	7025590	7029016	7013148	7011915	7006806	7004883	7006810	7006085
E63 B34R1185 & Above							7276395			
E80 AET310001 -1290, AETB10001 - 12910	6666334	6666333	7025590	7010351	7013148	7011915	7006806	7004884	7006811	7006085
E80 AET312911 & Above, AETB12911 & Above.							7276395			
E85 B34T1001 - 2014	6666334	6666333	7025590	7029016	7029012	7004879	7006806	7004884	7006811	7006085
E85 B34T2015 & above							7276395			
E85 B34S11001 - 2014						7006806				
E85 B24S2015 & above						7276395				

Compact Excavator

Compact Excavator

The Bobcat Filter Reference Guide is subject to change. Consult your Operation & Maintenance Manual for maintenance intervals and additional maintenance items.

Compact Tractor	Air Filter (Inner)	Air Filter (Outer)	Engine Oil Filter	Fuel Filter	Hydrostatic Filter	Hydraulic Filter	Hydrostatic Cap
CT120 CT122		6673752	6694509	6694422	6695914	6695918	6697543
CT225 CT230 CT235	6666334	6666333	6696286	6695912	6695914	6695913	6695641
CT335 CT440 CT445 CT450	6666334	6666333	6696286	6695912	7002299	7250475	6695641

Utility Vehicle	Air Pre-Filter	Air Filter	Engine Oil Filter	Air Breather Filter	Engine Breather Filter	Fuel Filter	In-line Fuel Filter	CVT Filter	Hydraulic Filter
2100 2100S		1015426CC	103887901CC			102003201CC			
2200/2200S Diesel Engine		6672467	6671057			6667352	102434701CC		
2200/2200S Honda Engine		6672467	P502007			102657301CC	102003201CC		
2200/2200S Kawasaki Engine		6672467	103887901CC			102657301CC	102003201CC		
2300		6672467	6671057			6667352	102434701CC		
3200	7016382	7016381	7017416	7018886	7016378		7016379	7016384	
3400 AJNT 3400 XL AJNV(Gas Versions)	7016382	7016038	7017416	7018886	7016378			7016384	
3400 B3FL (Gas Version)		6672467	7257438	7018886		6988961			
3400 XL B3FN(Gas Version)		6672467	7018465	7018886					
3400 AJNU 3400 XL AJNW(Diesel Versions)	7016382	7016038	7018465	7018886		6988961		7016384	
3400 B3FK 3400 XL B3FM(Diesel Versions)		6672467	7257441			7257117			
3450 (Diesel Versions)	7016382	7016038	7018465	7018886		6988961			
3600 AVW211001 & Above 3650 AVW411001 & Above	7025283	6672467	7018465			6988961			6686926
3600 B3C211001 & Above 3650 B3C311001 & Above		6672467	7257441			7257117			7023342

Utility Vehicle

Utility Vehicle

The Bobcat Filter Reference Guide is subject to change. Consult your Operation & Maintenance Manual for maintenance intervals and additional maintenance items.

Toolcat	Air Pre-Filter	Air Filter (Outer)	Engine Oil Filter	Fuel Filter	Fuel Filter - In-Line	Hydraulic Filter	Hydraulic In-Line	Heater Filter
5600 SN: 5205 11001 & above, 4247 11001 & above, 4248 11001 & above, A002 11001 & above, A003 11001 & above	6666334	6666333	6675517	6667352		6516722, 6668819		6727140
5600 SN: A0W0 11001 5610 SN: A7Y711001 & above	6983022	6983021	6675517	6667352		6516722, 6668819		6727140
5600 SN: A94Y11001 & above 5610 SN: APFB11001 & above	7003490	7003489	6675517	6667352		6516722, 6668819		6727140
5600 SN: AHG811001 & Above 5610 SN: B2LH11001 & Above	7003490	7003489	7012303	7023589		6686217, 6668819		6727140

Versahandler TTC	Air Filter (Inner)	Air Filter (Outer)	Engine Oil Filter	Fuel Filter	Hydrostatic Filter	Hydraulic Filter	Hydraulic Breather Cap	Recirculation Filter
V417 SN: A7MK 11001 & above, A7ML 11001 & above	6910726	6910725	6678233	6667352	6919493	6661248	6917778	6910502
V417 SN: AC1C11001 & Above, AC1D11001 & Above	75687-4	95686-6	6678233	6667352 7251998	6919493	6661248	6917778	6910502
V518 SN: 3670 11001 & above, 3673 11001 & above V623 SN: 3671 11001 & above, 3672 11001 & above, 3674 11001 & above, 3675 11001 & above			6511766	64903-8 64978-0 6669033 3551883	75990-2	6913059	6917778	6910502
V519	7010031	7286652	7012303	7023589	7219048	7225338	6727475	7228497
V518 SN: A8G8 13000 & above, A8G9 13000 & above V638 SN: A8HM 13000 & above, A8HN 13000 & above V723 SN: A8HP 13000 & above, A8HL 13000 & above, A8HK 13000 & above	6910726	6910725	6511766	6911907	6919913	6913059	6917778	6910502
VR518 VR638	6910726	6910725	36925-6	6911907	6919913	6913059	6917778	6910502
VR530c VR723	6910726	6910725	36925-6	6911907	75990-2	6913059	6917778	6910502

Articulated Loader	Air Filter (Inner)	Air Filter (Outer)	Engine Oil Filter	Fuel Filter	Fuel Filter In-Line	Hydraulic Filter	Heater Filter
1600	6598362	6598492	6675517		3885315	6598903	
2000 SN: 12001 & above	6598362	6598749	960698		3885315	6598903	
2000 SN: 12999 & below	6598362	6598749	960698		3885315	6559458 8" Long 6515541 5.5" Long	
2000 SN: 13001 & above, 2000RTF	6598362	6598749	960698		3885315	6515541 6598903	
2400, 2410	6630940	6630939	6511766		3885315 6511393	6668819	
AL275	5501660914	5501660912	6675517	6683139		5003650368 N/A	5388665486 N/A
AL350	5501660914	5501660912	6678233	6689336 N/A	6680796	5003820082 N/A	5388665486 N/A
AL440	5501660914	5501660912	6678233	6689336 N/A	6680796	5003820082 N/A	5388665486 N/A

Feller Buncher	Air Filter (Inner)	Air Filter (Outer)	Engine Oil Filter	Fuel Filter (In-Line)	Hydraulic Filter
1213	6598362	6598492	6659329	3885315	6661248 Primary 6668819 Secondary

Loader Backhoe	Air Filter (Inner)	Air Filter (Outer)	Engine Oil Filter	Fuel Filter	Fuel Filter - In-Line	Hydraulic Filter
B100 B100T B100T B-Series		6961194 6960207 6960959 Turbo	6657635	6640801 6960823	6633977	6961187 6960724
B200 B250 B250 B-Series		6961194	6657635 6675517	6640801	6633977	6961187
B250 B-Series Tier II SN: 5729 11001 & above	6672468	6672467	6657635	6667352	6633977 PreFilter	6961187
B300 SN: 5713 11001 & above		6682497 6961194 6961287 Turbo	6675517 6657635	6682493 6640801	6683101	6961199 6961187
B300 Tier I SN: 5723 11001 & above		6682497	6675517	6682493 6640801	6683101 PreFilter	6961199 6961187
B300 Tier II SN: 5731 11001 & above	6666334	6666333	6675517	6667352 6640801	6683101 PreFilter	6961199 6961187
BL275		6960959 6682494	6657635 6675517	6640801	6633977 PreFilter	6969403 6961187
BL370 BL375 BL470 BL475		6682497 6961194 6961287 Turbo	6675517	6682493 6640801	6683101 PreFilter	6961199 3974113 6961187
BL570 BL575		6682497 6961194 6961287 Turbo	6675517	6682493 6640801	6683101 PreFilter	6961811 6961199

Compaction

Compaction	Air Filter (Inner)	Air Filter (Outer)	Engine Oil Filter	Fuel Filter	Fuel Filter - In-Line	Hydraulic Filter
BCA12		IR54489034	IR54485917		IR54489026	IR43919083
BCA14	IR54477195	IR43919166	IR54477096	IR36791929	IR54477161	IR59213041
BCA24	IR15193234	IR14519261	IR544770104	IR54477153	IR54477161	IR59764498
BCT13	IR54477195	IR54477187	IR54647680	IR13248497	IR54477161	IR58874769

Compaction

Telescopic Handlers

Telescopic Handlers	Air Filter (Inner)	Air Filter (Outer)	Engine Oil Filter	Fuel Filter	Fuel Filter - In-Line	Hydraulic Filter	Recirculation Filter
T2250	6910726	6910725	6678233	6667353		6661248 Primary 6919493 Secondary	6918862
T2556 T2566 T35100 T35100L T35100SL T35120L T35120SL T3571 T3571L T40140 T40170	6910726	6910725	6911905	6911907	6915875 Prefilter	6913059	6910502

Telescopic Handlers

Light Construction	Air Filter (Inner)	Air Filter (Outer)	Fuel Filter
Air Compressor			
BA2	IR70243399	IR70243712	
BA2T	IR32336901	IR32337313	
BA5.5	IR70243399	IR70243712	
BA9		IR70243712	
Generator			
BG3.5		IR85491462	IR85491355
BG3H, BGT			IR16534018
BG5, BGE7		IR85491363	IR85491686
BG5H		IR54573928	
BGE7H		IR24898249	
Plate Compactors			
BC70 SN: 2328482 & below		IR13221312	IR54475751
BC70 SN: 2328483 & above		IR13221312	IR54475744
BC90 SN: 2827376 & below		IR54475447	IR54475751
BC90 SN: 2827377 & above		IR54475447	IR54475744
BC110		IR54475447	IR54475744
BCR70		IR59853812	IR59853366
BC15 SN: 2328482 & below		IR13221312	IR54475751
BC15 SN: 2328483 & above		IR13221312	IR54475744
BC19, BC22		IR54475447	IR54475744

Light Construction

Light Construction

The Bobcat Filter Reference Guide is subject to change. Consult your Operation & Maintenance Manual for maintenance intervals and additional maintenance items.