

General Power Equipment Co.
Service Department
201 E. Brink St.
Harvard, Illinois 60033
815/943-7421

Atlas

Effective January 15, 1986
(Supersedes all previously published
Atlas Master price Lists.)

ATLAS/GENERAL POWER PARTS INTERCHANGE

The following interchange list is provided to change Atlas part numbers to the current General Power Equipment (GPE) part numbers. Atlas Power Equipment now uses the GPE part numbers. This list is for equipment produced prior to the 1985 model year. To use, refer to the original Atlas part number. Listed with the Atlas number is the GPE part number. The GPE number listed is in the current GPE Master Parts Price List or Snowthrower supplement.

OBSOLETE PARTS ARE NOT LISTED.

Part number listed may not be an exact replacement, however, it will interchange.

Atlas Part No.	G.P.E. Part No.	Description	Atlas Part No.	G.P.E. Part No.	Description	Atlas Part No.	G.P.E. Part No.	Description
1-68	707026	Auger Assy., 11T	2-235	454942	Housing, Blade	3-162	498048	Wheel
1-108	030270	Blade, 19" Offset	2-239	455014	Housing, Transmission	3-163	497875	Wheel, 7½" Ball Bearing
1-109	030296	Blade, 20" Offset	2-240	455030	Housing, Blade	3-164	498691	Wheel
1-110	030338	Blade, 21" Offset			(Specify model number)	3-165	497917	Wheel Assy., 10" x 5/6 I.D.
1-111	030353	Blade, 22" Offset						
1-113	409920	Auger Assy., 30T	2-241	455048	Housing, Blade	3-166	497933	Wheel, L.H.
1-114	409946	Blade, Scraper	2-243	455089	Housing, Mower	3-167	497958	Wheel, R.H.
1-121	410035	Blade, Shredder	2-244	455097	Housing	3-168	498659	Wheel
1-128	410126	Blade, Shredder w/Stiffener	2-247	455147	Housing, Gear Box	3-169	041053	Wheel
			2-248	455162	Housing Assy., Auger	3-171	498048	Wheel, 8" Plastic
1-132	410183	Auger Assy., L.H.	2-249	455196	Housing Assy., Gear Box	3-174	498618	Wheel
1-133	410225	Auger Assy., R.H.				3-181	498659	Wheel
1-139	410290	Blade, 21" Mulcher	2-250	455220	Housing Assy., Gear Box	3-182	498212	Wheel
1-143	410399	Auger Assy., L.H.				3-183	498220	Wheel
1-144	410423	Auger Assy., R.H.	2-254	455642	Housing	3-186	498212	Wheel, R.H.
1-147	410464	Impeller Assy.	2-255	028282	Housing	3-187	498220	Wheel, L.H.
1-148	712117	Shell, Auger	2-256	028142	Housing, Mower	3-190	498261	Wheel, R.H.
1-149	712117	Paddle	2-257	455345	Housing, Mower			15 x 6.00-6
1-150	712117	Paddle	2-258	028142	Housing, Mower	3-191	498279	Wheel Assy., L.H.
1-152	410555	Blade, 20" Offset	2-259	455493	Housing			15 x 6.00-6
1-153	712117	Auger Assy.	2-261	455428	Housing Assy., Trans.	3-192	498618	Wheel
			2-262	455451	Housing Assy., Trans.	3-193	498295	Wheel, 7" Plastic
2-130	028209	Housing, Mower	2-264	028993	Housing, Mower	3-196	498337	Wheel, 8" Drive
2-131	028399	Housing, Mower	2-265	455519	Housing, Mower	3-198	498352	Wheel Assy., 10" x 5/8 I.D.
2-133	454371	Housing	2-266	455535	Housing, Mower	3-199	498360	Wheel Assy., 10" x 1/2 I.D.
2-134	454769	Housing Assy.	2-267	455550	Housing, Mower	3-200	498394	Wheel, 6" Plastic
2-151	453852	Housing, Mower	2-268	455576	Housing, Mower	3-201	498469	Wheel
2-159	028399	Housing			(Specify model number)	3-202	040741	Wheel, Drive
2-165	454017	Housing, Clutch				3-203	498592	Wheel
2-176	453852	Housing	2-269	455584	Housing, Mower	3-204	497545	Wheel
2-186	454264	Housing, Mower	2-272	455634	Housing, Auger	3-205	498444	Wheel, 8" Sleeve
2-191	594770	Housing, Top Assy.	2-273	455642	Housing, Auger	3-207	498469	Wheel, 7" Plastic
2-192	454488	Housing	2-277	455709	Housing, Mower	3-208	498592	Wheel
2-194	454355	Housing, Bottom				3-211	498519	Wheel, R.H.
2-195	454363	Housing, Top	3-49	499137	Wheel 4" Auxiliary	3-212	498543	Wheel, L.H.
2-196	454371	Housing, Gear	3-59	497826	Wheel	3-213	498865	Wheel, 8" Plastic
2-197	454769	Gear Housing Assy.	3-60	498691	Wheel	3-216	498584	Wheel, 7" Plastic
2-198	454421	Housing, Mower	3-62	499327	Wheel, 6" Sleeve Brg.	3-217	498592	Wheel, 8" Plastic
2-199	454439	Housing, Mower	3-64	041046	Wheel	3-218	498600	Wheel, 6" Plastic
2-201	454488	Housing, Center Assy.	3-65	040386	Wheel	3-219	498618	Wheel, 7" Plastic
2-204	454520	Housing, Top Assy.	3-66	498691	Wheel	3-220	041053	Wheel, 8" Plastic
2-205	454538	Housing, Bottom	3-68	499392	Wheel, 8" Gear Tread	3-221	498659	Wheel
2-207	454553	Housing, Top Rear	3-88	040386	Wheel	3-222	498659	Wheel, 8" Plastic Drive
2-214	454645	Housing, Mower	3-90	041111	Wheel	3-223	041046	Wheel, 7" Sleeve
2-215	454652	Housing, Mower	3-91	498691	Wheel	3-224	041111	Wheel, 8" Sleeve
2-217	454769	Gear Housing Assy.	3-92	041046	Wheel, 7½" Sleeve Brg.	3-225	498691	Wheel, 8" Ball Bearing
2-222	454769	Gear Housing Assy.	3-106	041095	Wheel, 8" Gear Tread	3-226	040386	Wheel, 7" Ball Bearing
2-224	454785	Housing Assy., Auger	3-118	497545	Wheel	3-228	498725	Wheel, 7" Sleeve
2-225	454801	Housing Assy., Gear Box	3-133	498618	Wheel	3-229	041111	Wheel, 8" Sleeve
			3-134	497545	Wheel	3-230	498758	Wheel, 8" Ball Bearing
2-226	454819	Housing	3-135	041111	Wheel, 8" Sleeve Brg.	3-234	040246	Wheel, 7" Plastic
2-227	454835	Housing, Disc Drive	3-143	497651	Wheel, 7½" Plastic	3-235	498808	Wheel, 10" x 1/2 I.D.
2-232	454900	Housing, Blade	3-158	497818	Wheel Assy., Spoke	3-236	498816	Wheel, 10" x 1/2 I.D.
2-233	454926	Housing, Blade	3-159	497826	Wheel Assy.,	3-237	498824	Wheel, 7" Plastic
2-234	454934	Housing, Blade			10" x 1/2" I.D.	3-240	498865	Wheel

Atlas Part No.	G.P.E. Part No.	Description	Atlas Part No.	G.P.E. Part No.	Description	Atlas Part No.	G.P.E. Part No.	Description
3-241	041079	Wheel	5-26	750901	Grip, Lever	7-390	771022	Drag Bracket Assy.
4-141	731083	Handle	5-30	750950	Grip	7-395	771097	Handle Bracket
4-142	731067	Handle	5-31	750968	Grip	7-396	771105	Bracket, Brake
4-161	730911	Handle, Clutch	5-32	750992	Grip, Metal	7-397	771121	Bracket Assy., Switch
4-163	730937	Handle, L.H.	6-26	762708	Clevis Assy., Tiller	7-398	771139	Bracket, Shift Lever
4-164	730945	Handle, R.H.	6-45	762906	Yoke, Mower	7-403	697136	Bracket
4-167	730978	Handle, Clutch	6-46	762930	Yoke, Clutch	7-404	771238	Bracket Assy., Axle
4-169	731000	Handle Bar Assy.	6-47	763318	Yoke	7-405	771253	Bracket, Idler Drive
4-172	731075	Handle	6-48	763110	Yoke	7-408	771295	Bracket, Speed Control Lever
4-173	731109	Handle	6-55	763136	Yoke	7-410	771337	Bracket, Axle Bearing
4-174	731067	Handle, Folding	6-56	763060	Clevis	7-414	771386	Bracket
4-175	731075	Handle, Folding	6-58	763086	Yoke	7-417	771428	Bracket Assy., Height Adj.
4-176	731083	Handle, Folding	6-59	763094	Yoke	7-420	771477	Bracket Ass., Yoke Right
4-177	731091	Handle, Shredder	6-61	763110	Yoke	7-421	771493	Bracket Assy., Yoke Right
4-178	731109	Handle, Upper	6-62	763318	Yoke	7-422	771527	Bracket Assy., Yoke Left
4-179	731117	Handle, Shredder	6-63	763136	Yoke	7-423	771535	Bracket, Chute
4-181	731109	Handle	6-64	763151	Yoke	7-425	771576	Bracket, Depth Bar
4-182	731083	Handle	6-65	763169	Yoke	7-426	771600	Bracket
4-185	731216	Handle Bar Assy.	6-66	419614	Clevis	7-432	771675	Bracket, Clamp
4-187	731232	Handle, Traction Clutch	6-67	763201	Yoke	7-433	771691	Bracket, Hinge
4-188	731240	Handle, Traction Clutch	6-68	763227	Yoke Assy., Traction Engagement	7-434	742015	Bracket
4-189	731257	Handle Assy., Auger Clutch	6-70	763250	Yoke, Speed Control	7-436	771733	Bracket
4-191	731281	Handle Assy., Auger Clutch	6-71	763268	Yoke	7-437	771766	Bracket
4-192	731307	Handle Assy.	6-72	763276	Yoke	7-438	771782	Bracket
4-194	662064	Handle Assy.	6-73	763284	Yoke	7-441	771832	Bracket
4-198	731406	Handle Bar Assy.	6-76	763318	Yoke	7-442	771857	Bracket
4-200	731455	Handle Assy., Speed Control	6-77	763318	Yoke	7-452	771972	Bracket, Yoke L.H.
4-202	731505	Handle, L.H.	6-78	763359	Yoke, Speed Control	7-454	771766	Bracket
4-203	731539	Handle, R.H.	6-80	763383	Clevis, U-Joint	7-456	772020	Bracket, Axle Support
4-205	731559	Handle, Upper	6-83	763425	Yoke	7-460	772152	Bracket
4-206	731570	Handle, Clutch	6-84	070227	Yoke Bracket, L.H.	7-461	772178	Bracket
4-208	731596	Handle, Upper	6-85	070219	Yoke Bracket, R.H.	7-462	772152	Bracket
4-209	731612	Handle, Door	6-86	763458	Yoke	7-463	772178	Bracket
4-214	731695	Handle, Clutch	7-32	769984	Bracket, Furrower	7-466	772152	Bracket, Yoke L.H.
4-215	731703	Handle, Tiller L.H.	7-126	767707	Bracket, Grass Catcher	7-467	772178	Bracket, Yoke R.H.
4-216	731711	Handle, Tiller R.H.	7-154	768028	Bracket, Fork	7-473	772244	Bracket
4-221	731802	Handle Weldment	7-230	768887	Bracket, Drag Bar	7-476	772293	Bracket, Rel. Arm Pivot
4-222	731810	Handle, Folding	7-234	768460	Bracket	7-480	772376	Bracket Assy., Cable
4-224	732545	Handle	7-237	768952	Bracket, Yoke L.H.	7-485	772434	Bracket, Chute Adj.
4-225	731844	Handle, Folding	7-238	768960	Bracket, Pinion Tube	7-489	772491	Bracket Assy., Cable
4-226	731851	Handle, Mower	7-245	769067	Bracket	7-495	772566	Detent, Clutch Adj.
4-227	731877	Handle, Clutch	7-262	770954	Bracket	7-497	772616	Bracket
4-228	731901	Handle, Clutch	7-263	770628	Bracket	7-498	772632	Bracket
4-231	731950	Handle, Traction Clutch	7-282	769620	Bracket	7-499	772657	Bracket
4-232	731976	Handle, Auger Clutch	7-283	769653	Bracket	7-504	772749	Bracket, Panel Support
4-233	731984	Handle, Folding	7-284	769513	Bracket, Clutch	7-507	772780	Bracket
4-234	731992	Handle, Folding	7-290	769778	Bracket	7-512	772848	Bracket, Cable
4-238	732073	Handle, Clutch	7-294	770594	Bracket, Yoke L.H.	7-513	772889	Bracket, Idler Mtg.
4-239	732081	Handle, Upper	7-295	770628	Bracket, Yoke R.H.	7-518	772954	Drag Bracket Assy.
4-240	732107	Handle, Clutch	7-302	769778	Bracket, Idler	7-521	773010	Bracket, Cable
4-241	732115	Handle, Clutch	7-330	770123	Bracket	7-523	773044	Bracket, Yoke L.H.
4-249	732560	Handle	7-331	770149	Bracket	7-524	773085	Bracket, Wheel
4-250	732230	Handle, Lower	7-332	770156	Bracket, Upper	7-584	773085	Bracket
4-252	732313	Handle, Clutch	7-339	770222	Plate, Shaft Lock			
4-253	732321	Handle, Starter	7-340	770248	Bracket			
4-254	732347	Handle Clutch	7-341	770255	Bracket, L.H.	8-57	781088	Control, Throttle
4-255	732362	Handle, Clutch	7-342	770263	Bracket, R.H.	8-67	781195	Control, Throttle
4-256	732388	Handle, Clutch	7-345	770743	Bracket	8-84	781393	Control, Throttle
4-258	732420	Handle, Upper	7-347	770743	Drag Bracket	8-85	781419	Control, Throttle
4-259	732446	Handle, Upper	7-349	770347	Bracket, Handle L.H.	8-86	781427	Control, Throttle
4-260	732479	Handle, Clutch	7-350	770396	Bracket, Handle R.H.	8-87	050104	Control
4-261	732487	Handle, Upper	7-352	770412	Bracket, Shift Lever	8-88	780106	Control, Clutch
4-263	732511	Handle, Upper	7-353	770438	Bracket	8-89	050047	Control, Throttle
4-264	732537	Handle, Upper	7-361	770537	Bracket, Fork	8-90	050104	Control, Throttle
4-265	732545	Handle, Upper	7-362	770594	Bracket	8-91	050104	Control, Throttle
4-266	732560	Handle, Upper	7-363	770628	Bracket	8-92	050104	Control
4-267	732602	Handle, Clutch	7-364	770594	Bracket	8-93	780106	Control
4-268	732610	Handle, Clutch	7-365	770628	Bracket	8-94	050104	Control
4-273	732701	Handle, Clutch	7-368	770669	Bracket, Strain Relief	8-96	781542	Control, Throttle
4-274	732727	Handle, Clutch	7-370	770719	Drag Bracket Assy.	8-97	781559	Control, Throttle
4-275	732735	Handle, Folding	7-371	770743	Drag Bracket Assy.	8-98	781567	Control, Throttle
4-276	732743	Handle, Upper	7-372	770750	Saf-T-Lift	8-99	781575	Control, Throttle
4-277	732776	Handle, Clutch	7-373	770768	Slide	8-100	780106	Control, Clutch
4-279	732818	Handle, Upper	7-375	770784	Yoke & Battery Brkt.	8-102	780106	Control
4-285	732933	Handle, Upper	7-376	770792	Bracket, Magnet	8-106	780197	Crank Assy.
4-291	733030	Handle, Upper	7-379	770826	Slide, LR & RF	8-107	780213	Control, Handle Drive Clutch
4-294	071464	Handle	7-380	770842	Slide, RR & LF			
4-295	071472	Handle	7-381	770859	Bracket, Right	8-108	780221	Control, Throttle
			7-382	770867	Bracket, Left	8-109	780239	Control, Throttle
			7-383	770891	Drag Bracket Assy.	8-110	780254	Control, Throttle
5-5	751032	Grip	7-384	770925	Wheel Bracket Assy.	8-111	780262	Control, Throttle
5-13	750760	Grip, Mower	7-385	770933	Bracket, Clutch Handle	8-112	780320	Control
5-19	750828	Grip	7-386	770958	Bracket, Switch	8-113	780320	Control
5-21	750851	Grip, Lever	7-387	770974	Bracket, Handle Mtg.	8-114	780296	Control, Throttle
5-25	750893	Grip	7-389	771006	Bracket, Idler Mtg.			(for manual choke)

Atlas Part No.	G.P.E. Part No.	Description	Atlas Part No.	G.P.E. Part No.	Description	Atlas Part No.	G.P.E. Part No.	Description
8-114A	780296	Control, Throttle (for remote choke)	10-272	570499	Trailguard	12-170	427906	Plate
			10-273	414573	Trailguard	12-171	435198	Plate
8-115	780304	Control, Throttle	10-274	414581	Cover, Pinion	12-174	770784	Plate
8-116	780312	Control, Throttle	10-276	414615	Trailguard	12-175	428185	Back Plate
8-117	780320	Control, Throttle	10-279	414656	Cover, Pinion	12-178	428367	Plate
8-118	780338	Control, Throttle	10-282	414714	Cover, Belt	12-179	428383	Plate
8-119	780346	Control, Throttle	10-283	125419	Trailguard	12-181	662031	Plate
8-120	780361	Control, Throttle				12-183	428284	Plate Assy.,
8-122	780403	Control, Handle Auger Clutch	11-17	423616	Bearing, Sleeve			Bearing Tube
			11-18	423731	Bearing, Tiller	12-187	428342	Plate, Bearing
8-123	780429	Control, Handle Drive Clutch	11-19	423830	Bearing			Drive Shaft
			11-24	424036	Bearing, Wheel	12-188	428359	Plate Assy.,
8-124	780437	Control, Choke	11-25	424044	Bearing, Wheel			Spindle Mounting
8-125	780445	Control, Clutch	11-30	424101	Bearing, Mower	12-189	428367	Plate, RR & LF
8-126	780452	Control	11-32	424127	Bearing, Eccentric	12-190	428383	Plate, LR & RF
8-128	780494	Control Panel Assy.	11-33	424135	Bearing	12-192	428284	Plate Assy.,
8-129	780502	Control, Throttle	11-34	424143	Bearing			Bearing Tube
8-130	780528	Control, Clutch	11-35	424150	Bearing	12-193	428433	Plate, Q.W.A., LR & RF
8-131	780536	Control, Throttle	11-36	424168	Bushing	12-194	428441	Plate, Q.W.A., LF & RR
8-133	050385	Control, Throttle	11-37	424242	Bearing	12-195	428458	Plate
8-134	780569	Control, Throttle	11-38	424184	Bearing, Mower	12-198		Plate (Order 428623 for
8-135	780577	Control Drive	11-43	424242	Bushing, Flange			RF, LR; 428631 for
9-52	788943	Switch, Shredder	11-63	424465	Bearing, Flange			LF & RR)
9-53	788968	Switch	11-64	424473	Bearing, Flange	12-199	090290	Plate, Q.W.A.
9-54	788968	Switch	11-89	424747	Bearing, Flange	12-204	428573	Plate, Q.W.A., RF, LR
9-55	788976	Switch	11-90	424762	Bearing, Flange	12-205	428581	Plate, Q.W.A., LF, RR
9-57	788992	Module (B & S)	11-92	424788	Bearing, Flange	12-206	428607	Plate Assy., Electric
9-58	789040	Module	11-93	424796	Bearing, Nylon			Motor Base
9-59	789024	Module (B & S)	11-94	424804	Bearing, Ball	12-208	428623	Plate, Q.W.A., RF, LR
9-60	789040	Module (Tecumseh)	11-95	424812	Bearing, Sleeve	12-209	428631	Plate, Q.W.A., LF, RR
9-61	789057	Module (B & S)	11-96	424820	Bearing, Flange	12-210	428664	Plate, Q.W.A., RF, LR
9-63	789081	Switch & Harness Assy.	11-97	424838	Bearing, Flange	12-211	428714	Plate, Q.W.A., LF, RR
9-64	132993	Switch	11-99	424853	Bushing, Flange	12-212	090431	Plate, Q.W.A., LF, RR
			11-104	422840	Bearing, Ball	12-213	090449	Plate, Q.W.A., RF, LR
10-121	412312	Cover, Gear Housing	11-106	422865	Bushing, Spacer	12-214	090555	Plate, Q.W.A., RF, LR
10-122	412338	Cover, Tiller	11-107	422881	Bushing, Cable	12-215	090563	Plate, Q.W.A., LF, RR
10-123		Cover Assy. (Use 412338 w/423731 & 774547)	11-109	422907	Bearing, Sleeve			
			11-115	422972	Bearing, Flange	13-8	433136	Sleeve
			11-117	133249	Bearing, Wheel	13-15	432922	Sleeve
10-152	412676	Cover, Belt	11-124	707638	Bushing	13-16	432930	Sleeve, Clutch
10-164	412833	Cover, Chain	11-135	423202	Bearing, Flange	13-18	432963	Sleeve
10-187	413088	Guard, Trailing	11-137	423228	Bearing, Needle	13-19	432971	Sleeve
10-188	413096	Guard, Trailing	11-143	423293	Bushing	13-24	468272	Sleeve
10-189	413104	Guard, Trailing	11-145	423319	Bearing			
10-190	413120	Guard, Trailing	11-146	423327	Bushing, Wire	14-31	436154	Stiffener, Bracket
10-191	413138	Cover, Main Support	11-147	423335	Bushing, Bar			
10-192	413179	Guard, Toe 21"	11-149	423350	Bearing	15-21	126466	Adapter, Mower Blade
10-193	413203	Guard, Toe 19"	11-151	423384	Bushing, Terminal	15-26	437418	Adapter, Blade Assy.
10-197	413245	Cover, Belt	11-155	423434	Bearing, Needle	15-31	437491	Adapter, Blade
10-201	413914	Guard	11-156	423442	Bearing, Oilite	15-32	437509	Adapter, Blade
10-206	413435	Cover, Chain	11-158	423467	Bearing, Axle	15-33	437590	Adapter, Bag
10-207	413914	Guard	11-159	423475	Bearing, Drive Shaft	15-34	437616	Adapter, "A" Frame
10-208	413468	Cover, Chain	11-160	423491	Bearing, Roller Shaft	15-35	437657	Adapter
10-211	413534	Cover	11-161	423509	Bearing, Needle	15-36	437657	Adapter, Blade
10-212	413534	Cover, Chain & Belt	11-162	423517	Bearing, Race Thrust	15-37	437665	Adapter, Chute
10-213	413567	Cover, Handle Brace	11-163	423525	Bearing, Thrust	15-38	437673	Adapter, Blade
10-214	413583	Guard, Belt	11-164	423533	Bearing, Auger	15-39	437699	Adapter Assy., Blade
10-216	413617	Cover, Chain	11-165	423558	Bearing & Retainer			
10-217	413633	Guard, Belt			Assy., Auger	16-1	150276	Key, Woodruff
10-222	413757	Guard, Belt	11-166	423566	Bearing & Retainer	16-2	446401	Key, Square
10-223	414045	Guard			Assy., Impeller	16-3	446518	Key, Woodruff
10-228	414300	Cover	11-167	423582	Bearing, Impeller	16-4	446666	Key
10-234	413914	Guard, Trailing	11-168	423590	Thrust, Race	16-7	446740	Key, Square
10-237	413971	Guard, Trailing	11-169	423608	Bearing	16-8	446765	Key, Pawl
10-238	413997	Cover, Gear	11-170	423624	Bearing	16-9	446773	Key, Woodruff
10-239	414003	Cover, Transmission	11-171	423632	Bearing	16-11	446518	Key
10-240	414037	Guard, Trailing	11-172	423657	Bearing, Plate Assy.	16-13	446773	Key
10-241	414045	Guard, Trailing	11-173	423665	Bearing, Drive Shaft	16-15	446351	Key, Hi Pro
10-242	414060	Cover, Pinion	11-174	423673	Bearing, Transmission	16-16	446369	Key, Square
10-243	414078	Cover, Transmission	11-175	423681	Bushing	16-17	446377	Key, Woodruff
10-244	414094	Guard, Chain	11-176	423699	Bearing, Drive Shaft	16-18	446443	Key (Use 16-23)
10-245	414102	Cover, Transmission	11-177	423707	Bushing, Drive Shaft	16-19	446393	Key Woodruff
10-247	414128	Panel, Back	11-178	423715	Bearing	16-23	446443	Key
10-248	414144	Cover, Engine	11-179	423723	Race, Bearing	16-24	446450	Key, Woodruff
10-251	414185	Cover, Transmission	11-180	423749	Bushing	16-26	304352	Key, Ignition
10-253	414227	Belt Guard Assy.	11-181	423756	Bearing	16-27	446484	Key, Ignition
10-254	414250	Cover, Belt	11-182	423764	Bearing	16-30	446559	Key, Clutch
10-255	414268	Trailguard	11-183	423772	Bearing	16-31	446567	Key, Square
10-256	414300	Cover, Pinion	11-184	423780	Bearing	16-33	446583	Key, Square
10-259	414334	Cover, Chute	11-187	423814	Bearing, Bronze	16-34	446591	Key, Hi Pro
10-260	414375	Cover, Pinion	11-188	423822	Bearing, Needle	16-35	446609	Key, Square
10-263	414425	Toe Guard				16-36	446617	Key, Square
10-264	414433	Cover, Switch, L.H.	12-145	427807	Plate, Wheel Adj.	16-37	662056	Key, Switch
10-265	414441	Cover, Switch, R.H.	12-153	427906	Plate, Wheel Adj.	16-38	446658	Key, Switch
10-266	414474	Cover, Pinion	12-157	428045	Plate	16-39	446666	Key, Woodruff
10-268	414490	Panel, Back	12-158	427955	Plate, Battery	16-40	446682	Key
10-269	414847	Cover, Engine	12-164	428045	Plate, Shift Wire	16-41	446690	Key, Square
10-270	570499	Guard, Belt	12-165	428060	Plate, Bearing	16-42	446708	Key, Square

Atlas Part No.	G.P.E. Part No.	Description	Atlas Part No.	G.P.E. Part No.	Description	Atlas Part No.	G.P.E. Part No.	Description
17-1	130021	Clamp, Throttle Cable	18-49	450429	Screw, Hex Spinlock	19-30	452490	Wingnut
17-2	130021	Clamp, Throttle Cable	18-50	450445	Screw, Hex	19-39	452581	Wingnut
17-28	448167	Clamp, Throttle Cable	18-51	450452	Bolt, Carriage	19-41	452615	Nut, 1/4-20 Elastic
17-55	448464	Clamp, Clutch Cable	18-52	450460	Bolt, Hex H.T.	19-43	452631	Nut, Hex Blade
17-56	448472	Clamp, Throttle Cable	18-53	450478	Bolt, Spade	19-44	452649	Nut, Hex
17-57	448480	Clamp, Starting Cable	18-54	450486	Bolt, Shoulder Female	19-45	452656	Nut, Hex
17-59	448506	Clamp, Starting Cable	18-55	450494	Bolt, Hex H.T.	19-46	452664	Nut, Hex Jam
17-62	448548	Clamp, Harness	18-56	450502	Bolt, Carriage	19-47	452672	Nut, Palnut
17-66	448589	Clamp, Cable	18-57	450510	Bolt, Carriage	19-48	452680	Nut, Square
17-68	448605	Clamp, Oil Drain	18-58	450528	Bolt, Shoulder	19-51	452722	Nut, Hex
17-80	150318	Clamp, Casing	18-60	450551	Bolt, Hex Shoulder	19-54	452755	Nut, Hex
17-91	448860	Clamp, Cable	18-61	450569	Bolt, Carriage	19-57	452789	Nut, Hex Lock
17-104	447375	Clamp, Throttle Cable	18-62	450577	Bolt, Carriage	19-58	452797	Wingnut
17-106	447409	Clamp, Shift	18-63	450890	Bolt	19-59	452805	Nut, Hex Lock
17-107	447417	Clip, Hairpin	18-64	450593	Bolt, Hex Shoulder	19-61	452839	Nut, Hex Lock
17-108	303859	Clamp, Hose	18-65	450601	Bolt, Carriage	19-65	452870	Nut, Hex
17-109	447433	Clamp, Cable	18-66	450619	Bolt, Shoulder	19-67	452896	Nut, Palnut
17-110	447458	Clamp Assy.	18-68	150011	Bolt, Carriage	19-68	452904	Nut, Hex
17-111	447466	Clamp, Harness	18-69	450643	Bolt, Hex Washer Hd.	19-75	452987	Nut, Keps
17-112	447458	Clamp	18-71	450676	Bolt, Hex Shoulder	19-76	452995	Turnbuckle
17-115	447516	Clip, Cable	18-72	450684	Eyebolt	19-77	453001	Wingnut
17-118	447540	Clamp, Battery	18-73	450692	Bolt, Hex Shoulder	19-78	453019	Nut, Hex Fastite
17-123	447607	Clamp, Clutch	18-74	450700	Bolt, Hex Shoulder	19-82	451492	Nut
17-124	447615	Clamp, Battery	18-75	450718	Bolt, Hex Shoulder	19-83	453076	Turnbuckle
17-125	447623	Clip, Spring	18-76	450726	Bolt, Hex Washer Hd.	19-84	453084	Nut, Hex Jam
17-131	110379	Clip, Cable	18-77	450734	Screw, Fillister Hd.	19-85	151340	Nut, Hex Keps
17-132	447706	Clamp	18-78	450742	Bolt, Shoulder	19-87	453118	Nut, Palnut
17-134	447755	Clamp	18-79	459941	Screw	19-88	453126	Nut, Hex Fastite
17-135	447730	Clamp, Bag	18-80	450775	Screw, Hex Hd.	19-90	453159	Nut, Square
17-137	447755	Clamp, Wire	18-83	450809	Bolt, Hex	19-91	453167	Nut, Hex Fastite
17-139	447771	Clamp, Strain Relief	18-84	450817	Bolt, Hex Shoulder	19-92	453175	Nut, Hex Elastic Stop
17-140	447797	Plastic Sleeve	18-88	450858	Bolt, Hex Washer Hd.	19-93	451963	Nut
17-141	447805	Strain Relief	18-91	450890	Bolt	19-95	453209	Nut, Plate
17-142	447813	Clamp, Battery	18-92	449926	Bolt	19-96	452805	Nut
17-143	447821	Clip	18-93	450916	Bolt, Shoulder Female	19-97	453225	Nut, Hex Nylok
17-145	447847	Clamp, Wire	18-98	490250	Groove Pin	19-98	453233	Turnbuckle
17-146	447854	Clip, Axle	18-99	450965	Bolt, Hex Hd.	19-103	451021	Nut, Lock
17-147	447870	Clip, Axle	18-100	449603	Bolt, Hex	19-110	451492	Nut
17-148	150318	Clamp, Choke Cable	18-101	449611	Bolt, Hex Shoulder	19-111	715524	Nut, Hex Jam Lock
17-149	447896	Clamp	18-102	449629	Bolt, Curved Hd.	19-114	451146	Nut, Tinnerman
17-150	447920	Clamp	18-103	449637	Bolt, Hex Shoulder	19-117	451179	Nut
17-151	447938	Clamp, Hose	18-104	449645	Bolt, Hex Shoulder	19-118	715490	Nut, Hex Lock
17-152	447946	Clamp Cord	18-105	449652	Bolt, Hex Shoulder	19-119	451195	Nut, Hex Lock
17-155	447979	Clamp	18-106	449660	Eyebolt	19-121	451229	Ball Joint
17-156	447995	Tab	18-107	449678	Bolt, Hex	19-122	451237	Nut, Hex Jam
17-158	448019	Clip	18-108	449686	Bolt, Hex Shoulder	19-123	451245	Nut, Hex
17-159	448027	Clip	18-109	449694	Bolt, Hex	19-124	451252	Turnbuckle
			18-110	152660	Bolt, Hex	19-125	451260	Nut, Hex Lock
18-1	449587	Screw, Hex	18-111	449728	Bolt, Hex	19-126	451278	Nut, Tinnerman
18-2	450106	Screw	18-112	449736	Bolt, Hex	19-127	451286	Nut, Tinnerman
18-3	715045	Screw, Hex	18-113	449744	Bolt, Hex	19-128	451294	Nut, Hex Slotted
18-4	450320	Screw, Hex	18-115	449769	Bolt, Hex Shoulder	19-129	451302	Nut, Plastic
18-5	450437	Screw, Hex	18-116	459552	Bolt	19-136	451385	Nut, Hex
18-6	450064	Screw	18-117	449785	Bolt, Hex	19-137	451393	Nut, Hex
18-7	450346	Screw	18-119	449801	Screw, Allen Hd.	19-138	451401	Nut, Palnut
18-8	450767	Bolt, Hex	18-121	449835	Bolt, Hex Hd.	19-139	451419	Nut, Hex Lock
18-9	450874	Bolt, Hex	18-122	449843	Bolt, Hex Hd.	19-141	715359	Nut, Hex Lock
18-10	449595	Bolt, Hex H.T.	18-123	152363	Bolt, Carriage	19-143	451468	Nut, Hex Washer
18-12	449819	Bolt, Hex Shoulder	18-124	449868	Bolt, Hex Hd. H.T.	19-145	451492	Nut
18-13	449926	Bolt, Carriage	18-125		Bolt (Use 459032 w/468322 & 462309)	19-146	451492	Nut, Hex Lock
18-14	450387	Bolt				19-147	715086	Nut, Keps
18-15	450049	Bolt, Hex	18-126	449884	Bolt, Axle	19-148	451518	Nut, Face
18-16	450056	Bolt, Hex	18-127	449892	Bolt, Carriage	19-149	451526	Nut, Hex Lock
18-17	450064	Screw, Hex	18-128	449900	Bolt, Crossdrilled	19-150	451542	Nut, Face
18-18	450072	Screw, Hex	18-129	457176	Bolt, Crossdrilled	19-154	451583	Nut, Hex Lock
18-19	450098	Bolt, Hex Shoulder	18-130	449934	Bolt, Hex Hd.	19-155	451591	Nut, Square
18-20	450114	Bolt, Hex H.T.	18-131	151936	Bolt	19-156	451609	Turnbuckle
18-21	450122	Bolt, Carriage	18-132	449959	Bolt, Hex	19-157	451617	Nut, Hex Lock
18-22	150433	Screw, Hex	18-133	449967	Bolt, Hex Hd. H.T.	19-158	451625	Nut, Hex
18-23	450148	Bolt, Carriage	18-134	449975	Bolt, Hex Hd. H.T.	19-159	451633	Nut, Hex
18-26	450171	Screw, Hex	18-135	153650	Bolt, Shoulder	19-161	451666	Nut, Centerlock
18-27	450189	Bolt, Hex H.T.	18-137	450007	Bolt, Hex	19-162	451674	Nut, Acorn Push
18-28	460121	Bolt				19-163	451682	Nut, Jam
18-29	450205	Bolt, Hex Shoulder	19-1	715334	Nut, Hex Keps	19-164	451690	Nut, Hex
18-30	449819	Bolt	19-2	715037	Nut, Hex Keps	19-165	451666	Nut
18-31	450239	Eyebolt	19-3	150136	Nut, Hex Keps	19-167	451724	Nut, Lock
18-32	150060	Bolt	19-4	452599	Nut, Hex	19-168	451849	Wingnut
18-36	152496	Bolt, Hex H.T.	19-5	452706	Nut, Hex Jam	19-170	451765	Nut, Tinnerman
18-37	450346	Screw	19-6	452805	Nut	19-171	451773	Nut, Lock
18-38	150250	Bolt	19-7	452920	Wingnut	19-174	451807	Nut, Tinnerman
18-40	450338	Bolt, Carriage	19-8	453035	Nut, Acorn	19-176	451823	Nut, Castellated
18-41	450346	Screw, Hex H.T.	19-10	450981	Nut, Hex	19-178	451849	Nut, Wing 1/4"
18-42	450353	Screw, Hex H.T.	19-19	451989	Nut	19-179	451856	Nut, Slotted
18-43	150250	Screw, Hex H.T.	19-20	452102	Nut, Hex Keps	19-180	451195	Nut
18-44	450379	Screw, Hex H.T.	19-22	452342	Nut, Hex	19-182	451898	Nut, Tinnerman
18-45	450387	Bolt, Hex H.T.	19-24	452425	Nut, Hex	19-183	150235	Nut, Wing 5/16"
18-46	450395	Bolt, Hex	19-25	452433	Nut, Keps	19-184	451922	Nut, Adapter
18-47	450403	Screw, Hex Spinlock	19-27	452458	Nut, Hexa Elastic Stop	19-185	451930	Nut, Palnut

Atlas Part No.	G.P.E. Part No.	Description	Atlas Part No.	G.P.E. Part No.	Description	Atlas Part No.	G.P.E. Part No.	Description
19-188	451963	Nut, Square	20-103	456582	Screw, Truss Head	20-273	458588	Screw, Hex
19-189	451971	Nut, Lock	20-105	456780	Screw	20-274	458596	Screw, Hex
19-190	451997	Nut, Painut	20-107	456624	Screw, Shoulder	20-275	458604	Bolt, Hex
19-191	452003	Nut, Knurled			Socket Head	20-277	458620	Screw
19-193	452029	Nut, Hex	20-108	715201	Screw, Hex	20-279	458737	Screw
19-194	715078	Nut, Flange	20-109	450353	Screw	20-280	458661	Screw, Shift Lever
19-195	715078	Nut, Hex	20-110	456665	Screw, Self Tapping	20-281	458679	Screw, Throttle Clamp
19-196	594655	Nut Assy., Hand	20-112	456681	Screw, RHMS	20-282	458687	Screw
19-197	715441	Nut, Whizlock	20-113	456699	Screw, Set	20-283	458695	Screw
19-201	452128	Palnut	20-114	456707	Screw, Shoulder	20-285	458711	Screw, Wing
19-202		Nut (Use 744219 w/461665)	20-115	456715	Socket Head	20-287	458737	Screw
19-203	310052	Nut	20-117	456731	Screw, Set	20-288	458745	Screw, Hex Washer Hd.
19-204	151993	Palnut	20-118	456731	Bolt, Carriage	20-291	458786	Screw, Thread Cutting
19-205	152579	Nut	20-119	450890	Bolt	20-292	458794	Screw, Round Head
19-206	452193	Nut	20-120	456756	Screw, Fillister Head	20-293	459552	Bolt
19-207	452201	Nut, Plastic	20-121	456772	Screw, Hex Shoulder	20-294	458810	Bolt
19-208	150961	Painut	20-124	456780	Screw, Hex	20-296	458836	Screw, Hex Washer Hd.
19-210	452243	Nut	20-124	456814	Screw, Self Tapping	20-297	458844	Screw, Set
19-211	452250	Palnut	20-125	456822	Screw, Self Tapping	20-299	458869	Screw, Phillips
19-213	151753	Nut, Acorn	20-126	456830	Screw, RHMS	20-301	458901	Bolt, Shoulder
19-214	151795	Nut, Wing 5/16"	20-127	456848	Screw, Self Tapping	20-303	458927	Bolt, Hex
19-215		Nut (Use 452275 w/152181)	20-131	456897	Screw, Self Tapping	20-304	458935	Bolt, Shoulder
19-216	452300	Palnut	20-132	456905	Screw, Truss Head	20-305	153601	Bolt, Thread Forming
19-217	310078	Nut	20-134	456921	Screw, RHMS	20-307	458968	Bolt, Whizlock
19-218	452326	Nut, Clip	20-142	457010	Screw, Hex Springtite	20-309	458984	Eyebolt
19-219		Nut (Use 452383 w/152181)	20-144	457200	Screw	20-310	459008	Bolt, Shoulder
19-220	452359	Pushnut	20-145	715052	Screw, Hex	20-311	153494	Bolt, Shear
19-221	452367	Nut	20-146	457051	Screw, Hex	20-312	459024	Screw, Phillips
19-222	452375	Nut, Tinnerman	20-148	457077	Screw, Self Tapping	20-313	459032	Bolt, Wheel
19-223	452383	Nut, Tinnerman	20-149	457085	Screw, Hex	20-314	459040	Bolt
20-1	715052	Screw	20-150	457101	Screw, Set	20-315	151936	Bolt, Curved Hd.
20-2	459321	Screw	20-151	457119	Screw, Hex	20-316	459065	Screw, Phillips Hd.
20-3	458877	Screw, Sheet Metal	20-152	457127	Screw, Truss Head	20-317	459073	Bolt
20-4	459834	Screw, Sheet Metal	20-153	457135	Screw, Set	20-318	459081	Bolt
20-5	459941	Screw, RHMS	20-155	457150	Screw, Shoulder	20-319	459099	Bolt
20-8	460279	Screw, RHMS	20-156	457168	Screw, Self Tapping	20-320	459115	Bolt
20-10	456541	Screw, Sheet Metal	20-157	457176	Screw, Hex	20-321	459123	Bolt
20-12	456764	Screw, Sheet Metal	20-158	457184	Screw, Hex	20-322	459131	Bolt
20-13	456871	Screw, RHMS	20-159	457192	Screw, Self Tapping	20-323	459149	Eyebolt
20-15	457093	Screw, RHMS	20-160	457218	Screw, Spade Head	20-324	459156	Bolt, Hex Hd.
20-16	457200	Screw, Truss Head	20-162	457234	Screw, Hex Shoulder	20-327	459180	Screw
20-21	457820	Screw, RHMS	20-168	457291	Screw, Hex	20-329	459206	Screw
20-22	457952	Screw, RHMS	20-169	457309	Bolt Carriage	20-330	459230	Screw
20-23	458109	Screw, Oval Head	20-171	457333	Screw, RHMS	20-331	459230	Screw
20-24	458216	Screw, Set	20-174	457366	Screw, Set	20-332	459248	Screw, Round Hd.
20-25	458323	Screw, Hex	20-183	457465	Screw, Pan Head			Phillips
20-26	458430	Screw, Set	20-185	457481	Screw, Self Tapping	20-333	150623	Screw, Sheet Metal
20-27	312322	Screw, Hex	20-186	153601	Screw, Self Tapping	20-334	120048	Screw, Hex
20-28	458653	Screw, RHMS	20-187	457507	Screw, Hex	20-336	459289	Bolt
20-29	458760	Thumbscrew	20-188	594671	Screw, Special	20-337	459297	Eyebolt
20-34	459321	Screw, RHMS	20-189	457523	Screw, Hex	20-338	459305	Eyebolt
20-35	459438	Screw, RHMS	20-192	457564	Screw, RHMS	20-339	459313	Eyebolt
20-36	459545	Screw, RHMS	20-195	150623	Screw, Hex Washer Hd.	20-340	459339	Bolt
20-37	151936	Bolt	20-198	457630	Screw, Hex	20-341	459347	Screw
20-40	459842	Screw, Set	20-200	457481	Screw	20-342	459354	Screw
20-42		Screw (Use 450346 w/467969)	20-214	457879	Screw, Flat Head	20-343	459362	Screw
20-44	459891	Bolt	20-216	150607	Screw	20-344	459370	Screw
20-45	459891	Bolt, Shoulder	20-218	457937	Screw, Set	20-345	459388	Screw
20-46	459909	Screw, Hex	20-219	457945	Screw, Truss Head	20-346	459396	Screw
20-47	459917	Screw, RHMS	20-220	457960	Screw, Hex	20-347	459404	Screw
20-49	459321	Screw	20-221	457994	Screw, Hex Washer Hd.	20-349	459420	Screw, Set
20-50	459958	Screw, Sheet Metal	20-222	458000	Screw, RHMS	20-350	459446	Screw
20-53	459982	Screw, Hex	20-223	458034	Screw, RHMS	20-351	459453	Bolt, Shoulder
20-61	450643	Screw	20-225	458059	Screw, Hex	20-353	459479	Bolt
20-63	460097	Screw, Truss Head	20-226	458133	Screw, Self Tapping	20-354	459487	Bolt
20-64	460105	Screw, Hex	20-229	458091	Screw, Self Tapping	20-357	459511	Bolt, Shoulder
20-66	460121	Screw, Hex	20-230	458117	Screw, Hex Head	20-358	150060	Bolt, Shoulder
20-67	715326	Screw, Hex	20-231	458125	Screw, RHMS	20-359		Bolt (Use 459032 w/468322 & 462039)
20-68	460147	Screw, RHMS	20-232	458133	Screw, Self Tapping			
20-72	460196	Screw, Truss Head	20-233	151613	Screw, RHMS	20-360	153668	Bolt, Shoulder
20-74	460212	Bolt, Shoulder	20-234	458158	Screw, Adjusting	20-361	459560	Bolt, Shoulder
20-76	460253	Bolt	20-236	458174	Screw, Hex	20-365	459602	Screw, Motor
20-77	460246	Thumbscrew	20-237	458182	Screw, Hex	20-366	459610	Screw, Field
20-78	460253	Bolt, Shoulder	20-238	458190	Screw, Hex Washer Hd.	20-367	459628	Screw
20-81	460295	Screw, Plow Head	20-239	150904	Screw	20-368	459636	Bolt
20-82	460303	Bolt, Carriage	20-240	150904	Screw, Hex	20-371	459677	Screw
20-83	460311	Screw, Hex	20-242	458240	Screw, RHMS	20-372	152181	Screw
20-84	460329	Screw, Hex Shoulder	20-246	458281	Screw, Sems	20-375	459719	Bolt, Engine
20-85	460337	Screw, RHMS	20-255	458380	Screw, Set	20-376	151936	Bolt, Curved Hd.
20-86	460345	Screw, Hex	20-256	458398	Screw, RHMS	20-378	152371	Eyebolt
20-90	460394	Screw, RHMS	20-257	458406	Screw, Pan Head	20-380	459776	Screw
20-98	460477	Screw, RHMS	20-260	458448	Screw, Hex Head	20-381	459784	Screw
20-99	460485	Screw, RHMS	20-262	458463	Screw, Set			
			20-267	458513	Screw, Sheet Metal	21-1	460584	Washer, Flat
			20-269	458539	Screw, Hex	21-2	461699	Washer, Ex. Shkproof
			20-270	458554	Screw, Hex	21-3	715185	Washer
			20-271	458562	Screw, RHMS	21-5	462309	Washer
			20-272	458570	Screw, Hex	21-11	460709	Washer, Cuplock Ext.

Atlas Part No.	G.P.E. Part No.	Description	Atlas Part No.	G.P.E. Part No.	Description	Atlas Part No.	G.P.E. Part No.	Description
21-12	460816	Washer, In. Shkproof	21-196	461657	Washer, Blade	23-73	466177	Kit, 32" Leveling/ Snow Blade
21-13	460923	Washer, Flat	21-197	461665	Washer, In. Shkproof			
21-14	715094	Washer, Split Lock	21-198	461673	Washer, Thrust	23-74	466193	Kit, Front Weight
21-16	461251	Washer, Fiber	21-199	461681	Washer, Flat	23-75	466219	Kit, Aerator
21-17	461368	Washer, Flat	21-200	461715	Washer, Ex. Shkproof	23-77	466243	Kit, Transmission
21-18	461475	Washer, Split Lock	21-201	461723	Washer, In. Shkproof	23-87	466326	Kit, Idler Arm
21-19	461582	Washer, Split Lock	21-202	461731	Washer, Flat			
21-21	461814	Washer, Flat	21-203	461749	Washer, Flat	25-109	467464	Fuel Line
21-25	462218	Washer, Ex. Shkproof	21-205	461764	Washer, Belleville	25-110	466698	Fuel Line
21-26	462226	Washer, Ex. Shkproof	21-206	461772	Washer, Clutch	25-111	466706	Tube, Primer
21-28	462242	Washer	21-207	461780	Washer	25-112		Tube, Bag (Use 102640 & 2 of 151464)
21-30	462275	Washer, Flat	21-208	461798	Washer, Flat			
21-33	462309	Washer, Flat	21-209	461988	Washer			
21-35	462325	Washer, Flat	21-210	461822	Washer, Flat	26-24	468801	Spacer
21-38	715185	Washer	21-211	461830	Washer, Thrust	26-26	317016	Spacer
21-39	462336	Washer, Countersunk	21-213	461855	Washer	26-67	469288	Spacer, Adj. Arm
21-42	462945	Washer	21-214	461566	Washer	26-70	469320	Spacer
21-43	462416	Washer, Split Lock	21-216	460923	Washer	26-71	469338	Spacer
21-44	715300	Washer, Flat	21-217	461905	Washer	26-75	469379	Spacer, Pulley
21-45	462432	Washer, Split Lock	21-221	715300	Washer	26-76	469395	Spacer, Arm
21-47	462457	Washer, Ex. Shkproof	21-223	461988	Washer, Flat	26-77	106005	Spacer
21-48	462465	Washer, Ex. Shkproof	21-227	462051	Washer	26-78	469411	Spacer, Handle
21-49	462473	Washer, Flat	21-228	462069	Washer	26-80	469452	Spacer, Sprocket
21-60	462606	Washer, Split Lock	21-230	715300	Washer	26-81	469460	Spacer, Gear
21-61	462614	Washer, Flat	21-232	462119	Washer, Spring	26-82	469478	Spacer, Gear
21-62	715185	Washer, Flat	21-233	462127	Washer, Nylon	26-83	469486	Spacer, Wheel
21-64	462648	Washer, Bow	21-234	462135	Washer, Lock	26-92	469585	Spacer, Deck L.H.
21-66	462663	Washer, Flat	21-237	462168	Washer, Lock	26-93	469593	Spacer, Deck R.H.
21-70	462721	Washer, Flat	21-238	662197	Washer	26-97	106005	Spacer, Blade
21-74	462762	Washer, Flat	22-43	462416	Plate, Support	26-103	467829	Spacer, Idler Arm
21-79	715300	Washer	22-70	462721	Plate, Adj.	26-104	467837	Spacer, Shim
21-83	462861	Washer, Ex. Shkproof	22-73	464990	Baffle	26-105	467845	Spacer
21-84	462879	Washer, Flat	22-74	462762	Baffle	26-106	467852	Spacer, Pivot
21-85	462887	Washer, Flat	22-90	462945	Baffle	26-107	467860	Spacer, Pinion
21-90	462945	Washer, In. Shkproof	22-96	463000	Plate	26-108	467878	Spacer, Pinion
21-91	462952	Washer, Flat	22-104	463141	Deflector, Bag	26-109	467886	Spacer, Engine
21-93	462978	Washer, Flat	22-105	463166	Plate, Idler Arm	26-110	467902	Spacer, Levers
21-94	462986	Washer, Flat	22-111	463240	Baffle, Moisture	26-111	467910	Spacer, Breaker Bar
21-96	463000	Washer, Flat	22-113	463273	Baffle	26-112	467928	Spacer, Breaker Bar
21-97	462432	Washer (Use 21-45)	22-114	463281	Baffle	26-113	467936	Spacer, Idler Arm
21-98	715094	Washer	22-115	463299	Baffle	26-114	467944	Spacer
21-99	463034	Washer, Flat	22-116	463307	Baffle	26-115	467951	Spacer, Pivot
21-113	715409	Washer	22-117	463323	Plate, Idler Pivot	26-116	467969	Spacer
21-114	460758	Washer, Flat Rubber	22-118	463349	Plate, Top Drag Brkt.	26-117	467977	Spacer
21-115	460766	Washer, In. Shkproof	22-119	463364	Plate, Btm. Drag Brkt.	26-120	468017	Spacer
21-116	460774	Washer, Flat	22-123	463422	Bellcrank, Control Plate	26-121	468025	Spacer
21-119	460808	Washer, Split Lock	22-125	463497	Plate Assy.	26-122	468033	Spacer, Tine Shaft
21-120	460824	Washer, Flat	22-126	463497	Plate Assy., Belt Guide	26-123	468041	Spacer, Main Support Beam
21-121	460832	Washer, Flat	22-130	463554	Plate, Side L.H.			
21-135	460980	Washer, Flat	22-131	463570	Plate, Side R.H.	26-124	468066	Spacer, Bellcrank
21-136	460998	Washer, Spring	22-132	463596	Plate, Side	26-125	468074	Spacer, Clutch Mtg. Short
21-137	461004	Washer, Curver	22-134	463612	Plate, End, Engine Mtg.			
21-138	461012	Washer, Spring	22-135	463901	Deflector	26-126	468082	Spacer, Clutch Mtg. Long
21-139	461020	Washer, Flat	22-138	463687	Plate, Belt Guide			
21-140	461046	Washer, Flat	22-145	463778	Plate, Bearing	26-127	468090	Spacer, Drag Bar Adj.
21-142	461061	Washer, Flat	22-146	463794	Baffle	26-128	468108	Spacer, Wheel & Pivot Adj.
21-143	461079	Washer, Curved	22-147	463794	Baffle, Front			
21-144	461087	Washer, In. Shkproof	22-148	464305	Baffle	26-129	468116	Spacer
21-146	461103	Washer, Flat	22-149	463810	Baffle	26-130	468132	Collar, Clutch
21-148	461129	Washer, Flat	22-151	463844	Baffle, Rear	26-131	468140	Spacer, Clutch
21-158	461236	Washer, Flat	22-152	463851	Baffle, Rear	26-132	468157	Spacer
21-159	311282	Washer, Flat	22-156	463901	Deflector, Snow Chute	26-134	468173	Spacer, Gear Box
21-161	461277	Washer, Flat	22-157	463919	Plate, Engine Mtg.	26-138	468215	Spacer
21-162	461285	Washer, Thrust	22-158	463927	Spindle Mtg. Plate Assy.	26-140	468249	Spacer, Tine Shaft
21-163	461293	Washer, Blade	22-159	463950	Chute Deflector	26-141	468256	Spacer
21-164	461301	Washer, Spring	22-160	463950	Chute Deflector Assy.	26-143	468272	Spacer
21-166	461327	Washer, Flat	22-161	463968	Chute Deflector	26-144	468280	Spacer, Wheel
21-167	461335	Washer, Keyed	22-162	463984	Baffle	26-145	468298	Spacer
21-168	461343	Washer, Thrust	22-164	464016	Plate, End	24-146	468306	Spacer
21-169	461350	Washer, Nylon	22-165	464024	Plate, Drive Spindle	26-147	468314	Spacer, Wheel
21-170	461376	Washer, Fiber	22-170	464099	Baffle	26-148	468322	Spacer, Wheel
21-171	461384	Washer, Slotted	22-171	464107	Baffle	26-149	468330	Spacer, Wheel
21-172	461392	Washer, Cup	22-172	464123	Bellcrank, Control Plate	26-150	468355	Spacer, Pivot
21-173	461400	Washer, Cup	22-176	464180	Plate, Belt Guide	26-151	468363	Spacer
21-175	461426	Washer, Thrust	22-177	464206	Plate, Belt Guide	26-152	468371	Spacer
21-176	461434	Washer, Flat				26-153	468389	Spacer
21-177	461442	Washer, Flat	23-54	465823	Kit, Tiller Furrowing	26-154	468397	Spacer
21-178	461459	Washer, Flat	23-56	465856	Kit, Tiller furrowing	26-155	468405	Spacer
21-180	461483	Washer, Lock	23-57	465872	Kit, "A" Frame	26-156	468413	Spacer
21-185	461533	Washer, Thrust	23-60	465948	Kit, Depth Gage Wheels	26-157	468421	Spacer, 1/4"
21-188	461566	Washer, Flat	23-61	465963	Kit, 6 Tine Cultivator/ Harrow	26-158	468454	Spacer, 5/16"
21-189	461574	Washer, Thrust				26-160	468488	Spacer
21-190	461590	Washer	23-62	465989	Kit, Cultivating Shields	26-160	468488	Spacer
21-191	150201	Washer, Curved	23-63	466003	Kit, 15" Sweep Plow	26-165	468538	Spacer, Shoulder
21-192	461616	Washer, Flat	23-64	466029	Kit, Power Wheel	26-166	468553	Spacer, Tip
21-193	461624	Washer, Spring	23-65	466045	Kit, Wheel Weights	26-167	468561	Spacer
21-194	461632	Washer, Flat	23-66	466060	Kit, 32" Rake	26-168	468579	Spacer
21-195	461640	Washer, Blade	23-67	466086	Kit, Chute Extender	26-169	468587	Spacer

Atlas Part No.	G.P.E. Part No.	Description	Atlas Part No.	G.P.E. Part No.	Description	Atlas Part No.	G.P.E. Part No.	Description
26-170	468603	Spacer	28-115	488908	Pin, Drag Bracket	43-372	741751	Main Support Assy.
26-171	468611	Spacer	28-116	488932	Pin, Drag Brkt. Assy.	43-373	741785	Brace, Deck
26-174	468645	Spacer	28-117	488940	Pin, Clevis	43-374	741793	Base, Motor
26-175	468652	Spacer	28-118	488957	Clevis Lanyard	43-379	741843	Handle Brace Assy.
26-176	468660	Spacer	28-119	488965	Pin, Clevis	43-391	742015	Support
26-178	468686	Spacer	28-121	488999	Pin, Groove	43-392	742015	Support, Pulley
			28-122	489005	Pin, Clevis	43-394	742031	Support
28-1	488684	Pin, Shear	28-123	489013	Pin, Clevis	43-395	742056	Panel, Brace
28-2	489385	Roll Pin	28-124	489021	Pin, Hair	43-396	742064	Panel
28-3	489492	Pin, Roll	28-126	489047	Rod, Shank	43-398	742098	Support, Axle
28-4	489609	Pin, Roll	28-128	489062	Pin, Hinge	43-399	742122	Brace Assy., Auger
28-5	489716	Pin, Lock	28-129	489088	Pin, Roll	43-401	742163	Brace
28-6	489823	Pin, Clevis 1-5/8"	28-130	489104	Pin, Spring	43-402	742197	Support, Axle
28-7	715011	Hairpin Cotter	28-131		Pin (Use 489385 w/490029)	43-404	742221	Support, Hinge Pin
28-8		Pin (Use 489005 w/452128)	28-140	489211	Pin, Klik	43-406	742254	Support
			28-141	489237	Pin, Roll	43-407	742262	Brace
28-9	490169	Pin, Roll	28-144	489260	Pin, Roll	46-36	744037	Knob, Throttle "T"
28-10	488692	Pin, Cotter	28-147	489294	Pin, Spring	46-40	744086	Knob
28-11	490235	Pin				46-41	744094	Knob, Thread No. 10
28-13	489096	Pin, Cotter	30-0150	499814	Replacement Bag (For 30-0100)	46-42	744102	Knob, Throttle
28-14	489203	Pin, Cotter				46-43	744110	Knob, Throttle
28-15	489328	Pin, Cotter	30-0210	500579	Grass Catcher	46-45	744136	Knob, Hopper
28-16	715029	Pin, Cotter	30-0215	160747	Grass Catcher	46-47	744151	Knob
28-17	489351	Pin, Clevis	30-0250	499863	Replacement Bag (For 30-0200)	46-50	744193	Knob
28-20	489393	Pin, Roll				46-51	744201	Knob
28-21	489401	Pin, Roll	30-0260	501833	Replacement Bag (For 30-0210)	46-52	744219	Knob 5/16"
28-23	314096	Pin, Roll				46-53	744227i	Knob
28-24	489435	Pin, Roll	30-0265	501882	Replacement Bag (For 30-0215)	46-54	744235	Knob
28-25	489443	Pin, Cotter				46-55	744243	Knob 3/8"
28-26	317016	Pin, Cotter	30-0310	502419	Grass Catcher	46-56	744250	Knob
28-27	489468	Pin, Cotter	30-0360	502971	Replacement Bag (For 30-0310)	46-57	744268	Knob
28-28	489476	Pin, roll				46-58	744284	Knob 5/16"
28-30	489500	Pin, Stud	30-0450	504035	Replacement Bag (Rear Bagger)	46-59	744292	Knob 5/16"
28-31	489518	Pin, Clevis				46-60	744318	Knob
28-32	489526	Pin Cotter	30-0455		Grass Catcher (Use 1-160382)	46-61	744326	Knob 1/4"
28-33	489534	Pin, Clevis			1-102640 2-151464, 1-103952 1-103945	46-62	744334	Knob 5/16"
28-34	489542	Pin, Extension				47-516	748525	Charger, Battery
28-37	489575	Pin, Clevis	30-0460	160382	Replacement Bag (Rear bagger w/steel deck)	47-544	748954	Cable
28-39	489591	Pin, Roll				47-545	748962	Cable, Clutch
28-40	489617	Pin, Roll	30-0500	499988	Shredder Bags (5 Pak)	47-546	792069	Cord Set, Engine
28-41	489625	Pin, Clevis				47-552	749028	Wire
28-42	489633	Pin, Roll	35-1	728212	Stud, Yoke	47-555	749036	Wire
28-43	489641	Pin, Clevis	35-8	728378	Stud, Control	47-562		Cable (Use 749135 w/488957)
28-44	489658	Pin, Cotter	35-17	152876	Stud, Control			
28-45	489666	Hairpin Cotter				47-565	749077	Harness
28-47	489682	Pin, Clevis	39-38	729624	Clutch Collar	47-567	749085	Cord Starter
28-48	489690	Pin, Clevis	39-50	729798	Disc, Back Up	47-569	749200	Wire
28-49	489708	Pin, Roll	39-57	729871	Disc, Clutch	47-570	749119	Cable, Clutch
28-50	715193	Pin, Roll	39-59	729905	Disc, Drive	47-572	749135	Cable
28-51	489732	Pin, Roll	39-60	729921	Disc, Ratchet	47-575	749168	Cable, Clutch
28-52	489740	Pin, Roll	39-64	729970	Drive Spindle Assy.	47-576	749176	Cable
28-55	489773	Pin, Roll				47-577	749184	Cable
28-61	489849	Pin, Clevis	41-141	735498	Panel, Control	47-578	749192	Cable
28-63	489864	Pin, Hinge	41-143	735514	Panel, Control	47-579	749200	Wire, Magneto Ground
28-65	489880	Pin, Clevis	41-164		Panel (Use 736371 w/731216)	47-580	749226	Cable, Drive
28-66	489906	Pin, Roll				47-582	749242	Cable
28-68	489914	Pin, Roll	41-169	735829	Panel, Side	47-583	749309	Cable
28-68	489914	Pin, Roll	41-170	735852	Panel, Top	47-584	749267	Cable, Auger Clutch
28-70	489948	Pin, Clevis	41-174	735894	Panel Assy.	47-585	749275	Cable, Traction Clutch
28-71	458091	Pin	41-175	735902	Panel	47-586	749283	Cable, Auger Clutch
28-72	489963	Pin, Cotter	41-179	736371	Panel	47-587	749291	Cable, Traction Clutch
28-77	490011	Hairpin Cotter	41-180	735985	Panel Assy.	47-588	749309	Cable, Clutch
28-78	490029	Pin, Roll	41-183	736025	Panel (Use 736355 w/447136)	47-589	749317	Cable, Clutch
28-79	490037	Pin, Clevis				47-591	749341	Cable, Clutch
28-80	490052	Pin, Guide	41-187	736421	Panel	47-592	749358	Cable, Height Adj.
28-81	490060	Pin, Guide	41-188	736371	Panel	47-595	749382	Cable Clutch
28-82	490078	Pin, Guide	41-189	736116	Panel	47-596	749390	Cable Clutch
28-83	490094	Pin, Spirol	41-192	736181	Panel, Bottom Eng.	47-597	749408	Wire, Magneto Ground
28-86	490128	Pin, Spirol	41-193	736207	Panel, Rear Eng. Mtg.	47-598	749416	Cable, Clutch
28-88	314062	Pin, Roll	41-194	736223	Panel, Handle	47-599	749424	Cable, Drive
28-90	317016	Pin	41-201	736371	Panel	47-600	749465	Cable
28-94	490219	Pin, Clevis	41-204	736355	Panel	47-603	789081	Cord & Socket Assy.
28-95	490227	Pin, Cotter	41-206	736371	Panel	47-604	792200	Cord & Switch Assy.
28-96	490235	Pin, Roll	41-208	736421	Panel	47-606	749507	Cable
28-97	490243	Pin, Clevis	41-214	570010	Panel Assy.	47-607	749515	Cord, Electric
28-98	490250	Pin, Groove				47-608	749523	Cable, Control
28-102	488726	Pin, Roll	43-321	741140	Brace, Handle	47-609	749531	Cable, Control
28-103	488734	Pin, Cotter	43-323	741165	Brace, Yoke	47-611	749556	Cable, Control
28-104	488742	Pin, Push	43-326	741785	Brace	47-612	749564	Cable, Control
28-105	488759	Pin, Shear 2"	43-360	598144	Brace, Handle	47-613	749572	Cable
28-107	488775	Pin, Roll	43-362	741611	Brace, Control	47-616	749580	Harness
28-108	488783	Pin, Shear 1-7/16"	43-363	741629	Brace	47-623	749671	Cable
28-109	488791	Pin, Hinge	43-367	741660	Panel, Control	47-624	749689	Cable
28-110	488817	Pin, Roll	43-368	598185	Panel, Control	47-626	050575	Cable
28-111	488825	Pin, Clevis 2"	43-371	741751	Main Support			
28-113	488841	Pin, Roll						
28-114	488874	Pin, Wheel Adj.						

Atlas Part No.	G.P.E. Part No.	Description	Atlas Part No.	G.P.E. Part No.	Description	Atlas Part No.	G.P.E. Part No.	Description
50-98	752154	Connector, Wire	75-7	774976	Hinge, Clutch	79-153	778241	Arm, Wheel Adj.
50-101	751164	Connector	75-8	774992	Hinge, Clutch	79-154	778266	Arm, Forward Hi
50-102	751172	Connector	75-9	775007	Hinge, Clutch	79-155	778282	Arm, Pivot
						79-156	778290	Arm, Wheel Adj.
56-18	761585	Tip, Lever	76-6	776344	Spring, Tiller Idler	79-157	778308	Arm, Wheel Adj.
56-19	110064	Tip	76-11	775130	Spring, Clutch Lock	79-158	778324	Arm, Wheel Adj.
			76-18	775882	Spring	79-159	778340	Arm, Wheel Adj.
			76-19	775890	Spring, Tiller Reverse	79-164	778415	Arm, Forward Idler
58-16	762013	Tape, Sponge	76-21	775924	Spring, Chute	79-165	778431	Arm, Reverse
58-17	762021	Gasket, Transmission	76-27	775981	Spring, Clutch	79-175	778555	Arm, Idler
58-18	762039	Gasket	76-37	776096	Spring	79-181	778647	Arm Assy., Door
58-19	762047	Gasket, Gear Box	76-39	776112	Spring	79-185	778696	Arm, Actuated
			76-40	776138	Spring, Clutch	79-186	778738	Arm, Front Left
59-8	120030	Shield, Muffler	76-46	776195	Spring, Wishbone	79-187	778779	Arm
59-15	762203	Shield, Tiller	76-50	776245	Spring, Latch	79-200	090118	Arm, Wheel Adj.
59-16	762211	Shield, Bearing	76-51	776252	Spring, Drive Bracket	79-201	090282	Arm, Wheel Adj.
59-19	762245	Shield, Tiller	76-67	776427	Spring, Blade Engage	79-202	778985	Arm, Pivot
59-20	762260	Shield	76-68	776435	Spring, Clutch Rod	79-205	779108	Arm
59-23	132142	Deflector, Muffler	76-70	776468	Spring, Chute	79-208	779108	Arm
59-24	762310	Shield	76-71	776500	Spring, Wheel Adj	79-210	779108	Arm, Idler
59-25	762344	Shield	76-75	776542	Spring, Idler			
59-28	762393	Shield	76-80	776617	Spring, Chain Tension	80-11	781609	Cup, Spring
59-30	762393	Shield	76-81	776641	Spring, Wheel Adj.	80-13	781625	Cup, Shaft Cover
59-31	762443	Shield, Engine	76-83	775981	Spring			
			76-84	776674	Spring, Blade Engage	82-33	784280	Rod, Brake
61-18	763706	Grommet	76-91	776757	Spring, Blade Brake	82-51	784934	Rod
			76-96	776807	Spring	82-88	784884	Rod, Pivot
62-24	763987	Rivet	76-99	776831	Spring, Control Rod	82-92	784934	Rod, Tie
62-34	764092	Pop Rivet	76-102	775056	Spring, Compression	82-96	784975	Rod, Blade Guard
62-37	764126	Rivet	76-103	775064	Spring	82-109	782870	Rod, Clutch Pivot
62-38	764134	Pop Rivet	76-104	775072	Spring, Compression	82-110	782896	Rod, Upper
62-39	764142	Pop Rivet	76-105	775080	Spring, Comp. Long	82-111	782904	Rod, Clutch Upper
62-41	764175	Pop Rivet	76-106	775155	Spring	82-130	783118	Rod, Lower
62-45	764217	Rivet	76-107	775106	Spring	82-131	783126	Rod, Clutch Upper
62-46	764225	Rivet	76-108	775114	Spring, Lever	82-132	783142	Rod, Clutch Lower
62-47	764233	Rivet	76-109	775122	Spring, Lever	82-134	783175	Rod, Upper
62-48	764241	Eyelet	76-111	775155	Spring, Cable	82-135	783183	Rod, Lower
62-49	764258	Rivet	76-114	775189	Spring	82-136	783209	Rod, Upper
62-50	764274	Rivet	76-115	662148	Spring, Switch	82-137	783217	Rod, Upper
62-51	764282	Rivet	76-116	775239	Spring	82-138	783225	Rod, Lower
62-52	764290	Rivet	76-117	775247	Spring	82-140	783258	Rod, Cleanout
			76-118	775254	Spring, Wheel & Pivot Adj.	82-141	783274	Rod, Lower
65-10	765065	Axle, Snow Thrower				82-144	783316	Rod, Upper
65-35	765339	Axle, Snow Thrower	76-120	775866	Spring	82-145	783357	Rod, Chute
65-36	765347	Axle Assy., Mower	76-121	775296	Spring, Brake	82-146	783373	Rod, Control Upper
65-44	765438	Axle, Snow Thrower	76-122	775304	Spring	82-147	783399	Rod, Control Idler
65-60	765644	Axle	76-123	775312	Spring	82-148	783415	Rod, Upper Traction
65-63	765677	Axle Assy.	76-124	775320	Spring Return	82-149	783423	Rod, Traction Clutch
65-65	765727	Axle Assy.	76-127	775353	Spring, Compression	82-150	783449	Rod, Drive Clutch
65-66	662098	Axle	76-128	775361	Spring, Torsion	82-151	783456	Rod, Drive Clutch
65-67	765750	Axle, R.H.	76-129	775379	Spring, Door Latch	82-152	783472	Rod, Auger Control
65-71	765834	Axle Assy., Front	76-133	775817	Spring	82-154	783498	Rod, Speed Control
65-72	765859	Axle Assy., Rear	76-134	775437	Spring, Lever Arm	82-157	783548	Rod Assy., Door
65-76	765925	Axle Weldment	76-135	775460	Spring, Tension	82-159	783571	Rod, Door Latch
65-77	765941	Axle Assy.	76-136	775551	Spring	82-160	783605	Rod, Engagement
65-81	766014	Axle Assy. Rear	76-137	775577	Spring	82-161	783621	Rod, Engagement
65-83	766121	Axle	76-141	775536	Spring, Traction	82-162	783639	Rod
65-85	766089	Axle Assy.	76-142	775544	Spring, Brake	82-165	783696	Rod, Engagement
65-86	766121	Axle Assy., Rear	76-143	775551	Spring, Clutch	82-167	783720	Rod, Clutch
65-87	766147	Axle	76-145	775577	Spring, Ratchet	82-171	783860	Rod, Lower
65-90		Axle (Use 766147 w/2 150961)	76-146	132423	Spring, Deflector	82-173	783886	Rod
			76-147	775593	Spring, Cable	82-175	783852	Rod, Spin Plate Support
			76-148	775635	Spring, Chain Tension	82-176	783860	Rod
68-20	766899	Hood, Tines	76-149	775809	Spring	82-177	783886	Rod, Clutch Drive
68-21	766915	Hood	76-150	775668	Spring	82-178	783894	Rod
68-22	766915	Hood, Tines	76-151	775676	Spring, Detent	82-179	783902	Rod
68-24	766956	Hood	76-152	775684	Spring, Clutch Return	82-180	783944	Crank, Chute Adj.
68-25	766972	Hood, Tine	76-153	775692	Spring, Auger Clutch	82-183	783985	Rod, Engagement Lever
68-26	766998	Hood, Tines	76-154	775700	Spring, Drive Clutch	82-184	784009	Rod, Engagement Lever
68-27	767012	Hood, Center	76-155	775718	Spring	82-185	784017	Crank Assy
68-28	767038	Hood, Left	76-157	090241	Spring, Q.W.A., RF			
68-29	767053	Hood, Right	76-158	090209	Spring, Q.W.A., RR	84-8	786483	Tine, Bolo L.H.
			76-159	090101	Spring, Q.W.A., LR	84-9	786707	Tine, Bolo R.H.
72-6	110379	Tie, Wire	76-160	090258	Spring, Q.W.A., LF	84-21	785410	Tine Assy., Inner L.H.
			76-161	090399	Spring, Q.W.A.	84-22	785428	Tine Assy., Inner R.H.
74-6	774836	Sealer, "Loctite"	76-162	775791	Spring	84-23	785436	Tine Assy., Outer L.H.
74-14	774539	Seal, Tiller Input	76-163	775809	Spring, Release Arm	84-24	785444	Tine Assy., Outer R.H.
74-15	774547	Seal, Tiller Output	76-164	775817	Spring	84-25	785469	Tine, Slasher R.H.
74-19	774588	Seal, Oil	76-165	775825	Spring	84-26	785485	Tine, Slasher L.H.
74-22	774620	Seal, Strip	76-168	775858	Spring	84-46	785733	Tine, Extension Kit
74-25	774653	Seal	76-169	775866	Spring	84-47	785758	Tine, Extension Kit
74-29	774695	Seal, Input Shaft				84-48	570382	Tine Assy.
74-31	774760	Seal	79-93	779991	Arm, Inner	84-49	570390	Tine Assy.
74-32	774737	Seal	79-94	780007	Arm, Outer	84-50	570416	Tine Assy.
74-33	774745	Seal	79-121	777862	Arm, Wheel Adj.	84-51	785840	Tine Assy.
74-35	774760	Seal, Output	79-145	778142	Arm, Blade Idler	84-52	785865	Tine Assy.
74-37	774786	Shield	79-151	778225	Arm, Reverse Idler	84-53	785881	Tine Assy., Outer L.H.
74-38	774794	Shield						

Atlas Part No.	G.P.E. Part No.	Description	Atlas Part No.	G.P.E. Part No.	Description	Atlas Part No.	G.P.E. Part No.	Description
84-54	570408	Tine Assy., Inner L.H.	99-74	791624	Frame	102-192	418251	Shaft, Clutch
84-55	600098	Tine Assy., Inner L.H.	99-75	791541	Frame	102-194	418285	Shaft, Auger
84-64	786103	Tine Assy., Inner L.H.	99-76	791558	Frame Assy.			
84-65	786129	Tine Assy., Inner R.H.	99-77	791574	Frame Assy.	104-7	419580	Ring, Chute
84-66	786152	Tine Assy., Outer L.H.						
84-67	786178	Tine Assy., Outer R.H.	100-2	415729	Fitting, Alemite	105-6	420414	Pulley, Tiller
84-68	786202	Tine Assy., Inner R.H.	100-3	415737	Fitting, Alemite	105-14	419903	Pulley
84-69	786236	Tine Assy., Outer R.H.	100-12	415687	Fitting, Grease	105-20	419986	Pulley, Tiller Dual
84-70	786277	Tine, R.H.	100-13	415695	Oil Minder	105-22	420000	Pulley
84-71	786301	Tine, L.H.	100-14	415703	Adapter	105-26	420042	Pulley, Control Cable
84-72	786327	Tine				105-27	420927	Pulley, Aux Shaft
84-73	786343	Tine	101-57		Gear (Use 416776, 417519 & 446666)	105-32	420117	Pulley, Mower
84-74	786368	Tine				105-61	420430	Pulley, Engine Fwd
84-75	786643	Tine	101-58		Worm (Use 416719 w/2 314062)	105-62	420448	Pulley, Engine Rev
84-76	786558	Tine Assy				105-63	420455	Pulley, Dual
84-77	786426	Tine Assy	101-71		Gear (Use 416834 w/489385)	105-65	420471	Pulley, Driven
84-78	786442	Tine Assy.				105-69	419903	Pulley
84-79	786640	Tine Assy.	101-82		Gear, Chute (Use 416859)	105-73	420562	Pulley, Dual Groove
84-84	786558	Tine Assy., Inner L.H.				105-78	420828	Pulley
84-85	786574	Tine Assy., Inner R.H.	101-84	416693	Pinion, 18T	105-80	420927	Pulley
84-86	786616	Tine Assy., Outer L.H.	101-86	416719	Worm	105-81	420869	Pulley, Dual Groove
84-87	786640	Tine Assy., Outer R.H.	101-87		Gear Use 416776, 417519 & 446666)	105-82	420661	Pulley, Control Cable
84-88	786665	Tine Assy., L.H. Inner				105-83	420760	Pulley
84-89	786681	Tine Assy., R.H. Inner	101-88		Gear (Use 416834 w/89385)	105-84	697144	Pulley
84-90	786723	Tine Assy., L.H. Outer				105-85	697144	Pulley
84-91	786749	Tine Assy., R.H. Outer	101-90	416776	Gear, Worm 30T	105-87	697144	Pulley, Idler
			101-91	416784	Gear, Brass	105-88	420760	Pulley & Clevis Assy
85-10	786905	Crank Assy.	101-92	416792	Gear, Worm	105-92	420828	Pulley, Three Groove
85-11	783860	Crank	101-94	416818	Gear, Drive	105-94	420869	Pulley, Dual Groove
			101-95	416834	Gear, Drive 18T	105-96	420919	Pulley, Dual Groove
87-16	787150	Body	101-96	662007	Gear Assy.	105-97	420927	Pulley, Reverse
87-20	787150	Body, Snow Thrower	101-99	416909	Gear, Chute	105-98	420935	Pulley, Forward
87-21	600148	Chute Assy.				105-99	420968	Pulley Assy
87-22	787184	Body, Snow Thrower	102-87	419051	Shaft, Auger	105-102	419630	Pulley, Engine Traction
87-24	787200	Body, Snow Thrower	102-88		Shaft Tiller Output (Use 417519, 416776 & 446666)	105-103	419648	Pulley, Traction
87-26	787242	Body Assy.				105-105	419689	Pulley, Drive
						105-106	419697	Pulley, Engine
89-40	787929	Hub, Adapter	102-89	419077	Shaft, Tiller Input	105-107	419705	Pulley, Impeller Drive
89-41	787937	Hub, Ext. Tine	102-93	419127	Shaft, Auger	105-108	419713	Pulley, Impeller Drive
89-42	787960	Hub, Outer	102-107	417006	Shaft, Idler	105-109	419721	Clevis Assy.
89-43	787994	Hub, Inner	102-109	417022	Shaft, Axle	105-100	419614	Clevis Assy.
89-44	788034	Hub, Ext.	102-135	417360	Shaft, Axle	105-112	419770	Pulley, Drive
89-50	788109	Hub Assy., Outer	102-136		Shaft (Use 417923 w/2 489385)	105-113	419788	Pulley
89-51	788133	Hub Assy., Inner				105-114	419820	Pulley
89-54	788182	Hub Assy., Outer	102-137	417386	Shaft, Drive	105-115		Pulley (Use 419838 w/418285)
89-55		Hub (Use 452243 w/788281)	102-138		Shaft (For B & S Engine, use 417741 for Tec. Engine, use 417444)	105-117	419820	Pulley, Engine
89-63	788281	Hub & Bushing Assy.				105-118	419838	Pulley, Auger
89-65	788315	Hub, Drive	102-139	417402	Shaft, Drive	105-119	697144	Pulley, Idler
			102-141	417436	Shaft, Input			
98-5	790238	Ring, Snap	102-143	417444	Shaft, Drive	107-8	421412	Belt "O" Section
98-6	790345	Ring "O"	102-144	417469	Shaft Assy., Input 11T	107-35	421313	Belt
98-7	790451	Ring, Snap	102-147	417501	Shaft Assy., Output 17T	107-37	421313	Belt, Special
98-10	789800	Ring, "O"	102-148	417519	Shaft, Output	107-38	421321	Belt, Forward
98-12	789826	Ring	102-149	417527	Shaft, Drive	107-39	421339	Belt, Reverse
98-14	789842	Ring, Retaining	102-150	417543	Shaft, Auger	107-40		Belt (Use 4L380)
98-15	789859	Ring, Retaining	102-152	417568	Spindle Assy., Disc Drive	107-41		Belt (Use 4L400)
98-17	789875	Ring, Retaining				107-42	421370	Belt
98-18	789883	Ring, Retaining	102-153	417584	Shaft, Disc Drive			
98-48	790212	Retainer, Belt	102-154	417592	Shaft, Clutch Roller	108-66	422162	Lever, Wheel Adj.
98-49	790220	Ring, Retaining	102-155		Shaft Assy., Drive (Use 417626 w/434779)	108-67	422188	Lever, Engagement
98-56	790303	Retainer				108-68	422196	Lever, Shift
98-59	790337	Ring, Retaining				108-69	422212	Lever, Engaging
98-62	790378	Ring, Retaining	102-157	417634	Shaft, Differential	108-70	422238	Lever, Wheel Adj.
98-66	790410	Ring, Retaining	102-158		Shaft (Use 410464, 490235 & 417956)	108-71	422253	Lever, Wheel Adj.
98-70	790477	Belt Retainer				108-76	422303	Lever, Clutch & Brake
98-71	790485	Belt Retainer Assy.	102-160	417691	Shaft & Sprocket, Input	108-79	422337	Lever, Auger Clutch
98-74	790535	Belt Retainer Assy.	102-162	417725	Shaft & Sprocket, Output	108-82	422386	Lever, Height Adj.
98-75	790550	Retainer, Bearing				108-84	422410	Lever, Height Adj.
98-76	790568	"O" Ring	102-163	417741	Shaft, Pinion	108-86	422451	Lever, Auger Clutch
98-77	790576	"O" Ring	102-164	417766	Shaft, Pinion	108-87	422477	Lever Assy., Auger Idler
98-78	790584	"O" Ring	102-165	417774	Shaft, Clutch	108-89	422519	Release Arm, Clutch
98-79		Ring (Use 452243 w/788281)	102-166	417808	Shaft, Drive	108-90	422550	Release Arm, Clutch
			102-169	417840	Shaft	108-97	422634	Lever
98-80	790618	Ring Retainer	102-171	417881	Shaft, Drive	108-98	422667	Lever
98-81	790626	Retainer, Bearing	102-173	417923	Shaft, Drive			
98-82	790634	"O" Ring	102-174	417931	Shaft, Auger	110-5	425322	Chain, Roller No. 41
98-83	790659	Retainer, Show Chute	102-176	417956	Shaft, Impeller	110-6	425439	Chain, Roller No. 41
98-84	790667	Ring, Retaining	102-177	417972	Shaft, Clutch Roller	110-9	425512	Master Link No. 41
98-86	790691	Retainer, Bearing	102-178	417980	Shaft, Auger	110-10	424895	Half Link No. 41
98-87	790709	Ring, Retaining	102-180	417881	Shaft, Drive	110-16	424952	Chain, Roller No. 41
98-88	790725	Retainer Plate, Bearing	102-181	418053	Shaft	110-24	425041	Half Link, No. 35
			102-183	418095	Shaft, Transmission	110-29	425090	Chain, Roller No. 41
			102-185	418285	Shaft	110-31	425124	Master Link No. 420
99-62	791350	Frame, Engine Mount	102-186	418160	Shaft, Clutch	110-36	425173	Chain
99-63	791376	Frame Assy.	102-187	418178	Shaft	110-37	425181	Chain, Roller No. 48
99-70	791467	Frame, Engine Mount	102-190	418236	Shaft	110-38	425199	Chain, Roller No. 48
99-71	791475	Frame				110-39	120295	Master Link No. 48

Atlas Part No.	G.P.E. Part No.	Description	Atlas Part No.	G.P.E. Part No.	Description	Atlas Part No.	G.P.E. Part No.	Description
110-40	425223	Half Link No. 48	129-8	432849	Gear Lube, Tiller	137-23	435602	Cap, Brush
110-43	425256	Chain, Roller No 41				137-24	435610	Cap, Fuel
110-46	425280	Chain, Roller No. 48	130-18	433268	Shroud			
110-47	425298	Chain, Roller No. 41	130-19	433276	Shroud, Engine	138-4	435750	Wrench
110-48	425306	Chain, Roller No. 48	130-20	433300	Chute			
110-49	425314	Chain, Roller No. 35	130-22	433300	Chute	139-6	435818	Cam, Ratchet
110-50	425421	Chain, Roller No. 420	130-25	433367	Chute Extension			
110-51	425348	Chain, Roller No. 50	130-26	433367	Chute	143-5	436584	Battery
110-53	425363	Chain, Roller No. 41	130-28	433391	Chute			
110-54	425371	Chain, Roller No. 41	130-32	433466	Chute Assy.	154-2	441790	Door, Hopper
110-55	425389	Chain, Roller No. 42	130-33	433482	Shroud	154-3	441808	Door, Hopper
110-56	425397	Chain, Roller No. 420	130-41	433599	Chute	154-6	441840	Door Chute
110-58	425413	Master Link No. 42	130-44	433631	Chute Assy.	154-7	124016	Door Assy.
110-59	425421	Chain, Roller No. 420	130-49	433698	Shroud Assy.			
110-60	425447	Chain, Roller No. 48				156-4	441931	Hopper Assy.
110-62	425462	Chain, Roller No. 48	134-13	434001	Link, Connecting	156-7	441972	Hopper Assy.
110-63	425470	Chain, Roller No. 48	134-14	434027	Link, Connecting			
110-64	425488	Chains (Use TC 13)			(for 8 HP snow thrower, order 82-141 rod)	158-3	132415	Brush Assy.
112-44	425959	Strap, Handle						
112-46	731216	Strap	134-15	434076	Link	161-1	446799	Pad, Protective
112-48	426015	Strap, Nut Plate	134-16	434050	Link			
112-49	662049	Strap, Chain Cover Mtg.	134-17	434076	Link	163-1	446856	Beam, Main Support L.H.
112-50	426056	Strap, Cover Mtg.	134-18	662171	Link			
112-53	426080	Strap, Trail Guard	134-19	434050	Link	163-2	446872	Beam, Main Support R.H.
			134-20	434076	Link			
114-5	426437	Plug, Tiller				163-3	446898	Beam, Main Support L.H.
114-24	426379	Plug, Oil Fill	135-5	434720	Sprocket, 11T			
114-26	426395	Plug	135-6	434845	Sprocket, Thrower 6T	163-4	446914	Beam, Main Support R.H.
			135-10	434233	Sprocket, Clutch Dog			
115-22	426627	Pad	135-20	434357	Sprocket, Thrower 45T	163-5	446930	Beam, Main Support R.H.
			135-23	434399	Sprocket, 13T			
120-11	697136	Slide	135-24	170142	Sprocket	163-6	446955	Beam, Main Support L.H.
120-12	697136	Slide	135-25	170142	Sprocket, 8T			
120-17	697136	Foot, Slide	135-40	434605	Sprocket, 18T			
			135-41	434613	Sprocket, 10T.	164-1	447011	Channel, Handle Support
121-34	430298	Brake Assy.	135-45	434662	Sprocket, 12T-26T, Lower	164-2	447052	Channel, Wheel Adj.
121-36	430314	Brake Hub Assy.				164-4	447078	Channel, Handle Mounting R.H.
121-39	430355	Stop, Clutch Hinge	135-47	590018	Sprocket, 11T-36T, Upper	164-5	447086	Channel, Handle Mounting L.H.
121-41	430397	Brake Lining						
			135-52	434753	Sprocket, Clutch 18T			
122-44	430850	Guard, Tiller Belt	135-53	434761	Sprocket, 24T	164-9	447136	Channel, R.H.
122-45	430876	Guide, Tiller Cable	135-54	434779	Sprocket	164-10	447037	Channel, L.H.
122-71	431171	Chain Guard Assy.	135-58	434829	Sprocket Assy.			
122-72	431197	Belt Guard	135-60	434860	Sprocket, Drive			
122-73	431221	Guide, Belt	135-61	434878	Sprocket, 8T	165-1	447144	Band, Brake
122-74	431254	Guide, Belt	135-62	170142	Sprocket, 8T			
122-80	431338	Guide, Belt	135-63	434910	Sprocket, Drive	166-1	447151	Drum
122-84	431387	Guide, Belt	135-64	434936	Sprocket			
122-85	431502	Guide, Belt	135-65	434944	Sprocket	167-1	447177	Rubber Strip
122-90	431502	Guide, Spring	135-66	434951	Sprocket	168-1	447185	Spout, Gas Overfill
123-12	431569	Roller, Lift Mechanism	136-11	435032	Bar, Tiller Drag			
123-13	431577	Roller, Brake	136-18		Bar (Use 454488 w/435198)	ES116	408922	Electric Starter Kit
123-14	431585	Roller, Disc Drive				ES120	408930	Electric Starter Kit
			136-19	435123	Bar, Breaker	ES130	408948	Electric Starter Kit
128-41	432260	Trans. Weld Assy.	136-21	435164	Bar, Breaker	TC10	409391	Tire Chains 2.75 x 10
128-42	432260	Trans. Weld Assy.	136-23	435198	Bar, Breaker	TC13	425488	Tire Chains 12.5/4.50-6
128-43	432310	Transmission Assy.	136-25	435230	Bar, Scraper	TC11	662676	Tire Chains 4.10x3.50-4
128-44	432708	Clutch Assy.	136-29	435289	Bar, Drag			
128-46	590026	Weld Assy., Transmission Half	136-33	435339	Bar, Scraper			
			136-36	435370	Bar, Scraper			
128-49	432427	Transmission Assy.						
128-52	432708	Clutch Assy.	137-9	435529	Tip			
128-56		Clutch (Use 432658 w/775809)	137-13	435495	Tip, Spring			
			137-14	435503	Tip			
128-58	432559	Gas Tank	137-15	435511	Cap, Protective			
128-59	432567	Clutch	137-16	435529	Tip, Q.W.A. Spring			
128-64	303388	Fuel Filter	137-18	435545	Tip			
128-65	432633	Primer	137-19	435552	Tip			
128-67	432658	Clutch Assy.	137-21	435586	Cap, Fuel			
128-71	432708	Clutch Assy.	137-22	110510	Cap			

ACCESSORIES

ES116	408922	Electric Starter Kit
ES120	408930	Electric Starter Kit
ES130	408948	Electric Starter Kit
TC10	409391	Tire Chains 2.75 x 10
TC13	425488	Tire Chains 12.5/4.50-6
TC11	662676	Tire Chains 4.10x3.50-4