



HP LaserJet - JetDirect Compatibility

HP LaserJet Enterprise series	ew2500	695nw	640n	635n	620n	1284B
HP LaserJet Enterprise 500 MFP M525*	√					
HP LaserJet Enterprise flow MFP M525c*	√					
HP LaserJet Enterprise 500 Color Printer M551*	√					
HP LaserJet Enterprise 500 Color MFP M575*	√					
HP LaserJet Enterprise color flow MFP M575c*	√					
HP LaserJet Enterprise 600 Printer M601	√					
HP LaserJet Enterprise 600 Printer M602*	√					
HP LaserJet Enterprise 600 Printer M603*	√					
HP LaserJet Enterprise MFP M630	√					
HP Color LaserJet Enterprise M651 Printer	√					
HP Color LaserJet Enterprise M680 Multifunction Printer	√					
HP LaserJet Enterprise series	ew2500	695nw	640n	635n	620n	1284B
HP LaserJet Enterprise 700 M712*	√					
HP LaserJet Enterprise 700 MFP M725*	√					

HP Color LaserJet Enterprise M750 Printer	✓					
HP LaserJet Enterprise 700 Color MFP M775*	✓					
HP LaserJet Enterprise M806 Printer	✓					
HP LaserJet Enterprise flow M830 Multifunction Printer	✓					
HP Color LaserJet Enterprise M855	✓					
HP Color LaserJet Enterprise flow MFP M880	✓					
HP Color LaserJet Enterprise CM4540 MFP	✓	✓	✓	✓		
HP LaserJet Enterprise M4555 MFP	✓	✓	✓	✓		
HP Color LaserJet Enterprise CP5525 Printer	✓	✓	✓	✓		
HP LaserJet Pro series	ew2500	695nw	640n	635n	620n	1284B
HP LaserJet Pro 300 M351 Printer	✓					
HP LaserJet Pro 400 M401 Printer	✓					
HP LaserJet Pro 400 M451 Printer	✓					
HP LaserJet series	ew2500	695nw	640n	635n	620n	1284B
HP Color LaserJet CM1015/CM1017 MFP	✓					
HP Color LaserJet CP1025	✓					
HP LaserJet 1160	✓					

	✓					
HP Color LaserJet CM1312 MFP						✓
HP LaserJet 1320 Printer	✓					
HP Color LaserJet CP1510/CP1514/CP1515/CP1518 Printer	✓					
HP Color LaserJet CP1525 Printer	✓					
HP LaserJet P2010/P2014 Printer	✓					
HP LaserJet P2015 Printer	✓					
HP Color LaserJet CP2025 Printer	✓					
HP LaserJet P2035 Printer	✓					
HP LaserJet P2055 Printer	✓					
HP LaserJet 2200 Printer				✓	✓	
HP LaserJet 2300 Printer				✓	✓	
HP LaserJet 2400/2410/2420/2430 Printer		✓	✓	✓	✓	
HP LaserJet series	ew2500	695nw	640n	635n	620n	1284B
HP Color LaserJet 2500				✓	✓	
HP Color LaserJet 2600n	✓					
HP Color LaserJet 2605	✓					

HP Color LaserJet 2700	✓					
HP Color LaserJet 3000 Printer	✓	✓	✓	✓	✓	✓
HP Color LaserJet P3005 Printer	✓	✓	✓	✓	✓	✓
HP LaserJet Enterprise P3015 Printer	✓	✓	✓	✓	✓	✓
HP LaserJet M3027 Multifunction Printer	✓	✓	✓	✓	✓	✓
HP LaserJet M3035 Multifunction Printer	✓	✓	✓	✓	✓	✓
HP Color LaserJet CP3505 Printer	✓	✓	✓	✓		✓
HP Color LaserJet CP3520/CP3525 Printer	✓	✓	✓	✓	✓	✓
HP Color LaserJet CM3530 MFP	✓	✓	✓	✓	✓	✓
HP Color LaserJet 3600 Printer	✓					
HP Color LaserJet 3700 Printer				✓	✓	
HP Color LaserJet 3800 Printer	✓	✓	✓	✓	✓	✓
HP LaserJet series	ew2500	695nw	640n	635n	620n	1284B
HP LaserJet 4000 Printer				✓	✓	
HP Color LaserJet CP4005 Printer	✓					
HP LaserJet P4014 Printer	✓	✓	✓	✓	✓	✓
HP LaserJet P4015 Printer	✓	✓	✓	✓	✓	✓

HP Color LaserJet Enterprise CP4025 Printer	✓	✓	✓	✓	✓	✓
HP LaserJet 4050 Printer				✓	✓	
HP LaserJet 4100 Printer				✓	✓	
HP LaserJet 4100 Multifunction Printer				✓	✓	
HP LaserJet 4200 Printer				✓	✓	
HP LaserJet 4240 Printer	✓	✓	✓	✓	✓	
HP LaserJet 4250 Printer	✓	✓	✓	✓	✓	
HP LaserJet 4300 Printer				✓	✓	
HP LaserJet 4345 Multifunction Printer		✓	✓	✓	✓	
HP LaserJet M4345 Multifunction Printer	✓	✓	✓	✓	✓	✓
HP LaserJet 4350 Printer	✓	✓	✓	✓	✓	
HP LaserJet 4500 Printer				✓	✓	
HP LaserJet series	ew2500	695nw	640n	635n	620n	1284B
HP LaserJet P4510/P4515 Printer	✓	✓	✓	✓	✓	✓
HP Color LaserJet Enterprise CP4525 Printer	✓	✓	✓	✓	✓	✓
HP LaserJet 4550 Printer				✓	✓	
HP LaserJet 4600/4610 Printer				✓	✓	

HP LaserJet 4650 Printer				✓	✓	
HP LaserJet 4700 Printer	✓	✓	✓	✓	✓	
HP Color LaserJet 4730 Multifunction Printer	✓	✓	✓	✓	✓	✓
HP Color LaserJet CM4730 MFP	✓	✓	✓	✓		✓
HP LaserJet 5000 Printer				✓	✓	
HP LaserJet M5025 Multifunction Printer	✓	✓	✓	✓	✓	✓
HP LaserJet M5035 Multifunction Printer	✓	✓	✓	✓	✓	✓
HP LaserJet 5100 Printer				✓	✓	
HP LaserJet 5200 Printer	✓	✓	✓	✓	✓	
HP LaserJet CP5225 Professional Printer	✓					
HP Color LaserJet 5500 Printer				✓	✓	
HP Color LaserJet 5550 Printer	✓	✓	✓	✓	✓	
HP LaserJet series	ew2500	695nw	640n	635n	620n	1284B
HP Color LaserJet CP6015 Printer	✓	✓	✓	✓	✓	✓
HP Color LaserJet CM6030/CM6040 MFP	✓	✓	✓	✓	✓	✓
HP LaserJet 8000 Printer				✓	✓	
HP CM8000/CM8050/CM8060 Color MFP		✓	✓	✓		✓

HP LaserJet 8100 Printer				✓	✓	
HP LaserJet 8150 Printer				✓		
HP Color LaserJet 8500 Printer				✓	✓	
HP Color LaserJet 8550 Printer				✓	✓	
HP LaserJet 8550 Multifunction Printer				✓	✓	
HP LaserJet 9000 Printer				✓	✓	
HP LaserJet 9000 Multifunction Printer				✓	✓	
HP LaserJet 9040 Printer		✓	✓	✓	✓	
HP LaserJet 9050 Printer		✓	✓	✓	✓	
HP LaserJet 9040/9050 MFP		✓	✓	✓	✓	
HP LaserJet M9040/M9050 MFP	✓	✓	✓	✓	✓	✓
HP Color LaserJet 9500 Printer				✓	✓	
HP Color LaserJet 9500 Multifunction Printer					✓	
HP LaserJet series	ew2500	695nw	640n	635n	620n	1284B
HP Color LaserJet 2800 All-in-One (2820/2840)	✓					
HP LaserJet 3050 All-in-One	✓					
HP LaserJet 3052 All-in-One	✓					

HP LaserJet 3055 All-in-One	✓					
HP LaserJet 3380 All-in-One	✓					
HP LaserJet 3390 All-in-One	✓					
HP LaserJet 3392 All-in-One	✓					