

IBM Software Support Services - ETS4 SAN/Storage
 Supported Products List
 Support Group: ETS4 SAN/Storage
 European, Middle Eastern, and African Regions (EMEA)
 Last Updated: 9 October 2018

Hardware Product Name	Product ID	Support End
SYSTEM STORAGE DS3400 DUAL	1726-PAM	
IBM SYSTEM STORAGE EXP3000	1729-01X	
EXP3000 DC POWER MODEL 02T	1730-01X	
DS3512 Express Dual Controller Storage System	1746-A2D	
Expansion	1746-A2E	
DS3512 Express Single Controller Storage System	1746-A2S	31.12.2018
DS3524 Express Dual Controller Storage System	1746-A4D	
Expansion	1746-A4E	
DS3524 Express Single Controller Storage System	1746-A4S	31.12.2018
DS3512 Express Storage System	1746-C2A	31.12.2019
DS3524 Express Storage System	1746-C4A	31.12.2019
DS3524 Express DC Storage	1746-C4T	31.12.2018
Expansion	1746-E2A	31.12.2019
Expansion	1746-E4A	
Expansion	1746-E4T	31.12.2018
DS3524 Express DC Dual Controller Storage System	1746-T4D	31.12.2018
EXP3524 Express Storage Expansion Unit	1746-T4E	31.12.2018
System Storage EXP2512	1747-HC1	
System Storage EXP2512	1747-HC2	
1812 81A DS4000 EXP810 FC-FC SBOD	1812-81A	31.12.2019
1812 81H DS4000 EXP810 FC-FC SBOD	1812-81H	31.12.2019
SYSTEM STORAGE EXP3800	1813-80E	31.12.2019
SYSTEM STORAGE DCS3860 Expansion	1813-80H	
SYSTEM STORAGE DCS3860	1813-86C	30.06.2019
SYSTEM STORAGE DCS3860	1813-86H	
SYSTEM STORAGE DCS3860	1813-96C	
IBM SYSTEM STORAGE DS5020 MIDRANGE DISK SYSTEM	1814-20A	31.12.2019
IBM SYSTEM STORAGE EXP520 STORAGE EXPANSION UNIT	1814-52A	31.12.2019
SYSTEM STORAGE DCS3860	1814-86C	
1818 51A IBM System Storage DS5100 Disk System	1818-51A	31.12.2019
1818 53A IBM System Storage DS5300 Disk System	1818-53A	31.12.2019
IBM System Storage DCS3700	1818-80C	30.06.2019
DCS3700 EXPANSION UNIT	1818-80E	
1818 D1A IBM System Storage EXP5000 Expansion UNIT	1818-D1A	31.12.2019
IBM SYSTEM STORAGE Remote Support Manager	1818-RS3	31.12.2018
2005 B08 SANB08-2 Fabric Switch (2005-B08)	2005-B08	
MCDATA ES-3216 ITERRUP FABRICA	2031-216	
MCDATA SPHEREON 4500 SWITCH	2031-224	
MCDATA ES-3232 ITERRUP FABRIC	2031-232	
MCDATA SPHEREON 4500 SWITCH	2031-E24	
MCDATA ED-6064 DIRECTOR FC	2032-064	
MCDATA ENTERPRISE FC DIRECTOR	2032-140	
2053 424 CISCO MDS 9124 Multilayer Fabric Switch	2053-424	31.01.2019
2054 AC1 CISCO MDS 9500 Series Directors 18/4 Multiservice Module	2054-AC1	31.12.2018
2054 E01 CISCO MDS 9222I	2054-E01	
2054 E04 CISCO MDS 9506 Multilayer Fabric Switch	2054-E04	
2054 E07 CISCO MDS 9509 Multilayer Fabric Switch	2054-E07	30.04.2019
2054 E11 CISCO MDS 9513 Multilayer Fabric Switch	2054-E11	
CISCO CWDM Ext. Distance Solution	2062-CW1	31.12.2018
2062 D04 CISCO Storage Switch MDS 9506	2062-D04	
2062 D07 CISCO Storage Switch MDS 9509	2062-D07	30.04.2019
2062 E11 CISCO MDS 9513 Multilayer Director	2062-E11	
2062 T04 CISCO Storage Switch MDS 9506	2062-T04	

2062 T07 CISCO Storage Switch MDS 9509	2062-T07	30.04.2019
Storwize V3700 LFF Dual Contro Enclosure	2072-12C	
Storwize V3700 LFF Expansion Enclosure	2072-12E	
Storwize V3700 LFF Dual Contro Enclosure	2072-24C	
Storwize V3700 LFF Expansion Enclosure	2072-24E	
V3700 SFF DC DUAL CONTROL	2072-2DC	
V3700 SFF DC EXPANSION	2072-2DE	
V3700 LFF DUAL CONTROL	2072-L2C	
V3700 LFF EXPANSION	2072-LEU	
IBM Storwize V3700 drive enclosure	2072-S2C	
Storwize V3700 Expansion Enclosure	2072-SEU	
V3700 SFF DC DUAL CONTROL	2072-T2C	
V3700 SFF DC EXPANSION	2072-TEU	
IBM Storwize V7000 Unified	2073-700	
STORWIZE V7000 UNIFIED	2073-720	
2076-112 Control Enclosure, with 12 3.5-inch drive slots	2076-112	
2076-124 Control Enclosure with 24 2.5-inch drive slots	2076-124	
V7000 LFF EXPANSION	2076-12F	
2076-212 Expansion Enclosure with 12 3.5" drive slots	2076-212	
2076-224 Expansion Enclosure with 24 2.5" drive slots	2076-224	
V7000 LFF EXPANSION	2076-24F	
IBM Storwize V7000 10 GbE controller LFF 12 drive enclosure	2076-312	
IBM Storwize V7000 10 GbE controller SFF 12 drive enclosure	2076-324	
V7000 SFF CONTROL	2076-524	
IBM Storwize V7000 24-drive enclosure SSDs	2076-624	
IBM Storwize V7000 Density Expansion	2076-92F	
IBM all Flash Storwize V7000 High-Density Expansion (all flash)	2076-A9F	
IBM all Flash Storwize V5030F controler	2076-AF6	
IBM Storwize V7000 High Density Expansion	2076-AFF	
IBM Storwize v7000 Storage utility model	2076-U7A	
IBM Storwize V5010 controler	2077-112	
IBM Storwize V5010 controler	2077-124	
IBM Storwize V5000	2077-12C	
IBM Storwize V5000 Expansion	2077-12E	
IBM Storwize V5010 Expansion	2077-12F	
IBM Storwize V5020 controler	2077-212	
IBM Storwize V5020 controler	2077-224	
IBM Storwize V5000	2077-24C	
IBM Storwize V5000 Expansion	2077-24E	
IBM Strowize V5020 Expansion	2077-24F	
IBM Storwize V5030 controler	2077-312	
IBM Storwize V5030 controler	2077-324	
IBM Storwize V7000 Density Expansion	2077-92F	
IBM all Flash Storwize V5030F High-Density Expansion (all flash)	2077-A9F	
IBM all Flash Storwize V5030F controler	2077-AF3	
IBM all Flash Storwize V5030F Expansion	2077-AFF	
IBM Storwize V5010 controler	2078-112	
IBM Storwize V5010 controler	2078-124	
IBM Storwize V5000	2078-12C	
IBM Storwize V5000 Expansion	2078-12E	
IBM Storwize V5000 Expansion	2078-12F	
IBM Storwize V5010 controler	2078-212	
IBM Storwize V5020 controler	2078-224	
IBM Storwize V5000	2078-24C	
IBM Storwize V5000 Expansion	2078-24E	
IBM Storwize V5000 Expansion	2078-24F	
IBM Storwize V5030 controler	2078-312	
IBM Storwize V5030 controler	2078-324	
IBM all Flash Storwize V5000 Expansion	2078-92F	
IBM all Flash Storwize V5030F High-Density Expansion (all flash)	2078-A9F	

IBM all Flash Storwize V5030F controler	2078-AF3	
IBM all Flash Storwize V5030F Expansion	2078-AFF	
IBM Storwize v5030 Storage utility model	2078-U5A	
IBM TotalStorage SAN Switch Cabinet C36U (RACK)	2109-C36	
SVC SFF EXPANSION ENCLOSURE	2145-12F	
SVC SFF EXPANSION ENCLOSURE	2145-24F	
2145 8A4 IBM System Storage SAN Volume Controller Storage Engine	2145-8A4	31.12.2018
2145 8G4 IBM System Storage SAN Volume Controller Storage Engine	2145-8G4	31.12.2018
IBM SVC High Density Expansion	2145-92F	
IBM SYSTEM STORAGE SAN VOLUME CONTROLLER STORAGE ENGINE	2145-CF8	30.06.2019
IBM SYSTEM STORAGE SAN VOLUME CONTROLLER STORAGE ENGINE	2145-CG8	30.06.2019
SVC STORAGE ENGINE	2145-DH8	
IBM Storage SVC	2145-SV1	
IBM Storage SVC	2147-12F	
IBM Storage SVC	2147-24F	
IBM SVC High Density Expansion	2147-92F	
IBM Storage SVC	2147-SV1	
2417 (SAN C-Type Switch Cisco MDS 9148)	2417-C48	
2421 951 IBM System Storage DS8100	2421-951	31.03.2019
2421 95E IBM System Storage DS8000 Expansion Unit	2421-95E	31.03.2019
2421 961 IBM System Storage DS8100	2421-961	
2421 96E IBM System Storage DS8000 Expansion Unit	2421-96E	
2422 951 IBM System Storage DS8100	2422-951	31.03.2019
2422 95E IBM System Storage DS8000 Expansion Unit	2422-95E	31.03.2019
2422 961 IBM System Storage DS8100	2422-961	
2422 96E IBM System Storage DS8000 Expansion Unit	2422-96E	
2423 951 IBM System Storage DS8100	2423-951	31.03.2019
2423 95E IBM System Storage DS8000 Expansion Unit	2423-95E	31.03.2019
2423 961 IBM System Storage DS8100	2423-961	
2423 96E IBM System Storage DS8000 Expansion Unit	2423-96E	
2424 951 IBM System Storage DS8100	2424-951	31.03.2019
2424 95E IBM System Storage DS8000 Expansion Unit	2424-95E	31.03.2019
2424 961 IBM System Storage DS8100	2424-961	
2424 96E IBM System Storage DS8000 Expansion Unit	2424-96E	
IBM SYSTEM STORAGE 8 GB B-TYPE SWITCH	2498-24E	
IBM System Networking SAN24B-5	2498-24G	
2498-B24 8Gb Switch	2498-B24	
2498-B80 8Gb Switch	2498-B80	31.07.2019
IBM Encryption Switch SAN32B-E4	2498-E32	31.12.2018
IBM System Networking SAN24B-5	2498-F24	
IBM System Storage SAN48B-5	2498-F48	
System Networking SAN96B-5	2498-F96	
SAN96B	2498-N96	
2498-R06 Router	2498-R06	
2498-R42 Router	2498-R42	
IBM System Networking SAN24B-5	2498-X24	
2498-DCX-4S 8Gb Director	2499-192	31.12.2019
2498-DCX 8Gb Director	2499-384	31.12.2019
IBM System Storage 16 Gbps Switch SAN384B-2	2499-416	
IBM System Storage SAN	2499-486	
IBM System Storage 16 Gbps Switch SAN768B-2	2499-816	
IBM System Storage Productivity Center V1.3	2805-MC3	
IBM System Storage Productivity Center V1.4	2805-MC4	
IBM System Storage Productivity Center V1.5	2805-MC5	
IBM XIV Gen3 Storage System	2810-114	
IBM XIV Gen3 Storage System	2810-214	
Model install in a customer rack (not standard)	2810-215	
XIV STORAGE SYSTEM MODEL R3	2810-216	
IBM XIV Storage System Model 314	2810-314	
2810 A14 IBM XIV Storage System Model A14	2810-A14	31.12.2018

IBM XIV Gen3 Storage System	2812-114	
Model install in a customer rack (not standard)	2812-116	
IBM XIV Gen3 Storage System	2812-214	
XIV STORAGE SYSTEM MODEL R3	2812-215	
IBM XIV Gen3 Storage System	2812-216	
IBM XIV Storage System Model 314	2812-314	
2812 A14 IBM XIV Storage System Model A14	2812-A14	31.12.2018
DS8884 Flash Expansion Gen2	2831-84E	
DS8886 Flash Expansion Gen2	2831-85E	
DS8886 Flash Expansion Gen2	2831-86E	
DS8884 Controler	2831-980	
DS8886 Controler	2831-981	
DS8880 all Flash Controler	2831-982	
DS8880 all Flash Controler	2831-984	
DS8886 Flash Controler Gen2	2831-985	
DS8886 Flash Expansion Gen2	2831-986	
DS8884 Expansion Unit	2831-98B	
DS8886 Expansion Unit	2831-98E	
DS8880 all Flash Expansion	2831-98F	
DS8884 Flash Expansion Gen2	2832-84E	
DS8886 Flash Expansion Gen2	2832-85E	
DS8886 Flash Expansion Gen2	2832-86E	
DS8884 Controler	2832-980	
DS8886 Controler	2832-981	
DS8880 all Flash Controler	2832-982	
DS8880 all Flash Controler	2832-984	
DS88886 Flash Controller Gen2	2832-985	
DS88886 Flash Controller Gen2	2832-986	
DS8884 Expansion Unit	2832-98B	
DS8886 Expansion Unit	2832-98E	
DS8880 all Flash Expansion Unit	2832-98F	
DS88884 Flash Controller Gen2	2833-84E	
DS88886 Flash Controller Gen2	2833-85E	
DS88886 Flash Controller Gen2	2833-86E	
DS8884 Controler	2833-980	
DS8886 Controler	2833-981	
DS8880 all Flash Controler	2833-982	
DS8884 Flash Expansion Gen2	2833-984	
DS88886 Flash Controller Gen2	2833-985	
DS88886 Flash Controller Gen2	2833-986	
DS8884 Expansion Unit	2833-98B	
DS8886 Expansion Unit	2833-98E	
DS8880 all Flash Expansion Unit	2833-98F	
DS8884 Flash Expansion Gen2	2834-84E	
DS8886 Flash Expansion Gen2	2834-85E	
DS8886 Flash Expansion Gen2	2834-86E	
DS8884 Controler	2834-980	
DS8886 Controler	2834-981	
DS8880 all Flash Controler	2834-982	
DS8884 Flash Controller Gen2	2834-984	
DS8886 Flash Controller Gen2	2834-985	
DS8886 Flash Controller Gen2	2834-986	
DS8884 Expansion Unit	2834-98B	
DS8886 Expansion Unit	2834-98E	
DS8880 all Flash Expansion Unit	2834-98F	
2857-003 IBM System Storage EXN3000 SAS/SATA expansion unit	2857-003	31.12.2018
IBM System Storage EXN3500 SAS expansion unit	2857-006	31.12.2018
Nseries N6220 Dual Node	2858-C25	31.12.2018
Nseries N6240 Dual Node Dual Chasis	2858-E21	31.12.2018
Nseries N6220 Dual Node Dual Chasis	2858-E25	31.12.2018

2863 004 IBM System Storage EXN4000 FC expansion unit	2863-004	31.12.2018
Magnetic Tape Subsystem	3490-C0S	
Magnetic Tape Subsystem	3490-CS2	
TS4300 Tape Library expansion	3555-E3A	
TS4300 Tape Library base module	3555-L3A	
TS2900 Tape Autoloader Model S5H	3572-S5H	
TS2900 Tape Autoloader Model S6H	3572-S6H	
Sys Stor TS2900 Tape	3572-S6R	
System Storage TS2900 Tape Autoloader	3572-S7H	
TS2900 Tape Autoloader with LTO Ultrium 8 Half-high SAS Tape Drive	3572-S8H	
Tape Library Driveless HVEC/XCC	3573-2UL	
Tape Library Driveless HVEC/XCC	3573-4UL	
IBM System Storage Tape Library Express Model - LTO 4 HVEC/XCC	3573-F4H	
3573 L2U IBM System Storage TS3100 EXPRESS Tape Library	3573-L2U	
3573 L4U IBM System Storage TS3200 Tape Library Express Model	3573-L4U	
3576 E9U IBM System Storage TS3310 Tape Library	3576-E9U	
3576 L5B IBM System Storage TS3310 Tape Library	3576-L5B	
Low cost LTO	3580-H4V	31.12.2018
DRIVE EXPRESS MODEL H5S FOR LTO ULTIUM 5	3580-H5S	
DRIVE EXPRESS MODEL H5S FOR LTO ULTIUM 5	3580-H6S	
DRIVE EXPRESS MODEL H5S FOR LTO ULTIUM 7	3580-H7S	
TS2280 SAS Tape Drive Model LTO ULTIUM 8	3580-H8S	
3580 L23 ULTRIUM 2 Tape Drive	3580-L23	31.12.2019
3580 L33 ULTRIUM 3 Tape Drive	3580-L33	31.12.2019
3580 L43 IBM System Storage Tape Drive Express Model - IBM LTO Ultrium 4 Tape Drive	3580-L43	31.12.2019
3580 L4X IBM System Storage Tape Drive Express Model - IBM LTO Ultrium 4 Tape Drive	3580-L4X	31.12.2019
TS2240DRVEXPMODH4V SAS DRVV2	3580-S4V	31.12.2019
LTO Gen. 5. FH bridge box	3580-S53	31.12.2018
DRIVE EXPRESS MODEL H5S FOR LTO ULTIUM 5 HVEC	3580-S5E	
LTO Gen. 5. FH bridge box HVEC	3580-S5X	
IBM System Storage TS2360	3580-S63	
TS2260 TAPE DRIVE MODEL H6S	3580-S6E	
TS2360 TAPE DRIVE MODEL S63	3580-S6X	
ULTRIUM TAPE 2U AUTOLOADER	3581-L28	31.12.2019
FIBRE TAPE AUTOLOADER	3581-L38	31.12.2018
3583 L36 ULTRIUM Tape Library	3583-L36	31.12.2018
3583 L72 ULTRIUM Tape Library	3583-L72	31.12.2018
Tape Library Expansion Frame	3584-D22	
3584 D23 IBM System Storage TS3500 Tape Library	3584-D23	
TS4500 HD2 EXPANSION FRAME	3584-D25	
3584 D52 Tape Library Expansion Frame	3584-D52	
3584 D53 IBM System Storage TS3500 Tape Library	3584-D53	
TS4500 HD2 EXPANSION FRAME	3584-D55	
3584 HA1 High Availability Frame	3584-HA1	
3584 L22 Tape Library Base Frame	3584-L22	
3584 L23 IBM System Storage TS3500 Tape Library	3584-L23	
3584 L25 Tape Library	3584-L25	
3584 L52 Tape Library Base Frame	3584-L52	
3584 L53 IBM System Storage TS3500 Tape Library	3584-L53	
TS4500 HD2 BASE FRAME	3584-L55	
3584 S24 IBM System Storage TS3500 Tape Library	3584-S24	
TS4500 HD2 EXPANSION FRAME	3584-S25	
3584 S54 IBM System Storage TS3500 Tape Library	3584-S54	
TS4500 HD2 EXPANSION FRAME	3584-S55	
IBM SYSTEM STORAGE TS4500 Top Rack	3584-TR1	
3588 F3A ULTRIUM 3 Tape Drive	3588-F3A	
3588 F3B IBM System Storage TS1030 Tape Drive	3588-F3B	
3588 F4A IBM System Storage TS1040 Tape Drive Model F4A	3588-F4A	
TS1050 ULTRIUM 5 TAPE DRIVE	3588-F5A	
TS1050 ULTRIUM 5 TAPE DRIVE	3588-F5C	

TS1060 ULTRIUM 6 TAPE DRIVE	3588-F6A	
TS1060 ULTRIUM 6 TAPE DRIVE	3588-F6C	
TS1060 ULTRIUM 7 TAPE DRIVE	3588-F7A	
TS1060 ULTRIUM 7 TAPE DRIVE	3588-F7C	
TS1070 ULTRIUM 8 TAPE DRIVE	3588-F8A	
TS1070 ULTRIUM 8 TAPE DRIVE	3588-F8C	
IBM TS1155 Tape Drive Ethernet	3592-55E	
IBM TS1155 Tape Drive Fibre Channel	3592-55F	
IBM TS1155 Tape Drive Fibre Channel	3592-55G	
IBM 3592 Tape Cartridge	3592-C07	31.12.2019
IBM System Storage Tape Drive	3592-E05	30.06.2019
IBM System Storage Tape Drive	3592-E06	
IBM System Storage Tape Drive	3592-E07	
IBM System Storage Tape Drive	3592-E08	
IBM System Storage Tape Drive	3592-EH7	
IBM System Storage Tape Drive	3592-EH8	
IBM System Storage Tape Drive	3592-EU6	
Tape Drive	3592-F05	
3592 J1A Enterprise Tape Drive	3592-J1A	
3592 J70 Enterprise Tape Controller	3592-J70	31.12.2018
BROCADE VDX6730 32 CONV switch	3759-C32	
BROCADE VDX6730 76 CONV switch	3759-C76	
Tape Frame Virtualization Engine TS7500	3952-F05	
Tape Frame Virtualization Engine TS7500	3952-F06	
3953 F05 IBM TotalStorage 3953 Tape Frame Model F05	3953-F05	
3953 L05 IBM TotalStorage 3953 Library Manager Model L05	3953-L05	
TS7740 cache controller	3956-CC8	31.12.2018
TS7740 cache controller	3956-CC9	
TS7720 CACHE CONTROLLER	3956-CS8	31.12.2018
TS7720 cache controller	3956-CS9	
IBM TS765G ProtecTier Gateway	3956-CSA	
TS7740 CACHE MODULE	3956-CX7	31.12.2018
TS7740 CACHE CNTRLLR 13.2 TB	3956-CX9	
TS7720 SATA CACHE MODULE	3956-XS7	31.12.2018
7720 cache drawer	3956-XS9	
IBM TS765G ProtecTier Gateway	3956-XSA	
IBM Virtualization Engine TS7740 Server	3957-V07	
VEB cache controller	3957-VEB	
IBM System Storage TS650G Server	3957-VEC	
TS7650G Server	3958-DD5	
TS7650G Server	3958-DD6	
TS7620 ProtecTIER Expansion Drawer	3959-EXP	
TS7620 ProtecTIER Deduplication Appliance Express	3959-SM2	
IBM Flex System V7000 Storage Node Control Enclosure	4939-A29	31.12.2019
IBM Flex System V7000 Storage Node Control Enclosure	4939-A49	31.12.2019
IBM Flex System V7000 Storage Node Control Enclosure	4939-H29	31.12.2019
IBM Flex System V7000 Storage Node Control Enclosure	4939-H49	31.12.2019
IBM Flex System V7000 Storage Node Control Enclosure	4939-X29	31.12.2019
IBM Flex System V7000 Storage Node Control Enclosure	4939-X49	31.12.2019
IBM ESS 2U24 Storage all-flash for Elastic Storage Server	5147-024	
IBM ESS JBOD Storage (5U84)	5147-084	
IBM Elastic Storage Server 4U106 Storage	5147-106	
IBM DS8886 all-flash Expansion	5331-85E	
IBM DS8886 all-flash Expansion	5331-86E	
IBM DS8888 all-flash Expansion	5331-88E	
IBM DS8882F rack mounted model	5331-983	
IBM DS8884 all-flash	5331-984	
IBM DS8886 all-flash	5331-985	
IBM DS8886 all-flash	5331-986	
IBM DS8888 all-flash	5331-988	

IBM DS8886 all-flash Expansion	5332-85E	
IBM DS8886 all-flash Expansion	5332-86E	
IBM DS8888 all-flash Expansion	5332-88E	
IBM DS8882F rack mounted model	5332-983	
IBM DS8884 all-flash	5332-984	
IBM DS8886 all-flash	5332-985	
IBM DS8886 all-flash	5332-986	
IBM DS8888 all-flash	5332-988	
IBM DS8886 all-flash Expansion	5333-85E	
IBM DS8886 all-flash Expansion	5333-86E	
IBM DS8888 all-flash Expansion	5333-88E	
IBM DS8882F rack mounted model	5333-983	
IBM DS8884 all-flash	5333-984	
IBM DS8886 all-flash	5333-985	
IBM DS8886 all-flash	5333-986	
IBM DS8888 all-flash	5333-988	
IBM DS8886 all-flash Expansion	5334-85E	
IBM DS8886 all-flash Expansion	5334-86E	
IBM DS8888 all-flash Expansion	5334-88E	
IBM DS8882F rack mounted model	5334-983	
IBM DS8884 all-flash	5334-984	
IBM DS8886 all-flash	5334-985	
IBM DS8886 all-flash	5334-986	
IBM DS8888 all-flash	5334-988	
XIV SW Defined Storage (PUT NUMBER OF LICENSES !!!!!!)	5725-U18	
IBM Storage Networking SAN24B-6	8960-F24	
IBM Storage Networking SAN64B-6	8960-F64	
IBM Storage Networking SAN128B-6	8960-F96	
IBM Storage Networking SAN64B-6	8960-N64	
IBM Storage Networking SAN128B-6	8960-N96	
IBM Storage Networking SAN256B-6	8961-F04	
IBM Storage Networking SAN512B-6	8961-F08	
Cisco MDS 9200 Multilayer Director	9710-E01	
Cisco MDS 9706 Multilayer Director	9710-E06	
Cisco MDS 9710 Multilayer Director	9710-E08	
Cisco MDS 9718 Multilayer Director	9710-E16	
CISCO MDS 9148S	9711-S48	
CISCO MDS 9396S Multilayer Fabric Switch	9711-S96	
CISCO MDS 9132T 32G Fabric Switch	9711-T32	
IBM FlashSystem 810	9830-AE1	31.12.2018
IBM FlashSystem 820	9830-AE2	
IBM FlashSystem 720	9830-AS2	
IBM FlashSystem 720/820	9831-AE2	31.12.2018
IBM FlashSystem 720/820	9831-AS2	31.12.2018
IBM Flashsystem 820 Storage System Model XE1	9832-XE1	31.12.2018
IBM Flashsystem 820 Storage System Model XE1	9832-XE2	31.12.2018
IBM Flashsystem 720 Storage System SLC Model XS1	9832-XS1	31.12.2018
IBM Flashsystem 720 Storage System Model XS2	9832-XS2	31.12.2018
IBM FlashSystem A9000R (Rack)	9835-415	
IBM FlashSystem A9000R (Rack)	9835-425	
IBM FlashSystem A9000 (POD)	9836-415	
IBM FlashSystem A9000 (POD)	9836-425	
IBM FlashSystem A9000R (Rack)	9837-415	
IBM FlashSystem A9000R (Rack)	9837-425	
IBM FlashSystem A9000R (Rack) - Utility Model	9837-U25	
IBM FlashSystem A9000 (POD)	9838-415	
IBM FlashSystem A9000 (POD)	9838-425	
IBM FlashSystem A9000 (POD) - Utility Model	9838-U25	
IBM FlashSystem 840	9840-AE1	31.12.2019
IBM FlashSystem 900	9840-AE2	

IBM FlashSystem 900	9840-AE3	
IBM FlashSystem 840	9843-AE1	31.12.2019
IBM FlashSystem 900	9843-AE2	
IBM FlashSystem 900	9843-AE3	
IBM FlashSystem 900 Storage utility model	9843-UF3	
IBM FlashSystem V9000 Expansion Enclosure	9846-12F	
IBM FlashSystem V9000 Expansion	9846-24F	
IBM FlashSystem V9000 High Density Expansion	9846-92F	
IBM FlashSystem 9100 High Density LFF Expansion Enclosure	9846-A9F	
IBM FlashSystem V840 Control Enclosure	9846-AC0	31.12.2019
IBM FlashSystem V840 Control Enclosure	9846-AC1	31.12.2019
IBM FlashSystem V9000	9846-AC2	
IBM FlashSystem V9000	9846-AC3	
IBM FlashSystem V840 Storage Enclosure	9846-AE1	31.12.2019
IBM FlashSystem V9000 Control Enclosure	9846-AE2	
IBM FlashSystem V9000 Control Enclosure	9846-AE3	
IBM FlashSystem 9110 SFF NVMe Control Enclosure	9846-AF7	
IBM FlashSystem 9150 SFF NVMe Control Enclosure	9846-AF8	
IBM FlashSystem 9100 SFF Expansion Enclosure	9846-AFF	
IBM FlashSystem V9000 Expansion Enclosure	9848-12F	
IBM FlashSystem V9000 Expansion Enclosure	9848-24F	
IBM FlashSystem V9000 High Density Expansion	9848-92F	
IBM FlashSystem 9100 High Density LFF Expansion Enclosure	9848-A9F	
IBM FlashSystem V840 Control Enclosure	9848-AC0	31.12.2019
IBM FlashSystem V840 Control Enclosure	9848-AC1	31.12.2019
IBM FlashSystem V9000 Control Enclosure	9848-AC2	
IBM FlashSystem V9000 Control Enclosure	9848-AC3	
IBM FlashSystem V840 Storage Enclosure	9848-AE1	31.12.2019
IBM FlashSystem V9000 Control Enclosure	9848-AE2	
IBM FlashSystem V9000 Control Enclosure	9848-AE3	
IBM FlashSystem 9110 SFF NVMe Control Enclosure	9848-AF7	
IBM FlashSystem 9150 SFF NVMe Control Enclosure	9848-AF8	
IBM FlashSystem 9100 SFF Expansion Enclosure	9848-AFF	

Software Product Name		
------------------------------	--	--

System Storage Software installed and running on the hardware devices above and listed as a supported version/release under http://www-01.ibm.com/software/support/lifecycle/
--