

For The ON-THE-GO Pet™

INSTRUCTION MANUAL VINTAGE STEEL CRATE

PG5627VC/PG5631VC/PG5636VC/PG5642VC



To see our full line of products, visit us online at: www.petgearinc.com

CUSTOMER SERVICE HELP DESK

customerservice@petgearinc.com

Toll-Free 877-752-9123 - Eastern Standard Time 8am-3pm, Monday through Friday

⚠ WARNING!

FOR PETS ONLY.

Not intended to be used as a restraining device for aggressive or dangerous animals that dig, chew or paw aggressively. Do not leave your pet unattended. **PET GEAR** is not liable for any damage caused by aggressive, destructive, immature or untrained animals. Do not use near an open or exposed flame. Failure to follow these warnings and the instructions could result in serious injury or death.

AVOIDING SUFFOCATION HAZARDS

Never use plastic shipping bags or other plastic film as pad covers not sold and intended for that purpose. They can cause suffocation. This product is not intended for commercial use.

SETTING UP THE CRATE

THIS PRODUCT REQUIRES ADULT ASSEMBLY.

Be sure the Crate is completely set up before use.

Always follow the instructions in the product instructions to set up the Crate.

Before each use, inspect this product for damaged hardware, loose joints, missing parts, or sharp edges.

Do not use the Crate if any parts are missing or broken.

Call **PET GEAR** at 1-877-752-9123 for replacement parts. Use only **PET GEAR** replacement parts.

Visit our website www.petgearinc.com to view or download the product instructions.

Do not substitute parts.

USING THE CRATE

Remove collar and leashes while using this product. The Crate is for playing or sleeping. When used for playing, never leave pet unattended and always keep pet in view. When used for sleeping, you must still provide the supervision necessary for the continued safety of your pet. Always keep the Crate away from hazards in the area that may injure your pet. DO NOT leave pet in product for prolonged periods of time.

PARTS LIST



CRATE ASSEMBLY

Step 1. Remove the folded steel crate from the carton as shown in Figure A.

Step 2. Grab any wire on the top panel and turn it like the page of a book.

Then grab the steel crate with both hands and pull upwards. This will form the top and sides (shown in Figure B.)

Figure A.




CRATE ASSEMBLY

Step 3. Reach in the crate and pull the end panel toward you, in an up and out motion, (shown in Figure C and D).



Pull Up From the Bottom, and Out



Step 4. Pull end panel up, until it fits into the clips on the ends of the side panels. See Figures E & F.

To secure the end panel to the top panel, gently pull forward on the end panel while pushing down on the top panel. Then, fit the hooks over the end wire on the top. See Figures E & F.

To disassemble, reverse this process.

Figure E.





Figure F.



CRATE ASSEMBLED

Figure G shows the crate fully assembled.

Figure G.



TO USE FRONT DOOR LATCH

To Unlock: Grab onto the latch to pull pin out of locking mechanism.

To Lock: Push pin into locking mechanism.



Figure H.

TO USE TOP DOOR

- **Step 1.** Stand beside the crate; the side that is closest to the latches works best. Lift up latches and slightly tilt them towards each other at a 45 degree angle (shown in Figure J).
- **Step 2.** Pull latches towards you until they are no longer touching the top door. Lift up on door to open.
- **Step 3.** To close door, just reverse this process.




Figure J.

REPLACEMENT PARTS

Please have your model number ready before calling. Use only **PET GEAR** replacement parts.



PO Box 99 West Rutland, VT 05777 877-752-9123 www.petgearinc.com