

Rowe Product Line Parts List

ITEM NUMBER	ITEM DESCRIPTION
B0012912	TAPE-FOAMED
B0030688	SPACER
B0030702	BLOCK-FOAM
B0030703	BILL-BOX (500BC)
B0030715	POWER SUPPLY & HARNESS ASSY
B0030721	INLET-CBA-2
B0030738	HARN ASSY-CBA-2 CREDIT (8 WAY)
B0030739	HARNESS ASSY-CBA-2 (4 WAY)
B0030740	CABLE ASSY, CBA2 ROWE LNK 2 WY
B0030755	BRACKET ASSY-LOGIC BOARD
B0030762	NUT-TWIN
B0030766	INLET-UNIVERSAL TYPE, CBA
B0030780	PLATE ASSY-SIDE (LH)
B0030781	PLATE ASSY-SIDE (RH)
B0030786	LABEL-BILL INSERTION
B0030789	HARNESS ASSY-CBA-2 (POWER)
B0030807	POWER SUPPLY-OEM CBA-2
B0030864	ROLLER-FLAT
B0030867	PCB ASSY, CBA2 LOGIC BD & BRKT
B0031924	PIN-DRUM PULLEY
B0031927	SPRING-INPUT SHAFT
B0031928	PLATE-PRESSURE
B0031929	PIN-CROWNED ROLLER
B0031930	SHAFT-FLAT ROLLER
B0031932	PLATE-SPACER
B0031933	GEAR-DRIVE
B0031936	GEAR-REDUCTION
B0031937	PIN-FLAT ROLLER
B0031938	CAM-STACKER, CBA/RBA
B0031941	SHAFT-ANTI CHEAT LEVER
B0031942	SHAFT-BILL BOX SPACER
B0031944	RING-RETAINING
B0031945	PIN-HOLDER
B0031946	BELT-TIMING
B0031947	HOLDER-PRESSURE ROLLER
B0031949	PLATE-SIDE (RH BARE)
B0031951	PLATE ASSY-SIDE (LH) CBA-2
B0031952	PLATE ASSY-SIDE (RH) CBA-2
B0031953	INLET-CBA-2
B0031954	TRACK-UPPER (CBA-2)
B0031955	TRACK-LOWER

B0031956	BELT-DRIVE, RBA/CBA
B0031959	BRACKET-STACKER MOTOR
B0031962	SEPARATOR, CBA/RBA
B0031963	GUIDE-STACKER, CBA/RBA
B0031964	BILL-BOX (200BC)
B0031968	BRACKET-TOP
B0031970	MAGNETIC HEAD, CBA/UBA
B0031972	TRANSFORMER & HARNESS ASSY
B0031974	PLATE & PIN ASSY-TRANSPORT
B0031975	BRACKET & CATCH ASSY-TOP
B0031987	HARN & CELL ASSY-LOWER
B0031988	LABEL-BILL INSERTION
T0076601	TE766 ADPT HRNS TE680-BC12,35
T0120101	BILL CHANGER TEST FIXTURE
00706801	VINYL-ROWESWOOD (20" WIDE)
00707307	TUBING-HEATSHRINK
00708401	TUBING, BRAIDED 1/4"ID BLACK
00708402	TUBING, BRAIDED 1/2"ID BLACK
00710201	SPONGE RUBBER-CLOSED CELL
00711003	SILVATRIM SECT#540
20029501	SOCKET-STARTER
200A0420440181	RES, 180 OHM 5W 5% WW
20223201	LIGHT-PILOT (#47)
20384301	ROLLER-BELT, MECH
203A7H60004707	CAP, 470UF 100V 20% RAD AL EL
20554502	CLIP-CABLE
20612803	SPRING
20612804	SPRING-CD MECH
20627202	SUPPORT-SPRING (UPPER)
20669501	SUPPORT-LOCK
20693602	LOCKBOLT
206A110050001	INDUCTOR, 1MH 4A CHOKE IRON CR
206A322070001	INDUCTOR, 220MH 5.5A CHOKE MPP
20746501	BALL BEARING (1/4")
20770301	BRACKET-CATCH
20789501	NUT-WELD (#6-32)
20789801	MTG PLATE & NUT ASSY
20819908	CABLE-REMOTE VOLUME CONTROL
20879501	BRACKET-RETAINER
20922502	SPACER
20922503	SPACER
20922505	SPACER
20922508	SPACER
20922510	SPACER
20925601	BRACKET-MOUNTING(JUNCTION BOX)
20927302	STUD-RETAINER
20930007	RIVET-ACCORDION
21048701	NUT-THIN (3/8-32 NEF)
21070802	BEARING ASSY
21072401	MAGNET
21072621	SWITCH-REED

21073101	SWITCH
21073102	SWITCH
21073201	SWITCH (NC)
21073401	SWITCH-MICRO LIGHT FORCE
21073402	SWITCH-MICRO GOLD CONTACT
21079202	PIN-TRUNNION
21080804	SHOE ASSEMBLY-INNER
21081101	SPRING-COMPRESSION
21082901	ACTUATOR-SWITCH
21083001	NUT-TWIN
21083601	SPRING-TENSION
21084902	STOP-PLUNGER
21085701	PLUNGER ASSEMBLY
21087801	BELT-TIMING (55 TOOTH)
21089401	BRACKET ASSY-ROLLER
21095501	SPRING-TENSION
21101301	LOCKNUT (3/8-16)
21110001	WASHER-THRUST
21116001	PIN-LINKAGE
21116002	PIN-LINKAGE
21121216	PLUG & CORD
21121221	PLUG & CORD (28",18GA)
21121222	PLUG & CONN-8 1/2"90 DEG,GMSTR
21121223	PLUG & CORD - 15 FT 90 DEG
21121224	PLUG & CONNECTOR
21150509	SOLENOID ASSY
21150510	SOLENOID ASSY
21153701	SUPPORT-SPRING (LOWER)
21186605	DOOR ASSY-CASH BOX
21244414	HOUSING-SOCKET (9 CKT)
21256201	SPRING-TENSION
21265203	PLATE ASSY-TIE DOWN
21270801	GEAR
21275101	RELAY
21278001	PIN-HINGE
21278901	SPRING-TENSION
21279502	KNOB & GEAR ASSY
21279602	BAR MOUNT ASSY
21280701	SPRING-TENSION
21284901	WASHER-BOW
21286622	SWITCH GANG ASSY (MOLDED)
21286901	SPRING-RELAY
21287201	LOCKBOLT
21287401	LEVER-COIN SWITCH
21301801	WASHER-CUP
21312202	PULLEY-TIMING (10 TOOTH)
21312303	PULLEY-TIMING (15 TOOTH)
21312304	PULLEY-TIMING (15 TOOTH)
21312401	ROLLER-IDLER (TIMING BELT)
21312501	ROLLER-IDLER (DRIVE)
21312502	ROLLER-IDLER

21312801	BELT-TIMING (64 TOOTH)
21313001	TERMINAL BOARD-CELL
21313002	PWB FAB, TERMINAL BD. CELL
21313301	CAPACITOR-MOTOR (107/130 MFD)
21314401	BRACKET & PIN ASSY-IDLER
21315602	ROLLER-IDLER (OUTPUT)
21315801	SPRING-TORSION
21316101	SPRING-COMPRESSION
21318901	INSULATOR-MICA
21318902	INSULATOR-PRECOATED
21325101	SPRING-TENSION
21328401	PLUNGER-SOLENOID
21328601	ARM ASSEMBLY-ROLLER
21328604	ARM ASSEMBLY-ROLLER
21328704	ROLLER ASSY-HEAD
21329001	SPRING-TENSION
21330201	HUB-ROLLER (HEAD)
21330801	RETAINER-PIVOT
21339701	PHOTOVOLTIAC CELL-SILICON
21339801	LIGHT SENSOR ASSY (INFRARED)
21339807	CKT BD ASSY-LIGHT SENSOR
21342701	SPRING-RETAINING (ROLLER)
21342702	SPRING-RETAINING (ROLLER)
21342703	SPRING-RETAINING (ROLLER)
21357802	NUT-ELASTIC STOP (#6-32)
21357804	NUT-ELASTIC STOP (1/4-20)
21357811	NUT-ELASTIC STOP (#8-32)
21357815	NUT-ELASTIC STOP (1/2-13 UNC)
21375901	OUTLET-CONVENIENCE (3 WIRE)
21375902	OUTLET-CONVENIENCE
21377502	BAR-LOCKING
21377801	BUMPER, MOLDED POLYURETHANE
21384603	SOLENOID ASSY-PRESSURE
21384701	RETAINER-WINDOW
21396801	REFLECTOR
21398501	SPRING-TENSION
21402401	SPRING-HANDLE RETURN
21408602	RECEPTACLE-STRAIGHT (.250)
21411401	SPACER
21419701	LOCKBAR
21420020	MTG BRKT.-RELAY
21425601	LOCKBOLT
21429503	CATCH ASSY-REJECTOR
21441801	COUNTER-ELECTRIC
21441802	COUNTER-ELECTRIC
21488101	HANDLE
21491301	GUIDE-DOOR
21492203	HINGE-SUPPORT(COIN ACC. BRKT)
21494201	SWITCH (4PTT)
21513502	INDUCTOR, 200UH 3A 10% 22AWG
21513506	INDUCTOR

21513507	INDUCTOR, 4.5MH IRON CORE
21513509	INDUCTOR
21513510	INDUCTOR
21520702	POT, 50K 1/2W 20% TOP HOZ ADJ
21520706	POT, 5K 1/2W 20% TOP HOZ ADJ
21520707	POT, 2M 1/2W 20% TOP HOZ ADJ
21520708	POT, 10K 1/2W 20% TOP HOZ ADJ
21520802	INSULATOR, MICA TO-220
21531702	OVERLAY-TRIM (LH)
21531802	OVERLAY-TRIM (RH)
21531902	OVERLAY-PAGE HOLDER
21532801	SPEEDNUT-PUSH ON
21533102	SPEAKER ASSY
21533801	GASKET-SPEAKER
21534203	SPACER, SHOULDER #8-32 3/8"OD
21534705	PIN-PIVOT
21534706	PIN-PIVOT, STACKER
21534707	PIN-PIVOT
21534709	PIN-PIVOT
21534901	SOCKET-LIGHT
21535801	NUT, PLASTIC SELF RETAINING
21537001	COVER-INSULATING (TO-3)
21540902	CON, JACK PHONO RCPTL
21540918	JACK-RCA (VERT FORM) RED
21540919	JACK-RCA (VERT FORM) WHITE
21540920	JACK-RCA (VERT FORM) YELLOW
21540921	JACK-STEREO W/SWITCH
21541206	INSTAL INSTR-PHONO ACCESS KIT
21541208	INSTRUCTIONS-PAGING KIT
21541405	HEATSINK, VERTICAL MNT TO-220
21541409	HEATSINK, TO-220
21541417	HEAT SINK, CD100K LED CONT.
21546801	KNOB-VOLUME CONTROL
21547006	CON, PHONO JACK PCB MT .676"HT
21547301	SOCKET-POWER TRANSISTOR (TO-3)
21548501	LABEL-FCC
21548502	LABEL-FCC
21567401	RETAINER-SPRING
21572601	CABLE-FALL STOP
21572604	CABLE-FALL STOP
21572605	CABLE-FALL STOP
21581801	SWITCH-PUSHBUTTON (MOMENTARY)
215A00RDE305A	THERMISTOR, 3A PTC
21620704	PLUG ASSY-AMP JUMPER(SHORTING)
21620706	JUMPER PLUG ASSY-AMP
21620707	JUMPER PLUG ASSY-AMP
21620711	JUMPER PLUG ASSY-AMP
21620712	JUMPER PLUG ASSY-AMP
21621001	JUMPER-PHONO PLUG
21621101	SHAFT, POTENTIOMETER SLOT/HEX
21621835	JUMPER ASSY

21621836	JUMPER ASSY
21621837	JUMPER ASSY
21624401	RELAY, DPDT 5A 30DC 120AC PCB
21626702	COVER-SECURITY
21627602	BAG-CONDUCTIVE 8"X 12"
21627604	BAG-CONDUCTIVE 12"X 16"
21630701	NUT-TWIN
21630901	SWITCH-MINIATURE
21630904	SWITCH-MINIATURE
21633601	MIC CABLE & PLUG ASSY-50 FT
21633603	MIC CABLE & PLUG ASSY
21633702	MIC CABLE & PLUG EXT (50 FT)
21637902	SWITCH, PB SPDT MOM 90DEG PCB
21638002	CAP-SWITCH
21639701	KIT-BGM VOL CONT/CD-100
21639702	KIT-BGM RELAY
21639703	KIT-BGM RELAY (NOSTALGIA)
21639704	KIT-BGM RELAY (WP100)
21639705	KIT-BGM VOL CONT (CD100K)
21639706	KIT-BGM RELAY (CD100K)
21639801	INSTRUCTIONS-BGM VOL CONTROL
21640501	SWITCH-PUSHBUTTON (MOMENTARY)
21640901	CON, HDR RIBBON CABLE 1.5MMCTR
21712701	LATCH ASSY-LH
21712801	LATCH ASSY-RH
21724102	TERMINAL STRIP (2 TERM)
21724902	LINK-LOCK BAR
21724905	LINK-LOCK BAR
21724906	LINK-LOCK BAR
21730001	HOOK-FALL STOP
21742908	BUTTON & SHAFT ASSY-REJECT
21742909	BUTTON & SHAFT ASSY-REJECT
21742911	BUTTON & SHAFT ASSY-REJECT
21742912	BUTTON & SHAFT ASSY
21742914	BUTTON & SHAFT ASSY
21742915	BUTTON & SHAFT ASSY
21742916	BUTTON & SHAFT ASSY
21751804	CATCH-TITLE PANEL
21754401	GASKET-COIN CHUTE
21757701	GUIDE
21757901	BLOCK-FOAM
21757903	BLOCK-FOAM
21759301	COVER-CORD HOLE
21765601	SPRING-COMPRESSION
21765901	SPACER-PUSHBUTTON
21766701	DISPLAY, LED COMMON ANODE
21766702	DISPLAY, LED 8-SEG .3" X .188"
21766705	DISPLAY, LED 7-SEG .738"X.386"
21766708	DISPLAY, LED 7-SEGMENT
21771004	PAD-INSULATION
21771010	INSULATON, PAD 8-1/2"X 8-13/16

21771016	PAD-INSULATION
21771107	INSULATION, BASE 8-1/16"WD X
21771110	INSULATION, BASE 9-3/4X11-3/4"
21771113	INSULATION-BASE
21772802	INSULATOR-CAPACITOR
21773303	SWITCH, PB SPST N/O PCB MT
21773306	SWITCH-PUSHBUTTON
21773308	SWITCH, PCB PB MOM. TACT
21773313	SWITCH-PB SPDT MOM
21776005	FASTENER-SPEED CLIP (U TYPE)
21776009	FASTENER-SPEED CLIP (U TYPE)
21776011	FASTENER-SPEED CLIP (U TYPE)
21776101	WASHER, RECTANGULAR 13/32X7/32
21780611	PAD-ACOUSTICAL
21780617	PAD-ACOUSTICAL, CD100K/IDL
21780701	BRACKET-RETAINER
21781905	FILTER, LIGHT (DISPLAY CARD)
21790104	HINGE-SUPPORT
21790201	HINGE-REJECTOR
21791603	BUTTON-COIN RETURN
21792403	LINK-CARRIAGE
21792901	DOOR-SLUG CUP
21793001	BRACKET-SLUG CUP
21795302	BEZEL-LOCK
21795305	BEZEL-LOCK
21795307	BEZEL-LOCK
21795902	CRANK ASSY
21797503	SCREW-TIE DOWN (5/16-18X2-1/4)
21798001	COVER
21799105	PAD-BOTTOM
21800501	JUMPER
21810110	INSERT-THREADED (#4-40)
21810201	LINK ASSY-TRANSFER
21810401	CRANK-TRUNNION
21811501	FOLLOWER-CAM
21811701	SCREW-LOCK (#6-32 X 5/16)
21812502	SUPPORT-MECHANISM
21812601	COLLAR
21813202	SHAFT-CAM DRIVE
21813302	COLLAR-TONE ARM CAM
21813802	BELT, MECH
21813804	BELT-MAGAZINE (BLUE)
21813805	BELT MAGAZINE (GREEN)
21813901	GROMMET
21814009	NUT-HEX LOCK (#4-40)
21816001	LEVER ASSY-SPRAG
21816103	BUSHING-STEM (SPRAG HUB)
21816301	PLUG-HOLE
21817802	PULLEY-50 HZ
21818401	KNOB-ADJUSTING
21818601	BRACKET ASSY-ADJUSTING

21820628	CHANNEL
21820631	CHANNEL, WP100
21822501	RECTIFIER-BRIDGE
21822503	DIODE, BRIDGE RECT FULL WAVE
21822504	DIODE, BRIDGE RECT 100V 10A
21822506	DIODE-BRIDGE RECT 200V 6A
21822507	DIODE, BRIDGE RECT FW 10A
21822510	RECTIFIER-BRIDGE
21822511	BRIDGE RECTIFIER
21822611	MANUAL-SERVICE (CD-100)
21822612	MANUAL-SERVICE (R-93)
21822613	MANUAL-SERVICE (R-94)
21822614	MANUAL-SERVICE (CD-51)
21822615	MANUAL-SERVICE (CD-100A VOL 2)
21822616	MANUAL-SERVICE (CD-100A VOL 1)
21822617	MANUAL-SERVICE (CD-100B VOL 1)
21822618	MANUAL-SERVICE (CD-100B VOL 2)
21822620	MANUAL-SERVICE (CD-100C VOL 1)
21822621	MANUAL-SERVICE (CD-100C VOL 2)
21822622	MANUAL-SERVICE (CD-51A)
21822623	MANUAL-SERVICE (CD-100D VOL 1)
21822624	MANUAL-SERVICE (CD-100D VOL 2)
21822625	MANUAL-SERVICE (CD-RN VOL 1)
21822626	MANUAL-SERVICE (CD-RN VOL 2)
21822627	MANUAL-SERVICE (MMCD-1)
21822628	MANUAL-SERVICE(CD-100E VOL.1)
21822629	MANUAL-SERVICE(CD-100E VOL.2)
21822630	MANUAL-SERVICE (WALLPHONO VOL1
21822631	MANUAL-SERVICE (WALLPHONO VOL2
21822632	MANUAL-CD100E VOL 1 (SPANISH)
21822633	MANUAL-CD-100E VOL.2 (SPANISH)
21822636	MANUAL-SERVICE (CD-100F VOL 1)
21822637	MANUAL-SERVICE CD100F VOL 2
21822638	MANUAL-SERVICE (MMCD-2) VOL 1
21822639	MANUAL-SERVICE (MMCD-2) VOL 2
21822641	MANUAL-SERVICE CD100G VOL 1
21822642	MANUAL-SERVICE CD100G VOL 2
21822643	MANUAL-SERVICE MMCD3 VOL 1
21822644	MANUAL-SERVICE MMCD3 VOL 2
21822645	MANUAL-WP100 VOLUME 1
21822646	MANUAL-WP100 VOLUME 2
21822647	MANUAL-CD100H VOL 1
21822648	MANUAL-CD100H VOL 2
21822649	MANUAL SERVICE ENCORE VOL 1
21822650	MANUAL SERVICE ENCORE VOL 2
21822651	MANUAL CD100I VOL I
21822652	MANUAL CD100I VOL II
21822653	MANUAL CD100I VOL I SPANISH
21822655	MANUAL CD100J VOL I
21822656	MANUAL CD100J VOL II
21822657	MANUAL CD100J VOL I SPANISH

21822658	MANUAL DL-11 VOL I OF I
21822660	MANUAL - IDL VOL 1
21822661	MANUAL - IDL VOL 2
21822662	MANUAL - DLW-1 VOL 1
21822664	MANUAL-GEMSTAR
21822666	MANUAL-SERVICE CD100K VOL 1
21822667	MANUAL-SERVICE CD100K VOL 2
21822668	MANUAL-DLW-2 VOL I
21822669	MANUAL-SERVICE CD100K SPANISH
21822670	MANUAL-IDL-1A VOL 1
21822901	SPRING-COMPRESSION
21823102	CAPACITOR-ELECT (10000 MFD)
21825702	BAG-SHIPPING,CD100/ENCORE
21825704	BAG-SHIPPING,NOSTALGIA
21826719	HOLDER-LAMP (FLUORESCENT)
21827201	BAG-ZIP LOCK, 5 1/16 X 8 1/16
21828201	SPACER-ROLLER
21828202	ROLLER-SPACER
21834801	CHANNEL
21835701	RELAY-24V (SPDT)
21835902	INSTRUCTIONS-INSTALLATION
21840201	SPRING-COMPRESSION
21845003	NAMEPLATE-ROWE (ADHESIVE)
21845401	STRAP-HINGE
21845605	WINDOW
21845607	WINDOW
21845609	WINDOW-TOP DOOR
21845610	WINDOW-DIGITAL DISPLAY
21845611	WINDOW-SELECTOR
21845612	WINDOW-PRICE CARD
21845613	WINDOW
21845614	WINDOW
21845615	WINDOW
21845616	WINDOW
21845617	WINDOW
21845618	WINDOW
21845620	WINDOW
21845621	WINDOW
21845622	WINDOW-DIGITAL DISPLAY
21845623	WINDOW-PRICE CARD
21845624	WINDOW-TITLE RACK
21845626	WINDOW-PRICE CARD
21845628	WINDOW
21845629	WINDOW
21845630	WINDOW-COIN BLOCK
21845631	WINDOW-B.A. BLOCK
21845632	WINDOW
21845633	WINDOW-BLOCKOUT
21845634	WINDOW-PRICE CARD
21845635	WINDOW-DOOR MMCD-3 (VERTICAL)
21845637	WINDOW-WP100

21845638	WINDOW-CD100I/J/NETSTAR
21848101	CHUTE ASSY-SLUG
21848601	HOOK-DOOR SUPPORT
21862201	LAMP & SOCKET ASSY
21862202	LAMP & SOCKET ASSY
21863803	SECURITY BAR & WELD STUD ASSY
21865301	LINK-PIVOT
21865303	LINK-PIVOT
21865306	LINK-PIVOT
21865307	LINK-PIVOT
21865308	LINKPIVOT
21865309	LINK-PIVOT
21865310	LINK-PIVOT
21865311	LINK-PIVOT
21865313	LINK-PIVOT
21868001	PLATE-CONTROL
21868601	KNOB-VOLUME CONTROL
21868602	KNOB
21869801	HOUSING ASSY-SWITCH
21870001	FASTENER-SNAP-IN
21874601	SUPPORT-BILL STACKER
21874603	SUPPORT-BILL STACKER
21875001	SPACER-REAR (OBA)
21876202	CABLE-COAXIAL
21883201	DECAL-\$1 & \$5
21883502	STRIKE
21883503	STRIKE
21883504	STRIKE
21883505	STRIKE
21883506	STRIKE
21883601	PLATE-ACTUATOR
21885301	JUMPER ASSY-HARNESS
21888001	CATCH-HOOK
21888613	GUIDE-PROGRAM REFERENCE V4.1
21890401	BAR ASSY-LOCK (LH)
21890501	BAR ASSY-LOCK (RH)
21890602	PIVOT-LOCK LINK
21890701	CATCH
21891301	GUIDE
21892201	SHAFT-COIN RETURN
21892601	LABEL-BILL INSERTION
21892604	LABEL-BILL INSERTION
21892605	LABEL-BILL INSERTION
21892606	LABEL-BILL INLET
21892609	LABEL-BILL INSERTION
21892610	LABEL-BILL INSERTION
21893301	INLET ASSY-BILL
21893401	LED ASSY-SPKR OVLD INDICATOR
21893402	LED ASSY-SPKR OVLD INDICATOR
21894203	SWITCH & PLATE ASSY
21896901	MANUAL-CD SUPPLEMENT

21896902	MANUAL-SERVICE (R-92 CD)
21897201	CARTRIDGE-6 CD MAGAZINE
21897301	BELT-O RING
21897401	PULLEY
21920101	BRACKET-UPSTOP
21920302	PLATE ASSY-PIVOT
21920801	CATCH ASSY (LH)
21920802	CATCH ASSY-LH
21920901	CATCH ASSY (RH)
21920902	CATCH ASSY (RH)
21921001	RETAINER-LICENSE
21921101	GUIDE
21921401	SHAFT-PIVOT
21921501	SPACER-SHOULDERED
21921901	RETAINER-TITLE RACK
21922001	STICKER-CD
21922201	RING-COMPRESSION
21922301	BRACKET-SUPPORT (HOUSING)
21922501	KIT-PUSHBUTTON
21940001	SPRING-HOLD DOWN
21940101	GROMMET-SHOCK MOUNT
21940102	GROMMET-SHOCK MOUNT(CD PLAYER)
21940201	SPACER-GROMMET
21940802	STRAP-HINGE
21941301	CATCH
21941401	RIVET-REST
21941402	RIVET-REST
21941701	LOCKBAR ASSY (LH)
21941801	LOCKBAR ASSY (RH)
21942101	BRACKET-CAM
21942102	BRACKET-CAM
21942201	SWITCH-MICRO
21942301	BUTTON & SHAFT ASSY-REJECT
21942401	BRACKET-HOLDER (PRICE CARD)
21942501	GEAR-SPUR (MOTOR)
21943501	BRKT-RETAINER (BLOCKOUT C.1.)
21943801	MOV ASSY (120VAC CKTS)
21944001	KIT-SPRING (FIELD INSTALLED)
21944101	SPRING-ISOLATION
21944401	SPACER-SPEAKER
21944801	MANUAL-SERVICE (HCD-1)
21945601	KIT-CD-100 PRINTER INTERFACE
21946301	PLATE-LOCK BAR
21946401	PLATE-LEAD IN
21946601	COUPLER-LOCK BAR
21946901	RECEPTACLE-LATCH
21947001	STUD-WING HEAD
21947101	RETAINER-STUD (WING HEAD)
21947401	LOCKBAR ASSY
21947403	LOCK BAR ASSY
21947501	WASHER-INDEXING

21947701	MANUAL-SERVICE (WCD)
21947702	MANUAL-SERVICE (WCD DOMESTIC)
21948301	KIT-CASH BOX (1000 BILL)
21948501	PLATE-CATCH ADJUST
21948601	SPACER
21948602	SPACER
21948603	SPACER
21948801	LABEL-WARNING
21949101	HARNESS-WCD/CD100 ROWELINK
21949202	CBA-2 PARTS GROUP (WALLPHONO)
21949203	CBA-2 PARTS GROUP (CD100F)
21949301	BLOCKOUT ASSY-SLUG CUP
21949701	KIT-BUTTON (POP,RESET & ARROW)
21950001	KIT-WALL MOUNT BRACKET
21950002	KIT-WALL MOUNT BRACKET
21951301	INSTRUCTIONS-CD SET UP
21951501	RETAINER-ANIMATION
21951701	SPRING-COUPLING
21952101	BALLAST 120V 60HZ
21952102	BALLAST - 50HZ
21953401	KIT-ANTISKATE (SERVICE)
21954601	PIN-GUIDE
21955101	KIT-SERVICE (GUIDE PIN)
21955501	BLOCK-FOAM
21955903	RESISTOR ASSY
21955907	RESISTOR ASSY
21956101	KIT-MAGAZINE (FIELD INSTALLED)
21957002	GUIDE-ROUTINE SERVICE REF
21957502	KIT-LASERSTAR IR REMOTE CONTR
21958005	DECAL-REMOTE CONTROL
21958006	DECAL-REMOTE CONTROL
21958303	TRANSMITTER-INFRARED (MODIFIED)
21958304	TRANSMITTER-INFRARED (MODIFIED)
21958305	TRANSMITTER-IR (DL 2-CH)
21958306	TRANSMITTER-IR (DL 4-CH)
21958307	TRANSMITTER-IR (CD100K)
21958402	INSTRUCTIONS-INSTALLATION (IR)
21958501	HARN-IR INTERFACE TO AMP/VOL
21958601	HARNESS-IR RCVR TO INTERFACE
21958901	SCREW EYE
21959401	PULLEY-DRIVE
21959501	HARNESS-CDM-4 DECODER BOARD
21959901	SCREW-CDM-4 PLAYER
21960102	HOLD DOWN ASSY-HUB (GOLD)
21960201	WASHER-TRACTION
21960202	WASHER-TRACTION 1/32 T CORK
21961101	WINDOW-FRONT
21961102	WINDOW-FRONT
21961201	BRACKET-LOCKDOWN
21961202	BRACKET-LOCKDOWN (CD PLAYER)
21961401	MANUAL-SERVICE (CD-WS20)

21961601	INSTRUCTIONS-CD RETAINER
21962201	BRACKET ASSY-ADJUSTING
21962301	PLATE ASSY-MOUNTING
21962401	SHAFT ASSY-DRIVE
21963001	MANUAL-SERVICE (CD WALLETTTE)
21963101	SHEET-PRICING
21963401	LOCKBOLT
21963601	RETAINER ASSY-STRIKE
21963826	JUMPER ASSY-GEMSTAR
21963827	JUMPER ASSY-GEMSTAR
21963901	KIT-I.R. REMOTE GND ADAPTOR
21964301	KIT-MECH CONTROL 05-62 FIX
21965501	VELCRO-HOOK
21965502	VELCRO-LOOP
21965601	BRACKET-RETAINER (BLOCKOUT)
21965701	STRIKE
21965901	LOCKBAR ASSY-LH
21966001	LOCKBAR ASSY-RH
21966101	POST-LIGHT (CLEAR)
21966102	POST-LIGHT (ORANGE)
21966103	POST-LIGHT (YELLOW)
21966104	POST-LIGHT (RED)
21966105	POST-LIGHT (GREEN)
21966201	PIVOT ASSY-GAS SPRING
21966301	BRACKET-PRICE CARD
21966501	RETAINER-ANIM WINDOW (UPPER)
21966601	KIT-LENS CLEANER
21967104	BILL ACCEPTOR PARTS GROUP
21967701	LEVER-STOP
21967801	TUBING-INSULATING
21968301	RETAINER-BLOCKOUT (B.A.)
21968501	BRACKET-CONNECTOR (B.A.)
21968601	DECAL-LASERSTAR
21968701	KIT-WALLETTTE DATA CONCENTRATOR
21968801	ACTUATOR-SERVICE SWITCH
21969101	BRACKET-ALIGNMENT
21969501	GUIDE-ERRORS (CD SERIES)
21970401	DEFLECTOR-COIN
21970701	INSTRUCTIONS-DUAL PHONO KIT
21971101	CABLE-CDX-A55 PLAYER INTERCONN
21971501	STRAP-RETAINER (BLOCKOUT)
21971601	RETAINER-BLOCKOUT (B.A.)
21972101	PLATE-BASE (REVOLVING)
21972201	WHEEL-DRIVE
21972801	O-RING (DRIVE WHEEL)
21973101	KNOB
21973201	SHAFT
21973301	WASHER-SQUARE HOLE
21973401	WASHER & HUB ASSY
21973701	LABEL-BILL INLET
21973801	RETAINER-WINDOW

21974101	STRAP-RETAINER (HEATER)
21974301	PLATE-SLIDE (B.A.)
21974401	BRACKET-REINFORCEMENT (CBA)
21974403	BRACKET-CBA REINFORCEMENT
21974603	KIT-BILL ACCEPTOR BLOCKOUT
21975201	SEPARATOR-COIN
21975501	PLATE-NUT
21976101	MANUAL-OPERATING (CD-RNH)
21976201	MANUAL-SERVICE (CD-RNH)
21976401	INSTRUCTIONS-CONVERSION
21976701	GUIDE-OPER REF (CD-51H/CDRNH)
21977201	ACTUATOR ASSY-SLUG
21977301	WHEEL & BRACKET ASSY
21977401	PULLEY-TIMING BELT
21977501	BELT-TIMING
21978801	STRAP-RETAINER (HEATER)
21978901	SPACER-SWITCH & TITLERACK
21979401	PIVOT ASSY-GAS SPRING (LH)
21979501	PIVOT ASSY-GAS SPRING (RH)
21980602	FERRITE-EMI SUPPRESSOR
21990203	COIN SWITCH & BRKT ASSY
21990204	COIN SWITCH & BRKT ASSY(EAGLE)
21990501	KIT-BLOCKOUT (BILL OR COIN)
21990901	CAP ASSY-END (LH BOTTOM)
21991201	SPACER-EXTRUSION CHANNEL
21991301	RETAINER-PRICE CARD HOLDER
21991401	KIT-SINGALONG (CDG)
21991402	KIT-SINGALONG W/CD PACK (CDG)
21991403	KIT-SINGALONG (CDV)
21991501	FLANGE-MICROPHONE MOUNT
21991502	FLANGE-MICROPHONE MOUNT
21991901	SPACER-CHUTE GUIDE
21992001	LEVER-WIRE FORM SWITCH
21992401	BRACKET-DETENT (BA)
21992501	SPRING-COMPRESSION
21992601	LINK-PIVOT (LOCK)
21992801	CLIP-LENS RETAINER
21992901	HARNESS-SHORTING PLUG
21994001	BRACKET-RETAINER (TITLE RACK)
21994101	RETAINER-ROD (TITLE RACK)
21994201	CLIP-ROD
21994407	KIT-SLUG REJ.(MARS 330 3 1/2
21994409	KIT-SLUG REJ.(MICROCOIN S5)
21994602	VOLUME CONTROL-TERMINATED, 6"
21994603	VOLUME CONTROL-TERMINATED, 4"
21994701	KIT-IR TRANSMITTER REPLACEMENT
21995002	BUTTON ASSY-MMCD-2
21995901	INSTRUCTIONS-KARAOKE
21996101	BEARING-HINGE (CD PLAYER)
21996303	CABLE-RIBBON
21997601	BRACKET-RETAINER (BLOCKOUT)

21998101	ACTUATOR-SERVICE SWITCH
21998202	COUPLER-LATCH
21998204	COUPLER-LATCH
21999501	INSTALL-INSTRUCT-CONVERT
21999502	INST INSTR-CDM4 TO CDM12
22000411	LOCK HANDLE W/HARDWARE
22000701	SUPPLEMENT-CDM12 MECHANISM
220A00401N5822	DIODE, SCHOTTKY 40V 3A 1N5822
220A01500GP15J	DIODE, 600V 1.5A DO-15
220A02800006A1	DIODE, RECT 50V 6A AX-8MM 6A1
22100101	BRKT-MTG (COIN SWITCH)
22100701	SPACER-SLIDE (TITLE RACK)
22100801	LEVER-TITLE PAGE
22100901	KNOB/HANDLE
22101001	CAM/SHAFT DRIVE
22101101	SPACER-BOTTOM SIDE
22101501	GEAR-REDUCTION/DRIVE
22101601	RACK-GEAR
22102201	RETAINER-BLOCKOUT
22103101	BRACKET-PRICE CARD
22103301	RETAINER-WINDOW (KEYBOARD)
22103401	RETAINER-WINDOW (DISPLAY)
22103501	RETAINER-WINDOW (KEYBOARD)
22103801	WINDOW AMI
22104002	LEVER-COIN SWITCH (.029)
22104101	RETAINER-GLASS (SIDE)
22104901	GUIDE
22105501	RETAINER-BLOCKOUT (LOWER)
22105701	KIT-SECURITY (EAGLE)
22106301	KIT-COIN COMPARITOR CC-40
22106801	PAINT (100F) ALMD BEIGE PEARL
22106802	PAINT (100F) DESERT TAUPE MET
22106803	PAINT (100F) CAYMAN GREEN MET
22106804	PAINT (100F) MEDIUM BRIGHT RED
22106805	PAINT (100F) BRIGHT SILVER
22106806	PAINT (100F) BLUE GREY MET
22106807	PAINT(100G) DARK ARGENT METALI
22106808	PAINT(100G)PUMICE PEARL METALI
22106809	PAINT (100I) ULTRA BLUE PEARL
22106810	PAINT (ENCORE) CARIBBEAN GREEN
22106811	PAINT (100I ENC) CARDINAL RED
22106812	PAINT (ENCORE) VOGUE SILVER
22106813	PAINT-SANDRIFT (CD100K ALL)
22106814	PAINT-GARNET (CD100K)
22106815	PAINT-TEAL (CD100K)
22109101	KIT-CBA
22109701	PLATE-PIVOT
22109901	BRACKET-HINGE (LOWER DOOR)
22110101	LINK-PIVOT (LOCK)
22110201	LOCKBOLT
22110202	LOCKBOLT-"KESET"

22110301	END CAP PLATE ASSY
22110401	BRACKET-ANIM MTG CD100G
22110601	STRIKE
22110801	STUD-REJECT LEVER
22111101	SHAFT WELD ASSY-PIVOT
22111201	BRACKET-B/A GUIDE
22111601	PLATE-END CAP (BOTTOM LEFT)
22111701	PLATE-END CAP (BOTTOM RIGHT)
22111807	KIT-MARS B.A., CD100H
22111808	B.A. PTS GRP MARS (ENCORE)
22111809	KIT-MARS B.A., WP100
22111812	KIT-MARS B.A., CD100I BLUE
22111815	KIT-MARS BRACKET CD100I
22111817	KIT-MARS BRACKET, ENCORE-RED
22111822	KIT-MARS B.A., WP100 GREEN
22111823	KIT-MARS B.A., WP100 GOLD
22111824	B.A. PTS GRP US MARS (BLUE)
22111825	B.A. PTS GRP US MARS (RED)
22111828	B.A. PTS GRP MARS (BLUE) WP100
22111829	B.A. PTS GRP MARS (GREEN)WP100
22111837	B.A. PTS GRP MARS (BLUE) DL-11
22111841	BA PTS GRP MARS(RED)(WP100SYM)
22111842	BA PTS GRP CD-100J CASHCODE BA
22112101	PIVOT ASSY-GAS SPRING
22112201	PLATE-RETAINER
22112401	SOCKET-FLUOR. LAMP
22112402	SOCKET-FLUOR. LAMP & STARTER
22112701	RETAINER-WINDOW (KEYBOARD)
22112801	PLATE, SPEAKER (TOP DOOR)
22113001	PIVOT ASSY-GAS SPRING (RH)
22113101	RETAINER-WINDOW (PRICE CARD)
22113201	RETAINER-WINDOW (PRICE CARD)
22113301	RETAINER-WINDOW (BLOCKOUT)
22113401	NAMEPLATE "ROWE AMI" CD100G/H
22113501	CARD-BLOCKOUT
22113602	DECAL-COIN INLET
22113603	DECAL-COIN INLET
22113801	N/C-9/30/97 KIT-DR ALIGNT 100F
22114801	KIT-PAL CDV CONV(WP100 USE 03)
22114802	KIT-NTSC CDV CONV(WP100 USE 04)
22114803	KIT-PAL CDV CONV (WP100)
22114804	KIT-NTSC CDV CONV (WP100)
22115501	INSTRUCTIONS-INSTALL (CDV)
22115701	LABEL-COIN RETURN
22116001	KIT-PHONO CLEAN & LUBE
22116101	GREASE-1/8 OZ TRIBOL
22116401	CLEANER-1/4 OZ LENS CLEANER
22116601	BRKT, TOP CORNER CAP
22116701	BRKT, BOTTOM CORNER CAP
22117001	APPLICATOR-LOW LINT
22117201	CLIP, NEON BULB

22117301	BRKT, DIFFUSER
22117601	BRKT, PRICE CARD
22117902	PLUG-ADAPTER 40 PIN INLINE
22117904	ADAPTER PLUG-28 PIN IN LINE
22118101	SUPPORT-POST
22118202	SUPPORT-SPACER
22118601	WASHER, SHOULDER
22118703	POWER INLET-IEC 320 C-14
22118704	POWER INLET-IEC W/EMI FILTER
22118901	HANDY PACK WP100 PTS GRP
22118903	HANDY PACK ENCORE PTS GRP
22118905	HANDY PACK CD100K
22119102	NAMEPLATE "ROWE AMI" WP100
22119103	NAMEPLATE "ROWE AMI" WP100
22119501	SOCKET-MINIATURE BI-PIN
22119601	SWITCH #1DM301
22119701	BRKT-FLUOR. LAMP
22119801	BRKT, BLOCKOUT
22120201	PIVOT ASSY
22120501	KIT-CD100 MODEM W/O MODEM
22121002	BRKT-MAIN WINDOW
22121101	BLOCKOUT-KEYHOLE
22121201	GASKET-FOAM
22121301	CARD,BLOCKOUT
22121303	CARD BLOCKOUT (TEMPEST)
22122001	SHAFT WELD ASSY-PIVOT
22122201	SPACER, WP100
22122601	PLATE-SWITCH
22123001	KIT-AUX/PAGE INTERFACE
22123401	KIT-PHONO CLEANING
22124401	I.R. REMOTE-BETA/BRITE
22124501	POWER SUPPLY-BETA/BRITE
22126601	KIT-NEON PWR SUP FIELD REPLACE
22126701	MANUAL-SPANISH
22127201	KIT-CROSSOVER RELOCATION (G&H)
22127501	NAMEPLATE "ROWE" ENCORE
22127601	BRACKET-HINGE (LOWER DOOR)
22128001	CATCH
22128101	LOCKBAR ASSY-LH
22128201	LOCKBAR ASSY-RH
22129101	BRKT-CATCH B/A
22129201	BRKT-PIVOT, B/A
22129401	SHAFT WELD ASSY-PIVOT
22131901	LINK-ANIMATION DRIVE
22132201	CABLE ASSY DR-RIB, KEYBRD(18")
22132202	CABLE ASSY DR-RIB, KEYBRD (9")
22132210	CABLE ASSY DR-RIB, CC PWR/RST
22132213	CABLE ASSY DR-RIB CC USB
22132214	CABLE ASSY DR-RIB, CC HARD DR
22132217	CABLE ASSY DR-RIB, CC KBRD
22132218	CABLE ASSY DR-RIB, CC ETH LED

22132220	CABLE ASSY DR-RIB, CC PWR/RST
22132224	CABLE ASSY - DR RIBBON
22132225	CABLE ASSY - DR RIBBON
22132227	CABLE ASSY-DR RIB, I/O TO MB
22132228	CABLE ASSY-DR RIB, I/O TO MB
22132229	CABLE ASSY-DR RIB, KEYBOARD
22132230	CABLE ASSY-DR RIB, DISPLAY
22133601	TIE ROD (TOP DOOR)
22134801	SPACER-PWB MOUNT
22135403	JUMPER PLUG 120V-CD100K
22135404	JUMPER PLUG 240V-CD100K
22135702	CABLE ASSY-RIB, TITLE PAGE
22135801	CABLE ASSY-RIB, CCC PWR
22136002	CABLE ASSY-RIB SR .1
22136003	CABLE ASSY-RIB SR .1
22136004	CABLE ASSY-RIB SR .1
22136005	CABLE ASSY-RIB SR .1
22136006	CABLE ASSY-RIB SR .1
22136007	CABLE ASSY-RIB SR .1
22136101	CABLE ASSY-ILLUMINATION LED
22136402	CABLE ASSY-MODULAR, CCC TO P.S
22136403	CABLE ASSY-MOD VOL CNTR 4 CH
22136404	CABLE ASSY-MOD AV CNTRL 4 CH
22136405	CABLE ASSY-MODULAR LED CNTRL
22136406	CABLE ASSY-MOD, CCC TO KID
22136407	CABLE ASSY-MOD, 2CH IR
22136408	CABLE ASSY-MOD, KID TO IR
22136410	CABLE ASSY-MOD, PREAMP
22137101	SUPPORT-LOCK
22137601	HANDLE-TRANSFORMER ASSY
22137701	PLATE-COVER (TRANSFORMER)
22137901	KIT-CD100I FULL KEYBRD UPDATE
22137902	KIT-KEYBRD BUZZER & LED CD100I
22138201	BA PTS GRP MARS NOSTALGIC
22139001	KIT-KEYBRD (01,02) SUBSTITUTE
22139301	MANUAL-SERVICE(STUDIO SND)SUPP
22139701	WINDOW - GRAPHICS (CENTER)
22139702	WINDOW-GRAPHICS (CENTER)
22140403	CABLE ASSY-ETHERNET JUMPER
22140601	STRIP-MIRROR (CDRN)
22140802	SWITCH-PUSHBUTTON/RIGHT ANGLE
22140901	CABLE ASSY SR-RIB, HUB PWR
22140903	CABLE ASSY SR-RIB, CI POWER
22140910	CABLE ASSY SR-RIB, RLC 9VDC
22140911	CABLE ASSY SR-RIB, RLC PWR
22140912	CABLE ASSY SR-RIB, CA TO RLC
22140913	CABLE ASSY SR-RIB
22140916	CABLE ASSY-SR RIB, .1
22140917	CABLE ASSY-SR RIB, .1
22140919	CABLE ASSY-SR RIB .1
22140920	CABLE ASSY SR RIB, WHITE LED

22141501	TAPE-MONITOR FOAM
22141701	BAY-HARD DRIVE
22141702	FRAME-HARD DRIVE
22142101	PLATE-RESET SWITCH MOUNTING
22143801	COMPUTER ASSY-CORE
22143802	COMPUTER ASSY-CORE
22144401	COVER-COMPUTER CARD
22145602	HARNESS ASSY-AMP VOLUME & MUTE
22145604	HARN ASSY-VOLUME CONTROL PANEL
22145606	HARNESS ASM-VOL CONTROL CD100K
22145607	HARNESS-VOLUME/IR 2 CH,CD100K
22145702	HARNESS ASSY-JOFEMAR COIN MECH
22145801	PWR SUPP ASSY-SYSTEM DLW-1/IDL
22145802	PWR SUPP ASSY-SYSTEM DLW-2
22145901	CHASSIS-PWR SUPPLY (DLW/IDL)
22146001	COVER-PWR SUPPLY (DLW-1)
22146301	BRKT-UPS RETAINER
22146401	BRKT-TRANSFORMER MTG
22146501	BRKT-AUDIO OUTPUT MTG
22146601	BRKT-COMPUTER MTG, LEFT
22146702	BRKT-COMP MTG, REAR UNIVERSAL
22146801	CONTAINER-COINS (DLW-1)
22146901	RETAINER-COIN CONTAINER
22147201	CHUTE-COIN, LOWER
22147301	DEFLECTOR-LOWER COIN CHUTE
22147401	SHELL ASSY (DLW-1/2)
22148001	DOOR-CENTER,DLW-SILVER/GREY
22148101	LENS-LEFT TRANSLUCENT WHITE
22148102	LENS-LEFT TRANSLUCENT CLEAR
22148201	LENS-RIGHT TRANSLUCENT WHITE
22148202	LENS-RIGHT TRANSLUCENT CLEAR
22148301	EXTRUSION-DOOR SIDE
22148501	BRKT-TOP
22148601	BRKT-BOTTOM
22148701	CLAMP-WING
22148801	NEON TUBE (STRAIGHT)
22148901	HINGE-DOOR (DLW)
22149001	BRKT-BILL ACCEPTOR
22149202	GLASS-LOWER LOGO-ROWE
22149203	GLASS-LOWER LOGO, ROWE (BLACK)
22149302	GLASS-UPPER LOGO-STARLINK
22149401	BRACKET - LIGHT
22149501	STRIKE-DOOR
22149701	BRKT-SECURITY (TOP)
22149801	BRKT-SECURITY (BOTTOM)
22149901	BRKT-SECURITY (SIDE)
22150101	SUPPORT-UPS, LEFT
22150201	SUPPORT-UPS, RIGHT
22150301	BRKT-RETAINER
22150401	PLATE-COVER,EXTERNAL MOUSE KIT
22150801	LATCH-DRAW, DOOR ASSY

22151401	NEON TUBE (CURVED)
22151501	BRKT-MTG FLATSCREEN ASSY
22151602	LIGHT ASSY-TOP 9"
22151701	LIGHT ASSY-LOGO (LOWER)
22151901	17" FLAT SCREEN W/MOUNTS
22152001	DOOR ASSY-MAIN (SILVER)
22152002	DOOR ASSY-MAIN (BLACK)
22152003	DOOR ASSY-MAIN (SILVER 15")
22152004	DOOR ASSY-MAIN (BLACK 15")
22152005	DOOR ASSY-MAIN DLW-2 (SILVER)
22152006	DOOR ASSY-MAIN DLW-2 (BLACK)
22152007	DOOR ASSY-SILVER W/O MONITOR
22152008	DOOR ASSY-BLACK W/O MONITOR
22152401	BA PTS GRP MARS BA
22152501	CARD READER PTS GRP DLW-1
22152701	NEON ASSY-STRAIGHT
22152801	NEON ASSY-CURVED, DLW
22152901	BLOCKOUT-CARD READER (SILVER)
22152902	BLOCKOUT-CARD READER (BLACK)
22153001	PLATE&STUD ASSY(B/A B/O)SILVER
22153002	PLATE & STUD ASSY(B/A B/O)(BLK
22153101	PLATE&STUD ASSY(COIN B/O)SILVE
22153102	PLATE & STUD ASSY(COIN B/O)BLK
22153201	BLOCKOUT ASSY-COIN (SILVER)
22153202	BLOCKOUT ASSY-COIN (BLACK)
22153301	BLOCKOUT ASSY-B/A (SILVER)
22153302	BLOCKOUT ASSY-B/A (BLACK)
22153401	BACKING PLATE-B/A BLOCKOUT
22153802	TRANSFORMER-FLATSCREEN
22153902	BRKT ASSY-NEW FLATSCREEN TRANS
22154001	BRKT, MONITOR BEZEL MTG
22154101	EXTRUSION-SPONGE RUBBER
22154201	BEZEL-MONITOR
22154301	SHROUD,MONITOR BEZEL(TOP DOOR)
22154401	GRAPHICS PANEL (RIGHT)IDL-MEX
22154501	GRAPHICS PANEL (CENTER)
22154601	GRAPHICS PANEL (LEFT) IDL-MEX
22155002	SHELL ASSY-UNIVERSAL (IDL)
22155101	SIDE PANEL-COMPUTER COLUMN (LH
22155301	SIDE PANEL ASSY-COMP COLUMN(RH
22155501	VENT-COMPUTER
22155701	VENT PASS THRU-COMPUTER
22155801	BRKT-MONITOR RETAINER,FRONT(LH
22155901	BRKT-MONITOR RETAINER,FRONT(RH
22156001	BRKT-MONITOR RETAINER, REAR
22156101	BRKT-MONITOR RAIL
22156201	BRKT-COMPUTER MTG
22156401	BRKT-LATCH ASSY MTG (LH)
22156501	BRKT-LATCH ASSY MTG (RH)
22156901	JUMPER PLUG 115V
22157201	CHANNEL-EDGE WEAR STRIP

22157502	HARNESS-GROUND
22157801	S/W, MY-T-SOFT KYBD
22158001	CNET USB MODEM, IDL
22158101	D-LINK USB HUB
22158201	RETAINER-HANGER
22158401	TAPE-FASTENER,DUAL LOCK
22158501	TRAY, HARD DRIVE
22158601	HD ASSY-AAEON (US)
22159101	BRKT, IR LIGHT BLOCK
22159601	DECAL SET-SILVER DLW-1
22159701	DECAL SET-BLACK DLW-1
22159901	PLATE-COVER (VOLUME CONTROL)
22160301	CLAMP-WING, AUX
22160501	HARNESS-MONITOR PWR, INTERNAL
22160601	HARNESS-MONITOR VGA, INTERNAL
22160701	HARNESS-MONITOR OSD, INTERNAL
22160802	FLATSCREEN W/MNTS 15" SAMSUNG
22161301	STOP-TOUCHSCREEN
22161402	DISP-LCD (15") SAMSUNG
22161501	TOUCHSCREEN-15" ELO
22162201	SENSOR-PROXIMITY, CD100K
22162301	INSTRUCTION CARD, CD100K
22162302	INSTRUCTION CARD,SPAN. CD100K
22162401	PRICE CARD, CD100K
22162402	PRICE CARD, MEXICO-CD100K
22162501	DISPLAY CARD, CD100K
22162502	DISPLAY CARD, MEXICO-CD100K
22162601	BRKT-BUBBLE LED (CONNECTOR)
22162701	BRKT-DISPLAY LED
22162801	BRKT-CROWN LED (SIDE)
22162901	CATCH, TOP DOOR LATCH
22163001	RETAINER, TOP DOOR LATCH
22163101	RETAINER, TOP DOOR SIGHT BLOCK
22163201	CARD RETAINER DISPLAY (SIDE)
22163301	RETAINER, DISPLAY PANEL
22163401	BRKT-CROWN DIFFUSER
22163601	KIT-LH B/A (DL11)
22164001	INSULATION-ACOUSTIC,T. DOOR-K
22164101	BRACE, TOP DOOR
22164201	CABLE-SVGA VIDEO 15 PIN M TO F
22164401	HARN-LED CTRL/PROXIMITY CD100K
22164601	CBA-WHITE LED
22164801	CBA-TRI COLOR LED, TITLE RACK
22164901	HARNESS ASM-PROX,SENSOR CD100K
22165001	SUPPORT-CIRCUIT BOARD
22165501	BA PARTS GRP (RED)
22165502	BA PARTS GRP (BLUE)
22165601	FAN-COMPUTER CORE
22165701	CASTER, MMCD-L
22165801	PLUG, KEYING (3M 3435-0)
22166201	DECAL-INSTR (ENGLISH), CD100K

22166202	DECAL-INSTRUCTION (MEXICO)
22166701	KIT-VIDEO OPTION IDL-1
22166901	KIT-LIGHTING DLW-1 DOOR
22167401	COMPUTER ASSY-CORE ATX
22167801	BRKT-FAN LED CONTROL
22167901	KIT-IR VOL 2CH PREAMP
221A02900ICTE5	DIODE, TRANS SUPPRESSOR 6V 1MA
222A00001N4688	ZENER, 4.7V .25W 5% 1N4688
222A0021N4739A	ZENER, 9.1V 1W. 5% DO-41
225A0000MPSA70	XSTR, PNP 40V .1A TO-92
225A000MPS2222	NOW 70030016
230A000005841A	IC, 8-BIT SER LATCH DRIVER 50V
230A000005890A	IC, 8-BIT SER LATCH DRIVER 80V
230A00000L4962	IC, VOLT REG ADJ 1.5A DIP-16
230A0000LM338K	IC, VOLT REG 5A ADJ LM338 TO-3
230A0LAS6330PI	IC, PULSE WIDTH MOD 5V
230S000002917A	IC, FREQ/VOLT CONVERTER SMD
230S00ADC0834C	IC, 8-BIT A/D CONVERTER LINEAR
232A00074HC00N	IC, QUAD 2-INPUT NAND CMOS
232A0074HC138N	IC, 3 TO 8-LINE DECODER/DEMUX
236A068HC11A1P	IC, MICROPROCESSOR 68HC11
238A0000004N37	IC, OPTOCOUPLED XSTR OUTPUT
240A0A1201B01	LAMP, NEON T-1 BULB
242A01F022S01	LED, T1-3/4 RED
25023902	TIE WRAP, 'LINK' 5-1/4"LG NYL
25030901	LABEL-WARNING
25045302	STUD-LOCK BAR (BC-12)
25050202	WEDGE-LOCKING
25051901	BRACKET-SLIDE SUPPORT
25052403	LATCH-SLIDE
25052902	BRACKET-REJECT SWITCH
25053301	LATCH ASSY
25053503	BRACKET-STOP (LOCK)
25054801	INSULATOR-SWITCH
25055602	TRIM-TOP & BOTTOM (BLUE)
25055606	TRIM-TOP & BOTTOM (CHAR BRN)
25055701	WIRE-HINGE
25056503	BUTTON & BLADE ASSY-REJECT
25056504	BUTTON & BLADE ASSY-REJECT
25057102	BRACKET-COIN CHUTE (UPPER)
25057201	CONNECTOR-EDGE (6 CKT)
25057206	CONNECTOR-EDGE (18 CKT)
25059002	SOCKET-LAMP
25060101	BRACKET-SIDE SHIELD
25060401	SWITCH-PUSHBUTTON (MOMENTARY)
25061301	ACTUATOR-SWITCH
25061601	PANEL-INSTRUCTION
25061602	PANEL-INSTRUCTION
25061603	PANEL-INSTRUCTION
25061604	PANEL-INSTRUCTION
25061607	PANEL-INSTRUCTION

25061901	SUPPORT-CHANGE DOOR
25062001	WIRE-HINGE
25063303	BRACKET-COIN CHUTE SUPPORT
25064301	DOOR-SLUG CUP
25064401	SPRING-TENSION
25065501	STRIP-ADHESIVE
25065703	COUNTER ASSY
25065709	COUNTER ASSY-BILLS ACCEPTED
25065710	COUNTER ASSY-CENTURY SERIES
25066201	INSULATOR
25067702	SPRING-TORSION
25067803	PLATE-PIVOT
25068301	GUARD ASSY-LOCK
25068402	LEVER-ANTI CHEAT (SHORT)
25068501	LEVER-ANTI CHEAT (LONG)
25068502	LEVER-ANTI CHEAT (LONG)
25070201	LABEL-BILL INSERTION
25070218	LABEL-BILL INSERTION (\$1 & \$5)
25070221	LABEL-BILL INSERTION(US-BLACK)
25070232	LABEL-BILL INSERTION (\$1 & \$5)
25070233	LABEL-BILL INSERT (\$1,5,10 BL)
25070234	LABEL-BILL INSERT (\$1,5,10,20)
25070236	LABEL-BILL INSERT (\$2,\$5,\$10)
25070237	LABEL-BILL INSERT (\$2,5,10,\$20)
25070239	LABEL-BILL INSERTION
25070901	LABEL-BILL JAM
25071701	LABEL-WARNING
25072108	CORD & PLUG ASSY
25072501	LABEL-230V
25073801	BELT-TIMING
25075401	GUIDE-LIGHT
25075402	GUIDE-LIGHT
25075601	BRACKET-MTG (LIGHT SENSOR)
25075701	BRACKET-LAMPHOLDER
25075901	PLATE-MOUNTING (HEAD)
25076002	HEAD ASSY-MAG
25076003	HEAD ASSY-MAG
25076201	ROLLER & SHAFT ASSY
25076202	ROLLER & SHAFT ASSY-DOUBLE
25076203	ROLLER & SHAFT ASSY-DOUBLE
25076204	ROLLER & SHAFT ASSY-DOUBLE
25076301	LAMP-PILOT (#755) (BURNED IN)
25076302	LAMP-PILOT (#756) (BURNED IN)
25076501	BRACKET-SUPPORT (BILL TRANSPRT)
25076502	BRACKET-SUPPORT (BILL TRANSPRT)
25076601	ROLLER & SHAFT ASSY-DRIVE
25076605	ROLLER & SHAFT ASSY-DRIVE
25076606	ROLLER & SHAFT ASSY-DRIVE
25076607	ROLLER & SHAFT ASSY-DRIVE
25076801	ROLLER & SHAFT ASSY-DRIVE
25076804	ROLLER & SHAFT ASSY

25076901	SHAFT-PIVOT
25076902	SHAFT-PIVOT
25077201	SWITCH-TOGGLE (SPST)
25077401	BRACKET-MOUNTING (LIGHT)
25078403	CORD & PLUG ASSY
25078502	LEVER-ANTI CHEAT (CENTER)
25078601	GROMMET
25078801	SCREW-SMOOTH HD (#6-32 X 5/16)
25079301	SHAFT-LATCH
25079801	LUG
25079802	LUG
25081201	PANEL-INSTRUCTION, BC3500
25081202	PANEL-INSTRUCTION
25084501	SPRING-TENSION
25092801	HANDLE & SHAFT ASSY
25092901	BEARING-REJECT LEVER
25095301	PLATE-PUSH
25095601	BRACKET-SWITCH
25095801	CATCH-CASH BOX
25096101	BLOCK-FOAM
25096105	BLOCK-FOAM (CBA)
25096201	ROLLER-IDLER (OUTPUT)
25096301	SHAFT-OUTPUT
25097701	SPRING-COMPRESSION
25098101	BAR HANDLE-HOPPER
25098301	SLEEVE-SPACER
25098403	PLATE-STOP (SOLENOID)
25098701	SUPPORT-SPACER
25099001	SHAFT-PIVOT (DOOR)
25099003	SHAFT-PIVOT (DOOR)
25099004	SHAFT-PIVOT (DOOR)
25099005	SHAFT-PIVOT (DOOR)
25099006	SHAFT-PIVOT (DOOR) BC100/200
25099007	SHAFT-PIVOT (DOOR)
25099101	PIN-PIVOT (LINK)
25099102	PIN-PIVOT (LINK)
25099403	SOLENOID ASSY
25099406	SOLENOID & FRAME ASSY
25099503	PLUNGER ASSY-SOLENOID
25099504	PLUNGER ASSY-SOLENOID
25099701	SPRING-COMPRESSION
25110001	TOGGLE-DOOR (LH)
25110101	TOGGLE-DOOR (RH)
25110501	LABEL-U.L.
25111202	BAR-PUSH (CASH BOX)
25111203	BAR-PUSH (CASH BOX)
25111502	COVER-BOX
25112002	SPRING-TORSION
25112402	BRACKET-MTG (DISPR CHUTE)
25112701	BUMPER-RUBBER
25112901	POST-SUPPORT

25112902	BRACKET-SUPPORT
25113002	SOCKET-8 CONTACT (JONES)
25113401	SPRING-COMPRESSION
25113501	GROMMET
25113701	DRIVE SHAFT & PIN ASSY
25113702	DRIVE SHAFT & PIN ASSY
25114701	BUMPER, COIN HOPPER
25120401	COVER-SWITCH GUARD
25120510	LABEL-TEST SWITCH
25132401	PULLEY-TIMING (18 TOOTH)
25142601	SPACER
25144201	PLATE-COVER
25144202	PLATE-COVER
25146101	SPRING-LATCH
25147901	HOLDER-BLADE, BC3500
25148001	BLADE
25148101	CLIP-SPRING
25151101	COUPLING-SHAFT (HOPPER MOTOR)
25151701	PLATE-HOLD DOWN
25151702	PLATE-HOLD DOWN
25152301	FOOT-ADJUSTABLE
25152602	FILTER-EMI (VDE CONNECTOR)
25152604	FILTER-EMI, HOME UNITS
25152605	FILTER-EMI
25152704	FILTER & LUG ASSY
25152708	FILTER & LUG ASSY
25152716	FILTER & LUG ASSY
25155901	BUMPER-SPLIT STEM
25156904	WASHER-SHOULDER
25156906	WASHER-SHOULDER
25156910	WASHER-SHOULDER
25156911	WASHER-SHOULDER
25156916	WASHER,SHLDR #4X.318"OD PHENOL
25156917	WASHER, SHLDR #4 X .290"OD NYL
25158001	STOP ASSY
25158901	PLUNGER & DOOR ASSY (SM DOOR)
25158902	PLUNGER & DOOR ASSY (LGE DOOR)
25160501	LINK-SCAVENGE LEVER
25161401	CLEAN OUT-COIN CHUTE
25161601	ACTUATOR ASSY-REJECTOR
25161603	ACTUATOR ASSY-REJECTOR M/F
25163101	BRACKET-SHIELD
25163201	PIN-PIVOT
25163902	LABEL-DISPENSER BUCKET LUBE
25164401	STRAP-SPRING
25164601	BAIL-HOPPER RETAINER
25164701	BRACKET-HANGER (BAIL)
25165202	BRACKET-MTG (CONTROL BOX)
25165802	LABEL-HOPPER IDENTIFICATION
25165901	HANDLE-HOPPER
25165902	HANDLE-HOPPER

25165903	HANDLE-HOPPER
25166502	ROD-STOP
25166602	SHIELD-COIN SPILL
25166801	LAMP & TERMINAL ASSY
25166901	TERMINAL BLOCK
25167301	XTAL, QTZ 3.579545MHZ LS-.486"
25167302	XTAL, QTZ 2.000MHZ HC-33/U
25167304	XTAL, QTZ 3.579545MHZ LS-.190"
25167306	XTAL, QTZ 4.0000MHZ LS-.190"
25167308	XTAL, QTZ 3.579545MHZ LS-.190"
25167309	XTAL, QTZ 10.739MHZ LS-.192"
25167310	XTAL, QTZ 5.7143MHZ LS-.190"
25167313	XTAL, QTZ 4.9152MHZ LS-.190"
25167314	XTAL, QTZ 12.288MHZ LS-.190"
25167318	XTAL, QTZ 3.6864MHZ LS-.190"
25167319	CRYSTAL-QUARTZ (12.200 MHZ)
25167323	XTAL, QTZ 9.216MHZ LS-.190"
25167324	XTAL, QTZ 8.000MHZ
25167326	XTAL, QTZ 1.8432MHZ LS-.190"
25167327	XTAL, QTZ 10MHZ
25167339	XTAL, QTZ 11.0592 MHZ HC49
25167342	XTAL, QTZ 9.216 MHZ HC49 W/SL
25167601	MFAB, BRACKET PWR SUPPLY ROWE
25168301	TERMINAL BLOCK
25168305	TERMINAL BLOCK
25168306	TERMINAL BLOCK
25168307	TERMINAL BLOCK
25168501	TERMINAL BLOCK ASSY
25168503	TERMINAL BLOCK ASSY
25168702	LABEL-POWER RELAY
25168801	SCREW-SHOULDER (SQ HD 1/4-20)
25169101	LABEL-DISPENSER WIRING
25170201	COVER-COIN CHUTE
25170301	BRACKET-STOP
25170401	CHUTE ASSY-COIN INLET
25170501	BRACKET-MOUNTING
25170601	ARM ASSEMBLY-REJECTOR
25170701	THUMB NUT-KNURLED (#8-32)
25171101	COVER-COIN SWITCH
25171202	AGITATOR ASSY-UPPER (COIN HOP)
25172001	DISC-AGITATOR
25172102	HUB-AGITATOR DISC
25172801	DEFLECTOR-COIN
25175701	PCB ASSY, BD & TERM PHOTO DET
25175702	PCB ASSY, BD & TERM PHOTO DET
25175801	COVER ASSY-JUNCTION BOX
25178401	CATCH-CASH BOX
25178501	BRACKET-SOLENOID
25178601	PLUNGER ASSY-SOLENOID
25178701	STOP-BILL
25178801	PIVOT-BILL STOP, STACKER

25179001	PLATE-SWITCH
25179101	LINK-PUSH PLATE
25179202	SHAFT-SUPPORT (LOWER)
25179501	SHAFT-ROLLER
25179601	ROLLER
25179701	CRANK & PIN ASSY
25180501	MANUAL-SERVICE (BC-35)
25181501	SUPPORT-COIN CHUTE
25181701	SPRING-TENSION
25181801	STOP & STUD ASSY-LWR BILL BOX
25185902	HARN ASSY-MOTOR CAPACITOR
25186401	BELT-DRIVE (SEMI-STRETCH)
25186701	CATCH-HOPPER
25187501	PIPE-SUPPORT (WHITE)
25187601	FITTING-PIPE (COMPR 1-1/4)
25188102	INSULATOR
25189201	PLATE ASSY-COVER
25189301	TEMPLATE-DRILL
25189701	INSULATION, PAD / BC-35 (CUT)
25189901	LABEL-CAUTION
25190001	PAD-SPONGE RUBBER
25190002	PAD-SPONGE RUBBER
25190003	PAD-SPONGE RUBBER
25190006	PAD-SPONGE RUBBER
25190008	PAD,TERMINAL COVER
25191201	RELAY, DPDT 24VDC 5A
25191301	LIGHT-INDICATOR & CLIP
25191601	MANUAL-SERVICE (OBA)
25191701	PIN-PIVOT
25191702	PIN-PIVOT
25192401	PULLEY-TIMING (20 TOOTH)-OBA
25192502	RIVET
25192902	PULLEY-TIMING(22TOOTH)OBA/BA50
25193301	ROLLER-CROWNED
25193302	ROLLER-CROWNED
25193304	ROLLER-CROWNED
25193401	SHAFT-CROWNED ROLLER, OBA
25193402	SHAFT-CROWNED PULLEY, BA50
25193403	SHAFT-ANTI CHEAT LEVER, BA50
25193601	ROLLER-CREASING
25193602	ROLLER-CREASING (SMALL)
25193605	ROLLER-CREASING (W/CPLG),BA50
25193701	SPACER-SHOULDERED
25193901	ROLLER-PRESSURE (UPPER)
25193902	ROLLER-IDLER (INPUT) BA50
25194101	BRACKET-TAKE UP SHAFT
25194102	BRACKET-TAKE UP SHAFT
25194501	BRKT & PIN ASSY-IDLER ROLLER
25194502	BRKT & PIN ASSY-IDLER ROLLER
25194701	ROLLER-IDLER
25194803	PAD-MOUNTING (TO18)

25194901	ROLLER-IDLER (OUTPUT)
25195601	AGITATOR (EX LARGE COINS)
25195701	RING-CHAIN GUIDE (EX LG COINS)
25195801	RELAY, DPDT 24V PCB MT
25196901	STRAP-HINGE
25197101	PLUG ASSY-OBA
25197102	PLUG ASSY-OBA
25197201	INSULATOR-CIRCUIT BOARD
25197801	SPACER-POST
25198101	BRACKET-STOP (BA)
25198102	BRKT-STOP (B.A.)
25198401	COVER-PROTECTIVE (SWITCH)
25198501	MANUAL-SERVICE (BC-12)
25198502	MANUAL-SERVICE (BC-12R)
25198503	MANUAL-SERVICE (WBC-12)
25199101	BRACKET-STOP (LOCKBAR)
25199301	SPRING-CATCH
25210508	JUMPER ASSY
25210509	JUMPER ASSY
25210601	STOP-BILL ACCEPTOR
25210602	STOP-BA
25210603	STOP-BA
25210701	MANUAL-SERVICE (BC-1)
25210801	BOOKLET-STATUS CODES (BC-1)
25210901	PLATE-MOUNTING (OBA)
25211503	BRKT-HOLD (C-8)
25211702	DECAL-COIN (HALF DOLLAR)
25211703	DECAL-COIN (QUAR & HALF DOLL)
25211706	DECAL-COIN (QUARTER)
25211713	DECAL-DECORATIVE, BC1200
25213501	SLEEVE-SHAFT (LONG)
25213502	SLEEVE-SHAFT (SHORT)
25213601	SPRING
25214601	STRIKE-HEX
25218602	CORD ASSY-LINE
25218603	CORD ASSY-LINE
25220401	BEARING-SPLIT
25220501	SHAFT-PRESSURE ROLLER
25220701	ROLLER-INPUT
25220901	SHAFT-LOWER INPUT
25222201	PULLEY & PIN ASSY
25222202	PULLEY & PIN ASSY
25222801	SEPARATOR-SWITCH
25223101	LABEL-FLAG
25223201	SPRING-TENSION
25223301	SPRING-TENSION
25223405	PKG-LOCK CYLINDER & KEY
25223702	SHAFT & PULLEY ASSY-FINAL
25223801	PWB-CELL
25224101	BEARING-PUSHER PLATE
25224501	BRACKET & BAFFLE ASSY

25224601	BRACKET-PRESSURE ROLLER SPRING
25224901	SPRING-FLAT (LOCKBAR)
25225003	SPRING-TENSION
25225301	ROLLER-FLANGE CBA/RBA
25225501	ROLLER-CROWNED
25225801	INSTALL INSTRUC-AUX HEATER KIT
25225901	KIT-AUXILLIARY HEATER (BC-12R)
25225902	KIT-AUXILLIARY HEATER (BC-2RC)
25225903	KIT-THERMOSTAT UPGRADE
25226801	PIVOT-LATCH
25226901	RAMP-COIN (HOPPER)
25227101	STRAP-SPACER
25227301	MANUAL-SERVICE (CBA)
25227401	TERMINAL BOARD ASSY
25227502	MOTOR & PULLEY ASSY (50 HZ)
25227801	CAM ASSY
25228001	JUNCTION BOX & FILTER ASSY
25228201	LEVER ASSY-ANTI CHEAT
25228303	PIN & ROLLER ASSY
25229601	SWITCH-DOOR INTERLOCK
25229701	LAMP-NEON (120V AC)
25229802	LAMP-OUT OF CHANGE
25229901	LINE CORD (VDE CONNECTOR)
25230501	SPRING-PUSH
25231311	ACCESSORIES BAG ASSY (BC-1200)
25231312	ACCESSORIES BAG ASSY (BC-3500)
25231313	ACCESSORIES BAG ASSY (BC-1400)
25231331	ACCESSORIES BAG ASSY-C2
25231355	ACCESORIES BAG ASSY (COLEMAN)
25232101	SOLENOID & STUD ASSY
25232103	SOLENOID & TERMINAL ASSY
25232104	SOLENOID ASSY
25234001	HEATER-FLEXIBLE (5W/SQ IN)
25234102	THERMOSTAT, RL CHANGERS
25234302	HARNESS ASSY-COMMUNICATION
25234601	HARNESS-STACKER SUBSTITUTE
25234701	MANUAL-SERVICE (OBA-4)
25234702	MANUAL-SERVICE (OBA-4)
25234801	MANUAL-OBA-4 PULSED OUT INTER
25234901	HARNESS ASSY-CREDIT
25235001	SHAFT-ROLLER, BA50
25235101	LABEL-BILL INSERT OVERLAY (OBA
25236201	SOCKET, IC PLCC-68 1.295"SQ
25236202	SOCKET, IC PLCC-32 SMT
25236302	CELL-PHOTOCONDUCTIVE, CBA
25236303	CELL, PHOTOCONDUCTIVE 29K 70V
25236304	PHOTOCELL
25236501	MANUAL-SERVICE (CBA-4)
25236502	MANUAL-SERVICE (CBA4 INTERFACE
25237302	KIT-CBA-2 ADAPTOR
25237304	KIT-CBA-2 ADAPTOR (SNGL PRICE)

25237309	KIT-CBA-2 ADAPTOR (SGL PRICE)
25237312	KIT-ADAPTOR (VENDO,ROCKOLA)
25237314	KIT-CBA-2 ADAPTOR
25237315	KIT-CBA-2 ADAPTOR (ROYAL V5.0)
25237316	KIT-CBA-2 ADAPTOR
25237320	KIT-UBA2 ADAPTER(DIXIE NARCO)
25238405	CAB ASSY-BC-150(\$1,\$5,\$10,\$20)
25238801	MANUAL-SERVICE (BC-3500)
25238802	MANUAL-SERVICE (BC-1200/1400)
25238803	MANUAL-SERVICE (BC-100)
25238804	MANUAL-SERVICE (BC-200)
25238806	MANUAL-SERVICE (BC-150)
25238809	MANUAL-SERVICE (CBC-1200/1400)
25238902	ROLLER-OUTPUT (W/COUPLING)BA50
25239001	BRKT-MTG (PWR CONT BOX)
25239601	DECAL-\$10 (BC-1400)
25239602	DECAL-\$10 & \$20 (BC-1400)
25239603	DECAL-\$10
25239604	DECAL-\$20
25239605	DECAL-\$1,5,10 (BC200)
25239701	SHAFT-DOOR (COIN CUP)
25239801	HARN ASSY-PCC (6 CKT)
25239901	HARN ASSY-PCC (7 CKT)
25240201	HARNASS ASSY-INTERCONNECT
25240801	BRKT ASSY-MTG (SENSOR)
25243201	SPACER-SHAFT (TAKE-UP ROLLER)
25244101	SHAFT & PULLEY ASSY
25244801	ROLLER ASSY
25245001	SHIELD-BILL TRANSPORT
25245301	LABEL-CAUTION (DOOR LATCH)
25246101	MANUAL-SERVICE (CBA-2/4 NO STK)
25246401	SHAFT-ANTI CHEAT LEVER, RBA
25246601	PIVOT
25246801	SPRING-ANTI CHEAT, RBA
25246902	SPRING-PRESSURE
25247108	SWITCH, SIP 8POS .1"CTR SLIDE
25247110	SWITCH, SIP 10POS .1"CTR SLIDE
25248001	STANDOFF-MALE
25248201	ROLLER
25248902	PLATE-CATCH ASSY
25250001	MANUAL-SERVICE (SBC-2)
25250201	LABEL-LIGHTED (UPPER) RBA-7
25250301	LABEL-LIGHTED (LOWER)
25250401	SPRING-TORSION (LH)
25250501	SPRING-TORSION (RH)
25250601	SHAFT
25250701	PIN-ROLLER
25250801	ROLLER-PRESSURE
25251001	MANUAL-SERVICE (RBA-7)
25251002	MANUAL-SERVICE (RBA-7)
25251201	LINK-PIVOT (BC-1200M)

25251301	LINK-ACTUATOR (BC-1200M)
25251701	MANUAL-SERVICE (RBA-7 INTERF)
25251801	LIGHT ASSY-INDICATOR (SBC-2)
25252601	KIT-HARNESS (RBA)
25253701	ROD-SUPPORT/STOP
25254801	CLEANING STRIP-BA50 MAG HEAD
25254804	KIT-CLEAN STRIP-CBA2 MAG HEAD
25254805	KIT-CLEANING STRIPS (6)-RBA7
25255301	ALARM,AUDIBLE 70 DB 1.3" DIA.
25255302	BUZZER-PIEZO (2 KHZ NOM.)
25520901	MANUAL-SERVICE (CBA-2 OEM)
25520902	MANUAL-SERVICE (CBA-2)
25520903	INSTRUCTIONS-CBA-2 INTERFACE
25530301	CORD & PLUG ASSY
25545401	HARNESS-ADAPTER B/A REPL
25552301	SPACER-CONTACT BOARD
25552401	BOARD & SPRING CONTACT ASSY
25552901	MANUAL-SERVICE (NSBC)
25553001	FLATTENER-ANTENNA
25553201	BRKT-STOP (REJECT LEVER)
25553601	MANUAL-SERVICE (C2,4,6,)
25554501	MANUAL-SERVICE (C8/C10)
25554703	SYSTEM SCHEMATIC-C8/10 11 X 17
25554801	KIT-BRAKE
25555801	MANUAL-SERVICE (C6RL,C10RL)
25556201	BRKT-B.A. STOP
25600201	PIN, .125 D.D. X 1.25 LONG
256A150013001	VARISTOR, 13J 150V MO 7MM
258A00001F001	SWITCH, SPST MOM NO 12MM
258A009990001	SWITCH, OPTIC SLOTTED 1MM APT.
262A1R00125A01	FUSE, PICO 1A 125VAC
262A3R00125A01	FUSE, PICO 3AMP 125V VERY FAST
26665101	PAINT-TOUCH UP (00147600)
26676802	QUALITY CARD-PHONO
26689901	TAG-DEFECTIVE PART
26690701	BOX-SMALL PARTS
26694703	KIT-AMPLIFIER ACCESSORY
26694704	KIT-AMPLIFIER ACC WP100
26694801	KIT-STUDIO SOUND SECOND AMP
26694802	KIT-CD100K SS SECOND AMP
26694901	KIT-NETSTAR SECOND AMP
26694902	KIT-DL-11A SECOND AMP
26699201	KEY-330A SERIES
26699503	KIT-SECURITY BAR
266A40002N5061	THYRISTOR, 60V .51A CONTINUOUS
26701401	KIT-PAGING ADAPTOR
26702101	KEY-COMMON C-033A SERIES
26703001	PAINT-TOUCH UP (GOLD METALLIC)
26703101	PAINT-TOUCH UP(BROWN METALLIC)
26703401	PAINT-TOUCH UP(SILVER METALLIC)
26703501	KIT-BATTERY

26704001	PAINT-TOUCH UP(SPICE METALLIC)
26704101	PAINT-TOUCH UP(ROSE BEIGE MET)
26704201	PAINT-TOUCH UP (DAY STAR BLUE)
26704301	PAINT-TOUCH UP (ENSIGN BLUE)
26704402	KIT-PAGING HAND HELD
26710301	PAINT-TOUCH UP (ONDO BLUE)
26710501	PAINT-TOUCH UP (BEIGE METALLIC
26710901	KEY-COMMON (C92A)
26710902	COMMON KEY-SERIES "94"
26711001	KIT-B.A. BLOCKOUT (R-92)
26711101	PAINT-TOUCH UP(SANDSTONE) R-93
26711102	PAINT-TOUCH UP (RUSSET) R-93
26711104	PAINT-TOUCH UP (SILVER) R-93
26711201	PAINT-TOUCH UP (PEWTER) CD-100
26711302	PAINT-TOUCH UP (CINNAMON)
26712201	KIT-SPRAG WHEEL
26712301	PAINT-TOUCH UP (MED NAV BL MET
26712304	PAINT-TOUCH UP (LT TAUPE MET)
26712501	PAINT-TOUCH UP(MAROON MET)CD51
26712901	PAINT-TOUCH UP(DARK SAD. MET.)
26713001	KIT-DOOR SUPPORT STRAPS (CD51)
26713201	PAINT-TOUCH UP (PRESTIGE SILV)
26713301	KIT-R92/R94 DOOR BRACE
26713401	PAINT-TOUCH UP(DK MOCHA BR/51A
26713502	KIT-DUAL PHONOGRAPH
26713701	KIT-DOOR & GRILLE ASSY (CD100C
26714101	PAINT TOUCH UP(COL.RED)CD100D
26714102	PAINT TOUCH UP(AZT.GOLD)CD100D
26714103	PAINT TOUCH UP(BLK MET)CD100D
26714201	PAINT TOUCH UP LT SANDSTN 100E
26714301	PAINT TOUCH UP MED CHAR MET
26714401	PAINT-TOUCH UP (LT BEIGE MET)
26714402	PAINT-TOUCH UP (RED MICA PEARL
26714601	PAINT-T/U STARLINK GM BLACK
26714602	PAINT-T/U STARLINK DK GRAPHITE
26714603	PAINT-T/U STRLINK SILVER PEARL
27023008	LOCK & KEY ASSY (VAN)
27023015	LOCK & KEY ASSY -1 PAIR,BC2800
27023302	PAWL-BRAKE ASSY
27023902	BRUSH-HOPPER
27025801	KIT-BUCKET SOL PLUNGER & DOOR
27025802	KIT-BUCKET SOL PLUNGER & DOOR
27027201	BRACKET-COIN BLOCK .50¢ & 1.00
27027202	BRACKET-COIN BLOCK (50¢)
27027203	BRACKET-COIN BLOCK (\$1.00)
27027204	BRACKET-COIN BLOCK
27027205	BRACKET-COIN BLOCK (ALL COINS)
27029311	DECAL-SERVICE (BC-2RC)
27029312	DECAL-SERVICE (BC-1400)
27029313	DECAL-SERVICE (BC2800)
27029801	KIT-COIN BLOCK

27029902	BRAKE LEVER (MULTI)
27029903	KIT - BRAKE REPLACEMENT
27030201	KIT-RETRIEV PREVENT (BC1400)
27032301	KIT-LOWER TRACK
27032502	KIT-BC35 & BC3500 DOOR SUPPORT
27032701	KIT-DOOR TRIM PLATE
27033201	KIT-HOPPER CONVERSION(STD CAP)
27033202	KIT-HOPPER CONVERSION (HI-CAP)
27033401	KIT-LAMP CONVERSION
27033501	PAINT-TOUCH UP (DK CAMEL TAN)
27033502	PAINT-TOUCH UP(DK VINTAGE BR)
27033503	PAINT-TOUCH UP (FLAT WHITE)
27033504	PAINT-TOUCH UP (BLUE)
27033505	PAINT-TOUCH UP (CHAR BRN)
27033701	KIT-CREASING ROLLER
27033801	LINK & STOP SCREW ASSY
27034601	KIT-DOOR GUARD BC1200 OS BROWN
27034602	KIT-DOOR GUARD BC100 BROWN
27034606	KIT-DOOR GUARD BC100 BLACK
27034607	KIT-DOOR GUARD BC1200 OS BLUE
27034609	KIT-DOOR GUARD BC1200 NS BLACK
27034611	KIT-DOOR GUARD BC1400 BLACK
27034624	HINGE-HASP
27034625	HASP-LOCK
27035120	DOOR-SERVICE (BC-12R HI SEC)
27035901	KIT-HOPPER BAFFLE (STD HI-CAP)
27036001	KIT-OBA PRESSURE ROLLER ASSY
27036307	MECHANISM-PACKED
27037401	KIT-25¢ COIN ACCEPTOR
27037701	KIT-TRACK & LEVER (OBA)
27037901	KIT-OPTICAL SWITCH
27038208	KIT-MIN ELECT COIN RETROFIT
27038210	KIT-MINI RETRO 25/\$1 BC35 MARS
27038220	KIT-MINI RETRO 25/\$1 BC12 MARS
27038701	KIT-CBA-2 REMOTE COUNTER
27038702	KIT-CBA-4 REMOTE COUNTER
27038703	COUNTER ASSY-REMOTE (CBA-2)
27038901	SHAFT & PULLEY ASSY-DRIVE
27039001	KIT-CBA-2 BILL BOX
27039002	KIT-CBA-2 BILL BOX
27039003	KIT-CBA-2 BILL BOX
27039004	KIT-CBA-2 BILL BOX
27039201	KIT-BA-50 RETROFIT (BC-12R)
27039202	KIT-BA-50 RETROFIT (BC-12)
27039203	KIT-BA-50 RETROFIT (BC-2RC)
27039204	KIT-BA-50 RETROFIT (BC-35)
27039209	KIT-BA50 RETRO (BC12R W/O DISP
27039210	KIT-CBC3500 TO CASHCODE
27039211	KIT-CBC1200 TO CASHCODE
27039801	KIT-CBA-2 LOGIC BD CONVERSION
27039804	KIT-CBA2 LOGIC BD CONVERSION

27039805	KIT-UBA2 LOGIC BD CONVERSION
27040001	KIT-BILL BOX(COVERED 225 BILL)
27040002	KIT-BILL BOX(COVERED 400 BILL)
27040003	KIT-BILL BOX(COVERED 550 BILL)
27040004	KIT-BILL BOX(COVERED 1000 BILL
27040005	KIT-BILL BOX (1000 BILL PHONO)
27040007	KIT-BILL BOX RBA-7 (500 BC)
27040008	KIT-BILL BOX RBA-7 (1000 BC)
27040010	KIT-BILL BOX (800 BILL PHONO)
27040201	KIT-BC1400 HISEC BA INLET
27040301	KIT-HARDWARE FOR 35081205
27040501	KIT-ANTI CHEAT PULL BACK LEVER
27040502	KIT-BA50 ANTI-STRINGING
27040901	INSTRUCTIONS-IMONEX COIN ACPTR
27041003	P03-SAA7210
27041004	P04-SAA7220
27041005	P05-TDA1541P
27041013	P13-TCA0372DP2
27041015	P15-MN4264-15
27041042	P42-BC848B
27041071	CAPACITOR-MYLAR (4.7UF)
27041101	KIT-LED PAIR (RBA7)
27041702	KIT-LOCK GUARD (C2,NSBC)
27041703	KIT-LOCK GUARD C-6
27041704	KIT-LOCK GUARD C-8
27041705	KIT-LOCK GUARD C-10
27042102	FILLER NSBC 2 & 4
27042120	KIT-FILLER SBC
27042501	TAPE-BILL CHGR MARKETING
27043001	KIT-LAMP ASSY (MMCD-1 60HZ)
27043101	KIT-SECURITY (CD100E)
27043801	KIT-FULL TO MINI CD100E (NO
27043802	KIT-FULL TO MINI W/COIN SWITCH
27044001	KIT-BASE LD SBC-2/4
27044002	KIT-BASE LD 6/8/10
27044003	KIT-BASE LD C2/4
27044101	KIT-FILLER, C-2/4
27044102	KIT-FILLER, C-6
27044103	KIT-FILLER, C-8
27044104	KIT-FILLER, C-10
27045401	C6 DOOR ASSY-SERVICE
27045501	C8 DOOR ASSY-SERVICE
27045601	C2/4 DOOR ASSY-SERVICE
27045801	KIT-BC3500 SNGL DMP RETROFIT
27045901	KIT-BC1200/1400/100 SNGL DMP
27062601	KIT-"E" DOOR BRACE
27062801	LUBRICANT-SILICONE (1/2 OZ)
27062901	KIT-DUST COVER SYSTEM
27063001	INSTALL-INSTRUCT DUSTCOVER
27063601	KIT-BASE HD SBC 2/4
27063602	KIT-BASE HD 6/8/10

27063603	KIT-BASE HD C-2/4
27063802	MARS ME330 \$1, 25¢
27063901	KIT-COIN ACCEPTOR-C6
27063903	KIT-COIN ACCEPTOR-C6RL
27063905	KIT-COIN ACCEPTOR-C6
27063906	KIT-COIN ACCEPTOR-C8 & 10
27065001	KIT-BA50 NEW \$5, \$10
27065002	KIT-C150 NEW \$5, \$10
27065003	KIT-METRODADE NEW \$5 & 10
27065005	KIT-NICKELS NEW \$5 & \$10
27065006	KIT-CM VDG NEW \$5 & \$10
27065101	KIT-OBA UPGR-NEW \$5, SGL BD
27065102	KIT-OBA UPGR-NEW \$5, DUAL BD
27065103	KIT-OBA4 UPGR-NEW \$5,\$10
27065104	KIT-OBA UPGR-NEW \$5, DUAL BD
27065901	KIT-COLEMAN ENTRY WIZARD
27066001	KIT-THERMOSTAT, BILL CHANGER
27070001	KIT-BA MTG-LESS B.A.CD100E
27070201	KIT-BILLBOX CVR,LOCKABLE DL-11
28030202	IC-PROGRAMMED GAL 16V8
28098708	IC-MICROCOMPUTER 87C52 OBA4 PB
28098710	IC-MICROPROCESSOR CBA2
28098711	IC-MICROP OBA2 SNGL
28098712	IC-MICROP OBA2 DBL
28098713	IC-MICRO GEMSTAR MIOB
28098714	IC-MICRO GEMSTAR USB CTRL
28098715	IC-MICRO GEMSTAR MAIN I/O REV2
28098716	IC-MICRO RS232/USB CONVERTER
28202101	CREDIT MODULE ASSY, 9600 BAUD
28251501	BILL ACC-ASTRO USA (GAMES)
28260001	COVER-SIDE, GEMSTAR
28260101	COVER-TOP, GEMSTAR
28260201	BASE, GEMSTAR
28260401	SPACER-COIN, MOLDED, GEMSTAR
28260501	MONITOR-14" W/TOUCHSCREEN
28260601	CARD SWIPE, GEMSTAR
28260701	BRKT W/A-MONITOR MTG, GEMSTAR
28260801	BEZEL-INJ MOLDED, GEMSTAR
28260901	BRKT W/A-DEFLECTION BOARD
28261203	CAMERA-LOGITECH QUICKCAM PRO
28261401	PAD-BOTTOM, GEMSTAR
28261501	INSERT-BOTTOM, GEMSTAR
28261701	BRKT-CPU MTG
28261801	DOOR ASSY-BACK, GEMSTAR
28261901	PANEL-LOWER LH, GEMSTAR
28262001	BRKT-MONITOR BEZEL LWR
28262201	BRKT-DOUBLE HEAT SINK
28262301	HARNESS-SPEAKER
28262401	COVER ASSY-SIDE
28262501	COVER ASSY-TOP
28262601	BEZEL ASSY-MONITOR

28262701	WEDGE-SUPPORT, GEMSTAR
28263201	COIN MECH-IMONEX, GEMSTAR
28263701	LAZY SUSAN
28264001	GRILL-SPEAKER
28264101	SPRING-PIN
28264302	CBA-SWITCH BD
28264401	GASKET-MONITOR BEZEL
28264501	CAM LOCK W/NICKEL PLATED KEY
28265001	SPRING-FRICTION DRIVE
28265101	PAD-NON SKID
28265201	GASKET-BEZEL
28267102	CBA-IRDA TRANSCEIVER
28267301	TAPE-MYLAR
28267601	GRILL-FAN, WIRE,CHROME-GEMSTAR
28268001	HARNESS ASSY-MAIN (GEMSTAR)
28268702	CBA-MAIN I/O
28269101	DOOR ASSY-BACK
28270201	DECAL-SIDE PANEL (GEMSTAR)
28270801	SPEAKER-4" 15W SHIELDED
28271102	CBA-AUXILIARY I/O
28271901	RIVET-SNAP, PLASTIC .203 DIA
28272001	HARNESS ASSY-MAIN POWER 110V
28272201	WINDOW-CAMERA
28272301	WINDOW-I/R, GEMSTAR
28272801	COIN BOX ASSY
28273502	CBA-NETWORK CONNECTOR
28273901	BLOCK 1-COIN RETURN, GEMSTAR
28274001	KNOB-COIN RETURN
28274002	KNOB-VOLUME CONTROL
28274101	MOUNT-VIBRATION, 6-32
28274201	BELLOWS ASSY, GEMSTAR
28275001	CABLE ASSY-KEYBD, MOUSE
28275101	HARN ASSY-COIN LIGHT, GEMSTAR
28275201	HARN ASSY-IRDA PASS THROUGH
28275301	U-BOLT, 1/4-20
28275601	SWITCH-MOM W/CONN, GEMSTAR
28275701	ACTUATOR ASSY-COIN RETURN
28275801	COIN ACCEPT PTS GRP-GEMSTAR
28276001	CAP-COIN RETURN KNOB
28276201	MOUNT-ADHESIVE BACKED
28276801	CAMERA ASSY
28277001	MICROPHONE-BRD MTG
28277201	CBA-MICROPHONE
28277501	DECAL-CARD READER (GEMSTAR)
28277701	HARNESS-AUX I/O TO MICROPHONE
28277801	HARNESS-AUX I/O TO CPU
28278001	WASHER - FLAT M3 BLACK OXIDE
28279101	ACCESSORIES BAG ASSY (GEMSTAR)
28279201	ADAPTER ASSY-USB
28279401	LABEL-PRESS TO RESET, GEMSTAR
28279501	MARQUEE-DISPLAY, GEMSTAR

28281201	CBA-RS232/USB ADAPTER CC REV2
30426002	HARNESS ASSY-AUX CONNECT
30426003	HARNESS ASSY-AUX CONN (WP100)
30426103	HARNESS ASSY-POWER AMP
30426104	HARN ASSY-PWR AMP (WP100)
30426703	BINDING POST STRIP (4A)
30426705	BINDING POST STRIP (7A)
30426706	BINDING POST STRIP
30426707	BINDING POST STRIP
30519703	GRIPPER BOW & HUB ASSY
30519704	GRIPPER BOW & HUB ASSY
30570701	CHUTE-COIN (TOP)
30570801	CHUTE-COIN (BOTTOM)
30576002	PUSHBUTTON, HI/LO VOLUME KEY
30576201	BOX ASSY-CASH
30578802	PCB ASSY, COIN SWITCH
30622102	WINDOW-CLEAR
30625701	COVER-HAND HOLE
30632201	REMOTE VOLUME CONTROL ASSY
30632209	REMOTE VOLUME CONTROL DUAL
30632211	REMOTE VOLUME CONTROL ASSY
30656905	MICROPHONE-PAGING
30656906	MICROPHONE, SINGALONG
30699609	BUTTON-COIN RETURN
30699610	BUTTON-COIN RETURN
30699613	BUTTON-GREEN LISA
30702601	BAG-CASH
30702602	BAG-CASH, WP100
30728403	HORN
30743126	KEY CAP SET, '1-0' KYBD PB SW
30743203	KEY CAP, 'RESET' HORIZONTAL
30743205	PUSHBUTTON-RESET
30743206	PUSHBUTTON-POPULAR
30743207	KEY CAP, 'RESET' VERTICAL
30743208	KEY CAP, 'POPULAR' KYBD PB SW
30743701	COLLAR-COIN CHUTE
30745003	GUIDE-CARRIAGE
30749001	HOUSING-CAP (UNIV CONN 2 PIN)
30749002	HOUSING-CAP (UNIV CONN 3 PIN)
30749003	HOUSING-CAP (UNIV CONN 4 PIN)
30749004	HOUSING-CAP (UNIV CONN 6 PIN)
30749005	HOUSING-CAP (UNIV CONN 9 PIN)
30749007	HOUSING-CAP (UNIV CONN 15 PIN)
30749008	HOUSING-CAP (UNIV CONN 1 PIN)
30749101	HOUSING-PLUG (UNIV CONN 2 PIN)
30749102	HOUSING-PLUG (UNIV CONN 3 PIN)
30749103	HOUSING-PLUG (UNIV CONN 4 PIN)
30749104	HOUSING-PLUG (UNIV CONN 6 PIN)
30749105	HOUSING-PLUG (UNIV CONN 9 PIN)
30749106	HOUSING-PLUG (UNIV CONN 12 PIN)
30749107	HOUSING-PLUG (UNIV CONN 15 PIN)

30752701	PCB ASSY, DRIVER
30762306	SWITCH, SLIDE DPDT 110V 6A
30763103	BATTERY, RECHARGEABLE 2.4V
30763106	BATTERY-RECHARGEABLE
30763504	CON, HDR 6POS .250"CTR STRAIT
30781702	CUP-SLUG (BLACK)
30781802	CAM-SWITCH
30783101	CHUTE-SIDE
30783202	HINGE-CASH BOX (OBA)
30783302	MOTOR ASSY-STACKER
30783401	MOTOR & SWITCH ASSY
30783402	MOTOR & SWITCH ASSY
30783403	MOTOR & SWITCH ASSY
30785602	COVER-BILL BOX
30785701	SWITCH-ROCKER (SPST)
30785702	SWITCH-ROCKER (DPST)
30785703	ROCKER SWITCH (SPDT) MOM.
30785704	SWITCH-ROCKER (DPST)
30786201	SWITCH, SLIDE 4POS 2POLE 125V
30786202	SWITCH-SLIDE (SPDT)
30786203	SWITCH-SLIDE (DPTT)
30786204	SWITCH, SLIDE SPDT 125V
30788401	POTENTIOMETER-DUAL CONCENTRIC
30790401	GEAR-MAGAZINE
30790603	ROTATOR ASSY
30790701	PLATE-MOTOR MOUNTING
30790801	MOTOR & CRANK ASSY
30790901	PLATE-SWITCH
30791002	TRUNNION-MACHINED
30791302	SHAFT-MAGAZINE SUPPORT
30791402	SUPPORT & SPRING ASSY-MECH
30791502	SUPPORT ASSY-MECH
30793202	GUIDE-SPRAG LEVER
30793301	HUB-SPRAG WHEEL
30793402	CAM-SWITCH
30793901	PLATE ASSY-MOUNTING (SPRAG)
30794501	BRACKET-MTG (OPTICAL SWITCH)
30800204	IC-POWER AMPLIFIER
30800212	IC-TRANSISTOR ARRAY
30800214	IC, DUAL OP-AMP LOW PWR LM358
30800215	IC, QUAD OP-AMP 4741 DIP-14
30800216	IC, QUAD OP AMP LM324 DIP-14
30800217	IC, 8BIT A/D CONVERTER ADC0804
30800218	IC, FREQ TO VOLTAGE CONVERTER
30800228	IC, DUAL RECEIVER RS-422
30800229	IC, MOTOR DRIVER FULL BRIDGE
30800230	IC, DUAL DRIVER/RECEIVER RS422
30800232	IC, PAL 18 X 72 X 8 AND ARRAY
30800234	IC, DIGITAL/ANALOG CONVERTER
30800236	IC, REAL TIME CLOCK RTC72421
30800237	IC, DISPLAY DRIVER VAC FLU

30800238	IC, DUAL OP-AMP LOW NOISE 4558
30800240	IC-RS232
30800243	IC, UNDER VOLT SENSOR 34064P-5
30800244	IC, DUAL OP-AMP LINEAR SMD
30800245	IC, EEPROM 64 X 16 SERIAL
30800246	IC, 8-INPUT MICROCOMPUTER HCT
30800255	IC, DUAL USART CMOS 88C681
30800257	IC, PWM CONTROL CIRCUIT
30800262	IC, MICROCOMPUTER W/EPROM I/F
30800263	IC, EEPROM 128 X 16 SERIAL
30800264	IC, LED DISPLAY DRIVER MM5481N
30800265	IC, MICROPROCESSOR 8-BIT 300MW
30800277	IC - OP AMP
30800287	IC-OP AMP & VOLT REF LM10
30800295	HALF-BRIDGE DRIVER
30800334	MODULE-IR DETECTOR (5V)
30800336	IC, GAL PROGRAMMED
30800337	MICROPROCESSOR-INTEL FC CELERO
30800338	INTEGRATED CKT DIGITAL, CMOS
30800339	IC-IRDA TRANSCEIVER
30800342	IC-USB HUB CONTROLLER
30800343	IC-HIGH SIDE SWITCH SMD
30800345	IC-HEADPHONE AMP LM4808M SMD
30800350	IC-EEPROM 32K X 8 SERIAL
30800352	IC-OP AMP PWR
30832403	CABLE & PLUG ASSY-TONE ARM
30834201	POTENTIOMETER-W/SWITCH
30834506	CORD ASSY-POWER
30834509	CORD ASSY-POWER
30837101	SWITCH, KEYBOARD 12VDC
30850401	INLET-COIN
30857901	BRACKET-ADJUSTMENT
30858001	SUPPORT ASSY-FRONT PLATE
30858004	PLATE ASSY-FRONT
30858005	SUPPORT ASSY-FRONT PLATE
30858401	SIDE ASSY-SUPPORT
30858402	SIDE ASSY-SUPPORT
30858801	BAR ASSY-SLIDE
30858802	BAR ASSY-SLIDE
30859001	PLATE-COVER
30859002	PLATE-COVER
30859401	BALLAST-30W (60 HZ)
30859402	BALLAST-30W (50 HZ)
30859501	BALLAST-15W (60 HZ)
30859502	BALLAST-15W (50 HZ)
30866501	LENS-BROWN
30866502	LENS-BLUE
30866503	LENS-CLEAR
30866504	LENS-MAGENTA
30866505	LENS-RED
30866506	LENS-ORANGE

30866906	STRAP-PROTECTIVE (SIDE)
30868402	SCREEN-ENCLOSURE
30869801	HANDY CASE
30869802	HANDY CASE (CENTER HOLE)
30870901	KNOB-DUAL
30871901	HARNESS ADAPTOR (MICROPHONE)
30872301	MFAB ASSY, MTG PLATE & STUD
30873101	BATTERY, LITHIUM 3V BR2325 UL
30877401	CAM-BILL STACKER
30878101	MOTOR & PIN ASSY
30878501	BRACKET-LATCH
30878701	INSULATION, PAD 10-7/8"SQ CUT
30879201	HARNESS ASSY-MIC CONNECT
30879202	HARNESS ASSY MIC CONN (WP100)
30885401	HARNESS ASSY-MECH/COMPUTER
30891001	LABEL-BILL INSERTION
30897301	HARNESS-BGM VOL CONT/CD-100
30897401	HARNESS-POWER
30897403	HARNESS-POWER
30897404	HARNESS-POWER
30898401	DIFFUSER-TRIM
30900801	HARNESS ASSY-KEYBOARD
30901426	STRIP-NUMBER (COMPLETE SET)
30901802	DIFFUSER-LIGHT
30901803	DIFFUSER-LIGHT
30902302	HARNESS ASSY-COIN SWITCH
30902401	CARD-READOUT
30904501	PIVOT-SCAVENGE
30904602	CHUTE ASSY-COIN (UPPER)
30904603	CHUTE ASSY-COIN (UPPER) CD-51A
30904901	COIL & BRKT ASSY-SPEAKER
30905001	BRACKET-GUIDE
30905901	OPTICAL SW & CONN ASSY, MECH
30906101	BRACKET-HARNESS SUPPORT
30906503	HARN ASSY-DIGITAL DISPLAY
30906801	SWITCH ASSY-OPTICAL (R-90)
30911301	CARD-CD SELECTIONS
30911601	HARNESS ASSY-CD TO CCC
30911602	HARNESS ASSY-CD TO CCC
30912001	HARNESS ASSY-CD AUDIO
30913105	HARNESS ASSY-CD INTERNAL
30913203	HARN ASSY-CD EXT (CDP-C900)
30913204	HARNESS ASSY-CD EXTERNAL
30920101	WINDOW-DIGITAL DISPLAY
30920401	BRACKET-PIVOT (LH)
30921201	CARD-PRICE (US)
30921202	CARD-PRICE (US)
30921502	FRAME-LICENSE (WHITE)
30922101	CARD-READOUT (US)
30922626	STRIP-NUMBER (COMPLETE SET)
30922826	STRIP-NUMBER (COMP SET CD)

30923001	BLOCKOUT ASSY-COIN
30923102	BLOCKOUT-COIN INLET
30923201	DECAL-BLOCKOUT
30923202	DECAL -BLOCKOUT
30923801	KEY CAP, 'POPULAR' KYBD PB SW
30923805	KEY CAP, '>'(ARROW) KYBD PB
30923807	PUSH BUTTON-ARROW
30923901	KEY CAP, 'RESET' KYBD PB SW
30924001	BRACKET-MOUNTING (PIVOT)
30924101	BRACKET-MOUNTING (LOCK)
30924702	MTG BRACKET & BEZEL ASSY
30925101	CATCH-LOCK LEVER
30925201	HARNESS ASSY-KEYBOARD
30925301	HARNESS ASSY-BILL ACCEPTOR
30925401	RETAINER-BA BLOCKOUT
30925501	BLANK-TITLE STRIP
30925602	DECAL-COMPACT DISC
30925701	BRACKET-PIVOT (CD)
30926401	BEZEL-C.D.
30926502	HUB-C.D.
30926904	DISC-ANIMATION
30927426	STRIP-NUMBER (FULL SET 10 CD)
30928501	PWB-ANIMATION
30929201	SPACER
30929701	RETAINER-BEARING
30930001	CAM-HOLD DOWN
30930002	CAM-HOLD DOWN
30930003	CAM-HOLD DOWN
30930402	MAGNETIC RING-GOLD (HOLD DOWN)
30930501	HARNESS-CDM (PLAYER)
30930601	HARNESS-PLAYER CONTROL
30930701	HARNESS-CDM (SIGNAL)
30931002	SHAFT-COIN RETURN
30931101	LINK-SCAVENGE
30931301	CARD-PRICE (US)
30931302	CARD-PRICE (US)
30931303	CARD-PRICE (US)
30931304	CARD-PRICE (US)
30931307	CARD-PRICE (KARAOKE)
30931308	PRICE CARD
30931401	INSERT-BILL ACCEPTOR INLET
30931601	BRACKET-GUIDE (REJECT)
30931901	ACTUATOR-SLUG REJECTOR
30932101	BRACKET-MECH TIE DOWN
30932203	LEVER-MECH RELEASE
30932501	CONVERTER-DC-DC/AC
30932601	CLIP-CD TITLE PAGE
30933202	DISPLAY, VAC FLU 16-CHARACTER
30933204	DISPLAY, VAC FLU 16-CHARACTER
30933301	COUNTER & PLUG ASSY, MECH
30933302	COUNTER & PLUG ASSY, GEMSTAR

30933902	PAGE & CLIP ASSY
30933903	PAGE & CLIP ASSY (RED)
30933904	PAGE & CLIP ASSY
30934101	PANEL ASSY-AMPLIFIER
30934201	CABLE ASSY-AUDIO
30934203	HARNESS ASSY-AUDIO
30934204	HARNESS ASSY-AUDIO
30934208	HARNESS ASSY-AUDIO
30934211	HARNESS ASSY-AUDIO
30934212	HARNESS ASSY-AUDIO
30934217	CABLE ASSY-AUDIO 3 FT GOLD
30934218	CABLE ASSY-AUDIO 6 FT GOLD
30934219	CABLE ASSY-AUDIO (1/8")
30934401	BRKT-MTG (ANIMATION WINDOW) RH
30934501	BRACKET-MTG (WINDOW-UPPER)
30934601	BRACKET-MTG (WINDOW-LOWER)
30934701	PIVOT ASSY-GAS SPRING
30934802	CARD-READOUT (US)
30934803	CARD-READOUT (US)
30934902	CARD-SELECTOR GRAPHICS
30935001	GUIDE-CENTER (CD PAGE ASSY)
30935101	DECAL-B.A.INLET
30935102	DECAL-B.A. INLET
30935501	GUIDE-SIDE (CD PAGE ASSY)
30935601	DIFFUSER-LIGHT
30935602	DIFFUSER-LIGHT
30935903	BLANK-TITLE STRIP
30935904	BLANK-TITLE STRIP (W/O NUMBERS)
30935905	BLANK-TITLE STRIP
30936203	MOTOR-GEAR(DC) (TITLE PAGE)
30936301	MOTOR & GEAR ASSY
30936501	BRACKET-BALL STUD
30936702	SHAFT
30936901	PLATE ASSY-ANIMATION DRIVE
30937201	BRKT-ANIMATION MTG (UPPER)
30937301	BRKT-ANIMATION MTG (LOWER)
30938101	BRACKET-MTG (UPPER LH)
30938201	BRACKET-MTG (UPPER RH)
30938301	PLATE-CONNECTOR
30938501	HARNESS ASSY-INTERCONNECT
30938702	SWITCH-POWER
30938801	SWITCH-SERVICE
30938802	SWITCH-SERVICE
30938901	SWITCH-PAGE
30939001	BLOCKOUT-COIN INLET
30939301	ACTUATOR ASSY
30939401	DECAL-COIN BLOCK
30939402	DECAL-COIN BLOCK (CD-100A)
30939701	BRACKET-LIGHT BLOCK (LH)
30939801	BRACKET-LIGHT BLOCK (RH)
30940002	LABEL-WARNING (NARROW)

30940501	CARD-PRICE (SPANISH)
30940506	CARD-PRICE (ENGLAND)
30940601	FILLER-TITLE PAGE
30940701	LABEL-WARNING
30940801	BUMPER-PAGE
30941001	SPRING-HOLD DOWN
30941101	BRACKET-LIGHT BLOCK
30941401	BRACKET-HOLD DOWN (GRAPHICS)
30941801	HANDLE-TITLE RACK
30941802	HANDLE
30942102	XFMR, DUAL-SECONDARY DC-DC/AC
30942601	BRACKET-REJECTOR MOUNTING
30943001	DIFFUSER-LIGHT
30943201	BRACKET-HANGER
30943301	WINDOW-ANIMATION
30943501	BRACKET-WINDOW (B.A.)
30943901	COVER-OPENING
30944301	BRACKET-WINDOW (LH & TOP)
30944501	CARD-GRAPHICS (BILL ACCEPTOR)
30944601	CARD-GRAPHICS (DIGITAL DISPLAY)
30944701	CARD-GRAPHICS (KEYBOARD)
30944703	CARD-SELECTOR GRAPHICS(SPANISH)
30944704	CARD-SELECTOR GRAPHICS (GERMAN)
30944705	CARD-SELECTOR GRAPHICS (FRENCH)
30944707	CARD-SELECTOR GRAPHICS(ITALIAN)
30944708	CARD-GRAPHICS (KEYBOARD)
30944709	CARD-PRICE (KARAOKE)
30944710	CARD-SELECTOR GRAPHICS(HUNGARY)
30944712	CARD-GRAPHICS (MEXICO)
30945201	HARNESS-KEYBOARD
30945901	DECAL-BILL ACCEPTOR (WCD)
30946102	PWB-PRICE CARD
30946201	FILLER-TITLE RACK (BAG OF 50)
30946301	LATCH-BILL ACCEPTOR
30946501	PCB ASSY, PRINTER INTERFACE
30946901	SHIELD-OIL SPRAY
30947701	RETAINER-SCENE
30947801	RETAINER-PRICE CARD
30948001	DECAL-SELECTOR GRAPHICS (U.S.)
30948301	DECAL-B.A. BLOCKOUT (CD-51)
30948401	PANEL ASSY-AMPLIFIER
30948501	CARD-PRICE (CD-51)
30948502	CARD-PRICE (CD-51)
30948503	CARD-PRICE (US)
30948801	BRACKET-MOTOR MOUNTING
30948901	SHAFT
30949001	HUB-DISC
30949201	BEARING
30949301	DECAL-ROWE LOGO
30949303	DECAL-ROWE LOGO
30949901	BRACKET-PWB (LAMP MOUNTING)

30950004	HARNESS-SPEAKER
30950201	DIFFUSER
30950501	TRIM ASSY-GRILLE
30951202	PAD-ACOUSTICAL
30951203	PAD-ACOUSTICAL
30951501	SUPPORT-DOOR (LOWER LH)
30951701	HARNESS ASSY-FRONT DOOR LIGHTS
30952301	BRACKET-DOOR MOUNTING
30952401	BRACKET-COIN BLOCK
30952601	STOP-GRIPPER BOW
30952901	CARD-PRICE (SPANISH)
30952906	CARD-PRICE (ENGLAND)
30952916	CARD-PRICE (ENGLAND)
30953101	CARD-SELECTOR GRAPHICS
30953201	HOUSING (IR RECEIVER)
30953301	BRKT-MTG (IR REMOTE CONTROL)
30953701	TRIM ASSY-GRILLE (8 LAMP)
30953801	TRIM ASSY-GRILLE (4 LAMP)
30953903	CAP-END (COLOR TUBE)
30953904	CAP-END (RED)
30954201	TUBE-COLOR
30954202	TUBE-COLOR
30954203	TUBE-COLOR
30954701	PLATE ASSY-HOLD DOWN
30954901	SUPPORT ASSY-PWB
30955501	HARNESS-CDM-4 MOTOR
30955601	HARNESS-CDM-4 LASER
30955901	PCB ASSY, INTERFACE (CDM-4)
30956301	SUPPORT-DOOR
30956302	SUPPORT-DOOR
30956601	PLATE-SHIELD
30957603	TRIM-EDGE (GREY)
30958501	CARD-PRICE (U.S.)
30958502	CARD-PRICE (UNIVERSAL)
30958803	LINK-ACTUATOR (WALLETTE)
30958901	LINK-PIVOT
30959101	BACK ASSY-GRILLE
30959201	SCRIM-GRILLE
30959301	HARNESS ASSY-KEYBOARD
30959401	HARNESS ASSY-DIGITAL DISPLAY
30959901	BRACKET & LOCK ASSY-REJECT
30960001	STRIKE-LOCK
30960101	SWITCH ASSY
30960102	SWITCH ASSY-COIN (CD-51/CD100C)
30960301	RETAINER-TOP
30960401	RETAINER-TOP (RH)
30961701	PLATE ASSY-TITLE PAGE
30961801	BRACKET & STUD ASSY-TITLE PAGE
30962001	CARD-PRICE (SPANISH)
30962101	CARD-DIGITAL DISPLAY
30962201	BLOCKOUT-COIN INLET

30962302	DECAL-COIN INLET
30962401	BRKT-ANIMATION MTG (LOWER)
30962501	BRKT-ANIMATION MTG (UPPER)
30962601	PLATE ASSY-ANIMATION DRIVE
30962701	PANEL ASSY-AMPLIFIER
30963301	BRACKET-LIGHT
30963401	STRIKE
30963501	BRACKET-WINDOW (TOP & BOTTOM)
30963801	NAMEPLATE "ROWE AMI" CD100C
30963802	NAMEPLATE "ROWE AMI" CD100D
30964001	BRACKET-CORNER BRACE
30964101	RETAINER-ANIM WINDOW (LOWER)
30964401	BRACKET-GUIDE
30964601	KIT-MECHANICAL COIN ACCEPTOR
30964703	KIT-SLUG REJ.(NRI G-18 12VDC)
30964801	HOLDER ASSY-ACCEPTOR
30965001	LATCH-B.A.
30965101	BRACKET ASSY-MOUNTING (B.A.)
30965201	SUPPORT ASSY-B.A.
30965301	BRACKET ASSY-STOP/CATCH
30965701	WINDOW-SCENE
30965901	FRAME-SCENE (SIDE)
30966001	TRIM-WINDOW
30966101	WINDOW-REFLECTIVE
30966501	DECAL-B.A. BLOCKOUT
30966502	DECAL-B.A. BLOCKOUT
30966601	STOP/CATCH-TITLE RACK
30966701	BRACKET-SUPPORT (TITLE RACK)
30966801	BRACKET-WINDOW (LH)
30966901	BRACKET-WINDOW (RH)
30967001	CARD-DIGITAL DISPLAY
30967003	CARD-DIGITAL DISPLAY (SPANISH)
30967301	SCAVENGE ASSY
30967501	STRAP-DOOR SUPPORT
30967602	BRACKET-REINFORCEMENT(MTG PLAT
30968301	BRKT-DOOR MTG
30968401	HARNESS-COIN ACCEPTOR (NRI)
30968501	HARNESS-COIN ACCEPTOR (COINCO)
30968701	HARN-COIN ACCEPT(MARS/COIN CTL
30968801	BRACKET-SECURITY
30968901	TRIM-DOOR
30969101	FRAME-GRILLE (L.H.), CDRN
30969201	FRAME-GRILLE (R.H.), CDRN
30969301	PLASTIC-SIDE (RED)
30969501	PLATE ASSY-BLOCKOUT
30969601	DECAL-B.A. BLOCKOUT
30969701	DECAL-COIN INLET
30969801	STRAP-MTG (BUBBLE TUBE)
30970001	BRACKET-MOUNTING (LAMP)
30970301	PLATE-MTG UPPER (LAMP)
30970401	BRACKET-LAMP

30970601	BRACKET-DIGITAL DISPLAY (L.H.)
30970801	BRACKET-CLAMP (PILASTER L.H.)
30970901	DIFFUSER
30971001	BRACKET-PRICE CARD
30971201	TRIM-LOWER (TITLE RACK) CDRN
30971401	PIVOT-SLUG
30971501	LINK-PIVOT (SIDE)
30971701	LEVER-CBA RETENTION
30971801	BAR-PLASTIC TRIM
30972101	LOGO-GRILLE, CDRN
30972301	TUBE-COLOR
30972401	RETAINER-WINDOW (TR LOWER)
30972501	RETAINER-WINDOW (TR UPPER)
30972601	SCREEN-ENCLOSURE
30973001	CASTER
30973101	CASTER & CUP ASSY
30973201	BRACKET-MOUNTING (TRANSFORMER)
30973301	BRACKET-ACTUATOR
30973501	CLAMP-HEATER
30973601	BAIL
30973701	PULLEY-DRIVE
30974301	PLATE-RAMP
30974501	LINER-TOP
30974502	LINER TOP
30974801	DIFFUSER ASSY-LOGO
30975101	CLAMP-GRILLE
30975201	TRIM-SIDE (T.R. LH), CDRN
30975301	TRIM-SIDE (T.R. RH), CDRN
30975401	BRACKET-LAMP (INCAND)
30975901	DIFFUSER ASSY
30976001	BRACKET-MTG (COIN CHUTE)
30976101	HINGE-COUNTER COVER (NOST)
30976301	CLAMP-UPPER (LH)
30976401	CLAMP-UPPER (RH)
30976701	PLATE-HEATER
30976801	COVER-HEATER
30976901	PLATE ASSY-BA BLOCKOUT
30977601	GUARD-MOTOR
30978701	TURNBUCKLE
30979901	SUPPORT-BEARING (TITLE RACK)
30980001	SLIDE-RACK TITLE RACK
30980101	FINGER-TITLE RACK PAGE
30980401	BRACKET-TOP TITLE RACK
30980501	BRACKET HANGER TITLERACK (TOP)
30980801	DECAL-BLOCKOUTS
30981001	RETAINER-ANIM WINDOW (LOWER)
30981101	BRACKET-WINDOW (UPPER)
30981201	BRKT-WINDOW (LOWER)
30981301	BRACKET-WINDOW
30981501	NAMEPLATE "ROWE AMI" CD100E
30982101	BEARING-PLATE (DISC)

30982303	MOTOR
30982304	MOTOR
30982501	CARD-DIGITAL DISPLAY
30982503	CARD-DIGITAL DISPLAY (SPANISH)
30982504	CARD-DIGITAL DISPLAY (GERMAN)
30982505	CARD-DIGITAL DISPLAY (FRENCH)
30982507	CARD-DIGITAL DISPLAY (ITALIAN)
30982508	CARD-DIGITAL DISPLAY (PORT)
30982510	CARD-DIGITAL DISPLAY (HUNGARY)
30982601	BRACKET-GUIDE
30982701	CARD-PRICE
30982702	CARD-PRICE (BLANK)
30982703	CARD-PRICE (SPANISH)
30982705	CARD-PRICE (FRANCE)
30982708	CARD-PRICE (ENGLAND)
30982901	BRKT-MOTOR MTG
30983101	SLUG REJECTOR-3-1/2" IMONEX
30983102	SLUG REJECTOR-3.5" CHILE 100P
30983104	SLUG REJECTOR 25¢/\$1.00 IMONEX
30983501	RETAINER-TITLE RACK
30983601	BAR-LATCH (TITLE RACK)
30983701	DECAL INSERT-UPPER MMCD1
30983702	DECAL INSERT-UPPER MMCD2
30983706	DECAL INSERT-UPPER PSU
30983707	DECAL INSERT-UPPER OSU
30983710	DECAL-INSERT UPPER MMCD3 TEAL
30983711	DECAL-INSERT UPPER MMCD3 RED
30983801	DECAL INSERT-LOWER MMCD1
30983807	DECAL INSERT-LOWER OSU
30983810	DECAL-INSERT LOWER MMCD3 TEAL
30983811	DECAL-INSERT LOWER MMCD3 RED
30983901	DECAL-ROWE AMI MMCD1
30983906	DECAL-ROWE AMI PSU
30983907	DECAL-ROWE AMI OSU
30984001	DECAL-B/A BLOCKOUT
30984002	DECAL-B/A BLOCKOUT
30984005	DECAL-B/A BLOCKOUT(U OF M & I)
30984006	DECAL-B/A BLOCKOUT (P.S)
30984201	DECAL-TITLERACK LOWER MMCD1
30984204	DECAL-TITLERACK LOWER WA
30984206	DECAL-TITLERACK LOWER PSU
30984207	DECAL-TITLERACK LOWER OSU
30984301	RETAINER-BLOCKOUT
30984402	HOLDER ASSY-COIN MECH ADAPTER
30984404	HOLDER ASSY-COIN MECH
30984701	SWITCH-COIN
30984901	PLATE ASSY-FACE (CBA)
30985001	BRACKET-KEYBOARD SUPPORT
30985201	BRACKET-REINFORCEMENT
30985302	HARN ASSY-OUTPUT TRANSFORMER
30985701	RETAINER-LENS

30985901	PLATE-MOUNTING (SINGALONG)
30986002	BRACKET-SUPPORT REINFORCEMENT
30986101	CHUTE-FRONT COIN MECH
30986201	CHUTE-BACK COIN MECH
30986501	SUPPORT ASSY-MTG (B.A.)
30986601	DECAL & WINDOW ASSY-FRONT DOOR
30986602	DECAL & WINDOW ASSY (FR DOOR)
30986701	DECAL & WINDOW ASSY-LOWER
30986901	TRIM-WINDOW (TOP)
30987001	TRIM-WINDOW (SIDES)
30987201	RETAINER-LENS (CORNER)
30987301	RETAINER-LENS (END)
30987701	RETAINER-FRAME
30988001	HARNESS & SOCKET ASSY
30988301	BRACKET-MIC (KARAOKE)
30988501	POWER SUPPLY ASSY
30988901	BRACKET-BUTTON SUPPORT
30989101	BRACKET-COIN BLOCK MOUNTING
30989301	HARNESS ASSY-6 LAMP
30989601	HARNESS ASSY-VIDEO (INTERNAL)
30989901	PWB-BILL INLET LIGHTS
30990201	BRKT-COIN GUIDE
30990701	TRIM-EDGE (MMCD-1)
30990801	BALLAST (8W, 60 HZ)
30990802	BALLAST (8W 50 HZ)
30990901	BALLAST (18W, 60 HZ)
30990902	BALLAST (18W, 50 HZ)
30991201	PIN-CENTERING HUB
30991401	SOCKET-MINIATURE (BI PIN)
30991501	SHIELD-REJECTOR
30991901	PANEL & DECAL ASSY
30992001	BRACKET-MOUNTING (BA)
30992002	BRACKET-MTG (BA)
30992901	CARD-PRICE (US)
30992902	CARD-PRICE (US)
30992903	PRICE CARD-EXPORT
30993201	DECAL-BILL ACCEPTOR BLOCKOUT
30993501	BRACKET-WINDOW (TOP)
30993701	NAMEPLATE "EAGLE LASERSTAR"
30993901	DECAL-ROWE
30994001	DECAL-TOP (PRICE CARD)
30994002	DECAL-CENTER (BILL ACCEPTOR)
30994003	DECAL-BOTTOM (COIN INLET)
30994101	BAR-TRIM (CENTER)
30994102	BAR-TRIM (TOP)
30994401	LENS
30994901	HARNESS ASSY-PLAYER/VIDEO
30994902	HARNESS ASSY-CDM12 (CDV)
30995201	MICROPHONE-WIRELESS W/MODS
30995401	BRACKET-MOUNTING (BALLAST)
30995701	PIVOT-SCAVENGER

30996201	HOLDER ASSY-COIN MECH
30996701	RETAINER-WING
30996901	PWB-PRICE CARD
30998501	SEPARATOR-COIN CHUTE
30998701	CHUTE ASSY-MINI ADAPTER
30998801	HOLDER/ADAPTER-FULL TO MINI
30999402	BRKT-INDEX/HOME SWITCH F/G
30999501	SHAFT-DRIVE (TITLE RACK)
30999601	CRANK-GEAR ASSY
30999701	COVER-TITLE RACK LEVER
30999902	BRKT ASSY-MOTOR F/G
34000109	HOUSING-CAP (9CKT) MNL-DL
34000501	LIGHT ROPE ASSY
34000701	BRACKET,HINGE-FRONT DOOR
34001101	DECAL-BLOCKOUT
34001601	BRACKET-WINDOW UPPER
34001801	DECAL-ROWE AMI
34002001	BRACKET ASSY -PAGE ASSY (LH)
34002201	PWB-PRICE CARD
34002401	PLATE-MTG(END CAP)
34002601	CARD-AMI (LH)
34002701	CARD AMI (RH)
34002801	DECAL-SIDE (LH)
34002802	DECAL-VENUS (LH) (SILVER)
34002901	DECAL-SIDE (RH)
34002902	DECAL-VENUS (RH)
34003001	DECAL-COMPACT DISC,CD100F
34004001	BRACKET-LAMP (LH) CAB.
34004301	BRACKET-TITLE RACK HANGER
34004901	HOLDER-DISC
34005101	BRACKET-LAMP (RH) (CABINET)
34005201	BRACKET-LAMP (TOP DOOR)
34005301	PLUG & CORD ASSY-POWER (KOREA)
34006101	LABEL-TITLE RACK
34006102	LABEL-TITLE RACK
34006201	BRACKET-COIN SWITCH MTG
34006202	BRACKET-COIN SWITCH MTG(EAGLE)
34006801	PANEL-STARLIGHT GRAPHICS
34006901	PWB-4 LIGHT CURVE
34006902	PWB-6 LIGHT STRAIGHT
34006903	PWB-8 LIGHT STRAIGHT
34006904	PWB-5 LIGHT CURVE
34006907	PWB-2 LIGHT 2.63 CTR
34006908	PWB-4 LIGHT CURVE (RH)
34006927	PWB-2 LIGHT 2.63 CTR W/JUMPER
34007001	HARNESS ASSY-INLINE "G"
34007002	HARNESS ASSY-REVERSE "G"
34007102	TRIM-SIDE (LWR DOOR) ENCORE-1
34007201	BRACKET-HINGE (CABINET)
34007301	GLASS-STARLIGHT
34007401	PLATE ASSY (LH)

34007501	PLATE ASSY (RH)
34007601	BUTTON-REJECT
34007701	BEZEL-REJECT BUTTON
34007801	TRIM-LOWER (TOP DOOR)
34007802	TRIM-LOWER (TOP COVER)
34007901	BEZEL-B/A ADAPTER
34008001	BRACKET-B/A MOUNTING
34008101	PRICE CARD-(U.S.)
34008102	PRICE CARD-(U.S.)
34008103	PRICE CARD-(U.S.)
34008104	PRICE CARD-(ENG.)
34008105	PRICE CARD-(SPAIN)
34008110	PRICE CARD-(PORTUGUESE)
34008301	CHUTE-SLUG
34008401	BLOCKOUT-INFINITY (TOP)
34008902	CBA-LIGHT DISTRIBUTION
34009601	LAMP ASSY-MINI CD100G
34009701	FILTER-COLOR
34009702	FILTER-COLOR
34009801	BRACKET-COIN CHUTE MOUNTING
34010401	HARNESS-CDV DECODER (POWER)
34010501	HARNESS-CDV DECODER (SIGNAL)
34011101	HARNESS-CDV DECOD (2 WIRE SIG)
34011402	CBA-BGM RELAY
34012001	BELT-TIMING (WALLPHONO)
34012101	MOTOR ASSY-TITLERACK(WALLPHONO
34012102	MOTOR ASSY-TITLERACK
34012301	BRKT, MTG, COIN CHUTE
34012401	PUSHBUTTON-ALPHA SERIES
34012402	PUSHBUTTON-ALPHA SERIES
34012501	DIFFUSER-DISPLAY/KEYBOARD
34012701	CBA-IC 4739 SUBSTITUTE
34012801	MASK, MECHANISM, WP100
34012901	PRICE CARD (U.S.)
34012902	PRICE CARD (U.S.)
34012903	PRICE CARD (U.S.)
34012904	PRICE CARD (ENGLISH)
34012905	PRICE CARD (SPANISH)
34012911	PRICE CARD U.S.
34012912	PRICE CARD U.S.
34012913	PRICE CARD U.S.
34012914	PRICE CARD ENG
34012915	PRICE CARD SPANISH
34012921	PRICE CARD (U.S.) GOLD
34012923	PRICE CARD (U.S.) GOLD
34012934	PRICE CARD (U.S.)
34013001	KEYBOARD GRAPHIC,ENGLISH-WP100
34013002	KEYBOARD GRAPHICS (SPANISH)
34014201	BRKT-COIN CHUTE MTG
34014401	BRKT, FLUOR LAMP
34014502	BRKT-FLOURESCENT LAMP

34014601	DIFFUSER MECH WINDOW-WP100
34014901	CBA MODEM INTERFACE
34015201	RETAINER-WIRING
34015303	PWR SUPPLY-NEON (12VDC)
34015304	TRANSFORMER-POWER SUPPLY, DLW
34015401	STANDOFF-HANGER, WP100/DLW
34015501	SCREEN-AUDIO OUTPUT
34015601	LENS-NEON, WP100
34015602	LENS-NEON
34015801	PLATE ASSY-HOLD DOWN
34015901	COVER, DECORATIVE (CD MECH)
34016001	HARNESS-CCC TO CASHCODE INTF
34016101	PWR/PULSE HARNESS/BRAZIL 100G
34016501	RETAINER-WIRING
34016701	SOUND ENHANCEMENT-TDS
34016801	NAMEPLATE "TDS" CD100G
34017001	BEZEL-B/A ADAPTER
34017204	PLATE & STUD ASSY (NEW RED)
34017205	PLATE & STUD ASSY (PURPLE)
34017301	HUB-C.D.
34017401	SPINNER-C.D.
34017504	NEON POWER SUPPLY & BRKT ASSY
34018401	WINDOW-ANIMATION (CD100H)
34019201	FILTER-COLOR BLUE
34019202	FILTER-COLOR GREEN
34019205	FILTER-COLOR (LILAC)
34019305	DIFFUSER ASSY-KEYBOARD (LILAC)
34020201	DIFFUSER-LOWER DOOR
34020901	DIFFUSER, TOP DOOR (ENCORE)
34021101	BALLAST 13 WATT 60HZ
34021102	BALLAST 13 WATT 50HZ
34021301	BALLAST 18 WATT 26 INCH 60HZ
34021302	BALLAST 18 WATT 26 INCH 50HZ
34021401	BEZEL B/A ADAPTOR
34021901	PWR SUPPLY-240V AC BETA BRIGHT
34022301	HARNESS-MARS, CD100H
34022302	HARNESS-MARS (WP100)
34022304	HARN-MARS CD100I STUDIO SOUND
34022305	HARNESS-MARS (NOSTALGIA)
34022308	HARNESS ASSY - PULSE MARS
34022310	HARNESS ASSY-RLC TO MARS BA
34022311	HARNESS ASSY-MARS
34022312	HARNESS ASSY-MARS
34022401	BRKT-PIVOT
34022501	BEZEL-MARS CD100H
34023601	EDGE TRIM
34023801	BRKT-HINGE CABINET
34024101	BRKT-HINGE (LOWER DOOR)
34024501	LOCK BOLT
34024601	CRANK ANIMATION DISC
34024902	CD100I/J PRICE CARD (U.S.)

34024905	CD100I/J PRICE CARD (SPANISH)
34024911	CARD-PRICE
34025001	CARD-DIGITAL DISPLAY (ENGLISH)
34025002	CARD-DIGITAL DISPLAY (SPANISH)
34025011	DISPLAY CARD R.H. (ENGLISH)
34025012	DISP. CARD-RH,SPANISH-CD100I/J
34025101	TRIM-HORIZONTAL (TOP DOOR)
34025301	LAMP CONTROL ASSY
34025401	CARD-PRICE U.S.
34025411	CARD-PRICE (U.S.) ENCORE
34025901	BRKT-CARD RETAINER
34026802	HARN ASSY-SPKR-CD100K
34027001	PWB-STRAIGHT, LOWER ANIMATION
34027101	PWB-STRAIGHT, UPPER ANIMATION
34031001	LABEL-B.A. BLOCKOUT,CD100I/J
34031007	GRAPHICS-BILL BLKOUT,CD100K
34031101	LABEL-COIN INLET-CD100I/J
34031102	LABEL-COIN INLET
34031103	LABEL-COIN INLET, CD100K/IDL
34031401	BRKT-KEYBOARD ALIGN
34031601	BRACE, DIFFUSER
34031702	BRKT-DISPLAY GLASS RETAINER
34031801	BRKT, GLASS RETAINER
34032101	BRKT ASSY-PWB RETAINER
34032502	HARNESS COIN SWITCH, CD100K
34032601	HARN ASSY, PREAMP PWR
34032602	HARN ASSY-PREAMP POWER
34032603	HARNESS ASSY,PREAMP & MAIN PWR
34032605	HARN ASSY, AMP & MAIN PWR, DLW
34032606	HARN ASSY-PREAMP POWER
34032701	HARN ASSY, AMP PWR
34032802	HARNESS ASSY AMP XFMR-DUAL
34032804	HARN ASSY-DL-11 DUAL AMP XFMR
34032805	HARN ASSY-POWER XFMR
34032806	HARN ASSY-NETSTAR AMP XFMR
34032901	VOLUME CONTROL UNIT
34032903	VOLUME CONTROL UNIT
34033101	BRKT-LOCK SUPPORT
34033202	CABLE ASSY-RIBN CANCEL BUTTON
34033203	CABLE-RIBBON,SERV SWITCH,100K
34033204	CABLE ASSY-RIBBON,4 CH SERV SW
34033401	HARN ASSY-OUTPUT TRANSFORMER
34033901	COVER,TERMINAL (OUTPUT TRANS)
34034101	CBA-BUZZER
34034503	PLATE - TRANSFORMER MOUNTING
34034601	PLATE-COVER (AMP)
34034701	PLATE-COVER (AUDIO OUTPUT)
34034801	PLATE-COVER (REMOTE VOLUME)
34034902	HARN ASSY, MECH PWR/RL, CD100K
34035001	HARN, CBA-2/RBA-7(STUDIO SOUND
34035103	HARN ASSY, CROSSOVER-CD100K

34036201	HUB-CENTERING PIN
34036301	CD-PRO2 W/CENTERING HUB
34037901	CABLE ASSY-MOD, VCU
34037902	CABLE ASSY-MOD, A/V
34037905	CABLE ASSY-MOD, IR RCVR
34037907	HARNESS ASSY-RESET
34037908	CABLE ASSY-MOD, 100 FT
34037909	CABLE ASSY-MOD, VCU TO RLC
34037910	CABLE ASSY-MOD, IR RCVR TO RLC
34037912	HARNESS-RESET
34037913	HARNESS ASSY-RESET
34037915	CABLE ASSY-MOD
34038301	KID ASSY
34038401	MAGNETIC CARD READER-RS232
34038701	CABLE-DB9 SERIAL RL
34038702	CABLE-DB9 SERIAL ROWELINK 6 FT
34038804	HARNESS ASSY-PWR SUPPLY
34038902	HARNESS-MOD CARD READER
34039103	FAN-CHASSIS LED CONTROL,CD100K
34039201	MAG CARD RDR-RS232 ASSY
34039501	HEATSINK & FAN ASSY
34039502	HEATSINK & FAN ASSY
34039903	HARNESS ASSY-120V PWR, DLW
34039910	HARNESS - NEON INTERCONNECT
34040901	CBA-UPS INTERFACE
34041601	BALLAST - TWO LAMP 50/60 HZ
34042601	CBA-MONITOR OSD
34042902	TRANS ASSY-NEON,UNSHIELDED
34043501	MEDALLION "STARGLO", CD100K
34043601	MEDALLION "ROWE AMI", CD100K
34043901	BRKT-TITLE RACK LED
34044301	HARNESS-LED CTRL TO P.S,CD100K
34044401	HARNESS-110/220V TO P.S,CD100K
34045101	CBA-CROWN/PILASTER LED
34045601	PROXIMITY SENSOR ASSY
34046301	PLATE ASSY-PWR INLET
34046601	CBA-KEYBRD CD100K
34046701	PUSHBUTTON -"MY SONG FIRST"
34046801	LABEL-"MY SONG FIRST"
34046901	HARN ASM-AMP & MAIN PWR,CD100K
34046902	HARN ASSY-AMP & MAIN PWR 4 CH
35000201	DOOR-CHANGE
35000202	DOOR-CHANGE CUP (BC-1200)
35003201	CUP-COIN
35023307	BRACKET-MOUNTING (BA-50)
35025506	LEVER & BRACKET ASSY-LOCK
35025902	SUPPORT-TOP (INSIDE PANEL)
35026001	BRACKET ASSY-COIN ACCEPTOR
35026107	BRACKET & HARNESS ASSY-CA
35026111	BRKT & HARN ASSY-COIN ACCEPTOR
35026112	BRKT & HARN ASSY-COIN ACCEPTOR

35026114	BRKT & HARN ASSY-COIN ACCEPTOR
35026301	TRIM-SIDE (LH) BROWN
35026306	TRIM-SIDE (LH) (CHARCOAL BRN)
35026401	TRIM-SIDE (RH) VINT BROWN
35026402	TRIM-SIDE (RH) BLUE
35026406	TRIM-SIDE (RH) (CHARCOAL BRN)
35026801	DOOR-CHANGE
35027705	LOCKBAR ASSY
35027706	LOCKBAR ASSY
35027708	LOCKBAR ASSY (BC-12/12R)
35027709	LOCKBAR ASSY (BC-2R)
35027710	LOCKBAR ASSY-DOOR (BC-100)
35027711	LOCKBAR ASSY-DOOR (BC-100)
35027808	T-HANDLE ASSY(W/O LOCK CYL)
35028208	HARN & PLUG ASSY-COIN ACCEPTOR
35028211	HARNESS & PLUG ASSY-MINI ELECT
35028501	CUP ASSY-COIN
35031202	CHUTE-COIN
35031302	BACK-COIN CHUTE
35031602	BRACKET-COIN ACCEPTOR
35031702	MAGNET-LOCKOUT
35031704	LOCKOUT W/MAGNET 12 VDC
35031801	BRACKET & LOCK ASSY-COIN ACCEP
35031802	BRKT & LOCK ASSY-COIN ACCEPTOR
35032008	HARNESS ASSY-EMPTY LIGHT(BC-1)
35032009	HARNESS ASSY-EMPTY LIGHT(BC-12
35032203	CHUTE ASSY-SLUG
35032206	CHUTE ASSY-SLUG 1"
35032301	PANEL-INSTRUCT (COINS & BILLS)
35032804	BAR ASSY-PIVOT
35032905	BAR ASSY-SLIDE
35034406	SUPPORT ASSY-DOOR BC35/3500
35034907	HARNESS ASSY-UPPER TRACK
35035101	BRACKET-SHIELD
35035205	PLATE ASSY-SIDE (RH)
35035209	PLATE ASSY-SIDE (RH)
35035306	HARNESS ASSY-LOWER TRACK
35035307	HARN ASSY-LOWER TRACK (BC-2R)
35036001	PLATE ASSY-SIDE (LH)
35036003	PLATE ASSY-SIDE (LH)
35038203	TRIM-COIN INLET
35038204	TRIM-COIN INLET, BC1200
35038601	CHUTE-BILL
35038803	HANGER-FRONT
35039204	PLATE-PRESSURE
35039301	EDGE-CHUTE
35039305	EDGE-CHUTE (RH)
35039601	MOTOR & PIN ASSY
35043703	CHAIN-EXTENDED PIN
35043705	CHAIN-EX LONG EXTENDED PINS
35044502	GUIDE ASSY-INNER (COIN)

35044504	GUIDE ASSY-INNER (\$ COIN)
35044604	COVER-FRONT (W/LETTERING)
35044608	COVER-FRONT (W/LETTERING)
35044609	COVER-FRONT (W/LETTERING)
35044611	COVER-FRONT (W/LETTERING)
35044612	COVER-FRONT (W/LETTERING)
35044637	COVER-FRONT (W/LETTERING)
35044701	BRACKET-MOUNTING (HOPPER LH)
35044702	BRACKET-MOUNTING (HOPPER LH)
35044801	BRACKET-MOUNTING (HOPPER RH)
35044802	BRACKET-MOUNTING (HOPPER RH)
35045004	FRAME ASSY-BUCKET
35045101	DOOR ASSY-DIVERTER (LH)
35045201	DOOR ASSY-DIVERTER (RH)
35045301	DOOR-BUCKET
35045302	DOOR-BUCKET
35046401	BRACKET-MOUNTING (MOTOR)
35047101	SPACER-DRIVE
35047201	CAM-AGITATOR
35047202	CAM-AGITATOR (\$ COIN)
35047601	CHUTE ASSY-DISPENSER
35048003	BOX ASSY-ELECTRICAL
35048202	COVER-TERMINAL BOARD
35048501	GUIDE-CHAIN
35048801	BRACKET-TIE
35049002	HEAD-MAGNETIC (FULL TRACK)-OBA
35049102	MOTOR ASSY-DRIVE (HOPPER)
35049105	MOTOR ASSY-DRIVE (HOPPER)
35049201	PLATE-HOLD DOWN
35049307	LABEL-SERVICE (BC-35)
35049309	LABEL-SERVICE (BC-3500)
35049711	LABEL-HOPPER SERVICE
35050701	GUARD-SWITCH
35054902	PCB ASSY, TERMINAL
35058101	CAM-AGITATOR (Q,D,N, HOPPER)
35058102	CAM-AGITATOR (EX LG COINS)
35058203	SHIELD-TRANSPORT MOTOR
35058204	SHIELD-TRANSPORT MOTOR
35060501	PLATE & POST ASSY
35064901	BAR & PIN ASSY-LATCH
35065103	CRANK ASSY
35065803	CHUTE ASSY-COIN CUP
35065804	CHUTE ASSY-COIN CUP
35065806	CHUTE ASSY-COIN CUP (W/COVER)
35065807	CHUTE ASSY-COIN CUP (W/COVER)
35065901	STRAP & STOP ASSY-LH
35066004	HANGER BRKT & STOP ASSY (RH)
35066801	RELAY-POWER
35066802	RELAY, 4PDT 24V 10A COIL UL
35066803	RELAY-DPDT (30VAC COIL 30 AMP)
35066804	RELAY-DPDT (30VDC COIL 30 AMP)

35066810	RELAY-POWER (SPST)
35067902	BRACKET-MTG (STEPDOWN TRANS)
35068202	CHUTE ASSY-COIN (WELD)
35068203	CHUTE ASSY-WELD
35068302	PLATE-LOCK
35068501	CHUTE ASSY-SLUG
35069101	BRACKET-MOUNTING (BILL CHNGR)
35069201	BRACKET-COIN BOX
35072001	HANGER-REAR
35072101	HANGER-FRONT
35072102	HANGER-FRONT
35072201	MOTOR & CRANK ASSY
35072301	PLATE-MOTOR MOUNTING
35072401	LINK-DRIVE
35072402	LINK-DRIVE
35072501	PLATE-PUSH
35072701	BRACE-BOTTOM
35072801	EDGE-CHUTE
35073001	CHUTE ASSY-COIN
35074101	LOCKBAR ASSY
35074201	TOP ASSY-LARGE HOPPER
35074325	DECAL-CHANGE ID (\$1 BILL)
35074329	DECAL-CHANGE ID (\$1 & \$5 BILLS
35074330	DECAL-CHANGE ID (\$1 BILL)
35074331	DECAL-CHANGE ID (\$1 & \$5 BILL)
35074332	DECAL-CHANGE ID (\$1 OR \$5 BILL
35074333	DECAL-CHANGE ID (BC-1 \$5)
35074334	DECAL-CHANGE ID (BC-1 \$1)
35074401	CHUTE ASSY-COIN BOX
35074801	PLATE ASSY-FRONT (BUCKET)
35075401	LEVER ASSY-ANTI CHEAT
35077301	HARNESS ASSY-SINGLE STACKER
35077302	HARNESS ASSY-DOUBLE STACKER
35077303	HARNESS ASSY-SINGLE STACKER
35077304	HARNESS ASSY-DOUBLE STACKER
35077305	HARNESS ASSY-SINGLE STACKER
35077306	HARN ASM-SGL STK-BC100/150/200
35078101	SUPPORT-MOUNTING (PANEL)
35078501	SUPPORT ASSY-SIDE
35078701	BRACKET-MOUNTING
35078901	GLASS ASSY-CHANGE
35078902	GLASS ASSY-TOKENS
35079101	TEMPLATE-DRILL
35079601	BRACE-ANGLE (FRONT DOOR)
35079701	COVER-TOP FILLER
35079902	PWB-REFLECTIVE SENSOR (OBA)
35079903	PWB-REFLECTIVE SENSOR (DIEBOLD)
35079904	PWB-REFLECTIVE SENSOR
35079905	PWB-REFLECTIVE SENSOR
35079906	PWB-REFLECTIVE SENSOR (WBA-50)
35079907	PWB-REFLECTIVE SENSOR (WBA-50)

35080001	SHAFT-DRUM PULLEY
35080002	SHAFT-TAKE UP
35080003	SHAFT-PULLEY, BA50
35080004	SHAFT-ROLLER (TAKE UP) BA50
35080101	PULLEY
35080301	ROLLER-TAKEUP
35080302	ROLLER-FLAT
35080304	ROLLER-TAKE UP
35080501	ROLLER ASSY-LOWER INPUT
35080603	ROLLER ASSY-PRESSURE
35080604	ROLLER ASSY-PRESSURE
35080605	ROLLER ASSY-PRESSURE (NYLON)
35080701	CKT BD & BRACKET ASSY
35080702	CKT BD & BRACKET ASSY
35080801	SHAFT ASSY-DRIVE
35080903	BELT-DRIVE, CBA
35081301	BRACKET-CIRCUIT BOARD (SHORT)
35081602	SPRING-TORSION
35082001	BELT-TIMING, OBA
35082002	BELT-TIMING
35082004	BELT-TIMING, CBA
35082005	BELT-TIMING (210 TOOTH), BA50
35082007	BELT - TIMING (210T BA50)
35082010	BELT-TIMING
35082202	HOLDER-MAG HEAD
35082301	SHAFT-TOP
35082502	BASE ASSY-OBA CONTROL
35082503	BASE ASSY-OBA CONTROL
35082601	SPRING-PRESSURE ROLLER, OBA
35082801	CORD ASSY-POWER
35082904	INLET & STUD ASSY
35083004	TRACK-LOWER, OBA
35083701	BRACKET-WIRE HOLDING
35083801	LIGHTBLOCK
35083804	LIGHTBLOCK
35084201	SUPPORT-REAR (STACKER)
35084202	SUPPORT-REAR (STACKER)
35084301	BRACKET-LOCK
35084801	GUIDE-FRAME (STACKER)
35085101	BRKT-HOPPER HOLD DOWN
35085201	COVER-CONTROL BOX
35085501	SHIELD & HINGE ASSY
35085502	SHIELD & HINGE ASSY (BC-2RC)
35085503	SHIELD & HINGE ASSY
35085701	RAIL ASSY-GUIDE (LH)
35085702	RAIL ASSY-GUIDE (BC-2R)
35085801	RAIL ASSY-GUIDE (RH)
35086605	BRKT ASSY-MTG (OBA TRANSP)BC-1
35087203	KIT-BASE BC12/1200 BLUE
35087205	KIT-BASE BC12/1200 BLACK
35087213	KIT-BASE BC12/1200 CHAR BROWN

35087216	KIT-BASE BC100 BLACK
35087301	BRACKET-ANTI CHEAT
35087405	KIT-FILLER BC12/1200 BLACK
35087413	KIT-FILLER BC12/1200 CHAR BR
35087416	KIT-FILLER BC100 BLACK
35087524	KIT-ACCESSORY INSTALL (BC-100)
35087701	MOTOR ASSY-STACKER
35087801	MOTOR & SWITCH ASSY
35087901	PLATE-COVER
35088101	PLATE & STUD ASSY
35088201	COUNTER ASSY-VEND
35088210	COUNTER ASSY
35088301	FRAME & STUD ASSY
35088501	SENSOR & COIN ASSY
35088602	LIGHTBLOCK & REFERENCE ASSY
35090501	BRACKET,SPACER & PIN ASSY
35090605	CASTING, PLATE & HARNESS ASSY
35090608	CASTING,PLATING & HARNESS ASSY
35090802	SHROUD-CHANGE BUCKET
35091001	SUPPORT & CHUTE ASSY
35091201	LIGHTBLOCK & CATCH ASSY
35092001	PLATE-PRESSURE
35093701	MOTOR & SWITCH ASSY
35093901	MOTOR ASSY
35094601	PULLEY-DRUM, CBA/RBA
35095001	GEAR-REDUCTION
35095102	PULLEY-16 TOOTH, CBA/RBA
35095403	INSERT-TRIM (TOP FILLER/BLACK)
35096101	PLATE-PRESSURE
35096402	LEVER-ANTI CHEAT, OBA
35096404	LEVER-ANTI CHEAT (BA-50)
35097201	HASP ASSY-DOOR GUARD
35097402	SHAFT ASSY-ANTI CHEAT LEVER
35097501	SHAFT ASSY-CROWNED ROLLER
35097601	SHAFT ASSY-CREASING ROLLER
35097701	SHAFT ASSY-RING
35097801	SHAFT ASSY-PRESS & CRWN ROLLER
35097901	PLATE ASSY-SIDE (LH)
35098001	PLATE ASSY-SIDE (RH)
35098101	SHAFT ASSY-TAKE UP ROLLER
35098901	BRACKET-GUARD (MOTOR)
35098902	BRACKET-GUARD (DISP MOTOR)
35099403	TRACK & PRESSURE ROLLER ASSY
35099404	TRACK & PRESSURE ROLLER ASSY
35099701	SWITCH ASSY
35099801	HOLDER & STUD ASSY-HEATER
350A0499786200	CON, HDR 14POS 90DEG SHRD
350A2648107100	CON, HDR 7POS .156"CTR BRKAWAY
35104002	GUIDE - OUTPUT DRIVE
35110301	SPRING-BILL BOX
35110601	HARN ASSY-UPPER TRACK (BC-2R)

35110701	PLATE ASSY-TRIM (BA) BC-2R
35110801	LATCH ASSY-HOPPER (BC-2R)
35110901	OVERLAY-CHUTE
35111101	CHUTE & STUD ASSY
35111401	BRKT-THERMOSTAT MTG (BC-12R)
35111901	BRACKET-INPUT SHAFT (CBA)
35112301	RETAINER-MAG HEAD HOLDER
35112501	PCB ASSY, ELECTRICAL INTERFACE
35113601	SHAFT ASSY-DRIVE
35114001	BRACKET-SPRING
35114401	GEAR-DRIVE
35114501	SHAFT & PULLEY ASSY
35114701	HARNESS-POWER & CREDIT
35114901	BELT-DRIVE (UPPER) BA-50
35116401	PLATE ASSY-PRESSURE
35116901	DOOR-CHANGE CUP (BC-100)
35116902	DOOR-CHANGE CUP (BC-150)
35117001	ROLLER ASSY-PRESSURE
35117002	ROLLER ASSY-PRESSURE (NYLON)
35117701	SPRING-TORSION
35117901	BRACKET ASSY-TOP
35118501	HARN & BRACKET ASSY-MAG AMP
35118601	BELT-DRIVE, OBA
35118701	BILL-BOX (150 BILL) PLATED
35118801	HARNESS ASSY-TRANSPORT (BA-50)
35118802	HARNESS ASSY-TRANSPORT (BC-100)
35118803	HARN ASSY-DISP JUMPER (BA-50)
35118804	HARN ASSY-STKR JUMPER (BA-50)
35118805	HARN ASSY-BILL TRANSPORT(BA-50)
35118901	INSERT-WINDOW (BA-50)
35119101	BRACKET-LEGEND WINDOW (LED)
35119201	PCB ASSY, LEGEND WINDOW
35119501	HEATSINK & SOCKET ASSY
35119601	HARNESS ASSY-HEATSINK (BC-100)
35119701	HEATSINK & HARN ASSY (PCC)
35119902	DECAL-CHANGE ID (\$1,\$5,\$10)
35119903	DECAL-CHANGE ID (\$1,\$5,\$10,\$20)
35119904	DECAL-CHANGE ID (\$1,\$5,\$10)
35119905	DECAL-CHANGE ID (\$1,\$5,\$10,\$20)
35119906	DECAL-CHANGE ID (\$1 & \$5)
35119907	DECAL-CHANGE ID (\$1 \$5 \$10)
35120201	COVER ASSY-MAG AMP
35120701	HARNESS ASSY-EMPTY LIGHT
35120801	GUIDE-PWB (BC-3500)
35121301	HARNESS ASSY-POWER (CBA-2)
35121501	BRACKET-MTG (COIN CUP)
35121601	COVER-COIN CUP (BC-1400)
35122001	COVER-OPENING (COIN CUP)
35122801	PLATE-LOCK
35123101	JUNCTION BOX ASSY (BC2RC)
35123201	HARNESS-DISP.(JUMPER)(BC-2RC)

35123501	JUMPER-EXTERNAL (CBA-4)
35123503	HARNESS ASSY-CBA-4 ROWELINK
35123504	HARNESS ASSY-CBA4 INTERCONNECT
35123602	DECAL-\$1 & \$5 (BC1200)
35123603	DECAL-\$1 & \$5 (BC100 & 150)
35124101	DECAL-CHANGE ID (\$1 BILL)BC100
35124102	DECAL-CHANGE ID (\$1 BILL)BC100
35124401	PCB ASSY, CBA2 CONVERSION
35124501	HARNESS ASSY-CBA-2 CONVERSION
35124502	HARNESS ASSY-CBA-2 CONVERSION
35125401	LATCH ASSY-HOPPER
35126501	LEVER-ANTI PULL BACK (BA-50)
35127401	HARNESS ASSY-CBA-2
35127403	HARNESS ASSY-RBA-7
35127404	HARNESS ASSY RBA7
35127406	HARN ASSY-CBA4 INTERFACE
35127407	HARN ASSY-CBA-2 INTERFACE
35127408	HARNESS-RBA-7 INTERFACE
35127409	HARNESS-RBA7 B. CHGR
35127421	HARNESS ASSY-CBA4
35127423	HARNESS-RBA-7 INTERFACE(EXACTA
35127601	PCB ASSY, INTERCONNECT CBA4
35128601	SPRING-INPUT SHAFT
35128701	ROLLER ASSY-PRESSURE
35128901	PLATE ASSY-SIDE (LH RBA)
35129001	PLATE ASSY-SIDE (RH RBA)
35129101	BRACKET ASSY-TOP
35129201	LABEL-BILL 1/2/5/10/20/50/100
35129202	LABEL-BILL,RBA 1/2/5/10/20
35129203	LABEL-BILL, RBA 1/2/5/10
35129204	LABEL-BILL, RBA 1/2/5
35129205	LABEL-BILL, RBA 1
35129401	STOP-BILL (WITH HOLE)
35130003	HARNESS & SENSOR ASM-UPPER RBA
35130004	HARNESS & SENSOR ASM-LOWER RBA
35130101	HEAD-MAGNETIC, RBA
35130401	PLATE-PRESSURE
35130502	SHIELD-LIGHT
35131102	FILTER & LUG ASSY,SBC/C CHGRS
35131301	CORD ASSY-POWER
35131402	LOCKBAR ASSY-DOOR SBC2
35131403	LOCKBAR ASSY-DOOR
35131404	LOCKBAR ASSY-DOOR (NSBC-6)
35131405	LOCKBAR ASSY-DOOR (NSBC-8)
35131406	LOCKBAR ASSY (NSBC-10)
35132801	PLATE-ELECTRICAL BOX
35133201	BRACKET-STACKER LOCKDOWN
35133501	PLATE ASSY-CATCH
35133701	DECAL PACK
35133703	DECAL-\$1,\$5
35133704	DECAL-\$1,\$5,\$10

35133705	DECAL-\$1,\$5,\$10,\$20
35133801	LABEL(1,5,10,20 VARIATIONS)
35134401	CKT BD ASSY-INTERFACE (CTA)
35134501	LABEL-BILL INSERTION (FACE UP)
35134502	LABEL-BILL INSERTION (FACE UP)
35134701	MFAB, BRACKET UPPER TRACK
35135601	CAM-STACKER (LONG STROKE)
35135701	BILLBOX-SAFEGUARD(400B,1 LOCK)
35135703	BILLBOX-SAFEGUARD (1000 SL)
35135902	CBA-BC35 ADAPTER
35142801	BRKT-CONTACT MTG (DISPENSER)
35142901	BRKT-CONTACT MTG (HOPPER)
35143501	BRKT-CONNECTOR (BA)
35143502	BRKT-CONNECTOR (NSBC-6)
35143601	TRIM PLATE-COIN INLET
35143602	TRIM PLATE (NSBC6, NO COIN)
35143701	BRKT-ACTUATOR (NSBC-6)
35143901	DECAL PACK
35143902	DECAL-\$1, \$5
35143903	DECAL-\$1,\$5,\$10
35143904	DECAL-\$1,\$5,\$10,\$20
35143905	DECAL PACK
35143906	DECAL-\$5,\$10 (C6-CAN)
35143907	DECAL-\$5,10,20 (C6-CAN)
35144601	WIRE-BAIL
35145201	CBA-OBA4 PIGGY BACK
35145202	CBA-OBA2 ADAPTOR SNGL
35147001	CKT BD ASSY-BCX00 EPROM REPLAC
35147004	CKT BD ASSY-BCXX W/O EPROM
35147011	CBA-BCX00 EEPROM NEW AMP
35147101	HARNESS ASSY-RBA7/EXACTA
35147301	BLOCK-ANTI PULL BACK, BA50
35171501	SPACER-DOOR GUARD MTG
35172901	BAR-TORSION
35173901	COVER-CIRCUIT BOARD
35174601	HARNESS-CASHCODE ADAPTOR
35174801	LABEL-1 & 5 (BC100)
35174802	LABEL-1,5,10,20 (BC150)
35174804	LABEL-\$1,5,10 (BC100)
35175101	DECAL-TOKENS
35175102	DECAL-TOKENS
35176328	SOCKET-DUAL ROW, .1 CTR RA
36528003	MOTOR ASSY-TRANSPORT (BA)
36528004	MOTOR & CONTACT ASSY
36535512	COVER & MANUAL ASSY-SHOP (R90)
36536501	CORD ASSY-POWER
37003601	HARNESS ASSY-BA ADAPTOR
37004001	DECAL-TOKENS
37004002	DECAL-CHANGE
40242601	MOUNT ASSY-AMPLIFIER
40242603	MOUNT ASSY-AMP

40264401	TRANSFORMER-PWR SPLY (WALLBOX)
40527605	FRAME-CASH BOX DOOR
40546201	TRIM-TOP
40546602	KNOB
40633502	TRANSFORMER
40633503	TRANSFORMER-OUTPUT, 1000W AMP
40633606	TRANSFORMER ASSY-OUTPUT (120W)
40689101	POWER SUPPLY ASSY (SS)
40702808	RAIL-SKID
40702810	RAIL-SKID
40702811	SKID RAIL
40710105	PCB ASSY, DRIVER
40710106	CBA-DRIVER
40710303	HEATSINK, 250W AMP
40711302	MOTOR-BILL STACKER
40712402	PLATE ASSY-MOUNTING
40712603	CARRIAGE ASSY(OBA BILL STK LH)
40712604	CARRIAGE ASSY(OBA BILL STK RH)
40712702	COVER ASSY-REAR
40712703	COVER ASSY-REAR
40714905	SPRING-PNEUMATIC
40714908	SPRING-PNEUMATIC
40714910	SPRING-PNEUMATIC
40714911	SPRING-PNEUMATIC
40714912	SPRING-PNEUMATIC, ENCORE
40720102	SEPARATOR-RECORD MAGAZINE
40720201	GUIDE-BELT
40720202	GUIDE-BELT
40720401	GEAR-CAM
40720502	GEAR-SECTOR
40720601	GEAR-TRUNNION
40720703	GRIPPER BOW & TRUNNION ASSY
40720802	CAMSWITCH & MOTOR ASSY
40720901	MOTOR-CAM
40721303	GUIDE ASSY-GRIPPER BOW
40721801	PLATE-MOUNTING (INTERMEDIATE)
40721901	SPRAG ASSY
40722301	WHEEL-SPRAG
40722701	MOTOR-MAGAZINE
40722901	PLATE-MOUNTING (SPRAG)
40731002	SPEAKER-LOW FREQUENCY
40731003	SPEAKER-WOOFER
40731004	SPEAKER-LOW FREQUENCY
40732802	POWER CONTROL BOX-REMOTE
40733102	HEATSINK & PWR TRANSISTOR ASSY
40737806	TRANSFORMER-POWER
40737807	TRANSFORMER-POWER, HOME JUKES
40737811	TRANSFORMER-POWER
40737812	TRANSFORMER-POWER, 250W AMP
40737813	TRANSFORMER-PHONO PWR SUPPLY
40737815	TRANSFORMER-AUDIO OUTPUT

40737816	TRANSFORMER-LAMP CONTROL
40737817	TRANSFORMER-POWER
40737826	TRANSFORMER-POWER
40737831	TRANSFORMER-POWER
40737833	TRANSFORMER-POWER
40737841	TRANSFORMER-POWER, CD100K
40742701	GRILLE-LH
40742801	GRILLE-RH
40742902	TRANSFORMER
40745301	TRIM-PUSHBUTTON
40745303	TRIM-PUSHBUTTON
40767201	PCB ASSY, OBA STACKER
40769304	BILL-BOX ASSY-RIVET
40769307	BILL-BOX ASSY-RIVET
40770612	POWER SUPPLY-MAIN (120 VAC)
40777005	BOX ASSY-CASH (LH 500 BILL)
40777008	BOX ASSY-CASH (RH 500 BILL)
40777010	BOX ASSY-CASH (OBA-4 1000 BILL)
40782103	SPEAKER ASSY-WOOFER
40782202	SPEAKER-MIDRANGE (HIGH FREQ)
40783703	MODULATOR-RF
40787007	MTG BRKT & EXTENSION ASSY
40788901	BATTERY, LITHIUM 3V 1/2A
40791002	CKT BD ASSY-RELAY
40791206	MOTOR & HARN ASM-STKR-CBA/RBA
40797001	PCB ASSY, VOLUME CONTROL
40797301	CIRCUIT BOARD ASSY-STACKER
40797701	MFAB, BRKT MOUNTING UNV CBA2
40797702	MFAB, BRACKET MOUNTING CBA2
40800601	INLET-COIN
40802301	SHROUD-PHONO (OBA)
40807601	PCB ASSY, CD INTERFACE
40807603	PCB ASSY, CD INTERFACE
40820601	INLET-COIN
40820602	INLET-COIN
40820603	INLET-COIN
40821101	WINDOW-TOP
40821201	CONTROL ASSY-LAMP
40821901	SPEAKER ASSY (LH)
40822001	SPEAKER ASSY (RH)
40822702	DECAL-DECORATIVE (LH BLUE)
40823101	POWER SUPPLY (CBA)
40824201	PWB-C.D. ANIMATION
40824302	MOTOR & HARNESS ASSY
40824303	MOTOR & HARN ASM-CD100F ANIM.
40830002	HARNESS ASSY-CD MECH
40830003	HARNESS-CD MECH
40830201	BASE-DECODER
40830301	COVER-MECH CONTROL
40830401	TRANSFORMER-CD PLAYER
40830701	SPEAKER-WOOFER

40830702	SPEAKER-WOOFER
40830704	SPEAKER-WOOFER
40830803	SPEAKER-MIDRANGE (6")
40830805	SPEAKER-MID RANGE
40830806	SPEAKER-MID FREQ
40830901	SPEAKER-TWEETER (3")
40830903	SPEAKER-CELLULAR HORN
40831001	PFAB, HOLDER READOUT
40831201	SUPPORT-COIN CHUTE & REJ MECH
40831303	TRIM-SIDE
40831702	HOLDER-PRICE CARD
40831801	INLET-COIN
40831802	INLET-COIN
40832101	TRANSFORMER ASSY
40832102	TRANSFORMER ASSY
40832104	TRANSFORMER ASSY-OUTPUT
40832105	TRANSFORMER ASSY-OUTPUT
40832106	TRANSFORMER ASSY-OUTPUT
40832107	TRANSFORMER ASSY-OUTPUT
40832108	TRANSFORMER ASSY-OUTPUT
40832220	PCB ASSY, CENTRAL CONTROL COMP
40832225	PCB ASSY, CENTRAL CONTROL COMP
40832227	CCC ASSY-KUNIC (2 LAYER BRD)
40832242	CBA-WALLBOX (4 LAYER) WALL SEL
40832302	PCB ASSY, DISPLAY DIGITAL
40832303	DIGITAL DISPLAY ASSY
40832901	HARNESS ASSY-110V (60HZ)
40833401	HARNESS ASSY-DIGITAL DISPLAY
40833802	RACK-C.D. TITLE PAGE
40833803	RACK-C.D. TITLE PAGE
40833805	RACK-CD TITLE PAGE (SHORT)
40834101	WINDOW-ANIMATION
40834501	HARNESS ASSY-TOP DOOR LIGHT
40834701	GUIDE-CENTER (CD PAGE)
40834801	SUPPORT-DISC
40834901	GEAR
40835302	BRACE-MOUNTING
40835401	STRIP-NUMBERS (PAGE)
40835602	SWITCH ASSY-SERVICE
40835605	SWITCH ASSY-SERVICE
40835606	SWITCH ASSY-SERVICE
40836303	BLOCKOUT-BILL ACCEPTOR
40836502	SWITCH ASSY-SERVICE
40836801	KIT-KEYPAD & DISPLAY
40837102	TRIM & STRIKE ASSY
40837401	PCB ASSY, DIODE BIAS
40837701	COVER-UPPER (TITLE PAGE ASSY)
40837702	COVER-LOWER (TITLE PAGE ASSY)
40837901	TRANSFORMER
40838102	PCB ASSY, POWER SUPPLY
40838602	BRACKET-SUPPORT

40838702	BRACKET ASSY-MOUNTING
40839401	PCB ASSY, KEYBOARD
40839402	PCB ASSY, KEYBOARD
40839403	PCB ASSY, KEYBOARD
40839404	PCB ASSY, KEYBOARD
40839405	KEYBOARD
40839406	KEYBOARD ASSY
40839407	KEYBOARD
40839408	KEYBOARD ASSY
40839409	KEYBOARD W/KEYCAPS-CD100I/J
40839901	SHIELD-CASH BOX
40840201	DECAL-COMPACT DISC (WCD)
40840501	BEZEL-B.A. (WCD)
40840902	BRACKET ASSY-WALLMOUNT (WPHONO
40841801	PCB ASSY, DISPLAY DIGITAL
40842002	BLOCKOUT-BA (CD-51)
40842101	HARNESS ASSY-DIGITAL DISPLAY
40842201	PCB ASSY, KEYBOARD
40842301	WINDOW & DECAL ASSY
40842401	SUPPORT & STRIKE ASSY
40842501	HARNESS & BALLAST ASSY (50HZ)
40842502	HARNESS & BALLAST ASSY (60HZ)
40842902	CHUTE-SLUG (CD-51A)
40843001	PANEL ASSY-AMPLIFIER (TOP)
40843102	SCRIM-FRONT DOOR (MMCD-100)
40843301	TRIM-SIDE
40843303	TRIM-SIDE (MMCD-100)
40843601	TRIM EDGE - SILVER CD-51
40843602	TRIM-EDGE (GOLD)
40843801	PLATE-MOUNTING (SPEAKER LH)
40844301	PWB-LAMP MOUNTING
40844401	DECAL-DIFFUSER
40844403	DECAL-DIFFUSER
40844501	WINDOW-DECORATIVE
40844601	INSERT-GRILLE TRIM
40844603	INSERT-GRILLE TRIM
40844701	TRIM-BILL ACCEPTOR
40844801	INLET-BILL
40845501	PWB-LAMP
40846001	COVER-KEYBOARD (WATER RESIST)
40846202	PCB ASSY, INFRARED RECEIVER
40846302	RCVR ASSY-IR
40847402	BRACKET-MTG (PAGE SPRING)
40847501	HINGE-HOLD DOWN (CD PLAYER)
40848102	CKT BD ASSY-POWER SUPPLY
40848301	KNOB
40850201	PCB ASSY, PWR BD CD WALLETT
40850502	HOLDER ASSY-PAGE (UPPER)
40851002	PCB ASSY, INTERFCE COIN ACCEPT
40851101	HOLDER-PRICE CARD
40851201	TRIM-KEYBOARD

40851301	INLET-COIN
40851401	BEZEL-REJECT KNOB
40851501	FRONT-COIN CHUTE
40851601	BACK-COIN CHUTE
40851701	KNOB & SHAFT ASSY-REJECT
40851901	GRILLE-SPEAKER
40852001	WINDOW, WALLETTE
40852201	PCB ASSY, DIGITAL DISPLAY
40852301	OVERLAY-SHELF
40852402	DECAL-COMPACT DISC
40852501	BRACKET-SLUG REJECTOR
40853702	HARN ASSY-COIN ACCEPTOR (MARS)
40853901	INLET-COIN
40854001	INLET-BILL
40854002	INLET-BILL
40854003	INLET BILL (BLUE)
40854004	INLET-BILL (GREEN)
40854005	INLET-BILL (GOLD)
40854006	INLET BILL (RED)
40854201	WINDOW-ANIMATION
40854301	HARN ASSY-110V (60HZ)CD100D
40854401	BLOCKOUT-BILL ACCEPTOR
40854501	CHUTE ASSY-COIN
40854601	SCRIM-FRONT DOOR
40854602	SCRIM-FRONT DOOR
40854801	BRACKET-MOUNTING (LAMP RH)
40855001	DIGITAL DISPLAY W/MT
40855002	PCB ASSY, DIGITAL DISPLAY W/MT
40855003	DIGITAL DISPLAY ASSY
40855101	HARNESS ASSY-DIGITAL DISPLAY
40855103	HARNESS-DIGITAL DISPLAY
40855201	HARNESS ASSY-TOP DOOR LIGHTS
40855301	DIFFUSER-LIGHT (LOWER)
40855302	DIFFUSER-LIGHT (LWR FLUTED)
40855401	FILTER-COLOR (DECAL)
40855402	FILTER-COLOR (DECAL)
40855501	MFAB, PLATE MNTING DIG DISPLAY
40855601	HOLDER, DISPLAY 16-CHR VAC FLU
40855602	HOLDER, DISPLAY 16-CHR VAC FLU
40855701	DECAL-COMPACT DISC
40856101	INTERFACE ASSY-TITLE RACK
40856301	CHUTE-SLUG
40856401	PCB ASSY, CD WALLBOX CONCENTR
40856801	HARNESS ASSY-PWR/ROWELINK
40857001	PCB ASSY, DUAL PHONO INTERCONN
40857101	HARNESS-INTERNAL (DUAL PHONO)
40857401	PCB ASSY, HOME UNIT POWER SUP
40857501	TRIM-BOTTOM (GRILLE)
40857601	TRIM-SHELL, CDRN
40857701	BUBBLE TUBE-STRAIGHT
40857801	BUBBLE TUBE-CURVED (OUTER)

40857901	BUBBLE TUBE-CURVED (INNER)
40858001	PLASTIC-CENTER (TOP)
40858101	WINDOW-DOOR
40858201	HARNESS ASSY-110V (CABINET)
40858401	PANEL-MECH (LH)
40858501	PANEL-MECH (RH)
40858602	CHUTE ASSY-SLUG (CD-RN)
40858701	CHUTE ASSY-COIN (LOWER)
40859001	PLATE-LOCKBAR
40859301	RETAINER-WINDOW (LOWER)
40859401	BRACKET ASSY-CBA (NOSTALGIC)
40859601	BRACKET ASSY-MOUNTING (CBA)
40859801	CHUTE ASSY-COIN INLET
40860201	SUPPORT-TITLE RACK
40860202	SUPPORT-TITLE RACK (R.H.)
40860301	FILTER-LIGHT
40860401	MOTOR-PAGE
40860601	BRACKET ASSY-MOTOR
40861401	ACCEPTOR-3 COIN (IMONEX)
40861402	ACCEPTOR-COIN (QUARTER ONLY)
40861405	ACCEPTOR-COIN (MECH \$1/25)
40861701	HARNESS ASSY-110V (DOOR)
40861901	DIFFUSER-ARCH LIGHT (LH)
40862001	DIFFUSER-ARCH LIGHT (RH)
40863001	PCB ASSY, DIODE BIAS
40863101	DIODE ASSY-W/WIRES (BIAS)
40864601	CHUTE ASSY-COIN
40864702	RACK-TITLE RACK
40864801	BRACKET-MOTOR-TITLERACK
40865001	HARNESS ASSY-110V
40865301	SCRIM-FRONT DOOR
40865501	DOOR FRAME-TOP
40865502	DOOR FRAME TOP
40865701	DOOR FRAME-CENTER
40865801	DOOR FRAME-SIDE
40865902	BRACKET-B.A./COIN,MMCD
40865903	BRACKET-B.A. MTG
40866002	CHUTE-TOP HALF
40866003	CHUTE-BOTTOM HALF
40866601	SUPPORT-DOOR (UPPER LH)
40866801	WINDOW-ANIMATION
40866901	GLASS, TOP DOOR CD100E
40867101	INLET-COIN
40867301	SUPPORT-DISC
40867401	PWB-ANIMATION 4 LIGHT
40867501	INLET-BILL
40867801	LENS-DIAMOND
40867802	LENS-DIAMOND
40868001	BRKT-LIGHT/DISPLAY
40868301	DECAL-WINDOW MMCD1
40868302	DECAL-WINDOW MMCD2

40868306	DECAL-WINDOW PSU
40868307	DECAL-WINDOW OSU
40868901	PCB ASSY, VIDEO SINGALONG
40868903	CBA-SINGALONG AUDIO PAN (CDV)
40869101	BASE-AUDIO INTERFACE
40869402	SCAVENGE ASSY-MINIMECH
40869501	SINGALONG-VIDEO INTERFACE
40869502	SINGALONG-AUDIO PAN (CDV)
40869601	INTERFACE-AUDIO (SINGALONG)
40869702	CONTROL ASSY-LAMP
40869801	FRAME & STRIKE ASSY
40869802	FRAME AND STRIKE ASSY
40869803	FRAME & STRIKE ASSY (MMCD3)
40869901	DECAL-COMPACT DISC
40870201	PLATE-MIC (KARAOKE)
40870501	HARNESS ASSY-MARS 330 (MINI CA
40870601	HARNESS ASSY-COIN CONTRLS C120
40870701	HARNESS ASSY-MIC/COIN S5 M CA
40870801	HARNESS ASSY
40870803	HARNESS ASSY-COIN MECH KITS
40871401	HARNESS ASSY-PLAYER/VIDEO
40871501	HARNESS ASSY-VIDEO/SINGALONG
40871601	HARNESS ASM-CD MECHANISM
40871701	PAGE-CLEAR PLASTIC
40871801	BINDER-CUSTOM W/PAGES
40872101	BAR-SUPPORT (TOP 23.63)
40872102	BAR-SUPPORT (BOTTOM 24.63)
40872201	DECAL-TITLERACK UPPER MMCD1
40872205	DECAL-TITLERACK UPPER MI
40872206	DECAL-TITLERACK UPPER PSU
40872801	HINGE-DOOR (EAGLE)
40873021	FILLER-SINGALONG
40873701	POWER SUPPLY-MAIN
40874001	CASH BOX ASSY
40874301	WINDOW & DECAL ASSY
40874701	WINDOW-LAMPS
40874801	FILM-REFRACTOR
40875001	LENS-SHORT
40875101	LENS-LONG
40875301	TRANSFORMER ASSY
40875401	SCAVENGER ASSY
40875601	POWER SUPPLY (220VAC)
40875801	BLOCKOUT-DOOR
40875901	SWITCH & VOLUME CONTROL ASSY
40875903	SWITCH & VOLUME CONTROL ASSY
40875907	SWITCH & VOLUME CONTROL ASSY
40875909	SWITCH & VOLUME CONTROL ASSY
40875915	SWITCH & DUAL TERM BLOCK ASSY
40876002	LIGHT BLOCK
40876101	DECAL-COMPACT DISC,EAGLE
40876401	RETAINER-TOP HOUSING

40876501	RETAINER-PWB-LAMPS
40876801	FILTER-COLOR WING (LH)
40876901	FILTER-COLOR WING (RH)
40877001	COVER-LIGHT (LONG)
40877101	MOTOR-TITLE RACK
40877301	SUPPORT-BEARING CD100
40877401	SLIDE-PAGE TRAP CD100
40877502	CONTROL LAMP
40877701	PCB ASSY, CBA-LAMP CONTROL
40877901	BRACKET,MTG.-FRONT DOOR
40878001	TRIM,LEFT-FRONT DOOR
40878101	TRIM,RIGHT-FRONT DOOR
40878201	TRIM,CENTER LEFT-FRONT DOOR
40878301	TRIM,CENTER RIGHT-FRONT DOOR
40878302	TRIM-CENTER (FRONT DOOR)
40878401	TRIM,LOWER-FRONT DOOR
40878402	TRIM-LOWER (FRONT DOOR)
40878501	TRIM,CENTER-FRONT DOOR
40878601	COLUMN,INSIDE-FRONT DOOR
40878602	COLUMN-INSIDE (FRONT DOOR)
40878701	COLUMN,OUTSIDE-FRONT DOOR
40878801	TUBE ASSY,COLOR,LEFT-FRONT DR
40878901	TUBE ASSY,COLOR-RIGHT-FRONT DR
40878902	TUBE ASSY-COLOR (R.H.) (RED)
40879001	POWER SUPPLY-MAIN (120 VAC)
40879002	POWER SUPPLY-MAIN (120V)
40879008	POWER SUPPLY-MAIN 120 W/LF
40880201	HARNESS & BALLAST ASSY
40880501	INLET-BILL
40880601	INLET-COIN
40880801	CHUTE ASSY-COIN
40881101	TRIM-WINDOW LH
40881102	TRIM-WINDOW (LH)
40881201	TRIM-WINDOW RH (GOLD)
40881202	TRIM-WINDOW (RH)
40881301	BRACKET-SCAVENGE
40881401	BRACKET-PIVOT (LH)
40881402	BRKT-PIVOT
40881501	BRACKET-PIVOT (RH)
40881502	BRKT-PIVOT
40881801	SUPPORT ASSY-TITLE RACK
40881802	SUPPORT ASSY-TITLERACK
40882101	FILTER-COLOR
40882201	FILTER-COLOR
40882501	LATCH,DISPLAY-TOP DOOR
40882801	SHAFT-ANIMATION
40883001	DIFFUSER-ANIMATION
40883201	SIDE-HOUSING (RH)
40883801	HARN ASSY-TITLE RACK
40884001	STIFFENER-LOWER (TOP DOOR)
40884301	LABEL-VENUS

40884302	LABEL-CALIENTE (TITLE RACK)
40884306	LABEL-STARGLO
40884501	GUSSET (RH)
40885401	ROWELINK HUB ASSY
40890401	GRILLE-SPKR LH 100G
40890501	GRILLE-SPKR RH 100G
40890901	INLET, BILL
40890902	INLET-BILL
40891201	TRIM-BOTTOM (LOWER DOOR)
40891202	TRIM-BOTTOM LOWER DOOR
40891501	PLUG-COIN INLET
40891601	DIFFUSER-TOP DOOR
40891701	INLET-COIN
40891702	INSERT-COIN
40891703	INSERT-COIN (BLUE)
40891704	INSERT-COIN (RED)
40891801	BRACKET-B/A ADAPTER,GUIDE
40891901	HARNESS & BALLAST ASSY (60HZ)
40892101	LAMP CONTROL
40892401	HOLDER DIGITAL DISPLAY
40892701	BRACKET-WINDOW (UPPER)
40893002	CHUTE-COIN INLET
40893101	ANIMATION ASSY-CD100G
40893301	SCREEN-ENCLOSURE
40893501	INLET-COIN (GREEN)
40893502	INLET COIN (BLUE)
40893503	INLET COIN (DARK GREEN)
40893504	INLET COIN (GOLD)
40893601	DOOR FRAME-HORIZONTAL
40893701	DOOR FRAME-CENTER
40893801	DECAL-WINDOW MMCD-3
40894001	WINDOW & DECAL ASSY MMCD-3
40894201	CVR & HANGER ASSY(CDV DECODER)
40894503	INTERFACE ASSY-PAL CDV DECODER
40894504	INTERFACE ASSY-NTSC CDV DECODE
40895101	BEZEL-ADAPTER (CBA)
40895102	ADAPTER-BEZEL (MARS)
40895201	BRKT-B/A MTG (CBA)
40895301	CAP, TOP CORNER, WP100
40895302	CAP, TOP CORNER, (GOLD)
40895401	CAP, BOTTOM CORNER (LH) WP100
40895402	CAP BOTTOM (LEFT) (GOLD)
40895501	CAP, BOTTOM CORNER (RH)
40895502	CAP, BOTTOM (RIGHT) (GOLD)
40895601	LENS, DOOR (CLEAR)
40895602	LENS DOOR (SILVER)
40895603	LENS, DOOR (GOLD)
40895701	BRACE, BOTTOM DOOR
40896101	END PLATE-TITLERACK(WALLPHONO)
40896401	CASH BOX ASSY
40896701	DISPLAY MODULE-LIQUID CRYSTAL

40896901	MOTOR-TITLE RACK,WP100
40897001	COVER-NEON
40897002	COVER-NEON
40897003	COVER-NEON (LONG) (WP100SYM)
40897004	COVER-NEON (SHORT) (WP100SYM)
40897101	CAM-KNOB WALLBOX
40897201	CHASSIS-POWER SUPPLY (WP100)
40897301	POWER SUPPLY-WALL PHONO
40897801	KEYPAD & DISPLAY ASSY (MMCD3)
40898301	BALLAST ASSY
40898701	HARNESS-DOOR (WP100)
40898710	HARNESS ASSY-120V DOOR, DLW
40898901	CHUTE-COIN INLET (WALLBOX)
40899101	COVER ASSY-AUDIO OUTPUT
40899401	TRANS ASSY-AUDIO OUTPUT
40899801	BAR, DETENT
40899803	BRKT-DETENT 700 BILL
40899901	BULB, NEON (BLUE) SHORT
40899902	BULB-NEON (GREEN) SHORT
40899903	BULB-NEON (SHORT, GOLD)
40899904	BULB-NEON (SHORT) (RUBY RED)
40900101	BULB, NEON (LONG)
40900102	BULB-NEON (GREEN) (LONG)
40900103	BULB-NEON (LONG, GOLD)
40900502	BRKT-SWITCH ACTUAT & NEON TRAN
40900504	BRKT-SWITCH ACTUATOR
40900601	BRKT-SWITCH MTG
40900801	MIRROR-SIDE WALL, WP100
40900901	BACK PANEL-DECORATIVE, WP100
40901101	SWITCH & VOLUME CONTROL ASSY
40901102	SWITCH CONTROL ASSY
40901201	BLOCK, LIGHT
40901701	CBA-AUX PAGER INTERFACE
40902001	COVER-SWITCH & VOLUME CONTROL
40902101	BRKT-B/A MTG
40902401	BLOCKOUT ASSY (WP100A) (WOOD)
40904003	KEYBOARD-TOUCHPANEL W/LED
40904701	COUNTER ASSY WP100
40904801	COUNTER ASSY SELECTOR
40907501	FRAME ASSY-MARS CD100H
40907601	BRACKET-MARS BA RETRO (ENCORE)
40908002	TRIM CURVED (PILASTER) (LH)
40908502	LIGHT ASSY (PILASTER) (LH)
40908601	LIGHT ASSY (PILASTER) R.H.
40908602	LIGHT ASSY (PILASTER) (RH)
40908902	TRIM-BOTTOM (LOWER DOOR)
40909201	GRILL-LOWER DOOR, IDL/CD100I
40909401	SHAFT-DISC SUPPORT
40909501	CRANK ANIMATION MOTOR
40909606	HARN & BALLAST ASSY 60HZ
40909617	HARNESS & BALLAST ASSY (60 HZ)

40909620	HARN ASSY-BALLAST 3 WAY
40909802	CBA-IR RCVR
40910102	HINGE-DISPLAY (CD100I & J)
40910501	GLASS, TOP DOOR CD100I/J
40910601	DIGITAL DISPLAY ASSY
40910603	DIGITAL DISPLAY ASSY
40911002	CHUTE-COIN INLET
40911101	TRIM-SPEAKER (TWEETER)
40911401	BRKT-DISPLAY PIVOT
40912004	HARNESS-110V CABINET
40912005	HARNESS-110V, CABINET
40912301	SHAFT WELD ASSY
40912401	BRKT-CBA
40912903	FILTER-COLOR, IDL BLUE
40912904	FILTER-COLOR, IDL RED
40913102	HARN ASSY-ANIM. INTERCONN
40913201	LENS, POCKET LIGHT (L.H.)
40913301	LENS, POCKET LIGHT (R.H.)
40913302	LENS, POCKET LIGHT
40913601	PWB-FLEX, LOWER ANIMATION
40913701	PWB-FLEX, UPPER ANIMATION
40913801	GLASS-LOWER ANIMATION, CD100I
40913802	GLASS-LOWER GRAPHICS, CD100I/J
40913804	GRAPHICS PANEL (LOWER)-IDL MEX
40913807	GLASS-LOWER GRAPHICS (DL-11A)
40913901	GLASS-UPPER ANIMATION-CD100I/J
40913903	GRAPHICS PANEL (UPPER)-IDL MEX
40914401	LATCH SUB ASSY, DISPLAY
40914601	CBA-TITLE DISPLAY
40914901	DIFFUSER,LWR TOP DOOR-CD100I/J
40915401	BRKT KIT (MARS)
40915501	BRKT-B/A ADAPTER BEZEL (MARS)
40916001	DECAL & WINDOW ASSY ENCORE 2
40916101	BLOCKOUT-BILL
40916801	MARS BRKT ASSY-WP100
40916901	FILTER-TITLERACK(TOP) BLUE
40916902	FILTER-TITLERACK(TOP) YELLOW
40916903	FILTER-TITLE RACK TOP ORANGE
40917101	TRANSFORMER ASSY-SINGLE AMP
40917102	TRANSFORMER ASSY DL-11 AMP
40917104	TRANSFORMER ASSY (CD100K)
40917202	POWER SUPPLY
40917401	A/V CONTROLLER-4 CHANNEL
40917601	CENTRAL CONTROL COMPUTER
40917602	CENTRAL CONTROL COMPUTER
40919201	CLIP-PWB MOUNTING
40919701	PIVOT BRKT-LATCH ASSY
40920501	DIGITAL DISPLAY & KID ASSY
40922001	BIB & LENS ASSY-LWR DOOR(DL-11
40922201	LIGHT & BRKT ASSY-LWR DOOR BIB
40922503	PWR SUPPLY UNIV. 60W 5V CD100K

40922504	PWR SUPPLY-ATX
40922710	TOUCHSCREEN-ELO 19"
40922801	HARNESS-120V POWER, CD100K
40923001	CBA-SWITCHES
40923201	CBA-COIN INTERFACE
40923403	CBA-UNIVERSAL PWR SUPPLY 120V
40923405	CBA-UNIVERSAL PWR SUPPLY
40924001	BRKT-MONITOR MOUNT LH
40924101	BRKT-MONITOR MOUNT RH
40924204	SINGLE BD COMPUTER
40924301	COVER-CARD READER
40924401	UPS-OFFICE 350
40925801	BASE-ROWELINK CONTROLLER
40925901	COVER-ROWELINK CONTROLLER
40926001	ROWELINK CONTROLLER ASSY
40927201	LABEL-POWER REMOVAL
40927401	UPS-525SL
40927601	CHUTE-COIN, DOOR
40927602	CHUTE-COIN, DOOR
40927701	CHUTE-COIN, CABINET
40927702	CHUTE-COIN, CABINET
40929101	CBA-MONITOR INTERFACE
40929302	STRAP-UPS MTG W/LABEL
40929601	COVER-KYBD, CD100K
40929701	DISPLAY MODULE-16 CHAR. VF
40929901	BRKT-CROWN LED (CENTER)
40930101	HINGE DISPLAY/KEYBOARD-CD100K
40930201	WINDOW, MAIN-CD100K
40930801	CBA-PWR SUPPLY
40930901	COVER-LED CONTROL
40931001	BASE-LED CONTROL
40931101	LED ASSY-CONTROL
40931401	TRIM-LOWER DOOR
40931701	SHAFT-W/A, B/A BRKT
40932001	BRKT-PILASTER RETAINER,(LH)BTM
40932101	BRKT-PILASTER RETAINER,(RH)BTM
40932901	HARNESS ASSY-PWR SUPPLY
40933001	COVER, IR CONTROL
40933101	IR VOL CTRL 2CH PREAMP
40934401	BRKT-CABINET TRIM, TOP (LH)
40934501	BRKT-CABINET TRIM, TOP (RH)
40935401	FRAME ASSY - W/LATCH
45013401	TRIM-COIN INLET
45016203	TRIM-FRONT (CAB SHELF)
45016509	DOOR ASSY-WELD (BLUE)
45016512	DOOR ASSY-WELD (WHITE)
45016514	DOOR ASSY-WELD (CHARCOAL BRN)
45016710	INLET & CHUTE ASSY-COIN
45019001	CUP-SLUG
45030201	CARRIAGE ASSY
45030501	BRACKET ASSY-MOTOR

45030701	BRACKET-MOTOR
45030901	FRAME-BILL STACKER
45031102	HARNESS ASSY-BILL STACKER
45031103	HARNESS ASSY-BILL STACKER
45031501	TOP-COIN HOPPER
45031902	SLIDE ASSY-OUTER (COIN)
45031903	SLIDE ASSY-OUTER (\$ COIN)
45032101	BAFFLE PLATE-COIN
45032102	BAFFLE PLATE-COIN
45032401	SIDE ASSY-LH COIN (HOPPER)
45032402	SIDE ASSY-LH (COIN HOPPER)
45032403	SIDE ASSY-LH (COIN HOPPER)
45032501	SIDE ASSY-RH (COIN HOPPER)
45032503	SIDE ASSY-RH (COIN HOPPER)
45032607	BUCKET ASSY-CHANGE (DISPENSER)
45032614	BUCKET ASSY-CHANGE (BC-100/200)
45032615	BUCKET ASSY-CHANGE (BC-3500)
45032616	BUCKET ASSY-CHANGE (BC-1400)
45033305	FRAME-BUCKET (PLATED)
45033801	CRANK-MOTOR
45033901	GUIDE-CASH BOX
45034001	COUPLING-RATCHET
45034103	MOTOR-HOPPER DRIVE
45034204	AGITATOR-BEVELED
45034205	AGITATOR-COIN
45034301	SIDE-CASH BOX (LH)
45034601	BOX ASSY-CASH
45034603	BOX ASSY-CASH
45034604	BOX ASSY-CASH
45035001	CHUTE ASSY-COIN
45035005	CHUTE ASSY-COIN (HOPPER)
45035006	CHUTE ASSY
45035307	FRAME & PIVOT ASSY
45035308	FRAME & PIVOT ASSY
45035311	FRAME & PIVOT ASSY
45035312	FRAME & PIVOT ASSY
45035313	FRAME & PIVOT ASSY_DISPENSER
45035601	SPROCKET
45042601	GUARD-DISPENSER MOTOR
45042602	GUARD-DISPENSER MOTOR
45048004	TRIM-BA & COIN CUP
45048005	TRIM-COIN CUP
45048008	TRIM-BA & COIN CUP
45048009	TRIM-BA & COIN CUP
45048203	PCB ASSY, COIN SWITCH
45048904	LABEL-SERVICE
45048908	LABEL-SERVICE (BC-100)
45048909	LABEL-SERVICE (BC-1400)
45048910	LABEL-SERVICE (BC-200)
45048911	LABEL-SERVICE (BC-1200)
45049501	TRANSFORMER-POWER

45049502	TRANSFORMER-POWER
45049503	TRANSFORMER-POWER
45049505	TRANSFORMER-POWER
45049901	COVER-POWER CONTROL BOX
45050501	BOX ASSY-COIN
45052401	HARNESS ASSY-DOUBLE STACKER
45052501	FRAME-SUPPORT
45052601	CHUTE ASSY-SEPARATOR
45052701	COVER-CIRCUIT BOARD
45052802	BRACKET-MTG (LOWER BILL BOX)
45053301	BOX ASSY-COIN
45053701	MFAB, BASE CONTROL COMPUTER
45054201	LATCH ASSY-HOPPER
45054301	BOX ASSY-COIN (LOCKING)
45054501	SUPPORT-COIN BOX
45055603	TRANSFORMER-POWER (120V)
45055801	TRACK-UPPER
45056501	DECAL-CHANGE
45056502	DECAL-TOKENS
45057102	HARNESS ASSY-UPPER TRACK
45057505	CONTROL UNIT-OBA
45057509	CONTROL UNIT-OBA-2
45057517	CONTROL UNIT-OBA
45057520	CONTROL-OBA2 NEW \$5
45057521	CONTROL-OBA2 NEW \$5
45057522	CONTROL-OBA2 NEW \$5
45057523	CONTROL-OBA2 NEW \$5
45057601	HARNESS-INTERCONNECT
45057604	HARNESS ASSY-INTERCONNECT
45057610	HARNESS-INTERCONNECT (OBA-4)
45057613	HARNESS-INTERCONNECT(WHIP DRK)
45057618	HARNESS ASSY-INTERCONNECT
45057621	HARNESS-INTERCONNECT (OBA-4)
45057702	PLATE-SIDE (LH)
45057801	PLATE-SIDE (RH)
45058202	HARNESS ASSY-LOWER (OBA)
45058203	HARNESS ASSY-LOWER
45058205	HARN & BD ASSY-LWR REFL, BA50
45058206	HARNESS ASSY-LOWER, OBA4
45058208	HARN & BOARD ASSY-UPPER SENSOR
45058210	HARNESS ASSY-LOWER
45058404	MOTOR ASSY (OBA-4) (W/SHIELD)
45058407	MOTOR ASSY
45058408	MOTOR ASSY-BA-50 (W/ENCODER)
45058409	MOTOR ASSY-CBA-4/RBA-7
45058501	GEAR-REDUCTION
45058607	MOTOR ASM-DC, CBA/UBA TRANSPRT
45058803	HARNESS ASSY-HEAD & CELL
45059201	TRANSFORMER & HARNESS ASSY
45059203	TRANSFORMER & HARNESS ASSY
45059209	TRANSFORMER & HARN ASSY (OBA-4)

45059501	HARNESS & LAMP ASSY
45059803	HARNESS & HOLDER ASSY (OBA-4)
45060002	CHUTE ASSY-COIN CUP
45060301	HARNESS ASSY-LOWER
45060403	HARNESS ASSY-HEAD & CELL, OBA
45060501	HARN ASSY-BILL STACKER(CKT BD)
45060502	HARN ASSY-BC1 STACKER
45060802	GUIDE-PLATE (BC-2R)
45060803	GUIDE-PLATE (CONT COMP)
45060901	FRAME-MOUNTING (BA)
45060902	FRAME-STACKER (BA)
45061001	BOX ASSY-POWER CONTROL
45062001	T-HANDLE ASSY (MEDECO OR TUBAR
45062002	T-HANDLE ASSY(TUBAR OR MEDECO)
45062201	MOTOR-BILL STACKER
45062308	HARNESS ASSY-DC BILL STACKER
45062310	HARNESS ASSY-OBA-4 STACKER
45062601	PLATE-CKT BD MOUNTING
45063301	SPACER-DIODE
45063707	STAND ASSY-BILL ACCEPTOR
45064201	PLATE-FRONT (OBA)
45065801	LEVER-ANTI CHEAT
45065901	COVER ASSY-LOCKING MECH
45067102	DECAL-DOOR (\$1/\$5 PLATINUM)
45067112	DECAL-DOOR (\$1 PLATINUM)
45067907	CONTROL UNIT-CBA (ROWE)
45068301	BEZEL-COMPACT BILL ACCEPTOR
45068901	BILL-BOX ASSY
45069002	HARNESS & CELL ASSY-UPPER, CBA
45070004	HARNESS ASSY-INTERCONNECT
45070201	HARNESS ASSY-INTERCONNECT
45070203	HARNESS ASSY-INTERCONNECT
45070302	HARN&PLUG ASM-AUX HTR,RL CHGRS
45072101	BAFFLE & STUD ASSY
45072102	BAFFLE & STUD ASSY
45072201	COVER-CONTROL BOX
45072802	CKT BD ASSY-MAG AMP (BA50/70MM
45073001	PCB ASSY, INTERCONNECT (BA-50)
45073002	CKT BD ASSY-INTERCONNECT
45073101	HEAD & HOLDER ASSY
45073102	HEAD & HOLDER ASSY-CANADA
45073201	HARN & BRD ASM-INLET&LEDS,BA50
45073202	HARNESS ASSY-INLET SENSORS
45073301	HARNESS & BOARD ASSY-MAG AMP
45073302	HARNESS ASSY-MAG AMP
45073502	HARNESS & CELL ASSY-LOWER
45073506	HARNESS & CELL ASSY-LOWER CBA2
45073507	HARN & CELL ASSY-LOWER CBA2
45073602	PWB-SENSORS (CBA-2/4)
45073603	PWB SENSORS (CBA-2)
45073701	HARN & CELL ASSY-UPPER (CBA-4)

45074002	BILL-BOX ASSY-550 BILL
45074003	BILL-BOX ASSY-225 BILL
45074101	BOX ASSY-DOOR & FRAME
45074301	CUP ASSY-CHANGE (COINS)
45074302	CUP ASSY-CHANGE (COINS)
45074601	MFAB, COVER BILL BOX 1000BC
45074602	COVER-BILL BOX (500 BC)
45074603	COVER-BILL BOX (400 BC)
45074604	COVER-BILL BOX (200 BC)
45074701	HARN ASSY-BC-3500 PWR CTL CTR
45074702	HARN ASSY-BC-3500 PWR CTL CTR
45074703	HARN ASSY-BC-3500 PWR CTL CTR
45074801	BILL-BOX ASSY-1000 BILLW/COVER
45074802	BILL-BOX ASSY-500 BILL W/COVER
45075501	COVER ASSY-POWER CONTROL BOX
45075701	ROD-STOP (HOPPER) BC100/150
45075801	BOX ASSY-POWER CONTROL
45075802	BOX ASSY-POWER CONTROL
45075803	BOX ASSY-POWER CONTROL
45075901	BAIL-HOPPER RETAINER,BC100/150
45076101	PCB ASSY, HOLDER LED
45076102	HOLDER ASSY-LED (BA-50 KIT)
45076401	PCB ASSY, INTERCONNECT
45076402	PCB ASSY, INTERCONNECT
45076403	CBA-INTERCONNECT
45076404	CBA-INTERCONNECT
45076601	DECAL-DOOR (BC-1200)
45076602	DECAL-DOOR (BC-1200)
45076608	DECAL-DOOR (TOKENS)
45076701	DECAL-CHANGE ID (\$1/\$5 BC1200)
45076702	DECAL-CHANGE ID (\$1/\$5 BC1200)
45076801	DECAL-CHANGE ID (\$1,\$5,\$10)
45076802	DECAL-CHANGE ID (\$1 \$5 \$10)
45076901	DECAL-CHANGE ID (\$1,5,10,20)
45076902	DECAL-CHANGE ID (\$1,5,10,20)
45077001	HARN ASSY-SEGUE TO CCC
45077201	BELT-TIMING (HIGH FRICTION)OBA
45077302	HARN ASSY-CBA-2 & ROYAL 5.0 UP
45077902	COVER-COIN CUP (BC-1200)
45078003	POWER CONTROL CENTER W/BRKT
45078004	POWER CONTROL CENTER W/BRKT
45078006	POWER CONTROL CENTER-W/BRKT
45078101	BLOCK-FOAM
45079201	PCB ASSY, MAGNETIC HEAD
45079301	DECAL-DOOR (CBC-1200)
45079401	DECAL-CHANGE ID(\$2/\$5 CBC1200)
45079501	DECAL-CHANGE ID(\$2/\$5/\$10 BILL
45079502	DECAL-CHANGE ID(\$2/\$5/\$10 BILL
45079601	DECAL-CHANGE ID(\$2/\$5/\$10/\$20)
45082201	BRACKET-HANGER (FRONT R.H.)
45082202	BRACKET-HANGER (FRONT R.H.)

45083601	PCB ASSY, UPPER MAG AMP, RBA
45083801	PCB ASSY, RBA-7 LOWER MAG AMP
45083901	BRACKET-LOWER TRACK
45084001	LEVER-ANTI CHEAT, RBA
45084403	XFMR, PC MOUNT POWER
45084501	BILL-BOX ASSY (200BC)
45084502	BILL-BOX ASSY (500BC)
45085303	BOX ASSY-ELECTRICAL (UNIV)
45085601	CUP ASSY-CHANGE (COINS)
45085603	CUP ASSY-CHANGE (COINS)
45085605	CUP ASSY-CHANGE (COINS)
45085805	COMPUTER ASSY (SBC2) 50/60 HZ
45085806	COMPUTER ASSY (SBC2) 50/60 HZ
45085904	COMPUTER ASSY:C-SERIES W/MDB
45087101	PLATE-B.A. TRIM
45087201	PLATE-COIN CHUTE TRIM
45087501	CHUTE ASSY-COIN
45087701	BRACKET ASSY-ADAPTER
45087702	BRACKET ASSY-ADAPTER UNIV.
45087901	CHUTE ASSY-COIN DISCHARGE
45088301	COVER, POWER SUPPLY (RBA-7)
45088901	ADAPTER-SAFEGUARD
45089004	BRKT & CATCH ASSY(WITH PS BRKT
45100104	TRANSFORMER & HARNESS ASSY
45100401	EXTRUSION-LENS
45101301	BILL-BOX ASSY (200BC)
45101302	BILL-BOX ASSY (500BC)
45101303	BILL-BOX ASSY (1000BC)
45101304	BILL-BOX ASSY (2000BC)
45102101	LOCKED CASSETTE BILL BOX 500SL
45102401	HARNESS-CC-40 COIN MECH
45102501	INTERFACE-COIN COMP. CC-40
45102901	BRKT-TRIM
45103001	BRKT ASSY-MOUNTING & TRIM
45103101	BRKT ASSY-MOUNTING
45106901	CBA-LOW COIN SENSOR (STD CAP)
45106902	CBA-LOW COIN SENSOR (HI CAP)
45107301	BRKT-ANTENNA COVER
45107401	LABEL-DOOR
45107402	LABEL-DOOR (4 BILL)
45107403	LABEL DOOR-C2 DOM
45107701	HARN ASSY-290 W/DIVERSIFIED BA
45108101	HARNESS ASSY-COMP TO DISP
45108102	HARNESS ASSY-DISPENS (NSBC8/10
45108201	HARN ASSY-NSBC TO CBA4
45108203	HARNESS-C-CHGR BA(MARS/COINCO)
45108204	HARN ASSY-NSBC/BA (POWER)
45108205	HARN ASSY-NSBC/BA (CASHCODE)
45108206	HARN ASSY C/BA (CBA2)
45108208	HARNESS-C TO BA (RBA-7)
45108213	HARNESS-C6RL TO RBA-7

45108214	HARNESS-C-10RL TO RBA7
45108216	HARNESS-C-10RL TO MARS/COINCO
45108301	HARN ASSY-NSBC TO CA (MECH)
45108302	HARN ASSY-NSBC TO CA (330)
45108601	CHUTE ASSY-COIN (REJECT)
45108901	BOX ASSY-COIN,C-6 W/COIN
45109102	HARN ASSY-PWR CENTURY SERIES
45109103	HARNESS ASSY-POWER (C6RL)
45109201	BRKT & CHUTE ASSY-COIN MECH
45109301	BRKT-DOOR STOP
45109501	CHUTE ASSY-COIN
45111001	BRKT ASSY-MTG & HOLD DOWN
45111901	HARNESS-RBA7 TO TEST SW
45112601	ADAPTER-BA, HI SECURITY INLET
46502001	AUTOTRANSF-STEPDOWN (3 WIRE)
46509218	POWER SUPPLY-MAIN (220 VAC)
46509251	POWER SUPPLY-MAIN (220V) CE
46509302	TRANSFORMER-POWER (EXPORT)
47000601	GUIDE ASSY-COIN & CHAIN
47000602	GUIDE ASSY-COIN&CHAIN (\$ COIN)
47002002	LABEL-WAIT
47002004	LABEL-"PAYS \$1 COINS"
47002005	LABEL-WAIT (CHANGE RETURN)
47901420	HANDLE ASM-POPOUT
54801817	SWITCH-BA-50 ANTI-STRING KIT
60326705	DOOR-CASH BOX
60341802	HOLDER ASSY-PAGE
60341803	HOLDER ASSY-PAGE
60757102	RACK-TITLE
60788902	PANEL ASSY-FRONT (DOOR)
60792702	PCB ASSY, PREAMP ACCESSORY BD
60870703	BASE-MECHANISM (CD)
60870704	BASE-MECHANISM (BLACK)
60898004	REMOTE VOL CANCEL & PWR SWITCH
60935705	PCB ASSY, MAIN POWER SUPPLY
60936205	RACK-TITLE
60971501	BILL STKR ASSY (500 BILL, LH)
60971505	BILL STKR ASSY (500 BILL LH)
60971507	BILL STKR ASSY (500 BILL RH)
60971512	BILL STKR ASSY (500 BILL, LH)
60971514	BILL STACKER ASSY-500 BILLS
60971515	BILL STACKER ASSY-1000 BILLS
60971516	BILL STACKER ASSY (500 BILL RH)
60971517	BILL STKR ASSY(1000 BILL LH-DC
60971518	BILL STACKER ASSY-500 BILL LH
60972105	HARNESS ASSY-OBA (STACKER)
60992801	PCB ASSY, DIGITAL DISPLAY R90
61007901	FRAME-DOOR, CD100C
61007902	FRAME-DOOR, CD100D BLACK
61007903	FRAME-DOOR, CD100D RED
61020302	FRAME-TOP DOOR (BROWN)

61020305	FRAME-TOP DOOR (BLUE R-94)
61020306	FRAME-TOP DOOR (BROWN R-94)
61020701	CHUTE-COIN (LOWER)
61020801	HOLDER-DIGITAL DISPLAY
61021301	SHEET-UNIVERSAL PRICING
61022501	CKT BD ASSY-DIGITAL DISPLAY
61023103	HOUSING-DISC (WCD)
61023301	HARNESS & SOCKET ASSY
61023703	PCB ASSY, PREAMP
61024603	CHASSIS-AMPLIFIER
61024903	AMP ASSY-STEREO (250W W/EQ)
61027201	HARNESS & SWITCH ASSY-NOSTAL
61027602	INTERFACE ASSY-IR REMOTE
61029601	SLIDE
61029701	CABINET-FRONT
61029801	CABINET-REAR
61029901	CABINET-TOP
61030605	CKT BD ASSY-MECH CONTROLLER
61030705	MECH CONTROLLER & DECODER ASSY
61031150	PCB ASSY, C.C.C. (HOME PHONO)
61031201	COVER TOP CCC
61031202	PFAB, COVER TOP (CCC)
61031301	PFAB, COVER BOTTOM (CCC)
61031402	SHEET-UNIVERSAL PRICING
61031403	SHEET-UNIVERSAL PRICING,CD100K
61033101	TRIM-CONTROL PANEL (UPPER)
61033102	TRIM-CONTROL PANEL (UPPER)
61033201	TRIM-CONTROL PANEL
61033202	TRIM-CONTROL PANEL
61033405	TRIM-ANIMATION BOX
61033503	TRIM-SPEAKER PANEL
61033703	TRIM-BOTTOM
61033801	TRIM-KEYBOARD
61033901	TRIM-BILL ACCEPTOR
61034101	GRILLE-UPPER
61034102	GRILLE-UPPER
61034301	GRILLE-LOWER
61034302	GRILLE-LOWER
61034401	LOCKBAR
61034402	LOCKBAR
61034501	DOOR ASSY-FRONT
61034701	CHUTE-LOWER (COIN)
61034801	PLATE-MOUNTING (BA)
61035501	HARNESS & SWITCH ASSY
61036203	DECAL-COMPACT DISC
61036204	DECAL-COMPACT DISC (BROWN)
61036501	TUBE-COLOR
61036601	SHROUD
61036701	PLATE-TOP (CD PAGE ASSY)
61036702	PLATE-TOP (CD-100C)
61036703	PLATE-TOP

61036801	PLATE-BOTTOM (CD PAGE ASSY)
61036802	PLATE-BOTTOM (CD-100C)
61036803	PLATE-BOTTOM
61036902	SUPPORT-VERTICAL (CD PAGE ASSY)
61036903	SUPPORT-TITLE RACK
61036904	SUPPORT-VERTICAL
61037001	HOUSING-ANIMATION
61037201	HOUSING-SIDE (RH)
61037402	PWB-C.D. ANIMATION
61037601	FILTER-COLOR
61037602	FILTER-COLOR
61037603	FILTER-COLOR (BLUE)
61038905	CONTROL UNIT-OBA2 ROWELINK
61039002	HARNESS & SWITCH ASSY
61039101	HARNESS ASSY-DISPLAY
61039501	DOOR-WALLBOX
61039703	PCB ASSY, CONTROLLER (WCD)
61039902	PLATE-TOP
61040501	SUPPORT-VERTICAL
61040502	SUPPORT-VERTICAL
61040801	TRIM-KEYBOARD (CD WALLBOX)
61040802	TRIM-KEYBOARD
61040901	HOLDER-DIGITAL DISPLAY
61041001	RACK ASSY-TITLE (WALLBOX)
61041002	RACK ASSY-TITLE (CD-51)
61041101	ANIMATION ASSY-WCD
61041202	HARNESS ASSY-MAIN
61042201	BRACKET-HANGER (B.A.)
61042202	BRACKET-HANGER (BA)
61043802	SUPPORT & COIN CHUTE ASSY
61043920	CHUTE-LOWER (COIN)
61044004	HARNESS & SWITCH ASSY
61044701	AMPLIFIER ASSY
61045801	MAGAZINE ASSY-CD
61046401	PWB-LAMP
61047001	DOOR ASSY-FRONT (CD-100B BLUE)
61047002	DOOR ASSY-FRONT (CD-100B BRN)
61047201	HOUSING-ANIMATION (REAR)
61047601	FILTER-COLOR (ROLLER BLUE)
61047602	FILTER-COLOR (ROLLER BROWN)
61048001	PLATE ASSY-MOUNTING (CDM-4)
61048004	PLATE ASSY-MOUNTING(CD PLAYER)
61048005	PLATE ASSY-MTG (CDM 12)(HOME)
61048101	DECODER & MECH BOARD ASSY
61048402	PCB ASSY, WCD INTERFACE
61048801	FRAME-SCENE (UPPER)
61050201	FRAME-TOP DOOR (CD-51)
61050202	FRAME-TOP DOOR (CD-51 BROWN)
61050203	FRAME-TOP DOOR (CD-51A)
61050501	SCENE-LOWER
61050701	PANEL-DOOR (LOWER)

61050702	PANEL-DOOR (LOWER)(MMCD100)
61050803	GRILLE-LOWER
61050804	GRILLE-LOWER (MMCD)
61050901	TRIM-BOTTOM
61050903	TRIM-BOTTOM
61051101	LOCKBAR
61051103	LOCKBAR
61051104	LOCKBAR
61051105	LOCKBAR
61051301	HOUSING-SIDE (LH)
61051401	HOUSING-SIDE (RH)
61051901	PCB ASSY, SPEAKER CROSSOVER
61052001	DOOR ASSY-FRONT (CD-51)
61052003	DOOR ASSY-FRONT (CD-51A)
61052101	TRIM-KEYBOARD
61052203	DECAL-TITLE RACK HALO
61052701	PCB ASSY, SPEAKER CROSSOVER
61052703	CBA-CROSSOVER
61052704	CBA-CROSSOVER
61052901	SUPPORT-REAR, MECH
61053401	PCB ASSY, MECH CONTROL
61053602	PAGE-TITLE
61055003	SHELL ASSY-WOODGRAIN (CD-51A)
61055901	PCB ASSY, KEYBD WALLETT CD100
61056101	PCB ASSY, WALLETT CD100 LOGIC
61056201	TRIM-L.H.
61056301	TRIM-R.H.
61056401	RACK ASSY-TITLE,WALLETT
61056402	RACK ASSY-TITLE
61056601	TOP ASSY-GREY
61056701	HOUSING-LIGHT
61057101	TRIM-SIDE
61057701	CASHBOX
61058201	HOUSING-ANIMATION (REAR)
61058202	HOUSING-ANIMATION (REAR)
61058301	HOUSING-ANIMATION (TOP REAR)
61058401	HOUSING-ANIMATION (BASE)
61058501	HOUSING-ANIMATION (TOP & ENDS)
61058601	TRIM-BOTTOM
61058602	TRIM-BOTTOM
61060601	ANIMATION ASSY
61060701	GRILLE-LOWER
61060702	GRILLE-LOWER
61060801	CHUTE-COIN (LOWER)
61060802	CHUTE-COIN (LOWER)
61061101	PWB-C.D. ANIMATION
61061201	FILTER-COLOR
61061301	FRAME-BOTTOM (SCENE)
61061401	FRAME-TOP (SCENE)
61061601	WINDOW-SCENE
61061602	WINDOW-SCENE

61061801	FRAME-WINDOW
61061901	HINGE
61062002	GRILLE-UPPER (LH BLACK)
61062003	GRILLE-UPPER (LH GOLD)
61062102	GRILLE-UPPER (RH BLACK)
61062103	GRILLE-UPPER (RH GOLD)
61062201	TRIM-SIDE (LH)
61062401	DIFFUSER-LIGHT (UPPER)
61062402	DIFFUSER-LIGHT (UPPER FLUTED)
61062801	CHUTE-COIN (UPPER)
61063101	TRIM-EDGE(LH) (CD100C CABINET)
61063201	TRIM-EDGE(RH) (CD100C CABINET)
61065101	TRIM-TOP (LH)
61065201	TRIM-TOP (RH)
61065301	TRIM-PILASTER, CDRN
61065401	TRIM-GRILLE
61065501	TRIM-KEYBOARD
61065601	CURTAIN
61065701	DECAL-DECORATIVE (BACK)
61065801	PANEL-SPEAKER
61066002	SHELL-NOSTALGIC
61066101	PLASTIC-UPPER (LH) CDRN
61066201	PLASTIC-UPPER (RH) CDRN
61066401	PLASTIC-LOWER, CDRN
61066501	PANEL-DIGITAL DISPLAY
61066601	PWB-TITLE RACK LIGHTS
61066701	LIGHT ASSY-ROTATING (LH)
61066801	LIGHT ASSY-ROTATING (RH)
61067001	FILTER-COLOR, CDRN
61067101	TUBE ASSY-COLOR (LH)
61067201	TUBE ASSY-COLOR (RH)
61067501	PANEL-DOOR (LOWER)
61067801	GRILLE-UPPER (LH)
61067901	GRILLE-UPPER (RH)
61068701	LOCKBAR
61068802	PANEL-DOOR (LOWER)
61070601	PANEL-LAMP
61070701	CLOTH-GRILLE (GOLD), CDRN
61071002	FRAME-DOOR
61072101	HOUSING-TITLE RACK-CDRN
61072201	INLET-BILL (NOSTALGIC)
61072301	INLET-COIN (NOSTALGIC)
61072401	SUPPORT
61073301	SCENE ASSEMBLY
61078301	SCENE-REAR
61078401	RACK ASSY-TITLE (CD-100E)
61078502	RACK ASSY-TITLE (WALLPHONO)
61078503	RACK ASSY-TITLE
61078504	RACK ASSY-TITLE (MMCD-2)
61078507	RACK ASSY-TITLE (MMCD3)
61078702	DOOR ASSY-TOP (MMCD-2)

61078703	DOOR ASSY-TOP MMCD3 (TEAL)
61078704	DOOR ASSY-TOP MMCD3 (RED)
61078801	DOOR ASSY-FRONT (MMCD)
61078802	DOOR ASSY-FRONT (MMCD-2)
61078901	PAGE-TITLE (MMCD/ENCORE/EAGLE)
61079101	PLATE-BOTTOM (TITLE RACK)
61079302	DOOR ASSY-TOP CD100E RED
61079401	DOOR ASSY-FRONT
61079501	SHELL ASSY (CD-100E)
61080201	GRILLE-LOWER
61080301	TRIM-BOTTOM
61080501	INSERT-DOOR
61080502	INSERT-DOOR
61080901	PANEL-TRANSLUENT LIGHT
61081001	HOUSING-ANIMATION
61081102	HARNESS & SWITCH ASSY CD100E
61081201	FILTER-COLOR
61081202	FILTER-COLOR
61081401	PCB ASSY, SINGALONG
61081701	HINGE-CD100E
61081801	PWB-DIAMOND (LH)
61081901	PWB-DIAMOND (RH)
61082201	LOCKBAR
61082301	DIFFUSER-LIGHT (LOWER)
61082501	DIFFUSER-LIGHT (UPPER)
61082601	TRIM-SIDE (LH)
61082701	TRIM-SIDE (RH)
61083101	ANIMATION ASSY
61083401	COVER-TITLE PAGE
61083801	TRIM-EDGE
61084201	HANGER-TITLE RACK
61084503	CKT BD ASSY-LAMP CONTROL
61084701	HARNESS ASSY-TITLE RACK
61084705	HARNESS-TITLE RACK(CD100H//J)
61084802	BRACKET ASSY-BILL ACCEPTOR
61085001	CHIMNEY-AMPLIFIER
61085201	HARNESS ASSY-32 LAMP
61085401	SUPPORT-COIN ASSY
61085601	BANNER-KARAOKE
61085901	PCB ASSY, MECHANISM CONTROL BD
61085902	CBA-MECH CONT (CDV)
61086001	PLATE-BASE (MECH CONTROL)
61086101	COVER-MECH CONTROL
61086202	COMPUTER-MECH CONTROL (CDV)
61086501	PCB ASSY, POWER SUPPLY CD
61090301	SHELL-WALL PHONO
61090601	CHANNEL-DOOR SUPPORT
61091101	FRAME-DOOR, EAGLE (SILVER)
61091401	CHUTE ASSY-COIN
61091801	FRAME-WINDOW
61091901	HOUSING-TOP

61092001	TRIM-WING (LH)
61092101	TRIM-WING (RH)
61092201	WING (LH)
61092202	WING L.H.
61092301	WING (RH)
61092302	WING R.H.
61093401	CKT. BD. ASSY-LAMPS
61093801	BRACKET-SLIDE CARRIAGE
61093901	PLATE-END TITLE RACK
61094001	SUPPORT-HORIZONTAL
61094101	RACK ASSY-TITLE (CD100F)
61094104	KIT-TITLE PAGE ASSY (CD100H)
61094105	PAGE ASSY-TITLE (CD100I)
61094108	PAGE ASSY-TITLE (BLUE)(CD100I)
61094110	TITLE RACK ASSY (BLACK)
61094201	PAGE-TITLE
61094202	PAGE-TITLE (WHITE)
61094301	HOUSING ASSEMBLY-SPEAKER
61095201	WINDOW-ANIMATION
61095301	GLASS, TOP DOOR CD100F
61097101	FRAME-DOOR-CD100F
61097102	FRAME-DOOR-CD100F (RED)
61097201	END CAP-TOP (FRONT DOOR) (LH)
61097301	END CAP-TOP (FRONT DOOR) (RH)
61097401	END CAP-BTM (FRONT DOOR) (LH)
61097402	END CAP-BTM (FRONT DOOR) (LH)
61097501	END CAP-BTM (FRONT DOOR) (RH)
61097601	GRILL-FRONT DOOR
61097701	LOCKBAR-FRONT DOOR
61097801	PANEL-FRONT DOOR
61098001	DIFFUSER-FRONT DOOR
61098101	LIGHT ASSY-LEFT (FRONT DOOR)
61098104	LIGHT ASSY-FRONT DOOR (L.H.)
61098201	LIGHT ASSY-RIGHT (FRONT DOOR)
61098204	LIGHT ASSY-FRONT DOOR (R.H.)
61098301	COLUMN ASSY-FRONT DOOR (L.H.)
61098302	COLUMN ASSY-FRONT DOOR (L.H.)
61098401	COLUMN ASSY-FRONT DOOR (R.H.)
61098402	COLUMN ASSY-FRONT DOOR (R.H.)
61098701	TRIM-EDGE (R.H.)
61099101	HARNESS & SWITCH ASSY
61099202	CHIMNEY-AMPLIFIER
61099301	FILTER-COLOR
61099302	FILTER-COLOR (RED)
61099501	DIFFUSER-WHITE TRANSLUCENT
61099502	DIFFUSER-WHITE TRANSLUCENT
61099503	DIFFUSER-TOP, CD100I/J
61099601	END CAP
61099801	ADAPTER-SWITCH MTG
61100301	CHUTE, COIN-LOWER
61100501	SCAVENGER ASSY

61100601	TRIM-TITLE RACK SIDE (LH)
61100602	TRIM-TITLE RACK SIDE (LH)
61100603	TRIM-TITLERACK (L.H.)
61100701	TRIM-TITLE RACK SIDE (RH)
61100702	TRIM-TITLE RACK SIDE (RH)
61100703	TRIM-TITLERACK SIDE (R.H.)
61100801	GRILLE-UPPER-LH
61100901	GRILLE-UPPER-RH
61101001	HINGE-CD100F
61101301	FILTER-COLOR
61101302	FILTER-COLOR (RED)
61101401	HARN ASSY-LOW VOLTAGE
61101501	ANIMATION ASSY-CD100F
61101601	LENS TITLE RACK (LH)
61101801	DIFFUSER-TITLE RACK (LH)
61101901	DIFFUSER-TITLE RACK (RH)
61102101	DIFFUSER-WINDOW
61102601	WRAPPER-ANIMATION (TOP)
61103201	HARNESS & SWITCH ASSY
61103211	SERVICE SWITCH ASSY
61103301	HARNESS & BALLAST ASM
61104101	GLASS, TOP DOOR CD100G
61104102	GLASS, TOP DOOR CD100H
61104501	DOOR, TOP-CD100G
61104502	DOOR, TOP-CARDINAL (CD100K)
61104503	DOOR, TOP-BLACK (CD100H)
61104901	GRILL-LOWER DOOR
61104903	GRILL-LOWER DOOR(BLACK)
61105001	TRIM, UPPER (TOP DOOR) (LH)
61105003	TRIM-UPPER (TOP DOOR) L.H.
61105101	TRIM, UPPER (TOP DOOR) (RH)
61105103	TRIM-UPPER (TOP DOOR) R.H.
61105202	HOUSING-DISPLAY CD100G
61105302	COLUMN-LOWER L.H. (CABINET)
61105402	COLUMN-LOWER, R.H. (CABINET)
61105501	TRIM, SIDE (TOP DOOR) (LH)
61105502	TRIM-SIDE (TOP DOOR) L.H.
61105601	TRIM, SIDE (TOP DOOR) (RH)
61105602	TRIM-SIDE (TOP DOOR) R.H.
61105701	SHELL-CD100G/H
61105801	PANEL-LOWER DOOR
61106201	HARNESS & SWITCH ASSY CD100-G
61106211	SERVICE SW ASSY-CD100G
61106212	HARNESS ASSY-MAIN (CD100H)
61106401	CBA-LAMP CONTROL
61106402	CBA-LAMP CONTROL
61106501	DOOR ASSY-TOP CD100G
61106601	DOOR ASSY-FRONT CD100G
61106604	DOOR ASSY-FRONT (CD100H)
61107201	CHUTE-LOWER COIN
61107202	CHUTE-LOWER COIN

61107301	REFLECTOR-INFINITY (SIDE)
61107302	REFLECTOR-INFINITY (BOTTOM)
61107501	BLOCKOUT-INFINITY (MIDDLE)
61107902	BLOCKOUT-INFINITY LONG SIDE RH
61108001	TRIM-EDGE (LH) (CABINET)
61108101	TRIM-EDGE (RH) (CABINET)
61108201	FILTER-COLOR
61108501	MARQUEE-CD100G/H 120 VAC 60HZ
61108502	MARQUEE ASSY-CD100G/H 230 VAC
61108505	MARQUEE-CD100I 120 V
61108506	MARQUEE ASSY-CD100I 230 V
61108601	DISPLAY ARRAY LED-120 VAC,60HZ
61108701	INSERT-DOOR MMCD3 (TEAL)
61108702	INSERT-DOOR MMCD3 (RED)
61109201	CHUTE-COIN INLET
61109901	BRACKET-ADAPTER (B/A)
61109903	BRACKET-ADAPTER (MARS BA)
61110501	PANEL-DOOR (BLACK)
61110502	PANEL-DOOR (WOOD)
61110503	PANEL-DOOR (SUNRISE RED)
61110504	PANEL-DOOR (SYMPHONY RED)
61110505	PANEL-DOOR (VIOLET)
61110702	WINDOW-DOOR(SELECTOR,LIGHTNING
61110703	WINDOW-DOOR (LIGHTNING)
61110704	WINDOW-DOOR (STAINED GLASS)
61110705	WINDOW-DOOR(SELECT,STAIN GLASS
61110706	WINDOW-DOOR (SUNRISE)
61110707	WINDOW-DOOR (SUNRISE SELECT)
61110708	WINDOW-DOOR (STARBURST)
61110709	WINDOW-DOOR (STARBURST SELECT)
61110710	WINDOW - MAIN DOOR (SYMPHONY)
61110801	SUPPORT-VERTICAL (WALLPHONO)
61110901	DIFFUSER-WALLPHONO
61110902	DIFFUSER-BTM TITLERACK-WP100
61111001	SLIDE-TITLE PAGE, WP100
61111202	PAGE ASSY-WALLPHONO
61111401	SHELL-WALLBOX CABINET
61111701	CBA-KEYBOARD/DISPLAY
61111802	MECH (WALL) PRO
61112601	DOOR ASSY-MAIN
61112603	DOOR ASSY-MAIN
61112610	DOOR ASSY-BLK PANEL/GOLD LITES
61112612	DOOR ASSY-BLK PANEL/PURPLE LIT
61112614	DOOR ASSY-RED PANEL/RED LITES
61112618	DOOR ASSY-PURPLE PANEL/PURPLE
61112701	AMPLIFIER-WP100
61113101	CBA-ELECTRONIC BALLAST
61113201	BASEPLATE-MECHANISM
61113301	HARNESS-MAIN (WP100)
61113701	PARTITION-MECHANISM
61114001	HANGER-MOUNT WALLBOX WP100

61114002	HANGER-MOUNT (DLW-1)
61114201	PLATE ASSY-CD MTG
61114401	PWR SUPPLY & HARN ASSY-BRAZIL
61114801	BRKT ASSY-BILL ACCEPTOR FACE
61115001	BRKT-B/A MTG
61115701	PANEL-SUNBURST GRAPHICS
61116001	NEON LIGHT ASSY (BLUE)
61116002	NEON LIGHT ASSY (GREEN)
61116003	NEON LIGHT ASSY (GOLD)
61116004	NEON LIGHT ASSY (RED)
61116005	NEON LIGHT ASSY (PURPLE)
61116101	ANIMATION ASSY-CD100H
61116301	DOME-REFLECTIVE (LARGE)
61116401	DOME-REFLECTIVE (SMALL)
61116601	TOP DOOR ASSY BLACK (CD100H)
61116602	TOP DOOR ASSY RED (CD100H)
61116804	CBA-KID CTRL (CD100K)
61117501	MONO-AMP ASSY 50 WATT
61118203	CBA-CCC NT
61118301	REFLECTOR-INFINITY (BOTTOM)
61118401	REFLECTOR-INFINITY (SIDE)
61119801	PANEL,ENCORE TOP DOOR,WOOD
61119803	PANEL,ENCORE2 TOP DOOR,GREEN
61119804	PANEL-ENCORE 2 TOP DOOR (RED)
61120201	LOCKBAR, ENCORE
61120301	TRIM-HORIZONTAL (LOWER DOOR)
61120302	TRIM-HORIZ (LWR DOOR) ENCORE
61121601	SHELL ASSY-ENCORE GOLD
61121603	SHELL ASSY-ENCORE 2 (RED)
61121701	DOOR ASSY-FRONT ENCORE
61121702	DOOR ASSY-FRONT ENCORE 2
61121801	PAGE ASSY-TITLE (ENCORE)
61121902	HARN ASSY-ENCORE W/MARS
61122001	HARNESS & BALLAST ASSY 60HZ
61122601	WINDOW, GRAPHICS (ENCORE)
61122701	WINDOW, DOOR, MAIN (ENCORE)
61123301	PANEL-DOOR LOWER
61124101	BRKT-DIFFUSER RETAINER
61125601	SHELL CD-100I/J
61125701	DIFFUSER-PILASTER L.H.
61125702	DIFFUSER-PILASTER(LH),CD100I/J
61125703	DIFFUSER PILASTER, (LH) DL11
61125704	DIFFUSER PILASTER
61125801	DIFFUSER-PILASTER R.H.
61125802	DIFFUSER-PILASTER (RH)
61125803	DIFFUSER-PILASTER, (RH) DL11
61125804	DIFFUSER PILASTER
61126001	DOOR, TOP-BLUE (CD100I/IDL)
61126002	DOOR, TOP-RED (CD100I/J/IDL)
61126003	DOOR, TOP-BLACK (CD100J/DL-11)
61126601	DOOR ASSY-LOWER

61126602	DOOR ASSY-LOWER
61127001	TRIM-EDGE, LH (CABINET)
61127101	TRIM-EDGE, RH (CABINET)
61127201	TRIM-HORIZ. CENTER ENCORE 2
61127301	TRIM-HORIZ. LOWER ENCORE 2
61127401	TOP DOOR ASSY (CD100I-BLUE)
61127402	TOP DOOR ASSY (RED)
61127405	TOP DOOR ASSY (RED)
61127406	TOP DOOR ASSY (BLACK)
61127409	TOP DOOR ASSY (DL-11)
61127414	DOOR ASSY-TOP (DL-11A)
61127502	TRIM VERTICAL (TOP DOOR) (LH)
61127602	TRIM VERTICAL (TOP DOOR) (RH)
61127801	GRILL, TWTR(TOP DOOR)CD100I/IDL
61128001	CBA-DIGITAL DISPLAY
61128401	TRIM-SPEAKER (MIDRANGE)
61129102	FILTER-COLOR, BLUE IDL
61129103	FILTER-COLOR, RED IDL
61129501	ANIMATION SUB ASSY-LOWER
61130101	TITLE RACK MTG ASSY L.H.
61130701	DIFFUSER-TOP DR TR LH CD100I/J
61130801	DIFFUSER-TOP DR TR RH CD100I/J
61132002	AMP-EXTR. COOL AUDIO (1000W)
61132003	AMP-EXTR. COOL AUDIO (1000W)
61134101	BEZEL ASSY, MONITOR (TOP DOOR)
61134701	POWER SUPPLY-SYSTEM 120V
61134901	SHROUD, LIGHT BLOCK (MONITOR)
61135301	FRAME WELDMENT-VERTICAL
61137401	HOUSING-17 INCH TOUCHSCREEN
61138110	TOUCHSCREEN-17" ELO SAW
61138111	CBA-ELO TOUCHSCRN CNTRL-SERIAL
61138112	DISP-LCD(SAMSUNG LTH170E4-L01)
61138113	CBA-VIDEO INTF-XGA TO LVDS
61138114	CBA-5V P.S. & HARN(TOUCHSCREEN
61138115	CBA-INVERTER FOR LCD DISPLAY
61138116	CBA-OSD BOARD
61138117	HARNESS-5V P.S. INPUT
61138118	HARNESS-DB9 TO DUAL ROW
61138119	HARNESS-LVDS FOR DISPLAY
61138120	HARNESS-OSD TO VIDEO INTF.
61138121	HARNESS-INVERTER TO VIDEO INTF
61138123	CABLE-SVGA VIDEO 15 PIN M TO M
61138701	PREAMP ASSY-2 CHANNEL
61138702	PREAMP ASSY-2 CHANNEL
61139301	BEZEL-ADAPTOR 15" FLATSCREEN
61139401	HOUSING 15" FLATSCREEN
61139801	SHELL-DL11A
61140101	PANEL, DISPLAY, CD100K
61140201	GRILL, SPEAKER(TOP DOOR)CD100K
61140501	DOOR-TOP (GARNET RED) CD100K
61140503	DOOR-TOP (TEAL) CD100K

61140701	DIFFUSER "CROWN", CD100K
61140801	DIFFUSER "BUBBLE", CD100K
61140901	BRKT-DSPLY/KYBD
61141001	SIGHT BLOCK, GARNET CD100K
61141003	SIGHT BLOCK, TEAL CD100K
61141101	LATCH, TOP DOOR, CD100K
61141501	DOOR ASSY-TOP (RED)
61141502	DOOR ASSY-TOP (TEAL)
61141601	KYBD/DISPLAY ASSY
61142201	CBA-LED CONTROL, CD100K
61142301	BRKT-SECURITY, LOWER DOOR
61142401	GRILL-LOWER DOOR, CD100K
61142501	PANEL-LOWER DOOR, CD100K
61142601	LOWER DOOR ASSY-CD100K
61143201	PILASTER ASSY (LH) CD100K
61143301	PILASTER ASSY (RH) CD100K
61143401	DIFFUSER-PILASTER, CD100K
61143801	SHROUD-SIDE, T.R. (LH) CD100K
61143901	SHROUD-SIDE, T.R. (RH) CD100K
61144001	SHROUD-TOP, TITLE RACK CD100K
61144101	TITLE RACK ASSY-CD100K
61144201	SHELL ASSY-CD100K
61144601	COIN CHUTE-CD100K
61145001	PWR SUPPLY-MAIN
61145101	COIN CHUTE-LOWER, CD100K
61145201	SHROUD ASSY-TITLE RACK
61145601	SHROUD-ITOUCH MONITOR
61146203	CBA-PREAMP
61146301	MONITOR & T/S >SN 5218
61146901	250W AMP ASSY
65015302	TRIM-ACCEPTOR
65017101	CUP-COIN
65022401	TRIM-FRONT (BILL ACCEPTOR)
65022503	TRACK-UPPER (CASTING)
65022604	CASTING-LOWER TRACK
65022605	CASTING-LOWER TRACK
65022609	CASTING-LOWER TRACK
65022611	TRACK-LOWER (CASTING)
65024908	BILL STACKER ASSY (BC-12)
65024909	BILL STACKER ASSY (BC-12R)
65024919	BILL STACKER ASSY (BC200)
65024920	BILL STACKER ASSY-BC100/50
65027510	DISPENSER ASSY-COIN (BC-3500)
65027604	COIN HOPPER ASSY(QTR,DIME,NKL)
65027608	COIN HOPPER ASSY(QTR,DM,NKL)
65027609	COIN HOPPER ASSY(\$,COIN,QTR)
65027611	HOPPER ASSY (\$ COIN QTR)
65027612	HOPPER ASSY (QTR DIME NKL)
65027613	HOPPER ASSY (\$ COIN QTR)
65027615	HOPPER ASSY (HI CAP \$COIN QTR)
65027616	HOPPER ASSY-HI CAP (NDQ)

65027901	FUNNEL-FIXED (COIN HOPPER)
65027902	FUNNEL-HOPPER (INTERMEDIATE)
65027903	FUNNEL-FIXED
65028202	FUNNEL-SLIDING (COIN HOPPER)
65028803	RING-CHAIN GUIDE
65029107	HARNESS ASSY-DISPENSER
65029109	HARNESS ASSY-DISPENSER
65029114	HARNESS ASSY-DISPENSER
65029115	HARNESS ASSY-DISPENSER
65037809	CABINET ASSY-WELD (BC-12)
65037816	CABINET ASSY-WELD (BC1400)
65041801	PCB ASSY, POWER SUPPLY
65042302	HARNESS ASSY-POWER CONTROL
65042406	CHASSIS ASSY-POWER CONTROL
65042606	CONTROL CENTER ASSY-POWER
65042608	CONTROL CTR ASSY-FAST PAY
65042903	HARNESS ASSY-MAIN (BC-35)
65044405	COIN ACCEP-ELECT 25¢/\$ COIN
65044406	COIN ACCEP-MINI ELECTRONIC
65045201	PCB ASSY, MAIN PWR SUPPLY WBC
65046701	PCB ASSY, BILL STACKER DRIVER
65046804	BILL STACKER ASSY-DUAL
65046808	BILL STACKER ASSY-DUAL(BC1400)
65047002	CABINET TOP W/A-BC35 (WHITE)
65047003	CABINET TOP W/A-BC35 (BLACK)
65047004	CABINET TOP W/A-BC35 (BROWN)
65047301	DOOR ASSY-FRONT (WELD) BC-35
65047302	DOOR ASSY-FRONT (WELD) BC-35
65047303	DOOR ASSY-FRONT (WELD) BC-35
65047304	DOOR ASSY-FRONT (WELD) BC-35
65047309	DOOR WELD ASSY (BLUE, NO TPRT)
65047310	DOOR WELD ASSY
65047401	PANEL-MTG (CONTROL COMPUTER)
65047501	DOOR ASSY-FRONT (DK CAMEL TAN)
65047502	DOOR ASSY-FRONT (BLUE)
65047504	DOOR ASSY-FRONT (IBM BLACK)
65047507	DOOR ASSY-FRONT (BLK NEW STYLE)
65047603	COVER-COMPUTER CONTROL
65048020	PCB ASSY, COMPUTER CONTROL
65049202	BASE ASSY-WELD (WHITE)
65049203	BASE ASSY-WELD (IBM BLACK)
65049204	BASE ASSY-WELD (CHAR BRN)
65049302	DOOR ASSY-BASE (BC-35)
65049309	DOOR ASSY-BASE (BC-35)
65050301	PCB ASSY, O.B.A. LOGIC
65050501	KIT-SIGN-CHANGE
65050503	KIT-SIGN-TOKEN
65050806	PCB ASSY, PWR SUP & MOTOR CONT
65050807	PCB ASSY, PWR SUP & MOTOR CONT
65052103	KIT-BILL STACKER
65052105	KIT-BILL STACKER

65052106	KIT-BILL STACKER
65052107	KIT-BILL STACKER
65052803	COMP CONT ASSY-NORTH EUROPE
65053605	PANEL ASSY-W/GRAPHICS (BC1400)
65055701	CKT BD ASSY-BC-12 INTERCONNECT
65056237	DOOR ASSY-FRT \$1 BC-1 W/M-T LT
65056329	DOOR ASSY-WELD \$1 BC-1 W/MT LT
65056333	DR ASSY-WELD \$1(BC-1 W/M-T LT)
65056801	TRACK-INLET, OBA
65058001	DISPENSER
65058005	DISPENSER ASSY-COIN (BC-1)
65058009	DISPENSER ASSY-COIN
65058010	DISPENSER ASSY-COIN
65058011	DISPENSER ASSY-COIN (BC-1200)
65058012	DISPENSER ASSY-COIN (BC-1400)
65058013	DISPENSER ASSY-COIN (BC-150)
65058205	PCB ASSY, OBA LOGIC
65058206	PCB ASSY, OBA LOGIC
65061806	DOOR ASSY-WELD (BC1400)
65061947	DOOR ASSY (\$1/\$5) BC-12 NO CA
65061949	DOOR ASSY (\$1/\$5) BC-12 NO CA
65062701	CKT BD ASSY-INTERCONNECT (CBA)
65063303	PCB ASSY, CONTROL UNIT OBA-P
65063306	PCB ASSY, CONTROL UNIT CBA-1B
65063401	MFAB ASSY, BASE AND STUD
65063503	MFAB, COVER CONTROL UNIT OBA-P
65063903	DOOR ASSY-WELD (BC-2RC)
65064003	TRANSPORT-CBA (WHIPPANY)
65064203	FACEPLATE S/S ASM - BC200
65064403	FP ASSY-W/GRAPHICS (BC-1400)
65064404	PANEL ASSY-FRONT W/GRAPHICS
65064405	F P ASSY-WITH GRAPHICS
65064504	CABINET WELD ASM W/DOOR-BC200
65064601	CHUTE-COIN, BC200
65064703	HARNESS ASSY-MAIN (BC-200)
65064904	DOOR ASSY-BC-200
65065301	HARNESS ASSY-DISPENSER
65065302	HARNESS ASSY-DISPENSER
65065303	HARNESS ASSY-DISPENSER
65065339	HARNESS ASSY-DISPENSER
65065340	HARN ASSY-DISP, C-8/10/10RL
65065501	CABINET ASSY-WELD (BC-100)
65065502	CAB ASSY-WELD (BC-100)
65065801	HARN ASSY-OBA (STKR)
65066501	CONTROL CENTER ASSY-POWER
65067101	TRACK-LOWER, BA-50
65067102	TRACK-LOWER (BA-50 70MM)
65067205	HARNESS ASSY-MAIN (BC3500)
65067206	HARNESS MAIN,BC3500-NO TPORT
65067501	INLET-BILL (UPPER) BA50
65067502	INLET-BILL (UPPER)

65067601	INLET-BILL (LOWER)
65067701	HOLDER-MAG HEAD, BA50
65067801	KIT-CBA-2 MOUNTING ADAPTOR
65067902	HARNESS ASSY-MAIN (BC-100)
65067905	HARNESS ASSY-MAIN BC1200 12V
65068301	DOOR ASSY-WELD (BC-100 \$1/\$5)
65068302	DOOR ASSY-WELD (BC-100 \$1/\$5)
65068312	DOOR ASSY-WELD,BLACK BC100/150
65068401	DOOR ASSY-FRONT (BC-100 \$1,\$5)
65068402	DOOR ASSY-FRONT (BC-100 \$1,\$5)
65068403	DOOR ASSY-FRONT (BC-100 \$1,\$5)
65068501	TRANSPORT ASSY-BA50
65068801	WRAP-BILL BOX (1000 BC)
65069003	COMPUTER ASSY-CHANGER CONTROL
65069012	COMPUTER ASSY-CHANGER CONTROL
65069021	COMPUTER ASSY-CHANGER CNTRL
65069050	COMPUTER ASSY-CHGR CTRL(BC3500
65069051	COMPUTER ASSY-CHANGER (BC150)
65069056	COMPUTER ASSY-COLEMAN KIT
65069059	COMPUTER ASSY-FAST PAY 25¢+\$20
65069202	PCB ASSY,PWR SUPPLY (BC3500)
65069203	PCB ASSY-PWR SUPPLY BC3500
65069301	PFAB, COVER CONTROL COMPUTER
65069303	PFAB, COVER CONTROL COMPUTER
65069401	PFAB, BASE CONTROL COMPUTER
65069501	BILL-BOX ASSY (1000BC)
65069503	BILL-BOX ASSY (800BC)
65069702	PCB ASSY, PWR SUPPLY(1200/100)
65069705	PCB ASSY, PWR SUPPLY(1200/100)
65069901	MFAB, BRKT MTG PWR CONT CENTER
65069902	BRACKET-MOUNTING (PWR CONTROL)
65070702	HEAD & TRACK ASSY-CBA-4
65070704	HEAD & TRACK ASSY (UPPER)
65071201	DOOR ASSY-WELD (BC-1200) BROWN
65071202	DOOR ASSY-WELD (BC-1200) WHITE
65071203	DOOR ASSY-WELD (BC-1200) BLACK
65071204	DOOR ASSY-WELD (BC-1200) BLUE
65071206	DOOR ASM-WELD,BLK N.S.-BC1200
65071301	DOOR ASSY-NO C.A. (BC-1200)
65071309	DOOR ASSY-NO C.A. (BC-1200)
65071321	DOOR ASSY-NO CABINET (BC-1200M
65071330	DOOR ASSY-FRONT (BC-1400)
65071401	SHIELD, WATER TRANSPARENT
65073001	PCB ASSY, CONTROL OBA-4 PULSED
65073502	POWER CONTROL CENTER ASSY
65073504	PWR CONTROL ASSY-FAST PAY
65073901	PWR SUPPLY (CAN RW FM B0031972
65073902	POWER SUPPLY & HARNESS ASSY
65073903	POWER SUPPLY & HARNESS ASSY
65073909	POWER SUPPLY & HARNESS ASSY
65074101	POWER SUPPLY-CBA-2 (24 VOLT)

65074102	TRANSFORMER & HARNESS ASSY
65075001	COMPUTER BC'S W/2003 \$20'S
65075401	PCB ASSY, OBA-4 CONTROL
65075503	CONTROL ASSY OBA4 (8051)
65078101	POWER SUPPLY & HARNESS ASSY
65078430	CBA-RBA7 LOGIC, V4.1
65078431	CBA-RBA7 LOGIC-B.C. N \$5/\$10
65092901	HOPPER ASSY HICAP W/LOW COIN
65092902	HOPPER ASSY HICAP
65092903	HOPPER ASSY-HICAP W/LOW COIN
65092904	HOPPER ASSY HICAP W/LOW COIN
65093003	TRANSPORT-CBA2 COINCO/NO JONES
65093101	TRACK-UPPER
65093201	TRACK-LOWER, RBA
65093301	INLET, RBA
65093302	INLET (72MM)
65093305	INLET (CUT DOWN)
65093401	PLATE-SIDE (LH)
65093601	HEAD & UPPER TRACK ASSY-RBA
65093701	HEAD & LOWER TRACK ASSY-RBA
65093901	CATCH-DOOR POSITION
65094301	DOOR WELD ASSY (SBC-2)
65094305	DOOR ASSY-WELD (SBC-2/RBA-7)
65094707	HARNESS ASSY-MAIN SBC2 (UNIV)
65094777	HARNESS ASSY-MAIN (SBC2/RBA7)
65094801	DISPENSER ASSY-COIN
65094804	DISPENSER ASSY-COIN
65094805	COIN DISPENSER ASSY(LOW COIN)
65094901	HOPPER ASSY-COIN
65094902	HOPPER ASSY-LARGE COIN(SBC-2)
65094904	HOPPER ASSY-COIN
65094905	HOPPER ASSY-LARGE COIN (SBC2)
65094906	HOPPER ASSY-LARGE TOKEN (NSBC)
65094907	HOPPER ASSY-COIN (SMALL COIN)
65094908	HOPPER ASSY-COIN (LARGE COIN)
65095402	CBA-CENTURY COMPUTER CONTROL
65096801	BILL-BOX ASSY (1000BC)
65097001	BILL-BOX ASSY (2000BC)
65097622	CORNER-HONEY COMB, BC3500
65098203	PCB ASSY, CBA-4 V3.0
65099501	PCB ASSY, CBA-4 34V1.0
65099701	SHIELD-WATER
65100301	LOGIC BRD & BRACKET ASSY CBA2
65100302	LOGIC BD & BRACKET ASSY UBA2
65300802	PCB ASSY, POWER SUPPLY
65301501	PLATE ASSY-PUSHER
65301502	PLATE ASSY-PUSHER (LONG STROKE)
65404001	B. BOX SGD 2000SL ALLIED GARY
65404005	B. BOX SGD 2000SL ALLIED GARY
65404101	TRACK ASSY-UPPER (RBA-7)
65404201	TRACK ASSY-LOWER (RBA-7)

65404301	STACKER ASSY
65404302	STACKER ASSY (LONG STROKE)
65420901	CABINET ASSY-WELD (C-10)
65420902	CABINET ASSY-WELD (C-8)
65421001	DOOR ASSY-WELD (C-10)
65430703	CABINET ASSY-WELD (C-6)
65430704	CABINET WELD ASM-C2/4
65430801	PLATE ASSY-BOTTOM DUAL BC1400
65430902	FACEPLATE S/S ASM - BC2800
65431003	LABEL-C-6 DOMESTIC (W/O COIN)
65431007	LABEL-C6 SPANISH (NO COINS)
65431103	LABEL-C10 DOMESTIC (W/O COIN)
65431301	COIN DISPENSER ASSY (LOW COIN)
65431302	COIN DISPENSER ASSY (LOW COIN)
65431401	LABEL-C-8-DOM (W/COIN)
65431402	LABEL-C-8 DOMESTIC (W/O COIN)
65432002	DOOR WELD ASSY-C10RL
65432301	CABINET WELD ASSY-C6RL
65432401	PLATE-FRONT,C6RL
65432402	PLATE-FRONT,C10RL
65432801	CAB/DOOR ASM BC3500-BLACK
65432802	CAB/DOOR ASM BC3500-BLUE/WHITE
65432803	CAB/DOOR ASM BC3500-WHITE/WHT
66505903	KIT-SERVICE (CDM-4)
66505907	KIT-CONV. CDM 3/4 TO PRO MECH
66505909	KIT-SERVICE (PRO-MECH)
66505910	KIT-SERVICE (CD100F)
66505913	KIT-SERVICE (CD100K)
67002221	CARTON
67002610	CABINET ASSY-SERVICE (BC-1400)
67002612	CAB ASSY-SERV (BC12 BLK)
70010222	RES, 100 OHM 1/2W 10% CF
70010405	RES, 1.5K 1/2W 10% CC
70010619	RES, 1K 1/2W 10% CC
70010719	RES, 330 OHM 1/2W 10% CC
70010720	RES, 3.3K 1/2W 10% CC
70010724	RES, 22 OHM 1/2W 10% CC
70010821	RES, 2.2K 1W 10% CC (OR MO)
70010916	RES, 33 OHM 1/2W 10% CC
70011008	RES, 7.5 OHM 5W 10% WW
70011012	RES, 47 OHM 5W 10% WW
70011013	RES, 1 OHM 5W 5% CC
70011805	RES, .3 OHM 5W 10% WW CERAMIC
70012505	RESISTOR-PWR WW 10W (2 OHM)
70012510	RES, 150 OHM 5W 10% WW PWR CER
70012521	RESISTOR-WIREWOUND 5W .3 OHM
70012527	RESISTOR-WIREWOUND
70012528	RESISTOR-WIREWOUND
70012529	RESISTOR-WIREWOUND
70012801	RES, 5.1 OHM 15W 5% WW PWR CER
70012902	RESISTOR-POWER (CHASSIS MOUNT)

70013001	RES, MP930 50 OHM
70021301	CAP, .1UF 400V 20% RAD MYLAR
70021305	CAPACITOR-MET FILM (0.1 MFD)
70021311	CAP, 3uF 100V 10% RAD MYLAR
70021315	CAPACITOR
70021317	CAPACITOR
70021509	CAP, .0022UF 400V 5% RAD MYLAR
70021525	CAP, .01UF 400V 5% RAD MYLAR
70021526	CAP, .01UF 400V 10% RAD MYLAR
70021533	CAP, .022UF 200V 5% RAD MYLAR
70021536	CAP, .027UF 200V 10% RAD MYLAR
70021545	CAP, .068UF 100V 5% RAD MYLAR
70021549	CAP, .1UF 100V 10% RAD MYLAR
70021553	CAP, .22UF 100V 10% RAD MYLAR
70021555	CAP, .33UF 100V 10% RAD MYLAR
70021561	CAP, 1UF 100V 10% RAD MYLAR
70021609	CAP, .022UF 630V 10% MET.FILM
70022212	CAP, 100PF 500V 10% RAD CD Z5P
70022306	CAP, .01UF 500V 80/-20% RAD CD
70022314	CAP, .1UF 25V 20% RAD CD Z5U
70022402	CAP, .001UF 500V 10% RAD CD
70022421	CAP, .01UF 100V 20% RAD CD Z5V
70022506	CAPACITOR-CER DISC (.05 MFD)
70022508	CAP, .01UF 1KV 20% RAD CD Z5U
70022605	CAP, 20PF 500V 10% RAD CD N750
70022608	CAP, .01UF 1KV 10% RAD CD
70022801	CAP, 3.3UF 50V 20% RAD AL EL
70022809	CAP, 22uF 50V 20% RAD AL EL
70023304	CAP, 10UF 15V 10% AX AL EL
70023306	CAP, 100UF 6V 10% AX AL EL
70023310	CAP, 1200/1500UF 50V 10% AX
70023311	CAP, 470/500UF 25V 10% AX AL
70023318	CAP, 2200/2500UF 35V 20% AX
70023505	CAP, 2200/2500UF 50V -20/+100%
70023510	CAP, 15UF 50V -20/+100% AX
70023512	CAP, 4700UF 25V -20/+100% AX
70023513	CAPACITOR-ELECT(3000/3300 MFD)
70023601	CAP, 6800UF 35V 20% RAD AL EL
70023602	CAP, 2200UF 50V 20% RAD AL EL
70023603	CAP, 1000UF 35V 20% RAD AL EL
70023604	CAP, 4700UF 50V 20% RAD CER EL
70023605	CAP, 2200UF 80V 20% RAD AL EL
70023606	CAP, 1000UF 80V 20% RAD AL EL
70023610	CAPACITOR-ELECTRO 2200UF, 63V
70023611	CAPACITOR
70023804	CAP, 1UF 50V 20% RAD AL EL
70023805	CAP, 2.2UF 50V 20% RAD AL EL
70023806	CAP, 4.7UF 50V 20% RAD AL EL
70023808	CAP, 10UF 50V 20% RAD AL EL
70023809	CAP, 15uF 50V 20% RAD AL EL
70023810	CAP, 22UF 35V 20% RAD AL EL

70023812	CAP, 47UF 35V 20% RAD AL EL
70023814	CAP, 100UF 35V 20% RAD AL EL
70023902	CAPACITOR POLY PROP
70024002	CAP, .1UF 100V 10% RAD MF
70024004	CAP, .022UF 100V 10% RAD MF
70024007	CAP, .01UF 100V 10% RAD MF
70024020	CAP, .33UF 100V 10% RAD MF
70025102	CAP, 47UF 16V 20% RAD TANT
70025104	CAP, 22UF 16V 10% RAD TANTALUM
70025107	CAP, 2.2UF 20V 20% RAD TANT
70025108	CAP, 4.7UF 20V 10% RAD TANT
70025110	CAP, 10UF 20V 10% RAD TANT
70025111	CAPACITOR-TANTALUM (100 MFD)
70025116	CAP, 4.7UF 35V 20% RAD TANT
70025119	CAP, .33UF 35V 20% RAD TANT
70025123	CAP, .1UF 35V 20% RAD TANT
70025201	CAP, .1UF 16V 10% SMD TANTALUM
70025302	CAP, 15UF 15V 10% AX TANTALUM
70025303	CAP, 47UF 10V 10% AX TANTALUM
70028005	CAPACITOR-ELECT (47/50 MFD)
70028007	CAP, 47/50UF 50V 20% RAD AL EL
70028012	CAP, 100UF 50V 20% RAD AL EL
70028029	CAP, 1UF 100V 20% RAD AL EL
70028101	CAP, 1UF 100V 20% RAD AL EL
70028116	CAP, 2200UF 35V 20% RAD AL EL
70028305	CAP, 220UF 50V 20% RAD AL EL
70028310	CAP, 1000UF 16V 20% RAD AL EL
70028502	CAP, .01UF 100V 80/-20% AX CER
70028506	CAP, .033UF 50V 20% AX CER Z5U
70028510	CAP, .22UF 50V 20% AX CER Z5U
70028511	CAP, .1UF 50V 80/-20% AX CER
70028514	CAP, .1UF 50V 20% AX CER Z5U
70028515	CAP, .33UF 50V 20% AX CER Z5U
70028516	CAP, .47UF 50V 20% AX CER Z5U
70028517	CAP, .47UF 50V 80/-20% AX CER
70028523	CAP, .22UF 100V 20% AX CER Z5U
70028601	CAP, 100PF 50V 10% AX CER X7R
70028606	CAP, 220pF 50V 10% AX CER X7R
70028612	CAP, 470PF 50V 10% AX CER X7R
70028618	CAP, 1000PF 50V 10% AX CER X7R
70028636	CAP, .01UF 50V 10% AX CER X7R
70028638	CAP, .012UF 50V 10% AX CER X7R
70028641	CAP, .022UF 50V 10% AX CER X7R
70028649	CAP, .1uF 50V 10% AX CER XR7
70028705	CAP, 22PF 50V 10% AX CER COG
70028709	CAP, 47PF 50V 10% AX CER C0G
70028713	CAP, 100pF 50V 10% AX CER COG
70028719	CAP, 330pF 50V 10% AX CER COG
70028827	CAP, 120PF 50V 5% SMD CER NPO
70028837	CAP, 330PF 50V 5% SMD CER NPO
70028931	CAP, .0039UF 50V 5% SMD CER

70028933	CAP, .0047UF 50V 5% SMD CER
70028966	CAP, .1UF 50V 20% SMD CER X7R
70030004	XSTR, NPN 40V .5A MPS6531
70030005	TRANSISTOR-SILICON (NPN)
70030007	XSTR, NPN 25V 100MA MPS6521
70030008	XSTR, NPN 80V .5A MPSA06 TO-92
70030010	XSTR, NPN 45V 200MA SMD BCX70G
70030016	TRANSISTOR-SILICON (NPN) 2222
70030101	XSTR, PNP 25V .5A 3638A TO-92
70030104	XSTR, PNP -80V .5A MPS-A56
70030105	XSTR, PNP 60VCEO 1A D41D8
70030202	XSTR, NPN DARLINGTON MPSA14
70030205	TRANSISTOR-SILICON (DARL AMP)
70030206	XSTR, NPN DARLINGTON AMP 100V
70030207	XSTR, PNP DARLINGTON AMP 100V
70030213	XSTR, NPN DARLINGTON AMP 40V
70030214	XSTR, PNP DARLINGTON AMP 40V
70030215	XSTR-NPN DARLINGTON (40V)
70030301	XSTR, NPN DUAL 50V 30MA MD8002
70030401	XSTR, PNP 60V 3A 40W TIP32A
70030403	XSTR, PNP BIPLR 100V 3A TIP32C
70030504	TRANSISTOR-POWER (SILICON NPN)
70030805	XSTR, PNP DARLINGTON PWR 60V
70030807	XSTR, NPN DARLINGTON PWR 60V
70030808	XSTR, NPN DARLINGTON PWR 100V
70030809	XSTR, NPN DARLINGTON POWER 5A
70030901	XSTR, J-FET N-CHAN -25V 2N5484
70031101	TRANSISTOR-SWITCHING (NPN)
70031201	N CHANNEL POWER FET
70031204	N CHANNEL POWER FET
70031301	XSTR, NPN 25V 200MA 2N4124
70031503	XSTR, UNIJUNCTION 40V 2N6027
70033005	XSTR, NPN 60V 3A TIP31A TO-220
70033006	XSTR, NPN HIGH PWR 100V 3A
70033101	PHOTOXSTR, NPN SIDE LOOKING
70033202	PHOTOTRANSISTOR (NPN)
70033204	PHOTOTRANSISTOR (NPN)
70033401	SENSOR-REFLECTIVE, OBA
70033504	EMITTER, INFRARED OF 70033501
70033505	DETECTOR, INFRARED OF 70033501
70033601	SENSOR-REFLECTIVE OBJECT (IR)
70033602	SENSOR, REFLECTIVE OBJECT IR
70033605	OPTICAL SENSOR-INTERUPTOR
70033606	SLOTTED-OPTICAL SWITCH
70033702	IC, PHOTOCOUPLER OPTO-ISOLATOR
70033703	IC, PHOTOCOUPLER OPTO-TRIAC
70033705	IC, OPTOCOUPLER OPTO-TRIAC
70033706	IC, PHOTOCOUPLER OPTO-COUPLER
70033707	IC, PHOTOCOUPLER AC INPUT
70033710	IC, PHOTOCOUPLER OPTO-ISOLATOR
70033711	IC, OPTOCOUPLER QUAD XSTR OUT

70033712	IC, PHOTOCOUPLER OPTO-ISOLATOR
70033713	IC, PHOTOCOUPLER OPTO-ISOLATOR
70033714	IC, 2-CHANNEL OPTOCOUPLER
70033801	IC, TIMER 555 DIP-8
70034001	IC, QUAD 2-INPUT NOR GATE CMOS
70034002	IC-CMOS DUAL QUAD NAND GATE
70034013	IC, DUAL D FLIP-FLOP CMOS 4013
70034021	IC, 8-BIT SHIFT REGISTER 4021
70034025	IC, TRIPLE TRI-INPUT NOR GATE
70034028	IC, DECODER BIN/DEC CMOS 4028
70034029	IC, PRESETTABLE BINARY/DECADE
70034049	IC, HEX BUF/CONV INVTR CMOS
70034050	IC, HEX BUFFER NON-INV 4050
70034051	IC, 8-CHANNEL MUX/DEMUX CMOS
70034066	IC, QUAD ANALOG SWITCH/MUX
70034097	IC, TRI-STATE HEX BUFFER CMOS
70034106	IC, HEX SCHMITT TRIGGER CMOS
70034151	IC, 8-INPUT MULTIPLEXER CMOS
70034201	IC, DISPLAY DRIVER 5480 DIP-28
70034202	IC, DISPLAY DRIVER 5450 DIP-40
70034203	IC, DISPLAY DRIVER 5481 DIP-20
70034511	IC, BCD 7-SEG DECODER DRIVER
70034538	IC, DUAL MULTIVIBRATOR CMOS
70034704	IC, DUAL UART SCC2692AC1N40
70034705	IC, MICROCOMPUTER SBC-2
70034710	MICROCOMPUTER-8 BIT PROGRAMMED
70035004	DIODE, RECT 100V 3A 1N5401 T/R
70035005	DIODE-SILICON 1N4004
70035006	DIODE, RECT 400V 3A 1N5404
70035007	DIODE, SIGNAL 75V .75A 1N914B/
70035008	DIODE, RECT 1000V 8A 1N4007
70035009	DIODE, SIGNAL 30V 1N4157
70035010	DIODE, RECT 200V 8A MR752 CER
70035012	DIODE-SILICON IN4148
70035013	DIODE, RECT 400V 1.5A 1N5395
70035014	DIODE-SILICON TMPD4148
70035015	DIODE, RECT 400V 1A SMD SOD-80
70035017	DIODE, RECT 50V 5A MR820 CER
70035021	DIODE-SILICON
70035022	DIODE,FAST RECOVERY-1N 4937
70035024	DIODE-SILICON UF1005
70035101	DIODE, RECT 1V 90MA 1N270 DO-7
70035201	LED, VISIBLE RED DIF T1-3/4
70035303	LED, VISIBLE RED DIF T1-3/4 3V
70035305	LED, VISIBLE RED DIF T1-3/4
70035308	DIODE-LIGHT EMIT (INFRARED)
70035314	LED, VISIBLE GREEN T1-3/4 3V
70035315	LED, VISIBLE RED 2.5V CONE TOP
70035316	LED, VISIBLE RED ULTRA-HIGH
70035317	LED, VISIBLE YEL 50MA T1-3/4
70035318	DIODE-LIGHT EMITTING (GREEN)

70035319	LED, VISIBLE RED DIF 100MW
70035330	LED, BI-COLOR YELLOW/GREEN
70035333	LED EMITTER-350MA RED
70035334	LED EMITTER-350MA AMBER
70035335	LED EMITTER-350MA BLUE
70035336	LED EMITTER-350MA GREEN
70035337	LED EMITTER-350MA WHITE
70035338	LED-RED T1-3/4 HIGH INTENSITY
70035401	LED, FLASHING RED
70035501	DIODE-ZENER 1N4733A 5.1V 5%
70035503	DIODE-ZENER 1N4745A 16V 5%
70035506	ZENER, 13V 1W 5% 1N4743A T/R
70035507	ZENER, 5.6V 1W 5% 1N4734A T/R
70035508	ZENER, 6.2V 1W 5% 1N4735A T/R
70035512	ZENER, 24V 5% 1W AXIAL 1N4749A
70035514	ZENER, 10V .4W 5% 1N961B T/R
70035516	ZENER, 18V 1A 5% 1N4746A T/R
70035520	ZENER, 7.5V .4W 5% 1N958B T/R
70035521	ZENER, 10V 1W 5% 1N4740A T/R
70035522	ZENER, 15V .4W 5% 1N965B T/R
70035523	ZENER, 33V 1W 10% 1N4752 T/R
70035524	ZENER, 5.6V .5W 5% 1N5232B T/R
70035526	ZENER, 5.1V .5W 5% 1N5231B T/R
70035528	DIODE-ZENER 8.2V 5% 1N5237B
70035529	DIODE-ZENER 14V 5% 1N5244B
70035531	DIODE-ZENER 15V 5% 1N4744A
70035603	REFERENCE-VOLTAGE 4.096V
70035803	LENS-LED (RED)
70035901	INDICATOR-LED
70035902	INDICATOR-LED
70036303	IC, SELECTOR/MULTIPLEXER 74150
70036304	IC, HEX INVERTER TLL 7404
70036305	IC, HEX BUFFER OPEN COLLECTOR
70036306	IC, 7-SEG DECODER/DRIVER TTL
70036307	IC, TRIPLE 3-INPUT NOR GATE
70036308	IC, 8-BIT SHIFT REGISTER LSTTL
70036309	IC, HEX BUFFER OPEN COL TTL
70036311	IC, HEX BUFFER INVERTER TTL
70036501	VOLT REG, 5V LM340-5/7805 TO-3
70036505	VOLT REG, 5V LINEAR LM340T-5.0
70036506	VOLT REG, 5V .5A LM340/7805
70036507	VOLT REG, ADJ POS LM317T
70036508	VOLT REG, ADJ LM337 TO-220
70036510	VOLT REG, POS ADJ LM317 TO-3
70036511	REGULATOR-VOLTAGE (ADJ POS)
70036513	IC, VOLT REGULATOR CONVERTER
70036514	VOLT REG, 5V 1A 4% LM317HVK
70036515	VOLT REG, 5V 78L05 TO-92
70036516	I.C., VOLT REG 12V LINEAR
70036518	VOLT REG, 12V LINEAR LM7812
70036520	VOLT REG, ADJ SWITCHING 2576

70036521	VOLT REG, -12V/-200V LM7912CT
70036524	IC, VOLT REG SWITCHING POWER
70036525	VOLTAGE REG
70036527	IC-VOLT REG.LM350T 3AMP T0220
70036528	VOLTAGE REGULATOR-LOW DROPOUT
70036601	IC, RAM 256 X 4 STATIC CMOS
70036602	IC, RAM 2K X 8 STATIC CMOS
70036619	IC, 32K X 8 SRAM 62256 DIP
70036801	IC, QUAD COMPARATOR 3302/LM339
70036802	IC, DUAL COMPARATOR LOW POWER
70036901	IC, DARLINGTON ARRAY ULN2003
70036902	IC, 7-CHAN DARLINGTON ARRAY
70036906	IC, HIGH CURRENT SOURCE DRIVER
70036907	IC, DARLINGTON ARRAY SMD 2003
70036913	I.C. DRIVER-OCTAL SINK
70037003	THERMISTOR
70037004	THERMISTOR, 10K 10% AX (GLASS)
70037101	IC, BCD TO 1 OF 10 DECODER
70037105	IC, OCTAL TRANSPARENT LATCH
70037107	IC, HEX INVERTER 74LS04 DIP-14
70037108	IC, HEX INVERTER OPEN COLLECTR
70037109	IC, DUAL J-K FLIP FLOP 74LS112
70037111	IC, OCTAL EDGE TRIGGERED F/F
70037113	IC, DUAL 1 OF 4 DECODER TTL
70037116	IC, QUAD 2-INPUT NAND GATE TTL
70037117	IC, QUAD D FLIP FLOP 74LS175
70037118	IC, OCTAL BUFFER 74LS244N
70037122	IC, DEMULTIPLEXER 4-16 TTL
70037125	IC, DATA SELECT/MULTIPLEXER
70037141	IC, OCTAL D-F/F LATCH HCT SMD
70037144	IC, MICROCONTROLLER CMOS SMD
70037301	IC, QUAD 2-INPUT NAND GATE
70037503	VARISTOR, 30J 150VRMS RAD MO
70037505	VARISTOR, .8J 10VRMS RAD MO
70037506	VARISTOR, 2.3J 35VRMS RAD MO
70037512	MOSORB, TRANSIENT SUPPRESSOR
70037601	CURRENT REG, 10MA LINEAR LM334
70037701	VOLT REF, 1.2V LM385 TO-92
70037801	IC, TRANSCEIVER RS485 SN75176
70037802	IC, TRANSCEIVER RS485 SMD SO-8
70038002	THYRISTOR, SCR 30V 6A 2N5060
70038003	THYRISTOR-SCR
70038004	THYRISTOR, SCR 400V 20A 30W
70038102	THYRISTOR, TRIAC 400V 6A 10W
70038106	THYRISTOR, TRIAC 200V 1.6A 10W
70038110	THYRISTOR, TRIAC 200V 15A 10W
70038111	THYRISTOR, TRIAC 400V 25A
70038113	THYRISTOR, TRIAC 400V 15A 20W
70038115	THYRISTOR-TRIAC
70038210	IC-16K X 8 (PROGRAMMED EPROM)
70038212	IC-16K X 8 (PROGRAMMED EPROM)

70038213	IC, EPROM 16K X 8 REC/VID/CD
70038222	IC-16K X 8 PROGRAMMED EPROM
70038325	IC, EPROM 32K X 8 CD100
70038506	MICROCOMPUTER-8 BIT (8748)
70038514	MICROCOMPUTER-8 BIT (8748)
70038516	MICROCOMPUTER-8 BIT (8748)
70038604	IC, 8-BIT MICROCOMPUTER BC-1
70039002	IC, MICROCOMPUTER 6500/1 R1016
70039003	IC, MICROCOMPUTER PHONO C.C.C.
70039005	MICROCOMPUTER 3870
70039017	IC-MICROCOMPUTER PROGRAMMED
70039023	IC-MICROCOMPUTER PROGRAMMED
70039025	IC-MICROCOMPUTER PROGRAMMED
70039027	IC-MICROPROCESSOR PROGRAMMED
70039034	IC-MICROCOMPUTER PROGRAMMED
70039036	IC-MICROCOMPUTER PROGRAMMED
70039041	IC, MICROPROC PROG PIC 16F73
70039043	IC, PROG PIC 16F73 (IR VOL)
70039046	IC-MICROCOMPUTER PROGRAMMED
70039103	IC, PERIPHERAL I/F ADAPTOR
70039111	IC, EPROM 8K X 8 2764 DIP-28
70039114	IC, MICROPROCESSOR 6502 DIP-40
70039115	IC, MICROCOMPUTER 8-BIT 8035
70039125	IC, MICROPROCESSOR 8-BIT W/MEM
70039126	IC, MICROPROCESSOR 512KB 64180
70039201	IC, MICROCOMPUTER 8-BIT EPROM
70039205	IC, MICROCOMPUTER 8-BIT OBA
70039208	MICROCOMPUTER-8 BIT (8749)
70039214	MICROCOMPUTER-8 BIT (8749)
70039216	MICROCOMPUTER-8 BIT (8749)
70039219	MICRO COMPUTER-OBA (V6.0)
70039223	IC, MICROCOMPUTER 8-BIT CBA1B
70039224	MICROCOMPUTER-8 BIT (8749)
70039303	IC-MICROCOMP 8 BIT (8050)
70039309	I.C.-OBA CONTROL
70039310	IC, MICROCOMPUTER 8-BIT 8050
70039311	IC, MICROCOMPUTER 8-BIT 8050
70039401	PROCESSOR-VIDEO DISPLAY
70039402	IC, MICROCOMPUTER 8-BIT 8050
70039403	IC, MICROCONTROLLER 8-BIT
70039404	IC, MICROCOMPUTER IR REMOTE
70039408	IC, MICROCOMPUTER MC68HC05J1AP
70039411	MICROCOMPUTER-87C52 NSBC
70039501	IC, EPROM 4K X 8 2732 DIP-24
70039504	IC-4KX8 EPROM (2732) VIDEO-A
70039507	IC-4KX8 EPROM(2732)SYNTECH OBA
70039508	IC-4KX8 EPROM(2732)STD OBA
70039514	IC, EPROM 4K X 8 OBA HAMILTON
70039516	IC-EPROM(4KX8)(BC-35 HI-SEC)
70039518	IC-4K X 8 EPROM (BC-35 V4.1)
70039522	IC-EPROM (4KX8)(2732)(OBA,BC-1

70039523	IC-4K X 8 EPROM (OBA-4)
70039531	IC-4KX8 EPROM (SPECIAL BC-35)
70039537	IC-4K X 8 EPROM (OBA-2)
70039601	IC, DIGITAL PORT EXPANDER 8243
70039904	EPROM-CCC-27512 (1 VCR SYSTEM)
70039906	EPROM-CCC (27512)(DUAL PHONO)
70040001	POTENTIOMETER (2.5K)
70040003	POTENTIOMETER (750 OHM)
70040009	POT,200/250K 1/4W30% LIN'R HOZ
70040010	POT, 10K 1/4W 30% LINEAR HOZ
70040012	POT, 2K 1/4W 10% LINEAR HOZ MT
70040014	POT, 10K 1/4W 20% LINEAR HOZ
70040017	POT, 1MEG 1/4W 20% LINEAR HOZ
70040018	POT, 10K 1/4W 20% LOG TAP HOZ
70040022	POT-DUAL AUDIO PC 90 DEG 5K
70040023	POT 100K 20% .05W LINEAR
70040024	POT 10K 20% .05W LINEAR
70040304	TERMINAL
70040406	HOUSING-CAP (MINI MAT-N-LOCK)
70040409	HOUSING-CAP (MINI MAT-N-LOCK)
70040415	HOUSING-CAP (MINI MAT-N-LOCK)
70040504	POT, 5K .1W 30% LINEAR VERT
70040516	POTENTIOMETER-TRIMMER (10K)
70040518	POT, 50K .1W 30% LINEAR HORIZ
70040701	CONTACT-MINI MAT-N-LOCK (PIN)
70040702	CONTACT-MINI MAT-N-LOCK (SCKT)
70040703	CONTACT-MINI MAT-N-LOCK (PIN)
70040704	CONTACT-MINI MAT-N-LOCK (SCKT)
70041106	HOUSING-PLUG (MINI MAT-N-LOCK)
70041109	HOUSING-PLUG (MINI-N-LOCK)
70041112	HOUSING-PLUG (MINI MAT-N-LOCK)
70041401	INDUCTOR, 2MH AIR CORE 20AWG
70041404	INDUCTOR, 5MH AIR CORE 26AWG
70041502	INDUCTOR, .33UH 20% RF AX T/R
70042207	RELAY-REED (PC-12V)
70042208	RELAY, SPDT 12-15V .5A REED
70042405	RELAY, DPDT 12V 30W 1.25A COIL
70042411	RELAY-P C BOARD
70042413	RELAY, SPDT 12V 2A 60W COIL
70042501	RELAY, DPDT 12 VDC COIL UL
70042502	RELAY, DPDT 28V 5A COIL UL
70042602	CONNECTOR-2MM IDP 2 CKT
70042604	CONNECTOR-2.0MM IDP
70042607	CONNECTOR-2.0MM IDP
70042701	IC-EPROM (128K X 8)
70042703	IC-EPROM 128K X 8 HOME PHONO
70042704	IC-EPROM 128K X 8 CD100
70042705	IC-EPROM (MEG) (DUAL PHONO)
70042709	IC-EPROM 128K X 8 WALLBOX
70042712	IC-EPROM 128K X 8 CD100K
70042720	IC-EPROM 128K X 8 PROGRAMMED

70042902	SWITCH, DIP 2POS DPST
70043003	SWITCH, DIP 6POS TOGGLE/SLIDE
70043008	SWITCH, DIP 4POS SLIDE ON/OFF
70043009	SWITCH, DIP 1POS SLIDE ON/OFF
70043010	SWITCH, DIP 5POS SLIDE PCB MT
70043011	SWITCH, DIP 8POS TOGGLE/SLIDE
70043101	SWITCH, DIP 11POS TOGGLE 40V
70043502	SWITCH, PB SPST NO .449"D-BASE
70045001	SWITCH, SLIDE DPDT 125V .5A
70060022	LAMP-FLUORESCENT (15W T-8)
70060102	LAMP-FLUORESCENT
70060103	LAMP-FLUORESCENT
70060104	LAMP-FLUORESCENT (20W T-12)
70060107	LAMP-FLUORESCENT (19W T-8)
70060108	LAMP-FLUORESCENT (18W T-8)
70060110	LAMP-FLUORESCENT
70060111	FLUORESCENT LAMP
70060112	LAMP-FLUORESCENT (30W T-8)
70060113	LAMP FLUORESCENT
70060115	LAMP FLUORESCENT
70060116	FLUORESCENT LAMP-BLUE BLACK
70060411	LAMP-GLOBAL (A-19 INSIDE FROST
70060419	LAMP-TRANSPARENT GREEN
70060421	LAMP-TRANSPARENT YELLOW
70060423	LAMP-GLOBAL (INSIDE FROSTED)
70060424	LAMP-GLOBAL
70070501	SOCKET-LAMP (SUB MIN WEDGE)
70071902	FUSE, PICO SLOW-BLOW 1A 125V
70072002	FUSE, 8A, 250V, FAST ACTING
70072008	FUSE-CARTRIDGE (3 AMP)
70072101	FUSE, SLOW BLOW 1/2A 125V
70072105	FUSE
70072106	FUSE-CARTRIDGE (5 AMP)
70072504	RES-PTC .88 OHM 60V .30A
70072903	CIRCUIT BREAKER (3 AMP)
70072911	CIRCUIT BREAKER (3 AMP)
70073411	CIRCUIT BREAKER (1 AMP)
70073415	CIRCUIT BREAKER (2 AMP)
70073417	CIRCUIT BREAKER (3 AMP)
70073425	CIRCUIT BREAKER (10 AMP)
70073508	CIRCUIT BREAKER (5 AMP)
70073601	CIRCUIT BREAKER (1/2 AMP)
70073604	CIRCUIT BREAKER (1 AMP)
70073605	CIRCUIT BREAKER (2 AMP)
70073606	CIRCUIT BREAKER (3 AMP)
70073608	CIRCUIT BREAKER (5 AMP)
70073610	CIRCUIT BREAKER (7 AMP)
70073613	CIRCUIT BREAKER (10 AMP)
70073710	CKT BREAKER-PC MOUNT (3.15A)
70073928	SOCKET, IC DIP-28 MACH PINS
70073932	SOCKET, IC DIP-32 MACH PINS

70074240	SOCKET, IC DIP-40 TINNED STD
70074303	CON, HDR 3POS 2.5MMCTR STRAIT
70074304	CON, HDR 4POS 2.5MMCTR STRAIT
70074306	CON, HDR 6POS 2.5MMCTR STRAIT
70074307	CON, HDR 7POS 2.5MMCTR STRAIT
70074413	CON, HDR 13POS 2.5MMCTR 90DEG
70074609	WAFER-CHASSIS MTG (9 CKT)
70074802	CON, SKT 4POS .156"CTR STRAIT
70074904	CON, HDR 4POS .156"CTR STRAIT
70074923	CON, HDR 5POS .156"CTR STRAIT
70074931	CON, HDR 13POS .156"CTR STRAIT
70075003	CON, HDR 3POS .156"CTR STRAIT
70075004	CON, HDR 4POS .156"CTR STRAIT
70075005	CON, HDR 5POS .156"CTR STRAIT
70075006	CON, HDR 6POS .156"CTR STRAIT
70075007	CON, HDR 7POS .156"CTR STRAIT
70075010	CON, HDR 10POS .156"CTR STRAIT
70075011	CON, HDR 11POS .156"CTR STRAIT
70075012	CON, HDR 12POS .156"CTR STRAIT
70075015	CON, HDR 15POS .156"CTR STRAIT
70075017	CON, HDR 17POS .156"CTR STRAIT
70075018	CON, HDR 18POS .156"CTR STRAIT
70075502	CON, HSG 2POS .156"CTR STRAIT
70075503	CON, HSG 3POS .156"CTR STRAIT
70075504	CON, HSG 4POS .156"CTR STRAIT
70075505	CON, HSG 5POS .156"CTR STRAIT
70075506	CON, HSG 6POS .156"CTR STRAIT
70075507	CON, HSG 7POS .156"CTR STRAIT
70075508	CON, HSG 8POS .156"CTR STRAIT
70075509	HOUSING-CONNECTOR (9 PIN)
70075510	CON, HSG 10POS .156"CTR STRAIT
70075511	CON, HSG 11POS .156"CTR STRAIT
70075512	HOUSING-CONNECTOR (12 PIN)
70075513	CON, HSG 13POS .156"CTR STRAIT
70075514	HOUSING-CONNECTOR (14 PIN)
70075515	CON, HSG 15POS .156"CTR STRAIT
70075517	HOUSING-CONNECTOR (17 PIN)
70075518	CON, HSG 18POS .156"CTR STRAIT
70075601	CONTACT, POST 18-24AWG FEMALE
70075701	PLUG, KEYING .300"LG .100"SQ
70075702	PLUG, KEYING .300"LG .100"SQ
70075804	CON, HSG 4POS 2.5MMCTR STRAIT
70075805	HOUSING-TERMINAL (5 CKT)
70075806	HOUSING-TERMINAL (6 CKT)
70075808	HOUSING-TERMINAL (8 CKT)
70075809	HOUSING-TERMINAL (9 CKT)
70075812	HOUSING-TERMINAL (12 CKT)
70075813	HOUSING-TERMINAL (13 CKTS)
70075815	HOUSING-TERMINAL (15 CKT)
70075901	CONTACT, TERM 22-28AWG FEMALE
70076002	CON, HDR 2POS .156"CTR 90DEG

70076004	CON, HDR 4POS .156"CTR 90DEG
70076007	CON, HDR 7POS .156"CTR 90DEG
70076008	CON, HDR 8POS .156"CTR 90DEG
70076009	CON, HDR 9POS .156"CTR 90DEG
70076011	CON, HDR 11POS .156"CTR 90DEG
70076014	CON, HDR 14POS .156"CTR 90DEG
70076015	CON, HDR 15POS .156"CTR 90DEG
70076416	CON, HDR 16POS .1"CTR STRAIGHT
70076603	CONNECTOR-EDGE (3 CKT)
70077001	SOCKET-MINIATURE (SPRING)
70078716	HEADER
70078822	CON, HDR 22POS .1"CTR STRAIGHT
70078956	CIRCUIT BREAKER (6 AMP)
70079713	CON, HDR 13POS 2.5MMCTR 90DEG
70080001	STARTER-FLUORESCENT (FS-2)
70080002	STARTER-FLUORESCENT (FS5)
70080003	STARTER-FLUORESCENT (FS-25)
70080004	STARTER-FLUORESCENT (FS-4)
70080801	SHUNT, .1"PITCH
70084002	CON, HDR 2POS 2MMCTR STRAIGHT
70084004	CON, HDR 4POS 2MMCTR STRAIGHT
70084008	CON, HDR 8POS 2MMCTR STRAIGHT
70084104	CONNECTOR-2.0MM IDP
70084106	CONNECTOR-2.0MM IDP
70084107	CONNECTOR-2.0MM IDP
70084108	CONNECTOR-2.0MM IDP (8 CKT)
70084207	CONNECTOR-2MM-IDP (90)
70084709	CON, HDR 9POS 2MMCTR STRAIGHT
70084712	CON, HDR 12POS 2MMCTR STRAIGHT
70085320	HEADER-SHROUDED (MOLEX)
70085620	CON, 20 POS DUAL ROW INTERIM
70087003	CON, HSG 3POS .1"CTR STRAIGHT
70087030	CONTACT, TERM 22-26AWG CST FEM
70088914	CON, HDR 14POS 2MM CTR 90DEG
70091012	TERMINAL LUG - SPADE
70091302	TERM, .187 20-16AWG TIN PLATED
70091308	TERMINAL LUG-SLIP ON (.250)
70091702	LUG-SOLDER
70092107	CONNECTOR-SOLDERLESS
70092108	CONNECTOR-SOLDERLESS
70092601	CONTACT-SOCKET
70092602	CONTACT-PIN
70092610	CONTACT-PIN
70092611	CONTACT-SOCKET
70092708	RECEPTACLE-PIN
70092802	TERM, .250" 26-22AWG PCB MT
70092904	TERMINAL-MODIFIED FORK
70093101	CLAMP-CABLE (1/8)
70093102	CLAMP-CABLE (3/16)
70093103	CLAMP-CABLE (1/4)
70093104	CLAMP-CABLE (5/16)

70093105	CLAMP-CABLE (3/8)
70093106	CLAMP-CABLE (7/16)
70093107	CLAMP-CABLE (1/2)
70093112	CLAMP-CABLE (1-3/8)
70093303	CLAMP-CABLE
70093401	CLAMP-CABLE (17/32)=(1/2")
70093402	CLAMP-CABLE (13/16)
70093403	CLAMP-CABLE (1")
70093502	CLAMP-CABLE (SNAP-IN)
70093801	CLAMP-CABLE (CFCC)
70096303	TERMINAL BLOCK (4 TERM)
70096512	TERMINAL STRIP-BARRIER
70096703	TERM, FSTN 22-18AWG 90DEG INSL
70096705	FASTON-INSULATED (.250)
70097501	CONTACT, PIN 24-18AWG UNIV
70097502	CONTACT-UNIV CONN (SOCKET)
70097503	CONTACT-UNIV CONN (PIN)
70097504	CONTACT-UNIV CONN (SOCKET)
70097506	CONTACT-UNIV CONN (SOCKET)
70097507	CONTACT-UNIV CONN (PIN)
70099101	SPLICE-SELF STRIPPING
70099201	TERMINAL-SELF STRIPPING (.250)
70099301	SPLICE-SELF STRIPPING (2 WAY)
70110113	PIN-GROOVE (1/8 X 5/8)
70110114	PIN-DRIVE (3/16 X 1/2)
70110126	PIN-GROOVE (1/8 X 3/4)
70111007	RIVET-SEMI TUBULAR .121X11/64
70111105	RIVET-SEMI TUBULAR .187X3/16
70111107	RIVET-SEMI TUBULAR .121X1/4
70112508	RIVET-POP
70113003	PIN-ROLL .131/.135 X 11/16
70113005	PIN-ROLL .066/.069 X 7/16
70113006	PIN-ROLL .083/.086 X 5/8
70113013	PIN-ROLL .099/.103 X 7/8
70113019	PIN-ROLL .083/.086 X 3/4
70113022	PIN-ROLL .099/.103 X 1/2
70113023	PIN-ROLL .131/.135 X 1-1/4
70113106	PIN-ROLL .083/.086 X 1/2
70113114	PIN-ROLL .066/.069 X 5/8
70113116	PIN-ROLL .099/.103 X 3/4
70113205	PIN-SPIROL 5/6X O X11/16
70120001	WASHER
70120010	WASHER, #10 FLAT
70120019	WASHER
70120501	WASHER-PLAIN
70120524	WASHER-PLAIN
70120603	WASHER-PLAIN
70120703	WASHER-PLAIN (NYLON)
70120723	WASHER-PLAIN (NEOPRENE)
70120801	WASHER-PLAIN (TEFLON)
70120815	WASHER-PLAIN

70120903	WASHER
70120904	WASHER-NYLON
70120914	WASHER
70120915	WASHER
70120917	WASHER
70121010	SPACER
70121211	SPACER
70121401	SPACER
70121408	SPACER
70121413	SPACER
70121513	SPACER, 1/4"OD .140"ID 5/16"LG
70121517	SPACER
70121522	SPACER
70121612	SPACER
70121624	SPACER
70121626	SPACER (NYLON)
70121701	SPACER
70121706	SPACER
70121721	SPACER
70121734	SPACER
70121736	SPACER
70121739	SPACER
70121749	SPACER
70121756	SPACER
70121763	SPACER-NYLON .25 OD X.125 LONG
70121764	SPACER-NYLON 1/4 OD X 1 LONG
70122001	WASHER-INTERNAL LOCK
70122009	WASHER-INTERNAL LOCK
70122533	WASHER-BOWED
70124004	WASHER-CUP (TERMINAL) #8
70130109	9/16-18 JAM NUT
70130114	15/32-32 HEX MS NUT (THIN)
70134103	SCREW-SPECIAL(10-24 X 3/4)
70134109	SCREW-SPECIAL(8-32 HEX WHMS)
70134112	SCR-SPL(8-32 SEMS HEX WR HD SF
70134121	SCREW-SPECIAL(1/4-20 CARRIAGE)
70134122	SCREW-SPECIAL(1/4-20 CARRIAGE)
70134127	SCREW-SPECIAL
70134129	SCREW, S/T #8-18 X 3/8"
70134201	EYE BOLT (1/4-20 X 2)
70134501	THUMBSCREW (#6-32)
70134502	THUMBSCREW (#10-32)
70135508	PALNUT (3/16)
70135511	PALNUT (3/8-32)
70135512	PALNUT
70135514	PALNUT (5/32)
70135517	PALNUT
70136508	BRAD-COHERED
70137101	LEVELER
70138006	SCREW, COATED #4-40X1/2" HWHMS
70138102	SCREW, COATED 8-32 X 1/4 HWHMS

70143001	RING, EXT RETAINING .230"OD
70143002	RING-EXTERNAL RETAINING
70143003	RING-EXTERNAL RETAINING
70143004	RING-EXTERNAL RETAINING
70143005	RING-EXTERNAL RETAINING
70143006	RING-EXTERNAL RETAINING
70143010	RING-EXTERNAL RETAINING
70143018	RING-EXTERNAL RETAINING
70143301	RING-EXTERNAL RETAINING
70143801	RING-EXTERNAL RETAINING
70146001	BEARING-NYLINER
70146003	BEARING-NYLINER
70146004	BEARING-NYLINER
70146005	BEARING-NYLINER
70146006	BEARING-NYLINER
70146008	BEARING-NYLINER
70146010	BEARING-NYLINER
70146021	BEARING-NYLINER
70146601	BEARING-SLEEVE TYPE
70150103	STANDOFF-SELF CLINCHING
70150304	STUD-SELF CLINCHING(#8-32X1/4)
70162004	CYLINDER-LOCK (INDIV KEYING)
70162008	CYLINDER-LOCK (INDIV KEYING)
70162011	CYLINDER-LOCK (INDIV KEYING)
70162012	CYLINDER-LOCK (INDIV KEYING)
70163203	CYLINDER-LOCK (COMMON KEYING)
70163210	CYLINDER-LOCK (COMMON KEYING)
70163211	CYLINDER-LOCK (COMMON KEYING)
70163212	CYLIN LOCK TYPES(COMMON KEYING)
70163214	CYLINDER LOCK TYPES-COMMON
70163215	CYLINDER LOCK TYPES-COMMON KEY
70166006	LOCKBOLT-STRAIGHT
70166008	LOCKBOLT-STRAIGHT
70166010	LOCKBOLT-STRAIGHT
70166011	LOCKBOLT-STRAIGHT
70166012	LOCKBOLT-STRAIGHT
70210501	MOLDING-PROTECTIVE
70212110	SPONGE RUBBER
70212234	SPONGE RUBBER-CLOSED CELL
70212403	CORK COMPOSITION STRIP
70212412	CORK COMPOSITION STRIP
70212413	CORK COMPOSITION STRIP
70212507	FELT STRIP (ADHESIVE BACK)
70218209	TUBING-HEAT SHRINK
70218210	TUBING-HEAT SHRINK
70220486	FOAMED TAPE (3/4 X 1/2 X 39)
70220804	TAPE FOAMED
70221003	FOAMED PAD
70225006	EXTRUSION-FOAM RUBBER
70225008	EXTRUSION-FOAM RUBBER
70225010	EXTRUSION-FOAM RUBBER

70225015	EXTRUSION-FOAM RUBBER(1.50" LG
70225016	EXTRUSION-FOAM RUBBER(4.50" LG
70225101	EXTRUSION-FOAM RUBBER
70225106	EXTRUSION-FOAM RUBBER
70232104	STRAIN RELIEF
70232107	STRAIN RELIEF
70232203	STRAIN RELIEF
70232204	STRAIN RELIEF
70232301	STRAIN RELIEF-RT ANGLE
70232302	STRAIN RELIEF-RT ANGLE
70232401	STRAIN RELIEF, SPT-1 18/3 BLK
70233012	BUSHING-SNAP
70233202	BUSHING-SNAP (SPLIT)
70233204	BUSHING-SNAP (SPLIT)
70233205	BUSHING-SNAP (SPLIT)
70233206	BUSHING-SNAP (SPLIT)
70233207	BUSHING-SNAP (SPLIT)
70233208	BUSHING-SNAP (SPLIT) 1" I.D.
70239001	CAP-PROTECTIVE
70303401	KEY-MEDICO LOCK
70500004	SUPPORT-CKT BOARD
70500006	SUPPORT-CKT BOARD
70500018	SUPPORT-CKT BOARD
70500102	STANDOFF, 1/2" PCB SPRT POST
70500302	BUTTON-MOUNTING .094
70500308	BUTTON-MOUNTING
70704403	BUMPER
70800101	TIE WRAP, 4" X .10" SELF LOCK
71200001	CLAMP, SPLIT FLAT CABLE
71300080	STAND OFF-PC SUPPORT
71300081	STANDOFF, WP100
79800301	IC-32K X 8 CMOS EPROM
79800302	IC-32K X 8 CMOS EPROM
79800318	IC-32K X 8 EPROM
79800325	IC-8K X 8 EPROM
79800330	IC-64K X 8 EPROM
79800331	IC-32K X 8 EPROM
79800334	IC-32K X 8 EPROM
79800339	IC-8K X 8 EPROM
79800342	IC-64K X 8 EPROM
79800360	IC-32K X 8 EPROM
79800362	IC-32K X 8 EPROM
79800367	IC-32K X 8 EPROM
79800377	IC-32K X 8 EPROM
79800378	IC-64K X 8 EPROM
79800379	IC-64K X 8 EPROM
79800383	IC-64K X 8 EPROM
79800391	IC - 64K X 8 EPROM PROGRAMMED
79800392	IC-BC'S EPROM PROG(ANTI-RETRIE
79800393	IC-BC'S EPROM PROG(ANTI-RETRIE
79800416	IC-64K X 8 EPROM

79800428	IC-27C512 (PROGRAMMED) PAL
79800429	IC-27C512 (PROGRAMMED)NTSC
79800430	IC-64K X 8 EPROM
79800445	IC-EPROM COINMACH SCRIP
79901101	RES, 100 OHM 1/4W 5% CF
79901102	RES, 1K 1/4W 5% CF
79901103	RES, 10K 1/4W 5% CF
79901104	RES, 100K 1/4W 5% CF
79901105	RES, 1M 1/4W 5% CF
79901122	RES, 1.2K 1/4W 5% CF
79901151	RES, 150 OHM 1/4W 5% CF
79901152	RES, 1.5K 1/4W 5% CF
79901153	RES, 15K 1/4W 5% CF
79901181	RES, 180 OHM 1/4W 5% CF
79901182	RES, 1.8K 1/4W 5% CF
79901183	RES, 18K 1/4W 5% CF
79901220	RES, 22 OHM 1/4W 5% CF
79901221	RES, 220 OHM 1/4W 5% CF
79901222	RES, 2.2K 1/4W 5% CF
79901223	RES, 22K 1/4W 5% CF
79901271	RES, 270 OHM 1/4W 5% CF
79901272	RES, 2.7K 1/4W 5% CF
79901330	RES, 33 OHM 1/4W 5% CF
79901331	RES, 330 OHM 1/4W 5% CF
79901332	RES, 3.3K 1/4W 5% CF
79901333	RES, 33K 1/4W 5% CF
79901362	RES, 3.6K 1/4W 5% CF
79901392	RES, 3.9K 1/4W 5% CF
79901470	RES, 47 OHM 1/4W 5% CF
79901471	RES, 470 OHM 1/4W 5% CF
79901472	RES, 4.7K 1/4W 5% CF
79901561	RES, 560 OHM 1/4W 5% CF
79901562	RES, 5.6K 1/4W 5% CF
79901681	RES, 680 OHM 1/4W 5% CF
79901683	RES, 68K 1/4W 5% CF
79901820	RES, 82 OHM 1/4W 5% CF
79901821	RES, 820 OHM 1/4W 5% CF
79901911	RES, 910 OHM 1/4W 5% CF
79902241	RES, 240 OHM 1/4W 2% CF/MF
79902271	RES, 270 OHM 1/4W 2% CF/MF
79902562	RES, 5.6K 1/4W 2% CF/MF
79904100	RESISTOR 10 OHM
79904121	RES, 120 OHMS 1/2W 5% MF
79904150	RES, 15 OHM 1/2W 5% MF
79904151	RES, 150 OHM 1/2W 5% MF
79904152	RES, 1.5K 1/2W 10% MF
79904220	RES, 22 OHM 1/2W 5% MF
79904681	RES, 680 OHM 1/2W 5% MF
79904913	RESISTOR 91K
79905101	RES, 100 OHM 1/8W 5% CF
79905334	RESISTOR, 330K 1/8W 5% C.F.

799093931001	RES NET, 39K X 9 1W 10% SIP-10
799101004	RES, 1 MEG 1/8W 1% SMD1206
799111101	RES, 100 OHM 1/4W 5% SMD1206
799111102	RES, 1K 1/4W 5% SMD1206
799111103	RES, 10K 1/4W 5% SMD1206
799111184	RES, 180K 1/4W 5% SMD1206
79911221	RES, 220 OHM 1/4W 5% SMD1206
79911222	RES, 2.2K 1/4W 5% SMD1206
79911332	RES, 3.3K 1/4W 5% SMD1206
79911333	RES, 33K 1/4W 5% SMD1206
79911391	RES, 390 OHMS 1/4W 5% SMD1206
79911472	RES, 4.7K 1/4W 5% SMD1206
79911561	RES, 560 OHM 1/4W 5% SMD1206
79911681	RES, 680 OHM 1/4W 5% SMD1206
799121002	RES, 10K 1/4W 1% MF
799121602	RESISTOR-METAL FILM 1/4W 1%
799121801	RESISTOR-METAL FILM 1/4W 1%
799122001	RESISTOR-2K 1/4W 1%
799122212	RES, METALFILM 1/4W 1% 22.1K
799124702	RESISTOR-METAL FILM 1/4W 1%
79920100	RES, 10 OHM 2W 10% WW
79920102	RES, 1K 2W 10% WW
79920108	RES, .1 OHM 2W 10% WW
79920121	RES, 120 OHM 2W 10% WW
79920123	RES, 12K 2W 10% MO
79920151	RESISTOR-WW 2W (150 OHMS)
79920159	RES, 1.5 OHM 2W 5% WW
79920208	RESISTOR-WW 2W (.2 OHMS)
79920221	RES, 220 OHM 2W 10% WW
79920272	RES, 2.7K 2W 10% WW/MO
79920278	RES, .27 OHM 2W 10% WW
79920330	RES, 33 OHM 2W 10% WW
79920331	RES, 330 OHM 2W 10% WW OR MO
79920338	RES, .33 OHM 2W 5% WW
79920398	RES, .39 OHM 2W 10% WW
79920471	RES, 470 OHM 2W 10% WW
79920478	RES, .47 OHM 2W 10% WW
79920479	RES, 4.7 OHMS 2W 10% WW
79930000	IC, QUAD 2-INPUT NAND GATE HCT
79930002	IC, QUAD 2-INPUT NOR GATES HCT
79930004	IC, HEX INVERTER HCT 74HCT04
79930010	IC, TRI 3-INPUT NAND GATE HCT
79930014	IC, HEX INVERTER/SCHMITT TRIG
79930032	IC, QUAD 2-INPUT OR GATES HCT
79930138	IC, 1 OF 8 DECODER CMOS
79930151	IC, 8-INPUT DATA SELECT MUX
79930244	IC, OCTAL BUFFER NON-INVERTED
79930245	IC, OCTAL TRANSCEIVER HCT
79930373	IC, 8-BIT LATCH HCT 74HCT373
79930374	IC, OCTAL D-FLIP FLOP TRI-ST
79940000	IC, QUAD 2-INPUT NAND GATE HC

79940002	IC, QUAD 2-INPUT NOR GATE HC
79940008	IC, QUAD 2-INPUT AND GATE CMOS
79940014	IC, HEX SCHMITT-TRIG INVERTER
79940027	I.C.-3 INPUT NOR 74HC27
79940073	HC DUAL JK FLIP FLOP
79940125	IC, QUAD BUFFER CMOS 74HC125
79940151	IC, 8-INPUT DATA SELECT CMOS
79940175	I.C.-QUAD D FF 74HC175
79940244	IC, OCTAL BUFFER TRI-STATE
79940273	IC, OCTAL D-FLIP FLOP W/CLEAR
79940541	IC, OCTAL BUFFER 74HC541
79940574	IC, OCTAL D-LATCH 74HC574
79960165	IC-SHIFT REGISTER 74HC165
80022320	#6-32 X 1-1/4 SL FIL HD MS
80321604	#4-40 X 1/4 PHIL FHMS
80342308	#6-32 X 1/2 PHIL PAN HMS
80343004	SCREW, #8-32 X 1/4" PPHMS CSZP
80351603	#4-40 X 3/16 PHIL RD HMS
80351604	#4-40 X 1/4 PHIL RD HMS
80351606	SCREW, #4-40 X 3/8" PRHMS CSZP
80351608	#4-40 X 1/2 PHIL RD HMS
80351610	#4-40 X 5/8 PHIL RD HMS
80351616	#4-40 X 1 PHIL RD HMS
80382304	#6-32 X 1/4 PRHMS (SWAGE FORM)
80383006	#8-32 X 3/8 PRHMS (SWAGE FORM)
80384405	#10-32X5/16 PRHMS (SWAGE FORM)
80403004	#8-32 X 1/4 PH PHMS(SWAGE FORM)
80403005	#8-32 X 5/16 PH PHMS(SWAGEFORM)
80403006	#8-32 X 3/8 PH PHMS(SWAGE FORM)
80441605	#4-40 X 5/16 HEX WRHS (SF)
80442304	#6-32X1/4 HEX WHS (SWAGE FORM)
80442305	#6-32X5/16 HEX WHS (SWAGE FORM)
80442308	#6-32X1/2 HEX WHS (SWAGE FORM)
80443004	SCREW, #8-32 X 1/4" HWHTF CSZP
80443005	#8-32X5/16 HEX WHS (THD FORM)
80443006	SCREW, #8-32 X 3/8" HWHMS CSZP
80443007	#8-32X7/16 HEX WHS (SWAGE FORM)
80443008	#8-32X1/2 HEX WHS (SWAGE FORM)
80443010	#8-32X5/8 HEX WHS (SWAGE FORM)
80443012	#8-32X3/4 HEX WHMS (SWAGE FORM)
80443014	#8-32X7/8 HEX WHS (SWAGE FORM)
80443016	#8-32 X 1 HEX WHMS (SWAGEFORM)
80443018	#8-32X1-1/8 HEX WHMS(SWAGE FRM)
80443604	#8-32X1/4 HEX WHMS (SWAGE FORM)
80443706	#10-24X3/8 HEX WHMS (SWAGEFORM)
80443708	#10-24X1/2 HEX WHMS (SWAGEFORM)
80444406	#10-32X3/8 HEX WHS (SWAGEFORM)
80444408	#10-32X1/2 HEX WHS(SWAGE FORM)
80444410	#10-32X5/8 HEX WHS (SWAGE FORM)
80500508	#2-56 X 1/2 SEMS PHIL RD HMS
80542304	#6-32 X 1/4 SEMS PHIL RD HMS

80642306	#6-32 X 3/8 SEMS HEX HMS
80653006	#8-32 X 3/8 HEX HD MS
80656912	SCREW-MACHINE 5/16-18x3/4 HEX
80661608	SCREW, #4-40 X 1/2" HEX WHMS
80663004	SCREW, #8-32 X 1/4" HWHMS CSZP
80663020	#8-32 X 1-1/4 HEX WRHMS
80663024	#8-32 X 1-1/2 HEX WRHMS
80682304	#6-32 X 1/4 SL HEX WHMS
80711604	#4-40 X 1/4 SEMS HEX WHMS
80712304	#6-32 X 1/4 SEMS HEX WHMS
80712305	#6-32 X 5/16 SEMS HEX WHMS
80712306	#6-32 X 3/8 SEMS HEX WHMS
80712308	#6-32 X 1/2 SEMS HEX WHMS
80712310	SCREW, SEMS #6-32 X 5/8" HWHMS
80713004	SCREW, SEMS #8-32 X 1/4" HWHMS
80713006	#8-32 X 3/8 SEMS HEX WHMS
80713008	#8-32 X 1/2 SEMS HEX WHMS
80713010	#8-32 X 5/8 SEMS HEX WHMS
80713618	#8-32 X 1 1/8 SEMS HEX WHMS
80715708	1/4-20 X 1/2 SEMS HEX WRHMS
80715716	1/4-20 X 1 SEMS HEX WRHS
80743007	#8-32 X 7/16 SEMS HEX WHMS(SF)
80743010	#8-32X5/8 HEX WHMS (SWAGE FORM
80786108	1/4-20 X 1/2 SKT HD SET SCR
82661604	#4-40 X 1/4 HEX WHS (TYPE 23)
82662310	#6-32 X 5/8 HEX WRHS (TYPE 23)
82663006	#8-32 X 3/8 HEX WRHS (TYPE 23)
82663708	#10-24 X 1/2 HEX WR HD(TYPE 23
82664406	#10-32 X 3/8 HEX WHS (TYPE 23)
83663006	#8 X 3/8 HEX WRHS (TYPE 25)
83663008	#8 X 1/2 HEX WRHS (TYPE 25)
84743004	SCREW, SEMS S/T #8-32 X 1/4"
85342308	#6 X 1/2 PHIL PHMS (TYPE Z)
85352310	#6 X 5/8 PHIL RD HMS (TYPE Z)
86662708	#6 X 1/2 HEX WRHS (TYPE 17)
86663608	#8 X 1/2 HEX WRHS (TYPE 17)
86663610	#8 X 5/8 HEX WRHS (TYPE 17)
86663612	#8 X 3/4 HEX WRHS (TYPE 17)
86663614	#8 X 7/8 HEX WRHS (TYPE 17)
86663616	#8 X 1 HEX WRHS (TYPE 17)
86664816	#10 X 1 HEX WRHS (TYPE 17)
87831600	NUT, #4-40 HEX STD CSZP
87832300	NUT, #6-32 HEX STD CSZP
87833000	#8-32 HEX MS NUT
87835700	1/4-20 HEX MS NUT
87841600	NUT, KEPS #4-40 HEX STD CSZP
87842300	NUT, KEPS #6-32 HEX STD CSZP
87843000	#8-32 KEPS HEX MS NUT
87843700	#10-24 KEPS HEX MS NUT
87844400	#10-32 KEPS HEX MS NUT
87845700	1/4-20 KEPS HEX MS NUT

87846900	5/16-18 KEPS HEX MS NUT
88903000	#8 EXT LOCKWASHER
88931600	WASHER, FLAT #4 X 5/16"OD CSZP
88932300	WASHER, FLAT #6 CSZP
88933000	#8 MS WASHER
88934400	#10 MS WASHER
89281605	#4-24 X 5/16 P PAN HS (HI-LO)
89293007	#8-18 X 7/16 HEX WRHS (HI-LO)
89293008	#8 X 1/2 HEX WRHS (HI-LO)
89293010	#8 X 5/8 HEX WRHS (HI-LO)
89293016	#8 X 1 HEX WRHS (HI-LO)
89294412	#10 X 3/4 HEX WRHS (HI-LO)
89951604	#4 X 1/4 DRIVE SCR (TYPE U)
89973724	#10-24 X 1 1/2 CARRIAGE BOLT
92100258	SCREW, #6-32 X 3/8" HWHMS CSZP
92400061	NUT 1/2-13 TYPE 7
92400181	NUT 1/2-20 TYPE 4
93400151	SCREW, S/T #8 X 1/4" TYPE-Z
94060046	COIN COMP-CM6640 (CC40)
94060085	VAULT-CASHCODE 600, 66MM
94060091	BILL ACC-COINCO MAG50 SA-RLA
94060092	BILL ACC-COINCO MAG90 SA-RLA
95000073	WASHER, # 5/16 FLAT
95000082	WASHER, # 8, FLAT
95000102	WASHER, # 5/16 LOCK
96700721	CARTON - PRO MECH
96700722	FOAM PAD-ANTI STATIC