


## CHOOSE THE RIGHT POWER ADAPTOR FOR YOUR LAPTOP:;










- 1 Identify your laptop model on the following pages to determine the Targus power products compatible with your machine.
- 2 Determine where you want to use your power supply (At Home or in the Car or Plane).
- 3 If you are still unsure simply freecall Targus for expert advice on the best product for your needs.



## NEED FURTHER HELP CHOOSING THE RIGHT POWER ADAPTOR & TIP FOR YOUR LAPTOP?

Our customer service team are now available late night Monday to Friday as well as all day Saturday & Sunday to assist.

Simply Freecall **Australia** 1800 641 645 , or **New Zealand** 0800 633 222

Laptop Chargers	Universal*			Replacement		
Product Name	Universal Wall, Power Adaptor	Mobile Laptop Charger	Universal Wall, Auto/Air, Power Adaptor	Home/Office 75W Laptop Charger	Home/Office 90W Laptop Charger	90W Home/Office Laptop Charger
<b>Product Code</b>	APA68AU	APD80AU	APM68AU	APA02AU	APA03AU	APA30AU
<b>Voltage Output:</b>	Universal* , Output voltage set by tip	Universal* , Output voltage set by tip	Universal* , Output voltage set by tip	15 - 16 V	18.5 - 20V	18.5 - 20V
<b>Ideal for</b>	Home/Office	Car/Plane**	Home/Office, Car & Plane	Home/Office	Home/Office	Home/Office
<b>Power Input</b>		 	  			
<b>Laptop Tips Included in Pack</b>	L104, L105, L106, L107, L108, L109, L110, L111, L112	L104, L105, L106, L107, L108, L109, L110, L111, L112	L104, L105, L106, L107, L108, L109, L110, L111, L112	M, N, P	N, P, R, S, T, U	, A, D, N, P, Q, R, T,
<b>Other Tips Included in Pack</b>	No	Mini USB (U300), iPad/iPhone/iPod (X513)	No	No	No	No

\* Please check the Targus website ([www.targus.com.au](http://www.targus.com.au)) or call Targus on the numbers below for full compatibility on Universal Power Adaptors - alternatively check this chart.

\*\* May require a DC to empower adaptor for selected airlines/flights - Call Targus on the numbers for more information

**Revised for products effective March 2011**

If your laptop model is not listed on this chart or on the chart supplied with the product, please contact Targus on the numbers below. **WARNING: Damage can be caused by the use of incorrect power tips.** Care must be taken to ensure the correct tip is selected for your computer (laptop or device) as Targus Australia Pty Limited will not accept responsibility for any consequential damage upon the use of the incorrect power tip. It is stressed damage can be caused by the use of incorrect power tips. Compatibility is determined by Targus and in no way suggests endorsement by laptop manufacturers. Warranty details for Targus power adaptors are outlined on the product packaging. Targus is a trademark of Targus and all other marks shown are the property of their respective owners.



**Universal adaptors** are available in AC & AC/DC versions to provide power wherever it's needed. They will work with more than 90% of laptops in the market and can be used with most laptops via interchangeable tips that adjust the voltage automatically. **Replacement AC adaptors** are limited to laptop models that use 15/16V & 19/20V to suit most common brands & models –they are ideal as replacement or additional AC adaptors, but may not work with your next laptop.

Universal		Replacement		
90W AC - APAB6AU	90W DC - APD80AU	75W AC - APA02AU	90W AC - APA03AU	90W AC - APA30AU
90W AC/DC - APM68AU				

Brand	Model	Series	Tip	Tip	Tip	Tip	
Acer	AcerNote	367D, 367T, 390	L106	×	P	P	
		350, 355, 356, 370C, 374, 850C, 380	L106	×	U	×	
	AcerNote Light	380, 350, 360, 370, 370C, 370P, 70PC, 372, 373, 373+, P100	L106	×	U	×	
	Anywhere	1100LX, 1120LX	L106	×	P	P	
	Aspire		1362WLMi, 1363WLCi, 1522WLMi, 1524WLMi	L106	×	×	×
			3025WLMi, 3053WXM, 3102NWLMi, 3104LMI, 3683WXM, 4220-200508, 4520-301G12, 4520-5A0508, 5023WLMi, 5043WLMi, 5044WLMi, 5100-3372, 5112WLMi, 5520G-301G12, 5520G-402G16, 5520G-502G16, 5570z, 5580-6432, 5601AWLMi, 5610 Series, 5610-2273, 5610-4537, 5610-4610, 5610-4648, 5612WLMi, 5633WLMi, 5672WLMi, 5710 Series, 7520G-0602G20, 9300WLMi, 9305WSMi, 9425WSMi, AS4315, AS4920, AS5102AWLMi, AS5103WLMi, AS5104WLMi, AS5105WLMi, AS5520, AS5702, AS5720, AS5920, AS9305WLMi	L107	×	×	T
		3023, 3025, 1641WLMi, 1642, 1642WLMi, 1642XWLMi, 1683WLMi, 1691WLCi, 2012WLCi, 2012WLMi, 2025WLMi, 2920, 2930, 3002LC, 3002LMI, 3002WLC, 3003WLCi, 3003WLMi, 3004WLCi, 3005WLCi, 3022WLMi, 3050-1594, 3100-1405, 3100-1458, 3508, 3613, 3614WLMi, 3618AWLCi, 3620, 3622WXCi, 3623, 3623NWXM, 3623WLCi, 3623WLMi, 3623WXCi, 3623WXM, 3624, 3624WXCi, 3624WXM, 3634LMI, 3634WLMi, 3680-2022, 3690-2710, 3693WLMi, 3993WLMi, 4315-2004, 4315-2904, 4330, 4520-5582, 4715-4053, 4935, 5002WLMi, 5003WLMi, 5024, 5050-4570, 5050-5430, 5050-5954, 5100, 5100-3357, 5100-3577, 5100-3583, 5100-3825, 5100-3949, 5100-3959, 5100-5033, 5100-5328, 5100-5840, 5100-5873, 5101AWLMi, 5101WLMi, 5102AWLMi, 5102WLMi, 5104WLMi, 5105WLMi, 5315, 5315-2142, 5315-2808, 5512FWLM, 5512WLMi, 5513EWLM, 5514WLMi, 5514WXM, 5520-5281, 5520-5908, 5570-2067, 5570-2609, 5570-2758, 5570-2792, 5570-2935, 5570-4421, 5600, 5670, 5670WLMi, 5715, 5720-4230, 5720-4258, 5720-6113, 5735, 5735Z, 5920-6444, 5920-6574, 5920-6706, 6920-6141, 6920-6508, 6920-6621, 6920-6886, 6920G-583G25Bn, 6920G-583G32Bn, 6920G-6A3G25Bn, 6920G-6A4G25Mn, 6920G-814G32Bn, 6920G-834G32Bn, 6920G-934G32Bn, 6930-6809, 6930G-583G25Bn, 6930G-583G25Mn, 6930G-733G25Mn, 6935G-734G32Bn, 6935G-844G32Bn, 6935G-944G32Bn, 7520-5185, 7520-6A1G08Mi, 7520-7A1G08Mi, 7720-3A2G12Mi, 7720-5A2G16Mi, 7720-6381, 7720-6604, 7720-6844, 7720-6A2G25Mi, 7720G-302G25Mi, 7720G-302G25Mn, 7720G-302G32Hi, 7720G-5A2G16Mi, 7720Z-1A2G16Mi, 8920-6048, 8920G-6A3G25Bn, 8920G-6A4G32Bn, 8920G-834G32Bn, 8920G-934G50Bn, 8920G-934G64Bn, 8930G, 8930G-584G32Bn, 8930G-734G32Bn, 8930G-844G32Bn, 8930G-864G32Bn, 8930G-864G64Bn, 8930G-944G64Bn, 9500, AS3054WXM, AS3810T-354G25N, AS3935-754G25MN, AS4810T-354G32Mn, AS4810TG-944G50MN, AS5536-644G32Mn, AS5536G-644G32MN, AS5735-733G32MN, AS5738G-644G32MN, AS5738G-644G50MN, AS5738G-654G32MN, AS5810TG-354G50MN	L108	×	×	A	
		Aspire One Netbook	751H, AOA110, AOA150, AOD150, AOD250, One , ZG5	L108	×	×	A
		Extensa		515	L105	P	×
	900, Ess3-391T, EX366D, EX368D			L106	×	P	P
	501DX, 501T, 502D, 503DX, 505DX, 506DX			L106	×	U	×
	2900			L107	×	×	T
	2300, 3000, 4220-5963, 5220, 5220-2385, 5220-301G12Mi, 5230-571G16Mn, 5620-2A2G12Mi, 5620Z-4A1G12Mi, 5630-582G16Mn, 5630Z-322G16Mn, EX4220-2555, EX4420-5239, EX4420-5963, EX4620-4431, EX4620-4648, EX4620-6194, EX5420-5038, EX5620-4020, EX5620-4025, EX5620-4801, EX5620-6266, EX5620-6419			L108	×	×	A
	355, 500, 600, 610CD, 610CDT	L108	×	U	A		
	Ferrari		4005WLMi, 5005WLMi-FR	L106	×	×	×
3000LMI, 3400LMI, 4005LMI, 4006LMI, 4006WLMi			L106	×	P	P	
1100-604G25Mn, 1100-704G25Mi, 1100-804G32Mn			L108	×	×	A	
Tablet		TMC104TC, TMC110TC, TMC110Ti	L108	×	×	A	



**Universal adaptors** are available in AC & AC/DC versions to provide power wherever it's needed. They will work with more than 90% of laptops in the market and can be used with most laptops via interchangeable tips that adjust the voltage automatically. **Replacement AC adaptors** are limited to laptop models that use 15/16V & 19/20V to suit most common brands & models –they are ideal as replacement or additional AC adaptors, but may not work with your next laptop.

Universal		Replacement		
90W AC - APA68AU	90W DC - APD80AU	75W AC - APA02AU	90W AC - APA03AU	90W AC - APA30AU
90W AC/DC - APM68AU				

Manufacturer	Model Name	Series	Tip	Tip	Tip	Tip
Acer	TravelMate	512DX, 512T	L105	P	×	×
		4202WLMi	L106	×	×	×
		505DX, 506T, 507DX, 507T, 524TX, 524TXV	L106	×	U	×
		2413, 2434WLMi, 2600, 4200 Series, 4200-4091, 4200-4320, 4200-4493, 4200-4854, 4270, 4672WLMi	L107	×	×	T
		230, 2300, 2301WLCi, 2303WLCi, 2304WLCi, 230x, 230xc, 230xv, 230xv-PRO, 2310 Series, 2350 Series, 2400, 2410, 2413WLMi, 2418AWLMi, 2450, 2451WLCi, 2480, 2480-2153, 2480-2551, 2480-2705, 2480-2779, 290, 291, 3000 Series, 3002WTMI, 3004WTMI, 3010 Series, 3200 Series, 3210, 3220, 3230, 3270-6637, 3280, 3290, 380, 4000WLCi, 4001WLCi, 4001WLMi, 4002WLMi, 4050 Series, 4060, 4061, 4062, 4062WLMi, 4064, 4070, 4072, 4072WLCi, 4072WLMi, 4074, 4080, 4100, 4101WLMi, 4150 Series, 4220, 4222WLMi, 4270-6206, 4501WLMi, 4600 Series, 4603WLMi, 4604WLMi, 4720-6218, 4720-6220, 5004WLMi, 5270-6565, 5320-301G08Mi, 5320-301G12Mi, 5330-571G16Mi, 5530G-703G25Mn, 5602WLMi, 5610, 5620, 5710 Series, 5720-2A3G16Mi, 5720-4A1G16Mi, 5720-4A2G16Mi, 5720-4A3G16Mi, 5720-5678, 5720-6337, 5720-6462, 5720-6722, 5730-6B2G16Mn, 5730-6B2G25Mn, 5730-6B4G25Mn, 5730-844G32Mn, 5730-944G32Mn, 5730G-843G25Mn, 5730G-844G32Bn, 6000, 6292-5B2G16Mi, 6292-603G32Mi, 6292-834G25Mi, 6292-834G32Mi, 6293-5B3G32Mi, 6293-6B2G25Mn, 6293-842G25Mn, 6410, 6410-6189, 6410-6248, 6460, 6460-6263, 6460-6752, 6492, 6492-812G25Mn, 6493-844G32Mn, 6592, 6592G-602G25Mn, 6592G-834G25Mn, 6593-842G25Mn, 6593G-842G25Mn, 6593G-944G32Mn, 7520-7A1G12Mi, 7530, 7530-602G25Mn, 7720, 7720G-602G25Mi, 7720G-702G50Mi, 7730-6B3G25Mn, 7730-843G25Mn, 7730G-944G32Mn, 8000, 8100 Series, 8100A, 8103WLMi, 8104, 8104WLMi, 8105, 8200 Series, 8204WLMi, 8210, 8216WLMi, C110, C110CTI, C110TI, C300, TM220, TM230, TM260, TM270, TM279, TM280, TM350, TM360, TM370, TM380, TM520, TM530, TM610, TM620, TM630, TM660, TM730, TM740, TM800, TMC110, TMC113LCI	L108	×	×	A
		4000	L108	×	U	A
		Aluratek		AEBK01F	×	×
Amazon	Kindle	Kindle 2, Kindle 1	×	×	×	×
Apple	iPad	iPad	×	×	×	×
Astak		EB-06EZ	×	×	×	×
Asus	Asus	A2L, A3 Series, A3000, A3000N, A3500N, A3Ac, A3F, A3Fc, A3Fp, A3H, A3Hf, A3N/L, A3Vc, A3Vm, A3Vp, A6 Series, A6F, A6G, A6K, A6Kt, A6L, A6M, A6Ne, A6R, A6Rp, A6T, A6Tc, A6U, A6V, A6Va, A6Vm, A7c, A7D, A7J, A7Jc, A7S, A8F, A8H, A8Ja, A8Jm, A8Jp, A8Js, A8M, A8SC-A1, A8SC-B1, A8SC-B2, A8SC-X3, A9Rp, AK6, B1 Series, B50A-A1, B50A-B1, B50A-B2, B50A-C2, F2F, F2Hf, F2J, F2Je, F3E-A1, F3E-B1, F3E-B2, F3E-B3, F3Jc, F3Jm, F3Jp, F3Ka, F3KA-X4, F3Sa, F3SC-A1, F3SC-B1, F3SV-A1, F3SV-B1, F3SV-B2, F3SV-B3, F3SV-B4, F3SV-C1, F50Gx, F5N, F5V-A1, F5VL-A2, F5VL-B1, F5VL-D1, F6A-A2, F6V-A1, F7KR, F80S-A1, F8P-B1W, F8P-C1B, F8P-C1W, F8P-X2B, F8Sn-A1, F8Sn-B1, F8Sn-C1, F8Sn-D1, F8Sp-X1, F8SV-A1, F8Va-B1, F8Va-C1, F9Dc-A1, F9Dc-B1, F9E-A1, F9S, F9Sg-A1, G1S-A1, G1S-B1, G1S-B2, G1Sn-A1, G1Sn-B1, G1S-X1, G1S-X3, G2K, G2K-A1, G2S, G2S-A1, G2S-A4, G2S-B1, G2S-B2, G2S-X3, L2B, L2E, L3000TP, L3C, L3D, L4000E, L4000H, L4000L, L4000R, L4500R, L4E, L4H, L4R, L50Vn-A1, L50Vn-B1, L50Vn-C1, M2000C, M2400N, M3Np, M50Sa-AK023C, M50Sa-X1, M50Sv-A1, M50Sv-B1, M50Vm-A1, M50Vm-B1, M50Vm-B2, M50Vm-B4, M51A-A1, M51A-B1, M51E-A1, M51E-B1, M51Sn-A1, M51Sn-B1, M51Sn-C1, M51Sn-X2, M51Sr, M51Vr, M5A Series, M5Ae, M6, M6A, M6C, M6Ce, M6N, M6Ne, M6Rf, M70SA-A1, M70SA-B1, M70SA-X2, M70Vm-A1, M70Vm-B1, M70Vm-C1, M70Vn-C1, M70Vn-C2, M7V, M7VP, M9J, M9V, N10J-A1, N10J-A2, N10Jc-A1, N20A-A1, N50VC, N50Vn-A1B, N50Vn-B1B, N50Vn-C1S, N50Vn-C2S, N50Vn-C3S, N50VN-FP154C, N51Vf, N51Vg, N80Vn-A1, N80Vn-B1, PRO50, PRO50N, PRO55, R1E-B1, R1E-D1, R1F, R1F-A1, R1F-A2, S1000N, S1N, S5A, S6F Leather Collection, S6FM, U1E, U1F, U2E-A1B, U2E-B1B, U2E-B3B, U2E-X3, U3S-A1B, U3S-A1W, U5A, U6E, U6E-A1, U6E-X2, U6E-X3, U6S, U6V, V1S, V1S-A1, V1S-B1, V1V-A1, V2S, V2S-A1, V2S-B1, V6 Series, V6J, W1 Series, W1000Na, W1J00VC, W1Jc Carbon, W2Jc, W2P, W3 Series, W3A, W3J, W3N, W3V, W3Z, W5A, W5Ae, W5F, W6A, W6F, W6Fp, W7J, W7S-A1B, W7S-A1W, W7S-B1B, W7S-B2B, W7S-B2W, W7S-B3B, W7S-B3W, X59SR-A1, X71SL-A1, X71SL-B2, Z61Ae, Z71A, Z71V, Z71Vp, Z91N/L, Z93E, F6E, K50J, K52F, K72J, N61J, U50A, U50F-RBBAG05, U52F, UL30A, UL50VT-RBBBK05, UL80J, UL80V	L106	×	×	×



**Universal adaptors** are available in AC & AC/DC versions to provide power wherever it's needed. They will work with more than 90% of laptops in the market and can be used with most laptops via interchangeable tips that adjust the voltage automatically. **Replacement AC adaptors** are limited to laptop models that use 15/16V & 19/20V to suit most common brands & models – they are ideal as replacement or additional AC adaptors, but may not work with your next laptop.

Universal		Replacement		
90W AC - APA68AU	90W DC - APD80AU	75W AC APAQ2AU	90W AC APAQ3AU	90W AC APA30AU
90W AC/DC - APM68AU				

Manufacturer	Model Name	Series	Tip	Tip	Tip	Tip
Asus	Asus	A2C, A2Lp, A3E, A3G, A3N, A5E, A5Ec, A6000, A6J, A6JA, A6Jc, A6Je, A6Jm, A6KM, A8 Series, D1, F3F, F3J, F3JV, L1B, L2 Series, L3, L3H, L3S, L3Tp, L4, L4L, M5000, M5200, M6000, M6000C, M6000N, M6000R, M6R, M6V, M6Va, M7A, PRO30, PRO31F, PRO31J, PRO31P, PRO50SR, PRO50SR-AP301C, PRO50SR-AP327C, PRO77SV, S1A, S6F, V1J, V1JP, V6Z61A, W1000, W1-745, W1GC, W1N, W1NA, W1V, W2V, W7,	L106	×	P	P
		A1 Series, F7 Series, M5, M8 Series, S1 Series, S200, S200N	L107	×	×	T
		F7000, L1 Series, L3000C, L7 Series, L8 Series, M1 Series, M2 Series, M2C, M2E, M2N, M3000N, M3N, M5200N, M5N, S300N, S5, S5200N, S5N, S8 Series, T9 Series, M2Ne,	L107	×	T	T
	Eee PC	900, 1000, 1000H, 1000HE, 1002HA, 1004DN, 701SD, 900HA, S101H, 1000BLK00, 1000HABLK005X, 1000HABLK026X, 1000HAWHI001X, 1000HAWHI024X, 1000HD, 1000HDBKBB1, 1000HEBLU002X, 900A, 900APFB01, 900AREF, 900BBLU01X, 900BK028REF, 900BK041REF, 900BK072, 900BK076, 900BK076X, 900BK090X, 900HDBBLK001X, 900HDBLK008, 900HDBRED001X, 900HDBWHI001X, 900HDPKBB01X, 900P, 900W017, 900W047, 900W073, 901BK002XREF, 901BK019, 901W001REF, S101B-BLK043X, T91SA-VU1X-BK, 1000HA, 900HD, T91, 1000HDB-KTG01, 1000HDPKBB01, 1000HEBLK001X, 1000HEBLK005X, 1000HGRN009X, 1005PX, 4GW011REF, MK9016GPP, Netpal, S101	×	×	×	×
		1001P, 1001P-MU17, 1001P-MU17-BK, 1001PX, 1005HA, 1005HA-A, 1005HAB, 1005HAB-RBLK003X, 1005HAB-RBLU0058, 1005HA-E, 1005HA-EU1X, 1005HAEU1XBK, 1005HA-EU1X-BK, 1005HAGB, 1005HA-M, 1005HA-P, 1005HA-PU17-BK, 1005HA-PU17-BU, 1005HA-PU1X, 1005HA-PU1X-BK, 1005HA-PU1X-BU, 1005HA-V, 1005HA-VU1X, 1005HA-VU1X-BK, 1005HA-VU1X-BU, 1005HA-VU1X-PI, 1005HA-VU1X-WT, 1005P, 1005PE, 1005PEB, 1005PEB-RRED015, 1005PEG, 1005PE-MU17-BK, 1005PE-P, 1005PE-PU17-BK, 1008HA, 1008HAB, 1008HA-PU1X-BK, 1008HA-PU1X-BU, 1008HA-PU1X-PI, 1008HA-PU1X-WT, 1101HA, 1101HAB, 1101HA-MU1X, 1101HA-MU1X-BK, 1101HGO, 1104HA, 1106HA, 1201HA, 1201HAB, 1201N, 1201N-PU17-BK	L131 ☎ Freecall now for free tip!	×	×	×
Grandio	F7400, L7000, L7000C, L7200, L7300	L107	×	T	T	
	Lamborghini	VX1, VX2S-A1B, VX2S-A1Y, VX2S-A2B, VX2S-A2Y, VX2S-B1B, VX2S-B1Y, VX2S-B2B, VX2S-B2Y, VX3-A1B, VX3-A1Y	L106	×	×	×
Barnes & Noble	Nook	Nook	×	×	×	×
BenQ	Joybook	2100, 8000, 8100, A2400H, A32, A32E,	L106	×	P	P
		527, 5000, 5100, 5120, 6000, 7000, 5100N, 5100U, A82, DH7000, R53, S52, S52E, S53, S53W, S72 Series,	L107	×	×	T
		2100, 2100e, 3000, 3000v1, DH5000, DH5100, S100, V11, V12, V33, V37,	L108	×	×	A



**Universal adaptors** are available in AC & AC/DC versions to provide power wherever it's needed. They will work with more than 90% of laptops in the market and can be used with most laptops via interchangeable tips that adjust the voltage automatically. **Replacement AC adaptors** are limited to laptop models that use 15/16V & 19/20V to suit most common brands & models –they are ideal as replacement or additional AC adaptors, but may not work with your next laptop.

Universal		Replacement		
90W AC - APA68AU	90W DC - APD80AU	75W AC - APA02AU	90W AC - APA03AU	90W AC - APA30AU
90W AC/DC - APM68AU				

Manufacturer	Model Name	Series	Tip	Tip	Tip	Tip
Compaq	Armada	110, E500, E500S, E700, M300, M700, V300	L107	×	T	T
	Business Tablet	TC4400	L111	×	×	Q
	Evo	N115, N160, N180	L106	×	P	P
		N1000v, N1015v, N1020c, N1020v, N110, N150, N200, N400c, N410c, N600c, N610c, N620c, N800c, N800v, N800w	L107	×	T	T
	Mini NetBook	102, 700 series, 1048NR	L125* © Freecall now for free tip!	×	×	×
	Presario	1110, 2100, 1010, 1020, 1030, 1060, 1065, 1070, 1075, 1080, 1115, 1120, 1200 series, 1200AP, 1200T-12XL, 1200TC, 1200TH, 1200-XL106, 1200-XL110, 1201, 1201AP, 1201S, 1202, 1203, 1205, 1206R, 1207, 1210, 1211, 1212, 1213, 1214, 1215, 1216, 1217, 1219, 1220, 1232, 1234, 1235, 1236, 1237, 1238, 1240, 1242, 1244, 1245, 1246, 1247, 1250, 1252, 1255, 1256, 1257, 1260, 1262, 1263, 1266, 1267, 1270, 1272, 1273, 1274, 1275, 1277, 1278, 1279, 12XL, 12XL300B, 12XL400, 12XL401, 12XL404, 12XL410, 12XL420, 12XL423, 12XL426, 12XL427, 12XL430, 12XL500, 12XL501, 12XL504, 12XL505, 12XL526, 12XL527, 1400, 1400T, 1450, 14XL, 14XL240, 1600, 1600 series, 1600i, 1600S, 1610, 1611, 1621, 1622, 1625, 1626, 1640, 1645, 1655, 1670, 1680, 1681, 1682, 1685, 1687, 1688, 1690, 1692, 1693, 1694, 16XL, 1700, 1700 series, 1700T, 1701, 1702, 1702AP, 1703, 1704, 1705, 1705AP, 1710, 1710T, 1711, 1712, 1713, 1714, 1715, 1716, 1717, 1720, 1721, 1722, 1723, 1723AP, 1724, 1724TC, 1725, 1725TC, 1726, 1726TC, 17XL, 17XL260, 17XL360, 1800, 1800t, 1800XL180, 18XL, 18XL280, 18XL580, 2100 series, 2100AP, 2100Z, 2101AP, 2102AP, 2103AP, 2104AP, 2105AP, 2106AP, 2107AP, 2108AP, 2109AP, 2110AP, 2111AP, 2112AP, 2113AP, 2114AP, 2115AP, 2116AP, 2117AP, 2120AP, 2123AP, 2124AP, 2125AP, 2130AP, 2133AP, 2135AP, 2140AP, 2143AP, 2145AP, 2150AP, 2153AP, 2154AP, 2155AP, 2156AP, 2157AP, 2175, 2500, 2500 series, 2500AP, 2501, 2505AP, 2515AP, 2517, 2519, 2525AP, 2529, 2530AP, 2535AP, 2538AP, 2540AP, 2543AP, 2545AP, 2550AP, 2555AP, 2560AP, 2565AP, 2567AP, 2568, 2568AP, 2570, 2573AP, 2585, 2590, 2594, 2596, 2597, 2598, 2700, 2700 series, 2700T, 2700TC, 2700xx, 2701, 2702, 2710, 2710TC, 2711, 2711AP, 2711TC, 2712, 2715, 2716, 2720, 3000, 3005, 3015, 3017, 3019, 3020, 3080, 700, 700 series, 701, 702, 703, 703AP, 704, 705, 706, 709, 710, 710TC, 711, 71110, 712, 713, 714, 715, 716, 717, 718, 719, 720, 721, 722, 723, 724, 725, 726, 727, 728, 729, 730, 731, 732, 733, 734, 735, 736, 737, 738, 739, 800, 800T, 801, 802, 803, 850	L106	×	P	P
	N1050V, V6002xx, V6500T, V6500Z, V6501AU, V6502AU, V6503AU, V6504AU, V6505AU, V6506AU, V6507AU, V6508AU	L107	×	×	×	
	2158AP	L107	×	P	P	



**Universal adaptors** are available in AC & AC/DC versions to provide power wherever it's needed. They will work with more than 90% of laptops in the market and can be used with most laptops via interchangeable tips that adjust the voltage automatically. **Replacement AC adaptors** are limited to laptop models that use 15/16V & 19/20V to suit most common brands & models – they are ideal as replacement or additional AC adaptors, but may not work with your next laptop.

Universal		Replacement		
90W AC - APA68AU	90W DC - APD80AU	75W AC APA02AU	90W AC APA03AU	90W AC APA30AU
90W AC/DC - APME8AU				

Manufacturer	Model Name	Series	Tip	Tip	Tip	Tip
Compaq	Presario	2203AP, 2204AP, 2205AP, 2206AP, 2207AP, 2208AP, 2209AP, 2210AP, 2211AP, 2212AP, 2213AP, 2214AP, 2215AP, 2216AP, 2217AP, 2218AP, 2218RS, 2219AP, 2220AP, 2221AP, 2222AP, 2223AP, 2224AP, 2225AP, 2226AP, 2227AP, 2228AP, 2229AP, 2230AP, 2231AP, 2232AP, 2233AP, 2234AP, 2235AP, 2236AP, 2237AP, 2238AP, 2239AP, 2240AP, 2241AP, 2242AP, 2243AP, 2244AP, 2245AP, 2246AP, 2248AP, 2249AP, 2250AP, 2251AP, 2252AP, 2253AP, 2254AP, 2255AP, 2256AP, 2258AP, 2259AP, 2260AP, 2261AP, 2267AP, A936TU, B1801TU, B1900, B1959TU, B1973TU, B2800, B2801-TU, B3800, B3813AP, B3827AP, C302, C302TU, C310TU, C501TU, C502TU, C503TU, C504TU, C506TU, C551TU, C552TU, C553TU, C554TU, C555TU, C556TU, C557TU, C558TU, C559TU, C560TU, C561TU, C562TU, C563TU, C564TU, C565TU, C566TU, C567TU, C582TU, C700T, C710TU, C731TU, C763, C774TU, C7xxTU, DV6000T, F503AU, F551AU, F573AU, M2000, M2000Z, M2001AP, M2001xx, M2002AP, M2003AP, M2004AP, M2005AP, M2006AP, M2007AP, M2008AP, M2009AP, M2010AP, M2011AP, M2012AP, M2013AP, M2014AP, M2015AP, M2016AP, M2017AP, M2018AP, M2019AP, M2020AP, M2021AP, M2022AP, M2023AP, M2024AP, M2025AP, M2026AP, M2027AP, M2028AP, M2029AP, M2030AP, M2031AP, M2032AP, M2033AP, M2034AP, M2035AP, M2036AP, M2037AP, M2038AP, M2039AP, M2040AP, M2041AP, M2042AP, M2043AP, M2044AP, M2045AP, M2046AP, M2047AP, M2048AP, M2049AP, M2050AP, M2051AP, M2052AP, M2053AP, M2054AP, M2055AP, M2099xx, M2200, M2201AP, M2201TU, M2202AP, M2202TU, M2203AP, M2204AP, M2205AP, M2206AP, M2207AP, M2208AP, M2209AP, M2210AP, M2211AP, M2212AP, M2213AP, M2214AP, M2215AP, M2216AP, M2217AP, M2218AP, M2219AP, M2220AP, M2221AP, M2222AP, M2223AP, M2224AP, M2225AP, M2226AP, M2227AP, M2228AP, M2229AP, M2230AP, M2231AP, M2232AP, M2233AP, M2234AP, M2235AP, M2236AP, M2237AP, M2238AP, M2239AP, M2240AP, M2241AP, M2242AP, M2243AP, M2244AP, M2245AP, M2253AU, M2256AU, M2299xx MV IUR, M2340AP, M2401XT, N2000, V2000, V2001AP, V2002AP, V2003AP, V2004AP, V2005AP, V2006AP, V2007AP, V2008AP, V2009AP, V2010AP, V2011AP, V2012AP, V2013AP, V2014AP, V2015AP, V2016AP, V2017AP, V2018AP, V2019AP, V2020AP, V2021AP, V2022AP, V2024AP, V2025AP, V2026AP, V2027AP, V2028AP, V2029AP, V2030AP, V2031AP, V2032AP, V2033AP, V2034AP, V2035AP, V2036AP, V2042AP, V2100, V2157AP, V2300, V2300T, V2300Z, V2311AP, V2325AP, V2340AP, V2398xx MV IUR, V2399xx, V2399XX, V2400T, V2402AU, V2414TU, V2418AU, V2433AU, V2566AP, V2602XT, V2606CU, V2627AU, V2649TS, V3000, V3000T, V3000Z, V3020, V3021, V3118AU, V3200, V3200TU, V3201AU, V3201TU, V3202AU, V3202TU, V3203AU, V3203TU, V3204AU, V3204TU, V3205TU, V3206TU, V3207TU, V3208TU, V3211TU, V3218TU, V3219TU, V3230AU, V3239AU, V3239TU, V3240AU, V3243TU, V3244TU, V3250TU, V3255TU, V3256TU, V3307, V3329TU, V4000, V4000xx MV IUR, V4001AP, V4002AP, V4002xx MV IUR, V4003AP, V4003xx MV IUR, V4004AP, V4004xx MV IUR, V4005xx, V4100, V4101AP, V4102AP, V4103AP, V4104AP, V4105AP, V4106AP, V4107AP, V4108AP, V4109AP, V4110AP, V4111AP, V4112AP, V4113AP, V4114AP, V4115AP, V4116AP, V4117AP, V4118AP, V4119AP, V4120TU, V4121TU, V4122TU, V4201TU, V4202TU, V4209TU, V4214, V4229TU, V5000, V5000T, V5099xx, V5100, V5100Z, V5101AU, V5102TU, V5104AU, V5108CU, V5200, V6000, V6000T, V6000Z, V6001AU, V6002AU, V6003AU, V6107AP, V6107TU, V6109AU, V6150TU, V6201AU, V6204AU, V6301, V6502, X1401AP	L107	x	x	T



**Universal adaptors** are available in AC & AC/DC versions to provide power wherever it's needed. They will work with more than 90% of laptops in the market and can be used with most laptops via interchangeable tips that adjust the voltage automatically. **Replacement AC adaptors** are limited to laptop models that use 15/16V & 19/20V to suit most common brands & models –they are ideal as replacement or additional AC adaptors, but may not work with your next laptop.

Universal		Replacement	
90W AC - APAB8AU	90W DC - APDB8AU	75W AC APA02AU	90W AC APA03AU
90W AC/DC - APMB8AU			90W AC APA30AU

Manufacturer	Model Name	Series	Tip	Tip	Tip	Tip
Compaq	Presario	2866, 2867, 2868, 2869, 2870, 2871, 2887, 2888, 2890, 2891, 2892, 2893, 2894, 2895, 2896, 2897, 2898, 2899, 1500 Series, 1501AP, 1503AP, 1504AP, 1506AP, 1507AP, 1508AP, 1509AP, 1510AP, 1510TC, 1511AP, 1512AP, 1514AP, 1520AP, 1522AP, 1525AP, 1528AP, 1531AP, 1532AP, 1535AP, 1536AP, 1538AP, 1540AP, 1545AP, 1550AP, 1555AP, 1565AP, 1570AP, 1572AP, 1575AP, 1580AP, 2200, 2800, 2801, 2802, 2803, 2804, 2805, 2806, 2806AP, 2807, 2809, 2810, 2811, 2812, 2813, 2813AU, 2814, 2814AP, 2815, 2816, 2817, 2817AR, 2818, 2818AP, 2819, 2819AP, 2820, 2820AP, 2821, 2822, 2822AP, 2823, 2823AP, 2825, 2825AP, 2826, 2826TC, 2827, 2827AP, 2828, 2828AP, 2830, 2832, 2832AP, 2835, 2835AP, 2838, 2838AP, 2840, 2840TC, 2845, 2845AP, 2853, 2853AP, 2857, 2857AP, 2858, 2858AP, 2860, 2860AP, 2861, 2861AP, 2862, 2862AP, 2863, 2863AP, 2864, 2864AP, 2865, 2865AP, 2866AP, 2867AP, 2868AP, 2869AP, 2870AP, 2871AP, 2887AP, 2888AP, 2890AP, 2891AP, 2892AP, 2893AP, 2894AP, 2895AP, 2896AP, 2897AP, 2898AP, 2899AP, 2900, 2902, 2903, 2904, 2905, 2906, 2907, 2908, 300, 305, 900 Series, 910AP, 920AP, 921AP, 923AP, 925AP, 927AP, 930AP, 935AP, 940AP, 943AP, 945AP, 950AP, 955AP, V1000, V1001AP, V1002AP, V1003AP, V1004AP, V1005AP, V1006AP, V1007AP, V1008AP, V1009AP, V1010AP, V1011AP, V1012AP, V1013AP, V1014AP, V1015AP, V1016AP, V1017AP, V1018AP, V1019AP, V1020AP, V1021AP, V1022AP, V1023AP, V1024AP, V1025AP, V1026AP, V1027AP, V1028AP, V1029AP, V1030AP, V1031AP, V1032AP, V1033AP, V1034AP, V1035AP, V1036AP, V1037AP, V1038AP, V1039AP, V1040AP, V1041AP, V1042AP, V1043AP, V1044AP, V1045AP, V1046AP, V1047AP, V1048AP, V1049AP, V1050AP, V1051AP, V1052AP, V1053AP, V1054AP, V1055AP, V1056AP, V1057AP, V1058AP, V1059AP, V1060AP, V1061AP, V1062AP, V1063AP, V1064AP, V1065AP, V1066AP, V1067AP, V1068AP, V1069AP, V1070AP, V1071AP, V1072AP, V1073AP, V1074AP, V1075AP, V1101AP, V1102AP, V1103AP, V1104AP, V1105AP, V1106AP, V1107AP, V1108AP, V1109AP, V1110AP, V1111AP, V1112AP, V1113AP, X1000, X1001, X1010, X1012, X1012QV, X1021AP, X1022AP, X1023AP, X1026AP, X1027AP, X1028AP, X1029AP, X1030, X1031AP, X1032AP, X1033AP, X1034AP, X1035AP, X1036AP, X1037AP, X1038AP, X1040AP, X1041AP, X1042AP, X1043AP, X1044AP, X1045AP, X1046AP, X1047AP, X1048AP, X1049AP, X1050AP, X1051AP, X1052AP, X1053AP, X1054AP, X1055AP, X1056AP, X1057AP, X1058AP, X1060AP, X1061AP, X1062AP, X1063AP, X1064AP, X1065AP, X1066AP, X1067AP, X1068AP, X1069AP, X1070AP, X1071AP, X1072AP, X1073AP, X1074AP, X1075AP, X1076AP, X1077AP, X1078AP, X1079AP, X1080AP, X1081AP, X1082AP, X1083AP, X1084AP, X1085AP, X1086AP, X1087AP, X1088AP, X1089AP, X1090AP, X1091AP, X1092AP, X1093AP, X1094AP, X1095AP, X1096AP, X1097AP, X1098AP, X1099AP, X1200, X1201AP, X1202AP, X1203AP, X1204AP, X1205AP, X1206AP, X1207AP, X1208AP, X1209AP, X1210AP, X1211AP, X1212AP, X1213AP, X1214AP, X1215AP, X1216AP, X1217AP, X1218AP, X1219AP, X1220AP, X1221AP, X1222AP, X1223AP, X1224AP, X1225AP, X1227AP, X1228AP, X1229AP, X1230AP, X1231AP, X1232AP, X1233AP, X1234AP, X1236AP, X1237AP, X1238AP, X1239AP, X1240AP, X1241AP, X1242AP, X1300, X1301AP, X1302AP, X1303AP, X1304AP, X1305AP, X1306AP, X1307AP, X1308AP, X1309AP, X1310AP, X1311AP, X1312AP, X1313AP, X1314AP, X1315AP, X1316AP, X1317AP, X1318AP, X1319AP, X1320AP, X1321AP, X1322AP, X1324AP, X1325AP, X1326AP, X1327AP, X1328AP, X1330AP, X1360, X1460, X1480, X1480xx	L107	*	T	T
		6715b, B1200, B1201TU, CQ40-418AX, CQ40-419AU, CQ41-226TX, CQ45-138TX, CQ60, CQ60-217TX, CQ60-302AU, CQ61-107TU, CQ61-115TU, CQ61-117TU, CQ61-311AX, CQ61-314TU, CQ61-319TX, CQ61-320TX, CQ61-405AX, CQ61-406TU, CQ61-409TU	L111	*	*	Q
	Prosignia	150	L106	*	P	P
		170, 190	L107	*	T	T
Tablet	TC-1000, TC-1100	L107	*	T	T	
Dell	Inspiron	1000, 1200, 1300, 2200, 3000, 3200, 3500, 7000, B120, B130, 1600	L106	*	P	P
		1500, 1521, 1721, 1150, 1318 (Intel Graphic card), 1318 (NVIDIA Graphic card), 1420 (Intel Graphic card), 1420 (NVIDIA Graphic card), 1501, 1520 (Intel Graphic card), 1520 (NVIDIA Graphic card), 1525, 1526, 1545, 1720 (Intel Graphic card), 1720 (NVIDIA Graphic card), 300M, 500M, 510M, 5160, 6000, 600M, 630M, 6400, 640m, 700M, 710M, 8500, 8600, 9200, 9300, 9400, E1405, E1505, E1705, 13, 14, 15, 1425, 1440, 1564, 1745, 1750, 1764	L109	*	*	D
		2500, 2600, 2650, 3700, 3800, 4000, 4150, 5000, 7500, 8000, 8100, 8200	*	*	S	*
	Inspiron Netbook	Mini 9, Mini 10, Mini 12	L108	*	T	A
Latitude	110L	L106	*	P	P	
	XT, 131L, ATG D630, ATG E6400, D400, D410, D420, D430, D500, D505, D510, D520, D530, D531, D600, D610, D620 (Intel Graphic card), D620 (NVIDIA Graphic card), D630 (Intel Graphic card), D630 (NVIDIA Graphic card), D800, D810, D820, D830, E4200, E4300, E5400, E5500, E6400, E6500, L100, X1, X300, XFR D630, 13, D631, E6410, E6510, XT2 Tablet	L109	*	*	D	



**Universal adaptors** are available in AC & AC/DC versions to provide power wherever it's needed. They will work with more than 90% of laptops in the market and can be used with most laptops via interchangeable tips that adjust the voltage automatically. **Replacement AC adaptors** are limited to laptop models that use 15/16V & 19/20V to suit most common brands & models – they are ideal as replacement or additional AC adaptors, but may not work with your next laptop.

Universal		Replacement	
90W AC - APAB8AU	75W AC APA02AU	90W AC APA03AU	90W AC APA30AU
90W DC - APDB0AU			
90W AC/DC - APMB6AU			

Manufacturer	Model Name	Series	Tip	Tip	Tip	Tip
Dell	Latitude	C400, C410, C500, C510, C600, C610, C640, C800, C810, CP, Cpi, CPt, CPx, CS/CSx, LM, X200	x	x	S	x
	Precision	M20, M2300, M2400, M4300, M60, M65, M70, M6300	L109	x	x	D
	Studio	1535 (ATI Graphic card), 1535 (Intel Graphic card), 1536 (ATI Graphic card), 1536 (Intel Graphic card), 1537 (ATI Graphic card), 1537 (Intel Graphic card), 1555, 1735, 1737, 13, 1745, 1458, 1535, 1558, 1747, 1749, 14Z, S15Z-2249CPN, X1647-533OBK	L109	x	x	D
	Studio XPS	16	L109	x	x	D
	Vostro	1000, 1400, 1500, 1520, 1700, 1720, 1310 (Intel Graphic card), 1310 (NVIDIA Graphic card), 1400 (Intel Graphic card), 1400 (NVIDIA Graphic card), 1500 (Intel Graphic card), 1500 (NVIDIA Graphic card), 1510 (Intel Graphic card), 1510 (NVIDIA Graphic card), 2510, A840, A860, 1015, 1710	L109	x	x	D
	XPS	M1210, M1330 (Intel graphic card), M1330 (NVIDIA graphic card), M1530, 16, 1640, 1647	L109	x	x	D
eMachines	Netbook	eM250, eM350	L108	x	x	A
	Notebook	eME527, eME627, eME727, eME640, eME642, eME528, eME732, eME728	L108	x	x	A
Fujitsu	Amilo M	M1420, M7400	L106	x	P	P
	Amilo Pro	V2000D, V8010D	L108	x	x	A
	FMV-BIBLO	FLX2H, LOOX S80B, LOOX S80B/W, LOOX S80C, LOOX S80C/W, LOOX T50E, LOOX T50E/W, LOOX T50G/W, LOOX T50H, LOOX T50J, LOOX T50K, LOOX T55G, LOOX T70E, LOOX T70G, LOOX T70H, LOOX T70HN, LOOX T70J, LOOX T70JN, LOOX T70K/T, LOOX T93B, LOOX T93B/W, LOOX T93C, LOOX T93C/W, MG12B, MG12B/C, MG12B/M, MG12C, MG12C/M, MG12D, MG13D, MG17D/A, MG50E, MG50G, MG50H, MG50HN, MG50K, MG50K/T, MG55E, MG70E, MG70E/ST, MG70G, MG70G/ST, MG70H, MG70K/T, MG75E, MG75G, MG75H, MG75H/ST, MG75HN, MG75K, MR16B, NB14B, NB14B/R, NB15B, NB15B/S, NB15B/T, NB16B, NB16B/M, NB16C, NB16C/A, NB16C/R, NB16C/ST, NB16C/T, NB16C/V, NB16CA, NB16CR, NB18B, NB18C, NB18C/T, NB18D, NB18D/D, NB18D/F, NB18D/L, NB18D/V, NB19D, NB19D/D, NB50E, NB50G, NB50H, NB50HN, NB50J, NB50JN, NB50K, NB53E, NB55E, NB55E/T, NB55G, NB55G/T, NB55H, NB55H/T, NB55J, NB55J/T, NB55K, NB55K/T, NB70E, NB70E/T, NB70G, NB70H/T, NB75G, NB75G/T, NB75H, NB75H/T, NB75HN, NB75HN/T, NB75J, NB75K/T, NB80J, NB80JN, NB80K, NB90J/T, NB90J/TS, NB90JN/T, NB90K/T, NB90K/TS, NB90KN/T, NH24C, NH24D, NH26C, NH28D, NH50E, NH70E, NH90E/T, NU, RS18D, RS18D/D, RS18D/ST, RS18D/T, RS50E/T, RS55E/T	L130* © Freecall now for free tip!	N	x	x
	LifeBook	A1010, A3110, Amilo L, C1010, C1020, C1110, C1211D, C1410, C2010, C2110, C2111, C2210, C2220, C2230, C2240, C2310, C2320, C2330, C2340, C3367, C6637, C6xx5, Cxxx7, E2010, E4010, E4010D, E6624, E6634, E6644, E6654, E6664, E66xx, E7010, E7110, E8010, E8010D, E8020, E8020D, E8110, E8210, N3510, N3511, N3520, N3530, N6110, N6210, N6220, S6130, S6410, S7010, S7010D, S7011, S7110, Stylistic ST4120, Stylistic ST4121, T4010, T4010D, T4020, T4210, T4220	L106	x	P	P
		200, 270Dx, 280Dx, 400, 420D, 420Dx, 435Dx, 500, 520D, 520T, 530T, 531T, 535T, 535Tx, 555T, 555Tx, 565Tx, 585Tx, 585Tx1, 600, 635T, 635Tx, 635Tx1, 655Tx, 656Tx, 656Tx1, 675Tx, 690Tx, 700, 735Dx, 755Tx, 756Dx, 765Tx, 770Tx, 790Tx, 900, 985Tx, 990Tx2, A4170, B112, B142, B2, B2130, B2131, B2175, B245x, B2545, B2562, B2566, B256x, B2610, B2620, B2630, B3010D, B3020, B3020D, B5010, B6110D, B6210, C340, C350, C352, C353, C360, C4120, C4235, C5130, C5235, C6177, C6320, C6330, C6525, C6535, C6537, C6547, C6556, C6557, C6577, C6581, C6591, C6611, C6631, C6651, C7631, C7651, C7661, Celsius Mobile H, E330, E335, E340, E342, E350, E351, E360, E362, E370, E380, E5140, E5320, E5520, E6150, E6520, E6530, E6540, E6541, E6550, E6555, E6556, E6557, E6570, E6571, E6575, E6595, Exxx5, L440, L470, P1000, P1032, P1035, P1110, P1120, P1510D, P1610, P2000, P2040, P2046, P2110, P2120, P5010, P5010D, P5020, P5020D, P7010, P7010D, P7120, P7120D, P7230, Q2010, S2010, S2020, S2110, S4510, S4542, S4546, S4572, S5582, S6010, S6110, S6120, S6120D, S6210, S6220, S6230, S6231, S6240, ST5030, ST5030D, ST5031, ST5031D, ST5032, ST5032D, Stylistic 3400, Stylistic 3500, Stylistic CT2020, Stylistic LT C-500, Stylistic LT P-600, Stylistic ST4110, Stylistic ST4110P, Stylistic ST4120P, Stylistic ST4121P, Stylistic ST5010, Stylistic ST5010D, Stylistic ST5011, Stylistic ST5011D, Stylistic ST5020, Stylistic ST5020D, Stylistic ST5021, Stylistic ST5021D, Stylistic ST5022, Stylistic ST5022D, T3010, T3010D, U820	L130* © Freecall now for free tip!	N	x	x





**Universal adaptors** are available in AC & AC/DC versions to provide power wherever it's needed. They will work with more than 90% of laptops in the market and can be used with most laptops via interchangeable tips that adjust the voltage automatically. **Replacement AC adaptors** are limited to laptop models that use 15/16V & 19/20V to suit most common brands & models –they are ideal as replacement or additional AC adaptors, but may not work with your next laptop.

Universal		Replacement		
90W AC -APA68AU	90W DC -APD80AU	75W AC -APA02AU	90W AC -APA03AU	90W AC -APA30AU
90W AC/DC -APM68AU				

Manufacturer	Model Name	Series	Tip	Tip	Tip	Tip
Gateway	Gateway	400SD4, 400VTX, 4012GZ, 4024GZ, 4026GZ, 4028GZ, 405E, 405X, 450ROG, 450SX4, 4530GH, 4530GZ, 4535GZ, 4536GZ, 4538GZ, 4540GZ, 600YG2, 600YGR, M305, M500, W350A, M320X-CTO, M-73, MD7333U, NV5422U, NV5448U, NV5911H, NV7915U, PA6A, W350i, CX2750, M1634, M1634U, M-2625U, M-2626U, M-460ES, M6873h, M-6887U, M-7315U, M-7347U, MX6121, NV5214U, NV5302U, NV5378U, NV5435U, NV7802U, P-171x, P-6312, P-6317, T-6339U, T-6859U, W650A, W650I	L106	×	P	P
		EC14-33U, LT1000, LT1005u, LT20, LT2016U, LT21, LT2104U, LT31, LT3114U, EC19C02a, EC39C21a, ID49C03a, ID59C19a, NV59C39a, NV59C43a, LT3003a, LT3105a, LT3106a	L108	×	×	A
	Solo	1100 Series, 1150, 1200, 1400, 1450, 2100 series, 2150 Series, 2200 series, 2300 series, 2500 series, 2550 Series, 3100 Series, 3150 Series, 5100 series, 5150 Series, 5300, 5350, 9100 Series, 9150, 9300 Series, 9500, 9550	L106	×	P	P
HP	Business Tablet	TC4200	L107	×	T	T
		TC4400	L111	×	×	Q
	Business Thin Client	2533t, 4410t, 6720t	L111	×	×	Q
	Compaq	510, 511, 515, 516, 610 (ATI Graphics), 610 (Intel Graphics), 615 (ATI Graphics HD 3200), 615 (ATI Graphics HD 4330)	L111	×	×	Q
	EliteBook	2530p, 2540p, 2730p, 2740p, 6930p, 8440p (Intel Graphics), 8440p (NVIDIA Graphics), 8540p (Intel Dual-core processor ONLY), 8440w (Intel Graphics), 8440w (NVIDIA Graphics), 8540w (Intel Dual-core with NVIDIA 880M Graphics ONLY)	L111	×	×	Q
	Envy	13-1006TX, 13-1008TX, 13-1101TX, 13-1102TX	L111	×	×	Q
	HP	510, 530, 550, L2000, L2005A3, L2005A4, L2098XX, L2099XX	L107	×	T	T
		520, 540, 541, G60t, G70t	L111	×	×	Q
	HP Compaq Business	NX9000, NX9005, NX9008, NX9010	L106	×	P	P
		6520s (ATI Graphic card), 6820s, NX8220	L107	×	×	×
		6520s (Intel Graphic card), 6720s, NC4000, NC4010, NC4200, NC6000, NC6120, NC6200, NC6220, NC6230, NC8000, NW8000, NX5000, NX6100, NX6110, NX6115, NX6120, NX6125, NX7000, NX7010, NX7200, NX9020, NX9030, NX9040	L107	×	T	T
		2230s, 2510p, 2710p, 6510b, 6515b, 6530b, 6530s (Intel Graphics), 6531s (ATI Graphics), 6535b, 6535s, 6710b, 6710s, 6712b, 6715b, 6715s, 6715sb, 6730b, 6735b, 6735s, 6830s, 6910p, 8510p, 8510w, NC2400, NC4400, NC6140, NC6320, NC6400 (ATI Graphic card), NC6400 (Intel Graphic Card), NC6440, NC8230, NC8430, NW8240, NW8440, NX6310, NX6320, NX6325, NX7300, NX7400, NX8420, NX9420, 6730s (Intel Graphics), 6730s (ATI Graphics)	L111	×	×	Q
	Mini Netbook	2133 Mini-Note, 2140, 5101	L111	×	×	Q
		1101, 2102, 1000 series, 1000 Vivienne Tam series, 1001TU, 110-1004TU, 110-1008TU, 110-1100TU, 110-1106TU, 110-1156TU, 1109TU, 210-1015TU, 210-1016TU, 210-1017TU, 210-1018TU, 210-1020TU	L125 ☎ Freecall now for free tip!	×	×	×
Omnibook	2000, 2100, 2103, 2105, 300, 3000, 3100, 3101, 4000, 4000C, 4100, 4101, 4103, 4105, 4150, 4150B, 425, 430, 500, 5000, 510, 530, 5500, 5700, 6000, 6000B, 6000C, 6100, 7100, 7103, 7150, 900, 900B, N3000, VT6200, XE, XE 4400 BTO, XE2, XE2-DB, XE2-DC, XE2-DD, XE2-DI, XE3, XE3B, XE3C, XE3-GD, XE3-GF, XE4100, XE4200, XE4400, XE4500, XE-DA, XT1000, XT1500, XT6050, XT6200	L106	×	P	P	



**Universal adaptors** are available in AC & AC/DC versions to provide power wherever it's needed. They will work with more than 90% of laptops in the market and can be used with most laptops via interchangeable tips that adjust the voltage automatically. **Replacement AC adaptors** are limited to laptop models that use 15/16V & 19/20V to suit most common brands & models –they are ideal as replacement or additional AC adaptors, but may not work with your next laptop.

Universal		Replacement		
90W AC - APA68AU	90W DC - APD80AU	75W AC - APA02AU	90W AC - APA03AU	90W AC - APA30AU
90W AC/DC - APM68AU				

Manufacturer	Model Name	Series	Tip	Tip	Tip	Tip	
HP	Pavillion	2105, 3101, 4101, 4103, 4105, 5159, N3110, N3150, N3190, N3210, N3215, N3220, N3250, N3270, N3290, N3295, N3310, N3330, N3350, N3370, N3380, N3390, N3402, N3410, N3438, N3478, N3490, N5000 BTCCO, N5124, N5125, N5130, N5135, N5140, N5150, N5159, N5170, N5190, N5195, N5210, N5221, N5240, N5241, N5250, N5261, N5270, N5271, N5290, N5295, N5310, N5311, N5331, N5340, N5341, N5350, N5351, N5361, N5371, N5381, N5390, N5401, N5402, N5402L, N5412, N5415, N5420, N5421, N5421L, N5422, N5422L, N5425, N5430, N5431L, N5435, N5440, N5441, N5442, N5444, N5445, N5450, N5451, N5452, N5454, N5455, N5461, N5462, N5470, N5472, N5474, N5475, N5481, N5482, N5484, N5490, N5491, N5495, N5511L, N5584, N6190, N6195, N6300 BTO, N6395, N6396, N6397, N6398, N6399, N6400, N6401, N6402, N6403, N6404, N6490, XF125, XF145, XF235, XF255, XF315, XF325, XF328, XF335, XH136, XH156, XH176, XH215, XH216, XH226, XH355, XH365, XH395, XH455, XH485, XH525, XH535, XH545, XH555, XH575, XH625, XH675, XT115, XT118, XT125, XT128, XT155, XT178, XT183, XT188, XT236, XT276, XT345, XT375, XT395, XT412, XT4345QV, XT512, XT5300, XT5335QV, XT5366, XT5377, XT5377QV, XT545, XT555, XT565, XT575, XT585, XT595, XU/ZU BTCCO, XU155, XZ133, XZ148, XZ163, XZ168, XZ185, XZ275, XZ295, XZ335, XZ355, ZE1000, ZE1110, ZE1115, ZE1145, ZE1201, ZE1202, ZE1210, ZE1230, ZE1250, ZE1260, ZE4000, ZE4101, ZE4102, ZE4103, ZE4105, ZE4111, ZE4115, ZE4120, ZE4123, ZE4125, ZE4130, ZE4133, ZE4140, ZE4145, ZE4200, ZE4201, ZE4202, ZE4204, ZE4206, ZE4207, ZE4208, ZE4209, ZE4210, ZE4211, ZE4214, ZE4218, ZE4219, ZE4220, ZE4221, ZE4222, ZE4224, ZE4228, ZE4229, ZE4230, ZE4231, ZE4232, ZE4234, ZE4236, ZE4239, ZE4240, ZE4241, ZE4251, ZE4258, ZE4261, ZE4268, ZE4271, ZE4274, ZE4278, ZE4281, ZE4282, ZE4284, ZE4288, ZE4292, ZE4294, ZE4298, ZE4301, ZE4305, ZE4307, ZE4308, ZE4310, ZE4311, ZE4312, ZE4313, ZE4314, ZE4315, ZE4316, ZE4317, ZE4318, ZE4319, ZE4320, ZE4321, ZE4323, ZE4325, ZE4330, ZE4332, ZE4333, ZE4334, ZE4335, ZE4336, ZE4345, ZE4347, ZE4348, ZE4349, ZE4351, ZE4352, ZE4353, ZE4354, ZE4355, ZE4356, ZE4357, ZE4360, ZE4365, ZE4367, ZE4375, ZE4384, ZE4385, ZE4386, ZE4400, ZE4401, ZE4402, ZE4410AP, ZE4412AP, ZE4413AP, ZE4414AP, ZE4427, ZE4500, ZE4520AP, ZE4521AP, ZE4522AP, ZE4523AP, ZE4540, ZE4546, ZE4547, ZE4551, ZE4560, ZE4600, ZE4610, ZE4700, ZE4800, ZE5000, ZE5030, ZE5155, ZE5160, ZE5165, ZE5170, ZE5185, ZE5190, ZE5200, ZE5207, ZE5217, ZE5228, ZE5232, ZE5236, ZE5238, ZE5240, ZE5242, ZE5244, ZE5250, ZE5252, ZE5258, ZE5262, ZE5270, ZE5279, ZE5300, ZE5320AP, ZE5345, ZE5375, ZE5385, ZE5395, ZE5400, ZE5470, ZE5490, ZE5500, ZE5515AP, ZE5575, ZE5600, ZE5603AP, ZE5604, ZE5604AP, ZE5605AP, ZE5608AP, ZE5611AP, ZE5612AP, ZE5613AP, ZE5616AP, ZE5620, ZE5700, ZE5749, ZT1000-IB BTCCO, ZT1114, ZT1120, ZT1121, ZT1121S, ZT1122, ZT1122S, ZT1125, ZT1130, ZT1131, ZT1131S, ZT1132, ZT1132S, ZT1135, ZT1141, ZT1142, ZT1145, ZT1150, ZT1151, ZT1152, ZT1155, ZT1161, ZT1162, ZT1170, ZT1171, ZT1172, ZT1175, ZT1180, ZT1181, ZT1182, ZT1185, ZT1190, ZT1192, ZT1201, ZT1201S, ZT1210, ZT1211, ZT1213, ZT1230, ZT1231S, ZT1233, ZT1235, ZT1243, ZT1250, ZT1260, ZT1261, ZT1270, ZT1271, ZT1290, ZT1331, ZU1155, ZU1175, ZU175	L106	×	P	P	
		DV2000T, DV2024TX, DV2040TX, DV2085, DV2113TU, DV2123TU, DV2222TX, DV2305TU, DV2308TX, DV2503XX, DV2521TX, DV2522TX, DV2529TX, DV2530TX, DV2533TX, DV2538TX, DV2609TX, DV2619TX, DV2632TX, DV2633TX, DV2637TX, DV2700TV (NVIDIA Graphic card), DV2701TX Special Edition, DV2739TX Special Edition, DV2740TX Special Edition, DV2753TX Special Edition, DV2754TX Special Edition, DV2758TX Special Edition, DV2762TX Special Edition, DV2765TX Special Edition, DV2766TX Special Edition, DV2807TX, DV2808TX, DV2809TX, DV2813TX, DV2814TX, DV2817TX, DV2819TX, DV2820TX, DV2823TX, DV2825TX, DV2827TX, DV2828TX, DV2835TX, DV4000, DV6000, DV6000Z, DV6001XX, DV6113TX, DV6116TX, DV6121TX, DV6122TX, DV6129TX, DV6201TU, DV6207TX, DV6218TX, DV6221TX, DV6302TU, DV6304TX, DV6306TX, DV6404TU, DV6500, DV6500T, DV6500Z, DV6501TX, DV6502TX, DV6503TX, DV6504TX, DV6505TU, DV6505TX, DV6506TX, DV6507TX, DV6509TX, DV6510TX, DV6511TX, DV6512TX, DV6513TX, DV6514TX, DV6515TX, DV6516TX, DV6517TX, DV6518TX, DV6519TX, DV6520TX, DV6521TX, DV6522TX, DV6523TX, DV6524TX, DV6525TX, DV6526TX, DV6527TX, DV6528TX, DV6529TX, DV6531TX, DV6533TX, DV6534TX, DV6535TX, DV6536TX, DV6539TX, DV6540TX, DV6541TX, DV6542TX, DV6543TX, DV6544TX, DV6545TX, DV6546TX, DV6547TX, DV6548TX, DV6597xx, DV6598xx, DV6601AX, DV6614TX, DV6617TX, DV6700T(NVIDIA Graphic card), DV6709AX, DV6721TX, DV6724TX, DV6733TX, DV6746TX, DV6755TX, DV6757TX, DV6796TX, DV6835, DV6837TX, DV6838TX, DV8000, DV9000, DV9000T, DV9000Z, DV9001xx, DV9003xx, DV9007, DV9007TX, DV9008TX, DV9018, DV9018TX, DV9079, DV9095xx, DV9098xx, DV9203TX, DV9205TX, DV9218TX, DV9303TX, DV9304, DV9307TX, DV9500T, DV9500Z, DV9501TX, DV9502TX, DV9503TX, DV9504TX, DV9505TX, DV9506TX, DV9507TX, DV9508TX, DV9509TX, DV9511TX, DV9512TX, DV9513TX, DV9514TX, DV9516TX, DV9517TX, DV9518TX, DV9519TX, DV9520TX, DV9521TX, DV9596xx, DV9613TX, DV9615TX, DV9630, DV9700, DV9700T, DV9722TX, DV9724TX, DV9725TX, DV9748TX, DV9822TX, TX1219AU	L107	×	×	×	×



**Universal adaptors** are available in AC & AC/DC versions to provide power wherever it's needed. They will work with more than 90% of laptops in the market and can be used with most laptops via interchangeable tips that adjust the voltage automatically. **Replacement AC adaptors** are limited to laptop models that use 15/16V & 19/20V to suit most common brands & models –they are ideal as replacement or additional AC adaptors, but may not work with your next laptop.

Universal		Replacement		
90W AC - APA68AU		75W AC APA02AU	90W AC APA03AU	90W AC APA30AU
90W DC - APD80AU				
90W AC/DC - APM68AU				

Manufacturer	Model Name	Series	Tip	Tip	Tip	Tip
HP	Pavillion	ZE2001AP, ZE2001xxMV IUR, ZE2002AP, ZE2003AP, ZE2004AP, ZE2005AP, ZE2006AP, ZE2007AP, ZE2008AP, ZE2009AP, ZE2009XX MV IUR, ZE2009xxMV IUR, ZE2010AP, ZE2011AP, ZE2012AP, ZE2013AP, ZE2014AP, ZE2015AP, ZE2016AP, ZE2017AP, ZE2018AP, ZE2019AP, ZE2020AP, ZE2200, ZE2200T, ZE2200Z, ZE2201AP, ZE2201XX MV IUR, ZE2201xxMV IUR, ZE2202AP, ZE2203AP, ZE2204AP, ZE2205AP, ZE2206AP, ZE2207AP, ZE2208AP, ZE2209AP, ZE2209XX MV IUR, ZE2209xxMV IUR, ZE2210AP, ZE2211AP, ZE2212AP, ZE2296XX MV IUR, ZE2296xxMV IUR, ZE2297XX MV IUR, ZE2297xxMV IUR, ZE2298XX MV IUR, ZE2298xxMV IUR, ZE2299XX MV IUR, ZE2299xxMV IUR, ZE2401XT, ZE4901 MV IUR, ZE4902 MV IUR, ZE5526AP, ZT3050AP, ZT3301AP, ZV5203AP	L107	*	P	P
		DV1000, DV1001AP, DV1002AP, DV1003AP, DV1004AP, DV1005AP, DV1006AP, DV1007AP, DV1008AP, DV1009AP, DV1010AP, DV1013AP, DV1014AP, DV1015AP, DV1016AP, DV1017AP, DV1018AP, DV1019AP, DV101EAP, DV1020AP, DV1021AP, DV1022AP, DV1023AP, DV1024AP, DV1025AP, DV1026AP, DV1027AP, DV1029AP, DV1030AP, DV1031AP, DV1100, DV1101AP, DV1102AP, DV1103AP, DV1104AP, DV1105AP, DV1106AP, DV1107AP, DV1108AP, DV1109AP, DV1110AP, DV1111AP, DV1112AP, DV1113AP, DV1115AP, DV1116AP, DV1117AP, DV1118AP, DV1119AP, DV1120AP, DV1121AP, DV1122AP, DV1123AP, DV1124AP, DV1125AP, DV1127AP, DV1128AP, DV1129AP, DV1130AP, DV1131AP, DV1132AP, DV1133AP, DV1134AP, DV1135AP, DV1136AP, DV1137AP, DV1139AP, DV1300, DV1301XX MV IUR, DV1302XX MV IUR, DV1311AP, DV1312AP, DV1313AP, DV1314AP, DV1315AP, DV1316AP, DV1317AP, DV1318AP, DV1319AP, DV1320AP, DV1321AP, DV1324AP, DV1325AP, DV1326AP, DV1327AP, DV1328AP, DV1329AP, DV1330AP, DV1331AP, DV1332AP, DV1333AP, DV1334AP, DV1335AP, DV1336AP, DV1338AP, DV1339AP, DV1340AP, DV1341AP, DV1342AP, DV1343AP, DV1344AP, DV1345AP, DV1346AP, DV1347AP, DV1348AP, DV1349AP, DV1350AP, DV1351AP, DV1352AP, DV1353AP, DV1354AP, DV1355AP, DV1356AP, DV1357AP, DV1358AP, DV1359AP, DV1360AP, DV1361AP, DV1362AP, DV1362TU, DV1363AP, DV1364AP, DV1365AP, DV1366AP, DV1367TU, DV1368TU, DV1369TU, DV1370TU, DV1371TU, DV1372TU, DV1373TU, DV1374TU, DV1375TU, DV1376TU, DV1379TU, DV1380TU, DV1381TU, DV1382TU, DV1383TU, DV1384TU, DV1385TU, DV1386TU, DV1387TU, DV1388TU, DV1389TU, DV1390TU, DV1391TU, DV1392TU, DV1393TU, DV1394TU, DV1395TU, DV1396TU, DV1399XX MV IUR, DV1600, DV1610TN, DV1738OD, DV2000, DV2000Z, DV2002TU, DV2017TU, DV2020TX, DV2023, DV2023TU, DV2029TU, DV2036TU, DV2045TU, DV2-1001AU, DV2111TX, DV2112TX, DV2133, DV2401TU, DV2402TU, DV2403TU, DV2404TU, DV2405TU, DV2501xx, DV2502TU, DV2505TU, DV2506xx, DV2508TU, DV2509TU, DV2510TU, DV2511TU, DV2512TU, DV2513TU, DV2514TU, DV2515TU, DV2516TU, DV2517TU, DV2518TU, DV2519TU, DV2520TU, DV2521TU, DV4000xx MV IUR, DV4001AP, DV4001xx MV IUR, DV4002AP, DV4003AP, DV4004AP, DV4004xx MV IUR, DV4005AP, DV4005xx MV IUR, DV4006AP, DV4006xx MV IUR, DV4007AP, DV4007xx MV IUR, DV4008AP, DV4009AP, DV4010AP, DV4011AP, DV4012AP, DV4013AP, DV4014AP, DV4015AP, DV4016AP, DV4017AP, DV4018AP, DV4019AP, DV4020AP, DV4021AP, DV4022AP, DV4023AP, DV4024AP, DV4025AP, DV4026AP, DV4100, DV4114, DV4117AP, DV4121AP, DV4126AP, DV4201TU, DV4201TX, DV4202TU, DV4202TX, DV4203TU, DV4203TX, DV4204TU, DV4204TX, DV4205TX, DV4206TU, DV4206TX, DV4207TU, DV4207TX, DV4208TX, DV4209TX, DV4210TX, DV4211TX, DV4212TX, DV4213TX, DV4214TX, DV4215TX, DV4216TX, DV4217TX, DV4218TX, DV4219TX, DV4220TX, DV4221TX, DV4222TX, DV4223TX, DV4224TX, DV4225TX, DV4228, DV4420, DV5000, DV5000T, DV5100, DV5101TU, DV5101TX, DV5102TU, DV5102TX, DV5103TX, DV5104TU, DV5104TX, DV5105TU, DV5105TX, DV5106TX, DV5107TX, DV5108TX, DV5109TX, DV5110TX, DV5112TX, DV5113TX, DV5114TX, DV5115TX, DV5116TX, DV5117TX, DV5118TX, DV5120TX, DV5121TX, DV5123TX, DV5124TX, DV5125TX, DV5126TX, DV5127TX, DV5128TX, DV5129TX, DV5130TX, DV5131TX, DV5196XX, DV5197XX, DV5200, DV5200TU, DV5200TX, DV5201TU, DV5201TX, DV5202TU, DV5202TX, DV5203TU, DV5203TX, DV5204TU, DV5204TX, DV5205TX, DV5206TU, DV5206TX, DV5207TX, DV5208TX, DV5209TX, DV5210TX, DV5211TX, DV5212TX, DV5213TX, DV5214TX, DV5215TX, DV5216TX, DV5217TX, DV5218TX, DV5219TX, DV5220TX, DV5221TX, DV5222TX, DV5223TX, DV5224TX, DV5225TX, DV5226TX, DV5227TX, DV5228TX, DV5229TX, DV5230TX, DV5231TX, DV5232TX, DV5233TX, DV5235TX, DV5236TX, DV5237TX, DV6102OD, DV6128TU, DV6131OD, DV6200, DV6204AU, DV6501TU, DV6502TU, DV6503TU, DV6504TU, DV6506TU, DV6507TU, DV6508TU, DV6509TU, DV6599xx, DV6700T(Intel Graphic card), DV8000xx, DV8013xx, DV8040xx, DV8099xx, DV8200, DV8211TX, DV8218, DV8219, DV8308, DV8310TX, DV9598xx, DV9599xx, TX2-1015AU	L107	*	*	T



**Universal adaptors** are available in AC & AC/DC versions to provide power wherever it's needed. They will work with more than 90% of laptops in the market and can be used with most laptops via interchangeable tips that adjust the voltage automatically. **Replacement AC adaptors** are limited to laptop models that use 15/16V & 19/20V to suit most common brands & models –they are ideal as replacement or additional AC adaptors, but may not work with your next laptop.

Universal		Replacement		
90W AC - APA68AU	90W DC - APD80AU	75W AC - APA02AU	90W AC - APA03AU	90W AC - APA30AU
90W AC/DC - APM68AU				

Manufacturer	Model Name	Series	Tip	Tip	Tip	Tip
HP	Pavillion	4316, 3010AP, 3011AP, 4523, 6100 Series, DM1-1001TU, DM1-1002TU, DM1-1003TU, DM1-1004TU, DM1-1005TU, DM1-1006TU, DM1-1007TU, DM1-1008TU, DM1-1009TU, DM1-1010TU, DM1-1011TU, DM1-1012TU, DM1-1013TU, DM1-1014TU, DM1-1015TU, DM1-1016TU, DM1-1017TU, DM1-1018TU, DM1-1019TU, DM1-1020TU, DM1-1021TU, DM1-1022TU, DM1-1023TU, DM1-1024TU, DM1-1103TU, DM3-1011TU, DM3-1016AX, DM3-1022TX, DM3-1033TX, DM3-1104TX, DM3-1105TX, HDX9003TX, HDX9004TX, TX1000, TX1001AU, TX1001xx, TX1002AU, TX1002xx, TX-1003AU, TX1003xx, TX1004AU, TX1005AU, TX1006AU, TX1007AU, TX1008AU, TX1014AU, TX1030IA, TX2011AU, TX2500Z, TX2502AU, TX2503AU, V5022AP, ZT3000, ZT3010, ZT3010AP, ZT3011AP, ZT3012AP, ZT3013AP, ZT3014AP, ZT3015AP, ZT3016AP, ZT3017AP, ZT3018AP, ZT3019AP, ZT3020, ZT3020AP, ZT3021AP, ZT3022AP, ZT3023AP, ZT3024AP, ZT3025AP, ZT3026AP, ZT3027AP, ZT3028AP, ZT3029AP, ZT3030AP, ZT3031AP, ZT3032AP, ZT3033AP, ZT3034AP, ZT3035AP, ZT3036AP, ZT3037AP, ZT3038AP, ZT3039AP, ZT3040AP, ZT3041AP, ZT3043AP, ZT3044AP, ZT3045AP, ZT3046AP, ZT3047AP, ZT3048AP, ZT3049AP, ZT3050AP, ZT3051AP, ZT3201AP, ZT3202AP, ZT3203AP, ZT3204AP, ZT3205AP, ZT3206AP, ZT3207AP, ZT3208AP, ZT3209AP, ZT3210AP, ZT3211AP, ZT3212AP, ZT3250xx, ZT3280, ZT3302, ZT3340, ZT3350, ZT3380, DM3T, DM4	L107	×	T	T
		DV3-1000 series, DV3-2002TU, DV3-2007TX, DV3504TX, DV3505TX, DV3506TX, DV3507TX, DV3522TX, DV3528TX, DV3529TX, DV3530TX, DV3534TX, DV3535TX, DV3539TX, DV3540TX, DV3Z series, DV4-1000, DV4-1004TU, DV4-1015TX, DV4-1016TX, DV4-1041TX, DV4-1048TX, DV4-1049TX, DV4T-1000, DV5-1004TX, DV5-1007TX, DV5-1009TX, DV5-1010TX, DV5-1019TX, DV5-1020TX, DV5-1045TX, DV5-1046TX, DV5-1050TX, DV5-1053TX, DV5-1054TX, DV5-1055TX, DV5-1140TX, DV6-1107AX, DV6-1129TX, DV6-1130TX, DV6-1207AX, DV6-1214AX, DV6-1244TX, DV6-1246TX, DV6-1247TU, DV6-2113TX, DV6-2114TX, DV6-2120TX, DV6-2145TX, DV6-3006TX, DV7-1000, DV7-1002TX, DV7-1005TX, DV7-1014TX, DV7-1015TX, DV7-1019TX, DV7-1026TX, DV7-1104TX, DV7-1105TX, DV7-1107TX, DV7-2012TX, DV7-2014TX, DV7-2022TX, DV7-3105TX, DV7-3107TX, DV7Z-1000	L111	×	×	Q
	ProBook	4310s (ATI Graphics), 4310s (Intel Graphics), 4320s (ATI Graphics), 4320s (Intel Graphics), 4410s, 4411s, 4415s, 4416s, 4420s (ATI Graphics), 4420s (Intel Graphics), 4510s (ATI Graphics), 4510s (Intel Graphics), 4515s (ATI Graphics HD 3200), 4515s (ATI Graphics HD 4330), 4710s, 5310m, 6440b (ATI Graphics), 6440b (Intel Graphics), 6445b, 6545b, 4520s (Intel Graphics), 4520s (ATI Graphics), 4720s (Intel Graphics), 4720s (ATI Graphics)	L111	×	×	Q
	Special Edition	L2000, L2005A3 MV IUR, L2005A4 MV IUR, L2098XX MV IUR, L2099XX MV IUR	L107	×	T	T
	TouchSmart	TX2- series, TX2z series	L107	×	×	T
		TX2-1301AU, TX2-1304AU, TX2-1305AU, TX2-1307AU, TX2-1308AU, TX2-1310AU, TX2-1312AU, TX2-1314AU, TX2-1316AU, TX2-1322AU, TX2-1323AU, TX2-1325AU, TX2-1326AU	L107	×	T	T
	TM2-1001TX, TM2-1002TX, TM2-1004TX, TM21005TX, TM2-1007TX, TM2-1008TX, TM2-1009TX, TM2-1012TX, TM2-1013TX, TM2-1014TX, TM2-1018TX, TM2T-1000 CTO	L111	×	×	Q	
IBM/ Lenovo	3000	Y410	L106	×	P	P
		C100, C200, C205, N100 (Intel Graphic card), N100 (NVIDIA Graphic card), N200 (Intel Graphic card), N200 (NVIDIA Graphic card), V100, V200	L112	×	R	R
	IdeaPad	U110, U330, Y430, Y510, Y530, Y650, Y710, Y730, Y430-3222U, Y430-5232U, Y430-5342U, Y530-7343U	L106	×	P	P
	IdeaPad Netbook	S10, S10e, S10-1208U, S10-1211Uw, S10-2, S10-3T, S9, S9e	L106	×	P	P
	ThinkPad	240, 240X, 290, 365, 365XD, 380, 380D, 380E, 380ED, 380XD, 380Z, 385, 385D, 385ED, 385XD, 390, 390E, 390X, 560, 560E, 560X, 560Z, 570, 600, 600E, 600X, 701, 770, 770E, 770ED, 770X, 770Z, A20, A20m, A20p, A21, A21e, A21m, A21p, A22, A22e, A22m, A22p, A30, A30p, A31, A31p, A50, A50p, A51p, i1200, i1300, i1400-2621, i1500-2621, i1720, i1721, R30, R31, R32, R40, R40e, R50, R50e, R50p, R51, R51e, R52, T20, T21, T22, T23, T30, T40, T40p, T41, T41p, T42, T42p, T43, T43p, TransNote, X Series Tablet, X20, X21, X22, X23, X24, X30, X31, X32, X40, X41, X41 Tablet	L105	P	×	×
		1400-2611, 1500-2611, 310, 310D, 310E, 310ED	L106	×	U	×
		G50, R400, R500, R60, R60e, R61 (Intel Graphic card), R61 (NVIDIA Graphic card), R61e, R61i, SL300 (Intel Graphic card), SL300 (NVIDIA Graphic card), SL400 (Intel Graphic card), SL400 (NVIDIA Graphic card), SL500 (Intel Graphic card), SL500 (NVIDIA Graphic card), T400 (Intel Graphic card), T400 (NVIDIA Graphic card), T500 (ATI Graphic card), T500 (Intel Graphic card), T60 (ATI Graphic card), T60 (Intel Graphic card), T60p, T61 (Intel Graphic card), T61 (NVIDIA Graphic card), T61p (Intel Graphic card), T61p (NVIDIA Graphic card), W500, X200, X200S, X300, X301, X60, X60 Tablet, X60s, X61 Tablet, X61s, X61t, Z60m, Z60t, Z61e, Z61m, Z61p, Z61t, SL410, SL410-2842FBU, SL510, T410, X100e, X200 Tablet, X201 Tablet	L112	×	R	R
	ThinkPad Reserve	Cingular Edition, Verizon Edition	L112	×	R	R



**Universal adaptors** are available in AC & AC/DC versions to provide power wherever it's needed. They will work with more than 90% of laptops in the market and can be used with most laptops via interchangeable tips that adjust the voltage automatically. **Replacement AC adaptors** are limited to laptop models that use 15/16V & 19/20V to suit most common brands & models –they are ideal as replacement or additional AC adaptors, but may not work with your next laptop.

Universal		Replacement		
90W AC - APA68AU		75W AC - APA02AU	90W AC - APA03AU	90W AC - APA30AU
90W DC - APD80AU				
90W AC/DC - APM68AU				

Manufacturer	Model Name	Series	Tip	Tip	Tip	Tip
<b>iRex</b>		DR800SG	x	x	x	x
<b>Leader Computers</b>	COMPANION 210	Z96SP	L106	x	x	x
	COMPANION 212	Z96SP	L106	x	x	x
	COMPANION 214	Z96SP	L106	x	x	x
	EX600	MS-1636	L106	x	x	x
	EX620	MS-1674	L106	x	x	x
	GX620		L106	x	x	x
	Leader Slate		L131* © Freecall now for free tip!	x	x	x
	M670		L106	x	x	x
	U100		L106	x	x	x
	VR601		L106	x	x	x
	VR630		L106	x	x	x
	VR705		L106	x	x	x
<b>LG</b>	F1	F1-2224A	L107	x	x	x
		F1-2226A	L107	x	x	x
	LE Series	LE50-5	L107	x	x	x
	LM Series	LM50	L107	x	x	x
		LM60 Express	L107	x	x	x
	LS Express	LS55	L108	x	T	A
		LS70	L108	x	T	A
	LS Series	LS70-FLA4PA	L107	x	x	x
		LS50-1, LS50-2, LS50-3, LS50-4, LS50-5, LS50-UK2A, LU-20 Tablet	L108	x	T	A
	LW Series	LW20-22, LW40, LW60, LW65, LW70, LW75, LW80	L107	x	x	x
Netbook	X110, X100 Series, X110 Series	L106	x	P	P	
Pro	M1-M2FTV, P1, P1-52A7A, P1-J101A, P1-J102A, P1-J226A, P1-J2A8A, P1-J2B8A, P1-J5C6A, P1-J7P1A, P1-JUWSA, P1-JWS1A, P1-JWS2A, P1-KB10A, P1-KB11A, P1-KB20A, S1-MMNPA3, S1-P723A, Z1-A555P	L107	x	x	x	
<b>Macron</b>	Macron	M363C, M540G, M540N, M550G, M550N, M551N, NW120, NW150, NX150	L105	P	x	x
<b>Medion</b>	Medion	MD9326	L106	x	P	P



**Universal adaptors** are available in AC & AC/DC versions to provide power wherever it's needed. They will work with more than 90% of laptops in the market and can be used with most laptops via interchangeable tips that adjust the voltage automatically. **Replacement AC adaptors** are limited to laptop models that use 15/16V & 19/20V to suit most common brands & models –they are ideal as replacement or additional AC adaptors, but may not work with your next laptop.

Universal		Replacement		
90W AC - APA68AU		75W AC APA02AU	90W AC APA03AU	90W AC APA30AU
90W DC - APD80AU				
90W AC/DC - APM68AU				

Manufacturer	Model Name	Series	Tip	Tip	Tip	Tip
NEC	LaVie	C Series, F Series, G Series, J Series, L Series, M Series, ME Series, N Series, Pro Series, T Series	L106	×	P	P
	Pocket Gear	MC/PG5000, MC/PG7000	L106	×	P	P
	Ready	220T, 230T, 330T, 340T, 360T, 440T	L106	×	P	P
	Versa	2400, 2500, 2500CD, 2505, 2530, 4000, 4000 Series, 4000C, 4000D, 4000Hs, 4050C, 4050D, 4050H, 4080H, 4200, 4230, 500, 5000, 5060, 5060X, 5080, 5080X, 550D, A2100, C140, C150, C160, E120, E200, E2000, E3100, E3100-1812DW, E3100-1813DR, E600, E6000, E6000X, E6200, E6200-1703DR, E6210, E6210-1604DR, E6210-1627DR, E6210-1809DR, E6210-1810DR, E6210-1811DR, E6300, E6300-1504DR, E6300-1803DR, E6300-2201DR, E6310, E6310-2000DR, E680, FM320, FM500, FP520, FS800, IGO3000, IGO5000, IGO6000, L2100, L2100-1605DR, L2100-1606DR, L2100-1803DR, L2200-1802DR, L320, M300, M320, M3210, M440, M450, M500, M54, M540, P440, P520, P600, P700, P7200, P7200-1607DR, P7200-1800DR, P9110, P9110-1500DR, P9110-1800DR, P9110-2203DR, Premium, S1100, S800, S820, S940, S970, T400, T400S820, VersaNote, VX	L106	×	P	P
		2000C, 2000D, 2205C, 2250, 6000, 6000H, 6010H, 6030H, 6030X, 6050 Series, 6050MH, 6050MT, 6050MX, 6060, 6200 Series, 6200MX, 6200NT, 6220, 6230, 6260	×	×	S	×
	VersaPro	VJ13M/AF-T, VJ13M/DF-R, VJ13M/RF-R, VJ13M/RX-R, VJ16F/RF-R, VJ16F/RX-R, VJ17F/AF-T, VJ17F/AG-T, VJ17F/DF-R, VJ17F/DG-R, VJ18F/RF-R, VJ20F/AE-T, VJ20F/AF-T, VJ20F/AG-T, VJ20F/DF-R, VJ20F/DG-R, VY13M/AF-T, VY13M/DF-R, VY13M/EF-R, VY13M/EX-R, VY13M/RF-R, VY13M/RX-R, VY16F/EF-R, VY16F/EX-R, VY16F/RF-R, VY16F/RX-R, VY17F/AF-T, VY17F/AG-T, VY17F/DF-R, VY17F/DG-R, VY18F/RF-R, VY20F/AE-T, VY20F/AF-T, VY20F/AG-T, VY20F/DF-R, VY20F/DG-R	L106	×	P	P
VersaPro NX	LW23C/52, LW23D, LW26H, LW30H, LW33H	L106	×	P	P	
Optima	Centoris	25911, E+ Series, EF6C, EW1, EW2G, F Series, G Series, L2400, TW3, V470, V662, V670, V862, V870, W Series, ZW1, ZW9	L106	×	P	P
	ProLite	K Series	L108	×	T	A
Packard Bell	Butterfly	Butterfly Touch, Butterfly XS	L108	×	×	A
	Dot Netbook	Dot, Dot M, Dot MA, Dot S, Dot SE	L108	×	×	A
	EasyNote	1800DR, BG46, C16, C3, MB88-003, MX37-U-041, R8, SB88, XS20, LJ65-RB-055, LJ71-RB-025, LJ75-JO-080, TJ65-AU-031, TJ65-AU-052, TJ65-BT-041, TJ71-RB-050, TJ71-RB-055, TJ74-RB-050, TJ75-JN-070	L106	×	P	P
	G5	L108	×	T	A	
Panasonic	Toughbook	52, 74, CF18, CF19, CF29, CF30, CF50, CF51, CF73, CFR1, CFR4, CFR7, CFT1, CFT2, CFW2, CFW4, T4, T5, T7, T8, W5, W7, W8, Y4, Y5, Y7	L105	P	×	×
		CFV21, CFV21P	L110	×	N	N
		CF01, CF11, CF17, CF170, CF25, CF27, CF270, CF28, CF33, CF34, CF35, CF37, CF370, CF380, CF41, CF45, CF47, CF48, CF61, CF62, CF63, CF71, CF72, CFM34, CFR, CFT, CFV25, CFV41	L130 © Freecall now for free tip!	N	×	×
	Toughbook Netbook	H1, U1	L105	P	×	×
NoteMaster	486C/25	L104	M	×	×	
Samsung	Samsung	M40, NP-Q1, NP-Q30, NX05, NX10, NX15, NX30, P200, P28, P30, P35, P460-44G, P460-44P, P560-54G, P560-54P, Q1B, Q1P SSD, Q1P Vista, Q1U-CMXP, Q1U-EL, Q1U-ELXP, Q1U-SSDXP, Q1U-V, Q1U-XP, Q30, Q310-34G, Q310-34P, Q45, R50, R509, R510, R610, R610-64G, R710, X05, X06, X10, X10Plus, X11 (Intel Graphic card), X15, X15Plus, X20, X30, X360-34G, X360-34P, X460-41S, X460-44G, X460-44P, Q1P, R580-JS06AU, R580-JS07AU, R580-JS02AU, R580-JS05AU, Q320, QX310-S01AU, R580-JS04AU, Q330-JS03AU, QX510-S02AU, SF310-S01AU, SF510-S02AU, SF510-S01AU, R580-JT01AU, R580-JT02AU, R590-JS02AU, R780-JS04AU, R540-JS03AU, R540-JA02AU, R540-JS08AU, RV510-A01AU, P530-JS03AU, P580-JS02AU	L127* © Freecall now for free tip!	×	×	×
	Samsung Netbook	NC10, N150-JP03AU, N145-JP02AU, NF210-A01AU, NF310-A01AU	L110	×	N	N



**Universal adaptors** are available in AC & AC/DC versions to provide power wherever it's needed. They will work with more than 90% of laptops in the market and can be used with most laptops via interchangeable tips that adjust the voltage automatically. **Replacement AC adaptors** are limited to laptop models that use 15/16V & 19/20V to suit most common brands & models –they are ideal as replacement or additional AC adaptors, but may not work with your next laptop.

Universal		Replacement		
90W AC - APA68AU		75W AC APA02AU	90W AC APA03AU	90W AC APA30AU
90W DC - APD80AU				
90W AC/DC - APM68AU				

Manufacturer	Model Name	Series	Tip	Tip	Tip	Tip
Samsung	Sens	500, 810	L110	✗	N	N
		SX30-C160	L127* ☉ Freecall now for free tip!	✗	✗	✗
		700, 800	L130* ☉ Freecall now for free tip!	N	✗	✗
	SensPro	500, 505, 520, 521, 525	L110	✗	N	N
	PictureBook	C1X	L130	N	✗	✗
Sony	Vaio	705, 707, 717, 719, 729, 731, 735, 748, 800, 808, 81, 812, 818, 838, A17GP, A19GP, A29GP, A29TP, C1XW, F150, F160, F180, F190, F250, F270, F280, F290, F304, F305, F309, F340, F350, F360, F370, F390, F400, F400LT, F403, F409, F420, F430, F450, F480, F480K, F490K, F520, F540, F540K, F560, F560K, F580, F580K, F590, F590K, F630, F660, F670, F680, F690, F701, F707, F709, F709K, F801, F801A, F807, F807K, F808K, F809K, FR102, FR105, FR130, FR700H, FX101, FX103, FX105K, FX108K, FX109K, FX120, FX140, FX150, FX170, FX190, FX200, FX201, FX203, FX203K, FX205K, FX209K, FX220K, FX270, FX301, FX401, FX405, FX501, FX502, FX505, FX601, FX602, FX604, FX605, FX701, FX702, FX705, FX770K, FX800, FX801, FX802, FX804, FX805, FX880K, FX902P, FX905P, FXA32, FXA33, FXA36, FXA63, GRS100, GRS150, GRS515M, GRS515R, GRS515SP, GRS614MP, GRS700, GRS700K15, GRX316SP, GRX3P, GRX416SP, GRX500, GRX516SP, GRX520, GRX520/B, GRX550, GRX560, GRX570, GRX580K, GRX590, GRX5P, GRX600, GRX650, GRX670, GRX690, GRX700, NV100, NV105, NV109M, NV170, NV190, NV200, NV209, NV309, NVR23, PCG-7N2M, PCG-F670T, PCG-FR215E, PCG-FR215H, PCG-FR215M, PCG-FR215S, PCG-FR295MP, PCG-FR315M, PCG-FR700, PCG-FR700H, PCG-FR700S, PCG-FR720, PCG-FR720L, PCG-FR720S, PCG-FR820L, PCG-FR820S, PCG-FR825P, PCG-FR825SP, PCG-FR725, PCG-FX240, PCG-FX240K, PCG-FX390, PCG-FX390K, PCG-FX390P, PCG-FX770TK, PCG-FX800, PCG-FX880K, PCG-FX900, PCG-FX900H, PCG-FX950, PCG-FX950H, PCG-FX990, PCG-FXA10, PCG-FXA10H, PCG-GRX1P, PCG-GRX3HP, PCG-GRX3LP, PCG-GRX3P, PCG-GRX5LP, PCG-GRX5P, PCG-NV190, PCG-NV7EL, PCG-NV7L, PCG-R505AFH, PCG-R505AFT, PCG-R505AGT, PCG-R505CT, PCG-R505DT, PCG-R505GL, PCG-R505GLK, PCG-R505MFL, PCG-R505MGH, PCG-R505MGL, PCG-R505MP, PCG-R505TFL, PCG-R505TFP, PCG-TR5GP, PCG-XE17, PCG-Z505GAT, PCG-Z505GATH, PCG-Z505GATM, PG32, QR10, QR20, R500, R505B/P, R505CT, R505D, R505DS, R505DSK, R505DT, R505J, R505MP, R505MXC, R505T, R505TE, R505TEK, R505TFP, R505TS, R505TXCP, R505TZCP, R600HEK, R600HEP, R600HFPD, R600HMPP, R600MX, VGC-LJ25G/B, VGN-A115B, VGN-A115S, VGN-A115Z, VGN-A117S, VGN-A130, VGN-A130B, VGN-A130B28, VGN-A130P, VGN-A140, VGN-A140B, VGN-A140P, VGN-A140S, VGN-A150, VGN-A150P, VGN-A150S, VGN-A15LP, VGN-A160, VGN-A170, VGN-A170B, VGN-A170P, VGN-A17GP, VGN-A17LP, VGN-A17SP, VGN-A190, VGN-A195EP, VGN-A195HP, VGN-A197VP, VGN-A197XP, VGN-A19GP, VGN-A19LP, VGN-A19SP, VGN-A215M, VGN-A215Z, VGN-A217M, VGN-A217S, VGN-A21C, VGN-A230B1, VGN-A230P, VGN-A240, VGN-A250, VGN-A260, VGN-A270, VGN-A270B, VGN-A270P, VGN-A290, VGN-A295HP, VGN-A297XP, VGN-A29LP, VGN-A29SP, VGN-A317M, VGN-A317S, VGN-A397XP, VGN-A39GP, VGN-A417M, VGN-A417S, VGN-A497XP, VGN-A49GP, VGN-A517B, VGN-A517M, VGN-A517S, VGN-A59GP, VGN-A600, VGN-A60091, VGN-A600B, VGN-A600P, VGN-A60GP, VGN-A617B, VGN-A617M, VGN-A617S, VGN-A690, VGN-A790, VGN-AR38G, VGN-AX570G, VGN-AX580G, VGN-BX143, VGN-BX145CP, VGN-BX168GP, VGN-BX194VP, VGN-BX195EP, VGN-BX195VP, VGN-BX195XP, VGN-BX196SP, VGN-BX196VP, VGN-BX196XP, VGN-BX197XP, VGN-BX294VP, VGN-BX295SP, VGN-BX295VP, VGN-BX296VP, VGN-BX296XP, VGN-BX297XP, VGN-BX394VP, VGN-BX396BP, VGN-BX396VP, VGN-BX396XP, VGN-BX397XP, VGN-BX41XN, VGN-BX540B, VGN-BX541B, VGN-BX543B, VGN-BX546B, VGN-BX560B, VGN-BX561B, VGN-BX563B, VGN-BX565B, VGN-BX567B, VGN-BX570B, VGN-BZ15GN, VGN-C140G/B, VGN-C150P/B, VGN-C190, VGN-C190P/H, VGN-C1S/G, VGN-C1S/H, VGN-C1S/P, VGN-C1S/W, VGN-C1Z/B, VGN-C210E/H, VGN-C21GH, VGN-C220E/H, VGN-C240E/B, VGN-C250N/B, VGN-C25G, VGN-C290, VGN-C291NW/H, VGN-C2S/G, VGN-C2S/H, VGN-C2S/L, VGN-C2S/P, VGN-C2S/W, VGN-C2Z/B, VGN-C31GHW, VGN-CR22G/B, VGN-CR25GN, VGN-CR25GW, VGN-CR32G, VGN-CR32G/B, VGN-CR343N/B, VGN-CR343NB, VGN-CR353/B, VGN-CR353B, VGN-CR353L, VGN-CR353N, VGN-CR353P, VGN-CR353Q, VGN-CR353S, VGN-CR353T, VGN-CR353W, VGN-CR35G/W, VGN-CS15GN/B, VGN-CS16G/Q, VGN-CS25GN/B, VGN-CS26G/P, VGN-CS26GP, VGN-CS26GQ, VGN-CS26GR, VGN-CS26GW, VGN-CS35GN/B, VGN-CS35GNB, VGN-CS36G/J, VGN-CS36G/JC, VGN-CS36G/JI, VGN-CS36G/JJ, VGN-CS36G/JP, VGN-CS36G/JQ, VGN-CS36G/JR, VGN-CS36G/JT, VGN-CS36G/JU, VGN-CS36G/JV, VGN-CS36G/JW, VGN-FE11S, VGN-FE25TP, VGN-FE28B, VGN-FE28H, VGN-FE31B, VGN-FE31H, VGN-FE31M, VGN-FE31Z, VGN-FE41E, VGN-FE41M, VGN-FE41S, VGN-FE41Z, VGN-FE45G, VGN-FE48G, VGN-FE550G, VGN-FE570G, VGN-FE590GC, VGN-FE590P03, VGN-FE590PA, VGN-FE590PB, VGN-FE590PC, VGN-FE660G, VGN-FE670G, VGN-FE690, VGN-FE690GB, VGN-FE770G, VGN-FE780G, VGN-FE790, VGN-FE790GN, VGN-FE790PL, VGN-FE870E/H, VGN-FE880E/H,	L110	✗	N	N



**Universal adaptors** are available in AC & AC/DC versions to provide power wherever it's needed. They will work with more than 90% of laptops in the market and can be used with most laptops via interchangeable tips that adjust the voltage automatically. **Replacement AC adaptors** are limited to laptop models that use 15/16V & 19/20V to suit most common brands & models –they are ideal as replacement or additional AC adaptors, but may not work with your next laptop.

Universal		Replacement		
90W AC - APA68AU	90W DC - APD80AU	75W AC - APA02AU	90W AC - APA03AU	90W AC - APA30AU
90W AC/DC - APME8AU				

Manufacturer	Model Name	Series	Tip	Tip	Tip	Tip
Sony	Vaio	VGN-FE890, VGN-FE890N/H, VGN-FJ170/B, VGN-FJ180P/G, VGN-FJ180P/L, VGN-FJ180P/R, VGN-FJ180P/W, VGN-FJ1S/W, VGN-FJ1Z/W, VGN-FJ250P/B, VGN-FJ270P/B, VGN-FJ290, VGN-FJ290P1/G, VGN-FJ290P1/L, VGN-FJ290P1/R, VGN-FJ290P1/V, VGN-FJ290P1/W, VGN-FJ3S/W, VGN-FJ56C, VGN-FJ56G, VGN-FJ57C, VGN-FJ57SP, VGN-FJ58C, VGN-FJ58GP, VGN-FJ58SP, VGN-FJ66GP, VGN-FJ66GP/W, VGN-FJ67GP/W, VGN-FJ68GP, VGN-FJ68GP/W, VGN-FJ77GP/B, VGN-FJ78GP/B, VGN-FJ78GP/W, VGN-FJ78GPL, VGN-FJ78GPR, VGN-FJ79TP/V, VGN-FJ79TP/W, VGN-FR820, VGN-FR825P, VGN-FS115B, VGN-FS115E, VGN-FS115M, VGN-FS115S, VGN-FS115Z, VGN-FS15C, VGN-FS15GP, VGN-FS15LP, VGN-FS15SP, VGN-FS18CP, VGN-FS18GP, VGN-FS18LP, VGN-FS18SP, VGN-FS195VP, VGN-FS195XP, VGN-FS215B, VGN-FS215E, VGN-FS215M, VGN-FS215MR, VGN-FS215S, VGN-FS215SR, VGN-FS215Z, VGN-FS25C, VGN-FS25GP, VGN-FS25SP, VGN-FS285B, VGN-FS285E, VGN-FS285H, VGN-FS285M, VGN-FS28C, VGN-FS28GP, VGN-FS28SP, VGN-FS295VP, VGN-FS295XP, VGN-FS315B, VGN-FS315E, VGN-FS315H, VGN-FS315M, VGN-FS315MR, VGN-FS315S, VGN-FS315Z, VGN-FS35C, VGN-FS35GP, VGN-FS35SP, VGN-FS38C, VGN-FS38GP, VGN-FS38SP, VGN-FS395VP, VGN-FS415B, VGN-FS415E, VGN-FS415M, VGN-FS415S, VGN-FS485B, VGN-FS48GP, VGN-FS495VP, VGN-FS500, VGN-FS500B, VGN-FS500P, VGN-FS500P12, VGN-FS515B, VGN-FS515E, VGN-FS515H, VGN-FS520B, VGN-FS530B, VGN-FS540P, VGN-FS550, VGN-FS550F, VGN-FS550P, VGN-FS570, VGN-FS610FP, VGN-FS615FP, VGN-FS620P/W, VGN-FS625B/W, VGN-FS630/W, VGN-FS635B/W, VGN-FS640/W, VGN-FS640FP, VGN-FS645P/H, VGN-FS650F, VGN-FS655FP, VGN-FS660/W, VGN-FS660P/W, VGN-FS670FG, VGN-FS675P/H, VGN-FS680/W, VGN-FS690, VGN-FS690B, VGN-FS690P, VGN-FS710/W, VGN-FS710FP, VGN-FS715/W, VGN-FS715F, VGN-FS720/W, VGN-FS730/W, VGN-FS730F, VGN-FS740/W, VGN-FS740FP, VGN-FS742/W, VGN-FS745P/H, VGN-FS750F, VGN-FS750P/W, VGN-FS755FP, VGN-FS760/W, VGN-FS770/W, VGN-FS770FG, VGN-FS775P/H, VGN-FS790, VGN-FS810/W, VGN-FS810FP, VGN-FS812F, VGN-FS815F, VGN-FS830/W, VGN-FS840/W, VGN-FS850, VGN-FS850/W, VGN-FS850P, VGN-FS850P/W, VGN-FS875P/H, VGN-FS8900, VGN-FS8900P3, VGN-FS8900P4, VGN-FS8900P5, VGN-FS920, VGN-FS930F, VGN-FS940, VGN-FS960P, VGN-FS970P, VGN-FS980, VGN-FS990, VGN-FW15G/B, VGN-FW15GB, VGN-FW15GW, VGN-FW16G/W, VGN-FW16GW, VGN-FW17GU/H, VGN-FW17GUH, VGN-FW23G/W, VGN-FW25G/B, VGN-FW26G/B, VGN-FW27GU/H, VGN-FW33G/W, VGN-FW33GW, VGN-FW35G/B, VGN-FW36GJ/B, VGN-FW37, VGN-FW37GY/H, VGN-FW43G/W, VGN-FW43GB, VGN-FW43GW, VGN-FW45GJ/B, VGN-FW45GJB, VGN-FW46GJ/B, VGN-FW46GJB, VGN-FW47GY/H, VGN-FW47GYH, VGN-FW53GF/W, VGN-FW55GF/B, VGN-FW56GF/B, VGN-FW57GH/H, VGN-FZ17G, VGN-FZ25G, VGN-FZ27G, VGN-FZ28G, VGN-FZ323G, VGN-FZ32G, VGN-FZ35G, VGN-FZ35GN, VGN-FZ37G, VGN-FZ38GU, VGN-FZ55GN, VGN-N110G/W, VGN-N111H/W, VGN-N111M/W, VGN-N11S/W, VGN-N130G/W, VGN-N130P/B, VGN-N150G/W, VGN-N150P/B, VGN-N160G/W, VGN-N170G/T, VGN-N170G/W, VGN-N19EP/B, VGN-N19VP/B, VGN-N21E/W, VGN-N21M/W, VGN-N21M/W, VGN-N21S/W, VGN-N220E/B, VGN-N220E/W, VGN-N230E/B, VGN-N230E/T, VGN-N230E/W, VGN-N230N/B, VGN-N250E/W, VGN-N250N/B, VGN-N270E/T, VGN-N270E/W, VGN-N27GH, VGN-N29VN/B, VGN-N320E/B, VGN-N320E/W, VGN-N350E/B, VGN-N350E/T, VGN-N350E/W, VGN-NR37GHB, VGN-NR27G, VGN-NR37G/S, VGN-NR37GS, VGN-NS15G/S, VGN-NS25G/S, VGN-NW15G/T, VGN-NW15GS, VGN-NW15GT, VGN-NW15GW, VGN-NW17GJ/S, VGN-NW17GJS, VGN-NW23GF/P, VGN-NW25GF/P, VGN-NW29GF/B, VGN-S380, VGN-S380B, VGN-S38GP, VGN-S38GP/B, VGN-S38LP/B, VGN-S38SP, VGN-S3HP, VGN-S3VP, VGN-S3XP, VGN-S430P/S, VGN-S45, VGN-S45SP, VGN-S46, VGN-S460, VGN-S460/B, VGN-S460P/B, VGN-S46GP/S, VGN-S470P/S, VGN-S470P/SKIT, VGN-S470P/SKIT7, VGN-S47SP, VGN-S48, VGN-S480, VGN-S480B, VGN-S48GP/B, VGN-S49, VGN-S4HP, VGN-S4HP/B, VGN-S4HRP/B, VGN-S4M/S, VGN-S4VP/B, VGN-S4XP, VGN-S4XRP/B, VGN-S55, VGN-S550P/S, VGN-S55SP/S, VGN-S56, VGN-S560P/B, VGN-S56GP/S, VGN-S570P/S, VGN-S57SP/B, VGN-S58, VGN-S580, VGN-S58GP/B, VGN-S59, VGN-S5HP, VGN-S5M/S, VGN-S5VP, VGN-S5XP/B, VGN-S660/B, VGN-S67GP/S, VGN-S67TP, VGN-SR16GN/B, VGN-SR16GNB, VGN-SR16GNP, VGN-SR16GNS, VGN-SR16NB, VGN-SR26GN/B, VGN-SR36GN/B, VGN-SR46GD/B, VGN-SR46GDB, VGN-SR46GDP, VGN-SR53GF/W, VGN-SR56GG/B, VGN-SZ110/B, VGN-SZ120P, VGN-SZ120P/B, VGN-SZ140, VGN-SZ140PC, VGN-SZ140PD, VGN-SZ160P/C, VGN-SZ17G, VGN-SZ210P/B, VGN-SZ220/B, VGN-SZ230P/B, VGN-SZ23TP/B, VGN-SZ240, VGN-SZ250P/C, VGN-SZ260P, VGN-SZ26TP/C, VGN-SZ270P/C, VGN-SZ280P/C, VGN-SZ281P/X, VGN-SZ28TP/C, VGN-SZ2VP/X, VGN-SZ320P/B, VGN-SZ330P/B, VGN-SZ340, VGN-SZ360P/C, VGN-SZ370P/C, VGN-SZ381P/X, VGN-SZ38GP, VGN-SZ390, VGN-SZ390PW1, VGN-SZ3HP/B, VGN-SZ3VP/X, VGN-SZ3VWP/X, VGN-SZ3XP/C, VGN-SZ3XWP/C, VGN-SZ430N/B, VGN-SZ433NB, VGN-SZ43GN, VGN-SZ440, VGN-SZ44GN, VGN-SZ450N/C, VGN-SZ453NB, VGN-SZ460N/C, VGN-SZ470N/C, VGN-SZ480, VGN-SZ483NC, VGN-SZ48GN, VGN-SZ491N/X, VGN-SZ4MN/B, VGN-SZ4VN/X, VGN-SZ4VWN/X, VGN-SZ4XWN/C, VGN-SZ55GNB, VGN-SZ5MN/B, VGN-SZ75GN/B, VGN-SZ75GNB, VGN-SZ79GNC, VGN-SZ9GN/C, VGN-TX56GN, VGN-Z16GN/B, VGN-Z16GNB, VGN-Z17GN/B, VGN-Z17GNB, VGN-Z26GN/B, VGN-Z27GN/X, VGN-Z36GD/J, VGN-Z37GD/X, VGN-Z46GD/U, VGN-Z46GDB, VGN-Z46GDU, VGN-Z47GD/X, VGN-Z47GDX, VGN-Z48GD/X, VGN-Z48GDX, VGN-Z56GGE, VGN-Z57GGX, VGN-Z58GGX, VPC-CW15FG/W, VPC-CW1AGG/B, VPC-EB13FGBI, VPC-EB16FGB, VPC-EB17FGB, VPC-EB1AGGBI, VPC-F115FG/B, VPC-S113FG/B, VPC-S117GG/B, VPC-Y115FG/S, X18, X29, X9, XE17, XE7, XG18, XG19, XG28, XG28K, XG29, XG29K, XG38, XG39, XG39K, XG500, XG700, XG9, Z505, Z505FA, Z505GA, Z505GAH, Z505GAM, Z505HE, Z505HS, Z505HSK, Z505JE, Z505JEK, Z505JS, Z505JSK, Z505LE, Z505LEK, Z505LS, Z505LSK, Z505R, Z505RX, Z505S, Z505SX, Z600HEK, Z600LEK, Z600NE, Z600NEK, Z600RE, Z600TEK	L110	x	N	N





**Universal adaptors** are available in AC & AC/DC versions to provide power wherever it's needed. They will work with more than 90% of laptops in the market and can be used with most laptops via interchangeable tips that adjust the voltage automatically. **Replacement AC adaptors** are limited to laptop models that use 15/16V & 19/20V to suit most common brands & models –they are ideal as replacement or additional AC adaptors, but may not work with your next laptop.

Universal		Replacement		
90W AC - APA68AU		75W AC APA02AU	90W AC APA03AU	90W AC APA30AU
90W DC - APD80AU				
90W AC/DC - APM68AU				

Manufacturer	Model Name	Series	Tip	Tip	Tip	Tip
Sony	Vaio	B55T, C1MHP, C1MT, C1MT1, GR100, GR100K, GR114EK, GR114MK, GR114SK, GR150K, GR170K, GR200, GR200K, GR200P, GR214CP, GR214EP, GR214MP, GR215MP, GR215SP, GR250, GR250K, GR250P, GR270, GR270K, GR270P, GR290, GR290K, GR290P, GR300, GR314MP, GR315MP, GR370, GR390, GR414SP, PCG-C1MAH, PCG-C1MEL, PCG-C1MTL, PCG-SR19GKRT, PCG-SR19GT, PCG-SRX55H, PCG-SRX55L, PCG-SRX55TH, PCG-SRX55TL, PCG-SRX87, PCG-TR1, PCG-TR1L, PCG-TR1MP, PCG-TR1S, PCG-TR2, PCG-TR2L, PCG-TR2MP, PCG-TR2S, PCG-TR3, PCG-TR3AP3, PCG-TR3S, PCG-TR5AP, PCG-TR5L, PCG-TR5MP, PCG-V505AK, PCG-V505ECP14, PCG-V505GL, PCG-V505GP, PCG-V505GSP, PCG-V505L, PCG-V505MLP, PCG-V505MNP, PCG-V505MNSP, PCG-V505MP, PCG-V505MSP, PCG-V505MZL, PCG-V505P, PCG-V505SP, PCG-Z1GP, PCG-Z1LP, PCG-Z1MP, PCG-Z1RGP, PCG-Z1RPL, PCG-Z1VGP, PCG-Z1VJP, PCG-Z1VLP, PCG-Z1VXZLP, PCG-Z1XGP, PCG-Z1XJP, PCG-Z1X-LP, PCG-Z1XMP, PCG-Z1XSP, S150, S150P, S18GP, S26TP, S28TP, S36GP, S36TP, SR1, SR11K, SR17, SR17K, SR19G, SR19K, SR21, SR21K, SR5K, SR7K, SR9G, SRX41P, SRX51P, SRX51PA, SRX51PB, T17TP, T26SP, T37GP, T37SP, TR1, TR1A, TR1AP, TR2, TR2A, TR2AP1, TR2AP3, TR3, TR3A, TR3AP1, TR3AP2, TR5GP, V505A, V505AC, V505AX, V505AXP, V505B, V505BC, V505BX, V505BXP, V505D, V505DC1, V505DC11, V505DC1P2, V505DC1P7, V505DC1PC, V505DC1PF, V505DC21, V505DC2P1, V505DX, V505DXP, V505EC, V505EC29, V505ECP1, V505ECP29, V505ECP8, V505EX, V505EXP, V505GP, V505MP, V505P, VGN-B100B, VGN-B100B01, VGN-B100B02, VGN-B100B03, VGN-B100B04, VGN-B100B07, VGN-B100B08, VGN-B100B09, VGN-B100B28, VGN-B100GP, VGN-B1VP, VGN-B1XP, VGN-B3VP, VGN-B3XP, VGN-B55C, VGN-B55G, VGN-B55L, VGN-B55S, VGN-B66GP, VGN-B66SP, VGN-B77GP, VGN-B77SP, VGN-B88C, VGN-B88GP, VGN-B88L, VGN-B99C, VGN-B99GP, VGN-G11VN/T, VGN-G11XN/B, VGN-S16GP, VGN-S16LP, VGN-S16SP, VGN-S170, VGN-S170P6, VGN-S18GP, VGN-S18LP, VGN-S18SP, VGN-S1HP, VGN-S1VP, VGN-S1XP, VGN-S25C, VGN-S260, VGN-S260P, VGN-S26C, VGN-S26GP, VGN-S26LP, VGN-S26SP, VGN-S270, VGN-S270B, VGN-S270B13, VGN-S270P, VGN-S27C, VGN-S28C/P, VGN-S28GP, VGN-S28LP, VGN-S28SP, VGN-S2HP, VGN-S2HRP, VGN-S2VP, VGN-S2XP, VGN-S2XRP, VGN-S360, VGN-S360P, VGN-S36C/B, VGN-S36C/S, VGN-S36GP/S, VGN-S36LP/S, VGN-S36SP, VGN-S38CP/B, VGN-T140P/L, VGN-T140P/LKIT1, VGN-T140P/LKIT2, VGN-T150/L, VGN-T150/LKIT2, VGN-T150P/L, VGN-T150P/LKIT1, VGN-T150P/LKIT2, VGN-T150P/T, VGN-T15C/S, VGN-T15C/T, VGN-T160P/L, VGN-T160P/LKIT1, VGN-T160P/LKIT2, VGN-T16GP/S, VGN-T16LP, VGN-T16RLPS, VGN-T16SP, VGN-T170P/L, VGN-T17C/S, VGN-T17GP, VGN-T17GP/S, VGN-T17GP/T, VGN-T17LP, VGN-T1XP/L, VGN-T1XP/T, VGN-T240P/L, VGN-T250/L, VGN-T250P/L, VGN-T250P/S, VGN-T260P/L, VGN-T26C/L, VGN-T26C/T, VGN-T270P/L, VGN-T27C/L, VGN-T27GP, VGN-T27GP/L, VGN-T27GP/S, VGN-T27LP/L, VGN-T27LP/S, VGN-T27TP, VGN-T2XP/L, VGN-T2XP/S, VGN-T340P/L, VGN-T350/L, VGN-T350P/L, VGN-T350P/S, VGN-T350P/T, VGN-T360P/L, VGN-T370P/L, VGN-T37C/L, VGN-TT15GN/B, VGN-TT17GN/X, VGN-TT17GNX, VGN-TT27GD/X, VGN-TT27GDX, VGN-TT35GN/W, VGN-TT35GNB, VGN-TT35GNW, VGN-TT46GG/B, VGN-TT47GG/N, VGN-TT47GG/X, VGN-TX15C, VGN-TX16C, VGN-TX16GP/W, VGN-TX16SP/W, VGN-TX17C, VGN-TX17GP/B, VGN-TX17GP/W, VGN-TX17TP, VGN-TX1HP/W, VGN-TX1XP/B, VGN-TX1XP/L, VGN-TX27GP/B, VGN-TX27GP/T, VGN-TX27GPB, VGN-TX27GPT, VGN-TX27GPW, VGN-TX27TP, VGN-TX2HP/W, VGN-TX2XP/B, VGN-TX36GP/W, VGN-TX37, VGN-TX37GP/B, VGN-TX37GP/T, VGN-TX37GP/W, VGN-TX3HP/W, VGN-TX3XP/B, VGN-TX3XP/L, VGN-TX57GN, VGN-TX5MN/W, VGN-TX5VN/L, VGN-TX5XN/B, VGN-TX610P/B, VGN-TX630P/B, VGN-TX650P/B, VGN-TX651P/B, VGN-TX670P/B, VGN-TX670P/W, VGN-TX690P/LKIT1, VGN-TX750P/B, VGN-TX770P/B, VGN-TX770P/T, VGN-TX770P/W, VGN-TX790P/L, VGN-TX850P/B, VGN-TXN15P/B, VGN-TXN15P/W, VGN-TXN17P/B, VGN-TXN17P/T, VGN-TXN19P/L, VGN-TXN25N/B, VGN-TXN25N/W, VGN-TXN27N/B, VGN-TXN27N/T, VGN-TXN27N/W, VGN-TXN29N/L, VGN-TZ26GN/W, VGN-TZ27GN/R, VGN-TZ27GNB, VGN-TZ27GNR, VGN-TZ28GN/X, VGN-TZ28GNX, VGN-TZ36GN, VGN-TZ36GN/W, VGN-TZ37GN/B, VGN-TZ37GNB, VGN-TZ37GNN, VGN-TZ37GNP, VGN-TZ37GNR, VGN-TZ38GN/X, VGN-TZ38GNX, VGN-U750P, VGN-U8G, VGN-UX17GP, VGN-UX180P, VGN-UX180PKIT1, VGN-UX1XN, VGN-UX27GN, VGN-UX280P, VGN-UX380N, VGN-UX390N, VGN-UX57GN/L, VGN-UX57GNL, VGN-UX505VP, VGN-Y18C, VGN-Y18GP, VX71P, X505, X505ZPKIT, X505ZPKIT2, Z1, Z1A, Z1A1, Z1AP1, Z1AP2, Z1AP3, Z1M, Z1R5P, Z1RA, Z1RAP1, Z1RAP1KITB, Z1RAP2, Z1RAP3, Z1SP, Z1VA, Z1VAP1, Z1VAP1KITB, Z1VAP2, Z1VAP2KITB, Z1WA, Z1WAMP1, Z1WAMP2, Z1WAMP3, Z1WAP, Z1XGP, Z1ZAP1, Z505AX, Z505AXP	L130 © Freecall now for free tip!	N	*	*
		Vaio Netbook	VPC-W115XG/P, VPC-W126AG/P, VPC-W213AG/P, VPC-W215AG/L, VPC-W21EAG/W VGN-P13GH/W, VGN-P15G/R, VGN-P23G/W, VGN-P33GK/W, VGN-P45GK/W, VGN-P25G/N, VPC-X113KG/B, VPC-X115LG/B, VPC-X118LG/B, VPC-X125LG/S, VPC-X128LG/X	L110	*	N
			*	*	*	*



**Universal adaptors** are available in AC & AC/DC versions to provide power wherever it's needed. They will work with more than 90% of laptops in the market and can be used with most laptops via interchangeable tips that adjust the voltage automatically. **Replacement AC adaptors** are limited to laptop models that use 15/16V & 19/20V to suit most common brands & models –they are ideal as replacement or additional AC adaptors, but may not work with your next laptop.

Universal		Replacement		
90W AC - APA68AU		75W AC - APA02AU	90W AC - APA03AU	90W AC - APA30AU
90W DC - APD80AU				
90W AC/DC - APM68AU				

Manufacturer	Model Name	Series	Tip	Tip	Tip	Tip
Toshiba	Libretto	U100 (PLU10A-00500W), U100 (PLU10A-00900W)	L104	M	✗	✗
	Portege	3480CT (PP348E-6PU83), A600 (PPA60A-01H00G), A600 (PPA60A-03800G), A600 (PPA61A-00H005), A600 (PPA61A-00J005), M400 (PPM40A-00F00G), M400 (PPM40A-08M00G), M400 (PPM40A-1HD03D), M400 (PPM40A-1HE03D), M400 (PPM40A-3JS03Y), M400 (PPM40A-3JW03D), M405 (PPM40A-3NY03Y), M500 (PPM51A-01600D), M500 (PPM51A-01P00L), M700 (PPM70A-00W01G), M700 (PPM70A-01Q01G), M700 (PPM70A-03P01G), M700 (PPM70A-0G301G), M700 (PPM70A-0Q201G), M750 (PPM75A-007010G), M750 (PPM75A-01G010), M750 (PPM75A-01Q010), M750 (PPM75A-09U010), M750 (PPM75A-0JW010), R200 (PPR21A-00W01E), R400 (PPR40A-00H00L), R400 (PPR40A-01000L), R500 (PPR50A-00V01X), R500 (PPR50A-00V05C), R500 (PPR50A-02T01X), R500 (PPR50A-04N05C), R500 (PPR50A-04P05C), R500 (PPR50A-07Q05C), R500 (PPR50A-07R05C), R500 (PPR50A-07S05C), R500 (PPR50A-SP101X), R500 (PPR50A-SP105C), R500 (PPR50A-SSD3G), R600 (PPR61A-00300R), R600 (PPR61A-00400R), R600 (PPR61A-01L00R), R600 (PPR61A-02200R), R600 (PPR61A-022040), R600 (PPR61A-02900R), R600 (PPR61A-029040), R600 (PPR61A-02X00R), R600 (PPR61A-02X040)	L104	M	✗	✗
		M600 (PPM60A-035011), M600 (PPM60A-05F01D), M600 (PPM60A-05R011), M600 (PPM60A-06T01D), M600 (PPM60A-06W01D), M600 (PPM60A-07T01D), M600 (PPM60A-09D01D), M800 (PPM80A-01900P), M800 (PPM80A-03H009), M800 (PPM81A-01U01J), M800 (PPM81A-02201J), M800 (PPM81A-04901J), M800 (PPM81A-05701S), M800 (PPM81A-05W01J), M800 (PPM81A-06L01J), M800 (PPM81A-08S01S), M800 (PPM81A-0E101J), M800 (PPM81A-0E201J)	L106	✗	✗	P
	Quosmio	F60 (PQF65A-00Y002)	L106	✗	P	P
	Satellite	A100 (PSAA9A-046004), A100 (PSAARA-054007), A100 (PSAARA-055007), A100 (PSAARA-05601P), A100 (PSAARA-057007), A100 (PSAARA-058007), A100 (PSAARA-05R007), P100 (PSPA3A-05S00P)	L104	✗	✗	✗
		1800 (PS181X-00XXX), 1800 (PS181X-AAAA), A100 (PSAA8A-19Y03Q), A100 (PSAA8A-1HQ03R), A100 (PSAA9A-118038), A100 (PSAANA-04E005), M100 (PSMAAA-01M006), M100 (PSMAAA-020006), M100 (PSMAAA-026007), M110 (PSMB0A-01J00D), M110 (PSMB0A-01L00D), M40 (PSM40A-037009), M40 (PSM40A-038009), M40 (PSM40A-03K009), M40 (PSM40A-06X008), M40 (PSM40A-08L009), M40 (PSM40A-0TX008)	L104	M	✗	✗
		1710/1730 (PS170A-0002C), 1730/1750 (PS173A-21KK3), 3000 (PS302A-018XK), A200 (PSAF0A-02L01C), A200 (PSAF0A-03M019), A200 (PSAF0A-04X019), A200 (PSAF0A-04Y019), A200 (PSAF0A-0CQ01C), A200 (PSAF0A-0EV019), A200 (PSAF0A-0YK01C), A200 (PSAF6A-02C01N), A200 (PSAFCA-01400J), A200 (PSAFCA-01600K), A200 (PSAFCA-01C00J), A200 (PSAFCA-01H00J), A200 (PSAFCA-01K00J), A210 (PSAFGA-05C019), A300 (PSAG8A-07V011), A300 (PSAG8A-08D011), A300 (PSAGCA-09U01N), A300 (PSAGCA-0C301N), A300 (PSAGCA-0G601Q), A300 (PSAGDA-01C00R), A300 (PSAGDA-01R014), A300D (PSAH8A-01K00H), A350 (PSAL6A-05D016), A500 (PSAM3A-03P00E), A500 (PSAM3A-03Q00E), A500 (PSAM3A-04000E), A500 (PSAM3A-04100E), A500 (PSAM3A-04200E), A500 (PSAR3A-01K002), A500 (PSAR3A-026002), A500 (PSAR9A-02J001), L300 (PSLB0A-02L022), L300 (PSLB0A-02M027), L300 (PSLB0A-08C022), L300 (PSLB0A-08D022), L300 (PSLB0A-08E022), L300 (PSLB0A-08H022), L300 (PSLB8A-01F004), L300 (PSLB8A-047004), L300 (PSLB8A-04R004), L300 (PSLB8A-04S004), L300 (PSLB8A-058004), L300 (PSLB8A-059004), L300 (PSLB8A-06X004), L300 (PSLB8A-07U004), L300 (PSLB8A-0D3004), L300 (PSLB8A-0D4004), L300 (PSLB8A-0D5004), L300 (PSLB8A-0FM004), L300 (PSLB8A-0KW004), L300 (PSLB8A-0SN004), L300 (PSLB8A-0VK004), L300 (PSLB8A-0WC004), L300 (PSLB8A-0WD004), L300D (PSLC8A-02000Y), L300D (PSLC8A-02200Y), L300D (PSLC8A-02T00Y), L300D (PSLC8A-02U00Y), L300D (PSLC8A-03U00Y), L300D (PSLC8A-03V00Y), L500 (PSLJ0A-01E013), L500 (PSLJ0A-01F013), L500 (PSLJ3A-01R015), L500 (PSLJ3A-01U015), L500 (PSLJ3A-01V015), L500 (PSLJ3A-024015), L500 (PSLJ3A-02501Y), L500 (PSLS0A-016002), L500 (PSLS0A-01W002), L500 (PSLS0A-034002), L500 (PSLS0A-087002), L500 (PSLS3A-049002), L500 (PSLS6A-00X013), L500 (PSLS9A-025012), L500 (PSLS9A-02C012), L500D (PSLKO0A-00R009), L500D (PSLKO0A-00U009), L500D (PSLKO0A-00W009), L500D (PSLTOA-00V001), L510 (PSLFA-01T00R), L510 (PSLFA-01U00R), L510 (PSLFEA-01500C), L550 (PSLN8A-00Y008), L550 (PSLW8A-01101F), L550 (PSLWSA-01000Q), M200 (PSMCO0A-01X00N), M200 (PSMCO0A-02G00M), M200 (PSMC3A-04P008), M200 (PSMC3A-06N008), M200 (PSMC6A-03Q00S), M300 (PSMD0A-02700E), M300 (PSMD0A-04S00E), M300 (PSMD4A-023008), M300 (PSMD8A-03H00G), M300 (PSMDCA-01800C), M300 (PSMDCA-01900C), M300 (PSMDCA-01T00C), M300 (PSMDCA-03600R), M300 (PSMDCA-03700R), M300 (PSMDCA-03800R), M300 (PSMDCA-03J00R), M300 (PSMDCA-06F00R), M300 (PSMDCA-06G00R), M300 (PSMDCA-06J00S), M300 (PSMDCA-06K00R), M500 (PSMKCA-009007), P200 (PSPBGA-01W015), P200 (PSPBGA-01X015), P500 (PSPE8A-01R002), P500 (PSPE8A-024008), P500 (PSPG8A-01U004), P500 (PSPG8A-020004), T110 (PST1AA-00D007), T110D (PST1LA-00C008), T130 (PST3AA-02F006), T130 (PST3AA-02M02M), T130 (PST3AA-03F02M), U300 (PSU30A-02Y01U), U300 (PSU30A-05302P), U300 (PSU30A-0DJ02P), U400 (PSU40A-01M001), U400 (PSU40A-01S001), U400 (PSU44A-00H00C), U400 (PSU44A-00J00C), U400 (PSU44A-02C01D), U400 (PSU44A-03S01D), U400 (PSU44A-08W01D), U500 (PSU5EA-00X012), U500 (PSU82A-01W00M), U500 (PSU8CA-01D014), U500 (PSU9BA-01C002), U500 (PSU9MA-00K013)	L106	✗	P	P



**Universal adaptors** are available in AC & AC/DC versions to provide power wherever it's needed. They will work with more than 90% of laptops in the market and can be used with most laptops via interchangeable tips that adjust the voltage automatically. **Replacement AC adaptors** are limited to laptop models that use 15/16V & 19/20V to suit most common brands & models –they are ideal as replacement or additional AC adaptors, but may not work with your next laptop.

Universal		Replacement		
90W AC - APA68AU		75W AC - APA02AU	90W AC - APA03AU	90W AC - APA30AU
90W DC - APD80AU				
90W AC/DC - APM68AU				

Manufacturer	Model Name	Series	Tip	Tip	Tip	Tip	
Toshiba	Satellite Pro	P100 (PSPA4A-005002), P100 (PSPA4A-016002), P100 (PSPA4A-00G00D), P100 (PSPA4A-00J00D)	L104	×	×	×	
		A120 (PSAC0A-00D002), A120 (PSAC1A-00K005), A120 (PSAC1A-045005), A120 (PSAC1A-073004), A120 (PSAC1A-0QP01X), A120 (PSAC1A-0QV03J), A120 (PSAC1A-0R903H), A120 (PSAC1A-0VW03H), A120 (PSAC1A-0VX03J), S200 (PSSA1A-00V008), S200 (PSSA1A-0G9007), S300 (PSSB0A-06C00K), S300 (PSSB0A-06V00K)	L104	M	×	×	
		A200 (PSAF1A-001001), A200 (PSAF1A-003002), A200 (PSAF4A-001001), A200 (PSAF4A-003007), A200 (PSAF4A-008009), A200 (PSAF4A-009009), A200 (PSAF4A-00H007), A200 (PSAF4A-00J009), A200 (PSAF4A-00K009), A200 (PSAF4A-00S009), A200 (PSAF7A-003001), A210 (PSAFHA-00W008), A210 (PSAFHA-00W00L), A210 (PSAFHA-00X008), A210 (PSAFHA-00X00L), A210 (PSAFHA-01P00L), A300 (PSAG1A-003002), A300 (PSAG8A-03C011), A300 (PSAG8A-05P02D), A300 (PSAGDA-01Y00R), A300 (PSAGDA-03700R), A300 (PSAGDA-03D00R), L30 (PSL30A-00100E), L300 (PSLB1A-01L019), L300 (PSLB1A-01L019), L300 (PSLB1A-01N008), L300 (PSLB1A-02C01E), L300 (PSLB1A-02D008), L300 (PSLB1A-02R01E), L300 (PSLB1A-02S008), L300 (PSLB9A-00L002), L300 (PSLB9A-013001), L300 (PSLB9A-01G002), L300 (PSLB9A-02H002), L300 (PSLB9A-02K002), L300 (PSLB9A-02L001), L300 (PSLB9A-03T002), L300 (PSLB9A-058001), L300 (PSLB9A-05U002), L300 (PSLB9A-05W002), L300 (PSLB9A-064002), L300 (PSLB9A-067001), L300 (PSLB9A-06D002), L500 (PSLS1A-007002), L500 (PSLS1A-01200K), L500 (PSLS1A-022002), L500 (PSLS1A-02T00K), L500 (PSLS4A-00500L), L500 (PSLS4A-01100L), L500 (PSLS4A-01200L), L500 (PSLS4A-01F00L), L500 (PSLS4A-01G00L), L500 (PSLSAA-00K00U), L500 (PSLSAA-00L00U), L510 (PSLGXA-002002), L510 (PSLQ1A-004005), L510 (PSLS3A-020002), L510 (PSLT0A-00D001), L550 (PSLW9A-00X00N), L550 (PSLW9A-00Y00N), L550 (PSLWTA-00J00G), L550 (PSLWTA-00K00G), M200 (PSMC4A-00C001), M200 (PSMC4A-01N00C), M300 (PSMD1A-005004), M300 (PSMD9A-003002), M300 (PSMD9A-004002), M300 (PSMD9A-007002), M300 (PSMD9A-009002), P300 (PSPCDA-01N00D), P300 (PSPCDA-01P00D), P300 (PSPCDA-03P00D), T110 (PST1BA-009007), T130 (PST3BA-00M00U), T130 (PST3BA-00N00U), U500 (PSU83A-00N00D), U500 (PSU9CA-00D003), U500 (PSU9NA-00600N)	L106	×	×		P
Toshiba	Tecra	A6 (PTA63A-002002), A7 (PTA71A-012003), A7 (PTA71A-0DU003), A7 (PTA71A-0DW003), A7 (PTA71A-1EU003), A8 (PTA83A-0HV041)	L104	×	×	×	
		A10 (PTSB0A-002001), A10 (PTSB0A-006001), A10 (PTSB0A-00E001), A10 (PTSB0A-020001), A10 (PTSB0A-02D001), A10 (PTSB0A-03E001), A10 (PTSB0A-03G001), A10 (PTSB0A-04L001), A10 (PTSB0A-04X023), A10 (PTSB0A-04Y023), A10 (PTSB0A-059023), A10 (PTSB0A-05C023), A11 (PTSE1A-00K005), A11 (PTSE1A-00L005), A11 (PTSE1A-00M005), A6 (PTA61A-093005), A8 (PTA83A-042012), A8 (PTA83A-04F012), A8 (PTA83A-04G012), A8 (PTA83A-054012), A8 (PTA83A-056012), A8 (PTA83A-0HU041), A8 (PTA83A-0HV041), A8 (PTA83A-0HW041), A8 (PTA83A-0K5041), A9 (PTS52A-00T00F), A9 (PTS52A-00U00F), A9 (PTS52A-00V00F), A9 (PTS52A-023017), A9 (PTS52A-0CT017), A9 (PTS52A-0CU03F), A9 (PTS52A-0CV03F), A9 (PTS52A-0CW03F), A9 (PTS52A-0EV017), A9 (PTS52A-0EW03F), A9 (PTS52A-0EX03F), A9 (PTS52A-0EY03F), A9 (PTS52A-0GF03F), M10 (PTMB3A-00M001), M10 (PTMB3A-04S001), M10 (PTMB3A-05602H), M10 (PTMB3A-00L004), M10 (PTMB3A-00M004), M10 (PTMB3A-00N004), M10 (PTMB3A-01X001), M10 (PTMB3A-04L001), M10 (PTMB3A-05C004), M10 (PTMB3A-05E004), M10 (PTMB3A-0D3004), M10 (PTMB3A-0DJ004), M10 (PTMB3A-0G0004), M10 (PTMB3A-0HK004), M10 (PTMB3A-0KH06C), M10 (PTMB3A-0N606C), M10 (PTMB3A-0NP06C), M5 (PTM51A-0EG007), M5 (PTM51A-0EJ007), M5 (PTM51A-0RL05P), M5 (PTM51A-0RM05P), M5 (PTM51A-0RW05P), M5 (PTM51A-1FQ07P), M7 (PTM71A-01101H), M9 (PTM90A-01V00K), M9 (PTM90A-08P03H), M9 (PTM90A-0C603H), M9 (PTM90A-0CL03H), M9 (PTM91A-035002), M9 (PTM91A-036002), M9 (PTM91A-037002), M9 (PTM91A-05504L), M9 (PTM91A-0E104L), M9 (PTM91A-0EY04L), M9 (PTM91A-0MF04L), M9 (PTM91A-0MG04L), M9 (PTM91A-0T304L), M9 (PTM91A-0U204L), M9 (PTM91A-0U204L), P (PTS40A-02100V), P (PTS40A-02800V), P10 (PTSB3A-001001), P10 (PTSB3A-00S001), P10 (PTSB3A-05Q001), P10 (PTSB3A-05R001), P10 (PTSB3A-07U016), P10 (PTSB3A-0GE001), P10 (PTSB3A-0GF001), P10 (PTSB3A-0HE001), P10 (PTSB3A-0UV048), P10 (PTSB3A-0VD001), P10 (PTSB3A-0VR048), P11 (PTSE3A-00T00K), P11 (PTSE3A-00U00K), P11 (PTSE3A-00V00K), P5 (PTS53A-007006), P5 (PTS53A-009006), P5 (PTS53A-01G006), P5 (PTS53A-02F01D), P5 (PTS53A-05H03X), P5 (PTS53A-05Y01D), P5 (PTS53A-05Y03X), P5 (PTS53A-06003X), P5 (PTS53A-0FR03X), P5 (PTS53A-0FS03X), P5 (PTS53A-0FT03X), R10 (PTRB3A-001002), R10 (PTRB3A-00T002), R10 (PTRB3A-00U002), S3 (PTS30A-094008), S3 (PTS30A-0CG008)	L104	M	×	×	
	Toshiba Netbook	NB100 (PLL10A-00K02H), NB100 (PLL10A-01C02H), NB100 (PLL10A-01E02H), NB200 (PLL20A-002001), NB200 (PLL20A-00P001), NB200 (PLL20A-00Q001), NB200 (PLL23A-00501G), NB200 (PLL23A-00C01G), NB200 (PLL23A-00D01G), NB200 (PLL25A-009002), NB200 (PLL25A-00C002), NB200 (PLL25A-00D002), NB200 (PLL25A-00K002), NB200 (PLL28A-007012), NB200 (PLL28A-00E012), NB300 (PLL3EA-006007), NB300 (PLL3EA-00F007), NB305 (PLL3AA-00F009), NB305 (PLL3AA-00T009), NB305 (PLL3AA-01E009)	L106	×		P	P
WinBook	WinBook	J1, N, Si, Si2, X1, X2, X4, XL, XLI, XP, Z	L106	×		P	P