



Truck Diagnostic Software

2.11.3

New functions

Injector programming has been added for Volvo Trucks and Renault Trucks in the database.

Updated models

More than 150 models are updated with diagnostic functions in the TRUCKS database.

VW LCV are updated to year model 2012. Totally 25 brands are updated in

Generic Bus Systems

In 2011 Release 3 there has been added a new group of test abilities for Buses and Coaches. It is a generic bus systems group consisting of body systems to cover most of the electronic systems in the vehicle.

ISS Intelligent

System Scan
ISS is updated for:
Fiat, Opel and Renault.

Vehicle information

The Placement window with photos showing the location of the diagnostic socket in the vehicles has been updated with more models.

GUIDE

Brand	Model	Engine	Brake	Instrument	AC	Gearbox	Immobiliser	Restraints	Multifunction	Service
	2004-2007	●	●	●	●			●	●	●
	2004-2006	●	●							
	2006-2007								●	

Brand and Models are listed as in the CARS and TRUCKS software.

Year range in model includes a complete range for all systems with new or updated functionality.

The OBD functions e.g. Adjustments and programmings that are listed are new or updated for the marked system.

Systems with markers are new or updated with read/erase fault codes, real time data and/or activations.



15/12/2011



Citraën										
Jumpy Serie 3 [07-]	2008	•								
Catalytic particle filter (CPF) change	2008	•								
Fuel leak test	2008	•								
Write code for injector cylinder 1	2008	•								
Write code for injector cylinder 2	2008	•								
Write code for injector cylinder 3	2008	•								
Write code for injector cylinder 4	2008	•								

DAF										
LF 55	2001-2010	•	•				•		•	
ABS warning lamp OFF	2009-2010	•								
ASR solenoid valve	2009-2010	•								
Disable third brake (retarder)	2009-2010	•								
Front left ABS solenoid valve	2009-2010	•								
Front right ABS solenoid valve	2009-2010	•								
Fuel line filling	2009-2010								•	
Level sensor calibration	2001-2010								•	
Read service parameters	2009-2010								•	
Rear left ABS solenoid valve	2009-2010	•								
Rear right ABS solenoid valve	2009-2010	•								
Write new service parameters, range/date	2009-2010								•	

LF 45	2001-2010	•	•				•		•	
ABS warning lamp OFF	2009-2010	•								
ASR solenoid valve	2009-2010	•								
Disable third brake (retarder)	2009-2010	•								
Front left ABS solenoid valve	2009-2010	•								
Front right ABS solenoid valve	2009-2010	•								
Fuel line filling	2009-2010								•	
Level sensor calibration	2001-2010								•	
Read service parameters	2009-2010								•	
Rear left ABS solenoid valve	2009-2010	•								
Rear right ABS solenoid valve	2009-2010	•								
Write new service parameters, range/date	2009-2010								•	


XF 105	2006-2011	•								
---------------	-----------	---	--	--	--	--	--	--	--	--

CF 85	2006-2011	•								
--------------	-----------	---	--	--	--	--	--	--	--	--

CF 75	2006-2011	•								
--------------	-----------	---	--	--	--	--	--	--	--	--




15/12/2011



EvoBus Chassis								
O345 euro III	2000-2008	•	•	•	•	•		•
Compression test	2000-2008	•						
Cylinder Balancing	2000-2008	•						
Injection time	2000-2008	•						
Minor learning process for control module GSII gear control	2000-2008				•			
Reading out additional information for SCR fault codes	2000-2008	•						
Reset of cylinder balancing	2000-2008	•						
Unit pump programming cylinder 1	2000-2008	•						
Unit pump programming cylinder 2	2000-2008	•						
Unit pump programming cylinder 3	2000-2008	•						
Unit pump programming cylinder 4	2000-2008	•						
Unit pump programming cylinder 5	2000-2008	•						
Unit pump programming cylinder 6	2000-2008	•						
Unit pump programming cylinder 7	2000-2008	•						
Unit pump programming cylinder 8	2000-2008	•						
O530 Citaro	2000-2009	•				•		•
Reading out additional information for SCR fault codes	2000-2009	•						
Multego	2004-2009	•	•			•		•
Reading out additional information for SCR fault codes	2004-2009	•						
BR 400 euro III	2000-2009	•	•			•		•
Reading out additional information for SCR fault codes	2000-2009	•						
OC500	2000-2009	•				•		•
Reading out additional information for SCR fault codes	2000-2009	•						
O345 G euro III	2000-2008	•	•	•	•	•		•
Compression test	2000-2008	•						
Cylinder Balancing	2000-2008	•						
Injection time	2000-2008	•						
Minor learning process for control module GSII gear control	2000-2008				•			
Reading out additional information for SCR fault codes	2000-2008	•						
Reset of cylinder balancing	2000-2008	•						
Unit pump programming cylinder 1	2000-2008	•						
Unit pump programming cylinder 2	2000-2008	•						
Unit pump programming cylinder 3	2000-2008	•						
Unit pump programming cylinder 4	2000-2008	•						
Unit pump programming cylinder 5	2000-2008	•						
Unit pump programming cylinder 6	2000-2008	•						
Unit pump programming cylinder 7	2000-2008	•						
Unit pump programming cylinder 8	2000-2008	•						
O530 Citaro euro IV	2004-2009	•				•		•
Reading out additional information for SCR fault codes	2004-2009	•						
O560 euro III	2000-2009	•	•			•		•
Reading out additional information for SCR fault codes	2000-2009	•						
Intouro	2000-2009	•						•




15/12/2011



Reading out additional information for SCR fault codes	2000-2009	•																
Tourismo euro IV	2004-2009	•	•				•								•			
Reading out additional information for SCR fault codes	2004-2009	•																
O550 euro III	2000-2009	•	•				•		•						•			
Reading out additional information for SCR fault codes	2000-2009	•																
O520 Cito	2000-2009	•													•			
Reading out additional information for SCR fault codes	2000-2009	•																
BR 400 euro IV	2004-2009	•	•						•						•			
Reading out additional information for SCR fault codes	2004-2009	•																
Conecto	2004-2009	•							•						•			
Reading out additional information for SCR fault codes	2004-2009	•																
O580 Travego euro IV	2004-2009	•	•						•						•			
Reading out additional information for SCR fault codes	2004-2009	•																
O580 Travego	2000-2009	•	•						•						•			
Reading out additional information for SCR fault codes	2000-2009	•																
Capacity	2004-2009	•							•						•			
Reading out additional information for SCR fault codes	2004-2009	•																
BR 300 euro III	2000-2005	•	•					•		•					•			
Reading out additional information for SCR fault codes	2000-2005	•																
Travego euro IV	2004-2009	•	•						•						•			
Reading out additional information for SCR fault codes	2004-2009	•																
OC500 euro IV	2004-2009	•	•						•						•			
Reading out additional information for SCR fault codes	2004-2009	•																
O350 O403 euro III	2000-2008	•	•	•	•	•									•			
Compression test	2000-2008	•																
Cylinder Balancing	2000-2008	•																
Injection time	2000-2008	•																
Reading out additional information for SCR fault codes	2000-2008	•																
Reset of cylinder balancing	2000-2008	•																
Unit pump programming cylinder 1	2000-2008	•																
Unit pump programming cylinder 2	2000-2008	•																
Unit pump programming cylinder 3	2000-2008	•																
Unit pump programming cylinder 4	2000-2008	•																
Unit pump programming cylinder 5	2000-2008	•																
Unit pump programming cylinder 6	2000-2008	•																
Unit pump programming cylinder 7	2000-2008	•																
Unit pump programming cylinder 8	2000-2008	•																
Integro	2000-2009	•							•						•			
Reading out additional information for SCR fault codes	2000-2009	•																




15/12/2011



Integro euro IV	2004-2009	•	•				•											
Reading out additional information for SCR fault codes	2004-2009	•																
Intouro euro IV	2004-2009	•					•											
Reading out additional information for SCR fault codes	2004-2009	•																
OH XBC	2004-2009	•					•											
Reading out additional information for SCR fault codes	2004-2009	•																
MBC	2000-2009	•	•															
Reading out additional information for SCR fault codes	2000-2009	•																
MBC euro IV	2004-2009	•	•															
Reading out additional information for SCR fault codes	2004-2009	•																
Cobus 541	2004-2009	•																
Reading out additional information for SCR fault codes	2004-2009	•																



15/12/2011



Fiat								
Ducato [06-]	2006-2011	•	•	•			•	•
Accelerator and yaw sensors calibration	2011		•					
Accept configuration	2011		•					
Air flow meter replacement	2006-2011	•						
Delete oil change servicing information	2011			•				•
EGR Valve check	2006-2011	•						
EGR valve programming	2011	•						
EGR valve test	2011	•						
Glow plug preheating circuit test	2011	•						
Injector programming	2011	•						
Injector programming cylinder 1	2011	•						
Injector programming cylinder 2	2011	•						
Injector programming cylinder 3	2011	•						
Injector programming cylinder 4	2011	•						
Injector programming cylinder 5	2011	•						
Key programming	2011						•	
Lambda sensor replacement	2006-2011	•						
Lateral accelerator sensor calibration	2011		•					
Longitudinal acceleration sensor calibration	2011		•					
Oil change	2011	•						
Oil change reset (only for version with DPF)	2011	•						•
Particulate filter regeneration (only for version with DPF)	2011	•						
Pressure sensor calibration	2011		•					
Rail pressure sensor replacement	2006-2011	•						
Recall service message	2011			•				•
Reset adaption	2011	•						
Reset service	2011	•						
Seat belt warning buzzer	2011			•				
Self learnt functions reset	2011	•						
Static test	2011		•					
Steering angle calibration	2011		•					
Steering angle reset	2011		•					
Yaw sensor calibration	2011		•					
Doblo [06-]	2006-2011	•	•	•			•	•
Air flow meter replacement	2006-2011	•						
EGR Valve check	2006-2009	•						
EGR valve test	2010-2011	•						
Glow plug preheating circuit test	2011	•						
Injector programming	2011	•						
Key programming	2011						•	
Knock sensor and/or spark plug replacement	2011	•						
Lambda sensor and/or catalytic convector and/or injector repla	2011	•						
Lambda sensor replacement	2006-2011	•						
Oil change reset (only for version with DPF)	2010-2011	•						•
Particulate filter regeneration (only for version with DPF)	2010-2011	•						
Rail pressure sensor replacement	2006-2011	•						
Recall service message	2010-2011			•				•
Self learnt functions reset	2011	•						
Supercharging system components replacement	2011	•						
Timing sensor and/or cam replacement	2011	•						



15/12/2011




Ford								
Transit Connect	2010-2011	•	•	•			•	•
Brake bleed system ABS/ESP	2010-2011	•						
Configuration pressure sensor	2010-2011	•						
Configure the lateral acceleration sensor	2010-2011	•						
Cooling fan high speed	2010-2011	•						
Diesel particulate filter regeneration operation	2010-2011	•						
EGR - valve, duty cycle	2010-2011	•						
Glow plug	2010-2011	•						
Longitudinal acceleration sensor calibration	2010-2011	•						
Odometer programming	2010-2011			•				
Reset diesel partical filter data	2010-2011	•						
Reset KAM (Keep Alive Memory)	2010-2011	•						
Reset knock sensor adaptions	2010-2011	•						
Reset pressure sensor diesel partical filter	2010-2011	•						
Reset the Exhaust Gas Recirculation values	2010-2011	•						
Reset The Fuel Metering Valve Learned Values	2010-2011	•						
Reset The Water in fuel Warning Indicator	2010-2011	•						
Selftest, ignition on, engine off	2010-2011	•	•	•			•	•
Steering wheel calibration	2010-2011	•						
Turbo regulating valve	2010-2011	•						
Yaw Rate Sensor Calibration	2010-2011	•						

Transit [06-]	2011	•	•	•			•	•	•
Activation of hill launch assist	2011	•							
Brake bleed system ABS	2011	•							
Deactivation of hill launch assist	2011	•							
Fuel Injection Pump Learn	2011	•							
Injector programming	2011	•							
Longitudinal acceleration sensor calibration	2011	•							
Manual service light reset	2011			•					•
Pilot injection learn	2011	•							
Reset adjustment pressure sensor	2011	•							
Reset the Fuel Pressure Relief Valve Open Count Learned Value	2011	•							
Reset the Fuel Pressure Relief Valve Open Duration Learned Value	2011	•							
Reset The Water in fuel Warning Indicator	2011	•							
Selftest, ignition on, engine off	2011	•	•	•			•	•	•
Speed limit	2011	•							
Steering wheel calibration	2011	•							

Tourneo Connect	2010-2011	•	•	•			•	•
Brake bleed system ABS/ESP	2010-2011	•						
Configuration pressure sensor	2010-2011	•						
Configure the lateral acceleration sensor	2010-2011	•						
Cooling fan high speed	2010-2011	•						
Diesel particulate filter regeneration operation	2010-2011	•						
EGR - valve, duty cycle	2010-2011	•						
Glow plug	2010-2011	•						
Longitudinal acceleration sensor calibration	2010-2011	•						
Odometer programming	2010-2011			•				
Reset diesel partical filter data	2010-2011	•						



15/12/2011




Reset KAM (Keep Alive Memory)	2010-2011	●									
Reset knock sensor adaptations	2010-2011	●									
Reset pressure sensor diesel partical filter	2010-2011	●									
Reset the Exhaust Gas Recirculation values	2010-2011	●									
Reset The Fuel Metering Valve Learned Values	2010-2011	●									
Reset The Water in fuel Warning Indicator	2010-2011	●									
Selftest, ignition on, engine off	2010-2011	●	●	●				●	●		
Steering wheel calibration	2010-2011		●								
Turbo regulating valve	2010-2011	●									
Yaw Rate Sensor Calibration	2010-2011		●								

Ranger	2007-2011	●	●			●		●			
4WD indicator	2007-2011	●									
A/C compressor relay control	2007-2011	●									
Exhaust Gas Recirculation (EGR) Valve Solenoid Duty Cycle	2007-2011	●									
Exhaust gas recirculation solenoid valve 2	2007-2011	●									
Glow plug control	2007-2011	●									
Glow plug lamp	2007-2011	●									
Hub lock solenoid	2007-2011	●									
Injection shut-off cyl 1	2007-2011	●									
Injection shut-off cyl 2	2007-2011	●									
Injection shut-off cyl 3	2007-2011	●									
Injection shut-off cyl 4	2007-2011	●									
Injector programming	2007-2011	●									
Intake air shutter valve	2007-2011	●									
Intake air shutter valve 2	2007-2011	●									
Reset KAM (Keep Alive Memory)	2007-2011	●									
Reset Mass Air Flow sensor	2007-2011	●									
Self test	2007-2011							●			
Selftest, ignition on, engine off	2007-2011	●				●					
Selftest, ignition on, engine on	2007-2011	●									
Swirl control valve SCV	2007-2011	●									
Transmission Neutral In Tow Indicator	2007-2011	●									
Warm up solenoid	2007-2011	●									



15/12/2011



Generic Bus Systems								
16-pin Scania/DAF diagnostic socket	All Years	•	•	•		•		
ABS warning lamp OFF	All Years		•					
ASR solenoid valve	All Years		•					
Compression test	All Years	•						
Disable third brake (retarder)	All Years		•					
Front left ABS solenoid valve	All Years		•					
Front right ABS solenoid valve	All Years		•					
Rear left ABS solenoid valve	All Years		•					
Rear right ABS solenoid valve	All Years		•					
9-pin Deutsch diagnostic socket	All Years					•		
Solenoid valves test	All Years					•		
All supported systems	All Years	•	•	•		•		•
ABS warning lamp OFF	All Years		•					
Accelerator pedal calibration	All Years			•				
AdBlue circuit test with injection of AdBlue	All Years	•						
AdBlue filter leakage test	All Years	•						
AdBlue main filter and pump heating	All Years	•						
AdBlue metering module test large	All Years	•						
AdBlue metering module test medium	All Years	•						
AdBlue metering module test small	All Years	•						
Air circuit test/ Dosing module test	All Years	•						
Allocation drive program	All Years					•		
Allocation drive program 2	All Years					•		
ASR solenoid valve	All Years		•					
Automated cylinder performance test	All Years	•						
Autonomous system check test	All Years	•						
Bleed valve (AdBlue) in supply module	All Years	•						
Checking the air lines	All Years	•						
Clutch calibration with lining change	All Years			•				
Clutch calibration without lining change	All Years			•				
Compression test	All Years	•						
Compression test	All Years	•						
Coolant valve for AdBlue heating circuit	All Years	•						
Current settings drive program	All Years					•		
Cylinder Balancing	All Years	•						
Cylinder compression	All Years	•						
Cylinder deactivation	All Years	•						
Disable third brake (retarder)	All Years		•					
Emptying AdBlue circuit	All Years	•						
Front left ABS solenoid valve	All Years		•					
Front right ABS solenoid valve	All Years		•					
Heating of AdBlue lines in the supply module	All Years	•						
High-pressure test	All Years	•						
Initial startup	All Years	•						
Injection time	All Years	•						
Injector code programming	All Years	•						
Metering module	All Years	•						
Pump activation in the supply module	All Years	•						
Reading out additional information for SCR fault codes	All Years	•						



15/12/2011



Rear left ABS solenoid valve	All Years	●									
Rear right ABS solenoid valve	All Years	●									
Reset of cylinder balancing	All Years	●									
Reset torque limiting	All Years	●									
Reset values after exchanging particulate trap	All Years	●									
Shut-off cylinder 1	All Years	●									
Shut-off cylinder 2	All Years	●									
Shut-off cylinder 3	All Years	●									
Shut-off cylinder 4	All Years	●									
Shut-off cylinder 5	All Years	●									
Shut-off cylinder 6	All Years	●									
Solenoid valves test	All Years				●						
Status customer parameters	All Years				●						
Status 'Neutral when stationary' parameter	All Years				●						
Status output parameter	All Years				●						
Status shift parameters	All Years				●						
Unit pump programming	All Years	●									
Unit pump programming cylinder 1	All Years	●									
Unit pump programming cylinder 2	All Years	●									
Unit pump programming cylinder 3	All Years	●									
Unit pump programming cylinder 4	All Years	●									
Unit pump programming cylinder 5	All Years	●									
Unit pump programming cylinder 6	All Years	●									
Unit pump programming cylinder 7	All Years	●									
Unit pump programming cylinder 8	All Years	●									


37-pin MAN diagnostic socket	All Years	●		●		●						●
-------------------------------------	-----------	---	--	---	--	---	--	--	--	--	--	---

16-pin J1962 diagnostic socket	All Years	●	●	●		●						
---------------------------------------	-----------	---	---	---	--	---	--	--	--	--	--	--

ABS warning lamp OFF	All Years	●										
Accelerator pedal calibration	All Years			●								
AdBlue circuit test with injection of AdBlue	All Years	●										
AdBlue filter leakage test	All Years	●										
AdBlue main filter and pump heating	All Years	●										
AdBlue metering module test large	All Years	●										
AdBlue metering module test medium	All Years	●										
AdBlue metering module test small	All Years	●										
Air circuit test/ Dosing module test	All Years	●										
Allocation drive program	All Years					●						
Allocation drive program 2	All Years					●						
ASR solenoid valve	All Years	●										
Automated cylinder performance test	All Years	●										
Autonomous system check test	All Years	●										
Bleed valve (AdBlue) in supply module	All Years	●										
Checking the air lines	All Years	●										
Clutch calibration with lining change	All Years			●								
Clutch calibration without lining change	All Years			●								
Compression test	All Years	●										
Compression test	All Years	●										
Coolant valve for AdBlue heating circuit	All Years	●										
Current settings drive program	All Years					●						
Cylinder Balancing	All Years	●										




15/12/2011



Disable third brake (retarder)	All Years	•																	
Emptying AdBlue circuit	All Years	•																	
Front left ABS solenoid valve	All Years	•																	
Front right ABS solenoid valve	All Years	•																	
Heating of AdBlue lines in the supply module	All Years	•																	
High-pressure test	All Years	•																	
Initial startup	All Years	•																	
Injection time	All Years	•																	
Injector code programming	All Years	•																	
Metering module	All Years	•																	
Pump activation in the supply module	All Years	•																	
Reading out additional information for SCR fault codes	All Years	•																	
Rear left ABS solenoid valve	All Years	•																	
Rear right ABS solenoid valve	All Years	•																	
Reset of cylinder balancing	All Years	•																	
Reset torque limiting	All Years	•																	
Reset values after exchanging particulate trap	All Years	•																	
Shut-off cylinder 1	All Years	•																	
Shut-off cylinder 2	All Years	•																	
Shut-off cylinder 3	All Years	•																	
Shut-off cylinder 4	All Years	•																	
Shut-off cylinder 5	All Years	•																	
Shut-off cylinder 6	All Years	•																	
Solenoid valves test	All Years																		
Status customer parameters	All Years																		
Status 'Neutral when stationary' parameter	All Years																		
Status output parameter	All Years																		
Status shift parameters	All Years																		
Unit pump programming	All Years	•																	
Unit pump programming cylinder 1	All Years	•																	
Unit pump programming cylinder 2	All Years	•																	
Unit pump programming cylinder 3	All Years	•																	
Unit pump programming cylinder 4	All Years	•																	
Unit pump programming cylinder 5	All Years	•																	
Unit pump programming cylinder 6	All Years	•																	
Unit pump programming cylinder 7	All Years	•																	
Unit pump programming cylinder 8	All Years	•																	
12-pin MAN diagnostic socket	All Years	•																	
8-pin Volvo diagnostic socket	All Years	•																	
Cylinder Balancing	All Years	•																	
Cylinder compression	All Years	•																	
Cylinder deactivation	All Years	•																	
14-pin MB diagnostic socket	All Years	•																	
Compression test	All Years	•																	
Cylinder Balancing	All Years	•																	
Injection time	All Years	•																	
Reading out additional information for SCR fault codes	All Years	•																	
Reset of cylinder balancing	All Years	•																	
Unit pump programming cylinder 1	All Years	•																	



15/12/2011



Unit pump programming cylinder 2	All Years	●																
Unit pump programming cylinder 3	All Years	●																
Unit pump programming cylinder 4	All Years	●																
Unit pump programming cylinder 5	All Years	●																
Unit pump programming cylinder 6	All Years	●																
Unit pump programming cylinder 7	All Years	●																
Unit pump programming cylinder 8	All Years	●																

Hyundai																		
H1 [07-]	2009-2011	●	●															
Brake bleed system ABS/ESP	2011	●																

Iveco																		
Daily [06-]	2006-2010	●	●	●	●													●
Change air mass meter	2010	●																
Change differential pressure sensor	2010	●																
Change fuel pressure sensor	2010	●																
Change particle filter	2010	●																
Cylinder deactivation	2010	●																
Front abs test	2010		●															
Oil change	2010																	●
Rear abs test	2010		●															
Test for front asr	2010		●															
Test for rear asr	2010		●															

Mahindra/Renault																		
Logan	2003-2009	●																
Accelerator pedal position sensor A circuit	2003-2009	●																
Air Inlet Flap Motor command	2003-2009	●																
Camshaft sensor programming	2003-2009	●																
Cruise control / Speed limiter programming	2003-2009	●																
EGR valve	2003-2009	●																
Flywheel target programming	2003-2009	●																
Injector adaptives No.1	2003-2009	●																
Injector adaptives No.2	2003-2009	●																
Injector adaptives No.3	2003-2009	●																
Injector adaptives No.4	2003-2009	●																
Pressure regulation adaptive	2003-2009	●																
Rail pressure adaptives	2003-2009	●																
Turbocharging solenoid valve	2003-2009	●																



15/12/2011




MAN										
TGX	2008-2011	Engine	Brake	Instrument	AC	Gearbox	Immobiliser	Restraints	Multifunction	Service
Accelerator pedal calibration	2011								•	
AdBlue main filter and pump heating	2011	•								
AdBlue metering module test large	2011	•								
AdBlue metering module test medium	2011	•								
AdBlue metering module test small	2011	•								
Bleed valve (AdBlue) in supply module	2011	•								
Change engine oil quality	2008-2011									•
Change gearbox oil quality	2008-2011									•
Change rear axle oil quality	2008-2011									•
Checking the air lines	2011	•								
Clutch calibration with lining change	2011								•	
Clutch calibration without lining change	2011								•	
Compression test	2011	•								
Coolant valve for AdBlue heating circuit	2011	•								
Delete safety error memory	2008-2011		•							
Emptying AdBlue circuit	2011	•								
Heating of AdBlue lines in the supply module	2011	•								
High-pressure test	2008-2011	•								
Initial startup	2011	•								
Level sensor calibration	2011								•	
Metering module	2011	•								
Pressure sensors, Calibration	2011								•	
Pump activation in the supply module	2011	•								
Read service parameters	2011									•
Reset service	2011									•
Reset torque limiting	2008-2011	•								
Shut-off cylinder 1	2011	•								
Shut-off cylinder 2	2011	•								
Shut-off cylinder 3	2011	•								
Shut-off cylinder 4	2011	•								
Shut-off cylinder 5	2011	•								
Shut-off cylinder 6	2011	•								
Shut-off cylinder 7	2011	•								
Shut-off cylinder 8	2011	•								

TGS										
TGS	2008-2011	Engine	Brake	Instrument	AC	Gearbox	Immobiliser	Restraints	Multifunction	Service
Accelerator pedal calibration	2010-2011		•	•	•	•			•	•
AdBlue main filter and pump heating	2010-2011	•								
AdBlue metering module test large	2010-2011	•								
AdBlue metering module test medium	2010-2011	•								
AdBlue metering module test small	2010-2011	•								
Bleed valve (AdBlue) in supply module	2010-2011	•								
Change engine oil quality	2008-2011									•
Change gearbox oil quality	2008-2011									•
Change rear axle oil quality	2008-2011									•
Checking the air lines	2010-2011	•								
Clutch calibration with lining change	2010-2011								•	
Clutch calibration without lining change	2010-2011								•	
Compression test	2010-2011	•								
Coolant valve for AdBlue heating circuit	2010-2011	•								




15/12/2011



Delete safety error memory	2008-2011	•																
Emptying AdBlue circuit	2010-2011	•																
Heating of AdBlue lines in the supply module	2010-2011	•																
High-pressure test	2008-2011	•																
Initial startup	2010-2011	•																
Level sensor calibration	2010-2011																	•
Metering module	2010-2011	•																
Pressure sensors, Calibration	2010-2011																	•
Pump activation in the supply module	2010-2011	•																
Read service parameters	2010-2011																	•
Reset service	2010-2011																	•
Reset torque limiting	2008-2011	•																
Shut-off cylinder 1	2010-2011	•																
Shut-off cylinder 2	2010-2011	•																
Shut-off cylinder 3	2010-2011	•																
Shut-off cylinder 4	2010-2011	•																
Shut-off cylinder 5	2010-2011	•																
Shut-off cylinder 6	2010-2011	•																
Shut-off cylinder 7	2011	•																
Shut-off cylinder 8	2011	•																
TGL	2006-2009	•																•
Change engine oil quality	2006-2009																	•
Change gearbox oil quality	2006-2009																	•
Change rear axle oil quality	2006-2009																	•
High-pressure test	2008-2009	•																
Reset torque limiting	2008-2009	•																
TGM	2006-2009	•																•
Change engine oil quality	2006-2009																	•
Change gearbox oil quality	2006-2009																	•
Change rear axle oil quality	2006-2009																	•
High-pressure test	2008-2009	•																
Reset torque limiting	2008-2009	•																
TGA	2006-2007																	•
Change engine oil quality	2006-2007																	•
Change gearbox oil quality	2006-2007																	•
Change rear axle oil quality	2006-2007																	•




15/12/2011



MAN Bus Chassis									
PC6	2006-2010	•			•				
High-pressure test	2006-2010	•							
Reset torque limiting	2006-2010	•							
Reset values after exchanging particulate trap	2006-2010	•							
PG4	2006-2010	•			•				
High-pressure test	2006-2010	•							
Reset torque limiting	2006-2010	•							
Reset values after exchanging particulate trap	2006-2010	•							
PG5	2006-2010	•			•				
High-pressure test	2006-2010	•							
Reset torque limiting	2006-2010	•							
Reset values after exchanging particulate trap	2006-2010	•							
P15	2006-2010	•			•				
High-pressure test	2006-2010	•							
Reset torque limiting	2006-2010	•							
Reset values after exchanging particulate trap	2006-2010	•							
R37	2006-2010	•			•				
High-pressure test	2006-2010	•							
Reset torque limiting	2006-2010	•							
Reset values after exchanging particulate trap	2006-2010	•							
PB2	2006-2010	•			•				
High-pressure test	2006-2010	•							
Reset torque limiting	2006-2010	•							
Reset values after exchanging particulate trap	2006-2010	•							
R13	2006-2010	•			•				
High-pressure test	2006-2010	•							
Reset torque limiting	2006-2010	•							
Reset values after exchanging particulate trap	2006-2010	•							
PC9	2006-2010	•			•				
High-pressure test	2006-2010	•							
Reset torque limiting	2006-2010	•							
Reset values after exchanging particulate trap	2006-2010	•							
A67	2006-2010	•			•				
High-pressure test	2006-2010	•							
Reset torque limiting	2006-2010	•							
Reset values after exchanging particulate trap	2006-2010	•							
PB1	2006-2010	•			•				
High-pressure test	2006-2010	•							
Reset torque limiting	2006-2010	•							
Reset values after exchanging particulate trap	2006-2010	•							
R08	2006-2010	•			•				




15/12/2011



High-pressure test	2006-2010	●									
Reset torque limiting	2006-2010	●									
Reset values after exchanging particulate trap	2006-2010	●									
R33	2006-2010	●			●						
High-pressure test	2006-2010	●									
Reset torque limiting	2006-2010	●									
Reset values after exchanging particulate trap	2006-2010	●									
R12	2006-2010	●			●						
High-pressure test	2006-2010	●									
Reset torque limiting	2006-2010	●									
Reset values after exchanging particulate trap	2006-2010	●									
A77	2006-2010	●			●						
High-pressure test	2006-2010	●									
Reset torque limiting	2006-2010	●									
Reset values after exchanging particulate trap	2006-2010	●									
R07	2006-2010	●			●						
High-pressure test	2006-2010	●									
Reset torque limiting	2006-2010	●									
Reset values after exchanging particulate trap	2006-2010	●									
A39	2006-2010	●			●						
High-pressure test	2006-2010	●									
Reset torque limiting	2006-2010	●									
Reset values after exchanging particulate trap	2006-2010	●									
A69	2006-2010	●			●						
High-pressure test	2006-2010	●									
Reset torque limiting	2006-2010	●									
Reset values after exchanging particulate trap	2006-2010	●									
P12	2006-2010	●			●						
High-pressure test	2006-2010	●									
Reset torque limiting	2006-2010	●									
Reset values after exchanging particulate trap	2006-2010	●									
P21	2006-2010	●			●						
High-pressure test	2006-2010	●									
Reset torque limiting	2006-2010	●									
Reset values after exchanging particulate trap	2006-2010	●									
A89	2006-2010	●			●						
High-pressure test	2006-2010	●									
Reset torque limiting	2006-2010	●									
Reset values after exchanging particulate trap	2006-2010	●									
A26	2006-2010	●			●						
High-pressure test	2006-2010	●									
Reset torque limiting	2006-2010	●									




15/12/2011



Reset values after exchanging particulate trap	2006-2010	•																
P11	2006-2010	•			•													
High-pressure test	2006-2010	•																
Reset torque limiting	2006-2010	•																
Reset values after exchanging particulate trap	2006-2010	•																
PE6	2006-2010	•			•													
High-pressure test	2006-2010	•																
Reset torque limiting	2006-2010	•																
Reset values after exchanging particulate trap	2006-2010	•																
PC7	2006-2010	•			•													
High-pressure test	2006-2010	•																
Reset torque limiting	2006-2010	•																
Reset values after exchanging particulate trap	2006-2010	•																
A25	2006-2010	•			•													
High-pressure test	2006-2010	•																
Reset torque limiting	2006-2010	•																
Reset values after exchanging particulate trap	2006-2010	•																
A91	2006-2010	•			•													
High-pressure test	2006-2010	•																
Reset torque limiting	2006-2010	•																
Reset values after exchanging particulate trap	2006-2010	•																
P14	2006-2010	•			•													
High-pressure test	2006-2010	•																
Reset torque limiting	2006-2010	•																
Reset values after exchanging particulate trap	2006-2010	•																
A66	2006-2010	•			•													
High-pressure test	2006-2010	•																
Reset torque limiting	2006-2010	•																
Reset values after exchanging particulate trap	2006-2010	•																
A72	2006-2010	•																
High-pressure test	2006-2010	•																
Reset torque limiting	2006-2010	•																
Reset values after exchanging particulate trap	2006-2010	•																
A24	2006-2010	•																
High-pressure test	2006-2010	•																
Reset torque limiting	2006-2010	•																
Reset values after exchanging particulate trap	2006-2010	•																
A23	2006-2010	•																
High-pressure test	2006-2010	•																
Reset torque limiting	2006-2010	•																
Reset values after exchanging particulate trap	2006-2010	•																




15/12/2011



A20	2006-2010	•																
High-pressure test	2006-2010	•																
Reset torque limiting	2006-2010	•																
Reset values after exchanging particulate trap	2006-2010	•																
A21	2006-2010	•																
High-pressure test	2006-2010	•																
Reset torque limiting	2006-2010	•																
Reset values after exchanging particulate trap	2006-2010	•																
A35	2006-2010	•																
High-pressure test	2006-2010	•																
Reset torque limiting	2006-2010	•																
Reset values after exchanging particulate trap	2006-2010	•																
A78	2006-2010	•																
High-pressure test	2006-2010	•																
Reset torque limiting	2006-2010	•																
Reset values after exchanging particulate trap	2006-2010	•																
A22	2006-2010	•																
High-pressure test	2006-2010	•																
Reset torque limiting	2006-2010	•																
Reset values after exchanging particulate trap	2006-2010	•																




15/12/2011



Mazda									
BT-50	2007-2011	Engine	Brake	Instrument	AC	Gearbox	Immobiliser	Restraints	Service
4WD indicator	2007-2011	●							
A/C compressor relay control	2007-2011	●							
Exhaust Gas Recirculation (EGR) Valve Solenoid Duty Cycle	2007-2011	●							
Exhaust gas recirculation solenoid valve 2	2007-2011	●							
Glow plug control	2007-2011	●							
Glow plug lamp	2007-2011	●							
Hub lock solenoid	2007-2011	●							
Injection shut-off cyl 1	2007-2011	●							
Injection shut-off cyl 2	2007-2011	●							
Injection shut-off cyl 3	2007-2011	●							
Injection shut-off cyl 4	2007-2011	●							
Intake air shutter valve	2007-2011	●							
Intake air shutter valve 2	2007-2011	●							
Reset KAM (Keep Alive Memory)	2007-2011	●							
Reset Mass Air Flow sensor	2007-2011	●							
Self test	2007-2011							●	
Selftest, ignition on, engine off	2007-2011					●			
Swirl control valve SCV	2007-2011	●							
Transmission Neutral In Tow Indicator	2007-2011	●							
Warm up solenoid	2007-2011	●							



15/12/2011



Mercedes Truck								
Unimog 437	2000-2011	●	●	●	●	●	●	●
Actuation of clutch operator	2000-2011							●
Check metering quantity of AdBlue metering unit	2000-2011	●						
Cleaning of AdBlue metering unit	2000-2011	●						
Clutch calibration with lining change (Only for Axor)	2000-2011							●
Clutch calibration without lining change (Only for Axor)	2000-2011							●
Clutch wear check, test	2000-2011							●
Compression test	2000-2011	●						
Cylinder Balancing	2000-2011	●						
Initial startup of SCR exhaust aftertreatment system	2000-2011	●						
Injection time	2000-2011	●						
Learning process for control module GS (EPS)	2000-2011				●			
Major learning process for control module GS gear control	2000-2011				●			
Parameter reading, Tire rolling circumference	2000-2011	●						
Parameter settings: Tire rolling circumference of the front axle	2000-2011	●						
Parameter settings: Tire rolling circumference of the rear axle	2000-2011	●						
Read vehicle control unit list	2000-2011			●				
Reading out additional information for SCR fault codes	2000-2011	●						
Re-learn terminal W ratio	2000-2011							●
Reset of cylinder balancing	2000-2011	●						
Selected Maximum Vehicle Speed Limit	2000-2011							●
Test of AdBlue delivery circuit	2000-2011	●						
Test of AdBlue pump	2000-2011	●						
Test of AdBlue tank heater solenoid valve	2000-2011	●						
Test of SCR compressed air switching valve	2000-2011	●						
Unit pump programming cylinder 1	2000-2011	●						
Unit pump programming cylinder 2	2000-2011	●						
Unit pump programming cylinder 3	2000-2011	●						
Unit pump programming cylinder 4	2000-2011	●						
Unit pump programming cylinder 5	2000-2011	●						
Unit pump programming cylinder 6	2000-2011	●						
Unit pump programming cylinder 7	2000-2011	●						
Unit pump programming cylinder 8	2000-2011	●						
Unimog 405	2000-2011	●	●	●	●	●		●
Actuation of clutch operator	2000-2011							●
Check metering quantity of AdBlue metering unit	2000-2011	●						
Cleaning of AdBlue metering unit	2000-2011	●						
Clutch calibration with lining change (Only for Axor)	2000-2011							●
Clutch calibration without lining change (Only for Axor)	2000-2011							●
Clutch wear check, test	2000-2011							●
Compression test	2000-2011	●						
Cylinder Balancing	2000-2011	●						
Initial startup of SCR exhaust aftertreatment system	2000-2011	●						
Injection time	2000-2011	●						
Learning process for control module GS (EPS)	2000-2011				●			
Major learning process for control module GS gear control	2000-2011				●			
Parameter reading, Tire rolling circumference	2000-2011	●						
Parameter settings: Tire rolling circumference of the front axle	2000-2011	●						
Parameter settings: Tire rolling circumference of the rear axle	2000-2011	●						
Read vehicle control unit list	2000-2011			●				



15/12/2011

Engine	Brake	Instrument	AC	Gearbox	Immobiliser	Restraints	Multifunction	Service
■	■	■	■	■	■	■	■	■

Reading out additional information for SCR fault codes	2000-2011	●																	
Re-learn terminal W ratio	2000-2011																		●
Reset of cylinder balancing	2000-2011	●																	
Selected Maximum Vehicle Speed Limit	2000-2011																		●
Test of AdBlue delivery circuit	2000-2011	●																	
Test of AdBlue pump	2000-2011	●																	
Test of AdBlue tank heater solenoid valve	2000-2011	●																	
Test of SCR compressed air switching valve	2000-2011	●																	
Unit pump programming cylinder 1	2000-2011	●																	
Unit pump programming cylinder 2	2000-2011	●																	
Unit pump programming cylinder 3	2000-2011	●																	
Unit pump programming cylinder 4	2000-2011	●																	
Unit pump programming cylinder 5	2000-2011	●																	
Unit pump programming cylinder 6	2000-2011	●																	
Unit pump programming cylinder 7	2000-2011	●																	
Unit pump programming cylinder 8	2000-2011	●																	

Unimog 405050	2000-2005	●	●	●															●
Actuation of clutch operator	2000-2005																		●
Check metering quantity of AdBlue metering unit	2000-2005	●																	
Cleaning of AdBlue metering unit	2000-2005	●																	
Clutch calibration with lining change (Only for Axor)	2000-2005																		●
Clutch calibration without lining change (Only for Axor)	2000-2005																		●
Clutch wear check, test	2000-2005																		●
Compression test	2000-2005	●																	
Cylinder Balancing	2000-2005	●																	
Initial startup of SCR exhaust aftertreatment system	2000-2005	●																	
Injection time	2000-2005	●																	
Parameter reading, Tire rolling circumference	2000-2005		●																
Parameter settings: Tire rolling circumference of the front axle	2000-2005		●																
Parameter settings: Tire rolling circumference of the rear axle	2000-2005		●																
Read vehicle control unit list	2000-2005			●															
Reading out additional information for SCR fault codes	2000-2005	●																	
Re-learn terminal W ratio	2000-2005																		●
Reset of cylinder balancing	2000-2005	●																	
Selected Maximum Vehicle Speed Limit	2000-2005																		●
Test of AdBlue delivery circuit	2000-2005	●																	
Test of AdBlue pump	2000-2005	●																	
Test of AdBlue tank heater solenoid valve	2000-2005	●																	
Test of SCR compressed air switching valve	2000-2005	●																	
Unit pump programming cylinder 1	2000-2005	●																	
Unit pump programming cylinder 2	2000-2005	●																	
Unit pump programming cylinder 3	2000-2005	●																	
Unit pump programming cylinder 4	2000-2005	●																	
Unit pump programming cylinder 5	2000-2005	●																	
Unit pump programming cylinder 6	2000-2005	●																	
Unit pump programming cylinder 7	2000-2005	●																	
Unit pump programming cylinder 8	2000-2005	●																	

Axor II	2004-2009	●	●																●
Actuation of clutch operator	2004-2009																		●
Clutch wear check, test	2004-2009																		●



15/12/2011



Parameter reading, Tire rolling circumference	2004-2009	•																		
Parameter settings: Tire rolling circumference of the front axle	2004-2009	•																		
Parameter settings: Tire rolling circumference of the rear axle	2004-2009	•																		
Reading out additional information for SCR fault codes	2004-2009	•																		
Re-learn terminal W ratio	2004-2009																			•
Reset fault memory bit	2004-2009	•																		
Selected Maximum Vehicle Speed Limit	2004-2009																			•

Atego	1998-2003	•	•																	•
Actuation of clutch operator	1998-2003																			•
Clutch wear check, test	1998-2003																			•
Parameter reading, Tire rolling circumference	1998-2003	•																		
Parameter settings: Tire rolling circumference of the front axle	1998-2003	•																		
Parameter settings: Tire rolling circumference of the rear axle	1998-2003	•																		
Reading out additional information for SCR fault codes	1998-2003	•																		
Re-learn terminal W ratio	1998-2003																			•
Reset fault memory bit	1998-2003	•																		
Selected Maximum Vehicle Speed Limit	1998-2003																			•

Atego 2	2004-2009	•	•																	•
Actuation of clutch operator	2004-2009																			•
Clutch wear check, test	2004-2009																			•
Parameter reading, Tire rolling circumference	2004-2009	•																		
Parameter settings: Tire rolling circumference of the front axle	2004-2009	•																		
Parameter settings: Tire rolling circumference of the rear axle	2004-2009	•																		
Reading out additional information for SCR fault codes	2004-2009	•																		
Re-learn terminal W ratio	2004-2009																			•
Reset fault memory bit	2004-2009	•																		
Selected Maximum Vehicle Speed Limit	2004-2009																			•

Actros MP II	2002-2008	•	•	•																•
Actuation of clutch operator	2002-2008																			•
Combustion air blower	2002-2008				•															
Enter VIN-code 17 characters	2002-2008				•															
Glow plug	2002-2008				•															
Metering pump	2002-2008				•															
Parameter reading, Dashboard	2002-2008																			•
Parameter reading, Delay period of PTO switch	2002-2008																			•
Parameter reading, Exterior lamp switch	2002-2008																			•
Parameter reading, Fault properties	2002-2008																			•
Parameter reading, Headlamp range controller	2002-2008																			•
Parameter reading, Rear wall	2002-2008																			•
Parameter reading, Roof	2002-2008																			•
Parameter reading, Switch, Differential lock	2002-2008																			•
Parameter reading, Tire rolling circumference	2002-2008	•																		
Parameter setting: Exterior lamp switch	2002-2008																			•
Parameter setting: Headlamp range controller	2002-2008																			•
Parameter setting: Switch, Differential lock	2002-2008																			•
Parameter settings: Dashboard	2002-2008																			•
Parameter settings: Delay period of PTO switch	2002-2008																			•
Parameter settings: Fault properties	2002-2008																			•
Parameter settings: Rear wall	2002-2008																			•



15/12/2011



Parameter settings: Roof	2002-2008										•
Parameter settings: Tire rolling circumference of the front axle	2002-2008	•									
Parameter settings: Tire rolling circumference of the rear axle	2002-2008	•									
Reading out additional information for SCR fault codes	2002-2008	•									
Re-learn terminal W ratio	2002-2008										•
Reset fault memory bit	2002-2008	•									
Selected Maximum Vehicle Speed Limit	2002-2008										•
Updating of central data memory: From SPA to ZDS	2002-2008										•
Updating of central data memory: From SRS to ZDS	2002-2008										•
Updating of control units: From ZDS to control units	2002-2008										•
Updating of ZDS: From control units to ZDS	2002-2008										•
Water pump	2002-2008				•						

Econic	1998-2004	•	•								•
Actuation of clutch operator	1998-2004										•
Clutch wear check, test	1998-2004										•
Parameter reading, Tire rolling circumference	1998-2004	•									
Parameter settings: Tire rolling circumference of the front axle	1998-2004	•									
Parameter settings: Tire rolling circumference of the rear axle	1998-2004	•									
Reading out additional information for SCR fault codes	1998-2004	•									
Re-learn terminal W ratio	1998-2004										•
Reset fault memory bit	1998-2004	•									
Selected Maximum Vehicle Speed Limit	1998-2004										•

Econic II	2005-2009	•	•								•
Actuation of clutch operator	2005-2009										•
Clutch wear check, test	2005-2009										•
Parameter reading, Tire rolling circumference	2005-2009	•									
Parameter settings: Tire rolling circumference of the front axle	2005-2009	•									
Parameter settings: Tire rolling circumference of the rear axle	2005-2009	•									
Reading out additional information for SCR fault codes	2005-2009	•									
Re-learn terminal W ratio	2005-2009										•
Reset fault memory bit	2005-2009	•									
Selected Maximum Vehicle Speed Limit	2005-2009										•

Actros	1997-2002	•	•								•
Actuation of clutch operator	1997-2002										•
Clutch wear check, test	1997-2002										•
Parameter reading, Tire rolling circumference	1997-2002	•									
Parameter settings: Tire rolling circumference of the front axle	1997-2002	•									
Parameter settings: Tire rolling circumference of the rear axle	1997-2002	•									
Reading out additional information for SCR fault codes	1997-2002	•									
Re-learn terminal W ratio	1997-2002										•
Reset fault memory bit	1997-2002	•									
Selected Maximum Vehicle Speed Limit	1997-2002										•

Axor	2001-2003	•	•								•
Actuation of clutch operator	2001-2003										•
Clutch wear check, test	2001-2003										•
Parameter reading, Tire rolling circumference	2001-2003	•									
Parameter settings: Tire rolling circumference of the front axle	2001-2003	•									
Parameter settings: Tire rolling circumference of the rear axle	2001-2003	•									



15/12/2011



Reading out additional information for SCR fault codes	2001-2003	●													
Re-learn terminal W ratio	2001-2003														●
Reset fault memory bit	2001-2003		●												
Selected Maximum Vehicle Speed Limit	2001-2003														●

Actros MP III		2009	●	●		●									●
Actuation of clutch operator	2009														●
Combustion air blower	2009				●										
Enter VIN-code 17 characters	2009				●										
Glow plug	2009				●										
Metering pump	2009				●										
Parameter reading, Dashboard	2009														●
Parameter reading, Delay period of PTO switch	2009														●
Parameter reading, Exterior lamp switch	2009														●
Parameter reading, Fault properties	2009														●
Parameter reading, Headlamp range controller	2009														●
Parameter reading, Rear wall	2009														●
Parameter reading, Roof	2009														●
Parameter reading, Switch, Differential lock	2009														●
Parameter reading, Tire rolling circumference	2009		●												
Parameter setting: Exterior lamp switch	2009														●
Parameter setting: Headlamp range controller	2009														●
Parameter setting: Switch, Differential lock	2009														●
Parameter settings: Dashboard	2009														●
Parameter settings: Delay period of PTO switch	2009														●
Parameter settings: Fault properties	2009														●
Parameter settings: Rear wall	2009														●
Parameter settings: Roof	2009														●
Parameter settings: Tire rolling circumference of the front axle	2009		●												
Parameter settings: Tire rolling circumference of the rear axle	2009		●												
Reading out additional information for SCR fault codes	2009	●													
Re-learn terminal W ratio	2009														●
Reset fault memory bit	2009		●												
Selected Maximum Vehicle Speed Limit	2009														●
Updating of central data memory: From SPA to ZDS	2009														●
Updating of central data memory: From SRS to ZDS	2009														●
Updating of control units: From ZDS to control units	2009														●
Updating of ZDS: From control units to ZDS	2009														●
Water pump	2009				●										

Mitsubishi															
L200 IV [06-]	2007-2011		●	●		●	●	●	●	●	●	●	●	●	
Calibration of steering angle sensor	2010-2011														●
Injection quantity learning procedure	2011	●													
Injector programming	2011	●													
Supply pump exchange service	2011	●													



15/12/2011



Opel/Vauxhall										
Combo [02-]	2005-2011	Engine	Brake	Instrument	AC	Gearbox	Immobiliser	Restraints	Multifunction	Service
Calibration servo mechanism	2011									•
Enter security code (XXXX), press OK	2011						•			
Erase keys	2011						•			
Injector programming cylinder 1	2011	•								
Injector programming cylinder 2	2011	•								
Injector programming cylinder 3	2011	•								
Injector programming cylinder 4	2011	•								
Overheat protection	2011								•	
Particle filter regeneration	2011	•								
Program new key	2011						•			
Program old key	2011						•			
Recall service message	2011			•						•
Reset diesel partical filter	2011	•								
Reset differential pressure sensor	2011	•								
Reset fuel pump	2011	•								
Reset Pre catalyst	2011	•								
Start amount	2011								•	

Movano B	2010-2011	Engine	Brake	Instrument	AC	Gearbox	Immobiliser	Restraints	Multifunction	Service
Brake pressure sensor, reset	2010-2011		•							
EGR Valve Learn	2010-2011	•								
HVAC Actuators Learn	2010-2011				•					
Injector programming	2010-2011	•								
Intake Air Flow Valve Learn	2010-2011	•								
Lateral acceleration sensor, reset	2010-2011		•							
Learn camshaft variation	2010-2011	•								
Learn Fuel Pressure Regulator	2010-2011	•								
Learn glow plug	2010-2011	•								
Learn HO2S	2010-2011	•								
Learning Exhaust Aftertreatment Fuel Injector	2010-2011	•								
Learning Exhaust Gas Pressure Sensor 2	2010-2011	•								
Learning high-pressure fuel pump	2010-2011	•								
Longitudinal acceleration sensor, reset	2010-2011		•							
Mass air flow sensor, learning	2010-2011	•								
Reset steering angle sensor	2010-2011		•							
Reset the service interval	2010-2011			•						•
Steering wheel angle sensor programming	2010-2011		•							
Yaw Rate Sensor Learn Command	2010-2011		•							

Astra H	2004-2011	Engine	Brake	Instrument	AC	Gearbox	Immobiliser	Restraints	Multifunction	Service
Calibration stepper motors	2011				•					
Clutch bleed	2004-2011					•				
Erase keys	2011						•			
Erase registered crash	2011							•		
Injector programming	2011	•								
Key entering	2011						•			
Particle filter regeneration	2011	•								
Programming belt reminder	2011							•		
Programming daytime running lights	2011								•	
Programming gearbox parameters	2004-2011					•				



15/12/2011

Engine	Brake	Instrument	AC	Gearbox	Immobiliser	Restraints	Multifunction	Service
■	■	■	■	■	■	■	■	■


Recall service message	2011			●						●
Reset adaption	2011	●								
Reset diesel partice filter	2011	●								
Reset differential pressure sensor	2011	●								
Reset fuel pump	2011	●								
Reset lambda sensor	2011	●								
Reset Mass Air Flow sensor	2011	●								
Reset Pre catalyst	2011	●								
Reset rail pressure sensor	2011	●								
Sensor cluster calibration	2011		●							
Small Injection Quantity Learning	2011	●								
Steering angle calibration	2011								●	
Tire size programming	2011	●								
Touchpoint adaption	2004-2011				●					

Movano	2007-2010	●	●					●	●	●
Tire size programming	2007-2010	●								

Peugeot										
Expert Serie 2 [07-]	2008	●								
Catalytic particle filter (CPF) change	2008	●								
Fuel leak test	2008	●								
Write code for injector cylinder 1	2008	●								
Write code for injector cylinder 2	2008	●								
Write code for injector cylinder 3	2008	●								
Write code for injector cylinder 4	2008	●								
Partner Serie 2 [08-]	2008-2011	●								



15/12/2011



Renault										
Master II	2001-2008	Engine	Brake	Instrument	AC	Gearbox	Immobiliser	Restraints	Multifunction	Service
+ Accessories feed 1+2	2005-2008								•	
+ Accessories feed relay no. 3	2005-2008								•	
AC compressor relay	2001-2008	•								
Accelerator pedal position sensor A circuit	2001-2008	•								
Advance actuator command	2001-2008	•								
Air damper valve programming	2001-2008	•								
Air Inlet Flap Motor command	2001-2008	•								
Air path programming	2001-2008	•								
Automatic gearbox	2005-2008								•	
Automatic Locking when Driving	2005-2008								•	
Auxiliary water pump	2001-2008	•								
Basic power steering	2005-2008								•	
Camshaft sensor programming	2001-2008	•								
Card reader lightning	2005-2008								•	
Central locking	2005-2008								•	
Central locking key light	2005-2008								•	
Configuration A/C	2001-2008	•								
Configuration cruise control/speed limiter	2001-2008	•								
Configuration decrement idle speed	2001-2008	•								
Configuration increment of idle speed	2001-2008	•								
Configuration injection prohibiton	2001-2008	•								
Configuration power steering electric pump unit	2001-2008	•								
Configuration prevention of electrical consumers	2001-2008	•								
Configuration thermoplungers	2001-2008	•								
Control on steering wheels	2005-2008								•	
Cruise control / Speed limiter programming	2001-2008	•								
Cylinder 1 injector code	2001-2008	•								
Cylinder 2 injector code	2001-2008	•								
Cylinder 3 injector code	2001-2008	•								
Cylinder 4 injector code	2001-2008	•								
Deadlocking	2005-2008								•	
Deadlocking control, active	2005-2008								•	
Deadlocking control, inactive	2005-2008								•	
Deadunlocking	2005-2008								•	
EGR bypass valve	2001-2008	•								
EGR solenoid valve	2001-2008	•								
EGR valve	2001-2008	•								
EGR valve programming	2001-2008	•								
EGR valve programming after change	2001-2008	•								
EGR valve status	2001-2008	•								
Electric child safety (With)	2005-2008								•	
Electric child safety (Without)	2005-2008								•	
Engine adaptives	2001-2008	•								
Erase adaptive engine parameters	2001-2008	•								
Erase ECU configurations	2001-2008	•								
Erase EGR-adaptives	2001-2008	•								
Erase pressure regulation adaptives	2001-2008	•								
Erase programmed values	2001-2008	•								
Erase Vehicle function programming	2001-2008	•								
Erase, after changing tyres	2005-2008								•	




15/12/2011

Engine	Brake	Instrument	AC	Gearbox	Immobiliser	Restraints	Multifunction	Service
●	●	●	●	●	●	●	●	●

Exhaust injector circuit	2001-2008	●						
Fan unit high speed relay control	2001-2008	●						
Fan unit slow speed relay control	2001-2008	●						
Fault finding on starter aerals	2005-2008						●	
Flywheel target programming	2001-2008	●						
Fuel flap locking	2005-2008						●	
Fuel leak test	2001-2008	●						
Fuel pressure regulator	2001-2008	●						
Fuel pressure solenoid valve	2001-2008	●						
Fuel pump relay	2001-2008	●						
Fuel supply prevention	2001-2008	●						
Gearbox configuration	2001-2008	●						
Heated front seat	2005-2008						●	
Heater element auxiliary heater	2001-2008	●						
Heating resistor relay 1	2001-2008	●						
Heating resistor relay 2	2001-2008	●						
High pressure circuit leak test	2001-2008	●						
High pressure pump	2001-2008	●						
Highpressure fuel circuit fault finding	2001-2008	●						
Horn	2005-2008						●	
Injector adaptives No.1	2001-2008	●						
Injector adaptives No.2	2001-2008	●						
Injector adaptives No.3	2001-2008	●						
Injector adaptives No.4	2001-2008	●						
Injector cylinder 1	2001-2008	●						
Injector cylinder 2	2001-2008	●						
Injector cylinder 3	2001-2008	●						
Injector cylinder 4	2001-2008	●						
Injector programming	2001-2008	●						
Injector reinitialisation	2001-2008	●						
Inlet flap	2001-2008	●						
Inlet flap reinitialisation	2001-2008	●						
Interior light illumination	2005-2008						●	
Left indicator light	2005-2008						●	
Left side on which steering wheel fitted	2005-2008						●	
Light sensor sensitivity, 0	2005-2008						●	
Light sensor sensitivity, 1	2005-2008						●	
Light sensor sensitivity, 2	2005-2008						●	
Light sensor sensitivity, 3	2005-2008						●	
Lock computer	2003-2008					●		
Lock injector control	2001-2008	●						
Manual transmission	2005-2008						●	
Particle emission filter temperature	2001-2008	●						
Particle filter injector control circuit	2001-2008	●						
Particle filter regeneration	2001-2008	●						
Particle filter relative pressure sensor	2001-2008	●						
Power assisted steering minimum assistance	2005-2008						●	
Preheater unit	2001-2008	●						
Preheating control relay 2	2005-2008						●	
Preheating light	2005-2008						●	
Preheating prevention	2001-2008	●						
Preheating relay control	2005-2008						●	



15/12/2011



Pressure regulation adaptive	2001-2008	•																		
Programming reinitialisation	2001-2008	•																		
Programming valve codes	2005-2008																			•
Rail pressure adaptives	2001-2008	•																		
Rail pressure regulator	2001-2008	•																		
Read configurations	2001-2008	•																		•
Rear fog lights	2005-2008																			•
Rear screen wiper	2005-2008																			•
Reinitialisation egr valve	2001-2008	•																		
Relay for Engine Coolant Pump	2001-2008	•																		
Relay, preheater	2001-2008	•																		
Remote locking buzzer	2005-2008																			•
RH side side on which steering wheel fitted	2005-2008																			•
Right indicator light	2005-2008																			•
Selective opening of doors (With)	2005-2008																			•
Selective opening of doors (Without)	2005-2008																			•
Solenoid valve, fuel circuit	2001-2008	•																		
Static test	2001-2008	•																		
Stop fuel supply prevention	2001-2008	•																		
Stop preheating prevention	2001-2008	•																		
Tailgate	2005-2008																			•
Tailgate opening request	2005-2008																			•
Thermoplunger no1 relay control	2001-2008	•																		
Thermoplunger no2 relay control	2001-2008	•																		
Thermoplunger no3 relay control	2001-2008	•																		
Turbo charge control solenoid valve	2001-2008	•																		
Turbo charger boost solenoid valve	2001-2008	•																		
Turbo pressure solenoid valve	2001-2008	•																		
Turbo regulation solenoid valve	2001-2008	•																		
Turbocharging solenoid valve	2001-2008	•																		
Uch connections test	2005-2008																			•
Unlock computer	2003-2008																			•
Unlocking the doors and boot	2005-2008																			•
Valve set selection, summer	2005-2008																			•
Valve set selection, winter	2005-2008																			•
Variable power steering	2005-2008																			•
Water pump relay	2001-2008	•																		
Vehicle family, Espace long	2005-2008																			•
Vehicle family, Espace short	2005-2008																			•
Vehicle type; Espace IV	2005-2008																			•
Vehicle type; Velsatis F2	2005-2008																			•
With AC	2001-2008	•																		
With air condition with heated windscreen	2001-2008	•																		
With air condition without heated windscreen	2001-2008	•																		
With Air conditioning	2001-2008	•																		
With Arabian overspeed	2005-2008																			•
With automatic closing of windows by card	2005-2008																			•
With boiler	2001-2008	•																		
With driver seat memory	2005-2008																			•
With emergency braking hazard warning lights	2005-2008																			•
With follow-me-home lighting	2005-2008																			•
With hands free function	2005-2008																			•



15/12/2011



With hands free locking	2005-2008									•	
With hands free start	2005-2008									•	
With hazard warning lights illumination by ABS	2005-2008									•	
With headlight washers	2005-2008									•	
With light automatic illumination	2005-2008									•	
With power assisted steering	2001-2008	•									
With rain light sensor	2005-2008									•	
With rain sensor	2005-2008									•	
With running lights	2005-2008									•	
With sunroof	2005-2008									•	
With thermoplungers	2001-2008	•									
With tyre pressure monitoring	2005-2008									•	
With voice synthesiser	2005-2008									•	
Without AC	2001-2008	•									
Without air condition with heated windscreen	2001-2008	•									
Without air condition without heated windscreen	2001-2008	•									
Without air conditioning	2001-2008	•									
Without Arabian overspeed	2005-2008									•	
Without automatic closing of windows by card	2005-2008									•	
Without boiler	2001-2008	•									
Without driver seat memory	2005-2008									•	
Without emergency braking hazard warning lights	2005-2008									•	
Without follow-me-home lighting	2005-2008									•	
Without hands free function	2005-2008									•	
Without hands free locking	2005-2008									•	
Without hands free start	2005-2008									•	
Without hazard warning lights illumination by ABS	2005-2008									•	
Without headlight washers	2005-2008									•	
Without light automatic illumination	2005-2008									•	
Without power assisted steering	2001-2008	•									
Without rain light sensor	2005-2008									•	
Without rain sensor	2005-2008									•	
Without running lights	2005-2008									•	
Without sunroof	2005-2008									•	
Without thermoplungers	2001-2008	•									
Without tyre pressure monitoring	2005-2008									•	
Without voice synthesiser	2005-2008									•	
Write code for injector cylinder 1	2001-2008	•									
Write code for injector cylinder 2	2001-2008	•									
Write code for injector cylinder 3	2001-2008	•									
Write code for injector cylinder 4	2001-2008	•									
Write date of last after sales operation	2004-2008							•			

Traffic II	2001-2010	•									
Accelerator pedal position sensor A circuit	2001-2010	•									
Air Inlet Flap Motor command	2001-2010	•									
Camshaft sensor programming	2001-2010	•									
Cruise control / Speed limiter programming	2001-2010	•									
EGR valve	2001-2010	•									
Flywheel target programming	2001-2010	•									
Injector adaptives No.1	2001-2010	•									
Injector adaptives No.2	2001-2010	•									



15/12/2011




Injector adaptives No.3	2001-2010	●										
Injector adaptives No.4	2001-2010	●										
Pressure regulation adaptive	2001-2010	●										
Rail pressure adaptives	2001-2010	●										
Turbocharging solenoid valve	2001-2010	●										

Master III	2010-2011	●	●	●	●					●	●	
Air damper valve programming	2010-2011	●										
Alternator regulation	2010-2011										●	
Buzzer	2010-2011			●								
Country type	2010-2011										●	
Cruise control / Speed limiter programming	2010-2011	●										
Deactivate maximum speed limit	2010-2011	●										
Deactivation fast idle speed function	2010-2011	●										
Distance units	2010-2011										●	
Distribution motor: Defrost	2010-2011				●							
Distribution motor: Ventilators	2010-2011				●							
EGR valve	2010-2011	●										
End of cruise control / Speed limiter programming	2010-2011	●										
Engine adaptives	2010-2011	●										
Exhaust injector circuit	2010-2011	●										
Fast idle speed function	2010-2011	●										
Flywheel target programming	2010-2011	●										
Injector programming	2010-2011	●										
Instrument panel needles	2010-2011			●								
Instrument panel warning lights	2010-2011			●								
Lightning	2010-2011			●								
Maximum speed limiter	2010-2011	●										
Mixing motor: all cold	2010-2011				●							
Mixing motor: all hot	2010-2011				●							
Particle filter injector	2010-2011	●										
Particle filter injector solenoid valve	2010-2011	●										
Particle filter regeneration	2010-2011	●										
Particle filter relative pressure sensor	2010-2011	●										
Passenger compartment fan	2010-2011				●							
Preheater unit	2010-2011	●										
Proportional richness sensor programming	2010-2011	●										
Read configurations	2010-2011	●			●			●		●		
Recycling motor: external air	2010-2011				●							
Recycling motor: Recycled air	2010-2011				●							
Reinitialisation air inlet temperature sensor	2010-2011	●										
Reinitialisation egr valve	2010-2011	●										
Relay, preheater	2010-2011	●										
Restart the computer	2010-2011			●								
Speedo index programming	2010-2011		●									
Thermoplunger no1 relay control	2010-2011	●										
Thermoplunger no2 relay control	2010-2011	●										
Thermoplunger no3 relay control	2010-2011	●										
Turbocharging solenoid valve	2010-2011	●										
Water pump relay	2010-2011	●										
Write configuration	2010-2011										●	
Write date of last after sales operation	2010-2011		●								●	




15/12/2011



Renault Trucks									
Midlum dci	2000-2006	•							
Premium dci	1998-2006	•							
Kerax dci	1998-2006	•							
Kerax dxi	2006-2011	•							
Cylinder Balancing	2006-2011	•							
Cylinder compression, test	2006-2011	•							
Cylinder deactivation	2006-2011	•							
Injector programming cylinder 1	2006-2011	•							
Injector programming cylinder 2	2006-2011	•							
Injector programming cylinder 3	2006-2011	•							
Injector programming cylinder 4	2006-2011	•							
Injector programming cylinder 5	2006-2011	•							
Injector programming cylinder 6	2006-2011	•							
Urea crystallisation SCR Catalytic silencer, regeneration	2006-2011	•							
Magnum E-Tech	2000-2006								•
Unit pump programming	2000-2006								•
Magnum dxi	2006-2011	•							
Cylinder Balancing	2006-2011	•							
Cylinder compression, test	2006-2011	•							
Cylinder deactivation	2006-2011	•							
Injector programming cylinder 1	2006-2011	•							
Injector programming cylinder 2	2006-2011	•							
Injector programming cylinder 3	2006-2011	•							
Injector programming cylinder 4	2006-2011	•							
Injector programming cylinder 5	2006-2011	•							
Injector programming cylinder 6	2006-2011	•							
Urea crystallisation SCR Catalytic silencer, regeneration	2006-2011	•							
Premium dxi	2006-2011	•							
Cylinder Balancing	2006-2011	•							
Cylinder compression, test	2006-2011	•							
Cylinder deactivation	2006-2011	•							
Injector programming cylinder 1	2006-2011	•							
Injector programming cylinder 2	2006-2011	•							
Injector programming cylinder 3	2006-2011	•							
Injector programming cylinder 4	2006-2011	•							
Injector programming cylinder 5	2006-2011	•							
Injector programming cylinder 6	2006-2011	•							
Urea crystallisation SCR Catalytic silencer, regeneration	2006-2011	•							
Midlum dxi	2006-2011	•							
Cylinder Balancing	2006-2011	•							
Cylinder compression, test	2006-2011	•							
Cylinder deactivation	2006-2011	•							
Urea crystallisation SCR Catalytic silencer, regeneration	2006-2011	•							



15/12/2011



Scania										
R-Series	2005-2009	•								
Urea dosing system test	2005-2009	•								

P-Series	2005-2009	•								
Urea dosing system test	2005-2009	•								

G-Series	2005-2009	•								
Urea dosing system test	2005-2009	•								

Scania Bus Chassis										
K124	1999-2005	•								
Compression test	1999-2005	•								

K114	1999-2005	•								
Compression test	1999-2005	•								

Seat										
Inca	1995-2003	•						•		
Activate cruise control system	1995-2003	•						•		
Code engine control unit	1995-2003	•								
Deactivate cruise control system	1995-2003	•								
Variant coding	2003							•		

Škoda										
Roomster	2006-2010	•								
Activate cruise control system	2006-2010	•								
Code engine control unit	2006-2010	•								
Deactivate cruise control system	2006-2010	•								

Praktik	2006-2010	•								
Activate cruise control system	2006-2010	•								
Code engine control unit	2006-2010	•								
Deactivate cruise control system	2006-2010	•								

Felicia	1995-1999	•								
Activate cruise control system	1995-1999	•								
Code engine control unit	1995-1999	•								
Deactivate cruise control system	1995-1999	•								



15/12/2011



Toyota								
Hilux [05-]	2005-2011	•	•			•	•	•
Injector programming	2005-2011	•						
Pilot injection learn	2005-2011	•						
Reset memory	2005-2011		•			•		
Supply pump initialization	2005-2011	•						

Volkswagen								
Caddy III [11-]	2011	•	•	•	•	•	•	•
Adaption of remote control	2011							•
Bleed brake system	2011		•					
Bleeding, fuel system	2011	•						
Boost pressure regulator	2011	•						
Change value for oil quality	2011							•
Code control unit	2011	•	•	•	•			•
Coding rain/light sensor.	2011							•
Cruise control function	2011	•						
Deactivate factory mode	2011							•
Difference pressure sensor replaced	2011	•						
Electronic throttle control	2011	•						
Erasing fault memory - All systems	2011							•
ESP driving test	2011		•					
Gear shift unit/position sensor	2011				•			
General-purpose configuration	2011							•
Idle speed adjustment	2011	•						
Initialization of the steering angle sensor	2011		•					•
Injector programming	2011	•						
Inlet valves basic setting	2011		•					
Language Change	2011			•				
Learning end position damper motors	2011				•			
Main pressure, zero values	2011					•		
Mechatronic	2011					•		
Mechatronic adaption value resetting	2011					•		
Mechatronic remove position	2011					•		
Particle filter replaced	2011	•						
Particle filter, check the carbon content	2011	•						
Recall service message	2011			•				•
Regeneration	2011	•						
Reset adaption	2011	•						
Reset oxygen sensor adaptations	2011	•						
Separating valves basic setting	2011		•					
Service interval data - carbon content	2011			•				
Service interval data - days since last inspection	2011			•				
Service interval data - distance travelled since last inspection	2011			•				
Service interval data - lower limit for distance to next inspectio	2011			•				
Service interval data - lower limit for time to next inspection	2011			•				
Service interval data - oil quality	2011			•				
Service interval data - thermal load	2011			•				
Service interval data - upper limit for distance to next inspectio	2011			•				
Service interval data - upper limit for distance to next inspectio	2011			•				



15/12/2011




Service interval data - upper limit for time to next inspection	2011			●																
Service interval data - upper limit for time to next inspection (a)	2011			●																
Steering assistance	2011																			●
Steering wheel tiptronic contacts resetting	2011					●														
Synchronization positions	2011					●														
System status, gateway	2011																			●
Transport mode activation	2011																			●
Transport mode inactivation	2011																			●
Tyre pressure monitoring	2011	●																		
Unlock auxiliary heater	2011																			●
Variant coding	2011																			●
Zero compensation of brake pressure sensor	2011	●																		
Zero compensation of lateral acceleration sensor	2011	●																		
Zero compensation of longitudinal acceleration sensor	2011	●																		

T5 Transporter [09-]	2010-2011	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
Adaptation of steering angle sensor	2011	●																		
Adaption of remote control	2011																			●
Bleed brake system	2011	●																		
Bleeding, fuel system	2011	●																		
Catalytic particle filter (CPF) change	2011	●																		
Change value for oil quality	2011																			●
Code control unit	2011	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
Coding rain/light sensor.	2011																			●
Cruise control function	2011	●																		
Differential pressure sensor	2011	●																		
EGR system	2011	●																		
EGR valve	2011	●																		
Electronic throttle control	2011	●																		
Erasing fault memory - All systems	2011																			●
Front distribution flap motor.	2011					●														
Front/rear distribution flap motor	2011					●														
Gateway control unit coding	2011																			●
General-purpose configuration	2011																			●
Injector programming	2011	●																		
Inlet valves basic setting	2011	●																		
Language Change	2011			●																
Learning end position damper motors	2010-2011					●														
Rear distribution flap motor	2011					●														
Recall service message	2011			●																●
Regeneration	2011	●																		
Replace air filter	2011	●																		
Reset oxygen sensor adaptations	2011	●																		
Separating valves basic setting	2011	●																		
Service interval data - carbon content	2010-2011			●																
Service interval data - days since last inspection	2010-2011			●																
Service interval data - distance travelled since last inspection	2010-2011			●																
Service interval data - lower limit for time to next inspection	2010-2011			●																
Service interval data - oil quality	2010-2011			●																
Service interval data - thermal load	2010-2011			●																
Service interval data - upper limit for distance to next inspection	2010-2011			●																



15/12/2011




Service interval data - upper limit for distance to next inspection	2010-2011			●								
Service interval data - upper limit for time to next inspection	2010-2011			●								
Service interval data - upper limit for time to next inspection (a)	2010-2011			●								
System status, gateway	2011										●	
Transport mode activation	2011										●	
Transport mode inactivation	2011										●	
Variant coding	2011										●	
Zero compensation of brake pressure sensor	2011	●										
Zero compensation of lateral acceleration sensor	2011	●										
Zero compensation of longitudinal acceleration sensor	2011	●										

Crafter	2011-2012	●	●	●	●			●	●	●	●	●
ABS/ESP calibration	2011-2012	●										
Boost pressure regulation	2011-2012	●										
Code control unit	2011-2012	●										
Control unit initialization	2011-2012										●	
Difference pressure sensor replaced	2011-2012	●										
ESP driving test	2011-2012	●										
Exhaust feedback	2011-2012	●										
Fixed service interval adaptation	2011-2012			●								
Flap motors calibration	2011-2012				●							
Flexible service interval adaptation	2011-2012			●								
Fuel pump activation	2011-2012	●										
Idle speed adjustment	2011-2012	●										
Injector programming	2011-2012	●										
Particle filter replaced	2011-2012	●										
Particle filter, check the carbon content	2011-2012	●										
Regeneration	2011-2012	●										
Replace air filter	2011-2012	●										
Reset service	2011-2012			●								●
Throttle actuator	2011-2012	●										

Amarok	2011	●	●	●	●			●	●	●	●	●
Adaptation of steering angle sensor	2011	●										
Bleed brake system	2011	●										
Bleeding, fuel system	2011	●										
Catalytic particle filter (CPF) change	2011	●										
Change value for oil quality	2011			●								●
Code control unit	2011	●	●	●	●						●	
Coding rain/light sensor.	2011										●	
Cruise control function	2011	●										
Differential pressure sensor	2011	●										
EGR valve	2011	●										
Electronic throttle control	2011	●										
Erasing fault memory - All systems	2011										●	
Front distribution flap motor.	2011				●							
Gateway control unit coding	2011										●	
General-purpose configuration	2011										●	
Idle speed adjustment	2011	●										
Injector programming	2011	●										
Inlet valves basic setting	2011	●										
Language Change	2011			●								



15/12/2011




Particle filter, check the carbon content	2011	●																	
Recall service message	2011			●															●
Regeneration	2011	●																	
Replace air filter	2011	●																	
Reset oxygen sensor adaptations	2011	●																	
Separating valves basic setting	2011		●																
System status, gateway	2011																		●
Transport mode activation	2011																		●
Transport mode inactivation	2011																		●
Variant coding	2011																		●
Zero compensation of brake pressure sensor	2011		●																
Zero compensation of lateral acceleration sensor	2011		●																
Zero compensation of longitudinal acceleration sensor	2011		●																

T5 Multivan [09-]	2010-2011	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
Adaptation of steering angle sensor	2011	●																	
Adaption of remote control	2011																		●
Bleed brake system	2011		●																
Bleeding, fuel system	2011	●																	
Catalytic particle filter (CPF) change	2011	●																	
Change value for oil quality	2011																		●
Code control unit	2011	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
Coding rain/light sensor.	2011																		●
Cruise control function	2011	●																	
Differential pressure sensor	2011	●																	
EGR system	2011	●																	
EGR valve	2011	●																	
Electronic throttle control	2011	●																	
Erasing fault memory - All systems	2011																		●
Front distribution flap motor.	2011					●													
Front/rear distribution flap motor	2011					●													
Gateway control unit coding	2011																		●
General-purpose configuration	2011																		●
Injector programming	2011	●																	
Inlet valves basic setting	2011		●																
Language Change	2011			●															
Learning end position damper motors	2010-2011					●													
Rear distribution flap motor	2011					●													
Recall service message	2011			●															●
Regeneration	2011	●																	
Replace air filter	2011	●																	
Reset oxygen sensor adaptations	2011	●																	
Separating valves basic setting	2011		●																
Service interval data - carbon content	2010-2011			●															
Service interval data - days since last inspection	2010-2011			●															
Service interval data - distance travelled since last inspection	2010-2011			●															
Service interval data - lower limit for distance to next inspection	2010-2011			●															
Service interval data - lower limit for time to next inspection	2010-2011			●															
Service interval data - oil quality	2010-2011			●															
Service interval data - thermal load	2010-2011			●															
Service interval data - upper limit for distance to next inspection	2010-2011			●															
Service interval data - upper limit for distance to next inspection	2010-2011			●															



15/12/2011



Service interval data - upper limit for time to next inspection	2010-2011			●													
Service interval data - upper limit for time to next inspection (a)	2010-2011			●													
System status, gateway	2011																●
Transport mode activation	2011																●
Transport mode inactivation	2011																●
Variant coding	2011																●
Zero compensation of brake pressure sensor	2011	●															
Zero compensation of lateral acceleration sensor	2011	●															
Zero compensation of longitudinal acceleration sensor	2011	●															

LT II [96-]	2006																●	
--------------------	------	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	---	--

T5 Multivan [-09]	2003-2009																	●
Code control unit	2003-2009																	●

T5 Transporter [-09]	2003-2009																	●
Code control unit	2003-2009																	●

Caddy III [03-10]	2008-2010	●																
Inlet valves basic setting	2008-2010	●																
Separating valves basic setting	2008-2010	●																

Caddy II [95-03]	1995-2003	●																
Activate cruise control system	1995-2003	●																
Code engine control unit	1995-2003	●																
Deactivate cruise control system	1995-2003	●																

Volvo Bus Chassis

B12M	2001-2004	●																
Cylinder Balancing	2001-2004	●																
Cylinder compression	2001-2004	●																
Cylinder deactivation	2001-2004	●																

B12R	2001-2004	●																
Cylinder Balancing	2001-2004	●																
Cylinder compression	2001-2004	●																
Cylinder deactivation	2001-2004	●																

B12B	2001-2004	●																
Cylinder Balancing	2001-2004	●																
Cylinder compression	2001-2004	●																
Cylinder deactivation	2001-2004	●																




15/12/2011



Volvo Trucks									
FH16	2004-2011	●							
Cylinder Balancing	2004-2011	●							
Cylinder compression	2004-2011	●							
Cylinder deactivation	2004-2011	●							
Injector programming cylinder 1	2004-2011	●							
Injector programming cylinder 2	2004-2011	●							
Injector programming cylinder 3	2004-2011	●							
Injector programming cylinder 4	2004-2011	●							
Injector programming cylinder 5	2004-2011	●							
Injector programming cylinder 6	2004-2011	●							
FH	2005-2011	●							
Cylinder Balancing	2005-2011	●							
Cylinder compression	2005-2011	●							
Cylinder deactivation	2005-2011	●							
Injector programming cylinder 1	2005-2011	●							
Injector programming cylinder 2	2005-2011	●							
Injector programming cylinder 3	2005-2011	●							
Injector programming cylinder 4	2005-2011	●							
Injector programming cylinder 5	2005-2011	●							
Injector programming cylinder 6	2005-2011	●							
Urea crystallisation SCR Catalytic silencer, regeneration	2005-2011	●							
FM7	1998-2001	●							
Cylinder compression	1998-2001	●							
FM10	1998-2001	●							
Cylinder compression	1998-2001	●							
FM	2005-2011	●							
Cylinder Balancing	2005-2011	●							
Cylinder compression	2005-2011	●							
Cylinder compression, test	2009-2011	●							
Cylinder deactivation	2005-2011	●							
Injector programming cylinder 1	2005-2011	●							
Injector programming cylinder 2	2005-2011	●							
Injector programming cylinder 3	2005-2011	●							
Injector programming cylinder 4	2005-2011	●							
Injector programming cylinder 5	2005-2011	●							
Injector programming cylinder 6	2005-2011	●							
Urea crystallisation SCR Catalytic silencer, regeneration	2005-2011	●							
FH12	1999-2005	●							
Cylinder Balancing	1999-2005	●							
Cylinder compression	1999-2005	●							
Cylinder deactivation	1999-2005	●							
Injector programming cylinder 1	1999-2005	●							
Injector programming cylinder 2	1999-2005	●							
Injector programming cylinder 3	1999-2005	●							
Injector programming cylinder 4	1999-2005	●							
Injector programming cylinder 5	1999-2005	●							



15/12/2011



Injector programming cylinder 6	1999-2005	●																	
FM12	1998-2005	●																	
Cylinder Balancing	1998-2005	●																	
Cylinder compression	1998-2005	●																	
Cylinder deactivation	1998-2005	●																	
Injector programming cylinder 1	2004-2005	●																	
Injector programming cylinder 2	2004-2005	●																	
Injector programming cylinder 3	2004-2005	●																	
Injector programming cylinder 4	2004-2005	●																	
Injector programming cylinder 5	2004-2005	●																	
Injector programming cylinder 6	2004-2005	●																	
FM9	2002-2005	●																	
Cylinder Balancing	2002-2005	●																	
Cylinder compression	2002-2005	●																	
Cylinder deactivation	2002-2005	●																	
Injector programming cylinder 1	2002-2005	●																	
Injector programming cylinder 2	2002-2005	●																	
Injector programming cylinder 3	2002-2005	●																	
Injector programming cylinder 4	2002-2005	●																	
Injector programming cylinder 5	2002-2005	●																	
Injector programming cylinder 6	2002-2005	●																	
FL6	2000-2006	●																	
Cylinder compression	2000-2006	●																	
FL	2006-2011	●																	
Cylinder Balancing	2006-2011	●																	
Cylinder compression	2006-2011	●																	
Cylinder deactivation	2006-2011	●																	
Urea crystallisation SCR Catalytic silencer, regeneration	2006-2011	●																	
FE	2006-2011	●																	
Cylinder Balancing	2006-2011	●																	
Cylinder compression	2006-2011	●																	
Cylinder deactivation	2006-2011	●																	
Urea crystallisation SCR Catalytic silencer, regeneration	2006-2011	●																	