

SSP384

INTRODUCTION

This catalog replaces Tool Catalog SSP578 dated November, 1978.

This catalog contains information relative to tools used for modification and maintenance of Lycoming opposed aircraft engines. It consists of four sections: The first is an alphabetical index and the second a numerical pictorial listing with brief descriptions. The third is a Service Publication Cross Reference Index and the fourth is a listing of obsolete tools.

The illustrations used in this catalog show the general appearance of the tools but are not related according to size. In some cases, a single illustration has been used to cover a number of tools similar in appearance, with different tool numbers; therefore it is necessary, when ordering tools, to note carefully the descriptions and tool numbers in the text. Any tool described as being applicable to engines with "crosswise accessories" or "crosswise accessory housings" do not include VO-435-B1A and TVO-435-F1A helicopter engines and TIO-541 and TIGO-541 integral accessory drive engines; tools applicable to these engines are specifically designated by engine model.

PRICES

This catalog does not list prices. A separate numerically arranged parts and tool price list is available and is supplied to distributors of Lycoming Engines.

HOW TO ORDER

Tools must be ordered by or through authorized Lycoming distributors. A tool must be designated by a tool number together with a name sufficiently descriptive to identify the tool. It is not necessary to write the full catalog description of the tool. Do not enter price of the tool on the order. Be sure to give definite shipping instructions.

ALPHABETICAL INDEX

A

Adapter dynafocal mounts - 64898, ST-88 engine overhaul assembly - ST-165, ST-240 hand drive - ST-63 hydraulic tappets - 64899 overhaul stand - 64917 propeller shaft flange - 64836 sludge tube removal - 64866 test club - 64840, 64979, 64980, 64981, 64989, 64991, ST-242, ST-455 Adapter - 5/8-18 NC-2 thread to 16 MM x 2 thread - ST-333 Adapter, Puller check valve retainer - 64752 crankshaft front oil plug - 64735 crankshaft rear oil tube - 64737, 64831 crankshaft sludge tube - 64784 starter jaw - 64748 Arbor connecting rod slave bolts - ST-236, ST-237 counterweight balancing - ST-96 finish pilot bushing - 64590

B

Balls - sizing - ST-147-1, ST-147-2, ST-300-1, ST-300-2, ST-300-3 Bar, boring accessory housing cover bushing - 64884 cross shaft in accessory housing - 64877 generator drive bushing - 64870 Basket - valve parts, cleaning - 64553 Blade, Counterweight - 64603-7 Blade Valve Adjusting - ST-418-3 Block cylinder holding - 64526, 64526-1, 64526-2 thrust nut - 64607 vee - 64545 Bolt propeller - 64982, 64983, 64984 Bracket - engine lifting -64758 Burnisher connecting rod bushing - 64580 magneto drive idler gear - 64887 valve rocker bushing - 64541 Bushing oil relief valve - ST-243, ST-245

С

Cable - engine lifting - 1240, 64834, ST-220 Cap - protector, propeller shaft thread - 72762

C (Cont.)

Club - test - 64773, 64783, 64801, 64802, 64803, 64807, 64988, 64990, ST-241, ST-297, ST-298, ST-351, ST-456 Compressorpiston ring - 64529, 64559, 64712 valve spring - ST-25, ST-266, ST-419 Counterbore crankcase "o" ring recess - 64904, ST-323 cylinder heads - ST-199 Counterbore intake pipe bore salvage - ST-228, ST-274 spark plug pad - ST-370 Countersink intake pipe bore salvage - ST-273 oil relief valve - ST-248, ST-439 Crimping tool and wire stripper - 64861 Cutter salvage fretted crankcases - ST-145, ST-269 shroud tube relief - ST-363 oil pump housing -64868 valve seat - ST-50, ST-51, ST-52, ST-53, ST-54, ST-55, ST-56, ST-57, ST-58

D

Drift bushing installation - ST-276, ST-230 connecting rod bushing removal - 64535 connecting rod bushing replacement - 64536 crankshaft, front plug - ST-234 crankshaft, oil plug - 64647, 64754, ST-46, ST-295, 64770 crankshaft, oil tubes - 64548, 64648, ST-44 crankshaft pilot bushing -64588 crankshaft spline bushing - ST-170 exhaust valve guide - 64923 intake pipe bore salvage - ST-230 magneto coupling sleeve - 64741 magneto drive idler bushing - 64743 main bearing oil tubes - 64649 oil pump drive shaft bushing - 64747 oil seal plug - 64770 outer rocker shaft bushing - 64815, 64824 rocker shaft bushing - 64814, 64825, 64816 starter drive adapter bushing - 64745 valve guide - 64505, 64796, ST-302, ST-303, ST-304 valve seat - ST-64, ST-65 Drill crankcase thru-stud dowel - ST-124 dowel hole in crankcase - ST-379 piloted, exhaust valve guide conversion - 64939 plate, turbocharger - ST-135

ALPHABETICAL INDEX

D (Cont.)

reduction gear housing - ST-10 Drill Jig accessory housing assembly - ST-17, ST-19 crankcase mounting bushing - 64771 crankcase bearing oil drain - ST-372 Drive Assembly - test - 64894 Driver bearing dowel - ST-291, ST-305, ST-306, ST-307, ST-378 counterbore, intake pipe - ST-275 counterweight bushing - ST-92 crankcase thru stud - ST-316, ST-317 crankshaft plug - 64681 crankshaft rear spline bushing - ST-168 dowel crankcase - ST-332 intake pipe bore salvage - ST-253 oil relief valve - ST-215, ST-249 valve seat cutters - ST-62

Е

Expander - piston ring - 64528, 64560, 64713 Expander and staking tool - 64593 Eye - engine lifting - 64769, ST-48

F

Fixture accessory housing bushing - 64859 accessory housing cover bushing - 64863 connecting rod bushing - 64597 convert carburetor cylinder - ST-28 counterweight bushing - ST-93 crankcase fretting salvage - ST-144, ST-252 crankshaft counterweight holes - ST-280 crankshaft flange - ST-256 crankshaft gear drill - ST-390 crankshaft oil seal retainer - ST-40, ST-105 crankshaft rear spline bushing - ST-169 cylinder shroud tube - ST-364 drill bearing dowel hole - ST-377 fuel injector - ST-319 grind bushing - 64878 hydraulic lifters - ST-233 intake pipe bore salvage - ST-227, ST-277 locating and reaming - ST-149 oil seal cap - ST-39 plug type, drill generator housing - ST-20, ST-21 propeller, shaft locknut assembly - ST-329 reduction gear housing - ST-8 reduction gear housing, drive plate dowel - 64827 shroud tube adapter - ST-357

F (Cont.)

tappet body magnaflux - ST-387 turbocharger, holding - ST-133 valve guides, replace - 64501, 64644, 64714 valve guide hole - ST-179 valve rocker - 64540 valve seat - ST-250, ST-232 Former - oil relief valve seat - ST-340

G

Gage belt tension - ST-131 connecting rod bolt stretch - 64945 connecting rod bushing - 64767 connecting rod parallelism and squareness - 64530 counterweight bushing - ST-94 counterweight, circlip - 64892 counterweight, clearance in crankcase - ST-37 counterweight - dial bore - ST-73 counterweight, squareness - ST-91 feeler - 64992 flush pin, depth - ST-9 fuel injector and controller - ST-318 hydraulic tappet body - 64909 intake pipe bore salvage - ST-226 turbocharger - ST-136 spring positions - 64971 valve clearance - 62700, ST-23, ST-279 valve guides, bell mouthing - ST-71, ST-310 valve guides ID - 64514 Gage, flat plug connecting rod bushing - 64537 rocker shaft bushing - 64613 valve guide ID - ST-81 Gage, plug by-pass valve - ST-140, ST-141 rocker arm bushing - 64542 rocker shaft bushing - 64810, 64811, 64823, ST-191 valve guide ID - 64901, 64927, ST-26, ST-155 Gage valve guide ID - ST-314 valve guide OD - ST-89, ST-89-1, ST-89-2, ST-89-3, ST-89-4, ST-89-5, ST-259, ST-259-1, ST-259-2, ST-259-3, ST-259-4, ST-259-5, ST-429, ST-429-1, ST-429-2, ST-429-3, ST-429-4, ST-429-5, ST-431, ST-431-1, ST-431-2, ST-431-3, ST-431-4, ST-431-5 Gage, plug and depth - ST-126, ST-331 Gage block crankcase counterweight bushing - ST-212 turbocharger - ST-138

ALPHABETICAL INDEX

H

Handle cylinder base nut wrench - 64711 offset - spark plug wrench - ST-345 Holder, accessory drive shaft - ST-173, ST-174 Holder, shroud tube barrel springs - ST-376 Hub Assembly - 64774 Hub and Cone Assembly - ST-415

I

Indicator Expander - ST-24 Inserting Tool -64594 Installer, seal - ST-443

J

Jaws, slide hammer puller - 64886 Jig supercharger shaft gear - 64780 welding, by-pass valve - ST-139 Jig, drill - 64599

K

Kit -

engine overhaul ring mounting - ST-239 helicoil repair - ST-184 valve train removal - ST-368

Μ

Mount engine maintenance - ST-460, ST-461

Р

Pilot bar, rocker arm - ST-160 crankcase - ST-324 counterbore, intake bore salvage - ST-229 spark plug pad - ST-369 valve seat - ST-66, ST-66-1, ST-66-2, ST-66-3, ST-66-4, ST-66-5, ST-67, ST-67-1, ST-67-2, ST-67-3, ST-67-4, ST-67-5, ST-68, ST-68-1, ST-68-2, ST-68-3, ST-68-4, ST-68-5, ST-257, ST-257-1, ST-257-2, ST-257-3, ST-257-4, ST-257-5 Pin, locating - ream pinion cage - ST-149-9 Pin, locating - valve guide hole in cylinder head fixture -ST-179-3 Plate bushing - 64856, ST-123, ST-270, ST-327 crankcase - ST-122

P (Cont.)

engine mounting - ST-47 impeller nut - 64715 torque hold-down - ST-222 Plug bearing - 64906 crankshaft counterweight - ST-280-10, ST-280-11 Pointer - ignition timing - 64697 Protector - thread - 475-B, 72762, ST-86, ST-87 Puller compressor pulley - ST-321 crankcase thru stud - ST-271 crankshaft spline bushing - 64772 crankshaft counterweight bushing -64872 cylinder head insert - ST-356 generator and alternator - ST-158 generator drive countershaft - 64728 magneto drive shaft sleeve - 64766 magneto gear - 64976 oil seal - ST-172 pinion cage - 64698 piston pin - 64843 slide hammer - 64782 valve guide - ST-49

R

Reamer accessory housing oil transfer tube - ST-435, ST-436 counterweight bushing hole - 64874, 64875, 64876, ST-210, ST-211 crankcase, body fit thru studs - 64902, 64903 crankcase, thru stud dowel - ST-125, ST-328-2, ST-366-5, ST-366-1 crankshaft flange - ST-254, ST-255 crankshaft, pilot bushing - 64589 cylinder head shroud tube - ST-362 intake pipe bore salvage - ST-231 oil relief valve - ST-244, ST-246 oil temperature by-pass valve seat - ST-388 pinion cage - ST-150-1, ST-150-2, ST-299-1, ST-299-2, ST-299-3 propeller shaft bearing dowel - ST-380 reduction gear bolt - 64891, 64891-1, 64891-2, 64893, 64893-1, 64893-2 reduction gear housing, dowel hole - 64828, 64829, ST-12, ST-13, ST-14, ST-15 rocker shaft bushing ID - 64819, 64820, 64821, 64822, 64826 rocker shaft bushing hole - 64812, 64813, 64838, 64839, ST-427 shroud tube adapter - ST-354 valve guide ID - 64684, 64900, 64925, ST-27

ALPHABETICAL INDEX

R (Cont.)

ST-113-1, ST-113-2, ST-143-1, ST-143-2, ST-181-1, ST-181-2, ST-267, ST-309-1, ST-309-2, ST-315, ST-338 valve guide OD - ST-90-1, ST-90-2, ST-90-3, ST-90-4, ST-90-5, ST-180, ST-258-1, ST-258-2, ST-258-3, ST-258-4, ST-258-5, ST-430-1, ST-430-2, ST-430-3, ST-430-4, ST-430-5, ST-432-1, ST-432-2, ST-432-3, ST-432-4, ST-432-5 Removing Tool - heli-coil insert - 64595 Ring - engine mounting - 64759, ST-161, ST-272,

- ST-285, ST-286, ST-287
- Mount, Rubber test stand 64975

S

Shroud - cooling - 64612, 64857, 64867, 64888, 64944, ST-45, ST-114, ST-128, ST-164, ST-352 Skid - overhaul - ST-278 Sleeve connecting rod and gage - 64530-9, 64530-10 64530-11 turbocharger piston - ST-129 Socket connecting rod nut - ST-251 injector nozzle - ST-190-2 oil pressure screen - ST-80 spark plug wrench - ST-288 Spacer pinion cage - ST-148 supercharger impeller - 64704 Spinner - cylinder base nuts - 64987 Spinning Tool - crankshaft oil tubes - 64910 Spring Holder - shroud tube - ST-376 Spotfacer pilot and driver reduction gear modification - ST-112 rocker shaft bushing - 64862 Stand overhaul - ST-162, 64916 test, engine - 64765, ST-43 work - 64947 Stop, drill and reamer - ST-156 Stop Collar crankcase - 64905, ST-325 reduction gear housing seal - ST-11 holder - crankcase - ST-146 Stud, crankcase plate - ST-122-2 Swaging Tool intake pipe - 64781, 64948, ST-289 turbocharger exhaust pipes - ST-223

T (Cont.)

crankcase, thru stud high compression - 64907 spark plug, heli-coil insert - 18MM - 64596-1 Thermocouple Probe, Deck Temperature - ST-264-B ST-264-C Thermocouple Extension - ST-265 Tool baffle installation - 64885 crankcase separator - ST-389 crankshaft counterweight plug - 64603 crankshaft oil seal - ST-383 crimping - ST-22, ST-78, ST-198, ST-301 density controller adjusting - ST-260 flare cylinder head shroud tube adapter - ST-365 hydraulic tappet assembly - 64941, ST-440, ST-474 fuel injector oil filter - 64914 peening, crankshaft spline bushing - ST-171 pressure controller lock - ST-284 propeller flange bushing - ST-115 roll pin spreader - 64864 shroud tube holes 64974 shroud tube assembly and disassembly - ST-361 spinner, cylinder base nut - 64987 valve adjusting - ST-418

U

Universal - Drill, high compression crankcase - 64908

W

Weight - counterweight balancing - ST-95 Wrench - accessory drive shaft nut - 64709 Wrench crankshaft flange - ST-313 crankshaft spline - 1225-B, ST-38 cylinder - 64700, 64701, 64942, 64943, ST-83, ST-84, ST-322, ST-374, ST-375 engine timing - ST-235 exhaust head manifold - 64933 exhaust pipe flange - ST-163, ST-213 fuel flow adjustment - ST-29, ST-30 impeller - 64778 injector - 64932, 64970 magneto - 64977, ST-79 oil pump drive - ST-416 oil plug - ST-107 oil screen - 64946 pressure controller, differential - ST-283 propeller - ST-320 propeller flange spanner - 64721 propeller shaft sleeve nut - 64719 reduction gear housing - ST-108


Т

ALPHABETICAL INDEX


W (Cont.)

shroud tube - ST-142 tee bar - ST-345 thrust bearing lock nut - 40714 timing - 64729, 64764 turbocharger - ST-134 turbocharger impeller - ST-177 vacuum pump - 64934 weatherhead fittings - ST-104


Ref.	Tool No.	Nomenclature and Description
1	475-B	Protector, Crankshaft Propeller Nut Thread-All propeller shafts with No. 20 spline
2	1225-В	Wrench, Crankshaft No. 20 Spline - All propeller shafts with no. 20 spline (See ST-38 for No. 30)
3	1240	Cable, Engine Lifting - All engines employing two lifting straps
4	40714	Wrench, Thrust Bearing Lock Nut - All reduction gear housing employing a thrust bearing lock nut
5	62700	Gage, Valve Clearance - O-235, O-290-D Series solid tappets only
6	64501	Fixture, Valve Guide Replacement - All 4-3/8 in. and 4-7/8 in. bore cylinder assemblies
7	64505	Drift, Valve Guide Installation - All (flange) intake valve guides and all (flange) exhaust valve guides incorporating the .404/.405 guide hole I.D.
8	64514	Gage, Valve Guide ID - All intake valve guides and all exhaust valve guides incorporating the .404/.405 valve guide hole (See 64684 for Reamer)
9	64526	Block, Cylinder Holding - All cylinder assemblies with 4-3/8 in. bore
10	64526-1	Block, Cylinder Holding - All cylinder assemblies with 4-7/8 in. bore
11	64526-2	Block, Cylinder Holding - All cylinder assemblies with 5-1/8 in. bore
12	64528	Expander, Piston Ring - All cylinder assemblies with 4-7/8 in. bore
13	64529	Compressor, Piston ring - All cylinder assemblies with 4-7/8 in. bore
14	64530	Gage, Connecting Rod Parallelism and Squareness - All engines
15	64530-9	Sleeve, Tapered, Connecting Rod Parallelism and squareness gage. Detail of 64530. Used on 2.4205/2.4210 bearing bores
16	64530-10	Sleeve, Tapered, Connecting Rod Parallelism and squareness gage. Detail of 64530. Used on 2.2970/2.2975 bearing bores
17	64530-11	Sleeve, Tapered, Connecting Rod Parallelism and squareness gage. Detail of 64530. Used on 2.4305/2.4310 bearing bores
18	64535	Drift, Connecting Rod Bushing Removal - All engines
19	64536	Drift, Connecting Rod Bushing Replacement - All engines




- Ref. Tool No. Nomenclature and Description
- 20 64537 Gage, Flat Plug Connecting Rod Bushing Rejection All engines
- 21 64540 Fixture, Rebushing Valve Rocker All engines except 76 Series
- 22 64541 Burnisher, Valve Rocker Bushing All engines except 76 Series (Use with 64826)
- 23 64542 Gage, Plug, Valve Rocker Bushing ID (Finish) All engines except 76 Series
- 24 64545 Block, Vee Check Crankshaft Run All engines
- 25 64548 Drift, Replace Crankshaft Oil Tubes (Sludge Tubes) All four cylinder direct drive engines employing sludge tubes
- 26 64553 Basket, Valve Parts, Cleaning All engines
- 27 64559 Compressor, Piston Ring All cylinder assemblies with 4-3/8 in. bore
- 28 64560 Expander, Piston Ring All cylinder assemblies with 4-3/8 in. bore
- 29 64580 Burnisher, Connecting Rod Bushing All engines
- 3064588Drift, Crankshaft Pilot Bushing All geared engines
- 31 64589 Reamer, Crankshaft Pilot Bushing Finish All geared engines
- 32 64590 Arbor, Crankshaft Pilot Bushing Reamer All geared engines
- 33 64593 Expanding and Staking Tool, 18 MM Spark Plug Heli-Coil Insert All engines (Includes long reach plugs)
- 34 64594 Inserting Tool, 18 MM Spark Plug Heli-Coil Insert All engines (Including long reach spark plugs)



Ref.	Tool No.	Nomenclature and Description
35	64595	Removing Tool, 18 MM Spark Plug Heli-Coil Insert - All engines (Includes long reach plugs)
36	64596-1	Tap, 18 MM Heli-Coil Spark Plug Bottoming Tap .010 o/s - All engines (Includes long reach plugs)
37	64597	Fixture, Remove, Replace, Burnish Connecting Rod Bushing - All engines
38	64597-10	Spacer, Use under detail 1 or detail 9 to hold connecting rod level with fixture. Use with connecting rods with $\frac{1.271}{1.273}$ bearing cap width (detail of 64597)
39	64597-11	Spacer, Use under detail 1 or detail 9 to hold connecting rod level with fixture. Use with connecting rods with $\frac{1.331}{1.333}$ bearing cap width (detail of 64597)
40	64599	Jig, Generator Mounting Bushing Drill for Dowel Pin - GO-435-C2 Series, GO-480-B1C, -C1D6, -G1D6, -G1F6, -G2D6, -G2F6, -C2 Series, -F Series
41	64603	Tool, Crankshaft Counterweight Plugs, Removal and Replacement - All Counterweights employing threaded plugs
42	64603-7	Blade, Counterweight Removal and Replacement Plug - Detail of 64603
43	64607	Block, Thrust Nut in Thrust Plate Assembly Installation - All reduction gear housings employing a thrust bearing locknut.
44	64612	Shroud, Cooling - All four cylinder engines employing parallel valve cylinder except VO-360 and IVO-360
45	64613	Gage, Rocker Shaft Bushing Rejection - All engines except 76 Series
46	64644	Fixture, Valve Guide Replacement - All angle head cylinder assemblies
47	64647	Drift, Crankshaft Front Oil Plug - All geared engines except IGO-540, IGSO-540 and TIGO-541
48	64648	Drift, Crankshaft Oil Tubes - Replacement (Sludge Tubes) - All six cylinder vertical engines and all geared engines employing sludge tubes
49	64649	Drift, Rear Main Bearing Oil Tubes - GO-435-C2 Series, GO-480-B Series, -G1A6, -G1C6, -C1D6, -G1D6, -G1F6, -G2D6, -G2F6, -C2 Series, -F Series




Ref.	Tool No.	Nomenclature and Description
50	64681	Driver, Crankshaft Welch Plug - All direct drive except VO-435 and VO-540
51	64684	Reamer, Valve Guide ID - All intake valve guides and all exhaust valve guides incorporating the .404/.405 ID valve guide hole (See 64514 for Plug Gage)
52	64697	Pointer, Ignition Timing - All direct drive except TIO-541
53	64698	Puller, Pinion Cage - All geared engines except TIGO-541
54	64700	Wrench, (9/16 in. Spline) Cylinder base nut - All engines employing 68515 nut - (See 64701 for 3/4 in. Wrench)
55	64701	Wrench, (3/4 in. Spline) Cylinder base nut - All engines employing 68514 nut - (See 64700 for 9/16 in. Wrench)
56	64704	Spacer, Supercharger Impeller (This spacer is used as a tool in setting up impeller in supercharger housing assembly to obtain tool box clearance) - All supercharger engines
57	64709	Wrench, Accessory Drive Shaft Nut - All crosswise accessory housing
58	64711	Handle, Cylinder Base Nut Wrench - Use with 64700 and 64701
59	64712	Compressor, Piston Ring - All 5-1/8 in. bore cylinder assemblies
60	64713	Expander, Piston Ring - All 5-1/8 in. bore cylinder assemblies
61	64714	Fixture, Valve Guide Replacement - All 5-1/8 in. bore parallel valve cylinder assemblies
62	64715	Plate, Impeller Nut - All supercharged engines
63	64719	Wrench, Propeller Shaft Sleeve Nut - All reduction gears employing nut P/N 67729
64	64721	Wrench, Propeller Flange Spanner - All engines with flanged propeller shaft less bushings except TIGO-541



Ref.	Tool No.	Nomenclature and Description
65	64728	Puller, Generator Drive Countershaft - GO-480-B
66	64729	Wrench, Timing - All engines equipped for hand starters
67	64735	Adapter, Puller, Crankshaft Front Oil Plug P/N 70432 - VO-435, TVO-435, VO-540, TIVO-540
68	64737	Adapter, Puller, Crankshaft Rear Oil Tube P/N 69844 - VO-435, TVO-435, GO-480-D Series, -C1B6, -G1B6, -G1E6, GSO-480 Series, IGSO-480 Series, IGO-540 Series, IGSO-540 Series, VO-540 Series, TIVO-540 Series
69	64741	Drift, Magneto Coupling Sleeve Removal - All engines with crosswise accessory housings
70	64743	Drift, Magneto Drive Idler Gear Hub Bushing - All engines with crosswise accessory housings
71	64745	Drift, Starter Drive Adapter Bushing - All engines with crosswise accessory housings
72	64747	Drift, Oil Pump Drive Shaft Bushing Removal - All engines with crosswise accessory housings
73	64748	Adapter, Puller, Starter Jaw - All engines with crosswise accessory housings
74	64752	Adapter, Puller, Check Valve Retainer - All engines with crosswise accessory housings
75	64754	Drift, Crankshaft Oil Plug Installation - VO-435, TVO-435, VO-540, TIVO-540
76	64758	Bracket, Engine Lifting - GO-435-C2A, -C2B, VO-435-A Series
77	64759	Ring, Engine Mounting - All engines except turbocharger equipped and IO-720 Series. (Use adapters 64898 or ST-88 with 4 cylinder engines. Use engine mounts ST-460 and ST-461 on applicable 6 cylinder direct drive engines.) Use with ST-278, ST-162, and ST-165 as required.
78	64764	Wrench, Timing - All engines with crosswise accessory housing not employing hand starters except VO- 435-B1A and TVO-435-F1A
79	64765	Stand, Test-Helicopter Engines - All six cylinder vertical engines
80	64766	Puller - Magneto Drive Shaft Sleeve - All engines employing crosswise accessory housing with rear mounted magnetos
81	64767	Gage, Connecting Rod Bushing ID Finish - All engines
82	64769	Eye, Engine Lifting - VO-435, TVO-435, VO-540, IVO-540 and TIVO-540
0.2	(1770)	


83 64770

Drift, Oil Seal Plug Installation - O-235, O-290, O-320, IO-320, O-340, O-360, IO-360 and HIO-360 (Plug Size 1.753/1.755 P/N 61510




Ref.	Tool No.	Nomenclature and Description
84	64771	Drill, Jig, Mounting Bushing Crankcase - O-320
85	64772	Puller, Crankshaft Spline Bushing Rear - All engines with crosswise accessory housings
86	64772-1	Nut, Splined - 13 Teeth - Detail of 64772
87	64772-5	Nut, Splined - 14 Teeth - Detail 0f 64772
88	64773	Club, Test - GO-435-C2, VO-435, TVO-435, VO-540, IVO-540 and TIVO-540 (Use with 64774)
89	64774	Hub and Cone Assembly, Test Club (4 Blade) - All No. 20 spline propeller shafts with 2.365/2.367 OD
90	64778	Wrench, Impeller - GSO-480 Series, IGSO-480 Series and IGSO-540 Series
91	64780	Jig, Holding Supercharger Shaft Gear - GSO-480, IGSO-480, IGSO-540 Series
92	64781	Swaging Tool, Intake pipe - Engines employing intake pipe connections P/N 69602, 71699, 78914 with 1.672/1.696 ID
93	64782	Puller, Slide Hammer - Medium - Used with the following tools: 64735, 64737, 64748, 64752, 64784, 64831, 64866, ST-172 and ST-333
94	64783	Club, Test (4 Blade) - GO-480-B, -C1, -D, -F2, -F4A6, -G1 Series; GSO-480-A1, -B1 Series; IGSO-480; IGO-540 and IGSO-540
95	64784	Adapter, Puller, Crankshaft Sludge Tube - VO-435; TVO-435; VO-540; TIVO-540; IO-720 and all geared engines
96	64796	Drift, Valve Guide Installations - All (Flange) valve guides with .437/.438, .4375/.4385 ID valve guide hole
97	64801	*Club, Test -O-235 with AS-127 type 2 prop flange - O-290-D, O-320-A, -C, -E Series and IO-320-A, -D, -E series, AIO-320-A, -B, -C. Use with 64979 or 64980
98	64802	Club, Test - O-320-B, -D Series, IO-320-B, -C Series, O-340-A, -B. Use with 64980
99	64803	Club, Test - O-360; VO-360; IO-360; AIO-360; TIO-360; HO-360; HIO-360; IMO-360; O-540; IO-540; TIO-540 and TIO-541. (Use with 64981)
100	64807	Club, Test - GO-480-C2, -F6, -F1A6, -F3A6, -F3B6, -G2D6, -G2F6 Series; GSO-480-A2A6, -B2 Series. (Use with 64840)


* AS-127 Type 2 propeller flange can be identified by measuring from one prop attaching bushing across the center of the crankshaft to the opposite bushing. The center to center measurement is 4-3/4 inches.




Ref.	Tool No.	Nomenclature and Description
101	64810	Gage, Plug, Rocker Shaft Bushing Hole in Cylinder Head - All engines except 76 Series
102	64811	Gage, Plug, .005 o/s, Rocker Shaft Bushing Hole in Cylinder Head - All engines except 76 Series (See ST- 191 for .010 o/s)
103	64812	Reamer, .005 o/s - Outer Rocker Shaft Bushing Hole in Cylinder Head - All engines employing angle valves
104	64813	Reamer, .010 o/s - Outer Rocker Shaft Bushing Hole in Cylinder Head - All engines employing angle valves
105	64814	Drift, Rocker Sshaft Bushing Removal - All engines except 76 Series
106	64815	Drift, Outer Rocker Shaft Bushing Installation - All engines employing angle valves
107	64816	Drift, Inner Rocker Shaft Bushing Installation - All engines employing angle valves
108	64819	Reamer, Semi-Finish, Outer Rocker Shaft Bushing ID - All engines employing angle valves
109	64820	Reamer, Semi-Finish, Inner Rocker Shaft Bushing ID - All engines employing angle valves
110	64821	Reamer, Finish Outer Rocker Shaft Bushing ID - All engines employing angle valves
111	64822	Reamer, Finish Inner Rocker Shaft Bushing ID - All engines employing angle valves
112	64823	Gage, Plug - Rocker Shaft Bushing ID - All engines except 76 Series
113	64824	Drift, Outer Rocker Shaft Bushing Installation - All engines employing parallel valves except 76 Series
114	64825	Drift, Inner Rocker Shaft Bushing Installation - All engines employing parallel valves except 76 Series
115	64826	Reamer, Finish Inner and Outer Rocker Shaft Bushings - All engines employing parallel valves except 76 Series (Use with 64541)
116	64827	Fixture, Drill Drive Plate Dowel in Reduction Gear Housing - GO-480-F Series, -C2 Series, -G2D6, -G2F6 and GSO-480-B2D6
117	64828	Reamer, Drive Plate Dowel Hole in Reduction Gear Housing - GO-480-C2 Series, -F Series, -G2D6, -G2F6 and GSO-480-B2D6
118	64829	Reamer, Reduction Gear Housing Dowel Hole - GO-480-C2 Series, -F Series, -G2D6, -G2F6 and GSO-480- B2D6




Ref.	Tool No.	Nomenclature and Description
119	64831	Adapter, Puller, Crankshaft Rear Oil Tube - O-435-A, GO-435-C2 Series, GO-480-B, -C2, -F Series, -C1D6, -G1A6, -G2D6, -G1F6, -G2F6, -G1G6
120	64834	Cable, Engine Lifting - All engines not employing lifting eyes
121	64836	Adapter, Propeller Shaft Flange - GO-480-C2 Series, -F6, -F1A6, -F3A6, -F3B6, -G2D6, -G2F6
122	64838	Reamer, .005 o/s Inner Rocker Shaft Hole in Cylinder Head (Used with 64812 reamer for angle head cylinder. Used for both shaft holes in parallel valve cylinders except 76 Series)
123	64839	Reamer, .010 o/s Inner Rocker Shaft Hole in Cylinder Head (Used with 64813 reamer for angle head cylinder. Used for both shaft holes in parallel valve cylinders except 76 Series)
124	64840	Adapter, Test Club - GO-480-C2 Series, -F6, -F1A6, -F3A6, -F3B6 Series, -G2 Series, GSO-480-A2A6, -B2 Series
125	64843	Puller, Piston Pin - All engines
126	64856	Bushing Plate, Crankcase and Accessory Housing Drill - All engines with crosswise accessory housings
127	64857	Shroud, Cooling - All six cylinder angle valve cylinders employing down draft exhaust except TIO and TIGO-541
128	64859	Fixture, Bore Accessory Housing Bushing - All engines with crosswise accessory housings
129	64861	Crimping Tool and Wire Stripper - All 7MM ignition harnesses (See ST-198 for 5MM)
130	64862	Spotfacer, Inner Rocker Shaft Bushing - All engines employing angle head valves



Ref.	Tool No.	Nomenclature and Description
131	64863	Fixture, Bore Bushing in Accessory Housing Cover - All engines with crosswise accessory housings
132	64864	Tool, Roll Pin Spreader (Connecting Rod) - All engines employing roll pins
133	64866	Adapter, Sludge Tube Removal - O-540, IO-540 (P/N 60449)
134	64867	Shroud Cooling - All six cylinder parallel valve cylinders employing down draft exhaust
135	64868	Cutter, Oil Pump Housing (Convert to Large Capacity Filter) - All crosswise accessory housings not equipped with large filter
136	64870	Bar, Boring, Generator Drive Bushing and Annulus in Accessory Housing - All engines with crosswise accessory housings
137	64872	Puller, Remove and Install Crankshaft Counterweight Bushings - All engines with counterweight bushings
138	64874	Reamer, .005 o/s Counterweight Bushing Holes - All engines with counterweights (See ST-210 for .0075 o/s)
139	64875	Reamer, .010 o/s Counterweight Bushing Holes - All engines with counterweights (See ST-211 for .0125 o/s)
140	64876	Reamer, .015 o/s Counterweight Bushing Holes - All engines with counterweights
141	64877	Bar, Boring, Cross Shaft in Accessory Housing - All engines with crosswise accessory housings
142	64878	Fixture, Grind Bushings in Dynamic Counterweight - All engines with counterweight bushings
143	64884	Bar, Boring - Accessory Housing Cover Bushings - All engines with crosswise accessory housings
144	64885	Tool, Baffle Installation - All engines with cooling baffles
145	64886	Jaw, Slide Hammer Puller (Small Diameter) - All engines (Use with 64782)
146	64887	Burnisher, Magneto Drive Idler Gear (Hub Assembly) - All engines with crosswise accessory housings



Ref.	Tool No.	Nomenclature and Description
147	64888	Shroud Cooling (Permanent Installation) - All six cylinder down draft exhaust engines except IGO and IGSO-540, TIO and TIGO-541
148	64891	Reamer, Body Fit Bolts Reduction Gear "Service" (STD) - All geared engines in which P/N 71184 body fit bolts are to be installed in reduction gear housing
149	64891-1	Reamer, Body Fit Bolts Reduction Gear "Service" (.010 o/s) - All geared engines in which P/N 71184 body fit bolts are to be installed in reduction gear housing
150	64891-2	Reamer, Body Fit Bolts Reduction Gear "Service" (.020 o/s) - All geared engines in which P/N 71184 body fit bolts are to be installed in reduction gear housing
151	64892	Gages, Check Circlips in Counterweights - All engines with counterweights that employ circlips
152	64893	Reamer, Body Fit Bolts Reduction Gear (STD) - All geared engines in which P/N 68364 body fit bolts are to be installed in reduction gear housing
153	64893-1	Reamer, Body Fit Bolts Reduction Gear (.010 o/s) - All geared engines employing P/N 68364-P10 body fit bolts in reduction gear housing
154	64893-2	Reamer, Body Fit Bolts Reduction Gear (.020 o/s) - All geared engines in which P/N 68364-P20 body fit bolts are to be installed in reduction gear housing
155	64894	Drive Assembly, Test - All six cylinder, vertical engines (Use 74822 gasket)
156	64894-1	Nut, Slotted - 3/8-16 thread (detail of 64894)
157	64894-3	Bearing, 2.001 OD x 1.377 ID x 1.19 long (detail of 64894)
158	64894-4	Spacer, Tapered - 1.0 diameter x .150 thick (detail of 64894)
159	64894-5	Shim, Laminated - 7.13 OD x 4.63 ID x .060 thick (detail of 64894)
160	64894-6	Screw, Sholder500 diameter x 1.42 long - 3/8-16 thread (detail of 64894)
161	64894-7	Nut, 3/8-24 x 2.25 long - 9/16 hex (detail of 64894)
162	64894-13	Pad, Access hole cover (detail of 64894)
163	64894-16	Screw, Sholder500 diameter x 1.72 long - 3/8-16 thread (detail of 64894)



Ref.	Tool No.	Nomenclature and Description
164	64898	Adapter, Dynafocal Mounts (Test Stand and Mounting Ring) - All engines employing 30° mounts
165	64899	Adapter, Magnetic Particle Inspection of Hydraulic Tappets - All engines except O-235, O-290-D, 76 Series, TIO-541 and TIGO-541 (Use with ST-387)
166	64900	Reamer, Valve Guide ID (Exhaust) - All valve guides with .4375/.4385 ID valve guide hole (See 64901 for Plug Gage)
167	64901	Gage, Plug Valve Guide ID (Exhaust) - All valve guides with .4375/.4385 ID valve guide hole (See 64900 for Reamer)
168	64902	Reamer, Rework High Compression Crankcase (Rough) - O-320, O-340, O-360, VO-360 and O-540 Series - To incorporate Body Fit Thru Studs (P/N 72698)
169	64903	Reamer, Rework High Compression Crankcase (Final) - O-320, O-340, O-360, VO-360 and O-540 Series - To incorporate Body Fit Thru Studs (P/N 72698)
170	64904	Counterbore, Rework High Compression Crankcase "O" Ring Recess - O-320, O-340, O-360, VO-360 and O-540 Series - To incorporate Body Fit Thru Studs (P/N 72698)
171	64905	Stop Collar, Use with 64902 and 64903 Reamers - High Compression Crankcase - O-320, O-340, O-360, VO-360, and O-540 Series - To incorporate Body Fit Thru Studs (P/N 72698)
172	64906	Plug, Bearing, High Compression Crankcase - O-320, O-340, O-360, VO-360 and O-540 Series - To incorporate Body Fit Thru Studs (P/N 72698)
173	64907	Tap, .007 o/s for 1/2 in. Thru-Stud, High Compression Crankcase, O-320, O-340, O-360, VO-360, and O-540 Series - To incorporate Body Fit Thru Studs (P/N 72698)
174	64908	Universal, Drill 1/2 in Rework High Compression Crankcase, O-320, O-340, O-360, VO-360, and O-540 Series - To incorporate Body Fit Thru Studs (P/N 72698)
175	64909	Gage, Reject Hydraulic Tappet Bodies - All engines except O-235, O-290-D, 76 Series, TIO-541 and TIGO- 541
176	64910	Spinning Tool, Crankshaft Oil Tube Replacement (Sludge Tubes) - All engines employing sludge tubes



168 - 169

















Ref.	Tool No.	Nomenclature and Description
177	64914	Tool, Remove Fuel Injector Oil Filter - IGSO-480 Series
178	64916	Stand, Overhaul - All engines - available from (B.K. Sweeney Mfg. Co., 6300 East 44 th Ave., Denver 16, Colorado)
179	64917	Adapter, Overhaul - All engines - available from (B.K. Sweeney Mfg. Co., 6300 East 44 th Ave., Denver 16, Colorado)
180	64923	Drift, Exhaust Valve Guide Installation - All engines employing 1/2 in. (Flange) exhaust valve guides
181	64925	Reamer, Valve Guide ID (Brass) (Exhaust) - Pilot dia4888/.4893, Finished ID .4985/.4995 (Not used on Ni-Resist guides) (See 64927 for Plug Gage)
182	64927	Gage, Plug, Valve Guide ID (Exhaust) - All valve guides with .4985/.4995 ID valve guide hole (See 64925 for Reamer)
183	64932	Wrench, Offset Allen, Simmonds Injector Pump Installation - IGSO-540-B
184	64933	Wrench, 1/2 in. Top Exhaust Head Manifold Removal Tool - IO-540 Series, IGO-540-B Series, IGSO-540-B Series, IO-720-B Series
185	64934	Wrench 7/16 in. Dry Vacuum Pump Installation - All engines employing 3P-194 Pesco Vacuum Pump
186	64939	Piloted Drill, Install 1/2 in. Diameter Exhaust Valve Guide - All angle head engines to be converted from 7/16 in. to 1/2 in. exhaust valves
187	64941	Tool, Remove Hydraulic Tappet Assemblies - All engines except O-235, O-290-D, 76 Series, TIO-541 and TIGO-541
188	64942	Wrench, (1/2 in. Allen) Cylinder Base Nut - All engines employing P/N 71133 Nut (See 64943 for 3/8 in. wrench)
189	64943	Wrench, (3/8 in. Allen) Cylinder Base Nut - All engines employing P/N 71134 Nut (See 64942 for 1/2 in. wrench)
190	64944	Shroud, Cooling (Updraft Exhaust) - IO-540-B Series, IGO-540-B, IGSO-540-B Series, TIO-540-A Series




12

Ref. Tool No. Nomenclature and Description 191 64945 Gage, Connecting Rod Bolt Stretch - All engines employing stretch bolts in connecting rods 192 64945-7 Dial Indicator - Detail of 64945 193 64945-9 Set Master 2.1255 Length - Detail of 64945 194 64945-10 Set Master 2.2555 Length - Detail of 64945 Gage Assembly and Set Masters - Less dial indicator 195 64945-11 196 64946 Wrench, Offset, (1-5/16 in.) Change Oil Screen in Aero Commander - IGO-540, IGSO-540 64947 Stand, Work - IGO-540, IGSO-540 197 198 64948 Swaging Tool, Intake Pipe, O-235, O-290, O, IO, AEIO-320, O-340, O-360, IO-360, HO-360 engines employing intake pipe connections P/N 61376, 61377, 62115, 70482 with 1.422/1.446 ID 199 64970 Wrench, Adjust Bendix Injector (Idle Speed) on Aero Commander - IGO-540 Series 200 64971 Gage, Check Switch and Retard Terminal Contact Springs Positions (200 Series Magnetos) - All engines employing 200 series magnetos Tool, Rework Shroud Tube Holes in Cylinder Head - All engines employing angle head valves 201 64974 202 64975 Rubber Mount, Test Stand (64765) - All six cylinder, vertical engines Puller, Gear, Magneto Assembly (P/N 60971) - All engines employing low tension magnetos 203 64976 Wrench, Special, Gears on Low Tension Magnetos (P/N 60971) - All engines employing low tension 204 64977 magnetos





Ref.	Tool No.	Nomenclature and Description
205	64979	*Adapter, Test Club - All engines with AS-127 Type 2 propeller flange with bushings for 3/8 in. propeller attaching bolts (See ST-455 for AS-127 Type 1 propeller flange)
206	64980	*Adapter, Test club - All engines with AS-127 Type 2 propeller flange with bushings for 7/16 in. propeller attaching bolts
207	64981	*Adapter, Test club - All engines with AS-127 Type 2 propeller flange with bushings for 1/2 in. propeller attaching bolts
208	64982	Bolt, Propeller 3/8-24 Drilled Hex Head - Use with Adapter 64979
209	64983	Bolt, Propeller 7/16-20 Drilled Hex Head - Use with Adapter 64980
210	64984	Bolt, Propeller 1/2-30 Drilled Hex Head - Use with Adapter 64981
211	64987	Spinner, Cylinder Base Nut - All engines employing hex head cylinder base nuts
212	64988	Club, Test - IO-720
213	64989	Adapter, Test Club - IO-720
214	64992	Gage, Feeler to Set Simmonds 580 Injector IGSO-540-B Series
215	72762	Protector, Crankshaft Propeller Nut Thread - All propeller shafts with No. 30 spline
216	ST-8	Fixture, Counterboring P/N 72572 Reduction Gear Housing Seal - IGO and IGSO-540
217	ST-9	Depth Gage, Flush Pin, Counterbore Oil Passage Holes for "O" Rings on Reduction Gear Housing P/N 72572 - IGO and IGSO-540
218	ST-10	Drill, 4 Flute Flat Bottom, Drill Reduction Gear Housing P/N 72572 for Seal - IGO and IGSO-540
219	ST-11	Stop Collar, 19/32 in. Diameter Drill Reduction Gear Housing P/N 72572 for Seal - IGO and IGSO-540

* AS-127 Type 2 propeller flange can be identified by measuring from one prop attaching bushing across the center of the crankshaft to the opposite bushing. The center to center measurement is 4-3/4 inches.




Ref.	Tool No.	Nomenclature and Description
220	ST-12	Reamer, Hollow Dowel Holes in Reduction Gear - All GO and GSO-480 engines with flange propeller shaft
221	ST-13	Reamer, Hollow Dowel Holes in Reduction Gear .005 o/s - All GO and GSO-480 engines with flange propeller shaft
222	ST-14	Reamer, Hollow Dowel Holes in Reduction Gear .010 o/s - All GO and GSO-480 engines with flange propeller shaft
223	ST-15	Reamer, Hollow Dowel Holes in Reduction Gear .020 o/s - All GO and GSO-480 engines with flange propeller shaft
224	ST-17	Drill, Jig, Drill Hole to Pin Generator Drive Shaft Bushing in P/N 68967 Accessory Housing - GO-480-B, -B1A6 and -B1E6
225	ST-19	Drill, Jig, Remove and Install Generator Drive Gear Thrust and Drive Gear Bushings P/N 69525 Accessory Housing - GO-480-B1C
226	ST-20	Fixture, Plug Type Drill, Generator Housing Assembly - GO-435 and GO-480 Series
227	ST-21	Fixture, Plug Type Drill, Generator Housing Assembly - GO-435 and GO-480 Series
228	ST-22	Tool, Crimping, Crimp Burndy Hy-Rings on Low Tension Harness
229	ST-23	Gage, Valve Clearance .028080 - All engines requiring a valve clearance between .028080
230	ST-24	Indicator, Expander, Check alignment between crankshaft bore in accessory housing and the accessory drive - GSO-480, IGSO-480 and IGSO-540 Series
231	ST-25	Compressor, Valve Spring and Bar - All engines except 76 Series and TIO-541 Series (See ST-266 and ST-419)
232	ST-26	Gage, Plug, Valve Guide ID (Exhaust) - All valve guides with .437/.438 ID valve guide hole (See ST-27 for Reamer)
233	ST-27	Reamer, Valve Guide ID (Exhaust) - All valve guides with .437/.438 ID valve guide hole (See ST-26 for Plug Gage)
234	ST-28	Fixture, Drill Jig used to convert carburetor cylinders to fuel injection cylinders - All O-360, O-540 cylinders which are to be converted to IO-360, IO-540
235	ST-29	Wrench, Injector Fuel Flow Adjustment (Simmonds No. 580 Injector) - IGSO-540-B1A
226	ST 20	Wranch Injector Fuel Flow Adjustment (Simmends No. 580 Injector) ICSO 540 P1A






- Ref. Tool No. Nomenclature and Description
- 237 ST-37 Gage, Counterweight Clearance in Crankcase All VO-540 engines employing counterweights
- 238 ST-38 Wrench, Crankshaft No. 30 Spline All propeller shafts employing No. 30 spline
- 239 ST-39 Fixture, Insert Oil Seal in Thrust Bearing Cap All geared engines
- 240 ST-40 Fixture, Drill Four Holes in Crankshaft Oil Seal Retainer All direct drive engines with crankcase front main bearing bore 2.566/2.567 diameter - This fixture can be used only when engine is disassembled
- 241 ST-43 Stand, Engine Test VO-360 and IVO-360
- 242 ST-44 Drift, Install Rear Crankshaft Oil Tube All engines with crosswise accessory housing employing crankshafts with rear crankshaft oil tube (P/N 69843)
- 243 ST-45 Shroud, Cooling VO-360 and IVO-360
- 244 ST-46 Drift, Install Crankshaft Oil Plug O-540, IO-540 and TIO-540 (Plug size 1.380/1.382 P/N 71640)
- 245 ST-47 Plate, Engine Mounting VO-435, TVO-435, VO-540, IVO-540 and TIVO-540 Series
- 246 ST-48 Eye, Lifting All vertical engines
- 247 ST-49 Puller, Valve Guide All engines
- 248 ST-49-4 Hex Head Cap Screw, Valve Guide Puller (Detail of ST-49) All engines
- 249 ST-50-1 Cutter, Valve Seat (Intake) (.010 o/s) All cylinder heads with 2.307 valve seat hole
- 250 ST-50-2 Cutter, Valve Seat (Intake) (.020 o/s) All cylinder heads with 2.307 valve seat hole
- 251 ST-50-3 Cutter, Valve Seat (Intake) (.030 o/s) All cylinder heads with 2.307 valve seat hole




Ref.	Tool No.	Nomenclature and Description
252	ST-51-1	Cutter, Valve Seat (Intake) (.010 o/s) - All cylinder heads with 2.281 valve seat hole
253	ST-51-2	Cutter, Valve Seat (Intake) (.020 o/s) - All cylinder heads with 2.281 valve seat hole
254	ST-51-3	Cutter, Valve Seat (Intake) (.030 o/s) - All cylinder heads with 2.281 valve seat hole
255	ST-52-1	Cutter, Valve Seat (Exhaust) (.010 o/s) - All cylinder heads with 1.734 valve seat hole
256	ST-52-2	Cutter, Valve Seat (Exhaust) (.020 o/s) - All cylinder heads with 1.734 valve seat hole
257	ST-52-3	Cutter, Valve Seat (Exhaust) (.030 o/s) - All cylinder heads with 1.734 valve seat hole
258	ST-53-1	Cutter, Valve Seat (Intake) (.010 o/s) - All cylinder heads with 2.074 valve seat hole
259	ST-53-2	Cutter, Valve Seat (Intake) (.020 o/s) - All cylinder heads with 2.074 valve seat hole
260	ST-53-3	Cutter, Valve Seat (Intake) (.030 o/s) - All cylinder heads with 2.074 valve seat hole
261	ST-54-1	Cutter, Valve Seat (Exhaust) (.010 o/s) - All cylinder heads with 1.927 valve seat hole
262	ST-54-2	Cutter, Valve Seat (Exhaust) (.020 o/s) - All cylinder heads with 1.927 valve seat hole
263	ST-54-3	Cutter, Valve Seat (Exhaust) (.030 o/s) - All cylinder heads with 1.927 valve seat hole
264	ST-55-1	Cutter, Valve Seat (Intake) (.010 o/s) - All cylinder heads with 2.160 valve seat hole
265	ST-55-2	Cutter, Valve Seat (Intake) (.020 o/s) - All cylinder heads with 2.160 valve seat hole
266	ST-55-3	Cutter, Valve Seat (Intake) (.030 o/s) - All cylinder heads with 2.160 valve seat hole
267	ST-56-1	Cutter, Valve Seat (Intake) (.010 o/s) - All cylinder heads with 1.919 valve seat hole
268	ST-56-2	Cutter, Valve Seat (Intake) (.020 o/s) - All cylinder heads with 1.919 valve seat hole
269	ST-56-3	Cutter, Valve Seat (Intake) (.030 o/s) - All cylinder heads with 1.919 valve seat hole
270	ST-57-1	Cutter, Valve Seat (Intake) (.010 o/s) - All cylinder heads with 2.0885 valve seat hole
271	ST-57-2	Cutter, Valve Seat (Intake) (.020 o/s) - All cylinder heads with 2.0885 valve seat hole
272	ST-57-3	Cutter, Valve Seat (Intake) (.030 o/s) - All cylinder heads with 2.0885 valve seat hole
273	ST-58-1	Cutter, Valve Seat (Exhaust) (.010 o/s) - All cylinder heads with 1.995 valve seat hole
274	ST-58-2	Cutter, Valve Seat (Exhaust) (.020 o/s) - All cylinder heads with 1.995 valve seat hole
275	ST-58-3	Cutter, Valve Seat (Exhaust) (.030 o/s) - All cylinder heads with 1.995 valve seat hole
276	ST-62	Driver, Special Length for Use with Valve Seat Cutters - All cutters in ST series only
277	ST-63	Adapter, Hand Drive - Use with ST-62 Driver
278	ST-64	Drift, Valve Seat Replacement - All valve seats with dimensions between 1.870 and 2.040 ID
279	ST-65	Drift, Valve Seat Replacement - All valve seats with dimensions between 1.575 and 1.710 ID

252 THRU 269 270 THRU 275 270 THRU 275


Ref.	Tool No.	Nomenclature and Description
280	ST-66	Pilot, Valve Seat Cutter (Standard) - All cylinder heads with .5913 valve guide hole
281	ST-66-1	Pilot, Valve Seat Cutter (.010 o/s) - All cylinder heads with .5913 valve guide hole
282	ST-66-2	Pilot, Valve Seat Cutter (.020 o/s) - All cylinder heads with .5913 valve guide hole
283	ST-66-3	Pilot, Valve Seat Cutter (.030 o/s) - All cylinder heads with .5913 valve guide hole
284	ST-66-4	Pilot, Valve Seat Cutter (.040 o/s) - All cylinder heads with .5913 valve guide hole
285	ST-66-5	Pilot, Valve Seat Cutter (.005 o/s) - All cylinder heads with .5913 valve guide hole
286	ST-67	Pilot, Valve Seat Cutter (Standard) - All cylinder heads with .6613 valve guide hole
287	ST-67-1	Pilot, Valve Seat Cutter (.010 o/s) - All cylinder heads with .6613 valve guide hole
288	ST-67-2	Pilot, Valve Seat Cutter (.020 o/s) - All cylinder heads with .6613 valve guide hole
289	ST-67-3	Pilot, Valve Seat Cutter (.030 o/s) - All cylinder heads with .6613 valve guide hole
290	ST-67-4	Pilot, Valve Seat Cutter (.040 o/s) - All cylinder heads with .6613 valve guide hole
291	ST-67-5	Pilot, Valve Seat Cutter (.005 o/s) - All cylinder heads with .6613 valve guide hole
292	ST-68	Pilot, Valve Seat Cutter (Standard) - All cylinder heads with .6247 valve guide hole
293	ST-68-1	Pilot, Valve Seat Cutter (.010 o/s) - All cylinder heads with . 6247 valve guide hole
294	ST-68-2	Pilot, Valve Seat Cutter (.020 o/s) - All cylinder heads with . 6247 valve guide hole
295	ST-68-3	Pilot, Valve Seat Cutter (.030 o/s) - All cylinder heads with . 6247 valve guide hole
296	ST-68-4	Pilot, Valve Seat Cutter (.040 o/s) - All cylinder heads with . 6247 valve guide hole
297	ST-68-5	Pilot, Valve Seat Cutter (.005 o/s) - All cylinder heads with . 6247 valve guide hole
298	ST-71	Gage Check Bell-Mouthing of Exhaust Valve Guides - All parallel valve engines (See ST-310 for Angle Valve)
299	ST-71-8	Adapter (Post), Check Bell-Mouthing of 1/2 in. Exhaust Valve Guides - All parallel valve engines (Detail of ST-71)
300	ST-73	Gage, Counterweight Dial Bore (.7485/.7505 ID of Bushings) Replace Bushings in Counterweights - All engines equipped with counterweights employing bushings except counterweight P/N 77002
301	ST-78	Tool, Crimping Connecting Rod Nut and Ring Gear Plate Nut - All engines using crimp nuts
302	ST-79	Wrench, (Spanner) To Hold Magneto Gear - All four cylinder engines
303	ST-80	Socket, (Special) (1-5/16 in.) Remove Oil Pressure Screen - IGSO-540 Series
304	ST-81	Gage, Flat Plug Rejection (Intake Valve Guide ID) - All engines
305	ST-83	Wrench, Break Loose Cylinder Base Nuts - All engines employing 1/2 in. Allen head cylinder base nuts (P/N 71133)
306	ST-84	Wrench, Break Loose Cylinder Base Nuts - All engines employing 3/8 in. Allen head cylinder base nuts (P/N 71134)




Ref.	Tool No.	Nomenclature and Description
307	ST-86	Protector, Thread No. 20 Spline Shaft - This tool must be used when changing propeller in order to keep from damaging propeller shaft threads
308	ST-87	Protector, Thread No. 30 Spline Shaft - This tool must be used when changing propeller in order to keep from damaging propeller shaft threads
309	ST-88	Adapter, Dynafocal Mounts - All engines employing 18° mounts
310	ST-89	Gage, Plug Valve Guide OD (Exhaust) (Standard) - All valve guides with .6247/.6257 valve guide hole in cylinder head
311	ST-89-1	Gage, Plug Valve Guide OD (Exhaust) (.010 o/s) - All valve guides with .6247/.6257 valve guide hole in cylinder head
312	ST-89-2	Gage, Plug Valve Guide OD (Exhaust) (.020 o/s) - All valve guides with .6247/.6257 valve guide hole in cylinder head
313	ST-89-3	Gage, Plug Valve Guide OD (Exhaust) (.030 o/s) - All valve guides with .6247/.6257 valve guide hole in cylinder head
314	ST-89-4	Gage, Plug Valve Guide OD (Exhaust) (.040 o/s) - All valve guides with .6247/.6257 valve guide hole in cylinder head
315	ST-89-5	Gage, Plug Valve Guide OD (Exhaust) (.005 o/s) - All valve guides with .6247/.6257 valve guide hole in cylinder head
316	ST-90-1	Reamer, Valve Guide OD (Exhaust) (.010 o/s) - All valve guides with .6247/.6257 valve guide hole in cylinder head
317	ST-90-2	Reamer, Valve Guide OD (Exhaust) (.020 o/s) - All valve guides with .6247/.6257 valve guide hole in cylinder head
318	ST-90-3	Reamer, Valve Guide OD (Exhaust) (.030 o/s) - All valve guides with .6247/.6257 valve guide hole in cylinder head
319	ST-90-4	Reamer, Valve Guide OD (Exhaust) (.040 o/s) - All valve guides with .6247/.6257 valve guide hole in cylinder head
320	ST-90-5	Reamer, Valve Guide OD (Exhaust) (.005 o/s) - All valve guides with .6247/.6257 valve guide hole in cylinder head
321	ST-9 1	Gage, Counterweight Squareness (Check Parallel and Squareness of Finished Inside Diameter of Bushing Hole) - All engines equipped with counterweights employing bushings except Counterweight P/N 77002
322	ST-92	Driver, Counterweight Bushing (Remove and Install Bushings) - All engines equipped with counterweights employing bushings except Counterweight P/N 77002
323	ST-93	Fixture Assembly, Counterweight (Install Bushings in Counterweights) - All engines equipped with counterweights employing bushings except Counterweight P/N 77002
324	ST-93-3	Spacer, Control Depth of Bushing370 thick (detail of ST-93)
325	ST-93-5	Spacer, Control Depth of Bushing440 thick (detail of ST-93)




Ref.	Tool No.	Nomenclature and Description
326	ST-94	Gage, Counterweight Bushing Location (Check Hole Location After Grinding) - All engines equipped with counterweights employing bushings except Counterweight P/N 77002
327	ST-95	Weight, Counterweight Balancing (.004 pound - Check Balance of Counterweight after Rebushing) - All engines equipped with counterweights employing bushings except Counterweight P/N 77002
328	ST-96	Arbor, Counterweight Balancing (Check Balance of Counterweights after Rebushing) - All engines equipped with counterweights employing bushings except Counterweight P/N 77002
329	ST-104	Wrench, Install and Remove Weatherhead Fittings - All engines with crosswise accessory housings
330	ST-105	Fixture, Drill Four Holes for Crankshaft - Oil Seal Retainer - All direct drive engines with a 2.375 Crankshaft
		seal diameter - This fixture can be used only when the engine is assembled.
331	ST-107	Wrench, Front Oil Plug - Remove and replace front oil plug (controllable pitch propeller)
332	ST-108	Wrench, Offset to Torque Nuts on Reduction Gear Housing - All geared engines except TIGO-541
333	ST-112	Back Spotfacer, Pilot and Driver - Modify all flanged reduction gear housings for use of body fit bolts
334	ST-113-1	Reamer, Valve Guide ID Exhaust (Ni-Resist) Pilot Dia4828/.4833 - Finished ID .4985/.4995 for large ID valve guide replacement (See 64927 for Plug Gage)
335	ST-113-2	Reamer, Valve Guide ID Exhaust (Ni-Resist) Pilot Dia4778/.4783 - Finished ID .4985/.4995 for small ID valve guide replacement (See 64927 for Plug Gage)
336	ST-114	Shroud, Cooling - IO-720-B1A - Up Draft Exhaust
337	ST-115	Tool, Install and Remove Propeller Flange Bushings - All flanged propeller shafts employing bushings



Ref.	Tool No.	Nomenclature and Description
338	ST-122	Plate, Crankcase - Separates and draws together doweled crankcase halves - All engines employing crankcase thru stud dowels
339	ST-122-2	Stud, Crankcase Plate - (Detail of ST-122)
340	ST-122-3	Nut, (Detail of ST-122)
341	ST-122-4	Washer, (Detail of ST-122)
342	ST-123	Plate, Bushing (Crankcase) - Drill and ream crankcase for standard thru stud dowels - All engines to employ crankcase standard thru stud dowels, except large cylinder base flange crankcases (See ST-270)
343	ST-124	Drill, Crankcase (Standard) - Thru Stud Dowel - All engines to employ crankcase standard thru stud dowels
344	ST-125	Reamer, Crankcase (Standard) - Thru Stud Dowel - All engines to employ crankcase standard thru stud dowels
345	ST-126	Gage, Plug and Depth (Standard) - Crankcase - Thru Stud Dowel - All engines to employ crankcase standard thru stud dowels
346	ST-128	Shroud, Cooling - IO-720-A1A (Down Draft Exhaust)
347	ST-129	Sleeve, This tool is used to install AiResearch Piston (P/N 475515) into bypass cylinder - All T-1108 and T- 1112 turbochargers
348	ST-131	Gage - Belt, Tension Dial - All direct drive engines
349	ST-133	Fixture - Holding Turbocharger - All T-1108 and T-1112 turbochargers - Use with ST-135
350	ST-134	Wrench, Turbocharger - Wrench is used to remove back plate nut after it has been drilled and cracked - All T-1108 and T-1112 turbochargers
351	ST-135	Drill, Plate, Turbocharger - Drill plate is used to drill back plate nut in order that it may be cracked with a chisel. Use drill plate with holding fixture ST-133 - All T-1108 and T-1112 turbochargers
352	ST-136	Gage, Special Turbocharger (This gage is used for checking radial bearing play.) - All T-1108 and T-1112 turbochargers




Ref.	Tool No.	Nomenclature and Description
353	ST-138	Gage, Block, Turbocharger - This block is used to set up vernier height gage and oval indicator to measure impeller tip height - All T-1108 and T-1112 turbochargers
354	ST-139	Jig, Welding Single Butterfly Exhaust Bypass Valve - All turbochargers single butterfly exhaust bypass valve
355	ST-140	Gage, Plug - Exhaust Bypass Valve (Wire Type for size up to .125 dia.) - This is the clearance between the butterfly and the housing in the closed position - All turbocharger exhaust bypass valves
356	ST-141	Gage, Plug, Double Exhaust Bypass Valve - This is the clearance between the butterfly and the housing in the open position - All turbocharger exhaust bypass valves used on TIO-541 engines
357	ST-142	Wrench, Shroud Tube - All engines employing lock type shroud tubes
358	ST-143-1	Reamer, Valve Guide ID Exhaust (Ni-Resist) - Pilot Dia4828/.4833 - Finished ID .4995/.5005 for large ID valve guide replacement (See ST-155 for Plug Gage)
359	ST-143-2	Reamer, Valve Guide ID Exhaust (Ni-Resist) - Pilot Dia4778/.4783 - Finished ID .4995/.5005 for small ID valve guide replacement (See ST-155 for Plug Gage)
360	ST-144	Fixture, Salvage Fretted Crankcase - Used on four and six cylinder engines with conventional crankcases. Use this tool with ST-145 and ST-146. (See ST-252 for crankcases with large cylinder base flanges)
361	ST-145	Cutter, Salvage Fretted Crankcase (Conventional) - See ST-144, ST-269
362	ST-146	Holder, Stop Collar, Salvage Crankcase - See ST-144 and ST-252
363	ST-147-1	Balls, Sizing - Pinion Cage, Balls are used to burnish pinion shaft holes to proper size - All standard
	ST-147-2	reduction gears (Tools ST-148, ST-149, ST-150 are used in conjunction with this tool) - All engines with standard planetary reduction gears
364	ST-148	Spacer, Adjustable, Pinion Cage - Spacer is used inside of pinion cage to keep it from collapsing when sizing balls are pushed thru pinion cage - All engines with planetary reduction gears




Ref.	Tool No.	Nomenclature and Description
365	ST-149	Fixture, Location and Reaming Pinion Cage Gage was designed to keep pinion shaft holes in alignment with fixture - All engines with planetary reduction gears
366	ST-149-9	Pin, Locating (Detail of ST-149)
367	ST-150-1	Reamer, Piloted Pinion Cage (.011 in. o/s) - To keep pinion shaft holes in alignment with fixture ST-149. (ST-147, ST-148, ST-149 and are used in conjunction with this tool)
368	ST-150-2	Reamer, Piloted Pinion Cage (.022 in. o/s) - To keep pinion shaft holes in alignment with fixture ST-149. (ST-147, ST-148, ST-149 and are used in conjunction with this tool)
369	ST-155	Gage, Plug, Valve Guide ID (Exhaust) - All cylinder heads with .4995/.5005 ID valve guide hole (See ST-143-1 or ST-143-2 for Reamer)
370	ST-156	Stop, Drill and Reamer - All engines to employ crankcase thru-stud dowels (Tools ST-124 and ST-125 are used in conjunction with this tool)
371	ST-158	Puller ("V" Pulley) Generator and Alternator - All direct drive engines except O-145 and O-435 Series
372	ST-160	Pilot Bar, Assembling Rocker Arms to Cylinder Head - All engines except 76 Series
373	ST-161	Ring, Engine Counting - TIO-541 and TIGO-541
374	ST-162	Stand (Engine), - A-Frame, Overhaul - All engines


- 374ST-162Stand (Engine), A-Frame, Overhaul All engines375ST-163Wrench, Remove Exhaust Pipe Flange (7/16 in.) TIO-541 and TIGO-541 (See ST-213 for 1/2 in.)
- 376 ST-164 Shroud, Cooling TIO-541
- 377 ST-165 Adapter, Engine Overhaul Assembly All direct drive engines (Use with ST-278 overhaul A-frame skid)




Ref.	Tool No.	Nomenclature and Description
378	ST-168	Driver, (Special Assembly) Crankshaft rear spline bushing - All engines with crosswise accessory housings
379	ST-169	Fixture, Drill, Crankshaft Rear Bushing - All engines with crosswise accessory housings
380	ST-170	Drift, Crankshaft Rear Spline Bushing Dowel - All engines with crosswise accessory housings
381	ST-171	Tool, Peening, Crankshaft Rear Spline Bushing Dowel - All engines with crosswise accessory housings
382	ST-172	Puller Set - Oil Seal - All engines (Use with 64782 Slide Hammer)
383	ST-172-5	For Use With STD-547 Seal (Detail of ST-172)
384	ST-172-6	For Use With STD-911 Seal (Detail of ST-172)
385	ST-172-7	For Use with STD-2217 and STD-208 Seals (Detail of ST-172)
386	ST-172-8	For Use With STD-213 Seal (Detail of ST-172)
387	ST-172-9	For Use With LW-14260 and 61165 Seals (Detail of ST-172)
388	ST-172-10	For Use With STD-1708 Seal (Detail of ST-172)
389	ST-173	Holder, Accessory Drive Shaft - All crosswise accessory housings employing thirteen spline accessory drive shaft assemblies
390	ST-174	Holder, Accessory Drive Shaft - All crosswise accessory housings employing fourteen spline accessory drive shaft assemblies
391	ST-177	Wrench, Turbocharger Impeller - All T-1108 and T-1112 turbochargers
392	ST-179	Fixture, Reaming Valve Guide Hole in Cylinder Head - All parallel valve engines converting from 7/16 in. exhaust valves to 1/2 in. (Tools ST-180, ST-181 and ST-199 are used in conjunction with this tool)
393	ST-179-2	Bushing, Reaming Valve Guide Hole in Cylinder Head Fixture (Detail of ST-179)
394	ST-179-3	Pin, Locating - Reaming Valve Guide Hole in Cylinder Head Fixture (Detail of ST-179)
395	ST-180	Reamer, Rework Valve Guide Hole in Cylinder Head - All parallel valve engines converting 7/16 in. exhaust valves to 1/2 in. (Tools ST-179, ST-181 and ST-199 are used in conjunction with this tool



Ref.	Tool No.	Nomenclature and Description
396	ST-181-1	 Reamer, Valve Guide ID Exhaust (Ni-Resist) - All parallel valve engines employing 1/2 in. exhaust valves Pilot dia4828/.4833 - Finished ID .4985/.4995 - For large ID valve guide replacement (Tools ST- 179, ST-180 and ST-199 are used in conjunction with this tool) (See 64927 for Plug Gage)
397	ST-181-2	 Reamer, Valve Guide ID Exhaust (Ni-Resist) - All parallel valve engines employing 1/2 in. exhaust valves Pilot dia4778/.4783 - Finished ID .4985/.4995 - For small ID valve guide replacement (Tools ST- 179, ST-180 and ST-199 are used in conjunction with this tool) (See 64927 for Plug Gage)
398	ST-184	Kit, Heli-Coil Repair - All engines
399	ST-190-2	Socket, Injector Nozzle - All TIO-541 and TIGO-541 engines
400	ST-191	Gage, Plug, .010 o/s, Rocker Shaft Bushing Hole in Cylinder Head - All engines except 76 Series - See 64811 for .005 o/s
401	ST-198	Tool, Crimping (Grounded Sheath) Crimp ends on (5MM) harness (See 64861 for 7MM)
402	ST-199	Counterbore, Rework Parallel Valve Cylinder Heads in Exhaust Valve Guide Flange Area - All parallel valve engines converting from 7/16 in. to 1/2 in. (flange) exhaust valves (Tools ST-179, ST-180 and ST-181 are used in conjunction with this tool
403	ST-210	Reamer, .0075 in. o/s Counterweight Bushing Holes - All engines equipped with counterweights
404	ST-211	Reamer, .0125 in. o/s Counterweight Bushing Holes - All engines equipped with counterweights
405	ST-212	Gage Blocks, Crankshaft Counterweight Bushing - To check parallelism of counterweight bushing to crankshaft - All engines equipped with counterweights
406	ST-213	Wrench, Remove Exhaust Pipe Flange (1/2 in.) - TIO-541 and TIGO-541 (See ST-163 for 7/16 in.)
407	ST-215	Driver, Sleeve, Oil Pressure Relief Valve - All direct drive engines except 76 Series and adjustable valves. (See ST-249 for driver used on adjustable valves)
408	ST-220	Sling, Engine Lifting - TIO-541 and TIGO-541
409	ST-222	Plate, Torque Hold-Down - All engines except O-235 Series
410	ST-222-2	Insert Torque Hold-Down Plate (Detail of ST-222)




- Ref. Tool No. Nomenclature and Description
- 411 ST-223 Swaging Tool, Turbocharger Exhaust Pipes All turbocharger exhaust pipes used on Lycoming engines
- 412 ST-226 Gage, Intake Pipe Bore Salvage (Determine necessity for salvage) IO, HIO, TIO and LTIO-540 tuned induction
- 413 ST-227 Fixture, Intake Pipe Bore Salvage (Mount housing and fixture to radial drill press) IO, HIO, TIO and LTIO-540 tuned induction
- 414 ST-228 Counterbore, Intake Pipe Bore Salvage IO, HIO, TIO and LTIO-540 tuned induction
- 415 ST-229 Pilot, Counterbore, Intake Pipe Bore Salvage IO, HIO, TIO and LTIO-540 tuned induction
- 416 ST-230 Drift, Bushing Installation, Intake Pipe Bore Salvage IO, HIO, TIO and LTIO-540 tuned induction
- 417 ST-231 Reamer, .088 .089 Pin, Intake Pipe Bore Salvage IO, HIO, TIO and LTIO-540 tuned induction
- 418 ST-232 Fixture, Valve Seat Replacement and Refacing All cylinder assemblies employing angle head valves
- 419 ST-233 Fixture, Disassemble and Assemble Hydraulic Lifters 76 Series, TIO-541 and TIGO-541
- 420 ST-234 Drift, Crankshaft, Front Plug (OD Diameter 2.010/2.011) (P/N 77416)
- 421 ST-235 Wrench, Engine Timing (Starter Gear) VO-435-B1A, TVO-435-F1A
- 422 ST-236 Arbor, Connecting Rod Slave Bolts All connecting rods with a bore diameter of 2.4205/2.4210
- 423 ST-237 Arbor, Connecting Rod Slave Bolts All connecting rods with a bore diameter of 2.2870/2.2875
- 424 ST-239 Kit, Engine Overhaul Ring Mounting (Use with ring ST-161) TIO-541 and TIGO-541




422 - 423

Ref.	Tool No.	Nomenclature and Description
425	ST-240	Adapter, Engine Overhaul Assembly (Use with skid ST-278, overhaul stand ST-162 and ST-161 ring) - TIGO-541
426	ST-241	Club, Test (Used with adapter ST-242) - TIGO-541
427	ST-242	Adapter, Test Club - TIGO-541
		NOTE: The following tools, ST-243, ST-244, ST-245, ST-246, ST-248 and ST-249 are used to modify the crankcase for use of adjustable oil pressure relief valve. See latest revision of Service Instruction No. 1172
428	ST-243	Bushing, Pilot, Oil Relief Valve (.001 o/s) - All direct drive engines
429	ST-244	Reamer, Oil Relief Valve (.001 o/s) - All direct drive engines
430	ST-245	Bushing, Pilot, Oil Relief Valve (.004 o/s) - All direct drive engines
431	ST-246	Reamer, Oil Relief Valve (.004 o/s) - All direct drive engines
432	ST-248	Countersink, Oil Relief Valve (.001 and .004 o/s) - All direct drive engines (Use with Pilot ST-245)
433	ST-249	Driver, Oil Relief Valve (.001 and .004 o/s) - All direct drive engines
434	ST-250	Fixture, Valve Seat Replacement and Refacing - All cylinder assemblies employing parallel valves
435	ST-251	Socket, Connecting Rod Nut - All engines
436	ST-252	Fixture, Salvage Fretted Crankcases - Used on four cylinder engines with large cylinder base flange
		crankcases. Use this tool with ST-269 and ST-146. (See ST-144 for conventional crankcases)
437	ST-253	Driver, Intake Pipe Bore Salvage - IO, HIO, TIO and LTIO-540 Tuned Induction (Tools ST-226, ST-227, ST-228, ST-229, ST-230 and ST-231 are used in conjunction with this tool)
438	ST-254	Reamer, Crankshaft Flange010 o/s Bolt (Use with ST-256 Fixture) - All geared engines
439	ST-255	Reamer, Crankshaft Flange010 o/s Bolt (Use with ST-256 Fixture) - All six cylinder vertical engines




Ref.	Tool No.	Nomenclature and Description
440	ST-256	Fixture, Crankshaft Flange (.010 o/s Bolt) Use with ST-254 and ST-255 Reamers - All geared and six cylinder vertical engines
441	ST-257	Pilot, Valve Seat Cutter (Standard) - All cylinder heads with .6933 valve guide hole
442	ST-257-1	Pilot, Valve Seat Cutter (.010 o/s) - All cylinder heads with .6933 valve guide hole
443	ST-257-2	Pilot, Valve Seat Cutter (.020 o/s) - All cylinder heads with .6933 valve guide hole
444	ST-257-3	Pilot, Valve Seat Cutter (.030 o/s) - All cylinder heads with .6933 valve guide hole
445	ST-257-4	Pilot, Valve Seat Cutter (.040 o/s) - All cylinder heads with .6933 valve guide hole
446	ST-257-5	Pilot, Valve Seat Cutter (.005 o/s) - All cylinder heads with .6933 valve guide hole
447	ST-258-1	Reamer, Valve Guide OD (Exhaust) (.010 o/s) - All valve guides with .6933/.6943 valve guide hole in cylinder head
448	ST-258-2	Reamer, Valve Guide OD (Exhaust) (.020 o/s) - All valve guides with .6933/.6943 valve guide hole in cylinder head
449	ST-258-3	Reamer, Valve Guide OD (Exhaust) (.030 o/s) - All valve guides with .6933/.6943 valve guide hole in cylinder head
450	ST-258-4	Reamer, Valve Guide OD (Exhaust) (.040 o/s) - All valve guides with .6933/.6943 valve guide hole in cylinder head
451	ST-258-5	Reamer, Valve Guide OD (Exhaust) (.005 o/s) - All valve guides with .6933/.6943 valve guide hole in cylinder head
452	ST-259	Gage, Plug, Valve guide OD (Exhaust) (Standard) - All valve guides with .6933/.6943 valve guide hole in cylinder head
453	ST-259-1	Gage, Plug, Valve guide OD (Exhaust) (.010) - All valve guides with .6933/.6943 valve guide hole in cylinder head
454	ST-259-2	Gage, Plug, Valve guide OD (Exhaust) (.020) - All valve guides with .6933/.6943 valve guide hole in cylinder head
455	ST-259-3	Gage, Plug, Valve guide OD (Exhaust) (.030) - All valve guides with .6933/.6943 valve guide hole in cylinder head
456	ST-259-4	Gage, Plug, Valve guide OD (Exhaust) (.040) - All valve guides with .6933/.6943 valve guide hole in cylinder head
457	ST-259-5	Gage, Plug, Valve guide OD (Exhaust) (.005) - All valve guides with .6933/.6943 valve guide hole in cylinder head
458	ST-260	Tool, Density Controller Adjusting - All engines employing a slotted head density controller adjustment screw
459	ST-264-B	Probe, Thermocouple Deck Temperature - 3/8-16 NC-3 thread
460	ST-264-C	Probe, Thermocouple Deck Temperature - 7/16-20 NC-3 thread
161	CT 265	E trading The man all Line its CT OCA D CT OCA C

461 ST-265 Extension, Thermocouple - Use with ST-264-B, ST-264-C




Ref.	Tool No.	Nomenclature and Description
462	ST-266	Compressor, Valve Spring and Bar - TIO-541-E Series, TIGO-541-E Series (See ST-25 and ST-419)
463	ST-267	Reamer, Valve Guide ID (Ni-Resist) Pilot dia4778/.4783 - Finished ID .4980. This reamer is used only when valve guide is to be honed to size after reaming.
464	ST-269	Cutter, Salvage Fretted Crankcase "Conventional and Large Cylinder Base Flange Crankcases" - See ST-252
465	ST-270	Plate, Bushing (Crankcase) - Drill and ream crankcase for standard thru-stud dowels - All wide cylinder base flange crankcase (See ST-123 for conventional crankcases)
466	ST-271	Puller, Crankcase Thru-Stud - All engines employing drive thru-studs
467	ST-272	Ring, Engine Mounting - TIO-540 except -C1A, -E1A, G1A, H1A and V2AD (Use with ST-278 and ST-162)
		NOTE: The following tools, ST-273, ST-274, ST-275, ST-276 and ST-277 are used to modify the intake pipe bore in oil sump. See latest edition of Service Instruction No. 1168
468	ST-273	Countersink, Intake Pipe Bore - IO, AEIO, HIO, LIO and LHIO-360 engines employing large cylinder base flanges
469	ST-274	Counterbore, Intake Pipe Bore - IO, AEIO, HIO, LIO and LHIO-360 engines employing large cylinder base flanges
470	ST-275	Driver, Counterbore, Intake Pipe Bore - IO, AEIO, HIO, LIO and LHIO-360 engines employing large cylinder base flanges
471	ST-276	Drift, Bushing Installation, Intake Pipe Bore - IO, AEIO, HIO, LIO and LHIO-360 engines employing large cylinder base flanges
472	ST-277	Fixture, Intake Pipe Bore - IO, AEIO, HIO, LIO and LHIO-360 engines employing large cylinder base




Ref.	Tool No.	Nomenclature and Description
473	ST-278	Skid (Engine A-Frame Overhaul) - All engines (Use with ST-162)
474	ST-279	Gage, Valve Clearance - All engines requiring a valve clearance between .040105
475	ST-280	Fixture, Ream Crankshaft Counterweight - All engines equipped with counterweights
476	ST-280-3	Plug, Standard Crankshaft Counterweight - For .9369/.9377 hole - Plug may be used with fixture 64873 or ST-280
477	ST-280-7	Plug .005 o/s Crankshaft Counterweight - For .9420/.9425 hole - Plug may be used with fixture 64873 or ST-280
478	ST-280-8	Plug .010 o/s Crankshaft Counterweight - For .9470/.9475 hole - Plug may be used with fixture 64873 or ST-280
479	ST-280-9	Plug .0015 o/s Crankshaft Counterweight - For .9520/.9525 hole - Plug may be used with fixture 64873 or ST-280
480	ST-280-10	Plug .0075 o/s Crankshaft Counterweight - For .9445/.9450 hole - Plug may be used with fixture 64873 or ST-280
481	ST-280-11	Plug .0125 o/s Crankshaft Counterweight - For .9495/.9500 hole - Plug may be used with fixture 64873 or ST-280
482	ST-283	Wrench, Differential Pressure Controller Adjusting - All turbochargers employing differential pressure controllers
483	ST-284	Tool, Differential Pressure Controller Lock - All turbochargers employing differential pressure controllers
484	ST-285	Ring, Engine Mounting - TIO-360 (Use with ST-278 and ST-162)
485	ST-286	Ring, Engine Mounting - TIO-540-C1A and 6 cylinder direct drive engines without turbocharging (Use with ST-278, ST-162, ST-165)
486	ST-287	Ring, Engine Mounting - TIO-720-A (Use with ST-278 and ST-162)
487	ST-288	Socket, Spark Plug Wrench 7/8 in. hex - All engines
488	ST-289	Swaging Tool, Intake Pipe - IO, TIO, HIO, LTIO-540 engines employing intake pipe connections P/N 72167, 72168, 72169 and IO-720 engines employing intake pipe connections P/N 75121, 75123, 75125 with 1.542/1.568 ID


489 ST-291 Driver, Main Bearing Straight Dowel - All engines employing straight main bearing dowels



Ref.	Tool No.	Nomenclature and Description
490	ST-295	Drift, Crankshaft, Oil Plug - IO, HIO, AIO, TO, TIO, LIO-360; O, TIO, LTIO-540; TIO-541 and IO-720 (plug size 1.251/1.254)
491	ST-297	Club, Test (Left hand rotation) LIO-320
492	ST-298	Club, Test (Left hand rotation) LIO-360
493	ST-299-1	Reamer, Piloted Pinion Cage (.011 o/s) - To keep pinion shaft holes in alignment with fixture ST-149 (ST-148, ST-149 and ST-300-1 are used in conjunction with this tool)
494	ST-299-2	Reamer, Piloted Pinion Cage (.022 o/s) - To keep pinion shaft holes in alignment with fixture ST-149 (ST-148, ST-149 and ST-300-2 are used in conjunction with this tool)
495	ST-299-3	Reamer, Piloted Pinion Cage (.033 o/s) - To keep pinion shaft holes in alignment with fixture ST-149 (ST-148, ST-149 and ST-300-3 are used in conjunction with this tool)
496	ST-300-1	Balls, Sizing - Pinion Cage, (-1, .011 o/s, -2, .022 o/s, -3, .033 o/s) balls are used to burnish pinion shaft
	ST-300-2	holes to proper size - all heavy duty reduction gears (Tools ST-148, ST-149, ST-299 are used in
	ST-300-3	conjunction with this tool) - All engines with heavy duty planetary reduction gears
497	ST-301	Tool, Crimping - Crimp spark plug wire terminal on 5MM ignition harness having 5/8-24 nut
498	ST-302	Drift, Valve Guide Installation (Intake and Exhaust) - All angle head engines employing flangeless valve guides
499	ST-303	Drift, Valve Guide Installation (Exhaust) - All parallel head engines employing flangeless exhaust valve guides
500	ST-304	Drift, Valve Guide Installation (Intake) - All parallel head engines employing flangeless intake valve guides
501	ST-305	Driver, Bearing Dowel (Straight and Stepped) - All crankcases with 2.9370 bearing bore diameter
502	ST-306	Driver, Bearing Dowel (Straight and Stepped) - All crankcases with 2.5665 bearing bore diameter
503	ST-307	Driver, Bearing Dowel (Straight and Stepped) - All crankcases with 2.8165 bearing bore diameter
504	ST-309-1	Reamer, Valve Guide ID Exhaust (Ni-Resist) - Pilot dia4828/.4833 finished ID .5000/.5010 for large ID valve guide replacement (See ST-314 for Plug Gage)
505	ST-309-2	Reamer, Valve Guide ID Exhaust (Ni-Resist) - Pilot dia4777/.4783 finished ID .5000/.5010 for small ID valve guide replacement (See ST-314 for Plug Gage)
506	ST-310	Gage, Check Bell-Mouthing of Exhaust Valve Guides - All angle valve engines employing 1/2 in. exhaust valves with down exhaust - (See ST-71 for parallel valves)




Ref.	Tool No.	Nomenclature and Description			
507	ST-313	Wrench, Crankshaft Flange - TIGO-541			
508	ST-314	Gage, Plug, Valve Guide ID (Exhaust) - All valve guides with .5000/.5010 ID valve guide hole (See ST-315 for Reamer)			
509	ST-315	Reamer, Valve Guide ID (Brass) (Exhaust) - Pilot dia4888/.4893 finished ID .5000/.5010, (not used on No-Resist Guides) See ST-314 for Plug Gage			
510	ST-316	Driver, Crankcase Thru-Stud - TIO-541 and TIGO-541			
511	ST-317	Driver, Crankcase Thru-Stud - All engines employing thru-studs (except TIO and TIGO-541)			
512	ST-318	Gage, Fuel Injector and Controller Linkage - TIO-541 and TIGO-541 (Use with ST-319)			
513	ST-319	Fixture, Fuel Injector and Controller Linkage - TIO-541 and TIGO-541 (Use with ST-318)			
514	ST-320	Wrench, Propeller - TIGO-541			
515	ST-321	Puller, Compressor Pulley - All engines employing compressors			
516	ST-322	Wrench, (5/8 in. hex) Cylinder Base Nut - All engines employing P/N STD-2106 nut			
517	ST-323	Counterbore, Crankcase Oil Seal Recess - Use with ST-324, ST-325 - All engines employing crankcase thru-stud dowels			
518	ST-324	Pilot, Crankcase Oil Seal Recess Counterbore - Use with ST-323, ST-325 - All engines employing crankcase thru-stud dowels			
519	ST-325	Stop Collar, Crankcase Oil Seal Recess Counterbore - Use with ST-323, ST-324 - All engines employing crankcase thru-stud dowels			
520	ST-327	Plate, Bushing (Crankcase) - Use with ST-328-2 - Ream crankcase for o/s thru-stud dowels			
521	ST-328-2	Reamer, Crankcase (.6350 diameter for .010 o/s dowels) - Use with ST-327 - All engines to employ .010 o/s thru-stud dowels			
522	ST-329	Fixture, Propeller Shaft Locknut Assembly - TIGO-541			
523	ST-329-1	Fixture, Propeller Shaft Locknut (Detail of ST-329) - TIGO-541			
524	ST-329-2	Stand, Propeller Shaft Locknut (Detail of ST-329) - TIGO-541			
525	ST-331	Gage, Plug and Depth .010 o/s Crankcase Thru-Stud Dowel - All engines to employ crankcase .010 o/s thru-stud dowels (See ST-126 for standard gage)			
526	ST-332	Driver, Dowel Crankcase - Drive Press fit dowels in crankcase - All engines to employ crankcase thru-stud dowels			




Ref.	Tool No.	Nomenclature and Description
527	ST-333	Adapter - 5/8-18 NC-2 thread to 16 MM x 2 thread - Use with Metric Slide Hammer Puller
528	ST-338	Reamer, (Short) Hand-Expansion Valve Guide ID - All cylinder head with 1/2 in. valve guide hole
529	ST-340	Former, Oil Relief Valve Seat (Use with ST-245) - All engines
530	ST-345	Wrench, "T" Bar - Spark Plug (Use with ST-288) - All engines
531	ST-351	Club, Test (Left hand rotation) (Use with 64981) - LTIO-540
532	ST-352	Shroud, Cooling - All four cylinder angle valve engines
533	ST-354	Reamer and Stop, Shroud Tube Adapter - TIO and TIGO-541-E engines - Use with ST-356, ST-357, ST-376, ST-361, ST-362, ST-363, ST-364, ST-365
534	ST-356	Puller Insert, Shroud Tube Cylinder Head Adapter - All cylinder heads reworked to install shroud tube adapter (P/N LW-13398) - Use with ST-354, ST-357, ST-361, ST-362, ST-363, ST-364, ST-365 ST-376, ST-381, ST-382
535	ST-357	Fixture, Shroud Tube Adapter - Rework shroud tube adapter (P/N 77755) on TIO and TIGO-541-E engines - Use with ST-354, ST-356, ST-376, ST-361, ST-362, ST-363, ST-364, ST-365
536	ST-360	Reamer Set, Crankcase Bearing Dowel - All crankcases to employ .2545 or .2595 o/s Bearing Dowel Hole
537	ST-361	Tool, Shroud Tube Barrel, Spring and Assembly - TIO and TIGO-541-E - Use with ST-354, ST-356, ST-357, ST-362, ST-363, ST-364, ST-365, ST-376, ST-381, ST-382
538	ST-362	Reamer, (Tapered) Cylinder Head Shroud Tube Hole - Ream cylinder heads to install (P/N LW-13398) adapter - TIO and TIGO-541-E - Use with ST-354, ST-356, ST-357, ST-361, ST-363, ST-364, ST-365, ST-376, ST-381, ST-382
539	ST-363	Back Relief Cutter, Pilot and Driver - Cutter to relieve cylinder heads to install (P/N LW-13398) adapter - TIO and TIGO-541-E - Use with ST-354, ST-356, ST-357, ST-361, ST-362, ST-364, ST-365, ST-376, ST-381, ST-382
540	ST-364	Fixture, Cylinder Head Shroud Tube Hole - Ream cylinder head to install (P/N LW-13398) adapter - TIO and TIGO-541-E - Use with ST-354, ST-356, ST-357, ST-361, ST-362, ST-363, ST-365, ST-376
541	ST-365	Tool, Flaring - Flare cylinder head shroud tube adapter (P/N LW-13398) - TIO and TIGO-541-E - Use

S1-365
 Tool, Flaring - Flare cylinder head shroud tube adapter (P/N LW-13398) - TIO and TIGO-541-E - Use with ST-354, ST-356, ST-357, ST-361, ST-362, ST-363, ST-364, ST-376, ST-381, ST-382



.


Ref.	Tool No.	Nomenclature and Description
542	ST-366-5	Reamer, Piloted Crankcase (.005 o/s) - Ream thru-stud hole in crankcase - All engines employing P/N 76220-P05 thru-stud
543	ST-366-1	Reamer, Piloted Crankcase (.010 o/s) - Ream thru-stud hole in crankcase - All engines employing P/N 76220-P10 thru-stud
544	ST-368	Kit, Valve Train Removal - Remove valve train with a pumped up hydraulic Lifter - Angle valve cylinders
545	ST-369	Pilot, Spark Plug Pad Counterbore - Use with counterbore ST-370 - All engines
546	ST-370	Counterbore, Spark Plug Pad - Use with pilot ST-369 - All engines
547	ST-372	Drill Jig, Crankshaft Front Oil Drain - Crankcases with no thrust bearing oil drain converting to oil lubrication stainless steel thrust bearing - TIGO-541
548	ST-374	Wrench, cylinder Base Nut (9/16 hex) - All engines employing P/N STD-383-B nut
549	ST-375	Wrench, Cylinder Base Nut 3/4 hex) - All engines employing P/N STD-2090 nut
550	ST-376	Spring Holder, Shroud tube (Barrel Springs) - All engines employing Barrel Springs on Shroud Tubes
551	ST-377	Drill Fixture, Relocate front propeller shaft drive gear bearing dowel hole in crankcase - TIGO-541
552	ST-378	Driver, Bearing Dowel (Straight) - Crankcases with 2.923 bearing bore diameter - TIGO-541 - Use with ST-377, ST-379, ST-380
553	ST-379	Drill, Flat Bottom - Propeller shaft drive bearing dowel hole in crankcase - TIGO-541
554	ST-380	Reamer, Propeller shaft drive gear bearing dowel in crankcase - TIGO-541
555	ST-383	Tool, Crankshaft oil seal installation - All engines employing stretch seals
556	ST-387	Fixture, Tappet Body Magnaflux - All engines except O-235, O-290-D, 76 Series, TIO and TIGO-541 (Use with 64899)
557	ST-388	Reamer, Guide and Stop - Oil Temperature By-Pass Valve Seat - All direct drive engines except TIO-541
558	ST-389	Tool, Crankcase Separating - All doweled crankcase with drive thru-studs
559	ST-390	Fixture, Drill, Crankshaft Gear - TIO and TIGO-541




Ref.	Tool No.	Nomenclature and Description
560	ST-415	Hub and Cone Assembly, Test Club (4 Blade) - All No. 30 Spline propeller shafts with 2.615/2.617 OD
561	ST-415-2	Cone, Detail of ST-415
562	ST-416	Wrench, Spline, Oil Pump Drive - 76 Series engines
563	ST-418	Tool, (Solid tappets) Valve adjusting - O-235, O-290-D Series
564	ST-418-3	Blade, Screwdriver - Valve adjusting tool (Detail of ST-418)
565	ST-419	Compressor, Valve Spring - 76 Series engines
566	ST-427	Reamer, (STD) Rocker Shaft Bushing Hole - O-235, O-290 Series cylinder for installation of bushings
567	ST-429	Gage, Plug Valve Guide OD (Intake and Exhaust) (STD) - All valve guides with .5913/.5923 valve guide hole in cylinder head
568	ST-429-1	Gage, Plug Valve Guide OD (Intake and Exhaust) (.010 o/s) - All valve guides with .5913/.5923 valve guide hole in cylinder head
569	ST-429-2	Gage, Plug Valve Guide OD (Intake and Exhaust) (.020 o/s) - All valve guides with .5913/.5923 valve guide hole in cylinder head
570	ST-429-3	Gage, Plug Valve Guide OD (Intake and Exhaust) (.030 o/s) - All valve guides with .5913/.5923 valve guide hole in cylinder head
571	ST-429-4	Gage, Plug Valve Guide OD (Intake and Exhaust) (.040 o/s) - All valve guides with .5913/.5923 valve guide hole in cylinder head
572	ST-429-5	Gage, Plug Valve Guide OD (Intake and Exhaust) (.005 o/s) - All valve guides with .5913/.5923 valve guide hole in cylinder head
573	ST-430-1	Reamer, Valve Guide OD (Intake and Exhaust) (.010 o/s) - All valve guides with .5913/.5923 valve guide hole in cylinder head
574	ST-430-2	Reamer, Valve Guide OD (Intake and Exhaust) (.020 o/s) - All valve guides with .5913/.5923 valve guide hole in cylinder head
575	ST-430-3	Reamer, Valve Guide OD (Intake and Exhaust) (.030 o/s) - All valve guides with .5913/.5923 valve guide hole in cylinder head
576	ST-430-4	Reamer, Valve Guide OD (Intake and Exhaust) (.040 o/s) - All valve guides with .5913/.5923 valve guide hole in cylinder head
577	ST-430-5	Reamer, Valve Guide OD (Intake and Exhaust) (.005 o/s) - All valve guides with .5913/.5923 valve guide hole in cylinder head



560 - 561




562



Ref.	Tool No.	Nomenclature and Description
578	ST-431	Gage, Plug Valve Guide OD (Exhaust) (STD) - All valve guides with .6613/.6623 valve guide hole in cylinder head
579	ST-431-1	Gage, Plug Valve Guide OD (Exhaust) (.010 o/s) - All valve guides with .6613/.6623 valve guide hole in cylinder head
580	ST-431-2	Gage, Plug Valve Guide OD (Exhaust) (.020 o/s) - All valve guides with .6613/.6623 valve guide hole in cylinder head
581	ST-431-3	Gage, Plug Valve Guide OD (Exhaust) (.030 o/s) - All valve guides with .6613/.6623 valve guide hole in cylinder head
582	ST-431-4	Gage, Plug Valve Guide OD (Exhaust) (.040 o/s) - All valve guides with .6613/.6623 valve guide hole in cylinder head
583	ST-431-5	Gage, Plug Valve Guide OD (Exhaust) (.005 o/s) - All valve guides with .6613/.6623 valve guide hole in cylinder head
584	ST-432-1	Reamer, Valve Guide OD (Exhaust) (.010 o/s) - All valve guides with .6613/.6623 valve guide hole in cylinder head
585	ST-432-2	Reamer, Valve Guide OD (Exhaust) (.020 o/s) - All valve guides with .6613/.6623 valve guide hole in cylinder head
586	ST-432-3	Reamer, Valve Guide OD (Exhaust) (.030 o/s) - All valve guides with .6613/.6623 valve guide hole in cylinder head
587	ST-432-4	Reamer, Valve Guide OD (Exhaust) (.040 o/s) - All valve guides with .6613/.6623 valve guide hole in cylinder head
588	ST-432-5	Reamer, Valve Guide OD (Exhaust) (.005 o/s) - All valve guides with .6613/.6623 valve guide hole in cylinder head
589	ST-435	Reamer, Accessory Housing Oil Transfer Dowel - IGSO-540 engines
590	ST-436	Reamer, Accessory Housing Oil Transfer Dowel - IGSO-540 engines
591	ST-439	Countersink, (80°) Oil Relief Valve Seat Repair - 76 Series engines with 1/2 in. oil supply port (Use with ST-245 bushing)
592	ST-440	Tool, Hydraulic Plunger Removal - TIO, TIGO-541 Series
593	ST-443	Seal Puller and Installation Tool - Remove and install STD-2217 seal in vacuum pump adapter
594	ST-455	*Adapter, Test Club - All O-235 engines with AS-127 Type 1 prop flange and bushings for 3/8 in. prop attaching bolts
595	ST-456	*Club, Test - O-235 with AS-127 Type 1 prop flange (See 64801 for O-235 with AS-127 Type 2 prop flange)
596	ST-460	Mount, Engine Maintenance - All 6 cylinder direct drive engines without turbocharging. Use with 64759 at right top crankcase mounting pad
597	ST-461	Mount, Engine Maintenance - All 6 cylinder direct drive engines without turbocharging. Use with 64759 at left top crankcase mounting pad
598	ST-474	Tool Hydraulic Plunger Removal. 76 Series and TIO-541 Series

* AS-127 Type 1 prop flanges can be identified by measuring from one prop attaching bushing across the center of the crankshaft to the opposite bushing. The center to center measurement is 4-3/8 inches.



1225-BWrenchS.I. 1144 40714 WrenchS.B. 290, SI. 1144 64501 FixtureS.I. 1246, S.I. 1366 64514 GageS.B. 244 64535 DriftS.B. 244 64536 DriftS.B. 244 64537 DriftS.B. 244 64536 BurnisherS.B. 244 64547 DriftS.I. 1029 64580 BurnisherS.B. 244 64593 Expanding ToolS.I. 1043 64594 Inserting ToolS.I. 1043 64594 Inserting ToolS.I. 1043 64597 FixtureS.B. 244 64607 BlockS.B. 1142 64648 DriverS.I. 1043 64644 ReamerS.I. 1043 646484 ReamerS.I. 1043 64684 ReamerS.I. 1098 64684 ReamerS.I. 1098 64684 ReamerS.I. 1029 64701 WrenchS.I. 1029 64701 WrenchS.I. 1029 64772 PullerS.B. 292 64765 Test StandS.I. 1044, S.I. 1144 64772 PullerS.I. 1098 64722 PullerS.B. 216 64826 DriftS.I. 1098 64772 PullerS.I. 1098 64772 PullerS.I. 1098 64772 PullerS.I. 1044, S.I. 1145 64765 Test StandS.I. 1144 64772 PullerS.I. 1048 64826 DriftS.I. 1048<	Tool No.	Name	See Latest Revision of Publication No.
40714WrenchS.B. 290, S.I. 114464501FixtureS.I. 1246, S.I. 136664514GageS.I. 1246, S.I. 136664530GageS.B. 24464535DriftS.B. 24464536DriftS.B. 24464537DriftS.I. 102964580BurnisherS.B. 24464593Expanding ToolS.I. 104364594Inserting ToolS.I. 104364595FixtureS.B. 24464607BlockS.B. 24464607BlockS.B. 14464684DriverS.I. 10764684ReamerS.I. 10864684ReamerS.I. 102964700WrenchS.B. 29064701WrenchS.B. 29064701WrenchS.B. 29264765Test StandS.I. 114464767GageS.B. 29264765Test StandS.I. 114464767GageS.B. 29264765Test StandS.I. 114464767GageS.B. 21664828ReamerS.B. 21664829ReamerS.B. 23964861Crimping ToolS.I. 114264772PullerS.B. 23964861Crimping ToolS.I. 114264776GageS.B. 21664828ReamerS.B. 23964861Crimping ToolS.I. 114264875ReamerS.I. 114264876ReamerS.I. 114264877Prill<	1225-B	Wrench	S.I. 1144
64501 Fixture S.I. 1246, S.I. 1366 64514 Gage S.I. 1425 64530 Gage S.B. 244 64535 Drift S.B. 244 64536 Drift S.B. 244 64537 Drift S.B. 244 64536 Drift S.B. 244 64537 Drift S.I. 1029 64580 Burnisher S.B. 244 64593 Expanding Tool S.I. 1043 64594 Inserting Tool S.I. 1043 64597 Fixture S.B. 244 64607 Block S.B. 184, S.I. 1144 64684 Reamer S.I. 1029 64681 Driver S.I. 1029 64700 Wrench S.I. 1029 64701 Wrench S.I. 1029 64702 Puller S.B. 290 64737 Adapter S.B. 290 64765 Test Stand S.I. 1144 64766 Drift S.I. 1029 64772 Puller			
64514 Gage S.I. 1425 64530 Gage S.B. 244 64535 Drift S.B. 244 64536 Drift S.B. 244 64537 Drift S.B. 244 64547 Drift S.I. 1167 64572 Wrench S.I. 1029 64580 Burnisher S.B. 244 64593 Expanding Tool S.I. 1043 64594 Inserting Tool S.I. 1043 64597 Fixture S.B. 244 64607 Block S.B. 184, S.I. 1144 64648 Driver S.I. 1098 64684 Reamer S.I. 1029 64700 Wrench S.I. 1029 64719 Wrench S.B. 290 64701 Wrench S.B. 290 64772 Puller S.B. 1144 64767 Gage S.B. 244 64767 Gage S.B. 290 64719 Wrench S.B. 290 64770 Drift S.I. 1044, S.I. 1145 64763 Gage S.B. 216 6			,
64530 Gage S.B. 244 64535 Drift S.B. 244 64536 Drift S.B. 244 64536 Drift S.B. 244 64547 Drift S.I. 1167 64572 Wrench S.B. 244 64593 Expanding Tool S.I. 1043 64594 Inserting Tool S.I. 1043 64597 Fixture S.B. 244 64607 Block S.B. 144, 64648 Driver S.I. 107 64681 Drift S.I. 1098 64684 Reamer S.I. 1029 64700 Wrench S.I. 1029 64701 Wrench S.B. 290 64700 Wrench S.I. 1029 64701 Wrench S.B. 290 64737 Adapter S.B. 290 64755 Test Stand S.I. 1142 64766 Orift S.I. 1029 64772 Puller S.B. 244 64770 Drift S.I. 1048, S.I. 1145 64782 Reamer S.B. 216 648			
64535DriftS.B. 24464536DriftS.B. 24464547DriftS.I. 116764572WrenchS.I. 102964580BurnisherS.B. 24464593Expanding ToolS.I. 104364594Inserting ToolS.I. 104364595FixtureS.B. 24464607BlockS.B. 14464607BlockS.B. 14464648DriverS.I. 116764684ReamerS.I. 142564698PullerS.B. 29064700WrenchS.I. 102964701WrenchS.I. 102964701WrenchS.I. 102964701WrenchS.I. 102964701WrenchS.I. 1029647719WrenchS.B. 29264765Test StandS.I. 114464767GageS.B. 24464770DriftS.I. 104864772PullerS.I. 109864773AdapterS.B. 29264765Test StandS.I. 114464767GageS.B. 21664828ReamerS.B. 21664829ReamerS.B. 21664820SpotfacerS.B. 22564861Crimping ToolS.I. 114264874ReamerS.I. 114264875ReamerS.I. 114264876ReamerS.I. 114264877PullerS.I. 114264878FixtureS.I. 114264874ReamerS.I. 1142		•	
64536DriftS.B. 244 64547 DriftS.I. 1029 64580 BurnisherS.B. 244 64593 Expanding ToolS.I. 1043 64594 Inserting ToolS.I. 1043 $64596-1$ TapS.I. 1043 $64596-1$ TapS.I. 1043 64597 FixtureS.B. 244 64607 BlockS.B. 184, S.I. 1144 64648 DriverS.I. 1098 64684 ReamerS.I. 1029 64681 DriftS.I. 1029 64700 WrenchS.I. 1029 64701 WrenchS.B. 290 64701 WrenchS.B. 290 64719 WrenchS.B. 290 64771 AdapterS.B. 290 64772 PullerS.B. 290 64777 GageS.B. 244 64770 DriftS.I. 1029 64772 PullerS.I. 1044 64772 PullerS.I. 1044, S.I. 1145 64782 ReamerS.B. 216 64827 DriftS.I. 1246 64810 GageS.I. 1366 64827 DrillS.B. 216 64856 Drill JigS.B. 239 64861 Crimping ToolS.I. 1142 64872 PullerS.I. 1142 64874 ReamerS.I. 1142 64875 ReamerS.B. 225 64868 CounterboreS.B. 252 64868 CounterboreS.B. 252 64876 ReamerS.I. 1142 64877 Puller<			
64547DriftS.I. 1167 64572 WrenchS.I. 1029 64580 BurnisherS.B. 244 64593 Expanding ToolS.I. 1043 64594 Inserting ToolS.I. 1043 $64596-1$ TapS.I. 1043 64597 FixtureS.B. 244 64607 BlockS.B. 184, S.I. 1144 64648 DriverS.I. 1057 64681 DriftS.I. 1029 64684 ReamerS.I. 1029 64700 WrenchS.B. 290 64700 WrenchS.B. 290 64701 WrenchS.B. 290 64707 AdapterS.B. 292 64765 Test StandS.I. 1144 64767 GageS.B. 292 64765 Test StandS.I. 1144 64770 DriftS.I. 1029 64770 DriftS.I. 1044, S.I. 1145 64796 DriftS.I. 1044, S.I. 1145 64796 DriftS.I. 1044, S.I. 1145 64796 DriftS.I. 1044, S.I. 1145 64782 ReamerS.B. 216 64828 ReamerS.B. 216 64827 DrillS.B. 216 64828 ReamerS.B. 225 64861 Crimping ToolS.I. 1119 64861 Crimping ToolS.I. 1142 64874 ReamerS.I. 1142 64875 ReamerS.I. 1142 64874 ReamerS.I. 1142 64875 ReamerS.I. 1142 64876 ReamerS.I. 1142<			
64572WrenchS.I. 1029 64580 BurnisherS.B. 244 64593 Expanding ToolS.I. 1043 64594 Inserting ToolS.I. 1043 64594 Inserting ToolS.I. 1043 $64596-1$ TapS.I. 1043 64597 FixtureS.B. 244 64607 BlockS.B. 184, S.I. 1144 64648 DriverS.I. 1098 64684 ReamerS.I. 1098 64684 ReamerS.I. 1029 64700 WrenchS.I. 1029 64701 WrenchS.B. 290 64701 WrenchS.B. 290 64777 AdapterS.B. 290 64777 GageS.B. 290 64777 GageS.B. 290 64777 PullerS.I. 1029 64777 PullerS.I. 1044 64776 GageS.B. 292 64777 PullerS.I. 1098 647772 PullerS.I. 1098 647772 PullerS.I. 1098 647772 PullerS.I. 1098 647772 PullerS.I. 1144 64828 ReamerS.B. 216 64828 ReamerS.B. 216 64828 ReamerS.B. 239 64861 Crimping ToolS.I. 1119 64862 SpotfacerS.B. 252 64874 ReamerS.I. 1142 64875 ReamerS.I. 1142 64876 ReamerS.I. 1142 64876 ReamerS.I. 1142 64876 Reamer </td <td></td> <td></td> <td></td>			
64580BurnisherS.B. 244 64593 Expanding ToolS.I. 1043 $64596-1$ TapS.I. 1043 $64596-1$ TapS.I. 1043 64597 FixtureS.B. 244 64607 BlockS.B. 184, S.I. 1144 64648 DriverS.I. 1098 64684 ReamerS.I. 1098 64684 ReamerS.I. 1029 64700 WrenchS.I. 1029 64701 WrenchS.I. 1029 64701 WrenchS.I. 1029 64770 WrenchS.B. 290 64737 AdapterS.B. 290 64737 AdapterS.B. 290 64775 Test StandS.I. 1144 64766 DriftS.I. 1029 64772 PullerS.I. 1098 64772 PullerS.I. 1098 64772 PullerS.I. 1044, S.I. 1145 64810 GageS.I. 1044, S.I. 1145 64827 DriftS.I. 1044, S.I. 1145 64828 ReamerS.B. 216 64829 ReamerS.B. 216 64824 CounterboreS.B. 225 64861 Crimping ToolS.I. 1142 64874 ReamerS.I. 1142 64875 ReamerS.I. 1142 64876 ReamerS.I. 1142 <td< td=""><td></td><td></td><td></td></td<>			
64593 Expanding Tool S.I. 1043 64594 Inserting Tool S.I. 1043 64596-1 Tap S.I. 1043 64597 Fixture S.B. 244 64607 Block S.B. 184, S.I. 1144 64648 Driver S.I. 1098 64684 Reamer S.I. 1098 64684 Reamer S.I. 1029 64700 Wrench S.I. 1029 64701 Wrench S.B. 290 64701 Wrench S.B. 290 64701 Wrench S.B. 290 647719 Wrench S.B. 290 64765 Test Stand S.I. 1144 64767 Gage S.B. 244 64770 Drift S.I. 1044, S.I. 1145 64772 Puller S.I. 1048, S.I. 1145 64827 Drift S.I. 1044, S.I. 1145 64828 Reamer S.B. 216 64828 Reamer S.B. 216 64829 Reamer S.B. 225 64861 <			
64594 Inserting Tool S.I. 1043 64596-1 Tap S.I. 1043 64597 Fixture S.B. 184, S.I. 1144 64607 Block S.B. 184, S.I. 1144 64648 Driver S.I. 1098 64684 Reamer S.I. 1098 64684 Reamer S.I. 1029 64700 Wrench S.I. 1029 64701 Wrench S.B. 290 64701 Wrench S.B. 290 64737 Adapter S.B. 290 64737 Adapter S.B. 292 64765 Test Stand S.I. 1144 64770 Drift S.I. 1098 64772 Puller S.I. 1098 64772 Puller S.I. 1044, S.I. 1145 64796 Drift S.I. 1246 64810 Gage S.I. 1246 64828 Reamer S.B. 216 64828 Reamer S.B. 216 64826 Spotfacer S.B. 225 64861 Crimping Tool S.I. 1142 64874 Reamer S.I. 1142			
64596-1 Tap S.I. 1043 64597 Fixture S.B. 244 64607 Block S.B. 144, S.I. 1144 64684 Driver S.I. 1167 64681 Drift S.I. 1098 64684 Reamer S.I. 1425 64698 Puller S.B. 290 64700 Wrench S.I. 1029 64719 Wrench S.B. 290 64737 Adapter S.B. 290 64765 Test Stand S.I. 1144 64767 Gage S.B. 292 64765 Test Stand S.I. 1144 64767 Gage S.B. 244 64770 Drift S.I. 1098 64772 Puller S.I. 1044, S.I. 1145 64796 Drift S.I. 1044, S.I. 1145 64810 Gage S.I. 1044, S.I. 1145 64828 Reamer S.B. 216 64828 Reamer S.B. 216 64829 Reamer S.B. 225 64861 Crimping Tool<			
64597 Fixture S.B. 244 64607 Block S.B. 184, S.I. 1144 64607 Block S.B. 184, S.I. 1144 64681 Driver S.I. 1167 64681 Drift S.I. 1098 64684 Reamer S.I. 1425 64698 Puller S.B. 290 64700 Wrench S.I. 1029 64701 Wrench S.B. 290 64719 Wrench S.B. 290 64737 Adapter S.B. 292 64765 Test Stand S.I. 1144 64767 Gage S.B. 244 64770 Drift S.I. 1044, S.I. 1145 64772 Puller S.I. 1044, S.I. 1145 64766 Drift S.I. 1246 64810 Gage S.I. 1145 64796 Drill S.B. 216 64828 Reamer S.B. 216 64829 Reamer S.B. 239 64820 Spotfacer S.B. 225 64861 Crimping Tool <td></td> <td>•</td> <td></td>		•	
64607 Block S.B. 184, S.I. 1144 64648 Driver S.I. 1167 64681 Drift S.I. 1098 64684 Reamer S.I. 125 64698 Puller S.B. 290 64700 Wrench S.I. 1029 64711 Wrench S.B. 290 64772 Adapter S.B. 292 64765 Test Stand S.I. 1144 64767 Gage S.B. 244 64770 Drift S.I. 1098 64772 Puller S.I. 1044, S.I. 1145 64776 Gage S.I. 1044, S.I. 1145 64770 Drift S.I. 1098 64772 Puller S.I. 1044, S.I. 1145 64796 Drift S.I. 1246 64810 Gage S.I. 1366 64827 Drill S.B. 216 64828 Reamer S.B. 239 64861 Crimping Tool S.I. 119 64856 Drill Jig S.B. 252 64868 Counterbor			
64648 Driver S.I. 1167 64681 Drift S.I. 1098 64684 Reamer S.I. 1425 64698 Puller S.B. 290 64700 Wrench S.I. 1029 64710 Wrench S.I. 1029 64770 Wrench S.B. 290 64765 Test Stand S.I. 1144 64767 Gage S.B. 244 64770 Drift S.I. 1098 64772 Puller S.I. 1044, S.I. 1145 64796 Drift S.I. 1044, S.I. 1145 64796 Drift S.B. 216 64828 Reamer S.B. 216 64829 Reamer S.B. 216 64828 Reamer S.B. 239 64861 Crimping Tool S.I. 1142 64852 Spotfacer S.B. 252 64868 Counterbore S.B. 252 64864 Reamer S.I. 1142 64875 Reamer S.I. 1142 64874 Reamer S.I. 1142 64863 Counterbore S.B. 252			
64681 Drift S.I. 1098 64684 Reamer S.I. 1425 64698 Puller S.B. 290 64700 Wrench S.I. 1029 64701 Wrench S.I. 1029 64701 Wrench S.B. 290 64719 Wrench S.B. 290 64737 Adapter S.B. 292 64765 Test Stand S.I. 1144 64767 Gage S.B. 244 64770 Drift S.I. 1098 64772 Puller S.I. 1044, S.I. 1145 64796 Drift S.I. 1044, S.I. 1145 64796 Drift S.B. 216 64820 Reamer S.B. 216 64828 Reamer S.B. 216 64828 Reamer S.B. 216 64856 Drill Jig S.B. 225 64868 Counterbore S.B. 252 64868 Counterbore S.B. 252 64874 Reamer S.I. 1142 64875 Reamer S			
64684ReamerS.I. 1425 64698 PullerS.B. 290 64700 WrenchS.I. 1029 64701 WrenchS.I. 1029 64719 WrenchS.B. 290 64737 AdapterS.B. 292 64765 Test StandS.I. 1144 64767 GageS.B. 244 64770 DriftS.I. 1098 64772 PullerS.I. 1044, S.I. 1145 64796 DriftS.I. 1044, S.I. 1145 64796 DriftS.B. 216 64827 DrillS.B. 216 64828 ReamerS.B. 216 64829 ReamerS.B. 216 64856 Drill JigS.B. 239 64861 Crimping ToolS.I. 1142 64872 PullerS.I. 1142 64874 ReamerS.I. 1142 64874 ReamerS.I. 1142 64875 ReamerS.I. 1142 64874 ReamerS.I. 1142 64875 ReamerS.I. 1142 64876 ReamerS.I. 1142 64876 ReamerS.I. 1142 64876 ReamerS.I. 1142 64878 FixtureS.I. 1143 $64891-1-2$ ReamerS.I. 1012 64899 AdapterS.I. 1011 64899 AdapterS.I. 1011 64900 ReamerS.I. 1011			
64698 Puller S.B. 290 64700 Wrench S.I. 1029 64701 Wrench S.I. 1029 64719 Wrench S.B. 290 64737 Adapter S.B. 290 64765 Test Stand S.I. 1144 64767 Gage S.B. 244 64770 Drift S.I. 1098 64772 Puller S.I. 1044, S.I. 1145 64796 Drift S.I. 1044, S.I. 1145 64796 Drift S.B. 216 64810 Gage S.I. 1366 64827 Drill S.B. 216 64828 Reamer S.B. 216 64829 Reamer S.B. 216 64826 Drill Jig S.B. 239 64861 Crimping Tool S.I. 1119 64862 Spotfacer S.B. 252 64874 Reamer S.I. 1142 64875 Reamer S.I. 1142 64874 Reamer S.I. 1142 64875 Reamer S			
64700WrenchS.I. 1029 64701 WrenchS.B. 290 64719 WrenchS.B. 290 64737 AdapterS.B. 292 64765 Test StandS.I. 1144 64767 GageS.B. 244 64770 DriftS.I. 1098 64772 PullerS.I. 1098 64772 PullerS.I. 1044, S.I. 1145 64796 DriftS.I. 1246 64810 GageS.I. 1366 64827 DrillS.B. 216 64828 ReamerS.B. 216 64829 ReamerS.B. 216 64856 Drill JigS.B. 239 64861 Crimping ToolS.I. 1119 64862 SpotfacerS.B. 252 64874 ReamerS.I. 1142 64876 ReamerS.I. 1142 64878 FixtureS.B. 257, S.I. 1117 $64891-1-2$ ReamerS.I. 1143 $64891-1-2$ ReamerS.I. 1144 64899 AdapterS.I. 1011 64899 AdapterS.I. 1011 64900 ReamerS.I. 1425			
64701WrenchS.I. 102964719WrenchS.B. 29064737AdapterS.B. 29264765Test StandS.I. 114464767GageS.B. 24464770DriftS.I. 109864772PullerS.I. 1044, S.I. 114564796DriftS.I. 124664810GageS.I. 136664827DrillS.B. 21664828ReamerS.B. 21664829ReamerS.B. 21664856Drill JigS.B. 23964861Crimping ToolS.I. 111964862SpotfacerS.B. 25264868CounterboreS.B. 25264874ReamerS.I. 114264875ReamerS.I. 114264876ReamerS.I. 114264878FixtureS.I. 114364878FixtureS.I. 114364878FixtureS.I. 114264878FixtureS.I. 114364891-1-2ReamerS.I. 101264894Test Drive AssemblyS.I. 114464899AdapterS.I. 101164900ReamerS.I. 1011			
64719WrenchS.B. 29064737AdapterS.B. 29264765Test StandS.I. 114464767GageS.B. 24464770DriftS.I. 109864772PullerS.I. 1044, S.I. 114564796DriftS.I. 124664810GageS.I. 136664827DrillS.B. 21664828ReamerS.B. 21664856Drill JigS.B. 23964861Crimping ToolS.I. 111964862SpotfacerS.B. 22564868CounterboreS.B. 25264874ReamerS.I. 114264875ReamerS.I. 114264876ReamerS.I. 114264878FixtureS.I. 114364891-1-2ReamerS.I. 114364894Test Drive AssemblyS.I. 114464899AdapterS.I. 101164900ReamerS.I. 1425			
64737AdapterS.B. 29264765Test StandS.I. 114464767GageS.B. 24464770DriftS.I. 109864772PullerS.I. 1044, S.I. 114564796DriftS.I. 124664810GageS.I. 136664827DrillS.B. 21664828ReamerS.B. 21664829ReamerS.B. 21664856Drill JigS.B. 23964861Crimping ToolS.I. 111964862SpotfacerS.B. 22564868CounterboreS.B. 25264874ReamerS.I. 114264875ReamerS.I. 114264876ReamerS.I. 114264878FixtureS.I. 114364891-1-2ReamerS.I. 114364894Test Drive AssemblyS.I. 114464899AdapterS.I. 101164900ReamerS.I. 1425			
64765 Test Stand S.I. 1144 64767 Gage S.B. 244 64770 Drift S.I. 1098 64772 Puller S.I. 1044, S.I. 1145 64796 Drift S.I. 1246 64810 Gage S.I. 1366 64827 Drill S.B. 216 64828 Reamer S.B. 216 64829 Reamer S.B. 216 64856 Drill Jig S.B. 239 64861 Crimping Tool S.I. 1142 64862 Spotfacer S.B. 252 64868 Counterbore S.B. 252 64874 Reamer SI. 1142 64875 Reamer SI. 1142 64876 Reamer SI. 1142 64876 Reamer SI. 1142 64876 Reamer SI. 1142 64878 Fixture SI. 1143 64891-1-2 Reamer S.B. 257, S.I. 1117 64894 Test Drive Assembly SI. 1144 64899 Adapter SI. 1011 64890 Reamer SI. 1011			
64767GageS.B. 24464770DriftS.I. 109864772PullerS.I. 1044, S.I. 114564796DriftS.I. 124664810GageS.I. 136664827DrillS.B. 21664828ReamerS.B. 21664829ReamerS.B. 21664856Drill JigS.B. 23964861Crimping ToolS.I. 111964862SpotfacerS.B. 25564868CounterboreS.B. 25264874ReamerS.I. 114264875ReamerS.I. 114264876ReamerS.I. 114264878FixtureS.I. 114364891-1-2ReamerS.I. 114364894Test Drive AssemblyS.I. 114464899AdapterS.I. 101164900ReamerS.I. 1425			
64770DriftS.I. 109864772PullerS.I. 1044, S.I. 114564796DriftS.I. 124664810GageS.I. 136664827DrillS.B. 21664828ReamerS.B. 21664829ReamerS.B. 21664856Drill JigS.B. 23964861Crimping ToolS.I. 111964862SpotfacerS.B. 25264868CounterboreS.B. 25264872PullerS.I. 114264874ReamerS.I. 114264875ReamerS.I. 114264876ReamerS.I. 114264878FixtureS.I. 114364891-1-2ReamerS.I. 114364894Test Drive AssemblyS.I. 101264894GageS.I. 101164900ReamerS.I. 1425			
64772PullerS.I. 1044, S.I. 114564796DriftS.I. 124664810GageS.I. 136664827DrillS.B. 21664828ReamerS.B. 21664829ReamerS.B. 21664856Drill JigS.B. 23964861Crimping ToolS.I. 111964862SpotfacerS.B. 22564868CounterboreS.B. 25264872PullerS.I. 114264874ReamerS.I. 114264875ReamerS.I. 114264876ReamerS.I. 114264878FixtureS.I. 114364891-1-2ReamerS.I. 114364894Test Drive AssemblyS.I. 114464899AdapterS.I. 101164900ReamerS.I. 1425			
64796DriftS.I. 124664810GageS.I. 136664827DrillS.B. 21664828ReamerS.B. 21664829ReamerS.B. 21664856Drill JigS.B. 23964861Crimping ToolS.I. 111964862SpotfacerS.B. 22564868CounterboreS.B. 25264872PullerS.I. 114264874ReamerS.I. 114264875ReamerS.I. 114264876ReamerS.I. 114264878FixtureS.I. 114364891-1-2ReamerS.I. 114364894Test Drive AssemblyS.I. 114464899AdapterS.I. 101164900ReamerS.I. 1011			
64810GageS.I. 136664827DrillS.B. 21664828ReamerS.B. 21664829ReamerS.B. 21664856Drill JigS.B. 23964861Crimping ToolS.I. 111964862SpotfacerS.B. 22564868CounterboreS.B. 25264872PullerS.I. 114264874ReamerS.I. 114264875ReamerS.I. 114264876ReamerS.I. 114264878FixtureS.I. 114364891-1-2ReamerS.I. 114364894Test Drive AssemblyS.I. 114464899AdapterS.I. 101164900ReamerS.I. 1425		Drift	
64827DrillS.B. 21664828ReamerS.B. 21664829ReamerS.B. 21664856Drill JigS.B. 23964861Crimping ToolS.I. 111964862SpotfacerS.B. 22564868CounterboreS.B. 25264872PullerS.I. 114264874ReamerS.I. 114264875ReamerS.I. 114264876ReamerS.I. 114264878FixtureS.I. 114364891-1-2ReamerS.I. 101264894Test Drive AssemblyS.I. 114464899AdapterS.I. 101164900ReamerS.I. 1425			
64829ReamerS.B. 21664856Drill JigS.B. 23964861Crimping ToolS.I. 111964862SpotfacerS.B. 22564868CounterboreS.B. 25264872PullerS.I. 114264874ReamerS.I. 114264875ReamerS.I. 114264876ReamerS.I. 114264878FixtureS.I. 114264891-1-2ReamerS.I. 114364894Test Drive AssemblyS.I. 114464899AdapterS.I. 101164900ReamerS.I. 1425			
64856Drill JigS.B. 23964861Crimping ToolS.I. 111964862SpotfacerS.B. 22564868CounterboreS.B. 25264872PullerS.I. 114264874ReamerS.I. 114264875ReamerS.I. 114264876ReamerS.I. 114264878FixtureS.I. 114364891-1-2ReamerS.I. 114364894Test Drive AssemblyS.I. 114464899AdapterS.I. 101164900ReamerS.I. 1425	64828	Reamer	S.B. 216
64861Crimping ToolS.I. 111964862SpotfacerS.B. 22564868CounterboreS.B. 25264872PullerS.I. 114264874ReamerS.I. 114264875ReamerS.I. 114264876ReamerS.I. 114264878FixtureS.I. 114364891-1-2ReamerS.I. 101264894Test Drive AssemblyS.I. 114464899AdapterS.I. 101164900ReamerS.I. 1425	64829	Reamer	S.B. 216
64862SpotfacerS.B. 22564868CounterboreS.B. 25264872PullerS.I. 114264874ReamerS.I. 114264875ReamerS.I. 114264876ReamerS.I. 114264878FixtureS.I. 114364891-1-2ReamerS.B. 257, S.I. 111764892-1-2-3GageS.I. 101264894Test Drive AssemblyS.I. 114464899AdapterS.I. 101164900ReamerS.I. 1425	64856	Drill Jig	S.B. 239
64862SpotfacerS.B. 22564868CounterboreS.B. 25264872PullerS.I. 114264874ReamerS.I. 114264875ReamerS.I. 114264876ReamerS.I. 114264878FixtureS.I. 114364891-1-2ReamerS.B. 257, S.I. 111764892-1-2-3GageS.I. 101264894Test Drive AssemblyS.I. 114464899AdapterS.I. 101164900ReamerS.I. 1425	64861	Crimping Tool	S.I. 1119
64872PullerS.I. 114264874ReamerS.I. 114264875ReamerS.I. 114264876ReamerS.I. 114264878FixtureS.I. 114364891-1-2ReamerS.B. 257, S.I. 111764892-1-2-3GageS.I. 101264894Test Drive AssemblyS.I. 114464899AdapterS.I. 101164900ReamerS.I. 1425	64862	Spotfacer	S.B. 225
64874ReamerS.I. 114264875ReamerS.I. 114264876ReamerS.I. 114264878FixtureS.I. 114364891-1-2ReamerS.B. 257, S.I. 111764892-1-2-3GageS.I. 101264894Test Drive AssemblyS.I. 114464899AdapterS.I. 101164900ReamerS.I. 1425	64868	Counterbore	S.B. 252
64875ReamerS.I. 114264876ReamerS.I. 114264878FixtureS.I. 114364891-1-2ReamerS.B. 257, S.I. 111764892-1-2-3GageS.I. 101264894Test Drive AssemblyS.I. 114464899AdapterS.I. 101164900ReamerS.I. 1425	64872	Puller	S.I. 1142
64876ReamerS.I. 114264878FixtureS.I. 114364891-1-2ReamerS.B. 257, S.I. 111764892-1-2-3GageS.I. 101264894Test Drive AssemblyS.I. 114464899AdapterS.I. 101164900ReamerS.I. 1425	64874	Reamer	S.I. 1142
64878FixtureS.I. 114364891-1-2ReamerS.B. 257, S.I. 111764892-1-2-3GageS.I. 101264894Test Drive AssemblyS.I. 114464899AdapterS.I. 101164900ReamerS.I. 1425	64875	Reamer	S.I. 1142
64891-1-2ReamerS.B. 257, S.I. 111764892-1-2-3GageS.I. 101264894Test Drive AssemblyS.I. 114464899AdapterS.I. 101164900ReamerS.I. 1425	64876	Reamer	S.I. 1142
64892-1-2-3GageS.I. 101264894Test Drive AssemblyS.I. 114464899AdapterS.I. 101164900ReamerS.I. 1425	64878	Fixture	S.I. 1143
64894Test Drive AssemblyS.I. 114464899AdapterS.I. 101164900ReamerS.I. 1425	64891-1-2	Reamer	S.B. 257, S.I. 1117
64899 Adapter S.I. 1011 64900 Reamer S.I. 1425	64892-1-2-3		S.I. 1012
64900 Reamer S.I. 1425	64894	Test Drive Assembly	S.I. 1144
	64899	Adapter	S.I. 1011
C1001 0 0 1 1 105			
	64901	Gage	S.I. 1425
64902 Reamer S.B. 273			
64903 Reamer S.B. 273			
64904CounterboreS.B. 273	64904	Counterbore	S.B . 273

Tool No.	Name	See Latest Revision
1001110.	Tume	of Publication No.
64005	Caller	S B 272
64905	Collar	S.B. 273
64906 64007	Plug	S.B. 273
64907	Tap	S.B. 273
64908	Universal	S.B. 273
64910	Spinning Tool	S.I. 1167
64923	Installation Drift	S.I. 1136
64925	Reamer	S.I. 1028
64927	Gage	S.I. 1028, S.I. 1136, S.I. 1425
64939	Drill	S.I. 1028
64942	Wrench	S.I. 1029
64943	Wrench	S.I. 1029
64945	Gage	S.B. 302, S.B. 303, S.I. 1071, S.I. 1138, S.I.
(1071		1323, S.B. 371
64974	Shroud Tube Tool	S.I. 1347
64975	Gasket	S.I. 1144
ST-8	Fixture	S.I. 1064
ST-10	Drill	S.I. 1064
ST-11	Stop Collar	S.I. 1064
ST-23	Gage	S.B. 314, S.B. 315
ST-25	Compressor	S.I. 1425
ST-26	Plug Gage	S.I. 1246
ST-27	Reamer	S.I. 1246
ST-29	Wrench	S.I. 1069
ST-30	Wrench	S.I. 1069
ST-40	Fixture	S.I. 1073
ST-44	Drift	S.B. 292
ST-49	Puller	S.I. 1092, S.I. 1136, S.I. 1246
ST-50	Cutter	S.I. 1092
ST-51	Cutter	S.I. 1092
ST-52	Cutter	S.I. 1092
ST-53	Cutter	S.I. 1092
ST-54	Cutter	S.I. 1092
ST-55	Cutter	S.I. 1092
ST-56	Cutter	S.I. 1092
ST-57	Cutter	S.I. 1092
ST-58	Cutter	S.I. 1092
ST-62	Driver	S.I. 1092
ST-63	Adapter	S.I. 1092
ST-64	Drift	S.I. 1092
ST-65	Drift	S.I. 1092
ST-66	Pilot	S.I. 1092
ST-67	Pilot	S.I. 1092
ST-71	Gage	S.B. 293, S.I. 1088, S.B. 388
ST-71-8	Gage Adapter	S.B. 388
ST-73	Gage	S.I. 1143
ST-78	Plierwrench	S.B. 302, S.I. 1296
ST-83	Wrench	S.I. 1029
ST-84	Wrench	S.I. 1029
ST-91	Gage	S.I. 1143
ST-92	Driver	S.I. 1143

Teel No	Nome	See Latest Revision
Tool No.	Name	of Publication No.
ST-93	Fixture	S.I. 1143
ST-94	Gage	S.I. 1143
ST-95	Weight	S.I. 1143
ST-96	Arbor	S.I. 1143
ST-105	Fixture	S.I. 1073
ST-107	Wrench	S.I. 1098
ST-112	Pilot	S.I. 1117
ST-113-1	Reamer	S.I. 1425
ST-113-2	Reamer	S.I. 1425
ST-115	Tool	S.B. 253, S.I. 1098, S.I. 1111, S.I. 1342
ST-122	Plate	S.I. 1112, S.I. 1123
ST-123	Plate	S.I. 1112, S.I. 1123
ST-124	Drill	S.I. 1112, S.I. 1123
ST-125	Reamer	S.I. 1112, S.I. 1123
ST-126	Gage	S.I. 1112, S.I. 1123
ST-131	Gage	SL. L160, S.I. 1129
ST-143-1	Reamer	S.I. 1342, S.I. 1425
ST-143-2	Reamer	S.I. 1342, S.I. 1425
ST-144	Fixture	S.I. 1112
ST-145	Cutter	S.I. 1112
ST-146	Holder	S.I. 1112
ST-147	Ball	S.I. 1114
ST-148	Spacer	S.I. 1114, S.I. 1236
ST-149	Fixture	S.I. 1114, S.I. 1236
ST-150	Reamer	S.I. 1114
ST-155	Gage Stop Coller	S.I. 1425
ST-156 ST-157	Stop Collar Drift	S.I. 1112, S.I. 1123
ST-157 ST-158	Puller ("V" Pulley)	S.I. 1112 S.I. 1283
ST-168	Driver	S.I. 1145
ST-169	Fixture	S.I. 1145
ST-170	Drift	S.I. 1145
ST-171	Tool	S.I. 1145
ST-172	Puller Set	S.L. L195
ST-179	Fixture	S.I. 1136
ST-180	Reamer	S.I. 1136
ST-181	Reamer	S.I. 1136
ST-184	Repair Kit	S.I. 1122, S.L. L162
ST-190-2	Socket	S.B. 387, S.I. 1231
ST-198	Crimping Tool	S.I. 1153
ST-199	Counterbore	S.I. 1136
ST-210	Reamer	S.I. 1142
ST-211	Reamer	S.I. 1142
ST-212	Blocks	S.I. 1142
ST-222	Plate	S.I. 1112, S.I. 1029, S.I. 1123, S.I. 1290
ST-226	Gage	S.I. 1168
ST-227	Fixture	S.I. 1168
ST-228	Counterbore	S.I. 1168
ST-229	Pilot	S.I. 1168
ST-230	Drive	S.I. 1168

Teel No	Nama	See Latest Revision
Tool No.	Name	of Publication No.
ST-231	Reamer	S.I. 1168
ST-232	Fixture	S.I. 1092
ST-236	Arbor	S.I. 1092 S.I. 1184
ST-237	Arbor	S.I. 1184
ST-243	Drill Bushing	S.I. 1172
ST-244	Reamer	S.I. 1172 S.I. 1172
ST-245	Drill Bushing	S.I. 1172 S.I. 1172
ST-246	Reamer	S.I. 1172
ST-248	Countersink	S.I. 1172
ST-249	Drift	S.I. 1172
ST-250	Fixture	S.I. 1092
ST-252	Fixture	S.I. 1072 S.I. 1112
ST-252 ST-253	Driver	S.I. 1168
ST-254	Reamer	S.I. 1209
ST-255	Reamer	S.I. 1209
ST-256	Fixture	S.I. 1209
ST-264-B	Probe	S.I. 1187
ST-264-C	Probe	S.I. 1187
ST-265	Extension	S.I. 1187
ST-266	Compresssor	S.I. 1192, S.I. 1425
ST-267	Reamer	S.I. 1200
ST-269	Cutter	S.I. 1112
ST-270	Plate	S.I. 1112, S.I. 1123
ST-271	Puller	S.I. 1123, S.I. 1290
ST-273	Countersink	S.I. 1168
ST-274	Counterbore	S.I. 1168
ST-275	Driver	S.I. 1168
ST-276	Drift	S.I. 1168
ST-277	Fixture	S.I. 1168
ST-280	Fixture	S.I. 1142
ST-289	Swaging Tool	S.I. 1355
ST-291	Driver	S.I. 1225, S.B. 326
ST-299-1	Reamer	S.I. 1236
ST-299-2	Reamer	S.I. 1236
ST-299-3	Reamer	S.I. 1236
ST-300-1	Sizing Ball	S.I. 1236
ST-300-2	Sizing Ball	S.I. 1236
ST-300-3	Sizing Ball	S.I. 1236
ST-302	Drift	S.I. 1256, S.I. 1430
ST-303	Drift	S.I. 1256
ST-304	Drift	S.I. 1256
ST-305	Driver	S.I. 1225
ST-309-1	Reamer	S.I. 1116, S.I. 1425
ST-309-2	Reamer	S.I. 1116, S.I. 1425
ST-310 ST-314	Gage	S.B. 388
	Gage Reamer	S.I. 1116, S.I. 1425 S.I. 1116, S.I. 1425
ST-315 ST-316	Driver	S.I. 1116, S.I. 1425 S.I. 1290
ST-317	Driver	S.I. 1290 S.I. 1290
ST-318	Gage	S.I. 1290 S.I. 1211
51-510	Cuec	5.1. 1211

Tool No.	Name	See Latest Revision of Publication No.
ST-319	Fixture	S.I. 1211
ST-322	Wrench	S.I. 1029
ST-323	Counterbore	S.I. 1027 S.I. 1123
ST-324	Pilot	S.I. 1123 S.I. 1123
ST-325	Stop Collar	S.I. 1123 S.I. 1123
ST-327	Plate	S.I. 1123 S.I. 1123
	Reamer	
ST-328-2 ST-320	Fixture	S.I. 1123 S.I. 1202
ST-329 ST-329-1	Fixture	S.I. 1292 S.I. 1292
ST-329-2	Stand	S.I. 1292 S.I. 1292
ST-331	Gage	S.I. 1232 S.I. 1123
ST-332	Driver	S.I. 1123 S.I. 1123
ST-338	Reamer	S.I. 1125 S.I. 1116, S.I. 1425
	Former	S.I. 1110, S.I. 1425 S.I. 1172
ST-340 ST-354		
ST-354	Reamer and Stop Puller	S.I. 1297
ST-356	Fixture	S.I. 1297
ST-357	Reamers	S.I. 1297 S.I. 1225, S.B. 326
ST-360 ST 361	Shroud Tube Tool	S.I. 1225, S.B. 520 S.I. 1297
ST-361	Reamer	
ST-362	Cutter	S.I. 1297 S.I. 1297
ST-363 ST-364	Fixture	
		S.I. 1297
ST-365 ST 366 5	Flaring Tool	S.I. 1297 S.I. 1200
ST-366-5	Reamer	S.I. 1290
ST-366-1	Reamer	S.I. 1290
ST-367 ST 372	Wrench Drill Jig	S.I. 1029
ST-372 ST 376	Holder	S.I. 1292 S.I. 1207
ST-376		S.I. 1297
ST-377 ST 378	Fixture Driver	SI.1312
ST-378 ST-379	Drill	S.I. 1312 S.I. 1312
	Reamer	S.I. 1312 S.I. 1312
ST-380 ST-383	Oil Seal Tool	S.I. 1312 S.I. 1303 S.I. 1324
ST-387	Fixture	S.I. 1303, S.I. 1324 S.I. 1011
ST-388	Reamer, Guide and Stop	S.I. 1316
ST-389	Separator Tool	S.I. 1123
ST-394	Wrench	S.I. 1029
ST-394 ST-395	Tester	S.I. 1029 S.I. 1308
ST-418	Tool	S.L. L196
ST-419	Compressor, Valve Spring	
ST-419 ST-427	Reamer	S.B. 435 S.I. 1366
ST-427 ST-435	Reamer	S.I. 1300 S.I. 1394
ST-435 ST-436	Reamer	
ST-430 ST-439	Countersink	S.I. 1394 S.I. 1172
ST-439 ST-474	Hydraulic Tool	S.I. 1172 S.I. 1352, S.B. 424, S.B. 435
51-4/4	Tryutautic 1001	ы. 1 <i>552</i> , б.р. 424, б.р. 455

OBSOLETE SERVICE TOOLS

Tool No.	Description
218-В	Socket, Spark Plug Wrench (Replaced by ST-288)
1121-B	Wrench - Cylinder Base Nut (Replaced by ST-367)
1121 B 1130-B	Compressor - Valve Spring (Replaced by ST-25)
1228-B	Wrench - Thrust Bearing Locknut (Replaced by 40714)
61550	Wrench, Cylinder Base Nut (Replaced by ST-367)
61551	Wrench, Cylinder Base Nut (Replaced by ST-394, ST-375)
61552	Extension - Cylinder Base Nut Wrench (No Replacement)
61678	Bar - Wrench (No Replacement)
64507	Gage, Plug Valve Guide OD (Replaced by ST-429-5)
64509	Gage, Plug Valve Guide OD (Replaced by ST-429-1)
64511	Gage, Plug Valve Guide OD (Replaced by ST-429-2)
64516-1	Pilot - Valve Seat Removal (See latest revision of S.I. 1092)
64517	Holder - Remove Valve Seat Counterbore (See latest revision of S.I. 1092)
64518	Counterbore - Remove Exhaust Valve Seat (See latest revision of S.I. 1092)
64519	Counterbore - Remove Valve Seat (Exhaust) (See latest revision of S.I. 1092)
64520	Fixture - Remove and Replace Valve Seat (Replaced by ST-250)
64521	Drift, Replace Exhaust Valve Seat (Replaced by ST-65)
64522	Wrench, Cylinder Base Nut (Replaced by ST-394)
64523	Wrench, Cylinder Base Nut (Replaced by ST-367)
64525	Drift - Replace Intake Valve Seat (Replaced by ST-65)
64527	Drift - Piston Pin (Replaced by 64843)
64547	Drift, Crankshaft Oil Tube (Replaced by 64548)
64565	Drift, Main Bearing Oil Tubes (No Replacement)
64571	Gage, Plug Valve Guide OD (Replaced by ST-429)
64572	Wrench, Cylinder Base Nut (Replaced by ST-394)
64579	Drift, Main Bearing Oil Tubes (No Replacement)
64581	Plate - Engine Mounting (No Replacement)
64582	Pointer - Ignition Timing (No Replacement)
64583	Gage, Flat Plug Rejection - Valve Guide ID (Replaced by ST-81)
64597-1	Fixture - Remove, Replace, Burnish Connecting Rod Bushing (Replaced by 64597)
64598	Drift - Replace Generator Mounting Bushing (No Replacement)
64600	Gage, Plug - Generator Mounting Bushing Finished ID (No Replacement)
64609	Shroud (No Replacement)
64635	Compressor - Valve Spring (Replaced by ST-25)
64639	Gage, Plug Valve Guide OD (Replaced by ST-429-3)
64642	Drift - Valve Seat Replacement (Exhaust and Intake) (Replaced by ST-64)
64645	Puller - Valve Guide (Replaced by ST-49)
64670	Puller, Generator Drive Shaft Gear (No Replacement)
64678-2	Reamer, Valve Guide OD (Replaced by ST-430-5)
64678-3	Reamer, Valve Guide OD (Replaced by ST-430-1)
64678-4	Reamer, Valve Guide OD (Replaced by ST-430-2)
64678-5	Reamer, Valve Guide OD (Replaced by ST-430-3)
64688	Wrench, Pinion Cage Locknut (No Replacement)
64690	Driver - Relief Valve Sleeve (Replaced by ST-215)
64691 64692	Counterbore - Valve Seat Removal (Intake) (See latest revision of S.I. 1092)
	Counterbore - Valve Seat Removal (Exhaust) (See latest revision of S.I. 1092)
64693 64694	Counterbore - Valve Seat Removal (Intake) (See latest revision of S.I. 1092) Counterbore - Valve Seat Removal (Intake) (See latest revision of S.I. 1092)
64694 64695	Drift - Valve Seat Replacement (Replaced by ST-64)
64696	Fixture - Valve Seat Replacement (Angle Heads) (Replaced by ST-232)
64699	Drift, Piston Pin Puller (Replaced by 64843)
64702	Wrench, Pinion Cage Nut (No Replacement)
64703	Wrench, Engine Rotor (Replaced by 64764)
74708	Holder - Accessory Drive Shaft (Replaced by ST-173, ST-174)
/ 1/00	101001 11000001 Dire binne (repriede 05 01 170, 01 171)

OBSOLETE SERVICE TOOLS (CONT.)

Tool No.	Description
64717	Wrench - Cylinder Base Nut (Replaced by 64942)
64718	Wrench - Cylinder Base Nut (Replaced by 64943)
64722	Wrench, Pinion Cage Nut (No Replacement)
64724	Gage - Flat Plug Rejection - Valve Guide ID (Replaced by ST-81)
64725	Gage, Plug - Valve Guide ID (No Replacement)
64726	Reamer, Valve Guide ID (No Replacement)
64727	Drift, Piston Pin Removal (Replaced by 64843)
64753	Tool - Vertical Lifting (Replaced by ST-48)
64755	Drift, Crankshaft Rear Oil Tube (Replaced by ST-44)
64760	Skid, A-Frame Overhaul (Replaced by ST-278)
64761	Wrench, Magneto Bushing (No Replacement)
64762	Stand (Engine), A-Frame Overhaul (Replaced by ST-162)
64786	Handle, Cutter, Valve Seat Recess (Replaced by ST-62, ST-63)
64787-1, -2, -3	Cutter - Valve Seat Recess (Exhaust) (See latest revision of S.I. 1092)
64788-1, -2, -3	Pilot - Valve Seat Recess Cutter (Exhaust and Intake) (See latest revision of S.I. 1092)
64789-1, -2, -3	Cutter - Valve Seat Recess (Intake) (See latest revision of S.I. 1092)
64790-1, -2, -3	Cutter - Valve Seat Recess (Intake) (See latest revision of S.I. 1092)
64791-1, -2, -3	Cutter - Valve Seat Recess (Exhaust) (See latest revision of S.I. 1092)
64792-1, -2, -3	Cutter - Valve Seat (See latest revision of S.I. 1092)
64793-1, -2, -3 64794-1, -2, -3	Cutter - Valve Seat Recess (Intake) (See latest revision of S.I. 1092)
64795-1, -2, -3	Cutter - Valve Seat Recess (Intake) (See latest revision of S.I. 1092) Cutter - Valve Seat Recess (Exhaust) (See latest revision of S.I. 1092)
64800	Club - Test (Use 64801 or ST-456)
64804	Club - Test (No Replacement)
64805	Club - Test (No Replacement)
64806	Club - Test (Four-Blade) (Replaced by 64773)
64808	Jig - Drill, Rocker Shaft Bushing Dowel Hole (No Replacement)
64809	Jig - Dowel, Installing, Rocker Shaft Bushing (No Replacement)
64817	Drift, Dowel Installation, Rocker Shaft Bushing (No Replacement)
64818	Cutter - Rocker Shaft Bushing Dowel (No Replacement)
64832	Reamer - 0.005 o/s Inner Rocker Shaft Bushing Hole in Cylinder Head (Replaced by 64338)
64833	Reamer - 0.010 o/s Inner Rocker Shaft Bushing Hole in Cylinder Head (Replaced by 64839)
64837	Plate - Engine Mounting (No Replacement)
64842	Plate - Engine Mounting (No Replacement)
64869	Tool - Install and Remove Propeller Flange Bushing (Replaced by ST-115)
64873	Fixture - Ream Crankshaft Counterweight Holes (Replaced by ST-280)
64873-10	Plug, Crankshaft Counterweight (Replaced by ST-280-10)
64873-11	Plug, Crankshaft Counterweight (Replaced by ST-280-11)
64879	Spacer - Adjustable - Install Bushings in Counterweights (Replaced by ST-93)
64880	Counterbore - Exhaust Valve Seat Removal (See latest revision of S.I. 1092)
64881	Counterbore - Intake Valve Seat Removal (See latest revision of S.I. 1092)
64882-1, -2, -3 64883-1, -2, -3	Cutter - Intake Valve Seat Recess (See latest revisio of S.I. 1092) Cutter, Valve Seat Recess (Exhaust) (See latest revision of S.I. 1092)
64894-18	Gasket, Test Drive (Use 74822 Gasket)
64896	Drift, Installation, Expansion Plug (Replaced by 64681)
64897-1	Reamer (No Replacement)
64897-2	Reamer (No Replacement)
64911	Gage, Check Cam Lobe Wear (No Replacement)
64912, -1	Cutter - Copperlytic Exhaust Valve Seats (No Replacement)
64913, -1	Cutter - Copperlytic Intake Valve Seats (No Replacement)
64920	Gage, Flat Plug Rejection - Exhaust Valve Guide I.D. (See Table of Limits)

OBSOLETE SERVICE TOOLS (CONT.)

Tool No.	Description
64921	Drift - Valve Seat Replacement (Intake) (Replaced by ST-64)
64922-1, -2, -3	Cutter - Intake Valve Seat (See latest revision of S.I. 1092)
64924 i, 2, 3	Reamer, Valve Guide OD (Replaced by ST-432)
64924-1	Reamer, Valve Guide OD (Replaced by ST-432-5)
64924-2	Reamer, Valve Guide OD (Replaced by ST-432-1)
64924-3	Reamer, Valve Guide OD (Replaced by ST-432-2)
64924-4	Reamer, Valve Guide OD (Replaced by ST-432-3)
64926	Gage, Flat Plug Rejection - Exhaust Valve Guide I.D. (See Table of Limits)
64928	Gage, Plug Valve Guide OD (Replaced by ST-431-5)
64929	Gage, Plug Valve Guide OD (Replaced by ST-431-1)
64930	Gage, Plug Valve Guide OD (Replaced by ST-431-2)
64931	Gage, Plug Valve Guide OD (Replaced by ST-431-3)
64935	Hub and Cone Assembly, (Replaced by ST-415)
64937	Wrench - No. 30 Spline (Replaced by ST-38)
64938	Club - Test (Replaced by 64783)
64940	Gage, Plug Valve Guide OD (Replaced by ST-431)
64969	Gage, Dry Tappet Clearance (Replaced by ST-279)
64978	Reamer, Rocker Shaft Bushing Hole (Replaced by ST-427)
64985	Bolt - Propeller (See 64801 or ST-456)
64986	Flange, Propeller (See 64801 or ST-456)
65521	Handle, Offset - Spark Plug Wrench (Replaced by ST-345)
65522	Wrench - Cylinder Base Nut (Replaced by ST-375)
65523	Wrench - Cylinder Base Nut (Replaced by ST-374)
65526	Socket - Universal Joint (No Replacement)
65528	Gage, Valve Clearance - Dry Tappet (Replaced by ST-23)
ST-41	Fixture - Spotface, Mill contour of Stretch Bolt in Connecting Rod Cap (No
	Replacement)
ST-42	Drill - Special Flat Bottom Core, Mill Contour in Connecting Rod Cap for Stretch
	Bolt (No Replacement)
ST-59	Pilot - Valve Seat Cutter (No Replacement)
ST-60	Pilot - Valve Seat Cutter (No Replacement)
ST-61	Pilot - Valve Seat Cutter (No Replacement)
ST-74	Gage Ring (No Replacement)
ST-85	Fixture - Drill Jig (No Replacement)
ST-90	Reamer - Valve Guide OD (No Replacement)
ST-97	Gage - Counterweight Hole Location (No Replacement)
ST-98	Weight - Counterweight Master (No Replacement)
ST-106	Drift - Crankshaft Oil Plug (No Replacement)
ST-110	Fixture - Ream and Back Spotface Reduction Gear Housing (No Replacement)
ST-116	Puller - Remove Sludge Tubes from Crankshaft (Replaced by 64784)
ST-117	Gage, Flat Plug Rejection - Exhaust Valve Guide I.D. (See Table of Limits)
ST-118 ST-110	Gage, Flat Plug Rejection - Intake Valve Guide I.D. (Replaced by ST-81)
ST-119 ST-120	Gage, Flat Plug Rejection - Exhaust Valve Guide I.D. (See Table of Limits)
ST-120 ST-121	Gage, Flat Plug Rejection - Exhaust Valve Guide I.D. (See Table of Limits) Gage, Flat Plug Rejection - Exhaust Valve Guide I.D. (See Table of Limits)
ST-121 ST-127-1	Fixture, Test - Density Controller Calibration (Replaced by ST-282, ST-282-38)
ST-130	Drill, Piloted - Counterbore Crankcase for Oil Seal Retainer (No Replacement)
ST-130 ST-132	Meter - Fuel Flow (No Replacement)
ST-152 ST-151	Reamer - Hand - Valve Guide ID (Short) (Exhaust) (Replaced by ST-338)
ST-157	Driver - Dowel Crankcase (Replaced by ST-332)
ST-175	Reamer, Crankcase Vent Hole (No Replacement)
ST-176	Fixture, Reaming Valve Guide Hole in Cylinder Head (No Replacement)
ST-178	Reamer (Piloted) Rework Valve Guide Hole in Cylinder Head (No Replacement)
ST-181	Reamer, Valve Guide I.D. Exhaust (Replaced by ST-181-1 and ST-181-2)
21 101	

OBSOLETE SERVICE TOOLS (CONT.)

Tool No.	Description
ST-182	Wrench - Cylinder Base Nut 3/8 in. (End Spline) (No Replacement)
ST-183	Wrench - Cylinder Base Nut 1/2 in. (End Spline) (No Replacement)
ST-185	Bushing Plate, (4 Cylinder) Crankcase Body Fit Stud (No Replacement)
ST-186	Bushing Plate, (6 Cylinder) Crankcase Body Fit Stud (No Replacement)
ST-187	Drill Jig, (4 Cylinder) Crankcase Bushing Pin (No Replacement)
ST-188	Drill Jig, (6 Cylinder) Crankcase Bushing Pin (No Replacement)
ST-189	Counterbore, Crankcase Bushing "O" Ring (No Replacement)
ST-190	Wrench - Injector Nozzle (Replaced by ST-190-2)
ST-190-1	Wrench - Injector Nozzle (Replaced by ST-190-2)
ST-192	Gage, Flat Plug Rejection - Exhaust Valve Guide I.D. (See Table of Limits)
ST-193	Fixture, Test (Adjustable) Absolute Pressure Controller (Replaced by ST-282, ST-282-38)
ST-194	Fixture, Test - Absolute Pressure Controller (Replaced by ST-282, ST-282-38)
ST-200	Rings, Engine Mounting (Replaced by 64759)
ST-202	Shroud, Cooling - (Replaced by 64612 and ST-352)
ST-204	Reamer, Valve Guide ID (Exhaust) (No Replacement)
ST-205	Gage, Plug, Valve Guide ID (Exhaust) (No Replacement)
ST-206	Reamer, Valve Guide ID (Exhaust) (No Replacement)
ST-207	Gage, Flat Plug Rejection (Exhaust) (No Replacement)
ST-208	Gage, Flat Plug Rejection (Exhaust) (No Replacement)
ST-209	Gage, Plug, Valve Guide ID (Exhaust) (No Replacement)
ST-214	Wrench - Cylinder Base Nut (No Replacement)
ST-218	Bearingizer Internal Thru 2.4210/2.4205 Dia. (No Replacement)
ST-219	Bearingizer Internal Thru 2.2875/2.2870 Dia. (No Replacement)
ST-238	Skid, Engine A-Frame Overhaul (Replaced by ST-278)
ST-258	Reamer, Valve Guide O.D. (No Replacement)
ST-282	Test Stand - (See Latest Revision of S.L. 184)
ST-282-37	Kit Vacuum System - (See Latest Revision of S.L. 184)
ST-282-38	Test Stand - (See Latest Revision of S.L. 184)
ST-290	Driver, Bearing Dowel (Replaced by ST-291)
ST-308	Reamer, Hand Short Valve Guide (Replaced by ST-388)
ST-311	Driver, Intake Pipe Pin (No Replacement)
ST-328-1	Reamer, Crankcase Thru-Stud Dowel (No Replacement)
ST-330	Gage, Plug and Depth, Crankcase Thru-Stud Dowel (No Replacement)
ST-331	Gage, Plug and Depth, Crankcase Thru-Stud Dowel (No Replacement)
ST-335	Counterbore (No Replacement)
ST-336 ST-337	Counterbore (No Replacement)
ST-337 ST-367	Fixture (No Replacement) Wrench - Cylinder Base Nut (Replaced by ST-374)
ST-373	Fixture (No Replacement)
ST-391	Bushing Pilot, (Reamer) Oil Cooler Bypass Valve Housing (No Replacement)
ST-392	Driver, Seat - Thermostatic Control Valve (No Replacement)
ST-393	Bushing Pilot, (Reamer) Oil Cooler Bypass Valve Housing (No Replacement)
ST-394	Wrench - Cylinder Base Nut (Replaced by ST-375)
ST-395	Tester, Magneto Pressurization (No Replacement)
ST-414	Extractor, Hydraulic Lifter Plunger (Replaced by ST-474)
ST-430	Reamer, Valve Guide O.D. (No Replacement)
ST-432	Reamer, Valve Guide O.D. (No Replacement)
31 .02	