



HALO CHARGE IT ⚡ 3000.



Operating Instructions



**H**®

## What's Included With Your HALO

Detachable  
Standard USB-  
Micro USB cable



Detachable  
Standard USB-  
8-pin cable



30-pin tip



## Getting To Know Your HALO Phone Charger


Power button

Recharge Micro USB IN port



LED battery  
indicator

Standard  
USB OUT port



## To Turn On/Off Your HALO Charger


To turn on, press the power button, and the LED lights on the front of your charger will illuminate. To turn off, press and hold the power button for three seconds. Your HALO charger has an auto On/Off feature. Your HALO charger will turn on when plugged into any electronic device. It will turn off after 30 seconds of being unplugged from an electronic device.

Power button




## Charging Your HALO Charger

Wall Adapter  
(not included)



Computer (not included)







1. Using the provided detachable Standard USB-Micro USB cable, plug the Micro USB end into your charger's Micro USB IN port.
2. Next, connect the Standard USB end of the detachable Standard USB-Micro USB cable into the Standard USB port on your computer (not included) or an AC adapter (not included) that accepts Standard USB. Your HALO charger will automatically begin charging.






**Note: When recharging your HALO charger please allow 6 hours to fully recharge the unit.**

## Check Your HALO Chargers Battery Level

Press and release power button to display battery level.

Indicator Lights	How To Read	Amount of Charge
	One solid light	0%-25%
	Two solid lights	26%-50%
	Three solid lights	51%-75%
	Four solid lights	76%-100%

## Reading Your LED Battery Indicator While Charging Your HALO Charger

Indicator Lights	How To Read	Amount of Charge
	First light blinking	0%-25%
	First light solid, second light blinking	26%-50%
	First two lights solid, third light blinking	51%-75%
	First three lights solid, fourth light blinking	76%-99%
	All four lights solid	100% fully charged


# Choosing the Appropriate Cable/Tip to Charge Your Personal Electronic Device

Model

Corresponding Cable/Tip


---

iPhone 4, 4s, iPod classic,  
iPad 1, 2, 3, iPod nano  
& earlier models



Standard USB-Micro USB Cable  
+ 30-pin tip

iPhone 5, 5c, 5s, iPad 4,  
iPad Mini, iPad w/retina,  
iPod nano w/multi-touch  
and retina displays



Standard USB- 8-pin Cable

Android, Samsung  
and Windows Phones  
& Tablets



Standard USB-Micro USB Cable

## Intelligent Recognition

Your HALO charger is programmed with an intelligent recognition system to achieve higher compatibility for charging different mobile phones. If it does not charge when connected to your mobile phone, please restart the power charger.

## **Charging Your Personal Electronic Device iPhone 4, 4s, iPod Classic, iPod Nano and Earlier iPhone/iPod Models**

1. Using the provided Standard USB-Micro USB cable, plug the Standard USB end into the USB OUT port of your HALO charger.
2. Connect the provided 30-pin tip into the Micro USB end of the provided Standard USB-Micro USB cable.
3. Plug your personal electronic device into the 30-pin tip and your device will automatically begin charging. If your HALO charger does not power on automatically, please manually depress the power button.
4. Your HALO charger is also compatible with the charging cable provided with your personal electronic device. To use, plug the Standard USB end of the cable into the Standard USB OUT port of your HALO charger.

## **iPhone 5, 5c, 5s iPod Nano w/Multi-Touch and Retina Displays**

1. Using the provided Standard USB- 8-pin cable, plug the Standard USB end into the USB OUT port of your HALO charger.
2. Plug your personal electronic device into the 8-pin end of the provided Standard USB- 8-pin cable. Your device will automatically begin charging. If your HALO charger does not power on automatically, please manually depress the power button.
3. Your HALO charger is also compatible with the charging cable provided with your personal electronic device. To use, plug the Standard USB end of the cable into the Standard USB OUT port of your HALO charger.

## **Android, Samsung and Windows Phones/Tablets**

1. Using the provided Standard USB-Micro USB cable, plug the Standard USB end into the USB OUT port of the HALO charger.

2. Plug your personal electronic device into the Micro USB end of the provided Standard USB-Micro USB cable. Your device will automatically begin charging. If your HALO charger does not power on automatically, please manually depress the power button.

3. Your HALO charger is also compatible with the charging cable provided with your personal electronic device. To use, plug the Standard USB end of the cable into the Standard USB OUT port of your HALO charger.


### **Other Personal Electronic Devices**

Certain electronic devices (such as Nook Color, Nook HD, Samsung Galaxy Tab 2 & 3) have special connectors. If your personal electronic device does not accept one of the provided connectors, please use the cable provided with your device for charging. Plug the Standard USB end of the cable that came with your personal electronic device into the Standard USB OUT port of your HALO charger. Plug your personal electronic device into the other end of the cable and your device will automatically begin charging. If your HALO charger does not power on automatically, please manually depress the power button.

### **Compatible with:**

Mobile phones, Tablets, PSP, NDS, MP3, MP4, MP5, Bluetooth, GPS, Cameras and more

### **Example of Charging Your Personal Electronic Device:**





## Additional Usage Time When Using the HALO Charge It 3000:

Device	Approximate Average Usage Time per Device
Samsung Galaxy SIII	10.7 hours of talk time
Samsung Galaxy S4	12.9 hours of talk time
Samsung Galaxy S5	11.5 hours of talk time
Samsung Galaxy Note II	4.2 hours of video playing
Samsung Galaxy Tab II	2.8 hours of video playing
Samsung Galaxy Tab III	2.4 hours of web surfing on WiFi
iPhone 4	9.2 hours of talk time on 3G
iPhone 5	8.2 hours of talk time on 3G
iPhone 5C	11.9 hours of talk time on 3G
iPhone 5S	12.4 hours of talk time on 3G
iPad Mini	3.5 hours of web surfing cellular data network usage
iPad 2 <sup>nd</sup> Gen	2.0 hours of web surfing cellular data network usage
iPad 4 <sup>th</sup> Gen	1.4 hours web surfing cellular data network usage
iPad Air	2.1 hours of web surfing cellular data network usage
Blackberry Z10	10.5 hours of talk time on 3G
Kindle Fire	2.3 hours of reading, web surfing or video playing
Nook Color	1.6 hours of reading
Google Nexus 7	3.8 hours active use

### About RFID

RFID stands for 'Radio Frequency Identification.' Newer credit cards and Passports may contain an RFID chip, which allows wireless, automatic transfer of data. Check with your credit card company or Passport issuer to see if your card contains an RFID chip. Your HALO Charge It 3000 is lined with RFID blocking material that blocks the transfer of data between your personal credit cards and wireless RFID readers. The RFID material is located throughout the main lining of the flap, however, in order to be fully protected and blocked, your flap must be closed, so all contents are effectively shielded. Exposing your HALO Charge It 3000 to high heat (e.g. with an iron, oven, dryer, etc.), high humidity or getting it wet will damage the RFID material and may prohibit the RFID blocking from functioning.

## **Storing/Handling/Cleaning**

- **IMPORTANT:** Do not disassemble your HALO charger from the RFID flap. Your HALO charger is intended to be permanently adhered to the original RFID flap. Do not attempt to remove.
- Do not get wet or store in extreme temperature conditions.
- Do not disassemble or attempt to repair yourself.
- Use a soft cloth with soap to clean the exterior of your HALO charger. Do not use liquid detergent or chemicals of any kind.

## **Safety Precautions**

- Your HALO charger has been designed and manufactured to ensure personal safety. Please read the following carefully before using. Incorrect operation or incompatibility with your personal electronic device may result in reduced battery performance or damage.
- Carefully read the operating instructions, and use your HALO charger correctly.
- **Caution:** The lithium-ion rechargeable battery used in this charging device may present a risk of fire or chemical burn if mistreated. Do not disassemble, expose to heat above 212°F (100°C) or incinerate.
- Misusing or incorrectly connecting your HALO charger may cause electric shock to users and damage equipment. Your HALO charger may become warm under extended high power operation. During operation, keep your HALO charger away from materials that may be affected by these temperatures.
- When used correctly, lithium-ion rechargeable batteries provide a safe and dependable source of portable power. However, if they are misused or abused, this may result in leakage, burns, fire or explosion, causing personal injury or damage to other devices.

- Do not disassemble your HALO charger. There are no user-serviceable parts inside. Incorrect reassembly may result in shock or fire hazard.
- Do not drop or subject to strong impacts. Do not operate your HALO charger if it has received a sharp blow, or otherwise been damaged in any way.
- Do not expose your HALO charger to moisture, water, rain, or snow.
- Do not insert any object into the ports or openings of your HALO charger.
- Never charge your HALO charger unattended.
- There is a risk of the batteries exploding, overheating, or igniting. Do not disassemble, modify, heat or short-circuit the batteries. Do not place in fire or leave in hot places. Do not expose to direct sunlight.
- Only charge your HALO charger by the specified method with the specified USB cable.
- In the unlikely event of leakage or explosion use sand or a chemical fire extinguisher.
- Batteries should be recycled or disposed of as per state and local guidelines.

## **Specifications**

Battery Cell: rechargeable lithium polymer battery

Capacity: 3000 mAh

Micro USB Input: 5V/1A

USB Output: 5V/1A

Dimensions: 4"x 2.8"x 0.2" (105 x 70 x 6 mm)

## **FCC Compliance Statement**

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions:

- This device may not cause harmful interference, and
- This device must accept any interference received, including interference that may cause undesired operation.

## 15.21

You are cautioned that changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

### 15.105(b)

This equipment has been tested and found to comply with the limits for Class B digital devices, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

## Limited Warranty

### What does this limited warranty cover and how long is the coverage?

Halo2Cloud, LLC ("HALO") warrants its products to be free from defects in materials and workmanship under normal use and service for a period of one (1) year beginning on the date you purchase the product.

### **What is not covered by this limited warranty?**

This Limited Warranty does not cover defects or damage due to: (1) accidents, acts of God, misuse, abuse, abnormal use, abnormal conditions, improper storage, or exposure to liquid or moisture, (2) unusual or abnormal physical force or impact, including dropping of the product, (3) connection of the product to improper voltage supply, or (4) attempted repair or modification by anyone other than HALO or a facility authorized by HALO.

### **What are HALO's obligations under this limited warranty?**

Provided that you comply with the conditions of this Limited Warranty, during the duration of this Limited Warranty HALO will repair or replace the product, at its sole option, without charge. When repairing or replacing a product, HALO may, at its sole option, repair or replace the product with new, used, rebuilt or reconditioned parts or products. HALO will warrant any product that is repaired or replaced under this Limited Warranty for a period equal to the remaining time period under the original Limited Warranty or ninety (90) days, whichever is longer.

### **How do you get service?**

To obtain service under this Limited Warranty, you must (1) within ninety (90) days of the purchase of the product, register you product at [www.halo2cloud.com](http://www.halo2cloud.com), (2) obtain a return materials authorization number (RMA) by contacting HALO at (888) 907-6274, and (3) return the product to HALO at 148 Eastern Boulevard, Glastonbury, Connecticut 06033, Attention: Returns

Department, together with your RMA and the sales receipt or similar proof of sale showing the original date of purchase of the product and the seller's name and address. If HALO determines that your product is not covered by this Limited Warranty, HALO will notify you of such determination and you may decide whether to have HALO return the product to you or attempt to repair the product. In this case, you will be required to pay all shipping and labor charges for the repair or return of your product, as applicable.

### **What are the limits of HALO's liability?**

This Limited Warranty sets forth the full scope of HALO's obligations and liabilities with respect to the product. All implied warranties, including, without limitation, implied warranties of merchantability and fitness for a particular purpose, are limited to the duration of this Limited Warranty. In no event shall HALO be liable for any incidental, special, consequential or punitive damages or any damages or losses of or to electronic equipment or products that are used with any of HALO's products.

### **How does state law relate to this limited warranty?**

Some states do not allow limitation on how long an implied warranty lasts or the disclaimer or limitation of incidental or consequential damages. Therefore, some or all of the disclaimers and limitations above may not apply to you.

To contact us, email us at  
support@halo2cloud.com  
or call 888-907-6274

HALO INTERNATIONAL SECZ LTD.  
www.halo2cloud.com

The HALO cloud logo is  
a registered trademark of  
HALO2CLOUD, LLC

**Patents Pending** Made in China

The material used on this item is a Man Made Material





HALO

HALO2CLOUD.COM