


# **BALLANTINE** Ditch Witch® H314

Trencher Replacement Parts



American Made.  
American Strong.™

[www.ballantineinc.com](http://www.ballantineinc.com)

Faster Service  
Better Quality  
Lower Prices

## Replacement Parts for Ditch Witch® Trenchers

Ditch Witch® is a registered trade mark of Charles Machine Works Company.

All manufacturers' names, numbers, symbols and descriptions are used for reference purposes only and it is not implied that any parts listed are the products of the manufacturers.

### Main Office

840 McKinley Street  
Anoka, Minnesota 55303

### Branch Office

675 Wesleyan Drive South West  
Atlanta, Georgia 30336

### Branch Office

2209 S. Lilac Ave.  
Rialto, California 92316

Call Toll Free To Inside Sales

1/800/328/2424

FAX 1-763-427-2277

Email: [parts@ballantineinc.com](mailto:parts@ballantineinc.com)

[www.ballantineinc.com](http://www.ballantineinc.com)

## Ditch Witch® H314 Attachment



### Bare Chain 2" Pitch Every 4th

Ballantine Part No.	Dig Depth	Description
B2000400B21	42"	Bare Chain 21 Station
B2000400B24	48"	Bare Chain 24 Station



### Bare Chain 2" Pitch Anti Back Flex


Ballantine Part No.	Dig Depth	Description
B2ABF00B42	42"	Bare Chain 42 Station
B2ABF00B48	48"	Bare Chain 48 Station



### Cup Cutter Assemblies 2" Pitch Every 4th

Ballantine Part No.	Dig Depth	Description
B2000406C21	42"	Cup Cutter Assembly 6" Cut 21 Station
B2000406C24	48"	Cup Cutter Assembly 6" Cut 24 Station
B2000408C21	42"	Cup Cutter Assembly 8" Cut 21 Station
B2000408C24	48"	Cup Cutter Assembly 8" Cut 24 Station

Wider Cutting Widths Available Upon Request




### Cup Cutter Assemblies 2" Pitch Anti Back Flex

Ballantine Part No.	Dig Depth	Description
B2ABF06C42	42"	Cup Cutter Assembly 6" Cut 42 Station
B2ABF06C48	48"	Cup Cutter Assembly 6" Cut 48 Station
B2ABF08C42	42"	Cup Cutter Assembly 8" Cut 42 Station
B2ABF08C48	48"	Cup Cutter Assembly 8" Cut 48 Station

Wider Cutting Widths Available Upon Request

## Ditch Witch® H314 Attachment



### Terminator & Cup Combination Assemblies

Ballantine Part No.	Dig Depth	Description
T2ABF06M42	42"	1/2 Terminator & 1/2 Cup 6" 42 Station
T2ABF06M48	48"	1/2 Terminator & 1/2 Cup 6" 48 Station
T2ABF08M42	42"	1/2 Terminator & 1/2 Cup 8" 42 Station
T2ABF08M48	48"	1/2 Terminator & 1/2 Cup 8" 48 Station
Wider Cutting Widths Available Upon Request		



### Bolt On Terminator Assemblies

Ballantine Part No.	Dig Depth	Description
T2ABF0642	42"	Terminator Bolt On 6" Cut 42 Station
T2ABF0648	48"	Terminator Bolt On 6" Cut 48 Station
T2ABF0842	42"	Terminator Bolt On 8" Cut 42 Station
T2ABF0848	48"	Terminator Bolt On 8" Cut 48 Station
Wider Cutting Widths Available Upon Request		



### Terminator Chains

Ballantine Part No.	Dig Depth	Description
SH20000642	42"	Terminator Bolt On 6" Cut 42 Station
SH20000648	48"	Terminator Bolt On 6" Cut 48 Station
SH20000842	42"	Terminator Bolt On 8" Cut 42 Station
SH20000848	48"	Terminator Bolt On 8" Cut 48 Station

## Ditch Witch® H314 Attachment



### Rock & Cup Combination Assemblies

Ballantine Part No.	Dig Depth	Description
B2ABF06M42	42"	1/2 Carbide & 1/2 Cup 6" Cut 42 Station
B2ABF06M48	48"	1/2 Carbide & 1/2 Cup 6" Cut 48 Station
B2ABF08M42	42"	1/2 Carbide & 1/2 Cup 8" Cut 42 Station
B2ABF08M48	48"	1/2 Carbide & 1/2 Cup 8" Cut 48 Station
Wider Cutting Widths Available Upon Request		



### Bolt On Rock & Frost Assemblies

Ballantine Part No.	Dig Depth	Description
B2ABF06R42	42"	Rock & Frost Assembly 6" Cut 42 Station
B2ABF06R48	48"	Rock & Frost Assembly 6" Cut 48 Station
B2ABF08R42	42"	Rock & Frost Assembly 8" Cut 42 Station
B2ABF08R48	48"	Rock & Frost Assembly 8" Cut 48 Station
Wider Cutting Widths Available Upon Request		



### Alligator Chains

Ballantine Part No.	Dig Depth	Description
AL200006D42	42"	Alligator Chain 6" Cut 42 Station
AL200006D48	48"	Alligator Chain 6" Cut 48 Station
AL200008D42	42"	Alligator Chain 8" Cut 42 Station
AL200008D48	48"	Alligator Chain 8" Cut 48 Station

## Ditch Witch® H314 Attachment

### Chain Repair Components For 2" Pitch Every 4th And 2" Pitch Anti Back Flex

#### Chain Repair Components For 2" Pitch Every 4th And 2" Anti Back Flex



Ballantine Part No.	OEM Part Number	Description
B2ABF00B01	N/A	Chain Repair Section Anti Back Flex



Ballantine Part No.	OEM Part Number	Description
B2000400B01	N/A	Chain Repair Section Every Fourth Pitch



Ballantine Part No.	OEM Part Number	Description
B135351	N/A	Connecting Pin & Keeper



Ballantine Part No.	OEM Part Number	Description
B135358	N/A	"T" Head Keeper

### Cup Cutters



Ballantine Part No.	OEM Part Number	Description
B135924	135-1233	Cup Cutter Right Hand



Ballantine Part No.	OEM Part Number	Description
B135925	135-1236	Cup Cutter Left Hand



Ballantine Part No.	OEM Part Number	Description
B135502	N/A	Ground Breaker Right Hand



Ballantine Part No.	OEM Part Number	Description
B135501	N/A	Ground Breaker Left Hand

### Terminator Adapters



Ballantine Part No.	OEM Part Number	Description
T20004R	136-237	Terminator Adapter Right Hand - C.C. - 4" Cut



Ballantine Part No.	OEM Part Number	Description
T20004L	136-236	Terminator Adapter Left Hand -C.C. - 4" Cut



Ballantine Part No.	OEM Part Number	Description
T20005R	136-238	Terminator Adapter Right Hand - 5" Cut



Ballantine Part No.	OEM Part Number	Description
T20005L	136-239	Terminator Adapter Left Hand - 5" Cut



Ballantine Part No.	OEM Part Number	Description
T20006R	136-241	Terminator Adapter Right Hand - 6" Cut



Ballantine Part No.	OEM Part Number	Description
T20006L	136-240	Terminator Adapter Left Hand - 6" Cut



Ballantine Part No.	OEM Part Number	Description
T20000S	N/A	Terminator Adapter Straight Cut

## Ditch Witch® H314 Attachment

### Chain Repair Components For 2" Pitch Every 4th And 2" Pitch Anti Back Flex

#### Rock & Frost Adapters



Ballantine Part No.	OEM Part Number	Description
B136036	136-036	Rock & Frost Adapter Right Hand - C.C. - 4" Cut



Ballantine Part No.	OEM Part Number	Description
B136037	136-037	Rock & Frost Adapter Left Hand -C.C. - 4" Cut



Ballantine Part No.	OEM Part Number	Description
B136038	136-038	Rock & Frost Adapter Left Hand - 5" Cut



Ballantine Part No.	OEM Part Number	Description
B136039	136-039	Rock & Frost Adapter Right Hand - 5" Cut



Ballantine Part No.	OEM Part Number	Description
B136040	136-040	Rock & Frost Adapter Right Hand - 6" Cut



Ballantine Part No.	OEM Part Number	Description
B136041	136-041	Rock & Frost Adapter Left Hand - 6" Cut



Ballantine Part No.	OEM Part Number	Description
765CRFN	N/A	Carbide Bit - Full Cap - Includes Clip



Ballantine Part No.	OEM Part Number	Description
K91	N/A	Separate Clip



Ballantine Part No.	OEM Part Number	Description
765HB	N/A	Carbide Bit - Rock Buster



Ballantine Part No.	OEM Part Number	Description
765CB	N/A	Carbide Bit - Full Cap

## Ditch Witch® H314 Attachment

### Chain Components For 2" Pitch Every 4th And 2" Pitch Anti Back Flex

#### Adapters



Ballantine Part No.	OEM Part Number	Description
B135912	N/A	Adapter For 8" Cut

Ballantine Part No.	OEM Part Number	Description
B135950	N/A	Adapter For 10" Cut

Ballantine Part No.	OEM Part Number	Description
B135913	N/A	Adapter For 12" Cut

#### Flat Spacers



Ballantine Part No.	OEM Part Number	Description
6573375	N/A	Flat Spacer 1" Thick

Ballantine Part No.	OEM Part Number	Description
V30	N/A	Flat Spacer 5/16" Thick

#### Tube Spacers



Ballantine Part No.	OEM Part Number	Description
B135952	N/A	Tube Spacer Outside Mounting

Ballantine Part No.	OEM Part Number	Description
B135951	N/A	Tube Spacer Cup Mounted Inside

Ballantine Part No.	OEM Part Number	Description
B135043S	N/A	Tube Spacer Rock & Frost Or Terminator Inside Mounting

#### Bolts



Ballantine Part No.	OEM Part Number	Description
12201148	N/A	Bolt 1/2" X 20 X 1 1/4" Grade 8

Ballantine Part No.	OEM Part Number	Description
12202148	N/A	Bolt 1/2" X 20 X 2 1/4" Grade 8

Ballantine Part No.	OEM Part Number	Description
12202128	N/A	Bolt 1/2" X 20 X 2 1/2" Grade 8

Ballantine Part No.	OEM Part Number	Description
122038	N/A	Bolt 1/2" X 20 X 3" Grade 8

Ballantine Part No.	OEM Part Number	Description
12203148	N/A	Bolt 1/2" X 20 X 3 1/4" Grade 8

Ballantine Part No.	OEM Part Number	Description
12203128	N/A	Bolt 1/2" X 20 X 3 1/2" Grade 8

Ballantine Part No.	OEM Part Number	Description
12203348	N/A	Bolt 1/2" X 20 X 3 3/4" Grade 8

Ballantine Part No.	OEM Part Number	Description
122048	N/A	Bolt 1/2" X 20 X 4" Grade 8

Ballantine Part No.	OEM Part Number	Description
12204128	N/A	Bolt 1/2" X 20 X 4 1/2" Grade 8

Ballantine Part No.	OEM Part Number	Description
1220	N/A	Lock Nut 1/2" X 20



## Ditch Witch® H314 Attachment

### Drive Sprockets



Ballantine Part No.	OEM Part Number	Description
B142127	142-127	Drive Sprocket Split 12 Tooth

Ballantine Part No.	OEM Part Number	Description
B142044	142-044	Drive Sprocket Split 14 Tooth

Ballantine Part No.	OEM Part Number	Description
B105761	105-761	Drive Sprocket Bolt ( 8 Required )

Ballantine Part No.	OEM Part Number	Description
B105159	105-159	Cam Washer ( 16 Required )

### Auger Sprocket



Ballantine Part No.	OEM Part Number	Description
B142031	140-031	Auger Sprocket 14 Tooth Hex Bore

### Boom End Roller And Boom End Sprocket



Ballantine Part No.	OEM Part Number	Description
B142751	142-751	Boom End Roller Assembly - 14 1/2" O.D.

Ballantine Part No.	OEM Part Number	Description
B142752	142-752	Boom End Roller - 14 1/2" O.D.

Ballantine Part No.	OEM Part Number	Description
B142020	N/A	Boom End Sprocket Assembly - 24 Tooth

Ballantine Part No.	OEM Part Number	Description
B142021	N/A	Boom End Sprocket - 24 Tooth

Ballantine Part No.	OEM Part Number	Description
B125209	125-209	Bearing Kit - Includes All Items With An Asterisk *

Ballantine Part No.	OEM Part Number	Description
B747568 *	N/A	Bearing Cup ( 2 Required )

Ballantine Part No.	OEM Part Number	Description
B747576 *	N/A	Bearing Cone ( 2 Required )

Ballantine Part No.	OEM Part Number	Description
NPN04-05-94-1 *	N/A	Bearing Crush Ring

Ballantine Part No.	OEM Part Number	Description
NPN04-05-94-2 *	N/A	Snap Ring

Ballantine Part No.	OEM Part Number	Description
B180062 *	180-062	Dirt Shield ( 2 Required )

## Ditch Witch® H314 Attachment

### Chain Components For 2" Pitch Every 4th And 2" Pitch Anti Back Flex

#### Boom End Roller And Boom End Sprocket



Ballantine Part No.	OEM Part Number	Description
B180448	180-448	Idler Shaft



Ballantine Part No.	OEM Part Number	Description
B105313	105-313	Idler Shaft Nut



Ballantine Part No.	OEM Part Number	Description
B115165	115-165	Pipe Plug



Ballantine Part No.	OEM Part Number	Description
B115009	115-001	Grease Zerk

#### Boom Components



Ballantine Part No.	OEM Part Number	Description
B151053	151-053	Grease Cylinder



Ballantine Part No.	OEM Part Number	Description
B159093	159-093	Relief Valve

#### Augers And Auger Components



Ballantine Part No.	OEM Part Number	Description
B145070	145-070	Auger Right Hand 24"



Ballantine Part No.	OEM Part Number	Description
B145071	145-071	Auger Left Hand 24"



Ballantine Part No.	OEM Part Number	Description
B145109	145-109	Auger Right Hand 12"



Ballantine Part No.	OEM Part Number	Description
B145110	145-110	Auger Left Hand 12"



Ballantine Part No.	OEM Part Number	Description
B105391	105-391	Auger Bolt



Ballantine Part No.	OEM Part Number	Description
3410	105-953	Auger Nut



Ballantine Part No.	OEM Part Number	Description
B145244	145-244	Double Auger Shaft



Ballantine Part No.	OEM Part Number	Description
B145245	145-245	Single Auger Shaft



Ballantine Part No.	OEM Part Number	Description
B184189	184-189	Spacer For Double Auger Shaft 1.600" Long (2 Required)



Ballantine Part No.	OEM Part Number	Description
B184188	184-188	Spacer For Single Auger Shaft 2.900" Long

## Ditch Witch® H314 Attachment

### Drive Sprockets

#### Augers And Auger Components



Ballantine Part No.	OEM Part Number	Description
B125620	125-620	Hex Flange Bearing



Ballantine Part No.	OEM Part Number	Description
B145290	145-290	Bearing Plate



Ballantine Part No.	OEM Part Number	Description
B143021	145-021	Zerk Guard



Ballantine Part No.	OEM Part Number	Description
B184076	184-076	Guard Bushing (2 Required Per Bearing)



Ballantine Part No.	OEM Part Number	Description
B106632	106-632	Bolt Bearing To Plate (2 Required Per Bearing)



Ballantine Part No.	OEM Part Number	Description
B106594	106-594	Bolt Zerk Guard To Plate (2 Required Per Bearing)



Ballantine Part No.	OEM Part Number	Description
B106685	106-685	Nuts for Bearing Plate (4 required Per Bearing)

# **BALLANTINE**

Ground Engaging Parts Specialists

Corporate Headquarters: 840 McKinley Street, Anoka, MN 55303

Warehouse: 2209 South Lilac Ave., Rialto, CA 92316

Warehouse: 675 Wesleyan Drive SW, Atlanta, GA 30336

[www.ballantineinc.com](http://www.ballantineinc.com)

phone: 800-328-2424 • fax 763-427-2277 • [parts@ballantineinc.com](mailto:parts@ballantineinc.com)

©2016 U.S. Tsubaki Power Transmission, LLC. All Rights Reserved

Printed in the U.S.A. 05/17