



Universal Remote Codes

Programming your fetchtv remote to control your TV & DVD

Fetchtv features a universal remote that can be programmed to also control your TV & DVD.

To program your remote follow these steps:

- Check the list of TV and DVD brands below to identify the codes for your TV or DVD. There are two separate lists – the first one is for TVs the second one is for DVDs and starts on Page 26 of this document.
- If there is more than one code listed you will need to try each of them to determine which one is best for your equipment.
- Choose the mode by pressing either TV or DVD on your fetchtv remote (you can't reprogram it for the STB)
- The button should light up and then go off when you choose the mode.
- Hold down the RC Setup button until the selected mode button (TV or DVD) flashes once and then, after a pause, twice more.
- Type in the first of the 4 digit codes shown on the list for your brand of TV or DVD. The selected mode button will flash each time you enter a number.
 - If the 4 digit code has been successfully entered, the mode button will flash twice after you enter the last number.
 - If you type in an incorrect code the mode button will light up solid red and will not flash twice. You will need to start again from the beginning.
- Once you have correctly entered the code you then need to test whether it is the correct one for your model of TV or DVD. To do this check that the correct mode (TV or DVD) is selected on your fetchtv remote & then press the on/off button to see whether it turns on your TV or DVD
- If this does not work, it means the code you programmed is not correct for your TV or DVD. You need to repeat these steps using the next code shown on the list for your brand of TV or DVD.
- If it does work, test other buttons to check you are able to access the full functionality. It is possible that there are several codes on the list for your brand of TV or DVD that will work better than others. You may need to try several to find the best one.
- When you have found a code that works well, take off the battery cover of your fetchtv remote control. Write the code on the sticker inside the cover. You will need to re-enter the code if the batteries are removed from the remote control.



A.R. Systems 1726 0067 0403 0586 0382
0404 0485

Accent 0039 0067 0586

Acer 1369 1539 1433 1674

Acoustic Solutions 1179 1553 1067

Adcom 0655

ADL 1247 0920

Admiral 0123 0393 0448 0117 0193 0294

Advent 0906

Adyson 0247 0246

AEA 0067 0586

AEG 0636 1586 1067 1179 1402 1193

Afron 0921

Agashi 0246 0294 0247

AGB 0546

Agef 0117

Aiko 0039 0067 0099 0586 0401 0246 0065
0463 0910 0102 0391 0221 0294 0247

Aim 0067 0102 0442 0586 0783 0238 0736
0728 0664 0404 0481 0485 0636 0529

Airis 0874 1561

Aiwa 1938 1535

Akai 0391 1356 0238 0401 0067 0833 0463
0221 0065 0039 0102 0783 0248 0582 0744
0193 0736 0518 0728 0546 0745 0632 0586
0578 0611 0510 0247 0661 0246 0294 0478
0208 0407 0636 1067 1938 0503 1289 1278
1338

Akashi 0039

Akiba 0248 0312 0485 0067 0586 0324

Akira 0220 0448 0783 0067

Akito 0067 0586

Akura 0067 0586 0698 1675 1800 0442
0039 0248 0312 0388 0294 0744 2012 1393

Alaron 0209 0246

Alba 0067 1067 0586 0744 0039 0448 0400
0265 0401 0698 385 0248 0246 0277 0461
0193 0517 0241 0611 0066 938 0473 0581
1761

Alcyon 0241

AlfaView 1236

Alkos 0065

Allorgan 0236 0324 0247

Allstar 0067 0586

All-Tel 0895 1299

Ambassador 0207

Amitech 1311 0685 1498

Amoi 1559

Amplivision 0247 0400 0350

Amstrad 0207 0039 0546 0294 0384 0401
0248 0067 0586 0463 442 0392 1067 0611
2012

Anam 0067 0586 0039 0680

Anam National 0067 0586 0680

Andersson 1193 1179 1615

Anex 0451

Anglo 0039 0294

Anitech 0039 0294 0067 0586 0312 0132

Ansonic 0400 0067 0586 0039 0698 0404
0193 0322 0132 0441 289 0277 0458 0134

AOC 1395 1119 1618

Apollo 0503

Arc en Ciel 0139 0226

Arcam 0246 0247



Arçelik 0744
Ardem 0516 0744 0663 0067 0586
Arena 0067
Aristona 0586 0067
Art Mito 1615
Arthur Martin 0193 0267
ASA 0135 0376 0100 0134 0117 0193 0209
Asberg 0067 0586 0132
ASK 1777
Asora 0039
Astra 0067 0586
Asuka 0248 0247 0246 0294 0312
ATD 0728
Atec 1636 1758
Atlantic 0067 0586 0246 0236 0350 0289
Atori 0039
Auchan 0193
Audiosonic 0039 0067 0404 0850 0586 1830
1338 0139 1733 0744 745 0247 0400 0367
0294 0248 0516 0458
Audioton 0247 0516 0400 0294 0458
Audiovox 0481
Audioworld 0728
Aumark 0090
Autovox 0117 0236 0267 0379 0247 0277
0366
AVP 1938
AWA 0041 0066 0039 0187 0404 0481 0442
0067 0586 0246 636 0247 0138 0294 2015
1406 0208 0728
Axxent 0039
Axxon 0744
B&D 1247
Baier 0906 1402
Baird 0139 0373 0220 0222 0102 0103 0247
0238 1226 0636
Bang & Olufsen 0595 0117 0305
Barco 0582 0193
Base 1600 0810
Baseline 1274
Basic Line 0404 0067 0193 0698 0586 0039
0248 0312 0247 0485 369 1067
Bastide 0247
Bauer 0039 0728 0736 0294
Baur 0039 0333 0565 0225 0542 0067 0586
0584 0221 0391 379 1535 1040
Bazin 0247
BBK 1771
Beaumark 0208
Beko 0744 0516 0065 0745 0067 0448 0458
1830 0400 0586 636 0838 1682
Belson 1221
Bennett 0586 0067
BenQ 1242 1592 1062
Bensten 1600 1356
Beon 0067 0586 0448
Berthen 0698
Best 0367 0400 0451
Bestar 0067 0586 0400 0404
Bestar-Daewoo 0404
Bestwell 1356
Binatone 0247



Black Diamond 0850 1067 0586 0783 1193
0617

Black Panther 0132

Black Star 0277

Black Strip 0065

Blackway 0312 0248

Blaupunkt 0584 0225 0221 0565 0230 0357
0358 0478 0485 0200 066

Blauren 0404

Blue Media 1758 1636

Blue Sky 0067 1402 1067 1739 0744 1179
0517 1801 0698 0745 655 1682 1939 0586
0248 0312 0485 1938 1221 0838 393 1418
1344 1769

Blue Star 0312

BlueH 1775

Bondstec 0277

Boots 0247 0039

Bork 1393

Bosch 0350 0357

BPL 0067 0586 0312 0403

Brandt 0655 0139 0267 0226 0317 0365
0501 0373 0590 1395

Brandt Electronique 0317 0365

Brimax 1739

Brinkmann 0067 0586 0698 0448 0516

Brionvega 0067 0586 0392 0117 1544

Britannia 0246 0247

Brother 0294

Bruns 0117 0458 0516

BSR 0193 0324 0582 0391

BTC 0248

Bush 1067 1356 0744 0067 0698 1682 0248
0193 0379 0039 066 0401 0265 0312 0385
0393 0404 0294 0391 0517 241 0238 0247
1586 0728 0611 0324 0582 0586 1930 938
0808 1289 2012 1278 1712 1761 1196 0617
1338

Cameron 1553 0586

Camper 0067 0586 0516

Candle 0216

Canton 0248

Capsonic 0294

Carad 0640 0067 0586 0698 1067

Carena 0485 0067 0586

Carrefour 0066 0100 0067 0586

Carver 0200

Cascade 0039 0067 0586

Casio 0067 0586 0193 0379

CAT 1712

Cathay 0067 0586

CCE 0067 0586 0247

Celestial 0850

cello 1800

Centrex 0810 0921 1566 0728 1761

Centrum 1067

Centurion 0067 0586

Century 0117 0277 0268

CGE 0104 0114 0448 0277 0582 0400 0193

Cimline 0039 0265 0248

Cineral 0481

Cinex 1196 1586

Citizen 0481 0090 0216



City 0039

Clarivox 0448 0067 0586 0100 0132

Clatronic 0067 0400 0401 0744 0248 0294
0586 0247 0277 0039 132 0350 0636 1193

Clayton 0415 1067

CMS 0246

CMS hightec 0247

Cobolt 0921

Combitech 1938

Concorde 0039

Condor 0350 0067 0586 0400 0246 0039
0312 0132 0277 0448 344 0441 0193 0294

Conia 1675 0850 1553

Conrac 0838

Conrad 0067 0586

Contec 0246 0039 0187 0041 0066 0294
0067 0586

Continental Edison 0139 0267 0226 0317
0517

Cosmel 0039 0367 0067 0586

Crosley 0117 0277 0104 0114 0582 0193

Crown 0039 0742 0400 0516 0067 0586
0517 0744 0636 0745 451 0403 0448 0238
0683 0369 1067 1682 0698

Crystal 0461

CS Electronics 0246 0248 0277

CTC 0277

Curtis Mathes 0090 0123 0481 0196

CWR-Tech 1402

CyberHome 0824 1206

Cybertron 0248

Cytronix 1328

D.Boss 1420 0067

Daewoo 0664 0691 1233 0529 0404 1939
0067 0586 0039 0246 248 0247 0481 1167
1938 0910 1248 0906 0895 0728 744 0736

Dainichi 0248 0246

Dansai 0067 0586 0294 0065 0246 0039
0066 0247 0238

Dansette 0442

Dantax 0400 0516 1682 0744 0636 0745
1938

Datsura 0403 0238

Dawa 0039 0067 0586

Daytek 0728 1237 0736 1406 1404 0294
1661

Dayton 1237 1404

Daytron 0039 0404 0067 0586

de Graaf 0238 0193 0578 0393

DEC 0921 1356 1220 0926

Decca 0102 0546 0067 0586 0247 1167
1938 1086

Deitron 0067 0586 0404 0248

Dell 1433

Denko 0294

Denver 0067 1402 0586 0636 1219 0617
1739

DER 0220

Desmet 0350 0067 0586 0039 0117

DGM 1465

Diamant 0067 0586

Diamond 0294 0728 0039 0246 0401 0850
0926 0736

DiBoss 0067 0586



Digatron 0067 0586
Digihome 1179
Digiline 0067 0586 0135 0698
DigiLogic 0067 0586
Digimate 0920
Digital Device 1636
Digitek 1739 1801
Digitex 0850
Digitor 0067 0586 0918 2015 1527 1733
Digivision 0391
DigiX 0910
DiK 0067 0586
Dikom 1733 1726
Dixi 0039 0067 0586 0277 0247 0117
DK digital 1692
DL 0921 0810 0067 0617 0895 1393 1356
1233
DMTECH 1368
Domeos 0698 0067 1067
Domland 0424
Doric 0379
Dream Vision 0703 1734
DSE 0918 1586 1291 2015 1527 0850 1307
1733 1196 1593 661 0728 1712
DTS 0039
Dual 0379 0247 0373 0366 0067 0586 0289
0382 0424 0333 582 0193 0561 1167 0661
1179 1067 0808 1402 1193
Dumont 0117 0134 0132 0247 0100 0102
Dunai 0193
Durabrand 0067 0586 1682
Dux 0067 0586
D-Vision 0067 2012 0586
DVX 0921
Dynatron 0067 0586
e:max 0636 1561 1402
Easy Living 1278 1289 1583 1739 1247 1338
1661 0907 1196 1586 696 1324
Ecco 0803 0736 0728
Edison-Minerva 0517
Eiki 0765
Elbe 0441 0392 0465 0660 0268 0640 0289
0322 0400 0193 067 0586 0248 0221 0581
0247 0546 0391 0582
Elbe-Sharp 0546
Elcit 0117 0277 0546 0132 0582 0193
Electrion 1615
Elekta 0039 0067 0586 0294 0312
Elfunk 1238 1067
ELG 0067 0586
Elin 0246 0067 0586 0135 0134 0578 0391
0478 0379 0193 039
Elite 0248 0067 0586 0350
Elman 0132
Elonex 1806
Elta 0039 0294 0246 0461 1692
Emco 0277
Emerson 0207 0744 0208 0209 0117 0277
0067 0586 0401 0100 312 0350 0391 1939
0516 0400 0193 0351 0698
e-motion 1739
Emperor 0312
Enzer 0783 0803



Epson 0863 1409
Erae 1401 1221
Erisson 1712
Erres 0067 0586
ESC 0067 0586 0247
Estèle 0582 0193
Etron 0067 0586 0850 0039 0193
Eurofeel 0294 0247
EuroLine 0067
Euroman 0246 0294 0067 0586 0247 0451 0400
Europa 0067 0586
Europhon 0067 0546 0132 0193 0247 0586 0344 0277 0582 0461 246
Evesham 1278 1289 1758 1593 1636 1566
Excel 0067 0586
Excello 1067
Expert 0236 0289 0193
Exquisit 0067 0586 0277
Fagor 0067 0586
FairTec 1221 1403
Family Life 0067 0586
Fenner 0404 0039
Ferguson 0103 0655 0317 0222 0220 0365 0268 0139 0590 0067 586 0065 0373 0683 0134 0138 0391 0501 0578 0473 067 1938
Fidelity 0193 0542 0393 0067 0586 0401 0442 0561 0246 0294 938 0391
Filsai 0247
Finlandia 0238 0376 0578 0391 0193 0393 0102 0317 0373 0075
Finlux 0135 0134 0067 0586 0744 0376
1615 0247 0102 0582 193 0546 0745 0100 0117 0209 0132 0344 0441 0661 522 0510 1586 0659 0503 0448 0636 0838 1278
Fintec 2012
Firstline 0067 0586 0404 0698 0744 0193 0039 0324 0351 0246 415 0277 0582 1939 0344 0132 0247 0441 0379 0561 268 0102 0265 0238 0391 1067 1221 0838 1393 1193 418 1401 1338
Fisher 0134 0247 0066 0238 0400 0585 0075 0117 0187 0391 582 0193 0333 0379 0102
Flint 0067 0586 0640 0102 0248 0485 0294
FNR 0132
Force 1179
Formenti 0193 0067 0586 0516 0246 0117 0350 0582
Formenti-Phoenix 0246 0350 0582
Fortress 0123 0117
Fraba 0067 0586 0400 0561
Friac 0039 0067 0586 0132 0451 0400 0529 0685 0640
Frontech 0277 0294 0379 0393 0461 0478 0247 0039 0193
Fuchsware 0810
Fujicom 1739
Fujimaro 0895
Fujitsu 0209 0713 0883 0216 0839 0236 0102 0132 0344 0247 193 0039 0382 0067 0586 0391 0289
Fujitsu General 0039 0216 0247 0236 0193
Fujitsu Siemens 1696 1328 1289 1278 1403 1193 0838 0839
Funai 0209 1424 1067 1696 0698 0294 0324



0333 0442 1535 744

Futronic 0294 0728

Future 0067 0586

Gaba 1067 0067

Galaxi 0132 0067 0586 0391 0193

Galaxis 0400 0448 0067 0132 0586

Galeria 0039

GBC 0582 0193 0039 0404 0248 0393

GE 0373 0765 0208 0312 0481 0590 0317
0139 0365 0655

Geant Casino 0193

GEC 0193 0391 0379 0067 0546 0586 0073
0102 0247

Geloso 0277 0039 0393 0582 0193 0404

General 0139 0317 0501 0216

General Electric 0373 0317

General Technic 0039

Genesis 0039 0067 0586

Genexxa 0248 0067 0586 0442 0193 0039

Gericom 0895 1636 1328 1236 1247 0910
0838

Gevalt 1401 1221

G-Hanz 1393

Giant 0247 0039

G-Luxon 0874

Gold 1800

Goldfunk 0698

Goldhand 0246

Goldline 0367

GoldStar 0067 0039 0400 0407 0247 0277
0208 0246 0586 0461 193 0391 0139 0393

0636 0744 0745 0485

Gooding 0517

Goodmans 0664 0745 1289 1067 1278
0067 0529 0586 0744 0698 939 0404 0066
0294 0102 0546 0039 0209 0517 0401 373
0265 0065 0510 0590 0247 0365 0248 0481
1938 660 0691 1930 0910 1338 0617 1406
2015 1179 1675 712

Gorenje 0400 0451

GP 0783

GPM 0248

Gradiente 0683 0200 0067 0586

Graetz 0744 0391 0401 0193 0067 0369
0586 1193

Granada 0067 0586 0256 0386 0075 0102
0138 0238 0247 0066 369 0546 0503 0365
0590 0193 0393 0255 0373 0578

Grandin 0067 0586 0039 0193 0640 0744
0745 0698 0404 0350 312 0248 0485 1067
0895 1221 0910 1404 1405 1407 410 1418

Gronic 0132 0247 0193

Grundig 0225 0538 1401 1310 1221 1253
0565 0221 1612 0584 100 1067 0517 0067
0473 0736 0267 0586 0617 0039 066 0400
0770 1938 0660 1338 0208 1406 1830
0373 289

Grunkel 1193

Grunpy 0209

H&B 0838

Haaz 0736

Haier 0728 0294

Halifax 0294 0246 0247

Hammerstein 0294 0090

Hampton 0246 0247



Hanimex 0248 0324 1938

Hannspree 1806

Hanseatic 0067 0586 0529 0379 0193 0391
0322 0312 0424 0350 664 0458 0400 0691
0039 0324 0247 0403 0461 0117 407 0366
0744 0838 0516 0655

Hantarex 0039 0067 0586 0132 0546 0268
0859 1368

Hantor 0067 0586

Harley Davidson 0209 0073

Harsper 0895

Harwa 0803 1226 1299

Harwood 0039 0442 0067 0586 0517

Hauppauge 0067 0586

HCM 0039 0442 0067 0586 0247 0248
0448 0312 0294

Hedzon 0586 0067

Hema 0247 0039

Hemmermann 0379

Hicon 1497 1328

Hifivox 0139 0226

Higashi 0246

Highlander 1561

Highline 0294 0067 0586

Hikona 0248

Hinari 0238 0067 0586 0039 0248 0066
0209 0193 0385 0473 241 0517 0265 0324
0294 1938

Hisawa 0312 0248 0485 0640 1938 0744

Hisense 1393 1344 0238 1056 1103 0728
0921 0810

Hit 0117

Hitachi 1606 1802 0511 0608 0180 0255
0379 0138 0774 1615 386 1067 1514 1511
1255 0664 0503 0066 0193 0582 373 0226
1193 0606 1224 0529 1179 0827 0073
0224 510 0546 0102 0067 0586 0139 0393
0578 0208 1167 135 0522 0391 0542 0659
1990 0907 0247

Hitachi Fujian 0858 0138 0180 0067 0586
0255 0606 0529

Hitsu 0039 0640 0485 0248

HMV 0117

Höher 0744 1586 0895 1193

Home Electronics 0636

Hornyphon 0067 0586

Hoshai 0248 0485 0312

Huanyu 0404 0246

Hugoson 0920 1696 1247

Humax 1565

HYD 1661 1406

Hygashi 0247 0246

Hyper 0039 0246 0247 0277

Hypersonic 0391

Hypson 0067 0586 0744 0745 0294 0247
0312 0485 0268 1938 067 0698 0516

Hyundai 0067 0833 0895 1699 0586 0736
0783 1356 1561 1274 728 1324 0906 1311
1800 1307 1498 0294 1586 1036 918 1067
1661 1636 1406 0808 1593

Iberia 0067 0586

ICE 0294 0067 0401 0039 0586 0248 0247
0246

Ices 0248 0246

Ict 0067 1167 0586



iDEAL 1586
iISonic 1406
Iiyama 1247 0920
Imperial 0067 0193 0400 0104 0114 0538
0586 0660 0441 0391 379 0448 0277 0226
0461 0561 0582
Indesit 0267
Indiana 0067 0586
InFocus 0782 1194 1236 1460 1777
Ingelen 0517 0640 0744 0193 0391
Ingersoll 0039
Inno Hit 0039 1067 0102 0067 0586 0248
0247 0546 0277 0132 312 1193 1615
Innovation 0067 0586
Innowert 0895 1328
Inotech 0803 0850
Inspira 1402 1586
Interactive 0067 0586 0117 0542 0305 0357
0193 0391 0400 0139 441
Interbuy 0039 0067 0294 0277 0542 0586
Interfunk 0067 0586 0117 0542 0305 0357
0193 0391 0400 0139 379 0277 0230
Internal 0067 0586 0529 0404 1939
International 0246
Intervision 0312 0247 0485 0067 0401 0407
0478 0516 0400 0424 517 0248 0132 0461
0193 0294 0277 0039 0586
Irradio 0039 0067 0586 0248 0277 0401
0754
Isukai 0248 0067 0586 0312 0485
ITC 0247 0582 0350
ITS 0067 0401 0248 0312 0294 0246 0039
0586
ITT 0193 0510 0379 0391 0503 0578 0376
0369 0238 0209 640
ITT Nokia 0391 0578 0193 0503 0510 0379
0376 0238 0209 0369 636 0640 0661 0393
0461
ITV 0067 0294 0586 0277 0404
JDV 2012
Jean 0066
JEC 0065
JGC 1739
JMB 0067 0529 0664 0404 0586 0473 1938
JNC 0906 1566 0926
Jocel 0742
Jouge 1465
Jubilee 0586
JVC 0683 1183 0636 1683 0401 0761 0713
0066 0220 0222 248 0448 0099 0123 0680
Kaisui 0248 0312 0067 0586 0246 0485
0247 0039
Kambrook 0407 0461 0294
Kamp 0246
Kapsch 0193 0391 0236 0289 0134
Karcher 0067 0586 0451 0400 0640 0193
0312 0132 0344 0294 808 0744 1586 0636
2012 1338
Kathrein 0586 0067 0910
Kawa 0401
Kawasho 0246
KB Aristocrat 0193
Kendo 0640 0067 0586 0193 0542 0400
0407 0393 0458 0441 132 0265 0277 0392



0581 1615 1067 0516 1179 1193 167

Kennedy 0193 0236 0582 0465

Kennex 1067

Kenwood 0135

Keymat 1801 1356 1600

KIC 0247

Kingsbrook 1067

Kingsley 0246

Kiton 0586 0067 0698

Kneissel 0067 0415 0400 0640 0441 0404
0529 0586 0465 0289 322 0268 0392 1938

Kobra 1497 1328

Kolster 0067 0586 0132 0379 0277 0248

Konichi 0039

Konka 0067 0586 0401 0744 0448 0248
0671 0617 1220 0636

Kontakt 0517

Korpel 0067 0586

Korting 0117 0451 0400 0350

Kosmos 0067 0586

Kotron 0442 0294 1930

Koyoda 0039

Kraking 0268

Kross 1566

KTV 0247

Kuba 0379 0193

Kuba Electronic 0333 0379 0193

Kuro 0403

Kyoshu 0442 0448 0294

Kyoto 0415 0193 0246 0247

L&S Electronic 0895 0744

LaSAT 0516 0400

Lavis 1067 0067 0193

Leader 0039

Lecson 0067 0586

Legend 0039 0367

Lemair 0441

Lenco 0039 0751 0067 0193 0404 0586
0134 0617 1067 1661

Lenoir 0039 1219

Lenoxx 1219

Lentec 1561 1726

Lesa 0277

Levis Austria 0067 0586

Lexsor 1226 1537

Leyco 0294 0102 0067 0586 0324

LG 1453 0208 1262 1349 0067 0906 0400
0407 0039 0586 744 0247 0246 0461 0193
0636 0139 0728 0745 0853 859 1667 1176
1178 1221 0277 0391

Liesenkötter 0067 0357 0358 0586

Lifetec 0067 0698 1067 1167 0404 0039
0542 0685 0586 0744 248 0294 0713 1278
1289

Lloyd's 0039

LME 0461

Lodos 1067 1179

Loewe 0542 0663 0820 0067 0586 0685
0400 0117 0322 0581 392 0546 0821

Logik 0041 0728 0090 0803 0039 0294 0401
0910 1247 1067 675

Logix 0698

Luker 2012 2015



Luma 0067 0393 0236 0193 0441 0586
0404 0039 0392 0289

Lumatron 0393 0236 0067 0586 0392 0193
0289 0391 0247 0294 103

Lux May 0067 0039 0586 0611

Luxor 0224 1193 0267 0393 0510 0522
0379 0391 0238 0386 578 0193 0376 0503
0209 1067 0247 0661

LXI 0208

Madison 0067 0586

Magnadyne 0117 0277 0546 0132 0582
0193

Magnafon 0546 0132 0344 0246 0103

Magnavox 0067 0586 0066 0209 0810 1169
1233 0783

Magnum 0744 0067 0586 0745 1319

Mandor 0294

Manesth 0067 0586 0265 0247 0294 0350
0065 0324 0193 0393

Manhattan 0067 0906 0586 0698 1067 0193
0808

Maqma 1497 1328 1739 1636

Marantz 0067 0586 0442

Marelli 0117

Mark 0067 0586 0247 0246 0404 0039 0744
0745

Marks and Spencer 1800

Mascom 1586 0586 0067

Master's 0529 0067

Masuda 0401 0248 0039 0294 0067 0247
0586

Matrix 1307

Matsui 0067 1193 0586 0517 0473 0039

0265 0207 0041 0385 102 0066 0241 0247
0384 0324 0401 0463 0393 0485 193 0379
0546 0065 0461 0238 0075 0225 0221
0365 744 1938 1067 0659 1696 0910

Matsushita 0680

Matsuiama 0617

Maxam 0294

Maxdorf 0803 0728 0736 0294

Maxim 1196 2012 1586

MAXIVIDEO 0344

MCE 0039

McMichael 0073

McTronics 1692

Medialine 1236

Mediator 0067 0586

MediaVision 1421

Medion 0744 0838 0067 0698 0586 0542
1167 0728 1938 1067 930 1278 1289 0275
0661 1251 0910 1319 1196 1586 179 1771

MegaDrive 1289

Megas 0640

Megatron 0208

MEI 1067 0067 0586

Melectronic 0376 0067 0542 0139 0373
0277 0135 0134 0404 0039 247 0510 0522
0246 0441 0379 0193 0317 0586 0664 391
0221 0225 0691 0744 1682

Memorex 0039 0180 0208 0680 0090

Memphis 0367 0102 0039 0415

Mercury 0067 0039 0728 0294 0586 0736
0090

Merritt 0578 0391 0193



Metz 0776 0418 0477 0397 0117 1193 0225 2012
0565 0584 0221 067 0586 0617 0305 0698
1067
MGA 0180 0208 0067 0586 0248 0134
Micromaxx 0067 0586 0698 1067 0660
0838 0744 1402
Microstar 0838
MicroTEK 0850 0728 0736 0294
Mikomi 1179 1193 0774
Minato 0067 0586
Minerva 1278 0517 0565 0225 0100 0221
0584 0267 0546 0138 180
Minoka 0442 0067 0586
Mirai 1696 1681
Mirror 1930
Mitsai 1586
Mitsubishi 0138 0180 0123 0542 0067 0208
0384 0117 0066 0267 388 0565 0586 0721
0238 1067 1552
Mitsuri General 0193
Mivar 0322 0400 0246 0639 0546 0247
Mogen 1713
Monaco 0039
Moree 0067
Morgan's 0067 0586
Motorola 0123
MTC 0090 0400 0379 0542 0193 0246 0391
0478
MTlogic 0744 1338
Multimat 0344
Multistandard 0132 0344
Multitec 0067 0586 0516 0698 1067 1586
Multitech 0379 0039 0393 0516 0067 0400
0586 0247 0246 0277 132 0344 0294 0582
Murphy 0134 0246 0102 0193
Musikland 0067 0248 0277 0586
Mx Onda 1675
MyCom 1406 0208
Myryad 0586 0067
NAD 0196 0208 0895 0391 0193
Naiko 2012 0067 0636 0586
Nakimura 0404 0067 0586
Naonis 0393 0193
Narita 2012
NAT 0256 0370 0244
National 0244 0256 0267 0370
NEC 0200 0617 1200 1397 0066 0350 1549
0906 1805 0485 039 0404 0247 0067 0586
0041 0734 0275 0267 1734 529 0683 0801
1400 1165 0691 0912
Neckermann 0067 0221 0400 1535 1040
0230 0584 0586 0582 0193 357 0448 0379
0117 0277 0247 0441 0350 0393 0542
NEI 0067 0586 0367 0461 0401 0193 1067
NEO 1402
Neon 1762
Neovia 1236 0895 1403 1401 0906 1406
1420 1414 1368 1221
Nesco 0277 0209 1938
Nesx 1762
Netsat 0067 0586
Network 0367
Neufunk 0067 0039 0586 0640 0248 0312



0744
New Tech 0067 0039 0586 0373 0247 0478
New World 0248
Nicamagic 0246
Nikkai 0102 0248 0067 0586 0247 0294
0065 0367 0246 0039 066
Nikkei 0744 1624
Nikko 0208
Nintaus 0921
Nishi 0512
Noblisko 0132 0100 0246 0344
Nogamatic 0139 0226
Nokia 0391 0193 0510 0379 0578 0522
0503 0369 0238 0404 661 0636 0376 0209
0350 0640 0139 0581
Nordic 0247
Nordmende 0139 0921 0317 0226 0590
0373 0225 0067 0586 0365 193 0501 1289
1278 0744 1319 0520 0473 1615
Norfolk 0193
Normerel 0067 0586
Northern Star 1236
Novak 0067 0586
Novatronic 0067 0135 0404 0561 0586
Novex 1553
Novita 1414 1615
Nurnberg 0193 0391
NU-TEC 0485 0728 0850 0067 0586 0736
0294
O.K.Line 1067 1402 1586
Oceanic 0193 0391 0324 0238 0503 0578
0510
Odeon 0294
Okano 0400 0067 0586 0294 0102 0518
0039
OKI 1067
Olidata 1406
Olivia 1618
Omega 0294
Omni 0810 0921 0728 1600
Onn 1179 1739 0586 1800
Onwa 0401 0632 0248 0463 0611 0132
0461
Onyx 1739 1800
Opera 0067 0586
Optimus 0680 0196
Optoma 1652
Optonica 0123
Orava 0582 1067
Orbit 0067 0586
Orion 0209 0067 0473 0385 0744 0265
0586 0685 0324 0207 350 0041 0039 0351
0241 0344 0132 0294 0442 0546 561 1938
0910 1226
Online 0067 0248 0586
Ormond 0415 0698 1067 0067 0586
Orsowe 0546
Osaki 0102 0248 0247 0294 0067 0442
0404 0241 0385 0586
Osio 0067 0586
Oso 0248
Osume 0187 0102 0066 0248 0067 0586
OTIC 1233 1036 1675
Otto Versand 1535 1040 0066 0123 0542



0067 0586 0565 0225 0379 584 0221 0391
0265 0139 0324 0256 0277 0333 0350 247
0039 0312 0366 0373 0403 0458 0461 0546
0582

Pace 1938

Pacific 0067 0586 1167 0744 1067 0473

Packard Bell 1344

Pael 0246

Palladium 0400 0067 0685 0441 0660 0744
1167 0221 1535 1040 230 0448 0584 0586
0379 0277 0357 0117 0582 0193 247 0393
2012

Palsonic 0294 0442 0067 0247 0407 0248
0728 0586 0478 0518 803 0448 0808 1519
1226 1537 1299 1735 1356

Panache 1615

Panama 0039 0247 0294 0246 0067 0586
0277

Panasonic 0680 1666 1680 0138 0256 1340
1240 0370 0244 0391 883 0267 0397 0546
0067 0586 0193 0578 0801

Panavision 0067 0441 0586

Papouw 0067 0586

Pathe Cinema 0193 0268 0246 0350 0322
0379 0461 0582 0400

Pathe Marconi 0139 0226 0267

Pausa 0039

Perdio 0102 0350 0193 0067 0246 0312
0586

Perfekt 0067 0586

Philco 0117 0114 0104 0448 0277 0582
0193 0400 0067 0586 216

Philex 0581 0193

Philharmonic 0247

Philips 0586 0067 0268 0751 1536 0669
0635 1485 0802 1334 484 0584 0073 0117
0453 0373 0404 0039 0230 0391

Phocus 1319 1338 0744 1682 1830

Phoenix 0067 0586 0400 0516 0193 0117
0102 0246 0350 0415 582

Phonola 0067 0586 0117 0246

Phonotrend 1624

Pilot 0586 0067 0742 0736

Pioneer 1290 0790 0041 0200 0196 0709
0067 0586 0453 0458 400 0373 0391 0139
0193 0317 0516 0542

Pionier 0400 0516

Pixxel 1559

Plantron 0067 0586 0294 0039

Playsonic 0744 0067 0247 0369 0745 1830
1682

Plus 0801 1582

Polar 0067

Polaroid 1553 1675 1771

Policom 0132 0139 0226 0236 0267 0268
0305 0391 0193 0100 104 0114 0117 0565

Polytron 0312

Poppy 0039

Portland 0404 1939

Powerpoint 0517 0067 0586 0728 1800

Prandoni-Prince 0277 0546 0391 0393

Precision 0247

Premier 0039 0294 0921

Prima 0039 0294 0333 0442 1299 1537
1226

PrimeView 1636



Princess 0728 1356

Prinston 1067

Prinz 0102 0379 0391 0224

Profex 0039 0193 0461 0391 0393

Profi 0039

Profilo 1586

Profitronic 0067 0586 0344 0132

Proline 0067 0586 0655 0664 0660 0441
0351 0102 1406 1067

Prosonic 0067 0586 1769 0400 0404 0401
0910 1406 0698 0744 481 0246 0244 1800
1344 0247 1739 1762 0636 1537

Protech 0067 0586 0247 0039 0277 0379
0132 0294 0461 0448 367 0698 0312 0582
0193 0516 1067

Proton 0208

Proview 1675

Provision 0529 0067 0586 1067 0744 1561

Proxima 0765 1777

PVision 1221 0906 1248

Pye 0067 0586 0117 0584 0404 0379 0442

Pymi 0039

QONIX 1624

Quadral 0248

Quadro 0783 1356 0586 0067 1179 1193

Quasar 0277 0680 0895 0039

Quelle 0067 1535 1040 0041 0139 0542
0565 0379 0584 0221 391 0066 0247 0277
0104 0357 0114 0358 0100 0134 135 0698
0586 0187 0225 0230 0294 1067 0324
0376 451 0582 0039

Questa 0066

Radialva 0139 0248 0461 0193 0067 0586
0317 0367

Radiola 0067 0586 0247

Radiomarelli 0117 0546 0277 0067 0586

RadioShack 0067 0586 0208

Radiotone 0039 0067 0586 0458 0400 0448
0442 0698 0294 1067

Rank 0100

Rank Arena 0066 0187 0632 0783

RBM 0100

RCA 0655 0123 0590 0365 0373 0783

Realistic 0208

Recor 0067 0448 0586

Rectiligne 0067 0586

Red Star 1586

Rediffusion 0391 0578 0066 0376

Redstar 0067 0586

Reflex 0067 0586 1067 0698

Relisys 0895 0906 0907 1236 1237 1243
1239 1328 1406 1615 771 1770 1675

Reoc 0744 0664 1939

Revox 0067 0838 0586 0400

Rex 0236 0393 0441 0277 0193 0289 0294
0581

RFT 0117 0322 0400 0458 0102 0294 0067
0586 0516

Rhapsody 0246

Ricoh 0067 0586

Rinex 0803 0448 0728 0294 0736

R-Line 0067 0586 0193

Roadstar 1067 0745 0039 0448 0067 0586
0744 0698 0248 0294 312 1219 1930 1356



Robotron 0117

Rodex 0067 0586

Rolsen 1401 1221 0067 0586

Rover 0066 0907

Rowa 0294 0728 0247 0742 1471 0039
0736 0246 0617 0067 036 0586

Roxy 0478

Royal 0448 0636

Royal Lux 0451 0400 0442 0365

Rukopir 0586 0067

Saba 0655 1196 0139 0590 0373 0317 0117
0193 0546 0391 528 0226 0365 0578 0501
0680 0744 1618

Saccs 0268

Sagem 0640 0485 0312 0860 1343 0648

Saisho 0265 0664 0404 0546 0207 0039
0041 0247 0461 0193 294 0241 0384

Saivod 0067 2012 1193 0586 0698 1586
0742 1067

Sakai 0193

Sakura 1233

Sakyno 0485

Salora 0224 0379 0193 0386 0391 0546
0393 0403 0578 0369 238 0582 0510 0661
1196 1586 0808 1401

Salsa 0365

Sambers 0546 0132 0344

Samsung 0208 0648 0617 0123 1649 0586
1279 1660 0674 1265 039 0067 0247 0478
0512 0400 0518 0090 0844 0102 294 0712
0246 0193

Sandra 0246 0247

Sanela 0268

Sansei 0481

Sansui 0067 0586 0736 0685 0401 0632
0451 0485 0918 0783 401 1221 1561 1727
1583 1624 0728 0294 0744 1414 278 1586

Santon 0039

Sanyo 0238 1238 0187 0322 0751 0066
0041 0400 1537 0369 102 0246 0247 0134
0075 0585 0039 0193 0403 0067 138 0586
0516 0765 0923 0200 0734 1677 1678
1679 684 1067 1179 1193 1615

Save 0067 0586

Saville 1938

SBR 0067 0586 0073

Schaub Lorenz 0578 0744 0391 0379 0636
0516 0404 1221 1224 1393 401

Schneider 1167 0067 0586 0333 0379 0424
0382 0366 0289 0373 247 0277 0401 0391
0248 0698 1067 0193 0744 1939 938 1398
2012 0100 1402

Scotland 0193

Scott 1219 0208 0209

Sears 0208 0209

Seaway 0664

Seelver 0586 1067 0067

SEG 1067 0067 1193 0586 0698 0247 0517
0039 0379 0193 294 0664 0066 0132 0277
0392 0344 0246 0582 0248 939 1179

SEI 0117 0132 1535 1040 0582 0193 0546
0379 0324 0344 236 0067 0586 0207

Sei-Sinudyne 0132 0236 0324 0344 0546
1535 1040 0582 0067 0586 117

Seitech 1247 1402

Seleco 0236 0393 0289 0392 0193 0441
0703 0581 0401 0066 294 0376 0465 0660



Sencora 0039
Sentra 0065 0248 0039 0379
Serie Dorada 0208
Serino 0640 0485 0246 0123
SeViC 1735
Sharp 0123 1223 1689 1616 1423 0187
0066 0521 0324 0683 216 0546 0230
Sherwood 1429
Shintoshi 0067 0586
Shivaki 0067 0586 0473 0481 0404 0208
Shorai 0324 0209
Show 0448 0039 0102 0728 0294 0736
0067
Siarem 0582 0193 0117 0132 0546
Siemens 0221 0565 0584 0230 0225 0357
0358 0187 0067 0586 391
Siera 0067 0586 0617
Siesta 0400
Silva 0067 0586 0246 0391
Silva Schneider 0783 1586
Silver 0066 0067 0485 0586 0391 0209 0745
0193
SilverCrest 1067 0067 0586
SIM2 Multimedia 0703
Simpson 0216
Singer 0039 0117 0728 1586 0067 0586
0132 0277 0465 0365 193
Sinotec 0803 0448 0636 0728
Sinudyne 1402 0207 0117 0265 0132 0324
0582 0193 0391 0546 379 1535 1040 0344
0236 0067 0586 1938 0636
Skantic 0386
Sky 0312 0910 0067 0208 0586 1636 1406
1805 1775 1808 691 0895
Skymaster 0135
Skysonic 0783
Sliding 0895 0910 1402 1404 1405 1407
1413 1418 1398
SLX 0698
Smaragd 0517
S-Media 1247
Soemtron 0895 1328
Sogera 0350
Sogo 1406
Solavox 0391 0102 0193 0578 0067 0586
Sonawa 0248
Sonber 0132
Sonic 0783
Soniko 0067 0586
Soniq 1497 1328
Sonitron 0238 0400 0369 0247
Sonix 1762
Sonneclair 0067 0586
Sonoko 0067 0586 0039 0294 0312 0247
Sonolor 0238 0193 1535 1040 0578 0391
0312
Sontec 0067 0586 0400 0324 0039
Sony 1535 1681 1655 1040 1781 0041 0383
0066 0840 1955 132 0344 0772 0067 0586
0187 0123 0200 0104
Sound & Vision 0132 0248 0404 0067 0586
Soundesign 0208 0209 0216
Soundwave 0067 0586 0350 0448 0745



Soyea 0803
Soyo 1739
Spectra 0039
Ssangyong 0039
Staksonic 0039
Standard 0067 0586 1067 0248 0039 0247
0350 0404
Starion 1067
Starlite 0039 0582 0193 0067 0586 0294
0442
Stenway 0312 0248
Stern 0236 0289 0193 0393 0294 0441 0581
0465
Stevison 2012 1586
Strato 0067 0586 0294 0039
Strong 1193 1179 1067 0067 0586
Stylandia 0247
Sunic Line 0067 0586
Sunkai 0324 0385 0351 0485 0248 0265
0640 0067 0586 0517 561 0895
Sunny 0067
Sunstar 0401 0067 0586 0039 0294
Sunwatt 0485
Sunwood 0067 0586 0039
Super 1219
Superla 0546 0246 0247
Supersonic 0039 0238 0586 0728 0294 0485
0067
SuperTech 0039 0067 0586 0246 0248
Superton 0461
Supervision 0728 0294
Supra 0208 0404 0039 0067
Susumu 0365 0248 0317
Sutron 0039
SVA 0728 0294 0485 0238 0736
Svasa 0728 0238 0736 0294
Swedx 1636
Swissline 0277
Swisstec 1636 0910 1406 0895 1805 1806
1775 1808
Sydney 0246 0247
Sylvania 0216
Sysline 0067 0586
Sytong 0246
T+A 0477
Tandberg 0397 0441 0139 0367 0226 0392
0391 0193
Tandy 0248 0102 0247 0277 0123 0193
Targa 1401 1221 0648
Tashiko 0066 0073 0247 0200 0246 0193
0393
Tatung 0067 1583 1278 1586 1086 0586
0102 0546 0247 0041 659 1938 1401 1289
1221 1593 1402
TCL 1729 0655
TCM 0744 1319 0838 1338
Teac 0728 1675 0067 1067 0586 0542 0742
0698 0485 0247 736 0294 1939 0208 0039
0442 0379 0751 0312 0366 448 0461 0785
0200 0744 1179 1785 1233 1036 1651 559
1393 0617 1800 1739
TEC 0247 0039 0277 0501 0365 0367 0289
0582 0067 0586 391 0193
Tech Line 0067 0586 0698 1193



Tech Lux 1219 1736
Techica 0248
Technema 0350
Technica 2012
Technics 0680
Technika 1615
TechniSat 0685 0067 0586 0193
Technisson 0744 1319 1682
Techno 1615 1067
Technol Ace 0209 0728 0294 0664 0404
0246
Technosonic 0067 0586 0529 0910 1356
2012
Technotrend 1561
Techvision 1739 1561 1801
Techwood 1193 1067
Teckton 1406
Tecnimagen 0586
Teco 1070 1343 1553
Tedelex 0247 0728 0736 0636 0448 0067
0039 0238 0921 0617 586 0461 1739 1561
0294 1729 1248 1733
Teiron 0039
Tek 0850 0067 0728 0039
Teknika 0090 0209 0216
TELE System 0906 1398
Teleavia 0139 0317 0226 0520 0373
Telecor 0067 0586 0193 0248 0247 0289
0424
Telefunken 0655 0590 0617 0104 0139
0728 0742 0373 0528 0850 926 0501 0810
0921 0317 0114 0131 1733 1736 0365 103
0226 1566 0783 0736 0067 0586 0516 0744
0520 586 0376
Telefusion 0067 0586
Telegazi 0067 0193 0289 0248 0294 0586
Telemeister 0350 0067 0586
Telesonic 0067 0586
Telestar 0039 0067 0586 0442
Teletech 0067 0586 0698 0039 0277 0367
1067
Teleton 0247 0305 0236 0193 0379 0289
0216 0066 0393
Televideon 0350 0582 0193 0246
Televue 0067 0586
Telexa 0132
Temco 0324
Tempest 0039 0067 0586 0294
Tennessee 0067 0586
Tensai 0134 0248 0067 0586 0247 0324
0350 0039 0135 0404 401 0407 0277 0745
0193 1067
Tenson 0350 0039
Tesla 1067 0067 0698 0744 1682 0745 1167
0660 0401 0783 586 0268 0640
Tevion 1278 1328 1675 1289 0067 1220
0586 1586 0838 0895 698 1167 1801 0744
1067 1615 1771 1319 1830
Texet 0247 0404 0039 0246 0248
Thomson 0655 0590 0373 0317 0139 0501
0365 0226 0267 0067 586 0520 0350 0379
0246 0582 1618
Thorn 0138 0139 0255 0103 0373 0220
0391 1535 0268 0222 040 0104 0114 0565
0529 0067 0102 0586 0134 0041 365 0542



0066 0073 0075 0404 0100 0065 0131 0386
Thorn-Ferguson 0134 0138 0139 0220 0222
0268 0391 0529 0365 0103 065
Tiny 1226 1299
TMK 0208 0207
Tobishi 0248
Tokai 0102 0067 0586 0367 0698 0478 0193
0247 0404 0039 067 0582
Tokaido 1067
Tokyo 0246 0065 0478 0333
Tomashi 0312 0248
Tongtel 0810 0617
Top Show 0728 0803 0448 0039 0294 0736
Topline 1067 0698
Toshiba 1538 0538 0090 0065 1319 0744
0066 0100 0132 0271 194 1612 1734 0247
0139 0520 0225 0221 0648 1938 039 0728
0067 0862 1586 0680 1067
Tosumi 2012 1800
Towada 0379 0132 0344 0247 0582
Toyoda 0039 0401 0294
Trakton 0039 0294 0247
TRANS-continent 0698 1067 1404 1407
0895 0586 0067 0516 0247
Tranasonic 0067 0586 0485 0617 0542 0294
0728 0742 0448 0039 393 1356
Transtec 0246
Triad 0067 0586 0248 0039
Trical 0187
Trident 0546 0247
Trio 1593 1583 1675 1278
Tristar 0294 0248
Triumph 0207 0546 0376 0586 0067
Tsoschi 0312
TVTEXT 95 0586
Uher 0067 0586 0236 0350 0333 0404 0448
0516 0400 0289 510
Ultra 0222
Ultravox 0117 0132 0404 0277 0246 0582
0193 0344 0067 0586
UMC 1636 1805 1775
Unic Line 0067 0586 0503 0485 0379
United 0744 0067 0745 0586 1938 1067
0617 2012 1682 1800
Universal 0744 0067 0586
Universum 1067 0067 1193 0376 0698
0135 0510 0225 0503 1179 134 0565 0391
0041 0542 0277 0522 0400 0230 0448 324
0066 0187 0100 0582 0193 0294 0586 0451
0518 441 0104 0357 0358 1535 1040 0379
0247 0139 0392 367 0207 0661 0584 0039
0114 0200 0648
Univox 0067 0586 0367 0117 0193 0268
Utax 0193
V7 Videoseven 1785 0208 0910 1406 1247
1696 0648 1681 1535
Vanguard 0067 0586
Venus 1356
Vestel 1067 1193 1615 0067 0698 0582
0193 0247 0586
Vexa 0039 0067 0586
Victor 0683
Videologic 0248 0246
Videologique 0246 0248 0247
Videosat 0277



VideoSystem 0067 0586
Videotechnic 0246 0350 0247 0404
Videoton 0386 0193 0461 0520
Vidikron 1322 0132 0703 0765
Vidtech 0066 0208
Viewpia 0906
ViewSonic 1608 1785 1360 1618
Viper 0367
Visiola 0246
Vision 0067 0294 0586 0350 0518 0247
1760
Vistar 0236 0391
Vistron 1393
Vivax 1356 1338 0067 1739
Vivo 1727
VMS 0344
Vortec 0067 0586
Voxson 0117 0067 0586 0393 0448 0193
0208
Vue 1600
Walker 1179
Waltham 0247 0386 0448 0317 0415 0067
0586 0698 0139 1067 461 0520 0193 0473
Wards 0209
Watson 1067 1278 1289 0350 0586 0067
0193 0039 0698 0248 424 1938 1406 0357
Watt Radio 0132 0379 0582 0193 0246 0344
0516 0458
Wega 0067 0586 0066 0117
Wegavox 0039 0067 0586
Welltech 0744 1682
Weltblick 0067 0586 0350 0247
Weltstar 1067
Weston 0067 0586
Wharfedale 0067 0926 0921 0586 0728
1586 0736 1402
White Westinghouse 0350 0246 0067 0586
0367 1939
Wilson 0586
Windsor 0698 1067
Windstar 0312 0367
Windy Sam 0586
Wintel 0744 1036
World-of-Vision 0910 0920 0895 1319 1328
0907 1636 1247 1762
Worldview 0485 0075
Woxter 1561
Xenius 0664
XLogic 0728
XMS 1471
Xomax 1800
Xoro 1226 1247 1537
Xrypton 0067 0586
X-View 1221
Yalos 1801
Yamada 1370
Yamaha 0680 0827 1556 1606
Yamishi 0312 0485 0248 0067 0586 0247
Yokan 0067 0586
Yoko 0247 0067 0586 0248 0294 0039 0461
0451 0400 0369 246 0277 0403
Yorx 0248



Ytawai 1561

YU-MA-TU 0067

Zaapa 1219

Zanela 0268

Zanussi 0236 0393 0247

Zenith 1939

Zenor 0369

Zepto 1615

ZX 1938

SA T

Sat

Bush 1267

DVD

DVD Brands and Codes

Plus 0520 D LAB 0569 1579 Kus 1188

Acoustic Solutions 0760 2112 2148 0743
1272 1258

Advance Acoustic 1579

AEG 0818 0800 0820 1464 1263 1953 0705
2203

AFK 1228 1258 1182 1953 1081

Afreey 0728

AG Electronics 1258

Aim 0808 1195 1207 0729 0702 0820

Airis 1254 1351 0702 1035 1396 1375 1137
1652

Aiwa 0671 0725 0899 0563 1273 2050 2073

Akai 0820 0809 0818 1145 0928 0796 0746
0914 0743 0882 735 2005 1119 1425 1725
1263 1721 1587

Akashi 0868

AKI 0883 1035 0810

Akira 0729 1650 0808 1351

Akura 1201 2142 1200 0928 1081 1397
1170

Alba 0747 0729 0743 0753 0725 0760 0813
0569 0702 1170 081 1521 1560 1725 1865

Alize 1181

All-Tel 0820 1481

Amitech 0152 0800 0880

Amoi 0882

Amoisonic 0794

Amstrad 0743 1145 1181 1397 1601 1695
1203 0820 1519 1186 800

AMW 0902

Ansonic 0789 0861

Apex Digital 0702 0829 1086 1284

Arena 0882 1145

Aria 0923

Arianet 0923

Aristona 0569 0676

Art Mito 1451

ASCOMTEC 1953

Asono 1254

ATACOM 1254

ATD 0911

Atlantis Land 0828

A-Trend 0744

Audiola 1650

Audiosonic 1670 1953 1557

Audioworld 0820



Audix 1134 1182 2119 0743
Autovox 0743
Auvio 0873 1120
Auvion 1518
Avious 1195
AWA 0760 0902 1693 1585 0152
Axion 0760
Baier 0782
Base 1481 2118
Basic Line 0743 2024
Baze 1195 0928 0702
BBK 0892 1254 1114
Beep 1193
Bellagio 0902 1275 1034
Belson 1953 1660 2122 0618
Best Buy 0887 1119
Binatone 1953
Biostek 1035
Black Diamond 0743 0796 0914 1371 0863
Blaupunkt 0747 1069
Blu:sens 1519 1263 1351
Blue Sky 0743 0729 0725 0834 0702 0873
0808 0681 0820 0914
BlueTinum 1203
BNI 1351
Boghe 1034 1251
Boman 0813 0818 0928 1035
Bose 2053
Brainwave 0800 1145 1265
Brandt 0681 0581 0533
BSkyB 2010
Buffalo 1912
Bush 0743 0725 0863 1725 0760 0861 0729
0747 0808 0546 706 0848 0909 0914 0753
1195 1466 1449 1513 1170 862 1207 1397
1186 1560 0146
Cambridge Audio 1139 1114 0781 0726
Cambridge Soundworks 0726
Campomatic Digital 1081
CAT 0729 0816 0819 1844
CCE 1947
Celestial 0702 1050
Celestron 2005
cello 1472 1488 1760 2142
Centrex 0702 1034 1945
Centrum 0743 0819 0809 0923 2024 1035
1953 1535 0705
CGV 0800 0781
Cinea 0871
Cinetec 0743 0902
cineULTRA 0729
CineVision 0906
CJ Digital 2203
Classic 0760 1947 1760
Clatronic 0818 0809 0848 0702 1195 1871
1207 1464 0705 1263
Clayton 0743
Coby 0808 0760 1137 0882
Codex 1263
Compacks 1396 1137 1689
Conia 0702 0882 1660 0794 0546 1155
1351



Contel 0818
Continental Edison 0902 0861
CrossWood 1183
Crown 0800 0681 1186
Crypto 1258
C-Tech 0828 0798 1182
Cybercom 0861
CyberHome 0744 0846 1053
Cytron 0746 0681 0735 0861 1377
Daenyx 0902
Daewoo 0862 0863 1513 0735 0800 0744
1948 1466 0902 1171 871 1471 0808 1102
1693
Dalton 0816 1066
Dansai 0800 0777 0813 1145 1725
Dantax 0753 0725 1119 0743
Daytek 0902 1035
Dayton 0902
Daytron 1070
DCE 0861
DEC 0808 0729 0848 1720
Decca 0800
Denca 1186
Denon 0664 1664 1874 0520
Denver 0808 0729 0818 0928 0848 1137
1351 1445 1480 1953 086 1871 1295 0702
1207
Denzel 0695
Diamond 0681 0798 0808 0781 1186 0753
0820 1182 0800 1145
Digihome 0743
DigiLogic 0743 1693
digiRED 0747
Digital 2203
Digital i 0923
Digitech 1862
Digitek 0152
Digitor 0157 1035 0681
Digitrex 1945 0702 1086 1034
DigiX 1859
DiK 0861
Dimarson 1696 1263
Dinamic 0818
Disney 1253 0861
DiViDo 0735
DK digital 0861 1140 0870 1276 1284 1587
DL 0883
DMTECH 0813 0820 2076 1301 1541 1102
Dragon 0861
DSE 1760 0863 1182 1427 1425 1859 1557
0152 0705
DTS 0829
Dual 0861 0743 0695 0681 0760 0813 0809
0820 1053 1466 560 0914 1145
Durabrand 0861 0705 0743 1560 1693
D-Vision 1145 1397 1521 1203
DVX 0798 1862 1182
e:max 1263 1351 1588 0360 2203 0800
EagleTec 0744
eBench 1182
E-Boda 0753
Ecco 1585 2135



Eclipse 0753 0781
Ecron 1445
E-Dem 1254
Elco 1186
Electro 1119
Electrohome 0800
Elenberg 1258 1862
Elfunk 0880 0914 0743 0793
Elin 0800
Ellion 0880 1451 0152
Elta 0800 0818 0820 2021 1145 1181 1140
1263 1081 1203 689 2203
Eltax 0796 1650 1351 2017
Emerson 0621 0735 0899
Encore 0728
Enzer 0695 1258 0796 1035 1390 0800
EuroLine 0818 1145 1263 1914 1585 0705
Eurostar 1425
Fenner 1425
Ferguson 0681 1760 0928 0743 0914 1725
1158
Finlux 0771 0800 0813 0621 0702 0781
1177 1195 1914 0706 292
Fintec 0743 1560 1397
Firstline 0829 0899 0681 1560
Funai 0725 0705
Futronic 0923 1035
GE 0747
Germatic 1081
Giec 1251
Global Link 1254
Global Solutions 0798 1182
Global Sphère 0798 1182
Go Video 0813
Gold 2142
GoldStar 0621 0771
Goodmans 0743 1034 0753 0781 0813 0760
0681 0820 0848 0909 863 2044 1251 1170
1284 1953 1760 1207 0146 2010 560
GP Audio 1170
GPX 0771
Graetz 0695
Gran Prix 0861 0928
Grandin 0746 1284 0702 1203 0743 2203
Grundig 0725 0805 0569 0681 0820 0735
0743 0700 0753 2076 725 1034 0581 1760
1950 1466 1513 1862 1207
Grunkel 0800 1186 0861
GVA 1689
H&B 0848 0743 0871 0880 1263 1265 1451
0152
Haaz 0798 0781
Haier 0873 1120
Hanseatic 0771 0813 1183 0820 1914 1301
Harman/Kardon 0732
Haus 0816
HCM 0818
HDT 0735
HE 0760 1193 1953
Henß 0743
Hicon 0702
Hikona 1200



Himage 0855 1119

HiMAX 0887 0873

Hitachi 0694 0809 1950 2024 0695 0603
0887 0743 1865 1778 171 0914

Hiteker 0702 1953

Höher 0861 1034 1254 2203 0743 1560

Home Electronics 0760 0800

Home Tech Industries 1254 1953

HYD 1263

Hyundai 0813 0880 1186 1258 0796 2076
1557 0818 1451 0798 182 2142 0863

ICP 1182 1183

Ilekei 1371 1137

IISonic 2132

Ingelen 0818

Inno Hit 0743

Inotech 0624

International 1693

Irradio 0771 1145 1254 1263 0899 0870
0800

ISP 0725

it's 0747

Jamo 1066

Jay-tech 1265

JBL 0732 1956

JDB 0760

JDV 1397 1258 1585

Jeken 0729 0808

Jepssen 1213

Jeutech 0796

JGC 1696 1560

Jindian 0829

JMB 0725

JNC 1301

JNL 0765

Jocel 0810

JVC 0653 0588 1931 1970 1194 0569 0533
0668 0897 1271 890 1893

jWIN 1081

Kansai 1137

Kansas Technologies 1263 1560

Karcher 0813 1397

Kendo 0743 0729 0861 0702 1377 1725

Kennex 0800 0870 0743 0928

Kenwood 0564 0520 1936

KeyPlug 0800

Kiiro 0800 0810 0883

King D'Home 0829 0863

Kingavon 0848

Kiss 0871 1553 0695 0426

Koda 0848

Koss 0681

Kotron 0881 0909

KXD 0887 1137 1351 1953

Labway 0561

Lasonic 0828

Lawson 0735 0746 0798 1182

Lecson 0726 0777

Leiker 0902

Lenco 0729 0681 0800 0808 0848 0743
0861 1195 1535 0618 207

Lenoir 1258



Lenoxx 2044 0868 1035 1953
Lenoxx Sound 2044
Lexia 0729 1182 0798
Lexicon 0701
LG 1920 0771 1936 0899 2032 0621
Lifetec 0681 0861 1377
Limit 0746 1182 0798
LiteOn 1486 1188 1446 1088 1768 1674
Lodos 0743
Loewe 0569 0771
Logic3 0802
LogicLab 0798 1182
Logik 0743 0914 1862
Logix 0735 0813
Luker 1397
Lumatron 0735 1145 0771 0863 1351 0743
0760 0928 1862
Luxman 0603 1121 2136
Luxor 1034 0743 1760 0760 1275 0747
0914
Magnat 2076 1914
Magnavox 0848 0533 0705 1170 1207 0569
0743 1251 1384
Magnex 0753 1195 1519
Magnum 2044 1466 1535
Majestic 1137 1375 1186 1650
Manhattan 0735 0743
Marantz 0569
Mark 0743 0725 1725 0914
Marks and Spencer 2142
Marquant 0800 1481 0618 1521
Mastec 1036 1464 1251
Master-G 1186
Matrix 1272
Matsui 0743 0681 0702 0725 2131 0914
1102 1760 1488
Maxdorf 0818
Maxim 0855 0743 1272 1425 1397
Maya 1375
Maytag 1445
MBO 0760 1947
MDS 0729 0808
Mebeteck 0592
Mecotek 0800
Medialine 1301
Mediencom 0883 0781
Medion 0861 0813 1377 0681 0746 0788
1375 0909 0660 2042 120 1195 1036 1579
1446 1674 0771 2106
MEI 0820
Memorex 0861
Memory 0760 1081
Metz 0601 0555 0743 2024
MiCO 0753 0781 1251 1253 1209 1284
Micromaxx 1725 0725 1377
Micromedia 0533 0569
Micromega 0569
Microsoft 0552 1738
Microstar 0861
Minato 0782
Minax 0743
Minerva 0735



Minoka 0800 1145
Minowa 1195
Mirror 0909 0782
Mitsubishi 0743
Mizuda 0848 0887 1481
Monbel 1425
Monyka 0695
MPX 0873
MTlogic 1295
Multitec 1397
Mustek 1947 0760 1760
Muvid 2203
Mx Onda 0681 2010 0781 0753 1209 1253
1284
Myryad 1284
Mystral 0861 1186
NAD 0771 1857
Naiko 0800 1397 1034
Narita 1397
NEC 0899 0621 1948 0771
Neon 0152
Neovia 1301 2005
NeoXeo 2151
Netway 1519
Neufunk 0695
Nevir 0861 0800 0702
Nexius 0820
Nikenny 1119
Nikkai 1953
Nikkei 1284
Nintaus 0823 1081
Nordmende 0861 1560
Noriko 0782
Nortek 2203
NorthQ 1518
Nowa 0873
NU-TEC 0546 1258 1472 0624
Okano 0782
Omni 0728 0870 0729 0808 0863 1095
1134 1862 1258 2135 118
Onix 0868
Onkyo 0657 0533 1799
Onn 2142
Onyx 2142
Oopla 1188
Optim 0777 0873
Optimus 0601 0555
Orava 0848 1519
Orbit 0902
Orion 0725 1158 1725 1036 1263 1449
0928
Oritron 0681
OTIC 1371
P&B 0848 1481
Pacific 0820 1182 0798 0789 0834 0743
0861
Packard Bell 0861
Palladium 0725 0809 0743 1397
Palsonic 0702 0882 1086 1584 2094 0863
Panasonic 0520 1864 1938 1935 0662 1937
1040 1041 1609 1668



Panda 0747 0813 1137
Papouw 0563
Paramount Pictures 0809
peeKTON 0155 1070 1254 2130 0928
Philips 0569 0676 1370 1384 0915 1941
0705 1536 1842 1843 086 0533 1188 0701
1876 2079 2123
Philo 1375
Phocus 1722
Phonotrend 0729 1195 1871 1207
Pioneer 0601 1995 0661 0555 0668 1930
1932 0662 1841 1601 490
Playgo 1295
Plu2 1120 0880
Pointer 0800
Portland 0800
Powerpoint 0883 0902 0788 0810 1035
1670 2142
Prima 0796 1258 1472
Prima Electronic 0796
Prinston 1519
Prinz 0861
Prism 1036 1183 0861 1695 1119
Pro2 1302 1375
ProCaster 1034
Prodisma 0883
Proel 1871
Proline 0681 2112 0702 0820 1034 1513
0863 1945 1768 2119
Proscan 0552
Proson 0743 1114 1035
Prosonic 0729 1137 2142 0782 1953 1471
Provision 0729 0848 1193 1953 1351 1137
0760 1207 1302
Pye 0676 0569
QONIX 1207 0808 1081 1689
QVision 1696
Radionette 0771 0899 2054 1936 0671
Radiotone 0743
Raite 0695
Rank Arena 0810 1209
RCA 0552 0681
REC 0796 0520
Red Star 0789 0793 0800 0818 0928 0836
1070 1953 1137 1375
Redbell 1535
Redpoint 1284
Relisys 1377 2121
Reoc 0798 1182 0782
Revoy 0729 0871
Rex 0868
Richmond 1579 1263
Rimax 1181
Ritech 1390
Roadstar 0729 0743 0848 1069 0760 1081
0928 0863 2044 1859 959 1257 1207 1862
1464
Rocksonic 0819
Rolsen 2005
Ronin 0902
Rotel 0653 0588
Rowa 0789 1034 0546 0555 0747



Rownsonic 0819 0753
S&V 1195
Saba 0681 2203 0581
Sabaki 0828 0798
Saivod 0861 0789 1397 0800
Sakyno 1182 0798
Salora 0771
Sampo 0728 0782 1377
Samsung 0603 0774 1962 0850 1105 1966
2038 0520 1603 1665 778 0328 2137 2143
Sansui 0725 0746 0798 0800 1182 0753
0781 1258 1371 0881 579 1862 1914 1725
2017 1859 0152 1081 1145 0793 693 1521
Sanyo 0700 1471 0862 0725 0820 1693
0903 0743 1258
SAST 0836
Scan 0735 0880
ScanMagic 0760 1760
ScanSonic 0887
SCE 0819
Schaub Lorenz 0818 1195 0800 1265 1182
Schneider 0813 0861 0809 0569 0735 0834
0818 0743 0681 0899 820 1183 1914 1397
0676 1535 0292 1257
Schönteck 0743
Schwaiger 0782
Scientific Labs 0798 1182
Scott 0810 0681 0702 0911 0883 1066 2044
1263 1660 2203
Seeltech 1254 1481
SEG 0743 0695 0798 1182 0828 0914 0902
0793 2024 2005 560 1203 1513
SeViC 2094
Shanghai 0702
Sharp 0660 0782 0743 0725 2045 1286
1449 2054
Sherwood 0747 0771
Shinco 0747
Siemssen 1412
Sigmatek 0887 1254 1518 2135
Siltex 1254
Silva 0818 0928 0861
Silva Schneider 0861 1936 0771
SilverCrest 1182 1398 0798 0156 0161 2203
Singer 0746 0753 0781 0798 1182
Sinotec 0794 0800 1145
Sinudyne 1170 1284
Sistemas 0702
Sky 0152 2010 2154
Skymaster 0760 0798 1182
Skysonic 0796
Skyworth 0928 0796
Sliding 1145
Slim Art 0800
Slim Devices 0563
SM Electronic 0760 0798
Smart 0735 0743
Sogo 0883
Solavox 2119
Sonashi 0746 0861
Soniko 0818
Soniq 1689



Sontech 1186
Sonwa 1034
Sony 0563 1100 2011 1663 2050 1933 0894
0802 1964 1063 099 1047 2073 1897 1566
1854 2162
Sound Color 1263
Soundmaster 0798 1182
Soundmax 0798 1182
Soundwave 0813 1560
Spectra 0902
Standard 0681 1182 0798 0818 0861 0928
Star Clusters 0798 1257 1182 0828
Star Sound 1472
StarLogic 1035
Starmedia 0848 0923 0911 1254 1035
Stevison 1397 0706
Strato 1557 1412 2133 1182
Strong 0743
Sumvision 1472 1696
Sunfly 0887
Sunkai 0800 0880
Sunstech 0861 1102 1650 1541 1301
Sunwood 0818
Supervision 0760 0798
Supratech 0923
SVA 0702 0782
Swisstec 2154
Symphonic 0705
Synn 0798 1182
Sytech 0155
T.D.E. Systems 1186
Tandberg 0743 1725
Tangent 2017 1351
Targa 1188 1257 1649 1674 0146 2106 0771
1936
Tatung 0800
Tchibo 0771
TCM 0771
Teac 0747 0771 0820 0546 0601 0798 0788
1036 1182 0765 621 0789 1959 0863 1966
1257 0680 1195 0705 1254 258 1943 1689
2142 1693
TEC 0928
Technica 1203 1397
Technics 0520 1935 1937 1938
Technika 0800 1145 0861 1660 1560 1195
1519 0157 1182
Technosonic 1081 1145 1579 1397
Techwood 0743 1560 0569 2024
Tecnimagen 1263
Tedelex 1034 1258 0798 0800 1182
Telefunken 0820 0819 0818 1258 1953 1862
1720 0680 0863 1513 145 0788 0800 0624
1375 1585
Teletech 0743 0914 1182 0798
Tensai 0681 0800
TerraTec 0855
Tevion 1066 0681 0828 1412 1451 1200
1535 1182 1693 0798 034 1959 2044 1257
0863 1377 1760 1660
Theta Digital 0601
Thomson 0581 0552 0147 1284 2010 0861
Time 0152 1541



Tiny 1519
Tokai 0928 0695 0728 1587 0818 1263
Tokaido 0728
Tokiwa 0735 0746
Tom-Tec 0819 0863 1480
Tongtel 0794
Top Suxess 1254
Toshiba 0533 0788 1075 1540 2036 1667
1799
Tosumi 1397 2142
TProgress 0782
TRANS-continents 0902 0861 1357 1195
1263 0863
Transonic 0702 1195 1469
Tredex 0829 0873
Trevi 0861
Trio 0800
Triprox 1518
TruVision 0887 1481
TSM 1254 1579
TVE 0743
Umax 0561 1181
Unimade 0152
United 0818 0760 0820 1258 0702 1371
1195 0725 1145 0729 798 1263 1203 1519
1585 0743 0914 1182 1862 1397 021 0705
1689 1102 2142
Universal 1588
Universal Multimedia 0798 1182
Universum 0771 0743 0621 0809 1948 1943
1257 1859 0820 1560
Uptek 0793 0923
upXus 1310 1375
Venturer 0820 2112 1799
Vestel 0743 1560 2024
Vieta 0735 1295
Viewmaster 1114 0892 1254
Voxson 0760 0861
VTrek 1258
Waitec 1254 1947 0760
Walkvision 0747 1069 0618
Waltham 1560
Welkin 0861
Wellington 0743
Welltech 0618 1251
Weltstar 0743
Wesder 0729
Wharfedale 0798 0726 1862 0728 0753
0820 1182 0781 0782 0800 865 1145
Wilson 0861 1263
Windy Sam 0603
Wintel 1160
Wistar 1469
Woxter 1181 0911 1254 1521
XBox 0552 1738
Xenon 1953
XEOS 1579
XLogic 1862 0911 0800 0798 1182 0828
1258 1445
XMS 0818 1352 0800
Xomax 2142
Xoro 1213 1203 0836 1251 1521
Xwave 0561



Yakumo 1034 1086

Yamada 1034 0902 1181 1446 1086 1519
1188 1521 2135

Yamaha 0569 0676 0847 0520 1188

Yamakawa 0695 1579 0902 1134 1519

Yelo 0810

Yukai 0760 1947

Zenith 0533 0621 0771

Zennox 1295

Zeus 0881