UPDATED PHLEBOTOMY Procedures for Collection of D

Presented by: Helen Maxwell Executive Director, ASPT

Procedures for the Collection of Diagnostic Blood Specimens by Venipuncture; Approved Standard—Sixth Edition December, 2010

CLSI 2011 STANDARDS

Clinical Laboratory Standards Institute

- Formally NCCLS
- International, interdisciplinary, non-profit, standards-developing, educational organization
- World-wide standards
- Way to improve patient testing and healthcare services

What is CLSIP

UNIVERSAL PRECAUTIONS

Apply to transmission of blood borne pathogens.

STANDARD PRECAUTIONS

Cover transmission of all known infection agents; more comprehensive. **5**

Standard Precautions Combine

- Universal Precautions
- Body Substance
 Isolation Practices

CLSI Standards

Personal Protection in the Laboratory:

- Wear long-sleeved gowns with closed fronts or long-sleeved laboratory coats that are buttoned closed while in the laboratory.
- Wear laboratory coats or gowns inside the laboratory only.
- Reusable cloth or disposable gowns/coats may be used.

PROTECTIVE CLOTHING

Occlusive Dressing

 Cover all non-intact skin located on parts of the body exposed to blood or body fluid with a waterimpermeable occlusive bandage.

• NOTE:

REMOVE ALL PERSONAL PROTECTIVE EQUIPMENT BEFORE LEAVING THE LABORATORY OR WORK AREA.

PROTECTIVE CLOTHING

- Gloves of proper size and material must be provided for your protection.
 - Use aseptic techniques when both putting on and removing gloves.
 - Wear gloves at specimen receiving and set-up areas.
 - Do not contaminate clean areas by contact with contaminated gloves.
 - Change gloves after contact with each patient.
 - Removes gloves before handling telephones, uncontaminated laboratory equipment, doorknobs, etc.

HAND PROTECTION

- Decontaminate hands after touching all potentially infectious material, whether or not gloves are worn.
 - Use an alcohol-based hand rub or soap and water if hands are not visibly soiled.
- Removes gloves promptly after the completion of all tasks.

- Decontaminate hands immediately after gloves are removed and when otherwise indicated to avoid transfer of microorganisms to other surfaces and environments.
- Change gloves between patients when performing phlebotomy. Decontaminate the hands after glove removal and before donning new gloves.

- Decontaminate hands:
 - After the completion of work and before leaving the laboratory:
 - Before eating, drinking, smoking, applying makeup, changing contact lenses, and before and after using lavatory facilities; and
 - Before all other activities which entail hand contact with mucous membranes, eyes, or breaks in the skin

- Avoid soap products that may disrupt skin integrity.
 A moisturizing hand cream may reduce skin irritation caused by frequent hand washing; but some nonpetroleum-based hand creams may affect glove integrity.
- Avoid wearing artificial fingernails or extenders when in direct contact with patients at high risk for infections, such as those in intensive care units or operating rooms.

- Use facial barrier protection if there is a reasonably anticipated potential for spattering or splashing blood or body substances.
- Full-face shields made of lightweight transparent plastic are the preferred means of facial protection.
- Splashguards may serve as an acceptable alternative to plastic face shields.

FACIAL PROTECTION

- Use a fluid-resistant mask and eye protection if face shields are not available.
- Ordinary prescription glasses are not adequate eye protection. Use plastic, wraparound safety glasses that fit over regular glasses.

FACIAL PROTECTION

- All respirators used in healthcare settings in the United States must be certified and approved by NIOSH.
- In the United States, OSHA requires that respirators be used as part of a respiratory protection plan that includes medical evaluations, fit-testing, proper selection of respirators, annual training, and respirator maintenance.

RESPIRATORY PROTECTION

Following the steps in doing a proper venipuncture is critical in healthcare.

WHAT IS THE MOST IMPORTANT STEP IN DRAWING BLOOD?

- Identifying the In-Patient
 - Must be two (2) identifiers:
 - Ask the patient's FULL name
 - Ask the patient's date of birth

Patients that cannot communicate—caregiver will give the required communication.

19

- Identifying the Out-Patient
 - Must be at least two (2) identifiers:
 - Ask the patient's FULL name
 - Ask the patient's date of birth
 - Ask the patient's address

Patients that cannot communicate caregiver will give the required communication.

• NEVER DRAW IF THERE IS A DISCREPANCY!

- Identify yourself:
 - Who you are
 - Where you are from
 - What you are going to do

- VERIFY fasting states:
 - Have you had anything to eat or drink?
 - When was the last time you had anything to eat or drink?

- Verify Diet Restrictions
 - Some tests require diet restrictions
 - Fasting
 - Eliminating certain foods

**Each facility should have a policy manual

STEPS IN DOING A VENIPUNCTURE

Outpatient:
Ask patient if
medication has
been taken.

- Check Latex Sensitivity:
 - Gloves
 - Tourniquets
 - Bandages
- Check for Allergies:
 - Seafood
 - Other

- Sanitize hands
- Put gloves on
 - Recommended:
 DO NOT touch patient without gloves on.

Check Request Form Should Include:

- Patient's:
 - Full name
 - Date of birth
 - Identification number
 - Date, time it is drawn
 - Name or initial of HCP
 - Department/tube color

Other Information:

- Where drawn
- Special comments IV site and
 - information
- Documentation (if you had someone identify patient)

- Position the Patient
 - Make them comfortable
 - Foreign objects out of mouth
 - Gum
 - Mints
 - Food
 - Thermometer

- Assemble Supplies
 - Inspect all supplies
 - Remember to use the same (manufacturer) needle, holder, and tube

Inspect all tubes

- CLSI states—<u>NEVER</u> combine:
 - Tubes
 - Holders
 - Needles
 - From different manufactures

30

- Could cause:
 - Hemolysis
 - Needle/holder disengagement
 - Inadequate filling of a tube

• TUBES:

- **Check** for expiration dates.
- Must have a clear view of the contents *unless* test must be shielded from <u>light</u>.
- No sharp edges
- No surface roughness (capable of cutting skin)
- Should be used to collect blood straight into the tube
- Must retain vacuum

- Glass tubes are strongly recommended for medication levels.
- Plastic/glass serum should never be used before a coagulation tube.

- Tubes **MUST** be:
 - Durable over its shelf life and during centrifugation.
 - Plastic syringes should be avoided.

Apply tourniquet

- Tourniquet is used to increase intravascular pressure
 - (*Tourniquet should be latex-free; single use only.)
- Helps with the palpitation of vein
- Helps with filling of the tube
- Within 20 seconds, the analytes begin to change
- Suggested time=1 minute
- Retying a tourniquet: must wait two (2) minutes

STEPS IN DOING A VENIPUNCTURE

35


- Tourniquet Location
 - 2-4 inches above OR
 - 3 fingers

DO NOT HAVE PATIENT PUMP HAND!

- Blood Pressure Cuff:
 - Inflate no more than 40 mmHg
 - Pump hand one to two times
 - NO vigorous hand pumping (change certain analytes)

- DO NOT USE the following veins!!!
 - Underside wrist
 - Lower extremities
 - Feet
 - Ankles
 - On the side of a mastectomy arm

- Problems that can occur:
 - Phlebitis
 - Thrombophlebitis
 - Tissue Necrosis (death of tissue and cells)
 - Accidental Arterial Puncture
 - Nerve Damage



Select Site

Diagram: Clinical and Laboratory Standards Institute

STEPS IN DOING A VENIPUNCTURE

- Cleanse Venipuncture Site
 - Concentric motion from center to peripheral
 - Allow area to <u>DRY</u> at least 30 seconds
 - Do not wipe dry
 - Prevents:
 - Hemolysis
 - Prevent burn in sensation on patient
 - Allow antiseptic to work



Difficult Veins

If you MUST re-touch, then you MUST re-CLEAN!

STEPS IN DOING A VENIPUNCTURE

- Perform the Venipuncture
 - Hold arm below the venipuncture site.

**NO "window" method!

- Puncture at a 30 degree angle.
- Use correct order of draw.
 - See the ORDER OF DRAW NEXT SLIDE

YELLOW

• LT. BLUE

PLAIN RED

PLASTIC RED

GOLD, RED/GRAY

GREEN

• LAVENDER, TALL PINK PURPLE

GRAY

SPS (Blood Cultures)

Sodium Citrate

No Additive

Clot Activator

SST/Gel w/ Clot Activator

Heparin-Lithium or Sodium

EDTA

EDTA

Sodium Fluoride, Potassium Oxalate

• NOTE:

Other tubes will be added into the Order of Draw by their additives.

CLSI ORDER OF DRAW

• Invert tubes IMMEDIATELY:

- $CA \rightarrow 5$ times
- Na Citrate → 3-4 times
- Heparin → 8 times
- EDTA → 8 times
- Na Fluoride >> 8 times

• Perform the Venipuncture

- Release tourniquet.
- Place gauze over the site. (NO cotton balls!)
 - Gauze should be pre-packaged; 2X2.
- Remove needle and dispose **IMMEDIATELY**.

• NOTE:

- A <u>clearing tube</u> must be used if using a butterfly for coagulation studies
- A non-additive tube may be drawn *before* coagulation studies when using a **multi-draw needle**
- NO clot activator or additive tube should be drawn *before* coagulation studies

- If patient has a problem, do not use ammonia inhalants.
 - Patients may have an adverse reaction.

- Check the venipuncture site (after 3-5 minutes).
- Bandage for 15 minutes to one (1) hour.
- Patients should **NOT** bend the arm up.
- Healthcare professional should notify nurse or supervisor if bleeding lasts more than five (5) minutes.

• Labeling:

- Patient's last and first name.
- ID #
- Date, time, and initials of person collecting sample.
- Time when TDMs are being collected.

NEVER leave a patient before labeling tubes!

NEVER walk into a lab without a specimen being labeled!

- Examples of tests requiring specimen chilling are:
 - Gastrin
 - Ammonia
 - Lactic acid
 - Catecholamines
 - Pyruvate
 - Parathyroid hormone (PTH)

SPECIAL HANDLING

- Examples of tests requiring specimen transportation at 37 °C include:
 - Cold agglutinin
 - Cryofibrinogen
 - Cryoglobulins

SPECIAL HANDLING

- Examples of tests requiring specimen protection from light:
 - Bilirubin
 - All Vitamin levels
 - Beta Carotene
 - Porphyrins

SPECIAL HANDLING

- Send Blood Collection Tubes to the Proper Laboratories:
 - Appropriately labeled blood collection tubes should be sent to laboratories designated to perform the required testing procedures.
 Maintain proper transport conditions to preserve specimen integrity.

• Serum:

- Specimens should be clotted before centrifugation.
- Spontaneous and complete clotting normally occurs within 30 to 60 minutes at room temperature (20 to 25 °C).
 - NOTE: The use of a wooden applicator stick or similar device for the release of a clot attached to the tube closure or the sides of the tube (i.e., "rimming") is not recommended because it is a potential source for the laboratory-induced hemolysis.
- The time to clot will be prolonged if the patient is on anticoagulant therapy or if the specimen is chilled.

• Plasma:

- Use a collection device containing an anticoagulant when plasma is required or acceptable.
- Centrifuge anti-coagulated specimens immediately after collection.

Chilled Specimens:

- To chill a specimen, place it immediately in a mixture of ice and water. Good contact between the cooling medium and the specimen is essential.
- Adequate cooling is essential; however, avoid direct contact between the specimen and ice (or other cooling materials such as dry ice), because the temperature extreme may cause hemolysis.
 - **NOTE:** Chilling whole blood beyond two hours is contraindicated for a specimen intended for potassium.

• Preservatives:

- Use sodium fluoride to stabilize glucose in the presence of blood cells for up to 24 hours at 25 °C or 48 hours at 4 to 8 °C.
- Use micro collection devices containing a suitable anti-glycolytic agent for pediatric blood glucose collection.

Criteria for Rejection:

- Under the following conditions, blood specimens may not be acceptable for testing purposes:
 - Inappropriate specimen containers
 - Inadequate or incorrect specimen identification
 - Inappropriate volume of blood
 - Using the wrong collection tube
 - Hemolysis
 - Improper storage/transportation

• Time and Temperature:

- Transport specimens in the appropriate biohazard bags or containers to the laboratory in as short a time as possible.
- Unless chilling of the specimen is required (i.e., lactic acid, ammonia), transport all specimens at room temperature.
- Prompt removal of specimens from the collections area is especially important if the area temperature is above 22 °C, which may cause some measurands to deteriorate.

• Tube Orientation:

- Place tubes of blood in a vertical position.
- Non-anti-coagulated tubes that contain gel should always be stored in an upright position as soon as the mixing is completed.
 - NOTE:
 - Evaluate automated transport systems, pneumatic or otherwise, for any effects on laboratory results.

• Tube Closure:

• Keep tubes of blood closed at all times.

Keeping the tube in a closed position eliminated possible exogenous contamination of the specimen and prevents evaporation and the possibility of spills and aerosols.

• Agitation:

• Gentle handling of collected specimens helps to minimize erythrocyte damage leading to hemolysis of specimens.

• Exposure to Light:

- Avoid exposing blood specimens for photosensitive measurands (i.e., bilirubin) to artificial light or sunlight (ultraviolet) for any length of time.
- Protect these specimens with an aluminum foil wrap, an amber specimen container, or the equivalent.

Please feel free to contact ASPT with any further questions.

Thank you for your time today!

843.767.2464

www.aspt.org

hmaxwellaspt@sc.twcbc.com

QUESTIONS