

Learning MIPS & SPIM

- MIPS assembly is a *low-level programming language*
- *The best way to learn any programming language is to write code*
- We will get you started by going through a few example programs and explaining the key concepts
- *Tip: Start by copying existing programs and modifying them incrementally making sure you understand the behavior at each step*
- *Tip: The best way to understand and remember a construct or keyword is to *experiment with it in code*, not by reading about it*




MIPS Assembly Code Layout

- Typical Program Layout

```
.text          #code section
.globl main    #starting point: must be global
main:
# user program code
.data          #data section
# user program data
```

MIPS Memory Usage as viewed in SPIM



MIPS Assembler Directives

- Top-level Directives:
 - **.text**
 - indicates that following items are stored in the user text segment, typically instructions
 - **.data**
 - indicates that following data items are stored in the data segment
 - **.globl sym**
 - declare that symbol sym is global and can be referenced from other files

MIPS Assembler Directives

- Common Data Definitions:
 - **.word** w1, ..., wn
 - store n 32-bit quantities in successive memory words
 - **.half** h1, ..., hn
 - store n 16-bit quantities in successive memory halfwords
 - **.byte** b1, ..., bn
 - store n 8-bit quantities in successive memory bytes
 - **.ascii** str
 - store the string in memory but do not null-terminate it
 - strings are represented in double-quotes “str”
 - special characters, eg. \n, \t, follow C convention
 - **.asciiz** str
 - store the string in memory and null-terminate it

MIPS Assembler Directives

- Common Data Definitions:
 - **.float** f1, ..., fn
 - store n floating point single precision numbers in successive memory locations
 - **.double** d1, ..., dn
 - store n floating point double precision numbers in successive memory locations
 - **.space** n
 - reserves n successive bytes of space
 - **.align** n
 - align the next datum on a 2ⁿ byte boundary.
 - For example, **.align 2** aligns next value on a word boundary.
 - **.align 0** turns off automatic alignment of **.half**, **.word**, etc. till next **.data** directive

MIPS: Software Conventions for Registers

0	zero	constant 0	16	s0	callee saves
1	at	reserved for assembler	...		
2	v0	results from callee	23	s7	
3	v1	returned to caller	24	t8	temporary (cont'd)
4	a0	arguments to callee	25	t9	
5	a1	from caller: caller saves	26	k0	reserved for OS kernel
6	a2		27	k1	
7	a3		28	gp	pointer to global area
8	t0	temporary	29	sp	stack pointer
...			30	fp	frame pointer
15	t7		31	ra	return Address
					caller saves

Pseudoinstructions

- **Pseudoinstructions** do not correspond to real **MIPS** instructions.
- Instead, the assembler, would translate **pseudoinstructions** to real instructions (one on more instructions).
- **Pseudoinstructions** not only make it easier to program, it can also add clarity to the program, by making the intention of the programmer more clear.

Pseudoinstructions

- Here's a list of useful pseudo-instructions.
- **mov \$t0, \$t1:** Copy contents of register t1 to register t0.
- **li \$s0, immed:** Load immediate into to register s0.
 - The way this is translated depends on whether **immed** is 16 bits or 32 bits.
- **la \$s0, addr:** Load address into to register s0.
- **lw \$t0, address:** Load a word at address into register t0
- Similar pseudo-instructions exist for **sw**, etc.

Pseudoinstructions

- **Translating Some Pseudoinstructions**
- **mov \$t0, \$s0** addi \$t0, \$s0, 0
- **li \$rs, small** addi \$rs, \$zero, small
- **li \$rs, big** lui \$rs, upper(big) ori \$rs, \$rs, lower(big)
- **la \$rs, big** lui \$rs, upper(big) ori \$rs, \$rs, lower(big)

- where **small** means a quantity that can be represented using 16 bits, and **big** means a 32 bit quantity. **upper(big)** is the upper 16 bits of a 32 bit quantity. **lower(big)** is the lower 16 bits of the 32 bit quantity.
- **upper(big)** and **lower(big)** are not real instructions. If you were to do the translation, you'd have to break it up yourself to figure out those quantities.

Pseudoinstructions

- As you look through the branch instructions, you see **beq** and **bne**, but not **bge** (branch on greater than or equal), **bgt** (branch on greater than), **ble** (branch on less than or equal), **blt** (branch on less than). There are no branch instructions for relational operators!

System Calls

- System Calls (syscall)
 - OS-like services
- Method
 - Load system call code into register \$v0
 - Load arguments into registers \$a0...\$a3
 - call system with SPIM instruction `syscall`
 - After call, return value is in register \$v0
- Frequently used system calls

Service	Code(\$v0)	Arg	Result
Print_int	1	\$a1	
Print_string	4	\$a0	
Read_int	5		\$v0

System Call Codes

Service	Code (put in \$v0)	Arguments	Result
print_int	1	\$a0=integer	
print_float	2	\$f12=float	
print_double	3	\$f12=double	
print_string	4	\$a0=addr. of string	
read_int	5		int in \$v0
read_float	6		float in \$f0
read_double	7		double in \$f0
read_string	8	\$a0=buffer, \$a1=length	
sbrk	9	\$a0=amount	addr in \$v0
exit	10		

QtSPIM

- QtSpim is software that will help you to simulate the execution of MIPS assembly programs.
- It does a context and syntax check while loading an assembly program.
- In addition, it adds in necessary overhead instructions as needed, and updates register and memory content as each instruction is executed.
- Download the source from the SourceForge.org link at:
<http://pages.cs.wisc.edu/~larus/spim.html>
- Alternatively, you can go directly to:
<http://sourceforge.net/projects/spimsimulator/files/>
- Versions for Windows, Linux, and Macs are all available

QtSPIM

- QtSPIM window is divided into different sections:
 1. The *Register tabs display the content of all registers.*
 2. Buttons across the top are used to load and run a simulation
 - Functionality is described in Figure 2.
 3. The *Text tab displays the MIPS instructions loaded into memory to be executed.*
 - From left-to-right, the memory address of an instruction, the contents of the address in hex, the actual MIPS instructions where register numbers are used, the MIPS assembly that you wrote, and any comments you made in your code are displayed.
 4. The *Data tab displays memory addresses and their values in the data and stack segments of the memory.*
 5. The *Information Console lists the actions performed by the simulator.*

Reinitialize and load file

New... print register, data, etc. content

Reinitialize simulation

Pause, stop simulation (will likely not use)

Load file

New... Save log

Clear registers

Run simulation

Step through simulation

QtSpim

FP Regs
Int Regs [10]
Data
Text

Int Regs [10]

```

PC = 0
SPC = 0
Cause = 0
BadVAddr = 0
Status = 805371664

HI = 0
LO = 0

R0 [r0] = 0
R1 [at] = 0
R2 [v0] = 0
R3 [v1] = 0
R4 [a0] = 1
R5 [a1] = 2147483204
R6 [a2] = 2147483212
R7 [a3] = 0
R8 [a0] = 0
R9 [t1] = 0
R10 [t2] = 0
R11 [t3] = 0
R12 [t4] = 0
R13 [t5] = 0
R14 [t6] = 0
R15 [t7] = 0
R16 [a0] = 0
R17 [a1] = 0
R18 [a2] = 0
R19 [a3] = 0
R20 [a4] = 0
R21 [a5] = 0
R22 [a6] = 0
R23 [a7] = 0
R24 [t8] = 0
R25 [t9] = 0
R26 [a0] = 0
R27 [k1] = 0
R28 [gp] = 258468224
R29 [fp] = 2147483200
R30 [a8] = 0
R31 [ra] = 0
          
```

Text

```

User Text Segment [00400000]..[00440000]
[00400000] 81e40000 lw $4, 0($29) ; 183: lw $a0 0($sp) # argc
[00400004] 27a50004 addiu $5, $29, 4 ; 184: addiu $a1 $sp 4 # argv
[00400008] 24660004 addiu $6, $5, 4 ; 185: addiu $a2 $a1 4 # argv
[0040000c] 00d41080 all $2, $4, 2 ; 186: all $v0 $a0 2
[00400010] 00c23021 addu $6, $6, $2 ; 187: addu $a2 $a2 $v0
[00400014] 0c100009 jal 0x00400024 [main] ; 188: jal main
[00400018] 00000000 nop ; 189: nop
[0040001c] 34c2000a ori $2, $0, 10 ; 191: li $v0 10
[00400020] 0000000c syscall ; 192: syscall # syscall 10 (exit)
[00400024] 3c011001 lui $1, 4097 ; 19: lw $s0, 0 # load loop counter into $s0
[00400028] 0c300000 lw $16, 0($1) ; 16: la $t0, X # load the address of X into $t0
[0040002c] 3c011001 lui $1, 4097 [X]
[00400030] 34280004 ori $8, $1, 4 [X] ; 17: and $s1, $s1, $zero # clear $s1 aka temp sum
[00400034] 02208824 and $17, $17, $0 ; 18: lw $t1, 0($t0) # load the next value of x
[00400038] 0c050000 lw $9, 0($0) ; 19: add $a1, $a1, $t1 # add it to the running sum
[0040003c] 02298820 addi $17, $17, $9 ; 20: addi $t0, $t0, 4 # increment to the next address
[00400040] 21080004 addi $8, $8, 4 ; 21: addi $s0, $s0, -1 # decrement the loop counter
[00400044] 2210ffff addi $16, $16, -1
[00400048] 1410ffff bne $0, $16, -15 [loop-0x00400048]
[0040004c] 3c011001 lui $1, 4097 ; 23: sw $a1, $0 # store the final total
[00400050] ac310018 sw $17, 24($1) ; 25: li $v0, 10 # syscall to exit cleanly from main only
[00400054] 34c2000a ori $2, $0, 10 ; 26: syscall # this ends execution
[00400058] 0000000c syscall
          
```

User code: (a) your comments appear, (b) register name, number appear

Content of integer registers

- Can view as binary, hex, or decimal
- Do not need to consider floating point (FP) register tab
- PC value also included here

MIPS code

Memory and registers cleared
 Loaded: /var/folders/6r/c5y9zqs54cg28fnhl4z1214m0000gn/T/qt_temp.L17044
 SPIM Version 9.0.5 of January 9, 2011
 Copyright 1990-2010, James R. Larus.
 All Rights Reserved.

QtSPIM Program Example

- A Simple Program

```
#sample example 'add two numbers'
```

```
.text                # text section
.globl main          # call main by SPIM

main:  la $t0, value  # load address 'value' into $t0
      lw $t1, 0($t0)  # load word 0(value) into $t1
      lw $t2, 4($t0)  # load word 4(value) into $t2
      add $t3, $t1, $t2 # add two numbers into $t3
      sw $t3, 8($t0)  # store word $t3 into 8($t0)

.data                # data section
value: .word 10, 20, 0 # data for addition
```

QtSPIM Example Program

```
## Program adds 10 and 11
```

```
.text          # text section  
.globl main    # call main by SPIM
```

```
main:
```

```
ori    $8,$0,0xA    # load "10" into register 8  
ori    $9,$0,0xB    # load "11" into register 9  
add    $10,$8,$9    # add registers 8 and 9, put result  
                        # in register 10
```

QtSPIM Example Program: swap2memoryWords.asm

```
## Program to swap two memory words
```

```
.data          # load data  
.word 7  
.word 3
```

```
.text  
.globl main
```

```
main:
```

```
    lui $s0, 0x1001 # load data area start address 0x10010000  
    lw  $s1, 0($s0)  
    lw  $s2, 4($s0)  
    sw  $s2, 0($s0)  
    sw  $s1, 4($s0)
```

QtSPIM Example Program: procCallsProg2.asm

```
## Procedure call to swap two array words
```

```
        .text
        .globl main
main:
        la      $a0, array
        addi    $a1, $0, 0

load para- {
meters for }
swap       {
save return {
address $ra }
in stack   {

jump and   {
link to swap }
        jal    swap

restore    {
return    {
address   {
jump to $ra {

        #      equivalent C code:
        #      swap(int v[], int k)

        #      {
        #      int temp;
        #      temp = v[k];
        #      v[k] = v[k+1];
        #      v[k+1] = temp;
        #      }

        # swap contents of elements $a1
        # and $a1 + 1 of the array that
        # starts at $a0
swap:    add    $t1, $a1, $a1
        add    $t1, $t1, $t1
        add    $t1, $a0, $t1
        lw     $t0, 0($t1)
        lw     $t2, 4($t1)
        sw     $t2, 0($t1)
        sw     $t0, 4($t1)
        jr     $ra

        .data
array:   .word 5, 4, 3, 2, 1
        }
```

QtSPIM Example Program: systemCalls.asm

```
## Enter two integers in
## console window
## Sum is displayed
.text
.globl main
```

main:

```
    la $t0, value
```

```
    li $v0, 5 ← system call code
                for read_int
    syscall
```

```
    sw $v0, 0($t0) ← result returned by call
```

```
    li $v0, 5
    syscall
    sw $v0, 4($t0)
```

```
    lw $t1, 0($t0)
    lw $t2, 4($t0)
    add $t3, $t1, $t2
    sw $t3, 8($t0)
```

```
    li $v0, 4 ← system call code
                for print_string
    la $a0, msg1 ← argument to print_string call
    syscall
```

```
    li $v0, 1 ← system call code
                for print_int
    move $a0, $t3 ← argument to print_int call
    syscall
```

```
    li $v0, 10 ← system call code
                for exit
    syscall
```

```
.data
value: .word 0, 0, 0
msg1:  .asciiz "Sum = "
```