




an ISO 9001:2015 Registered Company

# 1968-76 Chevrolet Corvette

*without* Factory Air  
Evaporator Kit  
(561174-PCZ)



18865 Goll St. San Antonio, TX 78266

Phone: 800-862-6658

Sales: [sales@vintageair.com](mailto:sales@vintageair.com)

Tech Support: [tech@vintageair.com](mailto:tech@vintageair.com)

[www.vintageair.com](http://www.vintageair.com)



www.vintageair.com

# Table of Contents

Cover.....	1
Table of Contents.....	2
Packing List/Parts Disclaimer.....	3
Information Page.....	4
Wiring Notice.....	5
Engine Compartment Disassembly.....	6
Passenger Compartment Disassembly.....	7
Astro Air Ventilation Duct Removal, Fresh Air Cap Installation.....	8
Condenser Assembly and Installation, Compressor and Brackets, Pulleys.....	9
Defrost Duct Replacement.....	10
Passenger and Driver Side A/C Duct Hose Adapter Installation.....	11
Passenger Side Dash Modification.....	12
Center Louver Assembly Installation.....	13
Firewall Modification, Evaporator Installation.....	14
Evaporator Installation (Cont.).....	15
Drain Hose Installation.....	16
Firewall Cover.....	17
A/C Hose Installation, Heater Hose & Heater Control Valve Installation, Lubricating O-rings.....	18
Hose Routing.....	19
Final Steps.....	20
Control Panel & Duct Hose Routing.....	21
Evaporator Hardline Installation.....	22
Wiring Diagram.....	23
Gen IV Wiring Connection Instruction.....	24
Operation of Controls.....	25
Troubleshooting Guide.....	26
Troubleshooting Guide (Cont.).....	27
Firewall Modification Template, Passenger Compartment Modification Template.....	28
Packing List.....	29



www.vintageair.com


## Packing List: Evaporator Kit (561174-PCZ)

No.	Qty.	Part No.	Description
1.	1	764172	Gen IV Evaporator Sub Case
2.	1	781174-PCN	Accessory Kit


**\*\* Before beginning installation, open all packages and check contents of shipment. Please report any shortages directly to Vintage Air within 15 days. After 15 days, Vintage Air will not be responsible for missing or damaged items.**

1

Gen IV Evaporator  
Sub Case  
764172



2



Accessory Kit  
781174-PCN

**NOTE: Images may not depict actual parts and quantities. Refer to packing list for actual parts and quantities.**



www.vintageair.com

## Important Notice—Please Read

*For Maximum System Performance, Vintage Air Recommends the Following:*

**NOTE:** Vintage Air systems are designed to operate with R134a refrigerant only. Use of any other refrigerant could damage your A/C system and/or vehicle, and possibly cause a fire, in addition to potentially voiding the warranties of the A/C system and its components.

### Refrigerant Capacities:

**Vintage Air System:** 1.8 lbs. (28.8 oz.) or 816 grams of **R134a**, charged by weight with a quality charging station or scale. **NOTE: Use of the proper type and amount of refrigerant is critical to system operation and performance.**

**Other Systems:** Consult manufacturer's guidelines.

### Lubricant Capacities:

**New Vintage Air-Supplied Sanden Compressor:** No additional oil needed (Compressor is shipped with proper oil charge).

**All Other Compressors:** Consult manufacturer (Some compressors are shipped dry and will need oil added).

### Safety Switches

Your Vintage Air system is equipped with a binary pressure safety switch. A binary switch disengages the compressor clutch in cases of extreme low pressure conditions (refrigerant loss) or excessively high head pressure (406 PSI) to prevent compressor damage or hose rupture. A trinary switch combines Hi/Lo pressure protection with an electric fan operation signal at 254 PSI, and should be substituted for use with electric fans. Compressor safety switches are extremely important since an A/C system relies on refrigerant to circulate lubricant.

### Service Info:

**Protect Your Investment:** Prior to assembly, it is critical that the compressor, evaporator, A/C hoses and fittings, hardlines, condenser and receiver/drier remain capped. Removing caps prior to assembly will allow moisture, insects and debris into the components, possibly leading to reduced performance and/or premature failure of your A/C system. This is especially important with the receiver/drier.

Additionally, when caps are removed for assembly, **BE CAREFUL!** Some components are shipped under pressure with dry nitrogen.

**Evacuate the System for 35-45 Minutes:** Ensure that system components (Drier, compressor, evaporator and condenser) are at a temperature of at least 85°F. On a cool day, the components can be heated with a heat gun **or** by running the engine with the heater on before evacuating. Leak check and charge to specifications.

### Bolts Passing Through Cowl and/or Firewall:

To ensure a watertight seal between the passenger compartment and the vehicle exterior, for all bolts passing through the cowl and/or firewall, Vintage Air recommends coating the threads with silicone prior to installation.

### Heater Hose (not included with this kit):

Heater hose may be purchased from Vintage Air (Part#31800-VUD) or your local parts retailer. Routing and required length will vary based on installer preference.



www.vintageair.com

## Important Wiring Notice—Please Read

*Some vehicles may have had some or all of their radio interference capacitors removed. There should be a capacitor found at each of the following locations:*

- 1. On the positive terminal of the ignition coil.**
- 2. If there is a generator, on the armature terminal of the generator.**
- 3. If there is a generator, on the battery terminal of the voltage regulator.**

Most alternators have a capacitor installed internally to eliminate what is called “whining” as the engine is revved. If whining is heard in the radio, or just to be extra cautious, a radio interference capacitor can be added to the battery terminal of the alternator.

It is also important that the battery lead is in good shape and that the ground leads are not compromised. There should be a heavy ground from the battery to the engine block, and additional grounds to the body and chassis.

If these precautions are not observed, it is possible for voltage spikes to be present on the battery leads. These spikes come from ignition systems and charging systems, and from switching some of the vehicle’s other systems on and off. Modern computer-operated equipment can be sensitive to voltage spikes on the power leads, which can cause unexpected resets, strange behavior and/or permanent damage.

Vintage Air strives to harden our products against these types of electrical noise, but there is a point where a vehicle’s electrical system can be degraded so much that nothing can help.

Radio interference capacitors should be available at most auto and truck parts suppliers. They typically are cylindrical in shape, a little over an inch long and a little over a half inch in diameter, and they have a single lead coming from one end of the cylinder with a terminal on the end of the wire, as well as a mounting clip which is screwed into a good ground on the vehicle. The specific value of the capacitance is not too significant in comparison to ignition capacitors that are matched with the coil to reduce pitting of the points.

- Care must be taken, when installing the compressor lead, not to short it to ground. The compressor lead must not be connected to a condenser fan or to any other auxiliary device. Shorting to ground or connecting to a condenser fan or any other auxiliary device may damage wiring or the compressor relay, and/or cause a malfunction.
- When installing ground leads on Gen IV systems, the blower control ground and ECU ground must be connected directly to the negative battery post.
- For proper system operation, the heater control valve must be connected to the ECU.




www.vintageair.com

## Engine Compartment Disassembly

**NOTE:** Before starting the installation, check the function of the vehicle (horn, lights, etc.) for proper operation, and study the instructions, illustrations, & diagrams.

**Perform the Following:**

1. Disconnect battery.
2. Remove hood to ease installation (retain).
3. Drain radiator.
4. Remove OEM blower assembly and cover (discard).
5. Remove OEM heater core and cover (discard).



**Figure 1**





www.vintageair.com

## Passenger Compartment Disassembly

### Perform the Following:

1. Remove the passenger side dash (retain).
2. Disconnect the center dash (retain) and pull forward to remove the OEM center dash bezel (discard).
3. Remove the OEM radio (retain).
4. Remove the OEM control panel (discard panel, retain mounting support bracket). Refer to control panel kit instruction for installation of new control panel.
5. Drop the steering column from the console.
6. Disconnect the driver side dash and pull forward.
7. Remove the defrost duct and floor heater duct (discard) (See Figure 3, below) .
8. Remove the heater (discard).






www.vintageair.com


## Astro Air Ventilation Duct Removal

1. Remove driver and passenger side astro air ventilation ducts (discard) (See Figure 4, below).
2. Remove passenger side dash support brace (discard) and cut off the mounting tab on the kick panel as shown in Figure 4, below.
3. Remove the driver and passenger side astro air ventilation duct mounting brackets as shown in Figure 4, below.
4. Install (2) S-clips on inside fresh air caps as shown in Figure 4a, below.
5. Install inside fresh air caps onto the driver and passenger side as shown in Figure 4a, below.



## Fresh Air Cover Installation

1. Apply a 1/4" bead of silicone around the back side of the fresh air cap as shown in Figure 4b, below.
2. Attach the fresh air cap to the firewall using a 1/4-20 x 1" bolt and washer (See Figure 4b, below).








www.vintageair.com

## Condenser Assembly and Installation

1. Refer to separate instructions included with the condenser kit to install the condenser (See Figure 5, below, for condenser location).
2. Binary switch installation (Refer to condenser instructions).



**Figure 5**

## Compressor and Brackets

1. Refer to separate instructions included with the bracket kit to install the compressor bracket (See Figure 6, below, for compressor mounting location).

## Pulleys

1. In most instances, the belt lengths will remain the same (See Figure 6, below).

### Pulleys available through Vintage Air:

#### Short Pump Small Block Chevy

**22503-VCA** - Water Pump Pulley (2-Groove)

**22506-VCA** - Crankshaft Pulley (2-Groove)  
(with Power Steering, a 3-Groove Crank Pulley is Required)


**22507-VCA** - Crankshaft Pulley (3-Groove)

#### Short Pump Big Block Chevy

**735002** - Water Pump Pulley (3-Groove)  
Fits 1966-70 (5/8" Shaft)

**735003** - Water Pump Pulley (3-Groove)  
Fits 1971-74 (3/4" Shaft)

**NOTE:** Belt routing may vary with different bracket sets. Always refer to instructions included with brackets.



**Figure 6**



www.vintageair.com

## Defrost Duct Replacement

1. Remove screws attaching the OEM defrost duct (retain (2) screws attaching the duct to the dash pad) (See Photo 1, below).
2. Remove remaining screws attaching the dash pad to the dash, and remove the dash pad from the vehicle (retain) (See Photo 1, below).
3. Place new defrost duct on the dash pad, in place of the OEM defrost duct (See Photo 2, below).
4. Attach using (2) screws removed in Step #1. Tighten and reinstall the dash pad using the OEM screws previously removed (See Photo 3, below).




Photo 1




Photo 2








Photo 3



www.vintageair.com

## Passenger and Driver Side A/C Duct Hose Adapter Installation

1. Remove (2) vent knobs as shown in Figure 7, below (retain).
2. Remove the passenger and driver side vent adapters (discard) as shown in Figure 8, below. **NOTE: Retain mounting hardware.**
3. Install the inner and outer A/C duct hose adapters as shown in Figure 8, below. Use OEM screws to secure the adapters to the dash.
4. Install the vent knob as shown using a 10-24 x 1 1/4" pan head screw and 3/16" flat washer. **NOTE: The passenger side installation is shown below in Figure 8. Repeat the same steps for the driver side installation.**
5. See Figure 8a, below, for a completely assembled view of the A/C duct hose adapter.








www.vintageair.com

## Passenger Side Dash Modification

1. Align the template (provided on Page 28) on the back side of the passenger side dash as shown in Figure 9, below.
2. Using a pencil or scribe, mark along the edge of the template as shown.
3. Remove the template and cut along the dotted line. Remove the plastic portion of the dash. **NOTE: Do not cut through the foam dash pad on the back side of the plastic (See Figure 9a, below).**








www.vintageair.com

## Center Louver Assembly Installation

1. Remove the OEM center dash bezel, OEM wiper switch knob and OEM wiper switch as shown in Figure 10, below.
2. Secure the wiper switch and ground wire to the wiper switch bracket using (2) 10-32 x 1/2" pan head screws and (2) nuts with star washers as shown in Photo 4, below.
3. Install the OEM wiper switch assembly onto the supplied center louver bezel using (2) #6 x 3/8" pan head screws as shown in Photo 5, below.
4. Reinstall the wiper knob onto the wiper switch.
5. Install the center louver bezel assembly into the dash using the OEM mounting screws. As shown in Photo 5, below, secure the ground wire between the louver bezel assembly and the dash.







www.vintageair.com

## Firewall Modification

1. Cut out the firewall modification template provided on Page 28. Working in the engine compartment, place the template on the firewall as shown in Figure 12, below.
2. Once the template is aligned correctly and taped into place, mark around the dotted line (See Figure 12, below).
3. Once you have marked around the dotted line, remove the template. Cut along the dotted line to remove the shaded portion of the firewall as shown in Figure 12a, below.




## Evaporator Installation

**NOTE: To ensure a watertight seal between the passenger compartment and the vehicle exterior, for all bolts passing through the firewall, Vintage Air recommends coating the threads with silicone prior to installation.**


1. On a workbench, install the evaporator rear bracket, and install the evaporator hardlines with properly lubricated O-rings (See Figure 22, Page 22, and Figure 17, Page 18).
2. Install the front mounting bracket onto the evaporator using (2) 1/4-20 x 1/2" hex bolts, and tighten as shown in Figure 13, Page 15.
3. Place the polyethylene sheet over the stepper motors (See Figure 14, Page 15).
4. Lift the evaporator unit up under the dashboard (See Figure 14, Page 15). Secure loosely to the firewall using a 1/4-20 x 1" bolt and washer (See Figure 14, Page 15). **NOTE: To ensure proper drainage, it is very important that the evaporator is level, both left-right and fore-aft. Check for level on the flat portions of the case around the drain.**
5. Using a #14 x 3/4" sheet metal screw, secure the front evaporator mounting bracket to the inner cowl by aligning the right hole in the front evaporator mounting bracket with the OEM hole in the inner cowl (See Figure 14, Page 15).
6. To secure the left side of the front mounting bracket, with the evaporator mounting bracket in place, drill a 3/16" hole in the inner cowl using the left mounting bracket hole as a guide. Secure the bracket to the inner cowl using a #14 x 3/4" sheet metal screw (See Figure 14, Page 15).
7. Verify that the evaporator unit is level and square to the dash; then tighten all mounting bolts. **NOTE: Tighten the bolt on the firewall first. Then tighten the front mounting bracket screws.**



# Evaporator Installation (Cont.)



**Figure 13**



**Figure 14**



www.vintageair.com

## Drain Hose Installation

1. In line with the drain, lightly make a mark on the firewall. Measure 1" down and drill a 5/8" hole through the firewall (See Figure 15, below).
2. Install the drain hose to the bottom of the evaporator unit, and route through the firewall (See Figure 15, below).




Figure 15






www.vintageair.com

## Firewall Cover

1. Apply a 1/4" bead of silicone around the back side of the firewall cover as shown in Figure 16, below.
2. Pass the lines through the firewall cover, and secure with (2) 7/16" panel retainers (See Figure 16, below).
3. Once the firewall cover is in place, locate the hole on the left side of the firewall cover. Drill a 3/8" hole through the firewall. Install a 7/16" panel retainer to secure the left side of the firewall cover to the firewall (See Figure 16, below).
4. Install (2) grommets in the firewall cover cap as shown in Figure 16, below.
5. Apply a 1/4" bead of silicone around the back side of the firewall cover cap as shown in Figure 16, below. Using (2) #8 x 1/2" pan head screws, install the firewall cover cap as shown.





www.vintageair.com

## A/C Hose Installation

### Standard Hose Kit:

1. Locate the #8 compressor A/C hose. Lubricate (2) #8 O-rings (See Figure 17, below) and connect the 135° female fitting to the #8 discharge port on the compressor. Then route the 45° female fitting to the #8 condenser hardline coming through the core support (See Figure 18, Page 19). Tighten each fitting connection as shown in Figure 17, below.
2. Locate the #10 compressor A/C hose. Lubricate (2) #10 O-rings (See Figure 17, below) and connect the 45° female fitting with 134a service port to the #10 suction port on the compressor. Then route the straight fitting to the #10 evaporator hardline coming through the firewall (See Figure 18, Page 19). Tighten each fitting connection as shown in Figure 17, below. **NOTE: Wrap the #10 fitting connections at the firewall with press tape (See Figure 18, Page 19).**
3. Locate the #6 A/C hose. Lubricate (2) #6 O-rings (See Figure 17, below) and connect the 90° fitting to the #6 hardline coming through the core support from the drier. Attach the straight fitting with 134a service port to the #6 evaporator hardline coming through the firewall (See Figure 18, Page 19). Tighten each fitting connection as shown in Figure 17, below. Use a #6 Adel clamp to secure the #6 A/C hose to the inner fender well as shown in Figure 18, Page 19. Secure the Adel clamp to the inner fender using a 10-32 x 1/2" machine screw and nut.


### Modified Hose Kit:

1. Refer to separate instructions included with modified hose kit.


## Heater Hose & Heater Control Valve Installation

1. Route a piece of heater hose from the water pump to the heater line coming through the firewall as shown in Figure 19, Page 20. Secure using hose clamps.
2. Route a piece of heater hose from the intake to the heater line coming through the firewall as shown in Figure 19, Page 20. **NOTE: Install heater control valve in line with the intake manifold (pressure side) heater hose, and secure using hose clamps as shown in Figure 19, Page 20. Also note proper flow direction.**



## Lubricating O-rings



**NOTE: Standard torque specifications:**  
 #6: 11 to 13 ft-lb.  
 #8: 15 to 20 ft-lb.  
 #10: 21 to 27 ft-lb.



For a proper seal of fittings: Install supplied O-rings as shown and lubricate with supplied oil.



**Figure 17**



www.vintageair.com

# Hose Routing





Figure 18




www.vintageair.com

## Final Steps

1. Using the supplied tie wraps and a #10 x 3/4" sheet metal screw, install the driver side louver adapter assembly as shown in Figure 20, below. **NOTE: Use the tie wraps to raise and secure the louver adapter assembly.**
2. Install the duct hoses as shown in Figure 21, Page 21.
3. Reinstall the center dash assembly.
4. Reinstall the control panel assembly. Refer to control panel instructions. **NOTE: Controls must be calibrated for proper operation. Refer to control panel instructions.**
5. Plug the control panel harness into the ECU module on the sub case as shown in Figure 21, Page 21.
6. Plug the wiring harnesses into the ECU module on the sub case. Wire according to wiring diagrams on Pages 23 & 24.
7. Reinstall all previously removed items.
8. Fill radiator with at least a 50/50 mixture of approved antifreeze and distilled water. It is the owner's responsibility to keep the freeze protection at the proper level for the climate in which the vehicle is operated. Failure to follow antifreeze recommendations will cause heater core to corrode prematurely and possibly burst in A/C mode and/or freezing weather, voiding your warranty.
9. Double check all fittings, brackets and belts for tightness.
10. Vintage Air recommends that all A/C systems be serviced by a licensed automotive A/C technician.
11. Evacuate the system for a minimum of 45 minutes prior to charging, and perform a leak check prior to servicing.
12. Charge the system to the capacities stated on Page 4 of this instruction manual.
13. See Operation of Controls procedures on Page 25.



**Figure 19**



**Figure 20**



www.vintageair.com

# Control Panel & Duct Hose Routing





Figure 21



www.vintageair.com

# Evaporator Hardline Installation




**Figure 22**



www.vintageair.com


# Wiring Diagram

## 232007-VUR



VIEWED FROM WIRE SIDE

## 232002-VUA




VIEWED FROM WIRE SIDE

## PROGRAM

N/A


\* DASH LAMP (IF USED)

\*\*\* WIDE OPEN THROTTLE SWITCH (OPTIONAL)




## GEN IV ECU

GEN IV WIRING DIAGRAM  
REV E, 10/6/2017



PRE-WIRED



NOTE: = CHASSIS GROUND

\* Dash lamp is used only with type 232007-VUR harness.

\*\* Warning: Always mount circuit breaker as close to the battery as possible. (NOTE: Wire between battery and circuit breaker is unprotected and should be carefully routed to avoid a short circuit).


\*\*\* Wide open throttle switch contacts close only at full throttle, which disables A/C compressor.



www.vintageair.com

# Gen IV Wiring Connection Instruction

WIRING HARNESS



**NOTE:**  
MOUNT RELAY  
IN DESIRED  
LOCATION  
UNDER DASH

**NOTE:**  
YELLOW & ORANGE  
COMING FROM  
HARNESS ARE NOT  
USED.

**GRAY WIRE IS USED FOR  
PROGRAMMING CONTROLS  
IF APPLICABLE**

**NOTE: HEATER CONTROL  
VALVE CONNECTION AND  
CHASSIS GROUND MAY BE  
LOCATED ON EITHER SIDE  
OF THE FIREWALL. ENSURE  
CONNECTOR IS LATCHED  
FIRMLY.**

**NOTE: CONNECT WHITE  
WIRES DIRECTLY TO  
(-) BATTERY TERMINAL**

**WARNING:**  
ALWAYS MOUNT CIRCUIT BREAKER  
AS CLOSE TO THE BATTERY AS POSSIBLE.  
(NOTE: WIRE BETWEEN BATTERY AND  
CIRCUIT BREAKER IS UNPROTECTED  
AND SHOULD BE CAREFULLY ROUTED  
TO AVOID A SHORT CIRCUIT).

**Ignition Switch:**  
Violet 12V ignition switch source (key on accessory) position must be switched.

**Dash Light:**  
When using a Vintage Air supplied control panel, connect the tan wire from the Gen IV evaporator wiring harness to the factory dash lights to enable panel backlighting.

**Heater Control Valve:**  
Install with servo motor facing down, as shown. Note flow direction arrow molded into valve body and install accordingly.

**Binary/Trinary & Compressor:**  
Binary: Connect as shown (typical compressor wiring). Be sure compressor body is grounded.  
Trinary Switch: Connect according to trinary switch wiring diagram.

**Circuit Breaker/Battery:**  
White **must** run to (-) battery. Red may run to (+) battery or starter. Mount circuit breaker as close to battery as possible.





www.vintageair.com

## Operation of Controls

On Gen IV systems with three lever/knob controls, the temperature control toggles between heat and A/C operations. To activate A/C, move the temperature lever/knob all the way to cold and then back it off to the desired vent temperature. For heat operation, move the temperature lever/knob all the way to hot and then adjust to the desired vent temperature. The blower will momentarily change speed, each time you toggle between operations, to indicate the change. **NOTE: For proper control panel function, refer to the control panel instructions for calibration procedure.**

### Blower Speed


This lever/knob controls blower speed, from OFF to HI.

### Mode Control

This lever/knob controls the mode positions, from DEFROST to FLOOR to DASH, with a blend in between.

### Temperature Control

This lever/knob controls the temperature, from HOT to COLD.



## A/C Operation

### Blower Speed


Adjust to desired speed.

### Mode Control

Adjust to desired mode position (DASH position recommended).

### Temperature Control

For A/C operation, adjust to coldest position to engage compressor (Adjust between HOT and COLD to reach desired temperature).



## Heat Operation

### Blower Speed


Adjust to desired speed.

### Mode Control

Adjust to desired mode position (FLOOR position recommended).

### Temperature Control

For maximum heating, adjust to hottest position (Adjust between HOT and COLD to reach desired temperature).



## Defrost/De-fog Operation

### Blower Speed


Adjust to desired speed.

### Temperature Control

Adjust to desired temperature.

### Mode Control

Adjust to DEFROST position for maximum defrost, or between FLOOR and DEFROST positions for a bi-level blend (Compressor is automatically engaged).





www.vintageair.com

# Troubleshooting Guide

Symptom	Condition	Checks	Actions	Notes
1a. Blower stays on high speed when ignition is on.	No other functions work.	Check for damaged pins or wires in control head plug.	Verify that all pins are inserted into plug. Ensure that no pins are bent or damaged in ECU.	Loss of ground on this wire renders control head inoperable.
		Check for damaged ground wire (white) in control head harness.	Verify continuity to chassis ground with white control head wire at various points.	
	All other functions work.	Check for damaged blower switch or potentiometer and associated wiring.		See blower switch check procedure.
1b. Blower stays on high speed when ignition is on or off.	System is not charged.	Unplug 3-wire BSC control connector from ECU. If blower shuts off, ECU is either improperly wired or damaged.	Be sure the small, 20 GA white ground wire is connected to the battery ground post. If it is, replace the ECU.	No other part replacements should be necessary.
		Unplug 3-wire BSC control connector from ECU. If blower stays running, BSC is either improperly wired or damaged.	Check to ensure that no BSC wiring is damaged or shorted to vehicle ground. The BSC operates the blower by ground side pulse width modulation switching. The positive wire to the blower will always be hot. If the "ground" side of the blower is shorted to chassis ground, the blower will run on HI.	
	System is charged.	Replace BSC (This will require removal of evaporator from vehicle).		
2. Compressor will not turn on (All other functions work).	System is not charged.	System must be charged for compressor to engage.	Charge system or bypass pressure switch.	<b>Danger: Never bypass safety switch with engine running. Serious injury can result.</b>
		Check for faulty A/C potentiometer or associated wiring (not applicable to 3-pot controls).	Check continuity to ground on white control head wire. Check for 5V on red control head wire.	
	System is charged.	Check for disconnected or faulty thermistor.	Check 2-pin connector at ECU housing.	To check for proper pot function, check voltage at white/blue wire. Voltage should be between 0V and 5V, and will vary with pot lever position.
				Disconnected or faulty thermistor will cause compressor to be disabled.
3. Compressor will not turn off (All other functions work).	System is not charged.	Check for faulty A/C potentiometer or associated wiring.	Repair or replace pot/control wiring.	Red wire at A/C pot should have approximately 5V with ignition on. White wire will have continuity to chassis ground. White/Blue wire should vary between 0V and 5V when lever is moved up or down.
		Check for faulty A/C relay.	Replace relay.	



www.vintageair.com

# Troubleshooting Guide (Cont.)


Symptom	Condition	Checks	Actions	Notes
4.	Works when engine is not running; shuts off when engine is started (typically early Gen IV, but possible on all versions). System will not turn on, or runs intermittently.	Noise interference from either ignition or alternator.	Install capacitors on ignition coil and alternator. Ensure good ground at all points. Relocate coil and associated wiring away from ECU and ECU wiring. Check for burned or loose plug wires.	Ignition noise (radiated or conducted) will cause the system to shut down due to high voltage spikes. If this is suspected, check with a quality oscilloscope. Spikes greater than 16V will shut down the ECU. Install a radio capacitor at the positive post of the ignition coil (see radio capacitor installation bulletin). A faulty alternator or worn out battery can also result in this condition.
		Verify connections on power lead, ignition lead, and both white ground wires.	Check for positive power at heater valve green wire and blower red wire. Check for ground on control head white wire.	
		Verify battery voltage is greater than 10 volts and less than 16.	Verify proper meter function by checking the condition of a known good battery.	
		Check for damaged mode switch or potentiometer and associated wiring.	Typically caused by evaporator housing installed in a bind in the vehicle. Be sure all mounting locations line up and don't have to be forced into position.	
5.	Loss of mode door function.	Partial function of mode doors.	Check for obstructed or binding mode doors.	System shuts off blower at 10V. Poor connections or weak battery can cause shutdown at up to 11V.
		Check for damaged stepper motor or wiring.	Charge battery.	
6.	Blower turns on and off rapidly.	Battery voltage is at least 12V.	Ensure all system grounds and power connections are clean and tight.	System shuts off blower at 10V. Poor connections or weak battery can cause shutdown at up to 11V.
		Battery voltage is less than 12V.	Check for faulty battery or alternator.	
7.	Erratic functions of blower, mode, temp, etc.	Check for damaged switch or pot and associated wiring.	Repair or replace.	
8.	When ignition is turned on, blower momentarily comes on, then shuts off. This occurs with the blower switch in the OFF position.	This is an indicator that the system has been reset. Be sure the red power wire is on the battery post, and not on a switched source. Also, if the system is pulled below 7V for even a split second, the system will reset.	Run red power wire directly to battery.	






www.vintageair.com

# Firewall Modification Template



# Passenger Compartment Modification Template










# Packing List: Evaporator Kit (561174-PCZ)

No.	Qty.	Part No.	Description
1.	1	764172	Gen IV Evaporator Sub Case
2.	1	781174-PCN	Accessory Kit


Checked By: \_\_\_\_\_  
 Packed By: \_\_\_\_\_  
 Date: \_\_\_\_\_

1

Gen IV Evaporator  
Sub Case  
764172



2



Accessory Kit  
781174-PCN

**NOTE: Images may not depict actual parts and quantities.  
 Refer to packing list for actual parts and quantities.**