


Model AX411  
Dual Input Conductivity Analyzer



## The Company

We are an established world force in the design and manufacture of instrumentation for industrial process control, flow measurement, gas and liquid analysis and environmental applications.

As a part of ABB, a world leader in process automation technology, we offer customers application expertise, service and support worldwide.

We are committed to teamwork, high quality manufacturing, advanced technology and unrivalled service and support.

The quality, accuracy and performance of the Company's products result from over 100 years experience, combined with a continuous program of innovative design and development to incorporate the latest technology.

The NAMAS Calibration Laboratory No. 0255 is just one of the ten flow calibration plants operated by the Company, and is indicative of our dedication to quality and accuracy.

BS EN ISO 9001:1994



Cert. No. Q05907

EN 29001 (ISO 9001)



Lenno, Italy – Cert. No. 9/90A



Stonehouse, U.K.

## Use of Instructions



### Warning.

An instruction that draws attention to the risk of injury or death.



### Caution.

An instruction that draws attention to the risk of damage to the product, process or surroundings.



### Note.

Clarification of an instruction or additional information.



### Information.

Further reference for more detailed information or technical details.

Although **Warning** hazards are related to personal injury, and **Caution** hazards are associated with equipment or property damage, it must be understood that operation of damaged equipment could, under certain operational conditions, result in degraded process system performance leading to personal injury or death. Therefore, comply fully with all **Warning** and **Caution** notices.

Information in this manual is intended only to assist our customers in the efficient operation of our equipment. Use of this manual for any other purpose is specifically prohibited and its contents are not to be reproduced in full or part without prior approval of the Marketing Communications Department.

### Health and Safety

To ensure that our products are safe and without risk to health, the following points must be noted:

1. The relevant sections of these instructions must be read carefully before proceeding.
2. Warning labels on containers and packages must be observed.
3. Installation, operation, maintenance and servicing must only be carried out by suitably trained personnel and in accordance with the information given.
4. Normal safety precautions must be taken to avoid the possibility of an accident occurring when operating in conditions of high pressure and/or temperature.
5. Chemicals must be stored away from heat, protected from temperature extremes and powders kept dry. Normal safe handling procedures must be used.
6. When disposing of chemicals ensure that no two chemicals are mixed.

Safety advice concerning the use of the equipment described in this manual or any relevant hazard data sheets (where applicable) may be obtained from the Company address on the back cover, together with servicing and spares information.

# CONTENTS

Section	Page	Section	Page
<b>1 INTRODUCTION .....</b>	<b>2</b>	<b>6 INSTALLATION .....</b>	<b>29</b>
<b>2 OPERATION .....</b>	<b>3</b>	6.1 Siting Requirements .....	29
2.1 Powering Up the Analyzer .....	3	6.2 Mounting .....	30
2.2 Displays and Controls .....	3	6.2.1 Wall-/Pipe-mount Analyzers .....	30
2.2.1 Key Functions .....	3	6.2.2 Panel-mount Analyzers .....	31
2.3 Operating Page .....	6	6.3 Connections, General .....	32
2.3.1 Single Input Conductivity .....	6	6.3.1 Relay Contact Protection and Interference Suppression .....	33
2.3.2 Dual Input Conductivity .....	6	6.3.2 Cable Entry Knockouts, Wall-/Pipe-mount Analyzer .....	34
<b>3 OPERATOR VIEWS .....</b>	<b>7</b>	6.4 Wall-/Pipe-mount Analyzer Connections .....	35
3.1 View Set Points .....	7	6.4.1 Access to Terminals .....	35
3.2 View Outputs .....	8	6.4.2 Connections .....	36
3.3 View Hardware .....	8	6.5 Panel-mount Analyzer Connections .....	37
3.4 View Software .....	9	6.5.1 Access to Terminals .....	37
3.5 View Clock .....	9	6.5.2 Connections .....	38
<b>4 SETUP .....</b>	<b>10</b>	<b>7 CALIBRATION .....</b>	<b>39</b>
4.1 Sensor Calibration .....	10	7.1 Equipment Required .....	39
<b>5 PROGRAMMING .....</b>	<b>12</b>	7.2 Preparation .....	39
5.1 Security Code .....	12	7.3 Factory Settings .....	40
5.2 Configure Display .....	13	<b>8 SIMPLE FAULT FINDING .....</b>	<b>45</b>
5.3 Configure Conductivity Sensors .....	14	8.1 Error Messages .....	45
5.4 Configure Alarms .....	19	8.2 No Response to Conductivity Changes .....	45
5.5 Configure Outputs .....	22	8.3 Checking the Temperature Input .....	45
5.6 Output Functions .....	24	<b>APPENDIX A .....</b>	<b>46</b>
5.6.1 Bi-Linear Output .....	24	A1 Automatic Temperature Compensation .....	46
5.6.2 Logarithmic Output (2-decade) .....	25	A1.1 Calculation of Temperature Coefficient .....	47
5.6.3 Logarithmic Output (3-decade) .....	25	A2 Relationship Between Conductivity and Total Dissolved Solids (TDS) Measurement .....	47
5.7 Configure Clock .....	26	A3 Inferred pH Derived from Differential Conductivity .....	48
5.8 Configure Security .....	27	<b>SPECIFICATION .....</b>	<b>49</b>
5.9 Test Outputs .....	28		

---

# 1 INTRODUCTION

---

This conductivity analyzer has been designed for continuous monitoring and control of conductivity. It is available in wall-/ pipe-mount or panel-mount versions and can be used with either one or two sensors, each with a temperature input channel. When used with two sensors, readings can be compared to produce a range of extrapolated values.

When making temperature compensated measurements, the sample temperature is sensed by a resistance thermometer (Pt100 or Pt1000) mounted in the measuring cell.

Analyzer operation and programming are performed using five tactile membrane keys on the front panel. Programmed functions are protected from unauthorized alteration by a five-digit security code.

## 2 OPERATION

### 2.1 Powering Up the Analyzer




**Caution.** Ensure all connections are made correctly, especially to the earth stud – see Section 6.3.


- 1) Ensure the input sensors are connected correctly.
- 2) Switch on the power supply to the analyzer. A start-up screen is displayed while internal checks are performed, then the conductivity measurement readings screen (Operating Page) is displayed as conductivity measuring operation starts.

### 2.2 Displays and Controls


The display comprises two rows of 4½ digit, 7-segment digital displays, which show the actual values of the measured parameters and alarm set points, and a 6-character dot matrix display showing the associated units. The lower display line is a 16-character dot matrix display showing the programming information.



### 2.2.1 Key Functions



**Fig. 2.2 Membrane Key Functions**








Fig. 2.3B Overall Programming Chart

### 2.3 Operating Page

#### 2.3.1 Single Input Conductivity




#### 2.3.2 Dual Input Conductivity





# 3 OPERATOR VIEWS

## 3.1 View Set Points



### View Set Points

This page shows alarm set points. The value of each of the set points is shown, together with the name of the parameter it's assigned to.

Set point values and relay/LED actions are programmable – see Section 5.4.

#### Sensor A (Conductivity), Alarm 1 Set Point

#### Sensor A (Temperature), Alarm 2 Set Point

#### Sensor B (Conductivity), Alarm 3 Set Point – Dual Input Conductivity only

#### Sensor B (Temperature), Alarm 4 Set Point – Dual Input Conductivity only

**\*** **Note.** Alarm 4 is available only if the optional analog output board is fitted.

#### Alarm 5 Set Point

**\*** **Note.** Alarm 5 is available only if the optional analog output board is fitted.



**VIEW OUTPUTS** Return to main menu.

**SENSOR CAL.** If sensor calibration enabled – see Section 4.1.

**Security Code** If **Alter Sec. Code** is not set to zero – see Section 5.1.

**CONFIG. DISPLAY** If **Alter Sec. Code** is set to zero – see Section 5.2.

3.2 View Outputs



**Theoretical Analog Output**

There are up to four analog outputs, each showing information for one sensor:

**\*** **Note.** Analog outputs 3 and 4 are available only if the optional analog output board is fitted.

Current output.

Current output as a percentage of full scale for the output range selected.

VIEW HARDWARE See Section 3.3.



SENSOR CAL. If sensor calibration enabled – see Section 4.1.

Security Code If **Alter Sec. Code** is not set to zero – see Section 5.1.

CONFIG. DISPLAY If **Alter Sec. Code** is set to zero – see Section 5.2.


Analog Output 2 **Analog Output 2** – repeat for outputs 2 to 4.

3.3 View Hardware




**Sensor A Module**

Shows the type of sensor connected to the analyzer's Sensor A input.




**Sensor B Module – Dual Input Conductivity only**

Shows the type of sensor connected to the analyzer's Sensor B input.



**Option Board**

Shows the type of option board fitted to the analyzer (if applicable).




VIEW SOFTWARE See Section 3.4.

SENSOR CAL. If sensor calibration enabled – see Section 4.1.

Security Code If **Alter Sec. Code** is not set to zero – see Section 5.1.


CONFIG. DISPLAY If **Alter Sec. Code** is set to zero – see Section 5.2.

### 3.4 View Software




### 3.5 View Clock

**Note.** The **VIEW CLOCK** function is available only if the optional analog output board is fitted.




## 4 SETUP

### 4.1 Sensor Calibration



...4.1 Sensor Calibration


Edit



**Sensor Slope**

The upper display shows the measured conductivity. The lower display shows the process sensor slope.


Adjust the slope within the valid range 0.2000 to 5.000 until the conductivity reading is correct.



**Sensor Offset**

The upper display shows the measured conductivity. The lower display shows the process sensor offset.


Adjust the offset until the conductivity reading is correct.



**Temperature Slope**

The upper display shows the measured temperature. The lower display shows the temperature sensor slope.

Adjust the slope within the valid range 0.2000 to 1.500 until the temperature reading is correct.



**Temperature Offset**

The upper display shows the measured temperature. The lower display shows the temperature sensor offset.

Adjust the offset within the valid range -40.0 to 40.0°C (-40° to 104°F) until the temperature reading is correct.

Sensor Cal. A

Sensor Cal. B

Dual input conductivity only – Sensor B calibration is identical to Sensor A calibration.

SENSOR CAL.

Single input conductivity only – return to main menu.


SECURITY CODE

If **Alter Sec. Code** is not set to zero – see Section 5.1.

CONFIG. DISPLAY

If **Alter Sec. Code** is set to zero – see Section 5.2.

Reset



**Reset Calibration**

Select **Yes** and press **[Enter]** to reset the calibration data.

Select **No** and press **[Enter]** to abort.

Sensor Cal. A

Sensor Cal. B

Dual input conductivity only – Sensor B calibration is identical to Sensor A calibration.

SENSOR CAL.

Single input conductivity only – return to main menu.

SECURITY CODE

If **Alter Sec. Code** is not set to zero – see Section 5.1.

CONFIG. DISPLAY

If **Alter Sec. Code** is set to zero – see Section 5.2.

---

## 5 PROGRAMMING

---

### 5.1 Security Code



---

Enter the required code number, between 00000 and 19999, to gain access to the secure parameters. If an incorrect value is entered, access to subsequent programming pages is prevented and the display reverts to the **Operating Page** – see Section 2.3.




**Note.** This item is displayed only if **Alter Sec. Code** is not set to zero – see Section 5.8.

---


CONFIG. DISPLAY

See Section 5.2.

5.2 Configure Display




### 5.3 Configure Conductivity Sensors





...5.3 Configure Conductivity Sensors



**Conductivity Units**

Units can be programmed to suit the range and application. Select the required units, ensuring the range does not exceed the display limit of 10,000  $\mu\text{S cm}^{-1}$ :

- M\_0hms – Megohms-cm
  - TDS – Total Dissolved Solids (see Table 5.1)
  - mS/m – MilliSiemens  $\text{m}^{-1}$  ( $0.1\mu\text{S cm}^{-1}$ )
  - mS/cm – MilliSiemens  $\text{cm}^{-1}$  ( $1000\mu\text{S cm}^{-1}$ )
  - uS/m – MicroSiemens  $\text{m}^{-1}$  ( $100\mu\text{S cm}^{-1}$ )
  - uS/cm – MicroSiemens  $\text{cm}^{-1}$
- (see Table 5.2)

Conductivity Cell Constant (K)	Maximum Conductivity Range ( $\mu\text{S cm}^{-1}$ )	Maximum Effective TDS Range (ppm, mg/kg and mg/l)				
		TDS Factor (examples)				
		0.40	0.50	0.60	0.70	0.80
0.1	0 to 1,000	0 to 400	0 to 500	0 to 600	0 to 700	0 to 800
1.0	0 to 10,000	0 to 4,000	0 to 5,000	0 to 6,000	0 to 7,000	0 to 8,000


Table 5.1 TDS Range Limits for Different Cell Constants (K)

Conductivity Cell Constant (K)	Minimum Conductivity Range	Maximum Conductivity Range
0.01	0 to $0.1\mu\text{S cm}^{-1}$ 0 to $10.00\mu\text{S m}^{-1}$	0 to $100.0\mu\text{S cm}^{-1}$ 0 to $10,000\mu\text{S m}^{-1}$
0.05	0 to $0.5\mu\text{S cm}^{-1}$ 0 to $50.00\mu\text{S m}^{-1}$	0 to $500.0\mu\text{S cm}^{-1}$ 0 to $10,000\mu\text{S m}^{-1}$
0.10	0 to $1\mu\text{S cm}^{-1}$ 0 to $100\mu\text{S m}^{-1}$ 0 to $0.1\text{mS m}^{-1}$	0 to $1,000\mu\text{S cm}^{-1}$ 0 to $10,000\mu\text{S m}^{-1}$ 0 to $100.0\text{mS m}^{-1}$
1.00	0 to $10\mu\text{S cm}^{-1}$ 0 to $1,000\mu\text{S m}^{-1}$ 0 to $0.01\text{mS cm}^{-1}$ 0 to $1\text{mS m}^{-1}$	0 to $10,000\mu\text{S cm}^{-1}$ 0 to $10,000\mu\text{S m}^{-1}$ 0 to $10\text{mS cm}^{-1}$ 0 to $1,000\text{mS m}^{-1}$

Table 5.2 Conductivity Range Limits for Different Cell Constants (K)


**Cell Constant**

Enter the cell constant for the type of measuring cell used – see the relevant cell manual.



A: Temp.Comp Continued on next page...

...5.3 Configure Conductivity Sensors



**Temperature Compensation**

Select the type of temperature compensation required:

- None – Select when raw conductivity measurement without temperature compensation is required.  
**Examples**
  - Water for injection (WFI) for US Pharmacopoeia (USP) applications.
  - Purified water for USP applications.
- Linear – Select for non-standard applications monitoring and when manual addition of temperature coefficient of unknown purity is required.
- \* UPW – Select when temperature effect of pure water only is required or when manual addition of temperature coefficient of unknown impurity to pure water temperature effect is required – see Note below.
- \* HCl – Select when temperature effect of pure water with trace acids is required  
**Examples**
  - Cation exchanger in-bed and outlet applications.
  - Degassed cation conductivity applications.
- \* NaOH – Select when temperature effect of pure water with trace caustic is required  
**Example**
  - Inferred pH in caustic-dosed waters applications.
- \* NaCl – Select when temperature effect of pure water with trace salts is required  
**Examples**
  - General monitoring applications.
  - Mixed-bed exchanger applications.
  - Final polisher effluent applications.
  - Cation exchanger inlet applications.
  - Anion exchanger in-bed and outlet applications.
  - Reverse osmosis applications.
- \* NH3 – Select when temperature effect of pure water with trace ammonia is required  
**Examples**
  - Ammonia-treated make-up and boiler feed water applications.
  - Condenser sampling applications.
  - Hot well sampling applications.
  - Before-cation column applications.
  - Inferred pH in ammonia-dosed waters applications.


\* Applicable only on conductivities up to 10µS cm<sup>-1</sup>

 **Notes.**

- 1) If UPW is selected, the temperature coefficient ( $\alpha \times 100$ ) of the solution must be calculated if unknown – see Appendix A1.1.
- 2) Source data is based on IEC International Standard 65D/85/FD15

 A: Temp.Sensor Continued on next page...

...5.3 Configure Conductivity Sensors



**Temperature Sensor**

Select the type of temperature sensor used, Pt100 or Pt1000.

**Temperature Coefficient**

**\*** **Note.** Displayed only if **Temp.Comp.** is set to **Linear** or **UPW** – see previous page.

Enter the temperature coefficient ( $\alpha \times 100$ ) of the solution (0.01 to 5.0%/°C). If unknown, the temperature coefficient ( $\alpha$ ) of the solution must be calculated – see Appendix A1.1.

If the value has not yet been calculated, set it to 2%/°C provisionally.

**TDS Factor**

**\*** **Note.** Displayed only if **Cond.Units** is set to **TDS** – see page 15.

The TDS factor must be programmed to suit the particular application – see Appendix A2.

Enter the required TDS factor between 0.4 and 0.8.

For salinity applications, set the TDS factor to 0.5.

**TDS Units**

**\*** **Note.** Displayed only if **Cond.Units** is set to **TDS** – see page 15.

Select the TDS units (ppm, mg/l or mg/kg).

**Enable Calibration**

If Sensor Calibration is required, select **Yes**.



If **No** is selected the sensor calibration menus for Sensor A are disabled.

**Config. Sensor B** Dual input conductivity only – Sensor B configuration is identical to Sensor A configuration.


**CONFIG. SENSORS** Single input conductivity only – return to main menu.

**CONFIG. ALARMS** See Section 5.4.

...5.3 Configure Conductivity Sensors




## 5.4 Configure Alarms








## ...5 PROGRAMMING


### ...5.4 Configure Alarms



...5.4 Configure Alarms




5.5 Configure Outputs





...5.5 Configure Outputs



## ...5 PROGRAMMING

### ...5.5 Configure Outputs

Analog Output Assignment	Analog Output Span	Analog Output Zero
Conductivity	Programmable between 0.1% and 100% of conductivity span (Table 5.1)	Set automatically according to selected Analog Output Scale: <b>Linear</b> = Subject to a minimum range as per Table 5.2 <b>Bi-lin</b> = Subject to a minimum range as per Table 5.2 <b>Log. 2</b> = 1.0% of Analog Output Span <b>Log. 3</b> = 0.1% of Analog Output Span
If Conductivity Units = MΩ-cm		20.00 (maximum), 2.00 (minimum) (subject to minimum range of 1.00 MΩ-cm)
Temperature (°C)		150 (maximum), -10 (minimum) (subject to minimum range of 20°C)
Temperature (°F)		302 (maximum), 14 (minimum) (subject to minimum range of 36°F)

Table 5.3 Analog Outputs

## 5.6 Output Functions

### 5.6.1 Bi-Linear Output – Fig. 5.6






Fig. 5.6 Bi-Linear Output

## ...5.6 Output Functions

## 5.6.2 Logarithmic Output (2-decade) – Fig. 5.7




## 5.6.3 Logarithmic Output (3-decade) – Fig. 5.8




### 5.7 Configure Clock



**Note.** Available only if the optional analog output board is fitted.



## 5.8 Configure Security



5.9 Test Outputs




**Test Outputs**

Displays the output test details for the four channels. Test Output 1 only is shown; the remaining outputs are identical.

**Note.** Outputs 3 and 4 are available only if the optional analog output board is fitted.

Maintenance See below.




The theoretical output current value.


Output current as a percentage of the full range current.

FACTORY SETTINGS See Section 7.3.

Test Output 2 Test remaining outputs.



**Maintenance**



**Hold Outputs**

Enables the relay action and analog outputs to be maintained.

- On - Changes in relay action and analog outputs are inhibited.
- Off - Changes in relay action and analog outputs are not inhibited.
- Auto. - Hold is released automatically after six hours.

**Note.** The LEDs flash while the analyzer is in Hold mode.

TEST/MAINTENANCE Return to main menu.

CONFIG. SENSORS See Section 7.3.

## 6 INSTALLATION

### 6.1 Siting Requirements




#### Caution.

- Mount in a location free from excessive vibration.
- Mount away from harmful vapours and/or dripping fluids.





**Information.** It is preferable to mount the analyzer at eye level, allowing an unrestricted view of the front panel displays and controls.



6.2 Mounting



6.2.1 Wall-/Pipe-mount Analyzers – Figs. 6.2 and 6.3





## ...6.2 Mounting

## 6.2.2 Panel-mount Analyzers – Figs. 6.4 and 6.5



### 6.3 Connections, General



**Warning.** The power supply earth (ground) **must** be connected to ensure safety to personnel, reduction of the effects of RFI interference and correct operation of the power supply interference filter.



**Caution.** The metal braid in the conductivity cell connecting cable **must not** be earthed, or allowed to touch earthed components, and must be cut back to the insulation at the conductivity cell end.



#### Information.

- **Earthing (grounding)** – stud terminal(s) is fitted to the analyzer case for bus-bar earth (ground) connection – see Fig. 6.8 (wall-/pipe-mount analyzers) or Fig. 6.10 (panel-mount analyzers).
- **Cable lengths** – the integral cable may be extended using a suitable junction box, but the total cable length must not exceed 50m (137.5 ft) for cells with a constant of <0.1 or 100m (275 ft) for cells with a constant of 0.1.
- **Cable routing** – always route signal output/conductivity cell cable leads and mains-carrying/relay cables separately, ideally in earthed metal conduit. Use twisted pair output leads or screened cable with the screen connected to the case earth stud.  
Ensure that the cables enter the analyzer through the glands nearest the appropriate screw terminals and are short and direct. Do not tuck excess cable into the terminal compartment.
- **Cable glands & conduit fittings** – ensure that the NEMA4X/IP66 rating is not compromised when using cable glands, conduit fittings and blanking plugs/bungs (M20 holes). The M20 glands accept cable of between 5 and 9mm (0.2 and 0.35 in.) diameter.
- **Relays** –the relay contacts are voltage-free and must be appropriately connected in series with the power supply and the alarm/control device which they are to actuate. Ensure that the contact rating is not exceeded. Refer also to Section 6.3.1 for relay contact protection details when the relays are to be used for switching loads.
- **Analog output** – Do not exceed the maximum load specification for the selected analog output range.  
Since the analog output is isolated, the –ve terminal **must** be connected to earth (ground) if connecting to the isolated input of another device.

### ...6.3 Connections, General

#### 6.3.1 Relay Contact Protection and Interference Suppression – Fig. 6.6


If the relays are used to switch loads on and off, the relay contacts can become eroded due to arcing. Arcing also generates radio frequency interference (RFI) which can result in analyzer malfunctions and incorrect readings. To minimize the effects of RFI, arc suppression components are required; resistor/capacitor networks for a.c. applications or diodes for d.c. applications. These components can be connected either across the load or directly across the relay contacts. The RFI components must be fitted to the relay terminal block along with the supply and load wires – see Fig 6.6.

For **AC applications** the value of the resistor/capacitor network depends on the load current and inductance that is switched. Initially, fit a 100R/0.022 $\mu$ F RC suppressor unit (part no. B9303) as shown in Fig. 6.6A. If the analyzer malfunctions (locks up, display goes blank, resets etc.) the value of the RC network is too low for suppression and an alternative value must be used. If the correct value cannot be obtained, contact the manufacturer of the switched device for details on the RC unit required.

For **DC applications** fit a diode as shown in Fig. 6.6B. For general applications use an IN5406 type (600V peak inverse voltage at 3A – part no. B7363).




**Note.** For reliable switching the minimum voltage must be greater than 12V and the minimum current greater than 100mA.



...6.3 Connections, General

6.3.2 Cable Entry Knockouts, Wall-/Pipe-mount Analyzer – Fig. 6.7

The analyzer is supplied with 7 cable glands, one fitted and six to be fitted, as required, by the user – see Fig. 6.7.






**Warning.** Before making any connections, ensure that the power supply, any high voltage-operated control circuits and high common mode voltages are switched off.

## 6.4 Wall-/Pipe-mount Analyzer Connections

### 6.4.1 Access to Terminals – Fig. 6.8



...6.4 Wall-/Pipe-mount Analyzer Connections

6.4.2 Connections – Fig. 6.9





Fig. 6.9 Connections, Wall-/Pipe-mount Analyzer



**Warning.** Before making any connections, ensure that the power supply, any high voltage-operated control circuits and high common mode voltages are switched off.

## 6.5 Panel-mount Analyzer Connections

### 6.5.1 Access to Terminals – Fig. 6.10



**Fig. 6.10 Access to Terminals, Panel-mount Analyzers**

...6.6 INSTALLATION

...6.5 Panel-mount Analyzer Connections

6.5.2 Connections – Fig. 6.11




Fig. 6.11 Connections, Panel-mount Analyzers



## 7 CALIBRATION

### ★ Notes.

- The analyzer is calibrated by the Company prior to dispatch and routine recalibration is not necessary. High stability components are used in the analyzer's input circuitry and, once calibrated, the Analog to Digital converter chip self-compensates for zero and span drift. It is therefore unlikely that the calibration will change over time. It is not advisable to attempt recalibration unless the input board has been replaced or the calibration tampered with.
- Prior to attempting recalibration, test the analyzer's accuracy using suitably calibrated test equipment – see Sections 7.2 and 7.3.

### 7.1 Equipment Required


- a) Decade resistance box (conductivity cell input simulator): 0 to 10k (in increments of 0.1), accuracy  $\pm 0.1\%$ .
- b) Decade resistance box (Pt100/Pt1000 temperature input simulator): 0 to 1k (in increments of 0.01), accuracy  $\pm 0.1\%$ .
- c) Digital milliammeter (current output measurement): 0 to 20mA.




**Note.** Resistance boxes have an inherent residual resistance which may range from a few m up to 1 . This value must be taken into account when simulating input levels, as should the overall tolerance of the resistors within the boxes.

### 7.2 Preparation


- a) Switch off the supply and disconnect the conductivity cell(s), temperature compensator(s) and current output(s) from the analyzer's terminal blocks.
- b) Sensor A:
  - 1) Link terminals B9 and B10.
  - 2) Link terminal B12 to the Case Earth Stud – see Fig. 6.8.
  - 3) Connect the 0 to 10k decade resistance box to terminals B13 and B14 to simulate the conductivity cell. Connect the decade box earth to the Case Earth Stud.
  - 4) Connect the 0 to 1k decade resistance box to terminals B11 and B9 to simulate the Pt100/Pt1000.
- Sensor B (dual input conductivity only):
  - 1) Link terminals B1 and B2.
  - 2) Link terminal B4 to the Case Earth Stud – see Fig. 6.8.
  - 3) Connect the 0 to 10k decade resistance box to terminals B5 and B6 to simulate the conductivity cell. Connect the decade box earth to the Case Earth Stud.
  - 4) Connect the 0 to 1k decade resistance box to terminals B3 and B1 to simulate the Pt100/Pt1000.
- c) Connect the milliammeter to the analog output terminals.
- d) Switch on the supply and allow ten minutes for the circuits to stabilize.
- d) Select the **FACTORY SETTINGS** page and carry out Section 7.3.



7.3 Factory Settings



...7.3 Factory Settings



**Factory Settings Access Code**

Enter the required code number, between 00000 and 19999, to gain access to the factory settings. If an incorrect value is entered, access to subsequent parameters is prevented and the display reverts to the top of the **Factory Settings Page**.

**Calibrate Sensor A**

**Note.** The values in the display lines for sensor calibration are shown only as examples – the actual values obtained will differ.

**Cal. Sensor B** Dual input conductivity only – Sensor B calibration is identical to Sensor A calibration.

**Cal. Output 1** Single input conductivity only – see page 43.

**Dual Cond.** Return to **Operating Page**.

**Resistance Zero (Open Circuit)**

Open circuit the cell simulator.

The display advances automatically to the next step once a stable and valid value is recorded.

**Note.** The upper 6-segment display shows the measured input voltage. Once the signal is within range the lower 6-segment display shows the same value and **Calib** is displayed to indicate that calibration is in progress.

**Resistance Span (2k )**

Set the cell simulator to 2k

The display advances automatically to the next step once a stable and valid value is recorded.

**Resistance Zero (Open Circuit)**

Open circuit the cell simulator.

The display advances automatically to the next step once a stable and valid value is recorded.


0.230 Volts  
0.230 Calib  
A:Res.Zero (0/C)

2.015 Volts  
2.015 Calib  
A:Res.Span (2K0)

0.230 Volts  
0.230 Calib  
A:Res.Zero (0/C)

**A: Res.Vref** Continued on next page...

...7.3 Factory Settings



**Resistance Span (20 )**

Set the cell simulator to 20

The display advances automatically to the next step once a stable and valid value is recorded.

**Resistance Reference Voltage**

The analyzer calibrates the internal reference voltage automatically.

The display advances automatically to the next step once a stable and valid value is recorded.

**Temperature Zero (100R)**

Set the temperature simulator to 100

The display advances automatically to the next step once a stable and valid value is recorded.

**Temperature Span (150R)**

Set the temperature simulator to 150

The display advances automatically to the next step once a stable and valid value is recorded.

**Temperature Zero (1k )**

Set the temperature simulator to 1000


The display advances automatically to the next step once a stable and valid value is recorded.

**Temperature Span (1k5)**


Set the temperature simulator to 1500

The display returns automatically to **Cal. Sensor A** once a stable and valid value is recorded.

## ...7.3 Factory Settings



...7.3 Factory Settings




**Load/Save Configuration**

Select whether a configuration is to be loaded or saved.

\* **Note.** If **No** is selected, pressing the **[F1]** key has no effect.

Alter Fact. Code See below.

Dual Cond. Return to **Operating Page**.



**Load Factory Configuration**

\* **Note.** Applicable only if **Load/Save Config** is set to **Yes**.

Load Factory Config. – resets all the parameters in the **Configuration Pages** to the Company Standard.



Save User Config. – saves the current configuration into memory.

Load User Config. – reads the saved user configuration into memory.

\* **Notes.**

1) **Load User Config.** is displayed only if a User Configuration has been saved previously.

2) **Press ▲ to Set** and **Press ▼ to Abort** are displayed alternately on the lower display line.



**Alter Factory Code**

Set the factory settings access code to a value between 00000 and 19999.

FACTORY SETTINGS Return to main menu.

Dual Cond. Return to **Operating Page**.

## 8 SIMPLE FAULT FINDING

### 8.1 Error Messages

If erroneous or unexpected results are obtained the fault may be indicated by an error message – see Table 8.1. However, some faults may cause problems with analyzer calibration or give discrepancies when compared with independent laboratory measurements.

Error Message	Possible Cause
<b>A: FAULTY Pt100</b> <b>A: FAULTY Pt1000</b>	Temperature compensator/associated connections for Sensor A are either open circuit or short circuit.
<b>B: FAULTY Pt100</b> <b>B: FAULTY Pt1000</b>	Temperature compensator/associated connections for Sensor B are either open circuit or short circuit.
<b>BEFORE CAT. HIGH</b>	The conductivity value before the cation exchange unit has exceeded 10µS/cm.
<b>AFTER CAT. HIGH</b>	The conductivity value after the cation exchange unit has exceeded the programmed limit.

Table 8.1 Error Messages

### 8.2 No Response to Conductivity Changes

The majority of problems are associated with the conductivity cell which must be cleaned as an initial check. It is also important that all program parameters have been set correctly and have not been altered inadvertently – see Section 5.

If the above checks do not resolve the fault:

- a) Check the analyzer responds to a resistance input. Disconnect the conductivity cell cable and connect a suitable resistance box directly to the analyzer input – see Section 6.4. Select the **CONFIG. SENSORS** page and set **Temp.Comp.** to **None** – see Section 5.3. Check the analyzer displays the correct values as set on the resistance box – see Table 8.2 or use the expression:

$$R = \frac{K \times 10^6}{G}$$

Where: R = resistance  
K = cell constant  
G = conductivity

Failure to respond to the input indicates a fault with the analyzer which must be returned to the Company for repair. A response, but with incorrect readings, usually indicates an electrical calibration problem. Re-calibrate the analyzer as detailed in Section 7.3.

- b) If the response in a) is correct, reconnect the conductivity cell cable and connect the resistance box to the cell end. Check the analyzer displays the correct values as set on the resistance box in this configuration.

If the analyzer passes check a) but fails check b), check the cable connections and condition. If the response for both checks is correct, replace the conductivity cell.

Conductivity µS cm <sup>-1</sup> (G)	Cell Constant (K)		
	0.05	0.1	1.0
	Resistance (R)		
0.055	909.091kΩ	–	–
0.1	500kΩ	1MΩ	–
0.5	100kΩ	200kΩ	–
1	50kΩ	100kΩ	1MΩ
5	10kΩ	20kΩ	200kΩ
10	5kΩ	10kΩ	100kΩ
50	1kΩ	2kΩ	20kΩ
100	500Ω	1kΩ	10kΩ
500	100Ω	200Ω	2kΩ
1000	–	100Ω	1kΩ
5000	–	–	200Ω
10000	–	–	100Ω

Table 8.2 Conductivity Readings for Resistance Inputs

### 8.3 Checking the Temperature Input

Check the analyzer responds to a temperature input. Disconnect the Pt100/Pt1000 leads and connect a suitable resistance box directly to the analyzer inputs – see Section 6.4. Check the analyzer displays the correct values as set on the resistance box – see Table 8.3.

Incorrect readings usually indicate an electrical calibration problem. Re-calibrate the analyzer as detailed in Section 7.3.

Temperature °C	Input Resistance (Ω)	
	Pt100	Pt1000
0	100.00	1000.00
10	103.90	1039.00
20	107.79	1077.90
25	109.73	1097.30
30	111.67	1116.70
40	115.54	1155.40
50	119.40	1194.00
60	123.24	1232.40
70	127.07	1270.70
80	130.89	1308.90
90	134.70	1347.00
100	138.50	1385.00
130.5	150.00	1500.00

Table 8.3 Temperature Readings for Resistance Inputs

## APPENDIX A

### A1 Automatic Temperature Compensation

The conductivities of electrolytic solutions are influenced considerably by temperature variations. Thus, when significant temperature fluctuations occur, it is general practice to correct automatically the measured, prevailing conductivity to the value that would apply if the solution temperature were 25°C, the internationally accepted standard.

Most commonplace, weak aqueous solutions have temperature coefficients of conductance of the order of 2% per °C (i.e. the conductivities of the solutions increase progressively by 2% per °C rise in temperature); at higher concentrations the coefficient tends to become less.

At low conductivity levels, approaching that of ultra-pure water, dissociation of the H<sub>2</sub>O molecule takes place and it separates into the ions H<sup>+</sup> and OH<sup>-</sup>. Since conduction occurs only in the presence of ions, there is a theoretical conductivity level for ultra-pure water which can be calculated mathematically. In practice, correlation between the calculated and actual measured conductivity of ultra-pure water is very good.

Fig. A1 shows the relationship between the theoretical conductivity for ultra-pure water and that of high purity water (ultra-pure water with a slight impurity), when plotted against temperature. The figure also illustrates how a small temperature variation considerably changes the conductivity. Subsequently, it is essential that this temperature effect is eliminated at conductivities approaching that of ultra-pure water, in order to ascertain whether a conductivity variation is due to a change in impurity level or in temperature.

For conductivity levels above 1µS cm<sup>-1</sup>, the generally accepted expression relating conductivity and temperature is:

$$G_t = G_{25} [1 + \alpha (t - 25)]$$

Where:  $G_t$  = conductivity at the temperature t°C

$G_{25}$  = conductivity at the standard temperature (25°C)

$\alpha$  = temperature coefficient per °C

At conductivities between 1µS cm<sup>-1</sup> and 1,000µS cm<sup>-1</sup>,  $\alpha$  lies generally between 0.015/°C and 0.025/°C. When making temperature compensated measurements, a conductivity analyzer must carry out the following computation to obtain  $G_{25}$ :

$$G_{25} = \frac{G_t}{[1 + \alpha (t - 25)]}$$

However, for ultra-pure water conductivity measurement, this form of temperature compensation alone is unacceptable since considerable errors exist at temperatures other than 25°C.

At high purity water conductivity levels, the conductivity/temperature relationship is made up of two components: the first component, due to the impurities present, generally has a temperature coefficient of approximately 0.02/°C; and the second, which arises from the effect of the H<sup>+</sup> and OH<sup>-</sup> ions, becomes predominant as the ultra-pure water level is approached.

Consequently, to achieve full automatic temperature compensation, the above two components must be compensated for separately according to the following expression:

$$G_{25} = \frac{G_t - G_{upw}}{[1 + \alpha (t - 25)]} + 0.055$$

Where:  $G_t$  = conductivity at temperature t°C

$G_{upw}$  = ultra-pure water conductivity at temperature t°C

$\alpha$  = impurity temperature coefficient

0.055 = conductivity in µS cm<sup>-1</sup> of ultra-pure water at 25°C


The expression is simplified as follows:

$$G_{25} = \frac{G_{imp}}{[1 + \alpha (t - 25)]} + 0.055$$

Where:  $G_{imp}$  = impurity conductivity at temperature t°C

The conductivity analyzer utilizes the computational ability of a microprocessor to achieve ultra-pure water temperature compensation using only a single platinum resistance thermometer and mathematically calculating the temperature compensation required to give the correct conductivity at the reference temperature.





### A1.1 Calculation of Temperature Coefficient

The temperature coefficient of a solution can be obtained experimentally by taking non-temperature compensated conductivity measurements at two temperatures and applying the following expression:

$$\alpha = \frac{G_{t_2} - G_{t_1}}{G_{t_1}(t_2 - 25) - G_{t_2}(t_1 - 25)}$$

Where:  $G_{t_2}$  = conductivity measurement at a temperature of  $t_2$  °C

$G_{t_1}$  = conductivity measurement at a temperature of  $t_1$  °C

One of these measurements could be made at the ambient temperature and the other obtained by heating the sample.

Temperature coefficient (%/°C) =  $\alpha \times 100$ .

For ultra pure water applications the temperature compensation equation becomes,

$$\alpha = \frac{G_{imp1} - G_{imp2}}{[G_{imp2}(t_1 - 25) - G_{imp1}(t_2 - 25)]}$$

Where:  $G_{imp1} = G_{t_1} - G_{upw1}$

$G_{imp2} = G_{t_2} - G_{upw2}$

### A2 Relationship Between Conductivity and Total Dissolved Solids (TDS) Measurement

The TDS factor (i.e. the relationship between conductivity ( $\mu\text{S cm}^{-1}$ ) and TDS in p.p.m.) is totally dependent on the properties of the solution being measured.

In simple solutions where only one electrolyte is present, the conductivity/TDS ratio can easily be ascertained, e.g. 0.5 in the case of sodium chloride. However, in complex solutions where more than one electrolyte is present, the ratio is not easily calculated and can only be reliably determined by laboratory testing (e.g. precipitation and weighing). The ratio in these cases is found to vary between approximately 0.4 and 0.8, depending on the chemical constituents, and is constant only when the chemical ratios remain constant throughout a particular process.

In cases where the TDS factor cannot be determined easily, refer to the supplier of the particular chemical treatment being used.

### A3 Inferred pH Derived from Differential Conductivity

Where cation resin columns are used to remove the effects on the conductivity measurement of alkaline and hydrazine chemical treatment on boilers, it is common practice to measure both before- (specific conductivity) and after-cation conductivity. The sensitivity of the conductivity measurement to chemical contaminants resulting from condenser leaks or poor boiler-feed make-up water is increased by passing the sample through the cation column. Both measurements can be made on one dual conductivity input analyzer.

If it is known that a sample contains only one impurity, e.g. ammonia, the conductivity measurement now becomes an indication of the concentration of that impurity. It is now possible to calculate the pH of the sample from the concentration data and the result is referred to as 'inferred pH'.

It is stressed that the inferred pH value is valid only if there are no other impurities present. To ensure this, the chemist looks at the after-cation conductivity (which is a sensitive method of detecting impurities in the sample) and only after establishing that it is low is the inferred pH value validated.

The dual input conductivity analyzer, when used to monitor direct and after-cation conductivities on a sample, automatically calculates the inferred pH for the most commonly used pH correction chemicals when programmed to do so. The user-configurable after-cation conductivity alarm is used to detect other impurities in the sample and can thus inform the user of the validity of the inferred pH value.

The maximum after-cation conductivity value is programmable between 0.060 and 1.000 $\mu\text{S cm}^{-1}$  dependent on local conditions. Values above this level generate an **AFTER CAT. HIGH** alarm and before-cation conductivity above 10.000 $\mu\text{S cm}^{-1}$  generates a **BEFORE CAT. HIGH** alarm.

**\*** **Note.** Both conductivity inputs must be configured as  $\mu\text{S cm}^{-1}$  in order to calculate inferred pH.

The inferred pH feature can be used only in the following circumstances:

- a) On steam raising plant.
- b) For boiler chemical treatment such as ammonia, sodium hydroxide, and/or hydrazine. For this application, either **NH<sub>3</sub>** or **NaOH** temperature compensation must be selected – see Section 7.3.

**\*** **Note.** Inferred pH measurement is inappropriate to chemical treatments such as phosphate, morpholine and quinhydrone.

- c) Where the after-cation conductivity value is an insignificant value to the before-cation value, or is greater than 1.0 $\mu\text{S cm}^{-1}$ .

---

# SPECIFICATION

---

## Conductivity

### Range

Programmable 0 to 0.5 to 0 to 10000  $\mu\text{S}/\text{cm}$   
(with various cell constants)

### Units of measure

$\mu\text{S}/\text{cm}$ ,  $\mu\text{S}/\text{m}$ ,  $\text{mS}/\text{cm}$ ,  $\text{mS}/\text{m}$ ,  $\text{M}^{-1}\text{cm}$  and TDS

### Accuracy

Better than  $\pm 1\%$  of reading

### Operating temperature range

$-10$  to  $150^\circ\text{C}$  ( $14$  to  $302^\circ\text{F}$ )

### Temperature compensation

$-10$  to  $150^\circ\text{C}$  ( $14$  to  $302^\circ\text{F}$ )

### Temperature coefficient

Programmable 0 to  $5\%/^\circ\text{C}$  and fixed temperature compensation curves (programmable) for acids, neutral salts and ammonia

### Temperature sensor

Programmable Pt100 /Pt1000

### Reference Temperature

$25^\circ\text{C}$  ( $77^\circ\text{F}$ )

---

## Display

### Type

Dual 5-digit, 7-segment backlit LCD

### Information

16-character, single line dot-matrix

---

## Environmental Data

### Operating temperature limits

$-20$  to  $65^\circ\text{C}$  ( $-4$  to  $149^\circ\text{F}$ )

### Storage temperature limits

$-25$  to  $75^\circ\text{C}$  ( $-13$  to  $167^\circ\text{F}$ )

### Operating humidity limits

Up to 95%RH non condensing

## EMC

### Emissions and immunity

Meets requirements of:  
EN61326 (for an industrial environment)  
EN50081-2  
EN50082-2

---

### Analog Retransmission

#### Number of signals

Two, fully-isolated outputs supplied as standard  
Four, fully-isolated outputs when ordered with option card

#### Output current

0 to 10mA, 0 to 20mA or 4 to 20mA  
Analog output programmable to any value between 0 and 22mA to indicate system failure

#### Accuracy

$\pm 0.25\%$  FSD,  $\pm 5\%$  of reading

#### Resolution

0.1% at 10mA 0.05% at 20mA

#### Maximum load resistance

750  $\Omega$  at 20mA

#### Configuration

Can be assigned to either measured variable or either sample temperature

---

## ...SPECIFICATION

---

### Relay Outputs

#### Number of relays

- Three, supplied as standard
- Five, when ordered with option card

#### Set point adjustment

- Fully programmable

#### Hysteresis

- Programmable 0 to 5% in 0.1% increments

#### Delay

- Programmable 0 to 60s in 1s intervals

#### Relay contacts

- Single-pole changeover
- Rating 5A, 115/230V AC, 5A DC

#### Insulation

- 2kv RMS contacts to earth/ground

---

### Power supply

#### Voltage requirements

- 85 to 265V AC 50/60 Hz
- 24V AC or 12 to 30V DC (optional)

#### Power consumption

- <10VA

#### Insulation

- Mains to earth (line to ground) 2kV RMS

---

### Safety

#### General safety

- EN61010-1
- Overvoltage Class II on inputs and outputs
- Pollution category 2

---

### Hazardous area approvals

- ATEX Type n Pending
- FM non-incendive Class I Division 2 Pending
- CSA non-incendive Class I Division 2 Pending

### Mechanical Data

#### Panel-mount versions

- IP66/NEMA4X
- Dimensions 192mm high x 230mm wide x 94mm deep (7.56 in. high x 9.06 in. wide x 3.7 in. deep)
- Weight 1kg (2.2 lb)

#### Panel-mount versions

- IP66/NEMA4X (front only)
- Dimensions 96mm x 96mm x 162mm deep (3.78 in. x 3.78 in. x 6.38 in. deep)
- Weight 0.6kg (13.2 lb)

SS/AX400 issue 1

---

## NOTES

---



# PRODUCTS & CUSTOMER SUPPORT

## Products

### Automation Systems

- *for the following industries:*
  - Chemical & Pharmaceutical
  - Food & Beverage
  - Manufacturing
  - Metals and Minerals
  - Oil, Gas & Petrochemical
  - Pulp and Paper

### Drives and Motors

- *AC and DC Drives, AC and DC Machines, AC motors to 1kV*
- *Drive systems*
- *Force Measurement*
- *Servo Drives*

### Controllers & Recorders

- *Single and Multi-loop Controllers*
- *Circular Chart, Strip Chart and Paperless Recorders*
- *Paperless Recorders*
- *Process Indicators*

### Flexible Automation

- *Industrial Robots and Robot Systems*

### Flow Measurement

- *Electromagnetic Magnetic Flowmeters*
- *Mass Flow Meters*
- *Turbine Flowmeters*
- *Wedge Flow Elements*

### Marine Systems & Turbochargers

- *Electrical Systems*
- *Marine Equipment*
- *Offshore Retrofit and Referredishment*

### Process Analytics

- *Process Gas Analysis*
- *Systems Integration*

### Transmitters

- *Pressure*
- *Temperature*
- *Level*
- *Interface Modules*

### Valves, Actuators and Positioners

- *Control Valves*
- *Actuators*
- *Positioners*

### Water, Gas & Industrial Analytics Instrumentation

- *pH, conductivity, and dissolved oxygen transmitters and sensors*
- *ammonia, nitrate, phosphate, silica, sodium, chloride, fluoride, dissolved oxygen and hydrazine analyzers.*
- *Zirconia oxygen analyzers, katharometers, hydrogen purity and purge-gas monitors, thermal conductivity.*

## Customer Support

We provide a comprehensive after sales service via a Worldwide Service Organization. Contact one of the following offices for details on your nearest Service and Repair Centre.

### United Kingdom

ABB Limited  
Tel: +44 (0)1453 826661  
Fax: +44 (0)1453 827856

### United States of America

ABB Inc.  
Tel: +1 (0) 755 883 4366  
Fax: +1 (0) 755 883 4373

### Client Warranty

Prior to installation, the equipment referred to in this manual must be stored in a clean, dry environment, in accordance with the Company's published specification. Periodic checks must be made on the equipment's condition.

In the event of a failure under warranty, the following documentation must be provided as substantiation:

1. A listing evidencing process operation and alarm logs at time of failure.
2. Copies of operating and maintenance records relating to the alleged faulty unit.

---

ABB has Sales & Customer Support expertise in over 100 countries worldwide

[www.abb.com](http://www.abb.com)

The Company's policy is one of continuous product improvement and the right is reserved to modify the information contained herein without notice.

Printed in UK (07.02)

© ABB 2002



**ABB Limited**  
Oldends Lane, Stonehouse  
Gloucestershire, GL10 3TA  
UK  
Tel: +44 (0)1453 826661  
Fax: +44 (0)1453 827856

**ABB Inc.**  
2175 Lockheed Way  
Carson City, NV 89706  
USA  
Tel: +1 (0) 775 883 4366  
Fax: +1 (0) 775 883 4373