

[Skip to content](#)

Manuals+

User Manuals Simplified.



Instant VORTEX PLUS 6 Quart Air Fryer User Guide

[Home](#) » [Instant](#) » Instant VORTEX PLUS 6 Quart Air Fryer User Guide

Contents [[hide](#)]

1 Instant VORTEX™ PLUS 6 Quart Air Fryer

- 1.1 Initial Setup
- 1.2 Product Overview
- 1.3 Initial Test Run
- 1.4 More Controls
- 1.5 Smart Programs
- 1.6 Cooking Timetable

2 Related Manuals:

Instant VORTEX™ PLUS 6 Quart Air Fryer



Getting Started Guide



Full Manual, How to Videos and Recipes available online at instantappliances.com

Register your product today at instantappliances.com/support/register




Initial Setup

- Remove all packaging material from in and around the Air Fryer, as well as all accessories from inside the cooking chamber.
- Follow Care & Cleaning instructions in the Safety, Maintenance & Warranty booklet to clean the

air fryer before first use.

- Place the Air Fryer on a stable, level surface, away from combustible material and external heat sources. Leave at least 5" of space around the air fryer.
- Do not place anything on top of the air fryer and do not block the air vents.
- Never use the Air Fryer on a stovetop.
- Read all Important Safeguards in the Safety, Maintenance & Warranty booklet before use. Failure to do so may result in property damage and/or personal injury.

Product Overview




The models listed here may not be representative of all models in the Vortex, Vortex Plus and Vortex Pro series.

For a complete list of colors and patterns, visit [instantappliances.com](https://www.instantappliances.com).

Initial Test Run


(approximate time: 25 minutes)

1. Connect the power cord to a 2 120V power source. Air fryer is in Standby and display indicates "**OFF**".




Note: To wake the air fryer, press the dial button or touch the screen.

2. Remove the air fry basket from the cooking chamber.




3. Place the cooking tray on the bottom 4 of the air fry basket.



Note: Ensure the indicator arrows point towards the back or the front of the air fryer.


4. Insert the air fry basket back into the cooking chamber.



5. Select Smart Program: **Air Fry**.




- Touch **Temp**, then use the dial to adjust the cooking temperature to 205 °C/400 °F. Touch **Time**, then use the dial to adjust the cook time to 20 minutes.*



***Note:** Smart Programs automatically save your last temperature and time settings.

- Touch **Start** to begin cooking. The display indicates “**On**” while the air fryer **Preheats**.




Touch the **Time** or **Temp** key to select the desired setting, then use the dial to adjust the cook time and temperature at any time during cooking.




- When the air fryer reaches the target temperature, the display indicates “**Add Food**”. For this initial test, do not add food to the air fry basket.*

* **Note:** Some food items do not require a preheat time. Whether you remove the basket or not, cooking will proceed after 10 seconds.



When cooking, food may be added before or after preheating, as you desire.

- Carefully remove and re-insert the 10 air fryer basket. Display changes from “**Add Food**” to indicate cook time and temperature. Display also indicates “**Cook**”.



10. Part way through the Smart Program, the air fryer beeps and displays **“turn Food”** to remind you to flip or shake your food items.*



Remove the air fry basket to pause the Smart Program and insert it into the cooking chamber to resume.

* **Note:** Notice only appears on **Air Fry** and **Roast**. Some food items do not require attention. Cooking will proceed after 10 seconds whether food has been turned or not.

11. When 1 minute remains, the cook time counts down in seconds. When the Smart Program completes, the display indicates **“End”** and the fan continues to blow to cool the air fryer.

Note: If the door is not opened, the Air Fryer will remind you that food is ready after 5, 30, and 60 minutes.



For further operation instructions, refer to the full User Manual online at [instantappliances.com](https://www.instantappliances.com).

CAUTION The air fryer and air fry basket will be hot during and after cooking. Do not touch hot surfaces. Allow the air fryer to cool to room temperature, then clean the air fry basket according to **“Care & Cleaning”** instructions in the included Safety, Maintenance & Warranty booklet.

More Controls

Cancel	Touch to stop cooking. Air fryer returns to Standby and displays "OFF".
Sound On/Off	When in Standby, touch and hold both Temp and Time keys for 3 seconds to toggle sound on or off. <i>Note: Error alerts cannot be silenced.</i>
Temperature (°F to °C)	Touch and hold Temp until the display changes from °F to °C, or vice versa.
Smart Program Reset	When in Standby, touch and hold the Smart Program for 3 seconds. The Smart Program is restored to its default setting.
Full Reset	When in Standby, press the dial in and hold it for 3 seconds. All settings and Smart Programs are restored to default settings.

Smart Programs

Smart Program	Time Range	Temperature Range
AirFry	1 - 60 minutes	180 - 400°F / 82 - 205°C
Roast	1 - 60 minutes	180 - 400°F / 82 - 205°C
Bake	1 - 60 minutes	180 - 400°F / 82 - 205°C
Reheat	1 - 60 minutes	120 - 360°F / 49 - 182°C
Broil*	1 - 40 minutes	400°F / 205°C
Dehydrate*	1 - 72 hours	95 - 175°F / 35 - 79°C

* **Broil & Dehydrate** Smart Programs are only available on Vortex Plus 6 models.

For further information on controls and Smart Programs, refer to the full User Manual online at instantappliances.com.

Cooking Timetable

Food	Setting	Cook Time*	Temperature*	Instruction
Thin-cut fries (Frozen)	AirFry/Roast	14 - 18 minutes	385°F / 196°C	Shake partway
Thin-cut fries (Fresh)	AirFry/Roast	18 - 20 minutes	385°F / 196°C	Shake partway
Thick-cut fries (Frozen)	AirFry/Roast	16 - 20 minutes	385°F / 196°C	Shake partway
Thick-cut fries (Fresh)	AirFry/Roast	20 - 25 minutes	385°F / 196°C	Shake partway
Chicken wings	AirFry/Roast	20 - 30 minutes	400°F / 205°C	Shake or turn partway
Half chicken (up to 2lbs)	Roast	30 - 40 minutes	380°F / 193°C	Optionally, baste partway
Chicken nuggets (Frozen)	Broil / Air Fry	10-15 minutes	400°F / 205°C	Turn partway
Shrimp (Fresh)	Air Fry	8 - 10 minutes	350°F / 177°C	Turn partway
Fish sticks (Frozen)	Broil	8 - 12 minutes	400°F / 205°C	Turn partway
Asparagus	Broil / Bake	7 - 9 minutes	380°F / 193°C	Turn partway
Cauliflower	Broil / Bake	6 - 10 minutes	380°F / 193°C	Turn partway
Nachos	Broil	3 - 5 minutes	400°F / 205°C	Check cheese halfway
Cake	Bake	25 - 35 minutes	365°F / 185°C	Use a springform cake pan

***Note:** Cook times and temperatures are recommendations only

All oven safe cookware is safe to use in the Air Fryer

For a complete cooking timetable, visit instantappliances.com

Instant VORTEX PLUS 6 Quart Air Fryer User Guide – [Optimized PDF](#)

Instant VORTEX PLUS 6 Quart Air Fryer User Guide – [Original PDF](#)

Related Manuals:

1. [Instant VORTEX PLUS 10 Quart Air Fryer User Guide](#) Instant VORTEX PLUS 10 Quart Air Fryer User Guide Welcome...
2. [PowerXL Vortex Air Fryer Pro CM-007 Instruction Manual](#) Owner's Manual SAVE THESE INSTRUCTIONS - FOR HOUSEHOLD USE ONLY...
3. [Instant Pot Air Fryer Lid Manual](#) Instant Pot Air Fryer Lid Manual - Optimized PDF Instant...
4. [INSIGNIA NS-AF53MSS0 5 Qt. Mechanical Control Air Fryer User Guide](#) USER GUIDE 5 Qt. Mechanical Control Air Fryer NS-AF53MSS0 Before...
5. [Instant Milk Frother User Manual](#) IMPORTANT SAFEGUARDS (Yes, we have to) At Instant Brands, your...
6. [INSIGNIA NS-PC6SS7 6 Quart Pressure Cooker User Guide](#) USER GUIDE 6 Quart Pressure Cooker NS-PC6SS7 Recipes are included...