ALLEGIC	N [™] SYST	ASTI EM	ER KEY SUMMA	RY		This form must be attached to the Master Key Order form and P.O. provide as complete and accurate as possible provide what you need for your Key Syste			
Job Name					Acco	unt			
Address					No				
City / State									
Country					P.O	.#			
-	ailed instructions on ho	w to c	omplete th	is form	nlease refu	er to nages 4 & 5			
For detailed instructions on how to complete this form please refer to pages 4 & 5 System Overview									
<u> </u>									
∐ New		Ш			info below)				
Attached Dea	ler Specified Combination	s	Registry #						
		Structure or							
Factory Order #									
	•	1. Se	lect Syst	em					
Schlag	е				Falcon				
☐ Classic		Standard							
	Primus ®/ Primus ® XP				Schlage C				
Everest ®		Restricted *							
`	Format IC, Restricted *)	Interchangeable Core A2							
C (Open)			Interchangeable Core A4						
	Primus®/Primus® XP *								
☐ D (Restr	•								
	Primus ®/Primus ® XP *						,		
Everest 29 ™				-		wards compatible to Everest			
☐ R (Small Format IC, Restricted *)			keyways and have the following relationships:						
☐ S (Open)			R family sections > B family keyways						
☐ Primus ®/Primus ® XP *			S family sections > C family keyways T family sections > D family keyways						
☐ T (Restricted *)			•			- Tulling Roywayo			
	Primus ®/Primus ® XP *				* = Atta	ach required documentation			
<u>Type</u>	,	Const	ruction Keye	<u>ed</u>					
□ 5 - Pin □	6 - Pin 🔲 7 - Pin		Yes		No				
See compatibility	chart on page 5	Full Si	ze Construc	tion Co	res (Schlage	e Only)			
			ICA		ICB				
Keyway		Small	Format Cons	structio	n Cores				
Specified **:			Green		Brown	□ Black			
		Const	ruction Keye	ed Type					
** = The Commercial	Master Key Department		Falcon		CK (BOK)	☐ Lost Ball			
makes the final decisi	on in the selection of key		Schlage		CK (Split)	RCK			
se	ctions					(5-Pin C only)			

		2.	Select Keys	s & Key Stan	nping			
Change								
	No. of Keys per S	_						
	No. of Keys per Cy	linder_						
<u>Type</u>								
	Standard Bow		Standard Bow (Unembossed)		Access Bow (Schlage Only)	Large Bow		
Key Sta	mp Details							
	Keyset Symbol		Do Not Duplicate (DND)		With Custom Die (Specify)			
	Non-standard Cod	e (Spec	ify)		<u>.</u>			
	Key Packaging and							
Pack	Keys Independently	y (PKI) (of Lock or Cylind	der ***				
	Yes		No			standard at no charge with construction keying		
If I	PKI, ship change ke	vs to ·			, ,	, ,		
	-	y3 to . □						
	Dealer See Primus Facesl		Other					
Ш	See Pillius Facesi	neet	-					
			0. Oalast O.	dia dan Otana	· • · · · ·			
		,	3. Select Cy	linder Stamp	oing			
Cylinder	Stamp Details			Cylinder Stamp	ing Location			
	With Industry Stand	ard Key	/ Symbol	☐ Plug Fa	ce (N/A in Primus) - VKC		
☐ Non-Standard Code (Specify) ☐ Concealed (N/A in Falcon STD) - CKC								

4. Select Key Quantities									
<u>Level</u>	Qty. Per	Master Key Sym	bol (s)	Total Quantity					
GGM									
GM		-	_						
MK or RMK			_						
Control									
Emergency									
Others									
2 333 2			_						
Ship Master Keys	s to:		_						
☐ Dealer		See Primus Facesheet	Other						
Special Function									
		Qty. Per		Qty. Per					
RCK (Lost Ba	II) ****	Full Size Con	struction Core Keys ((Schlage Only)					
CK (Split-Key)	****	Full Size Con	struction Core Contro	ol Keys (Schlage Only)					
Extractor Tool	ls ****	Small Format	Construction Core K	(eys					
		Small Format	Construction Core C	Control Keys					
		***	= Used with Construc	ction Keying					
**** = Used with Construction Keying 5. Select Master Key Future Expansion									
		5. Select Master	Key Future Exp	ansion					
List Future	MK Sym		Approx. # of Chang	ansion ge Key Symbols Under Future MK					
List Future Example:	MK Sym		Approx. # of Chang	ge Key Symbols Under					
	MK Sym		Approx. # of Chang	ge Key Symbols Under					
Example: MK_ GGM_	_ ■	bols BJ, BK	Approx. # of Chang Each F	ge Key Symbols Under					
Example: MK_ GGM_	_ ■	bols BJ, BK	Approx. # of Chang Each F	ge Key Symbols Under					
Example: MK GGM GM	_ 🗖	bols BJ, BK	Approx. # of Chang Each F	ge Key Symbols Under					
Example: MK GGM GM MK		bols BJ, BK	Approx. # of Chang Each F	ge Key Symbols Under					
Example: MK GGM GM MK		BJ, BK	Approx. # of Chang Each F	ge Key Symbols Under					
Example: MK GGM GM MK		bols BJ, BK	Approx. # of Chang Each F	ge Key Symbols Under					
Example: MK GGM GM MK MK		BJ, BK	Approx. # of Chang Each F	ge Key Symbols Under					
Example: MK_ GGM_ GM_ MK_ MK_ MK_ Others_		BJ, BK 6. Select Ope	Approx. # of Chang Each F 40 each	ge Key Symbols Under Future MK					
Example: MK	erwise s	6. Select Ope	Approx. # of Chang Each F 40 each rating Instruction of the second of	pe Key Symbols Under Future MK Ons Operate cross-keyed cylinders) ed is operated by					
Example: MK_ GGM_ GM_ MK_ MK_ MK_ Others	erwise s	6. Select Ope	Approx. # of Chang Each F 40 each rating Instruction in the start in	je Key Symbols Under Future MK					
Example: MK	erwise s	6. Select Ope	Approx. # of Chang Each F 40 each rating Instruction of the second of	pe Key Symbols Under Future MK Ons Operate cross-keyed cylinders) ed is operated by					
Example: MK	erwise s	6. Select Ope specified, all hierarchical is operated by these change keys	Approx. # of Chang Each F 40 each rating Instruction of Chang al master keys will of Cross Keye Cylinder	pe Key Symbols Under Future MK Ons Operate cross-keyed cylinders) ed is operated by					
Example: MK GGM GM MK MK Others (Unless oth Cross Key Cylinder X	erwise s	6. Select Ope specified, all hierarchicatis operated by these change keys	Approx. # of Chang Each F 40 each rating Instructi al master keys will of Cylinder X	pe Key Symbols Under Future MK Ons Operate cross-keyed cylinders) ed is operated by					
Example: MK	erwise s	6. Select Ope specified, all hierarchicatis operated by these change keys	Approx. # of Chang Each F 40 each rating Instruction Cross Keye Cylinder X X	ions perate cross-keyed cylinders) ed is operated by these change keys					

7. Instructions and Compatibility

General Information

If you do not know the registry number (R#), structure number or the original factory order number for an existing

Tel. 1-877-671-7011 Fax 1-800-452-0663

- Only one structure may be ordered on the same purchase order
- Classic refers to Obverse, Numbered (Paracentric), Quad, and Reverse key section families
- Classic Primus refers to Primus Obverse and Primus Quad key section families

Section 1: Select a System

Full Size Construction Cores

Schlage only

Small Format Construction Cores

- 7-pin only for Schlage
- 6- and 7-pin for Falcon

CK (Split)

- 6-pin for Schlage and Falcon
- Split-Key construction keying is not available for Classic Primus or Everest Primus

RCK (Lost Ball)

- 5-pin (C keyway) only for Schlage
- 5-, 6-, and 7-pin for Falcon

System Selection

Refer to the compatibility chart

Section 2: Select Keys and Key Stamping

Stamp Details

- Unless otherwise specified, industry standard key symbols are stamped on Everest[™] and Primus® keys
- For custom die, attach RFQ approval for Schlage

Section 3: Select Cylinder Stamping

Type

For cylinder type refer to the compatibility chart

Keyway (specify)

- Schlage Commercial's default key section for new Master Key Systems is Everest ™ S145

Section 4: Key Quantities

Level

 Unless otherwise specified, the control key has the same cut as the highest-level key in the system (Except SFIC systems)

Special Function

Construction keys are not furnished unless specified

Change Keys

• Unless otherwise specified 2 change keys are furnished per lock or cylinder

Section 5: Select Master Key Future Expansion

• Do not use the letters "I", "O", "CK", "KA", or "KD" for any master key symbols

Section 6: Select Operating Instructions

- Cross keying reduces the security and expansion of key systems
- Unless otherwise specified, all hierarchical master keys will operate cross-keyed cylinders

Compatibility Chart

	5 Pin	6 Pin	7 Pin	Split- Key	Block- O-Key	Lost Ball	Temp Core	A2	A4	0.025	0.018
Schlage											
Classic	Х	Х		Х		Х	Х				
Everest B			Х				Х	Х			
Everest C		Х		Х			Х				
Everest D		Х		Х			Х				
Everest 29 R			Х				Х	Х			
Everest 29 S		Х		Х			Х				
Everest 29 T		Х		Х			Х				
Classic Primus (XP)		Х					Х				
Everest Primus (XP)		Х					Х				
Everest 29 Primus (XP)		Х					Х				
Falcon											
Open	Х	Х	Х		Х	Х					Х
Restricted		Х	Х		Х	Х				Х	
Schlage C		Х		Х							
SFIC Open		Х	Х				Х	Х	Х		
SFIC Restricted		Х	Х				Х	Х	Х		