

MiniMax Cooling Counter

Depth: 560 incl. door

Models: MM2V2 / MM2V22 / MM22V22 / MM22STF / MM222STF / MM222STF



Congratulations!

You made a good choice.

Thank you for buying this perfect ,MiniMax Cooling Counter'. This cooling unit was made on the most modern production way.

The full-foamed housing guarrantees a low energie consumption.

This operating instruction shall give you some details for the perfect use of your cooling counter. If you have further questions, please contact your cooling specialist.

Table of contents

| 3 |
|---|
| 3 |
| |
| |
| 4 |
| 4 |
| |
| |
| |
| 5 |
| 5 |
| 6 |
| 6 |
| 6 |
| 7 |
| 9 |
| 1 |
| |



1. Mounting instruction - general

Place your counter on their right place by water level!

ATTENTION!

After adjusting the counter feets, please press, the foamed plug and the plastic plug into the holes! This enshures a better insulation.

ATTENTION. CAN TILT!

Please avoid rolling or sliding the bar with doors open.

2. Installation

Integral Models

- If your cooling counter ist mounted ready to plug in, please put the plug into the socket. The current has to be the same as on the Type button.
- Before using, please clean the inside of the housing.
- The digital controller shows the actual temperature of the housing, the ventilator works permanent. The cooling machine works immediately and cooles down, until the temperature of +4 °C is reached.

Remote Models (without cooler)

- If the condenser ist preinstalled, we recommend the following aspects!
- At installation, please use a pump down system for 3 (max. 4) cabinets per compressor.
- The prefered cooling capacity must be 150 Watts for the 1st cabinet, 100 Watts for each following cabinet.
- For bigger combinations please use further separate compressors or a combined bigger system in realtion with the energy consumption or safety-aspects.

03/2013

3. Energie saving - environmental protection

- Open the doors only as long as nessessary.
- Please check regular the seals of the doors.
- A wasted condenser causes a higher energy consumption. Please clean them regular as described under point ,Cleaning of the condenser'.
- Please avoid high outside temperatures, direct sun-burning or placement by a radiator, wich causes a higher energie consumption.

4. Digital controller LAE AT 1-5



Setting the temperature

- Press button

 for at least half second, to display the setpoint value.
- 2 Use ●■▼ or ▲■■ for changing the temperature.
- 3 Release all buttons and wait 10 sec.

Keypad lock

- Use i ⇒ and immediately release button ⇒ L I will be displayed.
- Press once ⇒ LOC will be displayed.
- 3 i please keeping pressed.

Activating / Deactivating: Push the buttons

■ ■ or ■ M

→ YES / NO

4 Release all buttons and wait 10 sec.

ON and OFF

- Press button **x** of for at least 3 seconds ⇒ **ON** will be displayed.
- For switch off, press button for at least 3 seconds.

ΕN

5. Defrost

- The defrosting works automatically all three ours. The cooling device stands still for 12 minutes. The display of the digital contoller changes to ,DEF' (defrost). The display changes to temperature scetch, if the recommended temperature is reached or if 10 miuntes are gone.
- During the defrosting is a minimal rise of the temperature inside the housing possible. The core temperature of the cooling goods will not be affected.

6. How to replace the bulbs

First of all and very important: Please unplug the cable.

- Then srew of the cover sheets right and left from the illumination with a Phillips screwdriver.
- 2 Then move the complete casing to the left and remove it out of the counter.
- 3 Remove the transparent cover by pressing it lightly together.
- 4 Then change the bulb by turning it to the left.









Now you can foreward to replace all parts into position.

03/2013

7. Cleaning

Please clean the cooling device minimum 1 time per month.

- 1 Open the machine housing with the included tooling.
- 2 Pull the plug out ouf the socket.
- 3 Clean the condenser with a broom or a vacuum cleaner.
- 4 Clean the machine case with a moist duster.
- 5 Put the stick into the socket and close the machine housing.
- 6 If nessessary please clean the fronts and grips with clean water.

For the cleaning of the inside of the housing dont take aggressive cleaners, only neutral, desinfective cleaners. Dry up the inside of the housing, to avoid an higher energy consumption as a result of frosting of the condenser.

8. Maintainance contract

- We recommend a maintainance contract with your cooling specialist.
- If you need any spare parts, please contact also your cooling specialist.

9. Important facts

- Mounting and connection of a dispensing system has to be made only by an expert, who will inform you about all facts on operating a dispensing system.
- We recommend for the installation of the water connections to contact a sanitairy specialist
- Pay attention on the right placement of the counter. The ventilation of the housing must be served!
- Noise of the cooling machine are unavoidable.
- By a longer time of none using the counter, please pull the plug and open the doors for avoiding a stink.
- If you want an other arrangement of your counter, please contact your cooling specialist.
- Pay attention, that the following load-carring capacities have not be broken:
 - Drawer modul (if installed) max.: 45 kg
 - Shelf for bottles inside the door modul: max. 75 kg each.



10. Trouble shooting

- At eventually delay, please check first by using the follwing list, if you have all, in these operating instruction noted facts payed attention.
- If it's not possible to repair the delay, please contact your authorised cooling specialist.


| Fault | Possible cause | Find a remedy |
|---|---|---|
| | | |
| Rattling noise | Loose screw connections or worn bearings | Contact your distributor |
| Display is not running | No voltage | Put the plug into the socket, controll the fuse |
| Mainswitch is not glowing | Mainswitch may be OFF | Check the contacts on the controller (el. know-how is recommended) |
| Display shows ,DEF' | Defrost mode | Wait until defrost is finished (max. 15 min), in case of demand, please ask your authorised technician to change the spacings |
| Temperature inside the cabinet is to high | The controller may be wrong adjusted | Modify the set point of the controller |
| | The evaporator is not ventilated sufficiently | Control and cleaning of the evaporator (pull the plug outt of the socket) |
| | Door gaskets are leaking | Change the door gaskets |
| | Evaporator fan is damaged | Change the fan (el. know-how is recommended) |
| | The cooling device is damaged | Repair by an authorised technician |
| | Doors or drawers are opened to long | Only open the doors as long as really nessessary |
| | The icing of the evaporator is to much | Correction of spacings and time of the defrost mode (el. know-how is recommended) |
| | | Remove the wet or not enough covered reefer |

03/2013 7


| Temperature inside the cabinet is to low | The controller may be wrong adjusted | Modify the set point of the controller |
|--|--------------------------------------|---|
| Display shows ,E1' | Fault on the thermometer probe | Check the contacts on the back of the controller (el. know-how is recommended). |
| | | Change the probe (el. know-how is recommended). |

- Please close the doors until your cooling specialist check the delay. Dont put new cooling goods into the counter.
- Dont try to repair the defect by yourself, if it's not possible by the list on the left side. Otherwise the defect will become bigger than before and it may be dangerous if there ist a defect on the electrical parts.

11. Electrical sketch



03/2013



12. EG-Declaration of Conformity

(Directives 2004/108/EC + 2006/95/EC + 2006/42/EC)

Herewith we declare that this machine corresponds to the basic EEC directives for security and health demands on the basis of its conception and model, as well as of the type that we brought in circulation.

This declaration loses its validity in case of modification of the machinery to which we did not agree.

| | EC Machinery Directive |
|-------------------------|--|
| Relevant EC Directives: | EC Low Voltage Directive |
| | EC Directive for Electromagnetic Compatibility |

| Applied harmonized standards: | EN 55014-1:2006+A1:2008 |
|--------------------------------|---|
| | EN 55014-2:1997+A1:2001+A2:2008 |
| | EN 62233:2008 |
| | EN 61000-3-2:2006 |
| | EN 61000-3-3:1995+A1:2001+A2:2005 |
| | EN 60335-1:2002+A1:2004+A11:2004 |
| Applied national standards and | Pressure Equipment Directive 97/23/EC 29.04.1997, |
| technical specifications: | VDE 0100, DIN 8975, UVV, VGB 20 |

Manufacturer:

K. & M. Holland GmbH Industriestr. 14 94327 Bogen Tel.: 09422 / 507-0

Fax: 09422 / 507-300

03/2013

Klaus Holland

Managing director

