INSTALLATION GUIDE

RESEARCH POWErStep

		MADE IN USA
APPLICATION	MODEL YR	PART #
Nissan Armada Nissan Titan Crew Cab Nissan Titan King Cab	2004 - up 2004 - up 2004 - up	75110-01A 75110-01A 75110-01A
		INSTALLATION TIME 3:00 hrs 3:00 hrs SKILL LEVEL 1 1 2 3:00 hrs SKILL LEVEL 1 2 3:00 hrs 3:00 hrs SKILL LEVEL 1 1 1 2 3 4= Experienced 1 </td


Designed and manufactured by AMP Research[®]. Patent Number 6,830,257; 6,641,158; 6,834,875; 6,938,909; 6,942,233; 7,007,961; 7,055,839; 7,163,221; 7,367,574; 7,380,807; 7,398,985; 7,413,204; 7,487,986. Other US and Worldwide patents pending. Made in USA © 2010 AMP Research 5-year limited warranty. Professional installation is recommended.

www.amp-research.com

IM3074 rev 06.08.10

INSTALLATION GUIDE Attaching motor to linkage assembly

The motors need to be installed before continuing with the rest of the Power Step install.



To insure our customers receive all components with full integrity, we pack the motors seperate from their linkage assemblies. This requires that the installer position and fasten the motor before continuing with the install. Please follow the instructions below and handle the assembly carefully.


CAUTION: Dropping the assembly or any excessive impact MAY cause damage to the motor.

Instructions:


1. Position the gear cover in place as shown if not already in place.

2. Seat motor into position on the three mounting bosses. This may require an adjustment of the gear by moving the swing arms.


3. After seating into place, fasten the motor with the three motor mount screws with T30 Torx. Tighten screws to 80 in-lbs (9N-m). Do not over torque.








AMP RESEARCH POWER STEP - NISSAN




AMP RESEARCH POWER STEP - NISSAN


Slide rubber grommet on wire harness into slot of motor cover. Insert motor cover onto motor.v




Install motor mounting bracket using the three M6x12 bolts. Then mount motor using the two M6x16 countersink bolts. Use thread locking compound.




Using supplied Posi-Tap[™] connector, splice Power Step trigger wires into the corresponding signal wires located in step 16.



Insert plastic push pin rivets in mounting holes of motor cover.



After removing step plate of front door of vehicle cabin, lift carpet and pull trigger wires though grommet. Remove kick panel and locate the appropriate signal wires (will match trigger wires).



DRIVER SIDE:


 Light Blue • Red w/ yellow stripe

(Crew Cab and ArmadaOnly)

PASSENGER SIDE:

- Red with Blue Stripe & Silver Dashes
- Grey (Crew Cab and Armada Only)

Replace fuse. Open doors to activate steps. Driver side doors should only activate the drive side step; passenger side doors should only activate the step on the passenger side



Congratulations on the purchase of your AMP Research Power Step



Here's what you should know...

OPERATION

The AMP Research Power Step automatically deploys when at least one door opens and automatically retracts under your vehicle when both front and rear doors close. If resistance or blockage is encountered while the Power Step is in motion, the drive system is designed to automatically stop. To reset, simply open or close the vehicle door and the Power Step will resume normal operation.

MAINTENANCE TIPS

The stepping surface and drive mechanism can be wash with mild soap and water using a soft brush or sponge to dislodge any mud, dirt or accumulated road grime. Rinse with fresh water.

To prevent slipping, avoid applying waxes, lubricants or protectants like Armor All® to the step surface.

When washing your vehicle, the Power Steps can be set to remain deployed with the doors closed for easy cleanning. Do this...

1 With the Power Step deployed, press and hold the board down with your foot.

- 2 Close the door while continuing to press down the board. (This will not harm motor.)
- **3** To reset the Power Step, simply open and close the door. (Repeat for both sides of vehicle.)

CAUTION! BE SURE TO KEEP HANDS AWAY WHEN THE POWER STEP IS IN MOTION.

amp-research.com

LIMITED WARRANTY

AMP RESEARCH warrants product to be free from defects in material and workmanship, for terms specified below, provided there has been normal use and proper maintenance. All remedies under this warranty are limited to the repair or replacement of any item found by the factory to be defective within the time period specified.

If you have a warranty claim, first you must call our factory at the number below for instructions. You must retain proof of purchase and submit a copy with any items returned for warranty work. Upon completion of warranty work, if any, we will return the repaired or replaced item or items to you freight prepaid. Damage to our products caused by accidents, fire, vandalism, negligence,

misinstallation, misuse, Acts of God, or by defective parts not manufactured by us, is not covered under this warranty.

THE WARRANTY TIME PERIOD IS AS FOLLOWS: 5-YEARS FROM DATE OF PURCHASE.

ANY IMPLIED WARRANTIES OF MERCHANTABILITY AND/OR FITNESS FOR A PARTICULAR PURPOSE CREATED HEREBY ARE LIMITED IN DURATION TO THE SAME DURATION AND SCOPE AS THE EXPRESS WRITTEN WARRANTY. OUR COMPANDY SHALL NOT BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGE.

Some states do not allow limitations on how long an implied warranty lasts, or the exclusion or limitation of incidental or consequential damages, so the above limitations or exclusions may not apply to you. This warranty gives you specific legal rights, and you may also have other rights that vary from state to state.

WARNING

Be sure to read and precisely follow the provided instructions when installing this product. Failure to do so could place the vehicle occupants in a potentially dangerous situation. After installing or reinstalling, re-check to insure that the product is