



# **Lunch Box Safety Webinar**

## ***Safety Over Sandwiches***

**May 6: Respiratory Protection**

---

*Presented by Joe Mlynek, Progressive Safety Services LLC*

# What is a Respirator?

- ▶ Protective device that covers the nose and mouth or the entire face or head to guard the wearer against hazardous atmospheres



# Why wear a respirator?

- ▶ Working in an area with insufficient oxygen
- ▶ Situations where harmful dusts, fogs, smokes, mists, fumes, gases, vapors or sprays are present
- ▶ These types of hazards may cause cancer, lung impairment, other disease, or death

# When is it Appropriate to Wear a Respirator?

- ▶ Where engineering controls, such as ventilation, or administrative controls are not feasible or insufficient
- ▶ During the time when engineering or administrative controls are being implemented
- ▶ For emergency response



# Respiratory Hazards

## ▶ Dusts

- Created when solid materials are broken down into fine particles that can be suspended in air before settling under gravity

## ▶ Fumes

- Created when solid material vaporizes under high heat and then condenses (welding)
- Vapors condense into small particles that are light enough to be breathable

# Respiratory Hazards

## ▶ Mists

- Tiny liquid droplets from liquid materials formed by condensation processes
- Spraying, mixing, plating, and cleaning operations

## ▶ Gases

- Substances that are similar to air
- Diffuse and spread freely throughout a container or air
  - i.e. Oxygen, carbon monoxide, nitrogen, helium, etc.

# Respiratory Hazards

## ▶ Vapors

- The gaseous state of substances that are either liquids or solids at room temperature. They are formed when solids or liquids evaporate.
  - Paint thinners, solvents, etc.

## ▶ Oxygen Deficiency

- Occurs when the percentage of oxygen in the air falls below 19.5%
- Can be caused by chemical reaction, fire, or when other chemicals displace oxygen from the air

# Respiratory Protection

»» Elements of an effective program



# Respiratory Protection Program

- ▶ Elements of an Effective Program
  - Written Worksite Specific Procedures
  - Program Evaluation
  - Respirator Selection
  - Medical Evaluation
  - Fit-Testing
  - Proper Use
  - Inspection, Cleaning and Maintenance
  - Training
  - Recordkeeping

# Worksite Specific Procedures

- ▶ Developed to ensure that employees use the respirator safely
- ▶ Familiarize employees with procedures and respirators available, and their limitations



# Program Evaluation

- ▶ Evaluate the effectiveness of the program regularly
- ▶ Modify written procedures as necessary to reflect evaluation results

# Respirator Selection

- ▶ Choosing the Right Respirator:
  - Determine what the hazard is and its extent
  - Consider user factors that affect respirator performance and reliability
  - Select an appropriate NIOSH–certified respirator



# Respirator Selection

- ▶ Things to consider:
  - Chemical and physical properties of the contaminant
  - Toxicity and concentration of the hazardous material
  - Amount of oxygen present

# Medical Evaluation

- ▶ Workers assigned tasks that require respiratory use must be physically able to perform work while using the respirator



# Medical Evaluation

- ▶ Local physician or licensed healthcare professional (LHCP) determine what health and physical conditions are pertinent
- ▶ Can be performed by using a medical questionnaire or by a medical examination that contains the same information as the questionnaire
  - Questionnaire – 1910.134 Respiratory Protection Appendix C

# Medical Evaluation

- ▶ Performed prior to fit-testing
- ▶ Employer must obtain a written recommendation from the LHCP for each employee's ability to wear a respirator



# What About Voluntary Use?

- ▶ Workers may choose to wear a respirator voluntarily in workplaces with no hazardous exposures
- ▶ Employers must evaluate the respiratory use to ensure it doesn't harm the employee
- ▶ If it could harm the employee, employer must medically evaluate employees.

# What about Voluntary Use?

- ▶ Employers must inform employees voluntarily using respirators of basic information contained in Appendix D of OSHA's Respiratory Protection Standard. Employees must do the following:
  - “Read and heed all instructions”
  - “Choose respirators certified for use to protect against the contaminants of concern”.
  - “Do not wear a respirator into atmospheres containing contaminants for which your respirator is not designed to protect against.”
  - “Keep track of your respirator that you do not mistakenly use someone else's respirator.

# Fit- Testing

- ▶ Performed for tight fitting facepiece respirators including filtering facepiece respirators required to be used.
- ▶ No one respirator will fit everyone!
- ▶ Two Types:
  - Quantitative
  - Qualitative

# Quantitative Fit Testing

- ▶ The fit test equipment measures the concentration of microscopic particles that exist in ambient air and those particles that leak into the respirator.



# Qualitative Fit Testing.

- ▶ Involves introduction of a harmless odoriferous or irritating substance into the breathing zone.
- ▶ If no odor or irritation is detected by the wearer, this indicates proper fit.



# Use of Respirators

- ▶ Factors that can affect the seal/fit of the respirator:
  - Facial hair
  - Corrective glasses
  - Facial scarring
  - Broken jaw
  - Changes in weight
  - Dentures




# Respirators

## »» Types

# Types of Respirators

- ▶ Tight Fitting – half masks which cover the mouth and nose and full facepieces which cover the face from the hairline to below the chin.





# Types of Respirators

- ▶ Loose Fitting

- Hoods or helmets that cover the head completely.



# Two Major Classes of Respirators

- ▶ Air Purifying
  - Remove contaminants from the air
- ▶ Atmosphere Supplying
  - Provide clean breathable air from an uncontaminated source



# Respirator Selection

- ▶ Immediately Dangerous to Life and Health
  - Atmosphere that poses an immediate threat to life, cause irreversible adverse health effects, or would impair a persons ability to escape from a dangerous atmosphere.
    - Use only SCBA, Supplied Air, or escape respirator.
  
- ▶ Non-IDLH
  - Use particulate filters or chemical filter media.

# Supplied Air and SCBA

- ▶ Breathing air must be of high purity.
  - Breathing air must meet at least the requirement for Grade D breathing air described in Compressed Gas Association Commodity Specification G7.1
  - Compressors for supplying air must have:
    - Safety devices and alarms
    - In-line filters
    - Sorbent Beds
    - CO Alarms
    - High temperature alarms

# Filtering Media


- ▶ Three common types of filter media:
  - Particulate
    - Removes particles from the air
  - Organic Vapor
    - Removed chemicals from the air by using solvents
  - Acid Gas
    - Removes acid based gases from the air.



# Limitations of Air Purifying Respirators

- ▶ Do not protect against oxygen deficiency
- ▶ Do not use when:
  - Performing abrasive blasting
  - In atmospheric concentrations above the IDLH
  - For Firefighting

# Filtering Face-Piece



# Particulate Filter Media

## Respirator Filter Media Ratings:

- ◆ “N” if they are *not* resistant to oil
- ◆ “R” if somewhat *resistant* to oil, and
- ◆ “P” if strongly resistant (*oil proof*)



# Disposable Particulate Facepieces



There are nine types of disposable particulate facepieces:

- ◆ N-95, N-99, N-100
- ◆ R-95, R-99, R-100
- ◆ P-95, P-99, P-100

# Disposable Particulate Respirator



- ◆ 95-99.97% efficiency rating
- ◆ Lightweight
- ◆ Easy to wear
- ◆ Do not require cleaning
- ◆ Usually come in three sizes
- ◆ Can be obtained with or without an exhalation valve

# Disposable Particulate Respirator

- ▶ Does not filter out chemical gases or vapors
- ▶ Does not provide a seal to prevent gases and vapors from being inhaled

# Respirator Usage

»» Protect Yourself

# Pre-Use Inspection

- ▶ Inspect the following:
  - Facepiece
  - Headband
  - Valves
  - Connections
  - Fittings
  - Cartridges, canisters, or filters
  
- ▶ SCBA's inspected monthly
  - Air cylinders charged
  - Regulator
  - Warning devices



# Pre-Use Inspection

- ▶ Before using a tight fitting respirator
  - Positive Pressure Test – cover exhalation valve with hand and exhale. Mask should bulge, but seal should remain.
  - Negative Pressure Test – Cover inhalation cartridges with hands and inhale, mask should collapse, but seal should remain.
- ▶ If either test fails, adjust and try again.

# Cleaning & Inspection

- ▶ Use warm soap and water
- ▶ Do not use harsh chemicals (bleach, etc.)
- ▶ Respirator wipes available



# Cleaning & Inspection

- ◆ Disposables cannot be cleaned or sanitized, however routine inspection is still necessary
- ◆ Determine whether the straps hold the facepiece tightly against the face; if not, dispose of it; never attempt to tighten a facepiece by knotting the straps
- ◆ Inspect the facepiece to determine if it is soiled or damaged; if so, dispose of it





# Care and Maintenance

- ▶ Properly store all respirators to protect from
  - Damaging chemicals
  - Sunlight
  - Extreme Temperatures/Moisture
- ▶ Do not store respirators in:
  - Areas where they can become contaminated
  - Open air environments
  - Toolboxes

# Change-Out

- ▶ Chemical cartridges must be equipped with an “end of service life indicator”
  - Changes color when time to replace, or
- ▶ Employer must develop a change schedule based on reliable information
  - Several Tools available on OSHA website

# Proper Storage

- ▶ Clean dry location
- ▶ Storing in a plastic bag when damp may prevent drying and encourage microbial growth. Allow respirator to dry prior to storing
- ▶ Label respirators with the user's name or other identifier

# Training

- ▶ Training must be provided to employees required to wear a respirator
  - Prior to use
  - Annual refresher



# Training

- ▶ Training should include an explanation of:
  - Why respirator use is necessary
  - Nature of the respiratory hazard and consequences of not fitting, using, and maintaining the respirator properly
  - Capabilities and limitations of the selected respirator
  - How to inspect, put on and remove, and check the seals of the respirator

# Training

## ▶ Continued:

- Proper maintenance and storage
- How to use the respirator effectively in emergency situations
- How to recognize medical signs and symptoms that may limit or prevent the effective use of the respirator

# Recordkeeping

- ▶ Employer must establish and retain written information concerning:
  - Respirator program
  - Medical recommendations from a licensed physician
  - Fit Test Records
  - Training

# Additional Information – osha.gov

- ▶ OSHA Respiratory Protection Handbook
- ▶ 1910.134 Respiratory Protection
- ▶ Appendix A – Fit Testing Procedures
- ▶ Appendix B–1 – User Seal Check Procedures
- ▶ Appendix B–2 – Respirator Cleaning Procedures
- ▶ Appendix C – Medical Questionnaire
- ▶ Appendix D – Information for Employees Using Respirators When not Required Under the Standard.



# Additional Information – osha.gov

- ▶ Wide range of training videos:
  - Respiratory Protection in General Industry
  - Respirator Types
  - Respirator Fit Tests
  - Maintenance and Care of Respirators
  - Medical Evaluations for Persons Who Wear Respirators
  - Voluntary Use
  - Respirator User Seal Checks Donning
  
- ▶ OSHA Occupational Chemical Database
- ▶ Subpart Z – Toxic and Hazardous Substances

# Additional Information

- ▶ Brief Quiz
- ▶ Supervisor Talking Points

# Disclaimer

- ▶ This presentation was developed to give general safety information. Progressive Safety Services LLC (Progressive Safety) does not make any representation or warranty as to the accuracy or completeness of the information in this presentation. Refrain from doing any act or omission that are reasonably foreseeable that a particular other person (or class of persons) is likely to suffer damage or loss as a result of the act or omission. Progressive Safety is excluded from liability for negligence for both personal injury and damage to property. The information within this presentation is general. It does not constitute and should not be relied on as legal advice. Progressive Safety Services LLC tries to ensure that the content of this presentation is accurate, adequate or complete, it does not represent or warrant or its accuracy, adequacy of completeness.



# Questions?

Joe Mlynek CSP, OHST

[Joe.mlynek@progressivesafety.us](mailto:Joe.mlynek@progressivesafety.us)