

Compatible Mobile Phone Models

KD-A95BT / KD-R90BT
 KD-R80BT / KD-SD80BT
 KD-AHD75BT / KD-HDR71BT / KD-A735BT / KD-R730BT
 KD-R736BT / KD-R731BT / KD-R739BT / KD-S88BT / KD-S48*
 KD-A65* / KD-R60* / KD-R50*
 KW-R900BT / KW-HDR81BT / KW-R800BT
 KW-R700BT / KW-SD70BT / KW-R600BT
 KD-X80BT / KD-X70BT / KD-X50BT
 KD-A925BT / KD-R926BT / KD-R921BT
 KD-R820BT / KD-R826BT / KD-R821BT
 KD-R726* / KD-A725* / KD-R720*
 KD-R729BT / KD-R728BT / KD-R727BT / KD-R721BT

* Optional USB adapter KS-BTA50 is required.

Manufacture	Model	Pairing/ Connect	Phone Function			Phonebook Function		Audio Function	
			Dialing/ Receiving	Voice Dialing	SMS/Text message receipt notification	Manual	Auto	Streaming [A2DP]	Control [AVRCP]
Apple	iPhone 2G	✓	✓	—	—	—	✓	—	—
Apple	iPhone 3G	✓	✓	—	—	—	✓	✓	✓
Apple	iPhone 3GS	✓	✓	✓	—	—	✓	✓	✓
Apple	iPhone 4	✓	✓	✓	—	—	✓	✓	✓
Apple	iPhone 4S	✓	✓	✓	—	—	✓	✓	✓
Apple	iPhone5	✓	✓	✓	—	—	✓	✓	✓
au	HTL21	✓	✓	—	—	✓	✓	✓	✓
au	INFORBAR A02	✓	✓	✓	—	N/A	✓	✓	✓
au	iPhone5	✓	✓	✓	—	—	✓	✓	✓
au	IS11S(XPERIA acro)	✓	✓	✓	—	—	✓	✓	✓
au	IS12M	✓	✓	✓	—	—	✓	✓	✓
au	IS12S(Xperia Acro HD)	✓	✓	✓	—	✓	✓	✓	✓
au	IS13SH	✓	✓	—	—	—	✓	✓	✓
au	IS17SH	✓	✓	—	—	✓	✓	✓	✓
au	ISW11F	✓	✓	—	—	—	✓	✓	✓
au	ISW11K	✓	✓	—	—	—	✓	✓	✓
au	ISW13HT	✓	✓	—	—	✓	✓	✓	✓
au	ISW13F	✓	✓	—	—	✓	✓	✓	✓
au	ISW16SH	✓	✓	—	—	✓	✓	✓	✓
au	iPhone4S	✓	✓	✓	—	—	✓	✓	✓
au	KYL21	✓	✓	—	—	N/A	✓	✓	✓
au	K009	✓	✓	—	—	✓	—	✓ ^{*1}	✓ ^{*1}
au	LGL21 (Optimus G)	✓	✓	—	—	N/A	✓	✓	✓
au	SHL21	✓	✓	—	—	N/A	✓	✓	✓
au	SOL21	✓	✓	✓	—	N/A	✓	✓	✓
au	T008	✓	✓	—	—	✓	—	✓ ^{*1}	✓ ^{*1}
au	URBANO AFFARE	✓	✓	—	—	✓	—	—	—
au	URBANO PROGRESSO	✓	✓	—	—	✓	✓	✓	✓
BlackBerry	7130g	✓	✓	—	—	—	—	—	—
BlackBerry	8707G	✓	✓	—	—	✓	✓	—	—
BlackBerry	8800	✓	✓	✓	—	✓	✓	—	—
BlackBerry	8900	✓	✓	✓	—	✓	✓	✓	✓
BlackBerry	9360	✓	✓	✓	—	✓	✓	✓	✓
BlackBerry	9630	✓	✓	✓	—	✓	✓	✓	✓
BlackBerry	9850	✓	✓	✓	—	✓	✓	✓	✓
BlackBerry	9860	✓	✓	✓	—	✓	✓	✓	✓
BlackBerry	Bold 9000	✓	✓	✓	—	✓	✓	✓	✓

BlackBerry	Bold 9700	✓	✓	✓	—	✓	✓	✓	✓
BlackBerry	Bold 9780	✓	✓	✓	N/A	N/A	✓	✓	✓
BlackBerry	Bold 9900	✓	✓	✓	—	✓	✓	✓	✓
BlackBerry	Torch 9800	✓	✓	✓	—	✓	✓	✓	✓
BlackBerry	Torch 9810	✓	✓	✓	—	✓	✓	✓	✓
BlackBerry	Torch 9860	✓	✓	✓	—	✓	✓	✓	✓
BlackBerry	Curve 8320	✓	✓	✓	—	✓	✓	✓	✓
BlackBerry	Curve 8330	✓	✓	✓	—	✓	✓	✓	✓
BlackBerry	Curve 8520	✓	✓	✓	—	✓	✓	✓	✓
BlackBerry	Curve 8900	✓	✓	✓	—	✓	✓	✓	✓
BlackBerry	Pearl 8130	✓	✓	✓	—	✓	✓ ¹	✓	✓
BlackBerry	Pearl Flip 8220	✓	✓	✓	—	✓	✓	✓	✓
BlackBerry	Storm 9500	✓	✓	✓	—	✓	✓	✓	✓
BlackBerry	Storm 9530	✓	✓	✓	—	✓	✓	✓	✓
BlackBerry	Storm 9550	✓	✓	✓	—	✓	✓	✓	✓
DELL	Streak 5	✓	✓	✓	—	✓	✓	✓	✓
DELL	Venue	✓	✓	✓	—	✓	✓	✓	✓
docomo	F-02E	✓	✓	—	—	N/A	✓	✓	✓
docomo	F-03D	✓	✓	—	—	—	✓	✓	✓
docomo	F-04E (Arrows V)	✓	✓	—	—	N/A	✓	✓	✓
docomo	F-05D	✓	✓	—	—	—	✓	✓	✓
docomo	F-08D (Disney mobile)	✓	✓	—	—	—	✓	✓	✓
docomo	F-10D	✓	✓	—	—	✓	✓	✓	✓
docomo	F-11D	✓	✓	—	—	✓	✓	✓	✓
docomo	F-12D	✓	✓	—	—	✓	✓	✓	✓
docomo	GALAXY S II LTE (SC-03D)	✓	✓	—	—	—	NG	✓	✓
docomo	L-05D	✓	✓	—	—	✓	✓	✓	✓
docomo	N-03E	✓	✓	—	—	N/A	✓	✓	✓
docomo	N-04E (MEDIAS)	✓	✓	✓	—	N/A	✓	✓	✓
docomo	N-05D	✓	✓	—	—	—	✓	✓	✓
docomo	N-07D	✓	✓	—	—	✓	✓	✓	✓
docomo	P-02D	✓	✓	—	—	—	✓	✓	✓
docomo	P-02E	✓	✓	✓	—	N/A	✓	✓	✓
docomo	P-06D	✓	✓	—	—	✓	✓	✓	✓
docomo	P-07D	✓	✓	—	—	✓	✓	✓	✓
docomo	SO-03D(Xperia™ acro HD)	✓	✓	✓	—	✓	✓	✓	✓
docomo	SC-02E	✓	✓	✓	—	N/A	✓	✓	✓
docomo	SC-03E	✓	✓	✓	—	N/A	✓	✓	✓
docomo	SC-04D	✓	✓	—	—	—	✓	✓	✓
docomo	SC-05D	✓	✓	—	—	✓	✓	✓	✓
docomo	SC-06D(Galaxy S3)	✓	✓	—	—	✓	✓	✓	✓
docomo	SH-01D	✓	✓	—	—	—	✓	✓	✓
docomo	SH-01E	✓	✓	—	—	N/A	✓	✓	✓
docomo	SH-09D	✓	✓	—	—	✓	✓	✓	✓
docomo	SH-10D	✓	✓	—	—	✓	✓	✓	✓
docomo	SH-02E	✓	✓	—	—	N/A	✓	✓	—
docomo	SH-04E	✓	✓	—	—	N/A	✓	✓	✓
docomo	SO-01E	✓	✓	✓	—	N/A	✓	✓	✓
docomo	SO-02E (XPERIA Z)	✓	✓	✓	—	N/A	✓	✓	✓
docomo	SO-04D	✓	✓	✓	—	✓	✓	✓	✓
docomo	SO-05D	✓	✓	✓	—	✓	✓	✓	✓
docomo	T-01D	✓	✓	—	—	—	✓	✓	✓
docomo	T-02D	✓	✓	—	—	✓	✓	✓	✓
docomo	Xperia arc(SO-01C)	✓	✓	✓	—	—	✓	✓	✓
docomo	Xperia NX (SO-02D)	✓	✓	✓	—	—	✓	✓	✓
docomo	Xperia ray (SO-03C)	✓	✓	✓	—	—	✓	✓	✓
Eten	X800	✓	✓	✓ ¹	—	✓	—	✓	✓
Eten	glofish X500	✓	✓	✓	—	✓	—	✓	✓
EMOBILE	GS02	✓	✓	—	—	—	✓	✓	✓
EMOBILE	GS03	✓	✓	—	—	✓	✓	✓	✓

EMOBILE	S51SE(Sony Ericsson mini)	✓	✓	✓	—	—	✓	✓	✓
Glofiish	X800	✓	✓	✓	N/A	✓	—	✓	✓
HP	iPAQ rw6828	✓	✓	—	—	✓	—	✓	—
HTC	Aria 65169	✓	N/A	—	N/A	—	✓	✓	✓
HTC	Desire HD	✓	✓	—	—	✓	✓	✓	✓
HTC	Desire C	✓	✓	—	—	✓	✓	✓	✓
HTC	Desire S	✓	✓	—	—	✓	✓	✓	✓
HTC	Desire Z	✓	✓	—	—	✓	✓	✓	✓
HTC	Diamond	✓	✓	—	—	—	✓	✓	✓
HTC	Diamond 2	✓	✓	—	—	—	✓	✓	✓
HTC	Droid incredible	✓	N/A	✓	N/A	✓	✓	✓	✓
HTC	Droid incredible2	✓	N/A	✓	N/A	✓	✓	✓	✓
HTC	EVO Design	✓	N/A	✓	N/A	✓	✓	✓	✓
HTC	Explorer	✓	✓	—	—	✓	✓	✓	✓
HTC	G2	✓	✓	✓	—	NG	✓	✓	✓
HTC	HD mini	✓	✓	—	—	✓	✓	✓	✓
HTC	Hero	✓	✓ ^{*1}	—	—	—	—	✓	✓
HTC	Incredible	✓	✓	—	—	—	✓	✓	✓
HTC	Incredible S	✓	✓	—	—	✓	✓	✓	✓
HTC	Inspire 4G	✓	✓	✓	—	✓	✓	✓	✓
HTC	Legend	✓	✓	—	—	✓	✓	✓	✓
HTC	Nexus One	✓	✓	✓	—	✓	✓	✓	✓
HTC	One S	✓	✓	—	—	✓	✓	✓	✓
HTC	One X	✓	✓	—	—	✓	✓	✓	✓
HTC	P3600	✓	✓	✓	—	✓	—	✓	✓
HTC	Pre	✓	✓	—	—	✓	✓	✓	✓
HTC	Rhyme	✓	✓	—	—	✓	✓	✓	✓
HTC	S730	✓	✓ ^{*1}	✓	—	✓	—	✓	✓
HTC	Sensation	✓	✓	—	—	✓	✓	✓	✓
HTC	Sensation XE	✓	✓	—	—	✓	✓	✓	✓
HTC	Sensation XL	✓	✓	—	—	✓	✓	✓	✓
HTC	Shadow	✓	✓	✓	—	✓	—	✓	✓
HTC	Tattoo	✓	✓	—	—	—	—	✓	✓
HTC	ThunderBolt	✓	N/A	✓	N/A	✓	✓	✓	✓
HTC	Titan	✓	✓	—	✓	—	✓	✓	✓
HTC	Touch	✓	✓	✓	—	✓	—	✓	✓
HTC	Touch 2	✓	✓	—	—	✓	✓	✓	✓
HTC	Touch Cruise	✓	✓	✓	—	✓	✓	✓	✓
HTC	Touch Dual	✓	✓ ^{*1}	✓	—	✓	✓	✓	✓
HTC	Touch HD	✓	✓ ^{*1}	✓ ^{*1}	—	✓	✓	✓	✓
HTC	Touch HD T8285	✓	✓	✓	—	✓	—	✓	✓
HTC	Touch Pro	✓	✓	✓	—	✓	✓	✓	✓
HTC	Touch Pro 2	✓	✓	—	—	✓	✓	✓	✓
HTC	TyTN II	✓	✓	✓	—	✓	✓	✓	✓
HTC	Wildfire	✓	✓	—	—	✓	✓	✓	✓
HTC	X01HT	✓	✓	—	—	✓	—	—	—
HTC	8S	✓	✓	✓	✓	✓	✓	✓	✓
HTC	8X	✓	✓	✓	✓	✓	✓	✓	✓
LG	CT810	✓	✓	✓	—	✓	—	✓	✓
LG	E510	✓	✓	—	—	✓	✓	✓	✓
LG	GD510	✓	✓	—	—	✓	✓	✓	✓
LG	GD880 mini	✓	✓	—	—	✓	✓	✓	✓
LG	GR500	✓	✓	✓	✓	✓	—	✓	✓
LG	GT540	✓	✓	—	—	✓	✓	✓	✓
LG	GW520	✓	✓	—	—	✓	✓	✓	✓
LG	GW620	✓	✓	—	—	—	—	✓	✓
LG	GW820	✓	✓	✓	—	✓	✓	✓	✓
LG	HB620T	✓	✓	—	—	✓	—	✓	✓
LG	KC910	✓	✓	—	—	✓	✓	✓	✓
LG	KE770 Shine	✓	NG	—	✓	✓	—	✓	✓
LG	KE800 Chocolate	✓	✓	—	✓	✓	—	✓	✓

LG	KE850 Prada	✓	✓	—	✓	NG	—	✓	✓
LG	KF350 Ice Cream	✓	✓	—	—	✓	—	✓	✓
LG	KG290	✓	✓	—	—	NG	—	—	—
LG	KP500	✓	✓	—	—	✓	NG	✓	✓
LG	KS20	✓	✓	—	—	✓	✓	✓	✓
LG	KU800	✓	✓	—	—	✓	—	✓	✓
LG	KU970 Shine	✓	✓	—	—	✓	—	✓	✓
LG	KU990 Viewty	✓	✓	—	—	✓	—	✓	✓
LG	Optimus 2X P990	✓	✓	—	—	✓	✓	✓	✓
LG	Optimus 4X HD P880	✓	✓	—	—	✓	✓	✓	✓
LG	Optimus Black P970	✓	✓ ¹	—	—	✓	✓	✓	✓
LG	Optimus Chic E720	✓	✓	—	—	✓	✓	✓	✓
LG	Optimus One P500	✓	✓	—	—	✓	✓	✓	✓
LG	Optimus S	✓	N/A	✓	N/A	✓	—	✓	✓
LG	VX 9400	✓	N/A	✓	N/A	✓	—	✓	✓
LG	T370	✓	✓	—	N/A	✓	✓	✓	✓
Motorola	Adventure V750	✓	N/A	✓	N/A	NG	✓	✓	✓
Motorola	Atrix	✓	✓	✓	—	✓	✓	✓	✓
Motorola	Atrix 2	✓	N/A	✓	N/A	NG	✓	✓	✓
Motorola	BACKFLIP ME600	✓	✓	—	—	—	—	NG	✓
Motorola	DEFY MB525	✓	✓	✓	✓	—	✓	✓	✓
Motorola	Droid 2 (Milestone 2)	✓	✓	—	—	✓	✓	✓	✓
Motorola	Droid PRO	✓	N/A	✓	N/A	✓	✓	✓	✓
Motorola	Droid RAZR 4G (MOTXT912-16)	✓	✓	✓	✓	✓	✓	✓	✓
Motorola	Droid RAZR XT910 MAXX	✓	✓	✓	✓	✓	✓	✓	✓
Motorola	Droid RAZR XT912	✓	✓	✓	✓	✓	✓	✓	✓
Motorola	Droid X	✓	N/A	✓	N/A	✓ ¹	✓	✓	✓
Motorola	E1070	✓	✓	✓	✓	✓	—	✓	✓
Motorola	Flipout MB511	✓	✓	✓	—	✓	✓	✓	✓
Motorola	KRZR K1	✓	✓	✓	✓	✓	—	✓	✓
Motorola	KRZR K3	✓	✓	✓	✓	✓	—	✓	✓
Motorola	M702iG	✓	✓	—	N/A	✓	—	✓	✓
Motorola	MB855	✓	✓	—	✓	✓	✓	✓	✓
Motorola	Milestone	✓	✓	✓	—	—	✓	✓	✓
Motorola	Milestone XT720	✓	✓	✓	—	✓	✓	✓	✓
Motorola	MOTO W7	✓	✓	—	—	✓	—	✓	✓
Motorola	MOTO ZN300	✓	✓	✓ ¹	✓	✓	—	✓	✓
Motorola	Q11	✓	✓	✓	—	✓	✓	✓	✓
Motorola	Q9h	✓	✓	✓	—	✓	✓	✓	✓
Motorola	QA1	✓	✓	✓	✓	✓	—	✓	✓
Motorola	Quench MB501	✓	✓	—	—	—	—	✓	✓
Motorola	Quench XT3 XT502	✓	✓	—	—	—	—	✓ ¹	✓
Motorola	RAZR maxx V6	✓	✓	✓	✓	✓	—	✓	✓
Motorola	RAZR maxx V1100	✓	✓	✓	✓	✓	—	✓	✓
Motorola	RAZR V3	✓	✓	✓	✓	✓	—	—	—
Motorola	RAZR V3X	✓	✓	✓	✓	✓	—	✓	✓
Motorola	RAZR2 V8	✓	✓	✓	—	✓	—	✓	✓
Motorola	RAZR2 V9	✓	✓	✓	✓	✓	—	✓	✓
Motorola	RIZR Z8	✓	✓	—	—	✓	—	✓	✓
Motorola	ROKR E2	✓	✓	✓	—	✓	—	✓	✓
Motorola	ROKR EM30	✓	✓	✓	✓	✓	—	✓	✓
Motorola	ROKR Z6	✓	✓	✓	—	✓	—	✓	✓
Motorola	SLVR L72	✓	✓	✓	✓	✓	—	✓	✓
Motorola	W510	✓	✓	✓	✓	NG	—	✓	✓
Motorola	W7	✓	✓	—	—	✓	—	✓	✓
Motorola	XT701	✓	✓	—	—	—	✓	✓	✓
Motorola	ZINE ZN5	✓	✓	✓	—	✓	—	✓	✓
Motorola	ZN300	✓	✓	✓	✓	✓	—	✓	✓
Motorola	XT550 Smart MIX	✓	✓	—	N/A	N/A	✓	✓	—
NEC	804N	✓	✓	—	N/A	✓	—	—	—

Nokia	300	✓	✓	—	—	✓	✓	✓	✓
Nokia	500	✓	✓	✓	✓	✓	✓	✓	✓
Nokia	2600 classic	✓	✓	—	—	✓	—	—	—
Nokia	2630	✓	✓	—	—	✓	—	—	—
Nokia	2660	✓	✓	—	—	✓	—	—	—
Nokia	2730 classic	✓	✓	✓	—	✓	✓	✓	✓
Nokia	3109 classic	✓	✓	✓	—	✓	—	✓	✓
Nokia	3110 classic	✓	✓	✓	—	✓	—	✓	✓
Nokia	3120 classic	✓	✓	✓	—	✓	✓	✓	✓
Nokia	3500 classic	✓	✓	✓	—	✓	—	✓	✓
Nokia	5130 XpressMusic	✓	✓	✓	—	✓	✓	✓	✓
Nokia	5230	✓	✓	✓	—	✓	✓	✓	✓
Nokia	5300	✓	✓	✓	—	✓	—	✓	✓
Nokia	5310 XpressMusic	✓	✓	✓	—	✓	✓	✓	✓
Nokia	5320 XpressMusic	✓	✓	✓	—	✓	✓	✓	✓
Nokia	5530 XpressMusic	✓	✓	✓	—	✓	✓	✓	✓
Nokia	5610 XpressMusic	✓	✓	✓	—	✓	✓	✓	✓
Nokia	5630 XpressMusic	✓	✓	✓	—	✓	✓	✓	✓
Nokia	5700 XpressMusic	✓	✓	✓	—	✓	—	✓	✓
Nokia	5800 XpressMusic	✓ ²	✓	✓	—	✓	✓ ¹	✓	✓
Nokia	6085	✓	✓	✓	—	✓	—	✓	✓
Nokia	6110 Navigator	✓	✓	✓	—	✓	—	✓	✓
Nokia	6120 classic	✓	✓	✓	—	✓	—	✓	✓
Nokia	6131	✓	✓	✓	✓	✓	—	—	—
Nokia	6151	✓	✓	✓	—	✓	—	—	—
Nokia	6260	✓	NG	✓	—	✓	✓	✓	✓
Nokia	6267	✓	✓	✓	—	✓	—	✓	✓
Nokia	6290	✓	NG	✓	—	✓	—	✓	✓
Nokia	6300	✓	✓	✓	—	✓	—	✓	✓
Nokia	6303 classic	✓	✓	✓	—	✓	✓	✓	✓
Nokia	6500 classic	✓	✓	✓	—	✓	✓	✓	✓
Nokia	6680	✓	✓	✓	—	✓	—	—	—
Nokia	6681	✓	✓	✓	—	✓	—	—	—
Nokia	6700 classic	✓	✓	✓	—	✓	✓	✓	✓
Nokia	6700 Slide	✓	✓	✓	✓	✓	✓	✓	✓
Nokia	7210 Supernova	✓	✓	✓	—	✓	✓	✓	✓
Nokia	7373	✓	✓	✓	—	✓	—	✓	✓
Nokia	7390	✓	✓	✓	—	✓	—	✓	✓
Nokia	7900 Prism	✓	✓	✓	—	✓	✓	✓	✓
Nokia	8600 Luna	✓	✓	✓	✓	✓	—	✓	✓
Nokia	8800	✓	✓	✓ ¹	✓	✓	—	✓ ¹	✓
Nokia	8800 arte	✓	✓	✓	—	✓	✓	✓	✓
Nokia	C3-00	✓	✓	—	—	✓	✓	✓	✓
Nokia	C5-00	✓	✓	✓	✓	✓	✓	✓	✓
Nokia	C6-00	✓	✓	✓	✓	✓	✓	✓	✓
Nokia	C7	✓	✓	✓	—	—	✓	✓	✓
Nokia	E51	✓	✓	✓	—	✓	—	✓	✓
Nokia	E52	✓	✓	✓	✓	✓	✓	✓	✓
Nokia	E61i	✓	✓	✓	—	✓	—	✓	✓
Nokia	E63	✓	✓	✓	—	✓	—	✓	✓
Nokia	E65	✓	✓	✓	—	✓	—	✓	✓
Nokia	E66	✓	✓	✓	—	✓	—	✓	✓
Nokia	E7	✓	✓	✓	—	—	✓	✓	✓
Nokia	E71	✓	✓	✓	—	✓	—	✓	✓
Nokia	E72	✓	✓	✓	✓	✓	✓	✓	✓
Nokia	E90	✓	✓	✓	—	✓	—	✓	✓
Nokia	Lumia520	✓	✓	✓	—	✓	✓	✓	✓
Nokia	Lumia610	✓	✓	✓	✓	—	✓	✓	✓
Nokia	Lumia710	✓	✓	✓	✓	—	✓	✓	✓
Nokia	Lumia800	✓	✓	—	✓	—	✓	✓	✓
Nokia	Lumia900	✓	✓	—	✓	—	✓	✓	✓

Nokia	N70	✓	✓	✓	—	✓	—	—	—
Nokia	N71	✓	✓	✓	N/A	✓	—	—	—
Nokia	N72	✓	✓	✓	—	✓	—	—	—
Nokia	N76	✓	✓	✓	—	✓	—	✓	✓
Nokia	N78	✓ ^{*2}	✓	✓ ^{*1}	—	✓	✓	✓	✓
Nokia	N8	✓	✓	✓	—	✓	✓	✓	✓
Nokia	N80	✓	✓	✓	—	✓	—	—	—
Nokia	N82	✓	✓	✓	—	✓	—	✓	✓
Nokia	N86	✓	✓	✓	—	✓	✓	✓	✓
Nokia	N9	✓	NG	—	—	✓	✓	✓	✓
Nokia	N93	✓	✓	✓	—	✓	—	—	—
Nokia	N95	✓	✓	✓	—	✓	—	✓	✓
Nokia	N96	✓	✓	✓ ^{*1}	N/A	N/A	✓	✓	✓
Nokia	N97	✓	✓ ^{*1}	✓	✓	✓	✓	✓	✓ ^{*1}
Nokia	N97 mini	✓	✓	✓	✓	✓	✓	✓	✓
Nokia	NM706i	✓	✓	✓	N/A	✓	—	✓	✓
Nokia	X6	✓	✓	✓	—	✓	✓	✓	✓
Nokia	Asha 305	✓	✓	—	N/A	✓	✓	✓	—
O2	XDA Stealth	✓	✓	✓	—	✓	—	✓	✓
Palm	Centro	✓	✓	—	—	✓	—	✓	✓
Palm	Pre	✓	✓	—	N/A	N/A	✓	✓	NG
Palm	Treo 750	✓	✓	✓	—	✓	—	✓	✓
Palm	Treo Pro	✓	✓	—	—	✓	—	✓	✓
Panasonic	705P	✓	✓	—	N/A	✓	—	—	—
Panasonic	921P	✓	✓	—	N/A	✓	—	✓	✓
Panasonic	P904i	✓	✓	—	N/A	✓	—	N/A	N/A
Panasonic	VS6	✓	✓	—	—	✓	—	—	—
Sagem	my501X	✓	✓	—	—	✓	—	—	—
Sagem	my700X	✓	✓	—	—	✓	—	✓	NG
Samsung	705SC	✓	✓	—	N/A	✓	—	✓	✓
Samsung	A897	✓	✓	✓	✓	✓	—	✓	✓
Samsung	C3050C	✓	✓	—	—	✓	✓	✓	✓
Samsung	C5212	✓	✓	—	✓	✓	—	✓	✓
Samsung	Captivate i897	✓	N/A	—	N/A	✓	✓	✓	✓
Samsung	Galaxy 580 i5801	✓	✓	—	—	✓	✓	✓	✓
Samsung	Galaxy Ace	✓	✓	—	—	✓	✓	✓	✓
Samsung	Galaxy Ace Plus GT-S7500	✓	✓	—	—	✓	✓	✓	✓
Samsung	Galaxy Dous S6802	✓	✓	—	—	✓	✓	✓	✓
Samsung	Galaxy Ace2 GT-i8160	✓	✓	✓	—	✓	✓	—	—
Samsung	Galaxy mini2 GT-S6500D	✓	✓	—	—	✓	✓	✓	✓
Samsung	Galaxy Note	✓	✓	✓	—	✓	✓	✓	✓
Samsung	Galaxy Note2	✓	✓	✓	—	✓	✓	✓	✓
Samsung	Galaxy Nexus	✓	✓	✓	—	✓	✓	✓	✓
Samsung	Galaxy S	✓	✓	—	—	✓	✓	✓	✓
Samsung	Galaxy S Plus(i9001)	✓	✓	—	—	✓	✓	✓	✓
Samsung	Galaxy SII	✓	✓	✓	—	✓	✓	✓	✓
Samsung	Galaxy S3	✓	✓	✓	—	✓	✓	✓	✓
Samsung	Galaxy S4	✓	✓	✓	—	✓	✓	✓	✓
Samsung	Galaxy SL i9003	✓	✓	—	—	✓	✓	✓	✓
Samsung	Galaxy Y Dous GT-S6102	✓	✓	—	—	✓	✓	✓	✓
Samsung	Galaxy Y S5360	✓	✓	—	—	✓	✓	✓	✓
Samsung	Galaxy Spica i5700	✓	✓	—	—	✓	NG	✓	✓
Samsung	i7500 Galaxy	✓	✓	—	—	—	—	✓	✓
Samsung	i8000 Omnia 2	✓	✓	—	—	✓	✓	✓	✓
Samsung	i8510 INNOV8	✓	✓	—	—	✓	✓	✓	✓
Samsung	i8910 Omnia HD	✓	✓	—	—	✓	✓	✓	✓
Samsung	Intercept SPH-M910	✓	N/A	—	N/A	✓	✓	✓	✓
Samsung	L708	✓	✓	—	—	✓	—	✓	✓
Samsung	M8800	✓	✓	—	✓	✓	—	✓	✓

Samsung	Nexus S	✓	✓	✓	—	✓ ¹	✓	✓	✓
Samsung	S5230	✓	✓	—	—	✓	✓ ¹	✓	✓
Samsung	S5560 Marvel	✓	✓	—	—	✓	—	✓	✓
Samsung	S5570 Galaxy Mini	✓	✓	—	—	✓	✓	✓	✓
Samsung	S8000 Jet	✓	✓	—	—	✓	✓	✓	✓
Samsung	S8300 Ultra touch	✓	✓	—	✓	✓	✓ ¹	✓	✓
Samsung	S8500 Wave	✓	✓	—	—	✓	✓	✓	✓
Samsung	SPH-A727	✓	✓	—	—	✓	—	✓	✓
Samsung	SGH-A767	✓	✓	—	✓	✓	—	✓	✓
Samsung	SGH-A867	✓	✓	—	—	✓	—	✓	✓
Samsung	SGH-A877	✓	✓	—	—	✓	—	✓	✓
Samsung	SGH-D510	✓	✓	—	—	✓	—	✓	✓
Samsung	SGH-D600	✓	✓	—	—	✓	—	✓	✓
Samsung	SGH-D900	✓	✓	—	✓	✓	—	✓	✓
Samsung	SGH-D900i	✓	✓	—	—	✓	—	✓	✓
Samsung	SGH-E950	✓	✓	—	—	✓	✓	✓	✓
Samsung	SGH-F210	✓	✓	—	—	✓	—	✓	✓
Samsung	SGH-F330	✓	✓	—	✓	✓	—	✓	✓
Samsung	SGH-F490	✓	✓	—	✓	✓	—	✓	✓
Samsung	SGH-G800	✓	✓	—	✓	✓	—	✓	✓
Samsung	SGH-i450	✓	✓	—	—	✓	✓	✓	✓
Samsung	SGH-i620	✓	✓	—	—	✓	—	✓	✓
Samsung	SGH-i637	✓	✓	—	—	✓	✓	✓	✓
Samsung	SGH-i780	✓	✓	—	—	✓	—	✓	✓
Samsung	SGH-J600	✓	✓	—	—	✓	✓ ¹	—	—
Samsung	SGH-M310	✓	✓	—	—	✓	✓	—	—
Samsung	SGH-M610	✓	✓	✓	—	✓	—	✓	✓
Samsung	SGH-S400i	✓	NG	—	—	✓	—	—	—
Samsung	SGH-U100	✓	✓	—	—	✓	✓	✓	✓
Samsung	SGH-U700	✓	✓	—	—	✓	—	✓	✓
Samsung	SGH-U900	✓	✓	—	✓	✓	—	✓	✓
Samsung	SGH-X830	✓	✓	—	—	✓	—	✓	✓
Samsung	SGH-Z240	✓	✓	—	—	NG	—	—	—
Samsung	SGH-Z360	✓	✓	—	—	✓	—	✓	✓
Samsung	SGH-Z510	✓	✓	—	—	✓	—	✓	✓
Samsung	SGH-Z630	✓	✓	—	—	✓	—	✓	✓
Samsung	SGH-Z720	✓	✓	—	—	✓	—	✓	✓
Samsung	SPH-M540	✓	N/A	✓	N/A	NG	✓	✓	✓
Samsung	Vibrant SGH-T959	✓	✓	—	—	✓	✓	✓	✓
Samsung	Galaxy Beam i8530	✓	✓	✓	N/A	✓	—	✓	✓
Sharp	703	✓	✓	—	—	✓	—	—	—
Sharp	825SH	✓	✓	—	N/A	✓	—	✓	✓
Sharp	923SH	✓	✓	—	N/A	✓	—	✓	✓
Sharp	SH906iTV	✓	✓	—	N/A	✓	—	N/A	N/A
Siemens	SL75	✓	✓	—	✓	✓	—	✓	✓
SoftBank	001SH	✓	✓	—	—	✓	—	✓	✓
SoftBank	007SH	✓	✓	—	—	—	✓	✓	✓
SoftBank	101F	✓	✓	—	—	✓	✓	✓	✓
SoftBank	101N	✓	✓	—	—	—	✓	✓	✓
SoftBank	102SH	✓	✓	—	—	—	✓	✓	✓
SoftBank	103SH	✓	✓	—	—	—	✓	✓	✓
SoftBank	104SH	✓	✓	—	—	—	✓	✓	✓
SoftBank	106SH	✓	✓	—	—	✓	✓	✓	✓
SoftBank	107SH	✓	✓	—	—	✓	✓	✓	✓
SoftBank	201F	✓	✓	—	—	N/A	✓	✓	✓
SoftBank	201M	✓	✓	✓	—	N/A	✓	✓	✓
SoftBank	iPhone 3G	✓	✓	—	—	—	✓	✓	✓
SoftBank	iPhone 3GS	✓	✓	✓	—	—	✓	✓	✓
SoftBank	iPhone 4	✓	✓	✓	—	—	✓	✓	✓
SoftBank	iPhone 4S	✓	✓	✓	—	—	✓	✓	✓
SoftBank	iPhone5	✓	✓	✓	—	—	✓	✓	✓

Sony Ericsson	Arc	✓	✓	✓	—	✓	✓	✓	✓
Sony Ericsson	C510	✓	✓	✓	✓	✓	✓	✓	✓
Sony Ericsson	C702	✓	✓	✓	✓	✓	✓	✓	✓
Sony Ericsson	C902	✓	✓	✓	✓	✓	✓	✓	✓
Sony Ericsson	C903	✓	✓	✓	✓	✓	✓	✓	✓
Sony Ericsson	C905	✓	✓	✓	✓	✓	✓	✓	✓
Sony Ericsson	C950	✓	✓	—	✓	✓	✓	✓	✓
Sony Ericsson	D750i	✓	✓	—	✓	✓	—	—	—
Sony Ericsson	G502	✓	✓	✓	✓	✓	✓	✓	✓
Sony Ericsson	G700	✓	NG	✓	✓	✓	✓	✓	✓
Sony Ericsson	G900	✓	✓	✓	✓	✓	✓	✓	✓
Sony Ericsson	J105i	✓	✓	—	✓	✓	✓	✓	✓
Sony Ericsson	K530i	✓	✓ ^{*1}	✓	✓	✓	✓	✓	✓
Sony Ericsson	K600i	✓	✓	✓	✓	✓	—	—	—
Sony Ericsson	K610i	✓	✓	✓	✓	✓	✓	✓	✓
Sony Ericsson	K660i	✓	✓	✓	✓	✓	✓	✓	✓
Sony Ericsson	K700i	✓	✓	✓	✓	✓	—	—	—
Sony Ericsson	K800i	✓	✓	✓	✓	✓	✓	✓	✓
Sony Ericsson	K810i	✓	✓	✓	✓	✓	✓	✓	✓
Sony Ericsson	K850i	✓	✓	—	✓	✓	✓	✓	✓
Sony Ericsson	M600i	✓	✓	✓	✓	✓	✓	✓	✓
Sony Ericsson	S302	✓	✓	—	—	✓	—	✓	✓
Sony Ericsson	S500i	✓	✓ ^{*1}	✓	✓	✓	✓	✓	✓
Sony Ericsson	T303	✓	✓	—	—	✓	—	—	—
Sony Ericsson	T650i	✓	✓	✓	✓	✓	✓	✓	✓
Sony Ericsson	W100i	✓	NG	—	—	✓	—	✓	✓
Sony Ericsson	W302	✓	✓	—	—	✓	—	✓	✓
Sony Ericsson	W395	✓	✓	—	—	✓	—	✓	✓
Sony Ericsson	W508	✓	✓	✓	✓	✓	✓	✓	✓
Sony Ericsson	W580i	✓	✓ ^{*1}	✓	✓	✓	✓	✓	✓
Sony Ericsson	W595	✓	✓	✓	✓	✓	✓	✓	✓
Sony Ericsson	W610i	✓	✓	—	✓	✓	✓	✓	✓
Sony Ericsson	W660i	✓	✓ ^{*1}	✓	✓	✓	✓	✓	✓
Sony Ericsson	W760i	✓	✓	✓	✓	✓	✓	✓	✓
Sony Ericsson	W880i	✓	✓	✓	✓	✓	✓	✓	✓
Sony Ericsson	W890i	✓	✓	✓	✓	✓	✓	✓	✓
Sony Ericsson	W900i	✓	✓	✓	✓	✓	—	—	—
Sony Ericsson	W902	✓	✓	✓	✓	✓	✓	✓	✓

Sony Ericsson	P1i	✓	✓	✓	✓	✓	✓	✓	✓	✓
Sony Ericsson	U1i (Satio)	✓	✓	—	✓	✓	✓	✓	✓	✓
Sony Ericsson	U5	✓	✓	—	N/A	✓	—	✓	✓	✓
Sony Ericsson	U10i (Aino)	✓	✓	✓	✓	✓	✓	✓	✓	✓
Sony Ericsson	W960i	✓	✓	✓	✓	✓	✓	✓	✓	✓
Sony Ericsson	X8	✓	✓	—	—	✓	✓	✓ ^{*1}	✓	✓
Sony Ericsson	XPERIA ARC	✓	✓	✓	—	✓	✓	✓	✓	✓
Sony Ericsson	XPERIA ARC S	✓	✓	✓	—	NG	✓	✓	✓	✓
Sony Ericsson	XPERIA ion LT28i	✓	✓	✓	—	NG	—	✓	✓	✓
Sony Ericsson	XPERIA J ST26i	✓	✓	✓	—	✓	✓	✓	✓	✓
Sony Ericsson	XPERIA Miro	✓	✓	✓	—	✓	✓	✓	✓	✓
Sony Ericsson	XPERIA NEO	✓	✓	✓	—	✓	✓	✓	✓	NG
Sony Ericsson	XPERIA NEO LMT25	✓	✓	✓	N/A	✓	✓	✓	✓	✓
Sony Ericsson	XPERIA P LT22i	✓	✓	✓	—	✓	✓	✓	✓	✓
Sony Ericsson	XPERIA pro	✓	✓	✓	—	✓	✓	✓	✓	✓
Sony Ericsson	Xperia ray	✓	✓	✓	—	✓	✓	✓	✓	✓
Sony Ericsson	XPERIA ST23i	✓	✓	✓	—	✓	✓	✓	✓	✓
Sony Ericsson	XPERIA U ST25i	✓	✓	✓	—	✓	✓	✓	✓	✓
Sony Ericsson	XPERIA X1	✓	✓	—	—	✓	✓	✓	✓	✓
Sony Ericsson	XPERIA X2	✓	✓	—	—	✓	—	✓	✓	✓
Sony Ericsson	XPERIA X10	✓	✓	—	—	—	✓	✓	✓	✓
Sony Ericsson	XPERIA X10i	✓	✓	—	—	✓	✓	✓	✓	✓
Sony Ericsson	XPERIA X10 mini pro	✓	✓	—	—	—	—	✓	✓	✓
Sony Ericsson	XPERIA X10 mini	✓	✓	—	—	✓	✓	✓	✓	✓
Sony Ericsson	XPERIA PLAY	✓	✓	✓	—	✓	✓	✓	✓	✓
Sony Ericsson	XPERIA S(LT26i)	✓	✓	✓	—	NG	✓	✓	✓	✓
Sony Ericsson	XPERIA SL LT26ii	✓	✓	✓	—	—	✓	✓	✓	✓
Sony Ericsson	Z1010	✓	✓	✓	✓	✓	—	—	—	—
Sony Ericsson	Z770i	✓	✓	✓	✓	✓	✓	✓	✓	✓
Sony Ericsson	Z800i	✓	✓	✓	✓	✓	—	—	—	—
Toshiba	823T	✓	✓	—	N/A	✓	—	✓	✓	✓
Toshiba	G500	✓	✓	—	—	✓	—	✓	✓	✓
Toshiba	V904T	✓	✓	—	N/A	✓	—	—	—	—
Toshiba	V910T	✓	✓	—	N/A	✓	—	—	—	—
Toshiba	W54T	✓	✓	—	N/A	✓	—	✓	✓	✓
WILLCOM	WX-03S(ENERUS)	✓	✓	—	—	✓	—	—	—	—
WILLCOM	WX-04K	✓	✓	—	✓	✓	✓	✓	✓	✓

✓ : Usable

✓^{*1} : Usable, but not stable.

✓^{*2} : Pairing is possible only with PIN (Personal Identification Number) code "0000".

NG : Function available on the mobile phone but cannot be used.

— : Function unavailable on the mobile phone.

The following is a list of things you should know including various potential issues when using Bluetooth functions. Be sure to read it.

General

- Since Bluetooth is a wireless communication, there may be cases where normal communication is not available depending on signal quality.
- Mobile phone models listed here have been tested and proven compatible by JVC as of Aug, 2013. If any modification has been applied to the mobile phone after our test, available functions may be different from the content listed here.
- Compatibility status shown above is applicable to the unit that we have used for the test. This does not guarantee that all units of the same mobile phone model will offer the same result.
- Some functions may require operations from the mobile phone. Refer to the mobile phone's instructions for details.
- Model names or model numbers are trademarks or registered trademarks of their respective holders.
- Connection with a PC is not supported.
- Number of characters available for each information display depends on the JVC head unit's display. All characters may not be displayed in all cases.
- Depending on the setting or status of the connected mobile phone, some functions may not work properly. For example on certain mobile phones, making a call via JVC head unit is possible only while the mobile phone's display is showing the standby screen.
- All functions related to Bluetooth depends on the version of JVC head unit, the software version of the mobile phone connected with JVC head unit, and the applications installed in the mobile phone.

Pairing

- A JVC head unit may not be able to be located depending on the signal condition quality or mobile phone setup.
- A JVC head unit may not be able to be located during while Auto Connect is enabled. In this case, try again after setting "Auto Connect" to "OFF".
- If the display does not show "Connected" or "Pairing Completed" after the Pairing process is completed, Pairing has failed. If so, please delete Pairing on both the JVC unit and the device to be connected then retry Pairing again.
- While establishing Bluetooth connection with one mobile phone, pairing with another mobile phone may fail. In this case, try again after disconnecting.
- On certain mobile phones, the PIN (Personal Identification Number) code is fixed. (e.g. "0000") The default PIN code of JVC head unit is "0000".
- The pairing and connection process depends on the mobile phone. Please check the operation of your mobile phone in advance.
- Paired device name may not display properly.
- Compatibility Check Mode will not work if Bluetooth connection has already been established with another mobile phone.
- Compatibility Check Mode only checks the connection of Bluetooth profiles, and does not guarantee all the functions of Hands-Free Call and Audio Streaming features.

Connection

- There may be cases where automatic connection is not established properly even if "Auto Connect" is set to "On". In this case, try again after confirming the settings of your mobile phone or turning the power off and then turning on again for both the JVC unit and your mobile phone.
- On certain mobile phones, Bluetooth function may not work properly while two mobile phones are connected to Hands-Free Profile.
- Connection status displayed on the JVC head unit may not necessarily correspond to that of the connected mobile phone.

Dialing, Receiving (HFP)

- Noise or loud echo may occur during a voice call.
- On certain mobile phones, Switching Conversation on HFP (between head unit and mobile phone) may not work properly or noise may occur when switching.
- A JVC head unit and certain mobile phones may not always match up properly (e.g. mobile phone doesn't end the phone call even if the JVC head unit ends the display of call function, etc.).
- On certain mobile phones, the other party's phone number and name may not be displayed properly at call reception, while talking, or while talking to a call-waiting caller. (e.g. Plus sign (+) may not be displayed depending on the mobile phone.)
- Call-waiting is not supported.
- Talking at the same time using two connected phones is not supported.
- Some mobile phones can not reject an incoming call because the mobile phone does not support this function.

Ring Tone in Phone

- Even if "Ring Tone" is set to "In Phone", the ring tone that is heard when receiving a call may not necessarily be identical to that set on the mobile phone.

Voice Recognition

- There may be cases where voices cannot be recognized easily or operation is not stable depending on the mobile phone model or environment in the car. If it is difficult to recognize your voice keyword, you can control mic input level or noise/echo cancel setting on the receiver to improve.
- On certain mobile phones, the status of Voice Recognition between JVC head unit and mobile phone may not always match up properly.

Phonebook Function (OPP, PBAP)

- On certain mobile phones, Phonebook and Call History may not be identical between those of the JVC head unit and mobile phone. (e.g. Plus sign (+) may not be displayed depending on the mobile phone.)
- If your mobile phone supports OPP, it is capable of transferring your phonebook data from the mobile phone to JVC head unit manually. The following operations are necessary to initiate/terminate phonebook transfer:
 1. Set the receiver to the transfer-wait mode (screen display example: "Ready to Receive 000/400").
 2. Use the mobile phone to transfer desired phonebook entries you desire (individual entries, groups, and/or the entire phonebook can be selected and transferred; actual operation may vary depending on the type of mobile phone used).
 3. Terminate the transfer-wait mode from the receiver (when maximum memory capacity is reached, the receiver will automatically terminate the transfer-wait mode).
- Before transferring phonebook data via OPP, it is necessary to delete pairing on both some mobile phones and the JVC head unit.
- Text characters of phone numbers that can be recognized a JVC head unit are numerals 0 to 9, + (plus), *(asterisk), a to d, A to D and # (pound) signs. Unrecognizable characters will be skipped; make sure the correct number has been displayed before making a call from the phonebook.
- Even if your mobile phone supports PBAP, it may be not available to access the phonebook/call history data memorized in your mobile phone or SIM card depending on your mobile phone's specification. Additionally, after HFP connection is established between JVC head unit and your mobile phone, it will require time to allow phonebook/call history data browsing on the JVC head unit automatically (depending on your mobile phone and the number of phonebook/call history.)
- International call may not be done from phonebook/call history of JVC head unit.

SMS (Short Message Service) or Text Message Receipt Notification

- Depending on the mobile phone, notification may not reach the JVC head unit.

Battery remainder/ Signal strength indication

- Signal strength indication and battery remainder indication do not necessarily correspond to those on the mobile phone.
- JVC head unit is not compatible with Bluetooth audio players' signal strength and/or battery remainder indications.

Audio (A2DP, AVRCP)

- Sound may be interrupted or playback speed may vary. For example, during music streaming, the sound may be interrupted while HFP is connecting/disconnecting, or auto connect is active.
 - Some mobile phones compatible with HFP only may stream music data. In this case, the sound quality will be low.
 - Some mobile phones may stream the key operation sound via HFP. In this case, this sound may interrupts music streaming.
 - When starting and ending the call, music or noise may be heard for a moment if music streaming is active in the background.
 - During music streaming, the Key/Play Mode Controls or Displays related to AVRCP may not function as they should depending on the device.
 - During Bluetooth audio playback, when the sound is interrupted by a call reception, call making, or voice recognition operation, playback may not resume automatically even after interruption ends.
 - There may be cases where sound cannot be played from the JVC head unit even though the music is being played back on the mobile phone.
 - To prevent distortion or static noise, adjust the volume level on the wirelessly connected device before use.
-