



**Federal Aviation  
Administration**

**Aeronautical Information Services**

# **Aeronautical Chart Users' Guide**

## **Terminal Procedure Publications**

**Effective as of 21 May 2020**



# Table of Contents

<b>WHAT'S NEW?</b>	<b>5</b>
VFR CHARTS	5
IFR ENROUTE CHARTS	5
TERMINAL PROCEDURE PUBLICATIONS (TPPS)	5
<b>INTRODUCTION</b>	<b>7</b>
KEEP YOUR CHARTS CURRENT	7
EFFECTIVE DATE OF CHART USERS' GUIDE AND UPDATES	7
COLOR VARIATION	7
REPORTING CHART DISCREPANCIES	7
<b>U.S. TERMINAL PROCEDURES PUBLICATION</b>	<b>9</b>
EXPLANATION OF TPP TERMS AND SYMBOLS	9
INSTRUMENT APPROACH PROCEDURE CHART	10
PLANVIEW	17
NAVAIDS	20
MISSED APPROACH INFORMATION	26
PROFILE VIEW	27
LANDING MINIMUMS	30
AIRPORT SKETCH	32
AIRPORT DIAGRAMS	33
DEPARTURE PROCEDURES (DPs)	35
STANDARD TERMINAL ARRIVAL (STARs) CHARTS	36
CHARTED VISUAL FLIGHT PROCEDURE (CVFP) CHARTS	36
<b>U.S. TERMINAL PROCEDURES PUBLICATION SYMBOLS</b>	<b>37</b>
GENERAL INFORMATION	37
LEGEND - STANDARD TERMINAL ARRIVAL (STAR) CHARTS - DEPARTURE PROCEDURE (DP) CHARTS	37
APPROACH LIGHTING SYSTEM	38
AIRPORT DIAGRAM/AIRPORT SKETCH	40
PLANVIEW SYMBOLS	41
PROFILE VIEW	43
COLD TEMPERATURE AIRPORTS	44
<b>REFERENCES</b>	<b>45</b>
<b>ABBREVIATIONS</b>	<b>47</b>
A	47
B	47
C	47
D	47
E	47
F	47
G	47
H	48

# Table of Contents

I.....	48
J.....	48
K.....	48
L.....	48
M.....	48
N.....	48
O.....	48
P.....	48
R.....	49
S.....	49
T.....	49
U.....	49
V.....	49
W.....	49

## WHAT'S NEW?

*Update as of 21 May 2020*

The following charting items have been added to the Online Chart Users' Guide since the Guide was last published on 26 March 2020:

### VFR CHARTS

#### Revision of Trauma Center and Hospital Helipad Designations on Helicopter Route Charts

Beginning with the 18 June 2020 effective date, users' will begin to see Trauma Center and Hospital Helipad designations charted under the broader heading of Medical Center.

---

### IFR ENROUTE CHARTS

#### Coincident Airways/Routes with Unusable Segment

No Changes Applied

---

### TERMINAL PROCEDURE PUBLICATIONS (TPPS)

No Changes Applied



# INTRODUCTION

This Chart Users' Guide is an introduction to the Federal Aviation Administration's (FAA) aeronautical charts and publications. It is useful to new pilots as a learning aid, and to experienced pilots as a quick reference guide.

The FAA is the source for all data and information utilized in the publishing of aeronautical charts through authorized publishers for each stage of Visual Flight Rules (VFR) and Instrument Flight Rules (IFR) air navigation including training, planning, and departures, enroute (for low and high altitudes), approaches, and taxiing charts. Digital charts are available online at:

- VFR Charts - [https://www.faa.gov/air\\_traffic/flight\\_info/aeronav/digital\\_products/vfr/](https://www.faa.gov/air_traffic/flight_info/aeronav/digital_products/vfr/)
- IFR Charts - [https://www.faa.gov/air\\_traffic/flight\\_info/aeronav/digital\\_products/ifr/](https://www.faa.gov/air_traffic/flight_info/aeronav/digital_products/ifr/)
- Terminal Procedures Publication - [http://www.faa.gov/air\\_traffic/flight\\_info/aeronav/digital\\_products/dtpp/](http://www.faa.gov/air_traffic/flight_info/aeronav/digital_products/dtpp/)
- Chart Supplements - [https://www.faa.gov/air\\_traffic/flight\\_info/aeronav/digital\\_products/dafd/](https://www.faa.gov/air_traffic/flight_info/aeronav/digital_products/dafd/)

Paper copies of the charts are available through an FAA Approved Print Provider. A complete list of current providers is available at [http://www.faa.gov/air\\_traffic/flight\\_info/aeronav/print\\_providers/](http://www.faa.gov/air_traffic/flight_info/aeronav/print_providers/)

The FAA Aeronautical Information Manual (AIM) Pilot/Controller Glossary defines in detail, all terms and abbreviations used throughout this publication. Unless otherwise indicated, miles are nautical miles (NM), altitudes indicate feet above Mean Sea Level (MSL), and times used are Coordinated Universal Time (UTC).

The Notices to Airmen Publication (NOTAM) includes current Flight Data Center (FDC) NOTAMs. NOTAMs alert pilots of new regulatory requirements and reflect changes to Standard Instrument Approach Procedures (SIAPs), flight restrictions, and aeronautical chart revisions. This publication is prepared every 28 days by the FAA, and is available by subscription from the Government Printing Office. For more information on subscribing or to access online PDF copy, [http://www.faa.gov/air\\_traffic/publications/notices/](http://www.faa.gov/air_traffic/publications/notices/)

In addition to NOTAMs, the Chart Supplement and the Safety Alerts/Charting Notices page of the Aeronautical Information Services website are also useful to pilots

## KEEP YOUR CHARTS CURRENT

Aeronautical information changes rapidly, so it is important that pilots check the effective dates on each aeronautical chart and publication. To avoid danger, it is important to always use current editions and discard obsolete charts and publications.

To confirm that a chart or publication is current, refer to the next scheduled edition date printed on the cover. Pilots should also check Aeronautical Chart Bulletins and NOTAMs for important updates between chart and publication cycles that are essential for safe flight.

## EFFECTIVE DATE OF CHART USERS' GUIDE AND UPDATES

All information in this guide is effective as of **21 May 2020**. All graphics used in this guide are for educational purposes. Chart symbology may not be to scale. Please do not use them for flight navigation.

The Chart Users' Guide is updated as necessary when there is new chart symbology or changes in the depiction of information and/or symbols on the charts. When there are changes, it will be in accordance with the 56-day aeronautical chart product schedule.

## COLOR VARIATION

Although the digital files are compiled in accordance with charting specifications, the final product may vary slightly in appearance due to differences in printing techniques/processes and/or digital display techniques.

## REPORTING CHART DISCREPANCIES

Your experience as a pilot is valuable and your feedback is important. We make every effort to display accurate information on all FAA charts and publications, so we appreciate your input. Please notify us concerning any requests for changes, or potential discrepancies you see while using our charts and related products.

*FAA, Aeronautical Information Services  
1305 East-West Highway  
SSMC4, Room 3424  
Silver Spring, MD 20910-3281*

*Telephone Toll-Free 1-800-638-8972  
Aeronautical Inquires: [https://www.faa.gov/air\\_traffic/flight\\_info/aeronav/aero\\_data/Aeronautical\\_Inquiries/](https://www.faa.gov/air_traffic/flight_info/aeronav/aero_data/Aeronautical_Inquiries/)*





# U.S. TERMINAL PROCEDURES PUBLICATION

The U.S. Terminal Procedures Publication (TPPs) includes the Instrument Approach Procedures (IAPs), Departure Procedures (DPs) charts, Standard Terminal Arrival (STAR) charts, Charted Visual Flight Procedure (CVFP) charts, and Airport Diagrams. Also included are Takeoff Minimums, (Obstacle) Departure Procedures, Diverse Vector Area (RADAR Vectors), RADAR and Alternate Minimum textual procedures.

## EXPLANATION OF TPP TERMS AND SYMBOLS

The information and examples in this section are based primarily on the IFR (Instrument Flight Rules) Terminal Procedures Publication (TPP). The publication legends list aeronautical symbols with a brief description of what each symbol depicts. This section will provide more detailed information of some of the symbols and how they are used on TPP charts.

FAA Terminal charts are prepared in accordance with specifications of the Interagency Air Committee (IAC) and their supporting technical groups for the purpose of standardization, which are approved by representatives of the Federal Aviation Administration (FAA), and the Department of Defense (DoD).

The Terminal Procedure Publication is made up of the following charts:

- Instrument Approach Procedure (IAP) Charts
- Airport Diagrams
- Departure Procedures (DP)
- Standard Terminal Arrival (STAR) Charts
- Charted Visual Flight Procedure (CVFP) Charts

## FAA Chart Users' Guide - Terminal Procedures Publication (TPP) - Terms

Margin Identification Information  
Briefing Strip Information  
Planview  
Missed Approach Information

Profile View  
Landing Minimums  
Airport Sketch



Margin Identification Information

CITY, STATE

AL-0000 (FAA)

00000

RNAV (GPS) RWY 00

AIRPORT NAME (XXX)

VOL, DD MMM YYYY to DD MMM YYYY

YYY WWW DD of YYY WWW DD 'YY

CITY, STATE

Orig DDMMYY

00°00'N-000°00'W

AIRPORT NAME (XXX)

RNAV (GPS) RWY 00

The margin identification at the top, bottom, and sides of the chart provides information about the airport location, procedure identification, and chart currency. The charts are organized by city first, then airport name and state, with the exception of military charts, which are organized by airport name. Going from the top of the chart, reading from left to right, and going down the chart, Margin Identification Information is organized in the following way.

The hash marks along the top and bottom borders of military Instrument Approach Charts indicate that the procedure was designed using High Altitude criteria contained in FAA Order 8260.3. These procedures are designed to support high performance military aircraft operations and are not intended for civilian use.



## Top Margin Information:

The city and state with which the airport is associated is located on both the top and bottom margins.

At the center of the top margin is the FAA numbering system. This Approach and Landing (AL) number is followed by the organization responsible for the procedure in parentheses, e.g., AL-18 (FAA), AL-227 (USAF).

WASHINGTON, DC		AL-5326 (FAA)		15344
WAAS CH <b>56239</b> <b>W34B</b>	APP CRS <b>326°</b>	Rwy Idg TDZE Apt Elev	<b>3715</b> <b>182</b> <b>192</b>	<b>RNAV (GPS) RWY 34L</b> MANASSAS RGNL/HARRY P DAVIS FIELD (HEF)

The procedure title is located on both the top and bottom margins. It is derived from the type of navigational facility that is providing the final approach course guidance. The title is abbreviated, e.g. ILS, RNAV, NDB, etc. For airports with parallel runways and simultaneous approach procedures, "L", "R" or "C" follows the runway number to distinguish between left, right, and center runways.

The airport name is shown on both the top and bottom margins below the procedure title. The airport identifier is shown in parentheses following the airport name. Airports outside the contiguous United States will be shown with the FAA designated identifier followed by the ICAO location identifier.

The Date of Latest Revision is shown on the top margin above the procedure title. The Date of Latest Revision identifies the Julian date the chart was last revised for any reason. The first two digits indicate the year, the last three digits indicate the day of the year (001 to 365/6).

WASHINGTON, DC		AL-5326 (FAA)		15344
WAAS CH <b>56239</b> <b>W34B</b>	APP CRS <b>326°</b>	Rwy Idg TDZE Apt Elev	<b>3715</b> <b>182</b> <b>192</b>	<b>RNAV (GPS) RWY 34L</b> MANASSAS RGNL/HARRY P DAVIS FIELD (HEF)
<div>15344</div> <div>Year Day of Year</div>				

## Side Margin Information:

The side margins show the volume identification, i.e. SW-3, followed by the current issue date and the next issue date, e.g. SW-3, 21 JUL 2016 to 15 SEP 2016.

## Bottom Margin Information:

The FAA Procedure Amendment Number, located on the left bottom margin below the City, State, represents the most current amendment of a given procedure. The Procedure Amendment Effective Date represents the AIRAC cycle date on which the procedure amendment was incorporated into the chart. Updates to the amendment number and effective date represent procedural/criteria revisions to the charted procedure, e.g., course, fix, altitude, minima, etc.

Example: Original Procedure Date

WASHINGTON, DC Orig 10DEC15	MANASSAS RGNL/HARRY P DAVIS FIELD (HEF) 38°43'N-77°31'W	<b>RNAV (GPS) RWY 34L</b>
--------------------------------	--	---------------------------

Example: Amendment Procedure Date

WASHINGTON D.C. Amdt 1B 28MAY15	MANASSAS RGNL/HARRY P DAVIS FIELD (HEF) 38°43'N-77°31'W	<b>RNAV (GPS) RWY 16R</b>
------------------------------------	--	---------------------------

The coordinates for the airport reference point are located at the center of the bottom margin.

## BRIEFING STRIP INFORMATION

At the top of every TPP is the Briefing Strip which consists of three stacked strips of information immediately above the planview. Information varies depending upon the type of procedure.

WASHINGTON, DC		AL-443 (FAA)		15288	
LOC/DME I-DCA		APP CRS		Rwy Ldg 6869	
<b>Top Briefing Strip</b>		ILS or LOC/DME RWY 1		RONALD REAGAN WASHINGTON NATIONAL (DCA)	
Chen 36		Apt Elev 14		ALSIF-2	
Circuling NA NE of Rwy 15-33		<b>Middle Briefing Strip</b>		MISSED APPROACH: Climb to 420 then climbing left turn to 2100 on DCA VOR/DME R 325 to GTN NDB/INT/DCA 5.9 DME and hold	
Night landing Rwy 4 1.5 NA		For inoperative ALSIF-2, increase S-LOC 1 Cat C and D visibility to 1.5 miles.			
ATIS 132.65		POTOMAC APP CON 119.85 124.2 269.0 (EAST)		<b>Communications Briefing Strip</b>	
		VORTAC 119.1 257.6		CLNC DEL 128.25	

### Top Briefing Strip

The top briefing strip contains procedural information in three separate boxes, in the following sequence from left to right:

<b>1</b>	<b>2</b>	<b>3</b>
NAVAID Info	APP CRS	Rwy Ldg TDZE Apt Elev

- Box 1: Primary Procedure Navigation Information:** The primary navigation type (VOR, LOC, NDB, RNAV, etc.) with its identifier and frequency/channel. If applicable, WAAS, the WAAS Channel Number, and the WAAS Reference Path indicator are shown stacked top to bottom. If the primary navigation type is GBAS, then the following information is shown, stacked top to bottom: GBAS, CH NNNN, RPI XXXX. If there is not a primary Navigation Box required, the first box is removed.
- Box 2: Final Approach Course Information.** The inbound Approach Course (APP CRS) is shown.
- Box 3: Runway Landing Information:** Stacked top to bottom, the runway landing distance (Rwy Ldg), the Touchdown Zone Elevation (TDZE), and the Airport Elevation (Apt Elev) are shown. Rwy Ldg may not reflect full runway length due to displaced thresholds and shorter declared distances.

Top Briefing Strip Examples:

Ground based NAVAID:

DENVER, COLORADO		16147	
LOC/DME I-DZG		ILS or LOC RWY 7	
<b>111.55</b>		DENVER INTL (DEN)	
Chen 52(Y)			
APP CRS			
<b>082°</b>			
Rwy Ldg			
<b>12000</b>			
TDZE			
<b>5352</b>			
Apt Elev			
<b>5434</b>			

RNAV-WAAS:

DENVER, COLORADO		16147	
WAAS		RNAV (GPS) Y RWY 16R	
CH <b>82628</b>		DENVER INTL (DEN)	
<b>W16B</b>			
APP CRS			
<b>173°</b>			
Rwy Ldg			
<b>16000</b>			
TDZE			
<b>5326</b>			
Apt Elev			
<b>5434</b>			

GBAS:

NEWARK, NEW JERSEY		AL-285 (FAA)	
GBAS		18256	
CH <b>22727</b>		GLS RWY 4L	
<b>G04A</b>		NEWARK LIBERTY INTL (EWR)	
APP CRS			
<b>039°</b>			
Rwy Ldg			
<b>8460</b>			
TDZE			
<b>10</b>			
Apt Elev			
<b>17</b>			

No Primary NAVAID box:

DENVER, COLORADO

APP CRS <b>173°</b>	Rwy Idg TDZE Apt Elev	<b>12000</b> <b>5339</b> <b>5434</b>
------------------------	-----------------------------	--

16147  
**RNAV (RNP) Z RWY 17L**  
DENVER INTL (DEN)

Circling Approach:

ROANOKE, VIRGINIA

VOR ODR <b>114.9</b>	APP CRS <b>236°</b>	Rwy Idg TDZE Apt Elev	<b>N/A</b> <b>N/A</b> <b>1175</b>
-------------------------	------------------------	-----------------------------	---

AL-349 (FAA)

16203  
**VOR/DME-A**  
ROANOKE-BLACKSBURG RGNL/WOODRUM FIELD (ROA)

Sidestep Procedure:

LOS ANGELES, CALIFORNIA

LOC/DME I-OSS <b>108.5</b> Chan <b>22</b>	APP CRS <b>251°</b>	Rwy Idg TDZE Apt Elev	24R <b>8925</b> <b>120</b> <b>126</b>	24L <b>9483</b> <b>121</b> <b>126</b>
---	------------------------	-----------------------------	--	--

AL-237 (FAA)

16315  
**ILS or LOC RWY 24R**  
LOS ANGELES INTL (LAX)

## Middle Briefing Strip

The middle briefing strip may contain information in up to three separate boxes, when available, in the following sequence from left to right:



- Box 1: Notes Box:** contains procedure notes, Equipment/Requirements Notes box and Takeoff, Alternate, RADAR, WAAS, and/or Cold Weather indicators (details provided below under Notes Box).
- Box 2: Approach Lighting System Box (when applicable):** shows the approach lighting system name and charting icon. Multiple approach lighting systems may be shown for approaches that have straight-in minimums for parallel runways.
- Box 3: Missed Approach Procedure Text Box:** The full textual description of the missed approach procedure is provided here.

## Notes Box

### Procedure Equipment Requirements Notes Box

Users will begin to see Performance-Based Navigation (PBN) Requirements and ground-based Equipment Requirements prominently displayed in separate, standardized notes boxes. For procedures with PBN elements, the PBN box will contain the procedure's navigation specification(s); and, if required: specific sensors or infrastructure needed for the navigation solution; any additional or advanced functional requirements; the minimum Required Navigation Performance (RNP) value and any amplifying remarks. Items listed in this PBN box are REQUIRED. The separate Equipment Requirements Box will list ground-based equipment requirements.

RADAR required for procedure entry.	
▼	Simultaneous approach authorized with Rwy 21L. # RVR 1800 authorized with use of FD or AP or HUD to DA.

On procedures with both PBN elements and ground-based equipment requirements, the PBN requirements box will be listed first.

PBN Requirements Box	From WINRZ, LIBGE: RNAV-1 GPS, RNAV-1GPS from MAP to YARKU.
Equipment Requirements Box	DME required for LOC only.
Standard Procedure Notes Box	<div>▼ Circling to Rwy 25 NA at night. #For inop MALSIR increase S-ILS 16R all cats visibility to 2½ SM.</div>

Notes Symbols

Several different symbols may appear within the Notes Box:

- ▼

Non-Standard Takeoff minimums and/or Departure Procedures exist. Refer to Takeoff Minimum, (Obstacle) Departure Procedures, and Diverse Vector Area (RADAR VECTORS) section of the TPP
- ▲

Non-standard IFR alternate minimums exist. Refer to IFR Alternate Airport Minimums section of the TPP.
- ▲ NA

Alternate minimums are not authorized due to unmonitored facility or absence of weather reporting service.
- W

WAAS (Wide Area Augmentation System)
- ❄-12°C

Cold Temperature Restricted Airport

The negative **W** within a black square box symbol shown in the Notes section below any “A” or “T” Symbol indicates that outages of the WAAS (Wide Area Augmentation System) vertical guidance may occur daily at this location due to initial system limitations. WAAS NOTAMs for vertical outages are not provided for this approach. Use LNAV minima for flight planning at these locations, whether as a destination or alternate. For flight operations at these locations, when the WAAS avionics indicate that LNAV/VNAV or LPV service is available, then vertical guidance may be used to complete the approach using the displayed level of service. Should an outage occur during the procedure, reversion to LNAV minima may be required.

When ❄-12°C appears in the Notes section below all other symbols it indicates a cold temperature altitude correction is required at that airport when the reported temperature is at or below the published restricted temperature. Advise ATC when altitude correction is made in the intermediate and/or missed approach segment. Reporting corrections to ATC in final segment is not required. See Notices to Airmen Publication (NTAP) Graphic Notices General for complete list of published airports, temperature/s, segments and procedure information.

When “ASR”, “PAR” or “ASR/PAR” appear in the Note section immediately below the “T” and “A” symbols it indicates there are published Radar Instrument Approach Minimums. Where radar is approved for approach control service, it is used not only for radar approaches (Airport Surveillance Radar [ASR] and Precision Approach Radar [PAR]) but is also used to provide vectors in conjunction with published non-radar approaches based on radio NAVAIDs (ILS, VOR, NDB, TACAN). Radar vectors can provide course guidance and expedite traffic to the final approach course of any established IAP or to the traffic pattern for a visual approach.

## Bottom Briefing Strip (Communications Information)

The communications briefing strip contains communication information when available, in separate boxes, listed from left to right in the order that they would be used during arrival with the tower frequency box bolded:


ATIS XXXXX	APP CON XXXX XXXX	<b>TOWER XXXX XXXX</b>	GND CON XXXXX	CLNC DEL XXXXX	UNICOM XXXXX
---------------	----------------------	----------------------------	------------------	-------------------	-----------------

- ATIS, AFIS (AK Only) or ASOS/AWOS frequencies (when available, ATIS or AFIS will be the only weather frequency/s published)
- the Approach Control (APP CON) name and frequencies; when the approach service is provided by other than Approach Control, e.g. FSS (Radio), Tower, Center, the appropriate air traffic facility call name is provided.
- the Control Tower (TWR) name and frequencies, to include Precision Radar Monitoring (PRM) and frequency
- Ground Control (GND CON) frequencies
- Clearance Delivery (CLNC DEL) frequencies; where a Control Tower does not exist or is part-time, a remoted CLNC DEL may be listed.
- Controller Pilot Data Link Communication (CPDLC)
- Ground Communications Outlet (GCO) frequency
- Common Traffic Advisory Frequency (CTAF), shown in parentheses when shares a frequency, e.g. UNICOM 122.8 (CTAF)
- UNICOM or AUNICOM frequency

Note: Part-time operations will be annotated with a star. Check Chart Supplement for times of operation.








Complex IAP Example with RF Legs


- **Feeder Routes** (highlighted in blue - See Simple IAP Example on previous page) may be used to provide a transition from the enroute structure to the IAF.
- **Initial Approach** (highlighted in purple in examples above) is the segment between the initial approach fix (IAF) and the intermediate fix (IF) or the point where the aircraft is established on the intermediate course or final approach course.
- **Intermediate Approach** (highlighted in yellow in examples above) is the segment between the intermediate fix or point and the final approach fix.
- **Final Approach Course** (highlighted in red in the examples above) is the segment between the final approach fix or point and the runway, airport, or missed approach point.
- **Missed Approach** (highlighted in green in the example above) begins at the MAP and continues until the designated fix or waypoint. Missed Approach Procedure Track is shown as a hash marked line in the planview. If the missed approach fix falls outside of the area of the planview it will be shown in a separate box in the planview.

- **DME arcs or Radius-to-Fix legs (RF)** are shown as smooth arcs from a designated start point to a designated terminus.




- **Visual segment** - Instrument approach procedures, including Copter approach procedures, that terminate or have missed approaches prior to the airport/heliport, and are authorized to proceed visually, will depict the visual flight path by a dashed line symbol from the missed approach point to the airport.

On RNAV charts where the visual track may only apply to a specific line of minima, the visual procedure track line will not be shown in the planview. There will be a note directed to that portion of the procedure track.



### Traditional (NAVAID) Approach




### RNAV Approach

NAVAIDS

NAVAIDs used on ground based charts will show the appropriate symbol accompanied by a data box that contains the facility name, frequency, identifier and Morse code. A NAVAID box with a heavy line indicates the primary NAVAID used for the approach.

NAVAIDs used on GPS based charts show the appropriate symbol identified with the name and identifier.



Localizer Depiction

The localizer is depicted in the Planview using the following symbol. The size of the charted localizer symbol does not serve as an indication of the service volume.



Restrictive Airspeeds Along the Procedure Track

Restrictive airspeeds along the procedure track are shown paired with their respective fix/facility.


Type	Description	Example
Recommended Speed	Recommended speed is depicted with no lines above or below it	180K
Minimum Speed	Minimum speed is depicted as a number with a line below it	120K
Maximum Speed	Maximum speed is depicted as a number with a line above it	250K
Mandatory Speed	Mandatory speed is depicted as a number with a line above and below it	175K

Altitudes

Restrictive altitudes along the procedure track are shown paired with their respective fix/ facility. Minimum, Maximum, Mandatory and Recommended Altitudes are shown.

Type	Description	Example
Recommended Altitude	Recommended altitude is depicted with no lines above or below it	3000
Minimum Altitude	Minimum altitude is depicted as a number with a line below it	<u>2500</u>
Maximum Altitude	Maximum altitude is depicted as a number with a line above it	<u>4300</u>
Mandatory Altitude	Mandatory altitude is depicted as a number with a line above and below it	<u>5500</u>
Mandatory Block Altitude	Mandatory block altitude is depicted with a minimum and a maximum altitude.	<u>5000</u> <u>3000</u>

Altitudes that are shown along a route are minimum altitudes.




Holding Patterns and Procedure Turns



Holding Patterns are used for many reasons, including deteriorating weather or high traffic volume. Holding might also be required following a missed approach. Each holding pattern has a fix, a direction to hold from the fix, and an airway, bearing, course, radial, or route on which the aircraft is to hold. These elements, along with the direction of the turns, define the holding pattern.



Missed Approach



Hold In-Lieu of Procedure Turn




Arrival

If a holding pattern has a non-standard speed restriction, it will be depicted by an icon with the limiting air speed shown inside the holding pattern symbol. These elements, along with the direction of the turns, define the holding pattern. If two types of holds are located at the same point, the procedural holding pattern will be shown in-lieu of arrival or missed approach holding patterns. Timing or distance limits for Hold-in-lieu of Procedure Turn Holding Patterns will be shown.


Waypoints designated as a holding fix are shown as fly-by, without the circle around the symbol. However, in the event the holding fix/waypoint is also designated in some other part of the procedure (i.e., IAF) with a fly-over function, then the holding fix/waypoint will be charted as a fly-over point.

A procedure turn (PT) is the maneuver prescribed to perform a course reversal to establish the aircraft inbound on an intermediate or final approach course. The procedure turn or hold-in-lieu-of procedure turn is a required maneuver when it is depicted on the approach chart. However, the procedure turn or the hold-in-lieu-of PT is not permitted when the symbol “NoPT” is depicted on the initial segment being flown, when a RADAR VECTOR to the final approach course is provided, or when conducting a timed approach from a holding fix. The procedure turn will be shown in the planview and in the profile of the chart.



## FAA Chart Users' Guide - Terminal Procedures Publication (TPP) - Terms

The primary approach airport is shown to scale by a pattern of all the runways. Airports other than the primary approach airport may be shown with an airport pattern and name when in close proximity to the primary airport.




### Relief (Terrain Features)

Terrain is depicted in the planview portion of all IAPs at airports that meet the following criteria:

- If the terrain within the planview exceeds 4,000 feet above the airport elevation, or
- If the terrain within a 6.0 nautical mile radius of the Airport Reference Point (ARP) rises to at least 2,000 feet above the airport elevation.

When an airport meets either of the above criteria, terrain will be charted by use of contours, spot elevations, and gradient tints of brown on all IAPs for that airport. Contour layers will be shown in no more than five brown tints, with consecutively darker tints used for consecutively higher elevation contour layers.




## Hydrography (Water)

Water Depiction is depicted in grey, in the planview portion of IAPs. See previous example. The following hydrographic features are shown:

- Oceans
- Significant rivers and streams
- Significant lakes - If only one river or one small lake is involved, not located in the immediate airport vicinity, the hydrographic information requirement may be waived.

## International Boundary

When the planview includes a boundary of another country the International boundaries are shown by a dashed line. International boundaries are identified with country name within the country area.




## Obstacles (Man-made, Terrain and Vegetation)


Obstacles are shown as  $\Delta$  when they are man-made or vegetation or as a  $\bullet$  when they are terrain. The highest obstacle, whether man-made or terrain is depicted with a bolder and larger symbol along with larger elevation font size. Any obstacle which penetrates a slope of 67:1 emanating from any point along the centerline of any runway shall be considered for charting within the area shown to scale. Obstacles specifically identified by the approving authority for charting shall be charted regardless of the 67:1 requirement.

Unverified obstacles shall be indicated by a doubtful accuracy symbol  $\pm$  following the elevation value.


On non-precision approaches, obstacles should be considered when determining where to begin descent from the MDA.



Highest Point - Obstacle



Highest Point - Terrain




Unverified Obstacle - Obstacle

## Special Use Airspace (SUA)

SUAs consists of that airspace wherein activities must be confined because of their nature, or wherein limitations are imposed upon aircraft operations that are not a part of those activities, or both. These are prohibited areas, restricted areas, warning areas, Military Operations Areas (MOAs), and alert areas. SUA that falls within the area of coverage of the instrument approach procedure chart are shown only when designated by the approving authority.

## Air Defense Identification Zone (ADIZ)


ADIZ is an area of airspace in which the identification, location, and control of aircraft is required in the interest of national security. When designated by the approving authority, ADIZ boundaries that fall within the area of coverage of the chart are shown. CONTIGUOUS U.S. ADIZ






## Minimum Safe Altitude (MSA)

MSAs are published for emergency use on IAP charts. MSAs appear in the planview of all IAPs except on approaches for which a Terminal Arrival Area (TAA) is used. The MSA is based on the primary NAVAID, waypoint, or airport reference point on which the IAP is predicated. The MSA depiction on the approach chart contains the identifier of the NAVAID/waypoint/airport used to determine the MSA altitudes. MSAs are expressed in feet above mean sea level and normally have a 25 NM radius; however, this radius may be expanded to 30 NM if necessary to encompass the airport landing surfaces. Ideally, a single sector altitude is established and depicted on the planview of approach charts; however, when necessary to obtain relief from obstructions, the area may be further sectorized and as many as four MSAs established. When established, sectors may be no less than 90° in spread. MSAs provide 1,000 feet clearance over all obstructions but do not necessarily assure acceptable navigation signal coverage.



## Terminal Arrival Areas (TAAs)


The TAA icons will be positioned in the planview relative to their relationship to the procedure. The icon will not have feeder routes, airways, or radar vectors depicted. The TAA provides a transition from the enroute structure to the terminal environment with little required pilot/air traffic control interface for aircraft equipped with Area Navigation (RNAV) systems. A standard TAA has three areas: straight-in, left base, and right base. The arc boundaries of the three areas of the TAA are published portions of the approach. A TAA provides minimum altitudes with standard obstacle clearance when operating within the TAA boundaries. TAAs are primarily used on RNAV approaches but may be used on an ILS approach when RNAV is the sole means for navigation to the IF; however, they are not normally used in areas of heavy concentration of air traffic.





### Example of Standard TAA

Non-standard TAAs may also be published; i.e., one base leg, no base legs.




Example of Non-Standard TAA

### Helicopter (Copter) Procedures

Copter procedures may contain either a visual or a VFR segment. Visual segments are depicted using the dashed line symbol below.




VFR Segments are not depicted with a line, but include the reference bearing and distance information at the endpoint of the VFR Segment, when provided, as shown below.



Example of Copter with VFR Segment (JFK)

When a visual flight path or VFR segment is required from the MAP to the heliport or alighting area, and as necessary for an explicit portrayal, an inset of the MAP area may be provided. This MAP area will depict significant landmark visual features. The procedure track, value and distance to the MAP and the visual segment and value to the landing point shall be shown within this inset. If it is a VFR segment, the reference bearing and distance text will be shown at the landing point.



Example of Copter with Inset

## MISSED APPROACH INFORMATION

Missed approach information is shown in 3 locations on the chart:


- The Middle Briefing Strip - The complete textual missed approach instructions are provided at the top of the approach chart in the middle pilot briefing strip.
- The Planview - The missed approach track is drawn using a thin, hash marked line with a directional arrow. If the missed approach fix is off the chart, the missed approach track shall extend to the chart border.

.....➤  
Missed Approach

- The Profile Box - Missed Approach Icons will be depicted in the upper left or upper right of the profile box. The Missed Approach Icons are intended to provide quick, at a glance intuitive guidance to the pilot, to supplement the textual missed approach instructions in the briefing strip. Space permitting, all textual missed approach instructions will be graphically depicted in sequence. If space does not permit the depiction of all missed approach icons, only the first four icon boxes will be shown.


Example Missed Approach Icons	Missed Approach Text
<div> <div>13000 ↑ RIL R-250</div> <div>TEKGU INT RIL 19</div> <div>EKR R-179</div> <div>WOKPA EKR 44.2</div> </div>	MISSED APPROACH: Climb to 13000 on RIL VOR/DME R-250 to TEKGU INT/RIL 19 DME and on EKR VOR/DME R-179 to WOKPA/EKR 44.2 DME and hold, continue climb-in-hold to 13000.
<div> <div>8000 ↖ SVC R-128</div> <div>Reverse Course</div> <div>SVC ☐</div> </div>	MISSED APPROACH: Climbing left turn to 8000 via SVC R-128, then reverse course to SVC VOR/DME and hold.

A profile diagram of the instrument approach procedure is shown below the planview. The published descent profile and graphical depiction of the vertical path using those facilities, intersections, fixes, etc. identified in the procedure to the runway are shown. A profile view of the procedure track is shown. The approach track begins toward the top of the primary facility line, unless otherwise dictated by the procedure, and shall descend to where the final approach ends and the missed approach begins.




## Precision Approaches

On precision approaches, the glideslope (GS) intercept altitude is illustrated by a zigzag line and an altitude. This is the minimum altitude for GS interception after completion of the procedure turn. Precision approach profiles also depict the GS angle of descent, threshold crossing height (TCH) and GS altitude at the outer marker (OM) or designated fix.




## Non-Precision Approaches

On nonprecision approaches, the final segment begins at the Final Approach Fix (FAF) which is identified with the Maltese cross symbol ✕. When no FAF is depicted, the final approach point is the point at which the aircraft is established inbound on the final approach course. Stepdown fixes may also be provided between the FAF and the airport for authorizing a lower minimum descent angle (MDA) and are depicted with the fix or facility name and a dashed line. On RNAV procedures without precision minima i.e., DAs, the approach track descends to the MDA or VDP point, thence horizontally to the missed approach point. On non-RNAV procedures without precision minima, the horizontal segment is shown from the VDP, when it exists, or the MDA when there is no VDP, and a vertical glide angle/TCH is provided.



## Visual Descent Point (VDP)

The Visual Descent Point (VDP), is shown by a bold letter "V" positioned above the procedure track and centered on the accompanying dashed line. (See example below.) The VDP is a defined point on the final approach course of a non-precision straight-in approach procedure from which normal descent from the MDA to the runway touchdown point may be commenced.



## FAA Chart Users' Guide - Terminal Procedures Publication (TPP) - Terms

Vertical Descent Angle (VDA)  $\rightarrow 3.00^\circ \geq$   
Threshold Crossing Height (TCH)  $\rightarrow$  TCH 40

Proceed VFR from MAP

OPNIC

2.8 nm

The diagram illustrates two different flight paths for a runway approach. The left side, labeled 'Traditional (NAVAID) Approach', shows a path starting from a 9000 ft altitude, turning 307° to a 7700 ft altitude, then 127° to a 7700 ft altitude, and finally 097° to a 7700 ft altitude. The right side, labeled 'RNAV Approach', shows a path starting from a 6700 ft altitude, turning 243° to a 6600 ft altitude, then 238° to a 5800 ft altitude, and finally 058° to a 6600 ft altitude. The RNAV path includes a 5 NM Holding Pattern and a 1.3 NM distance to RW23. The diagram also includes a table of altitudes and a table of distances.

Altitude	CPN
9000	CPN

Altitude	GESBE	243° tr	PUREE	LNNAV/VNAV - Fly visual 238° 1.8 NM, when using Alliance altimeter setting fly visual 238° 2.1 NM.
6700	GESBE	243° tr	PUREE	LNNAV/VNAV - Fly visual 238° 1.8 NM, when using Alliance altimeter setting fly visual 238° 2.1 NM.

## 29

### 34:1 Surface Clear Stipple Symbol

On RNAV approach charts, a small shaded arrowhead shaped symbol from the end of the VDA to the runway indicates that the 34:1 Obstacle Clearance Surface (OCS) for the visual segments is clear of obstacles. (See example in VDP Section.)

## LANDING MINIMUMS

The landing minimums section is positioned directly below the profile. This section gives the pilot the lowest altitude and visibility requirements for the approach. There are two types of landing minimums: Straight-in landing or Circling. Straight-in landing minimums are the MDA and visibility, or DH and visibility, required for a straight-in landing on a specified runway. Circling minimums are the MDA and visibility required for the circle-to-land maneuver.

The minimums for straight-in and circling are located under each aircraft category. When there is not a division line between minimums for each category, the minimums apply to two or more categories.

**LANDING MINIMA FORMAT**

In this example airport elevation is 1179, and runway touchdown zone elevation is 1152.

CATEGORY	A	B	C	D
S-ILS 27	1352/24		200 (200-½)	
S-LOC 27	1440/24	288	(300-½)	1440/50 288 (300-1)
CIRCLING	1540-1 361 (400-1)	1640-1 461 (500-1)	1640-1½ 461 (500-1½)	1740-2 561 (600-2)

**COPTER MINIMA ONLY**

CATEGORY	COPTER
H-176°	680-½ 363 (400-½)

**Annotations:**

- DA:** Decision Altitude
- Visibility (RVR 100's of feet):** 24, 288, 461, 561
- Aircraft Approach Category:** A, B, C, D
- HAT/HATh:** Height Above Touchdown
- MDA:** Minimum Descent Altitude
- HAA:** Height Above Airport
- Visibility in Statute Miles:** 400-1, 500-1, 500-1½, 600-2
- Copter Approach Direction:** H-176°
- Height of MDA/DA Above Landing Area (HAL):** 50, 34, 1½, 2
- No circling minimums are provided**
- All weather minimums in parentheses not applicable to Civil Pilots. Military Pilots refer to appropriate regulations.**

**Additional Labels:**

- Straight-in ILS to Runway 27
- Straight-in with Glide Slope Inoperative or not used to Runway 27

A second category of straight-in minimums called "sidestep" may be depicted where parallel runways exist.

CATEGORY	A	B	C	D
S-ILS 24R	320/18 200 (200-½)			
S-LOC 24R	460/24 340 (400-½)			460/40 340 (400-¾)
SIDESTEP RWY 24L	580/50 459 (500-1)			580-1½ 459 (500-1½)

The terms used to describe the minimum approach altitudes differ between precision and nonprecision approaches. Precision approaches use DH, which is referenced to the height above touchdown elevation (HAT). Nonprecision approaches use MDA, referenced to "feet MSL." The MDA is also referenced to HAT for straight-in approaches, or height above airport (HAA) for circling approaches. The figures listed parenthetically are for military operations and are not used in civil aviation.

The visibility values are shown after the DA/DH or MDA. They are provided in statute miles or runway visual range (RVR). RVR is reported in hundreds of feet. If the visibility is in statute miles, there is an altitude number, hyphen, whole or fractional number, e.g. 530-1. This indicates 530 feet MSL and 1 statute mile of visibility. The RVR value is separated from the minimum altitude with a slash, e.g., 1540/24. This indicates 1540 feet MSL and RVR of 2400 feet. When an RVR value is shown, the comparable statute mile equivalent is shown within the military minimums in parentheses as shown in the examples above. This value is determined from the Comparable Values of RVR and Visibility table located in the TPP Legend.

Comparable Values of RVR and Visibility

The following table shall be used for converting RVR to ground or flight visibility. For converting RVR values that fall between listed values, use the next higher RVR value; do not interpolate. For example, when converting 4800 RVR, use 5000 RVR with the resultant visibility of 1 mile.

RVR (feet)	Visibility (SM)	RVR (feet)	Visibility (SM)	RVR (feet)	Visibility (SM)	RVR (feet)	Visibility (SM)
1600	¼	2400	½	3500	¾	5500	1
1800	½	2600	½	4000	¾	6000	1¼
2000	½	3000	¾	4500	¾		
2200	½	3200	¾	5000	1		

When a reference mark (\*, \*\*, #, etc.) is shown on a line of minimums, the qualifying footnote is provided in the notes section.

FALMOUTH, MASSACHUSETTS

AL-10362 (FAA)

17061

LOC/DME I-BNX  
110.75  
Chan 44(Y)


APP CRS  
322°

Rwy Idg  
TDZE 116  
Apt Elev 130

ILS or LOC RWY 32

CAPE COD COAST GUARD AIR STATION (F'MH)

Circling NA northeast of Rwy 14 and northwest of Rwy 23.  
\*RVR 1800 authorized with use of FD or AP or HUD to DA.

MALSR  


MISSED APPROACH: Climb to 1400 then climbing left turn to 2000 on heading 112° and I-BNX localizer SE course to HAGTU INT/I-BNX 6.6 DME and hold.

ATIS  
120.475 236.825


CAPE APP CON ★  
284.6

COAST GUARD TOWER  
128.425

GND CON  
124.15 275.8

ELEV 130

TDZE 116



1400

2000

hdg 112°

I-BNX SE crs

HAGTU INT

HAGTU INT I-BNX 6.6

MVY 15

One Minute Holding Pattern

1700

142°

322°

1700

GS 3.00°

TCH 50

CATEGORY

A

B

C

D

S-ILS 32 \*

316/24

200 (200-½)

S-LOC 32

520/24

404 (400-½)

520/40

404 (400-¾)

CIRCLING

580-1

450 (500-1)

640-1

510 (600-1)

640-1½

510 (600-1½)

680-2

550 (600-2)

REIL Rwy 5 and 14

HIRL Rwy 5-23 and 14-32

FAF to MAP 4.2 NM

Knots 60 90 120 150 180

Min:Sec 4:12 2:48 2:06 1:41 1:24

FALMOUTH, MASSACHUSETTS

Amdt 1B 21JUL16

CAPE COD COAST GUARD AIR STATION (F'MH)

41°40'N-70°31'W










ILS or LOC RWY 32


## FAA Chart Users' Guide - Terminal Procedures Publication (TPP) - Terms

The approaches using standard circling approach areas can be identified by the absence of the  on the circling line of minima.

### Apply Expanded Circling Approach Maneuvering Airspace Radius Table

The airport sketch is a depiction of the airport with emphasis on runway pattern and related information, positioned in either the lower left or lower right corner of the chart to aid pilot recognition of the airport from the air and to provide some information to aid on ground navigation of the airport. The runways are drawn to scale and oriented to true north. Runway dimensions (length and width) are shown for all active runways.

Hard Surface	Other Than Hard Surface	Metal Surface	Closed Runway	Under Construction
				
Stopways, Taxiways, Parking Areas	Displaced Threshold	Closed Pavement	Water Runway	
				



Other information concerning lighting, final approach bearings, airport beacon, obstacles, control tower, NAVAIDs, helipads may also be shown.

The airport elevation is shown enclosed within a box in the upper left corner of the sketch box and the touchdown zone elevation (TDZE) is shown in the upper right corner of the sketch box. The airport elevation is the highest point of an airport's usable runways measured in feet from mean sea level. The TDZE is the highest elevation in the first 3,000 feet of the landing surface. Circling only approaches will not show a TDZE.



Runway Declared Distance Information

Runway declared distance information when available will be indicated by **D** and is shown to the right of the airport elevation in the sketch box. Declared distances for a runway represent the maximum distances available and suitable for meeting takeoff and landing distance performance requirements.


Runway Lights

Notes regarding approach lighting systems are shown at the bottom of the sketch box. Runway lights (HIRL) (MIRL) (LIRL) (TDZL)(TDZ/CL) shall be indicated by a note, e.g. HIRL Rwy 9-27.

Other approach lighting is shown on the airport sketch as a symbol on the side of the runway where they are actually located. Symbols that are shown in negative indicate pilot-controlled lighting.

Runway centerline lights (CL) are installed on some precision approach runways to facilitate landing under adverse visibility conditions. They are located along the runway centerline and are spaced at 50 foot intervals. Runways with CL are shown in a negative dot pattern through the middle of the solid runway as illustrated in the airport sketch to right.

Runway centerline lights will be indicated by a note only when paired with TDZL, e.g., TDZ/CL Rwys 6 and 24.



Time/Distance Table


When applicable, a Time/Distance Table is provided below the airport sketch. The table provides the distance and time that is required from the final approach fix to the missed approach point for select groundspeeds.

Base Information (Copter Approaches Only)

Base Information, as required and necessary to identify the MAP area and in the vicinity of the landing area shall be provided. Information shall be limited to and depict significant visual landmark features at and surrounding the MAP area and the heliport/pad of intended landing.

AIRPORT DIAGRAMS


Airport Diagrams are specifically designed to assist in the movement of ground traffic at locations with complex runway/taxiway configurations. Airport Diagrams are not intended for use in approach and landing or departure operations. An airport diagram assists pilots in identifying their location on the airport, thus reducing requests for “progressive taxi instructions” from controllers.



## Airport Diagram Features:










1. Runways
  - a. complete with magnetic headings (including magnetic variation and epoch year) and identifiers.
  - b. Runways under construction shall also be shown.
  - c. Runway dimensions, displaced thresholds, runway end elevations.
  - d. Runway surface composition
  - e. Weight bearing capacity (landing gear configuration or Pavement Classification Number)
  - f. Land and Hold Short (LAHSO) lines, ILS hold lines, Localizer/Glide Slope Critical Areas.
  - g. Arresting Gear. To include Engineered Materials Arresting System (EMAS).
2. Taxiways, with identifiers. Taxiways under construction shall also be shown.
3. Hot Spot locations.
4. Parking areas, run-up pads, alert areas, landing pads, "Non-Movement" areas (where pilot is NOT under air traffic control), ramps, aprons and hold pads.
5. Turnarounds, blast pads, stopways, overruns, and clearways (include dimensions when known).
6. Large tanks, including fueling area.
7. Control towers (include tower height).
8. Airport beacon.
9. Helicopter pads.
10. Radar reflectors.
11. Highest obstruction within diagram boundary.
12. Any building that pilot can taxi to.  
Other buildings to include terminal/administration and Base operations, fire station, NWS, AFSS, FAA, FSDO, ANG, USCG, FBO.
13. Comm Frequencies.

Note: Star when used in the Comm Frequencies indicates part-time status. Check Chart Supplement for times of operation.



## Runway Construction

Runway construction is depicted as follows:

Hard Surface	Other Than Hard Surface	Metal Surface	Closed Runway	Under Construction
				
Stopways, Taxiways, Parking Areas	Displaced Threshold	Closed Pavement	Water Runway	
				

## Hot Spots

Hot Spots (HS) are a runway safety related problem area or intersection on an airport. Typically it is a complex or confusing taxiway/taxiway or taxiway/runway intersection. A confusing condition may be compounded by a miscommunication between a controller and a pilot, and may cause an aircraft separation standard to be compromised. The area may have a history of surface incidents or the potential for surface incidents.

Hot Spots are indicated on the Airport Diagram with a brown open circle or polygon leadered to a Hot Spot number, e.g., HS 1. The number corresponds to a listing and description on the Hot Spot page in the front the TPP. More information and location of Hot Spots can be found at [http://www.faa.gov/airports/runway\\_safety/hotspots/hotspots\\_list/](http://www.faa.gov/airports/runway_safety/hotspots/hotspots_list/).

## DEPARTURE PROCEDURES (DPs)

Departure Procedures (DPs) are designed specifically to assist pilots in avoiding obstacles during the climb to the minimum enroute altitude, and/or airports that have civil IFR takeoff minimums other than standard. There are two types of DPs: Obstacle Departure Procedures (ODPs), printed either textually or graphically and Standard Instrument Departures (SIDs), always printed graphically. SIDs are primarily designed for system enhancement and to reduce pilot/controller workload, and require ATC clearance. ODPs provide obstruction clearance via the least onerous route from the terminal area and may be flown without ATC clearance. All DPs provide the pilot with a safe departure from the airport and transition to the enroute structure.


Generally, DP charts are depicted “not to scale” due to the great distances involved on some procedures or route segments. A “to scale” portrayal may be used if readability is assured.

The DP will show the departure routing, including transitions to the appropriate enroute structure. All routes, turns, altitudes, NAVAIDs, facilities forming intersections and fixes, and those facilities terminating the departure route are shown. A textual description of the departure procedure is also provided. For RNAV DPs, the transition text consists of the transition name and associated computer code. On non-RNAV DPs, the transition text will also include the description of all turns, altitudes, radials, bearings and facilities/fixes needed to guide the user from the common departure point to the terminating facility fix.

Copter DPs may also include a visual or VFR segment. Visual segments are depicted using the dashed line symbol below.



VFR Segments are not depicted with a line, but include the reference bearing and distance information at the endpoint of the VFR Segment, when provided, as shown below.



(H)

Example of Copter with VFR Segment

## STANDARD TERMINAL ARRIVAL (STARs) CHARTS

STARs are pre-planned Instrument Flight Rule (IFR) air traffic control arrival procedures for pilot use in graphic and/or textual form. STARs depict prescribed routes to transition the aircraft from the enroute structure to a fix in the terminal area from which an instrument approach can be conducted. STARs reduce pilot/controller workload and air-ground communications, minimizing error potential in delivery and receipt of clearances.

STAR charts generally shall be depicted 'not to scale' due to the great distances involved on many procedures and route segments. A 'to scale' depiction may be used only if readability is assured.

The STAR will show the arrival routing, including transitions from the appropriate enroute structure. All routes, turns, altitudes, NAVAIDs, facilities forming intersections and fixes, and those facilities/fixes terminating or beginning the arrival route shall be shown in the graphic depiction. A textual description of the arrival procedure is also provided. For RNAV STARs, transition text will consist of the transition name and associated computer code. For non-RNAV STARs, the transition text will also include a description of all turns, altitudes, radials, bearings and facilities/fixes needed to guide the user from the entry point to the common facility/fix.

## CHARTED VISUAL FLIGHT PROCEDURE (CVFP) CHARTS

CVFPs are charted visual approaches established for environmental/noise considerations, and/or when necessary for the safety and efficiency of air traffic operations. The approach charts depict prominent landmarks, courses, and recommended altitudes to specific runways. CVFPs are designed to be used primarily for turbojet aircraft. CVFPs are not instrument approaches and do not have missed approach segments.

CVFPs are named for the primary landmark and the specific runway for which the procedure is developed, such as: RIVER VISUAL RWY 18, STADIUM VISUAL RWY 24. The CVFP charts are divided into planview and notes sections separated by a bar scale in 1 NM increments. The planview of the CVFP includes the portrayal of visual approach procedures information, such as landmarks, NAVAIDs, visual track, hydrography, special use airspace and cultural features, as applicable.

CVFPs originate at or near, and are designed around, prominent visual landmarks and typically do not extend beyond 15 flight path miles from the landing runway. Visual tracks start at a geographical point or landmark where the procedure must be flown visually to the airport. The visual track is indicated by a dashed line. Visual tracks may include the track value, distance and minimum or recommended altitudes.


# U.S. TERMINAL PROCEDURES PUBLICATION SYMBOLS

## GENERAL INFORMATION

Symbols shown are for the Terminal Procedures Publication (TPP) which includes Standard Terminal Arrival (STARs) Charts, Departure Procedures (DPs), Instrument Approach Procedures (IAP) and Airport Diagrams.

## LEGEND - STANDARD TERMINAL ARRIVAL (STAR) CHARTS - DEPARTURE PROCEDURE (DP) CHARTS

LEGEND 19059



LEGEND 19059

## FAA Chart Users' Guide - Terminal Procedures Publication (TPP) - Symbols

## INSTRUMENT APPROACH PROCEDURES (CHARTS)

### APPROACH LIGHTING SYSTEM - UNITED STATES

A dot "•" portrayed with approach lighting letter identifier indicates sequenced flashing lights (F) installed with the approach lighting system e.g., (A<sub>1</sub>). Negative symbology, e.g., (A<sub>1</sub>), (V) indicates Pilot Controlled Lighting (PCL).

## 38

21 MAY 2020 to 18 JUN 2020

### APPROACH LIGHTING SYSTEM (Continued)

LEGEND 18256

## INSTRUMENT APPROACH PROCEDURES (CHARTS)


### APPROACH LIGHTING SYSTEM - UNITED STATES

Approach lighting and visual glide slope systems are indicated on the airport sketch by an identifier, (A<sub>2</sub>), (V) etc.

A dot "•" portrayed with approach lighting letter identifier indicates sequenced flashing lights (F) installed with the approach lighting system e.g., (A<sub>1</sub>). Negative symbology, e.g., (A<sub>1</sub>), (V) indicates Pilot Controlled Lighting (PCL).

PRECISION APPROACH  
PATH INDICATOR


## PAPI



Legend: ■ White ■ Red

② PULSATING VISUAL APPROACH SLOPE INDICATOR


**PVASI**



**CAUTION:** When viewing the pulsating visual approach slope indicators in the pulsating white or pulsating red sectors, it is possible to mistake this lighting aid for another aircraft or a ground vehicle. Pilots should exercise caution when using this type of system.

(V<sub>1</sub>) "T"-VISUAL APPROACH  
SLOPE INDICATOR


"T"-VASI



"T" ON BOTH SIDES OF RWY  
ALL LIGHTS VARIABLE WHITE.  
CORRECT APPROACH SLOPE-  
ONLY CROSS BAR VISIBLE.  
UPRIGHT "T"- FLY UP.  
INVERTED "T"- FLY DOWN.  
RED "T"- GROSS  
UNDERSHOOT.

TRI-COLOR VISUAL APPROACH  
SLOPE INDICATOR

## TRCV




**CAUTION:** When the aircraft descends from green to red, the pilot may see a dark amber color during the transition from green to red.

V5

## ALIGNMENT OF ELEMENTS SYSTEMS

**APAP**



Painted panels which may be lighted at night.  
To use the system the pilot positions the aircraft  
so the elements are in alignment.

21 MAY 2020 to 18 JUN 2020

21 MAY 2020 to 18 JUN 2020

FAA Chart Users' Guide - Terminal Procedures Publication (TPP) - Symbols

LEGEND 18256



AIRPORT DIAGRAM/AIRPORT SKETCH

19339

LEGEND

INSTRUMENT APPROACH PROCEDURES (CHARTS)

**Runways**

Hard Surface	Other Than Hard Surface	Stopways, Taxiways, Parking Areas	Metal Surface

Closed Runway	Closed Surface	Under Construction	Water Runway

ARRESTING GEAR: Specific arresting gear systems; e.g., BAK12, MA-1A etc., shown on airport diagrams, not applicable to Civil Pilots. Military Pilots refer to appropriate DOD publications.

uni-directional    bi-directional    Jet Barrier

ARRESTING SYSTEM (EMAS)

**REFERENCE FEATURES**

Displaced Threshold.....	
Hot Spot .....	
Runway Holding Position Markings.....	
Buildings.....	
24-Hour Self-Serve Fuel ##.....	
Tanks.....	
Obstructions.....	
Airport Beacon #.....	
Runway	
Radar Reflectors.....	
Control Tower #.....	

# When Control Tower and Rotating Beacon are co-located, Beacon symbol will be used and further identified as TWR.

## A fuel symbol is shown to indicate 24-hour self-serve fuel available, see appropriate Chart Supplement for information.

**NOTE:**  
All new and revised airport diagrams are shown referenced to the World Geodetic System (WGS) (noted on appropriate diagram), and may not be compatible with local coordinates published in FLIP. (Foreign Only)

Runway Weight Bearing Capacity/or PCN Pavement Classification Number is shown as a codified expression. Refer to the appropriate Supplement/Directory for applicable codes e.g., RWY 14-32 PCN 80 F/D/X/U S-75, D-185, 2S-175, 2D-325

**AIRPORT DIAGRAM/AIRPORT SKETCH**

Helicopter Alighting Areas

Negative Symbols used to identify Copter Procedures landing point.....

**NOTE:**  
Landmark features depicted on Copter Approach insets and sketches are provided for visual reference only.

Runway TDZ elevation.....TDZE 123

Runway Slope.....0.3% DOWN  
0.8% UP  
(shown when runway slope is greater than or equal to 0.3%)

**NOTE:**  
Runway Slope measured to midpoint on runways 8000 feet or longer.

U.S. Navy Optical Landing System (OLS) "OLS" location is shown because of its height of approximately 7 feet and proximity to edge of runway may create an obstruction for some types of aircraft.

Approach light symbols are shown in the Flight Information Handbook.

Airport diagram scales are variable.

True/magnetic North orientation may vary from diagram to diagram

Coordinate values are shown in 1 or 1/2 minute increments. They are further broken down into 6 second ticks, within each 1 minute increments.

Positional accuracy within ±600 feet unless otherwise noted on the chart.

Runway length depicted is the physical length of the runway (end-to-end, including displaced thresholds if any) but excluding areas designated as stopways.

A symbol is shown to indicate runway declared distance information available, see appropriate Chart Supplement for distance information.

The diagram shows a runway layout with various features labeled: HS 1, Runway End Elevation, ELEV 164, Runway Dimensions (9000 X 200), Runway Slope (0.7% UP), FIELD ELEV 174, Displaced Threshold, Runway Identification, Runway Heading (023.2°), Visual Screen, EMAS, and Movement Area Dimensions (1000 X 200).

SCOPE

Airport diagrams are specifically designed to assist in the movement of ground traffic at locations with complex runway/taxiway configurations. Airport diagrams are not intended to be used for approach and landing or departure operations. For revisions to Airport Diagrams: Consult FAA Order 7910.4.

LEGEND



PLANVIEW SYMBOLS

LEGEND 20086 INSTRUMENT APPROACH PROCEDURES (CHARTS)

Procedure Track

Missed Approach

Visual Flight Path

3100 NoPT 5.6 NM to GS Intcpt

045°

Minimum Route Altitude

2000

Feeder Route

155°

Mileage

(15.1)

TERMINAL ROUTES

Procedure Turn  
(Type degree and point of turn optional)

165°

345°

Missed Approach

Hold-in-lieu of Procedure Turn

Arrival

090°

270°

090°

1 min

270°

090°

(IAS)

270°

4 NM

HOLD 8000

HOLDING PATTERNS

Holding pattern with max. restricted airspeed:  
(175K) applies to all altitudes.  
(210K) applies to altitudes above 6000' to and including 14000'.  
Arrival Holding Pattern altitude restrictions will be indicated when they deviate from the adjacent leg.  
Timing or distance limits for Hold-in-lieu of Procedure Turn Holding Patterns will be shown.  
DME fixes may be shown.

Reporting Point

▲ Name (Compulsory)

△ Name (Non-Compulsory)

◆ WAYPOINT (Compulsory)

◆ WAYPOINT (Non-Compulsory)

⊙ FLYOVER POINT

⊕ MAP WP (Flyover)

Computer Navigation Fix (CNF) - No ATC Function  
x (NAME) ("x" omitted when it conflicts with runway pattern)

15 DME Distance From Facility

AUSTN INT

ARC/DME/RNAV Fix

R-198 Radial line and value

LR-198 Lead Radial

LB-198 Lead Bearing

FIXES/ATC REPORTING REQUIREMENTS

175K

120K

250K

180K

Mandatory Airspeed

Minimum Airspeed

Maximum Airspeed

Recommended Airspeed

INDICATED AIRSPEED

110.1

Underline indicates No Voice transmitted on this frequency

Compulsory:

VOR

VORTAC

DME

NDB/DME

VOR/DME

TACAN

NDB

Non-Compulsory:

VOR

VORTAC

DME

NDB/DME

VOR/DME

TACAN

NDB

LOM/LMM (Compass locator at Outer Marker/Middle Marker)

Marker Beacon

Marker beacons that are not specifically part of the procedure.

Localizer (LOC/LDA) Course

Right side shading- Front course; Left side shading- Back Course

SDF Course

LOC/DME

LOC/LDA/SDF Transmitter  
(shown when installation is offset from its normal position off the end of the runway.)

Primary Navaid with Coordinate Values

LIMA

114.5 UM

Chan 92

512°00.80'

W77°07.00'

Secondary Navaid

LMM

LIMA

248 NT

SCOTT

Chan 59

SKE

(112.2)

VHF Paired Frequency

RADIO AIDS TO NAVIGATION

5500

2500

4300

Mandatory Altitude

Minimum Altitude

Maximum Altitude

3000

5000

3000

Recommended Altitude

Mandatory Block Altitude


ALTITUDES

21 MAY 2020 to 18 JUN 2020

21 MAY 2020 to 18 JUN 2020

PLANVIEW SYMBOLS (Continued)

LEGEND 19171 INSTRUMENT APPROACH PROCEDURES (CHARTS)



LEGEND 19171


FAA Chart Users' Guide - Terminal Procedures Publication (TPP) - Symbols

21 MAY 2020 to 18 JUN 2020

21 MAY 2020 to 18 JUN 2020

PROFILE VIEW


LEGEND 18200 INSTRUMENT APPROACH PROCEDURES (CHARTS)



LEGEND 18200

# COLD TEMPERATURE AIRPORTS

## COLD TEMPERATURE AIRPORTS





NOTE: A  -12°C symbol indicates a cold temperature altitude correction is required at this airport when reported temperature is at or below the published temperature. See the following Cold Temperature Error Table to make manual corrections. Advise ATC with altitude correction. Advising ATC with altitude corrections is not required in the final segment. See Aeronautical Information Manual (AIM), Chapter 7, for guidance and additional information. For a complete list, see the "Cold Temperature Airports" link under the Additional Resources heading at the bottom of the following page: [http://www.faa.gov/air\\_traffic/flight\\_info/aeronav/digital\\_products/dtpp/search/](http://www.faa.gov/air_traffic/flight_info/aeronav/digital_products/dtpp/search/)

## COLD TEMPERATURE ERROR TABLE

REPORTED TEMP °C	HEIGHT ABOVE AIRPORT IN FEET													
	200	300	400	500	600	700	800	900	1000	1500	2000	3000	4000	5000
+10	10	10	10	10	20	20	20	20	20	30	40	60	80	90
0	20	20	30	30	40	40	50	50	60	90	120	170	230	280
-10	20	30	40	50	60	70	80	90	100	150	200	290	390	490
-20	30	50	60	70	90	100	120	130	140	210	280	420	570	710
-30	40	60	80	100	120	140	150	170	190	280	380	570	760	950
-40	50	80	100	120	150	170	190	220	240	360	480	720	970	1210
-50	60	90	120	150	180	210	240	270	300	450	590	890	1190	1500

# REFERENCES

There are several references available from the FAA to aid pilots and other interest parties to learn more about FAA Charts and other aspects of aviation.

Publication		FAA Publication ID
	Aeronautical Information Manual (AIM)  URL: <a href="http://www.faa.gov/air_traffic/publications/">http://www.faa.gov/air_traffic/publications/</a>	
	Airplane Flying Handbook  URL: <a href="https://www.faa.gov/regulations_policies/handbooks_manuals/aviation/airplane_handbook/">https://www.faa.gov/regulations_policies/handbooks_manuals/aviation/airplane_handbook/</a>	FAA-H-8083-3A
	Helicopter Flying Handbook  URL: <a href="http://www.faa.gov/regulations_policies/handbooks_manuals/aviation/helicopter_flying_handbook/">http://www.faa.gov/regulations_policies/handbooks_manuals/aviation/helicopter_flying_handbook/</a>	FAA-H-8083-21A
	Instrument Procedures Handbook  URL: <a href="http://www.faa.gov/regulations_policies/handbooks_manuals/aviation/instrument_procedures_handbook/">http://www.faa.gov/regulations_policies/handbooks_manuals/aviation/instrument_procedures_handbook/</a>	FAA-H-8083-16B
	Instrument Flying Handbook  URL: <a href="http://www.faa.gov/regulations_policies/handbooks_manuals/aviation/media/FAA-H-8083-15B.pdf">http://www.faa.gov/regulations_policies/handbooks_manuals/aviation/media/FAA-H-8083-15B.pdf</a>	FAA-H-8083-15B
	Pilot's Handbook of Aeronautical Knowledge  URL: <a href="https://www.faa.gov/regulations_policies/handbooks_manuals/aviation/phak/">https://www.faa.gov/regulations_policies/handbooks_manuals/aviation/phak/</a>	FAA-H-8083-25B
	Remote Pilot - Small Unmanned Aircraft Systems Study Guide  URL: <a href="http://www.faa.gov/regulations_policies/handbooks_manuals/aviation/media/remote_pilot_study_guide.pdf">http://www.faa.gov/regulations_policies/handbooks_manuals/aviation/media/remote_pilot_study_guide.pdf</a>	FAA-G-8082-22



# ABBREVIATIONS

## A

AAF - Army Air Field  
AAS - Airport Advisory Service  
AAUP - Attention All Users Page  
AC - Advisory Circular  
ADF - Automatic Direction Finder  
ADIZ - Air Defense Identification Zone  
ADS - Automatic Dependent Surveillance  
ADS-B - Automatic Dependent Surveillance-Broadcast  
Advstry - Advisory  
AFB - Air Force Base  
AFIS - Automatic Flight Information Service  
AFS - Air Force Station  
AFSS - Automated Flight Service Station  
AGL - Above Ground Level  
AIM - Aeronautical Information Manual  
AIRAC - Aeronautical Information Regulation And Control  
AK - Alaska  
AL - Approach and Landing  
ANG - Air National Guard  
APP - Approach  
APP CON - Approach Control  
APP CRS - Approach Course  
Apt - Airport  
APV - Approaches with Vertical Guidance  
ARP - Airport Reference Point  
ARTCC - Air Route Traffic Control Center  
ASDA - Accelerate-Stop Distance Available  
ASDE-X - Airport Surface Detection Equipment-Model X  
ASOS - Automated Surface Observing Station  
ASR - Airport Surveillance Radar  
ATC - Air Traffic Control  
ATIS - Automatic Terminal Information Service  
ATS - Air Traffic Service  
AUNICOM - Automated Aeronautical Advisory Station  
AWOS - Automated Weather Observing Station

## B

Baro-VNAV - Barometric Vertical Navigation  
BS - Broadcast Station

## C

CAC - Caribbean Aeronautical Chart  
CAT - Category  
CFA - Controlled Firing Areas  
CFR - Code of Federal Regulations  
CH - Channel  
CL - Runway Centerline Lights  
CLNC DEL - Clearance Delivery  
CNF - Computer Navigation Fix  
COP - Changeover Point  
CPDLC - Controller Pilot Data Link Communication  
CRS - Course  
CT - Control Tower

CTAF - Common Traffic Advisory Frequency  
CVFP - Charted Visual Flight Procedure  
CZ - Control Zone (Canada)

## D

DA - Decision Altitude  
DA - Density Altitude  
D-ATIS - Digital Automatic Terminal Information Service  
DH - Decision Height  
DME - Distance Measuring Equipment  
DND - Department of National Defense (Canada)  
DoD - Department of Defense  
DOF - Digital Obstacle File  
DP - Departure Procedure  
DT - Daylight Savings Time  
DVA - Diverse Vector Area

## E

E - East  
EFAS - Enroute Flight Advisory Service  
EFB - Electronic Flight Bag  
Elev - Elevation  
EMAS - Engineered Materials Arresting System

## F

FAA - Federal Aviation Administration  
FAF - Final Approach Fix  
FAP - Final Approach Point  
FAR - Federal Aviation Regulation  
FBO - Fixed-Based Operator  
FIR - Flight Information Region  
FL - Flight Level  
FLIP - Flight Information Publication  
FMS - Flight Management System  
FREQ - Frequency  
FRZ - Flight Restricted Zone  
FSDO - Flight Standards District Office  
FSS - Flight Service Station

## G

GBAS - Ground-Based Augmentation System  
GCO - Ground Communications Outlet  
GLS - GBAS Landing System  
GND - Ground  
GND CON - Ground Control  
GNSS - Global Navigation Satellite System  
GP - Glide Path  
GPS - Global Positioning System  
GS - Glide Slope  
GS - Ground Speed

## H

HAA - Height Above Airport  
HAR - High Altitude Redesign  
HAT - Height Above Touchdown  
HCH - Heliport Crossing Height  
HF - High Frequency  
HIRL - High Intensity Runway Lights  
HS - Hot Spot

## I

IAC - Interagency Air Committee  
IACC - Interagency Air Cartographic Committee  
IAF - Initial Approach Fix  
IAP - Instrument Approach Procedure  
ICAO - International Civil Aviation Authority  
IDT - Identifier  
IF - Intermediate Fix  
IFR - Instrument Flight Rules  
ILS - Instrument Landing System  
IMC - Instrument Meteorological Conditions  
INS - Inertial Navigation System  
IR - Instrument Route (Military)  
IRU - Inertial Reference Unit

## J

JO - Joint Order

## K

KIAS - Knots

## L

LAA - Local Airport Advisory  
LAAS - Local Area Augmentation System  
LAHSO - Land and Hold Short  
LDA - Landing Distance Available  
LDA - Localizer-type Directional Aid  
Ldg - Landing  
LF - Low Frequency  
LIRL - Low Intensity Runway Lights  
LNAV - Lateral Navigation  
LOC - Localizer  
LOM - Locator Outer Marker  
LPV - Localizer Performance with Vertical Guidance  
LRRS - Long Range Radar Station  
LTP - Landing Threshold Point

## M

MAA - Maximum Authorized Altitude  
MAP - Missed Approach Point  
MCA - Minimum Crossing Altitude  
MCAS - Marine Corps Air Station  
MDA - Minimum Descent Altitude  
MDH - Minimum Descent Height

MEA - Minimum Enroute Altitude  
MEF - Maximum Elevation Figure  
MF - Medium Frequency  
MIA - Minimum IFR Altitude  
MIRL - Medium Intensity Runway Lights  
MOA - Military Operations Areas  
MOCA - Minimum Obstruction Clearance Altitude  
MON - Minimum Operational Network  
MORA - Minimum Off-Route Altitude  
MRA - Minimum Reception Altitude  
MSA - Minimum Safe Altitude  
MSL - Mean Sea Level  
MTA - Minimum Turning Altitude  
MTR - Military Training Route  
MVA - Minimum Vector Altitude

## N

N - North  
N/A - Not Applicable  
NA - Not Authorized  
NAAS - Naval Auxiliary Air Station  
NAS - Naval Air Station  
NAS - National Airspace System  
NAV - Naval Air Facility  
NAVAID - Navigational Aid (Ground based)  
NDB - Non-Directional Radiobeacon  
NextGen - Next Generation Air Transportation System  
NFDC - National Flight Data Center  
NFPO - National Flight Procedures Office  
NM - Nautical Mile  
NOAA - National Oceanic and Atmospheric Administration  
NO A/G - No Air-to-Ground Communication  
NOTAM - Notice to Airman  
NoPT - No Procedure Turn  
NPA - Non-Precision Approach  
NTAP - Notices to Airman Publication  
NWS - National Weather Service

## O

OAT - Outside Air Temperature  
OBS - Omni Bearing Selector  
OCA - Ocean Control Area  
OCS - Obstacle Clearance Surface  
ODP - Obstacle Departure Procedure  
OM - Outer Marker  
OROCA - Off Route Obstruction Clearance Altitude

## P

PA - Precision Approach  
PAR - Precision Approach Radar  
PBN - Performance-Based Navigation  
PRM - Precision Runway Monitor  
PT - Procedure Turn  
PTP - Point-to-Point  
Pvt - Private



## R

R - Radial  
 R - Receive  
 R - Restricted Area (Special Use Airspace)  
 RCO - Remote Communications Outlet  
 RF - Radius-to-Fix  
 RNAV - Area Navigation  
 RNP - Required Navigation Performance  
 RNP AR - Required Navigation Performance Authorization  
     Required  
 ROC - Required Obstacle Clearance  
 RP - Right Pattern  
 RVR - Runway Visual Range  
 RVSM - Reduced Vertical Separation Minimum  
 Rwy - Runway

## S

S - South  
 SAAAR - Special Aircraft and Aircrew Authorization  
     Required  
 SAAR - Special Aircraft and Aircrew Requirements  
 SATNAV - Satellite Navigation  
 SDF - Simplified Directional Facility  
 SER - Start End of Runway  
 SFAR - Special Flight Rules Area  
 SFC - Surface  
 SFRA - Special Flight Rules Area  
 SIAPs - Standard Instrument Approach Procedures  
 SID - Standard Instrument Departure  
 SM - Statute Mile  
 SMAR - Special Military Activity Routes  
 SMGCS - Surface Movement Guidance and Control  
     System  
 SOIA - Simultaneous Offset Instrument Approaches  
 SSV - Standard Service Volume  
 STAR - Standard Terminal Arrival Procedure  
 SUA - Special Use Airspace  
 SVFR - Special Visual Flight Rules

## T

T - Transmit  
 TA - Travel Advisory  
 TAA - Terminal Arrival Area  
 TAC - Terminal Area Chart  
 TACAN - Tactical Air Navigation  
 TAS - True Air Speed  
 TCA - Terminal Control Areas (Canada)  
 TCH - Threshold Crossing Height  
 TDZ - Touchdown Zone  
 TDZE - Touchdown Zone Elevation  
 TDZL - Touchdown Zone Lights  
 TDZ/CL - Touchdown Zone/Centerline Lights  
 TERPS - U.S. Standard for Terminal Instrument Procedures  
 TFR - Temporary Flight Restriction  
 TIBS - Telephone Information Briefing Service  
 TIS-B - Traffic Information Service - Broadcast

TOC - Top of Climb  
 TOD - Top of Descent  
 TODA - Takeoff Distance Available  
 TOGA - Takeoff/Go Around  
 TORA - Takeoff Runway Available  
 TPP - Terminal Procedures Publication  
 TRSA - Terminal Radar Service Area  
 TWR - Tower

## U

UC - Under Construction  
 UHF - Ultra High Frequency  
 UIR - Upper Information Region  
 UNICOM - Universal Communications  
 U.S. - United States  
 USA - United States Army  
 USAF - United States Air Force  
 USCG - United State Coast Guard  
 UTA - Upper Control Area

## V

VCOA - Visual Climb Over Airport / Airfield  
 VDA - Vertical Descent Angle  
 VDP - Visual Decent Point  
 VFR - Visual Flight Rules  
 VGSI - Visual Glide Slope Indicator  
 VHF - Very High Frequency  
 VMC - Visual Meteorological Conditions  
 VNAV - Vertical Navigation  
 VOR - VHF Omnidirectional Radio Range  
 VORTAC - VHF Omnidirectional Radio Range/Tactical Air  
     Navigation  
 VPA - Vertical Path Angle  
 VR - Visual Route (Military)

## W

W - Warning Area (Special Use Airspace)  
 W - West  
 WAAS - Wide-Area Augmentation System  
 WAC - World Aeronautical Chart  
 WP - Waypoint  
 WX CAM - Weather Camera (Alaska)