

INSTRUCTIONS FOR ADDING PRIMOS SOUNDS TO BOSS DOGG™, ALPHA DOGG™ AND TURBO DOGG™

Boss Dogg™ Model# 3757

Alpha Dogg™ Model# 3756

Turbo Dogg™ Model# 3755

INSTALLATION:

STEP 1 – Connect Boss / Alpha / Turbo Dogg Speaker to computer (PC or Mac)

- a) Turn OFF Boss / Alpha / Turbo Dogg remote.
- b) Turn ON Boss / Alpha / Turbo Dogg Speaker.
- c) Plug USB connection into speaker (Boss Dogg/ Alpha Dogg located on back of speaker. Turbo Dogg located inside the battery compartment).
- d) Plug USB connection into computer.
- e) Some computers may notify of drive software installation and/or to open Removable Disk drive.

NOTE: It may take a few seconds for your computer to find the Removable Disk drive.



Boss Dogg:




Alpha Dogg:




Turbo Dogg:



STEP 2 – Opening Removable Disk and Creating New Subfolder



a) Open Removable Disk drive on computer.




b) Create a new subfolder (optional) or place the sound in an existing folder or subfolder.


WARNING: DO NOT add sounds or subfolders to the “Hunts” folder. The “Hunts” folder is specially designated for EXPERT HUNTS ONLY.

STEP 3 – Installing Primos Sounds from <http://sounds.primos.com> website

You should receive an email from each order you place at <http://sounds.primos.com> website. The email will inform you that the order is being processed. Once the PayPal payment goes thru, the sounds will be available for download from your sounds account on the website. Go to <http://sounds.primos.com> and use the login credentials you created during checkout.



a) Log in to <http://sounds.primos.com/my-account/> using the login information created during the checkout process or during account registration prior to purchase.



b) Once logged in you will be presented with the “My Account Dashboard”. From here you will see a list of each order placed (Recent Orders) and a list of sounds available to be downloaded (Available Downloads). In order to download sounds for the Boss Dogg™ you must have a Boss Dogg™ serial number registered under “Registered Device(s)”. You can find the serial number by looking in the battery compartment of your caller.™ Boss Dogg™ files will be available under “Boss Dogg™ Downloads”. Alpha Dogg™ and Turbo Dogg™ downloads will be available under “Standard Downloads”. Click on the desired sound to begin downloading it.

NOTE: Each sound will be downloaded individually.

WARNING: “Standard Downloads” will NOT work on the Boss Dogg™ device. You MUST

add your Boss Dogg™ serial number under “Registered Device(s).” The “Boss Dogg Downloads” will then be available.

c) Downloading of files may vary from computer to computer, as well as from browser to browser. You may be prompted to save the file to a specific location. If so DO NOT change the file name. You may save the file to any location on your computer or directly to the Boss Dogg™, Alpha Dogg™ or Turbo Dogg™ device.

WARNING: DO NOT change/rename sound files. This may result in the sound not being listed on the remote display correctly or can keep the sound file from working at all.

WARNING: DO NOT add sounds or subfolders to the “Hunts” folder. The “Hunts” folder is specially designated for EXPERT HUNTS ONLY.


d) Repeat **STEP 3** for each sound file that you would like save to your computer or directly to the device.

□ **NOTE:** If you have trouble downloading Boss Dogg sounds & receive an error that states “**something went wrong please try again. If the problem persists, please contact customer support. ERROR: FAILED TO ENCRYPT FILE**”, go back to “REGISTERED DEVICE” located in your sounds account to be sure you entered the serial number correctly. Be sure there are no letter o’s, the format can only have zero’s. Once the serial number entry is corrected, Boss Dogg sounds should download.

e) **IF** you chose to save the sound files directly to the Boss Dogg™, Alpha Dogg™ or Turbo Dogg™ device then proceed to **STEP 5** to complete the process. Otherwise continue to **STEP 4**.

STEP 4 – Copying Sound Files onto the Boss / Alpha / Turbo Dogg Speaker

- Open the file location where you saved or downloaded the files.
- Copy and Paste the sound files to the desired location.
- Once you have copied the sound files to the Boss Dogg™, Alpha Dogg™ or Turbo Dogg™ device continue to **STEP 5** to complete the process.



WARNING: DO NOT add sounds or subfolders to the “Hunts” folder. The “Hunts” folder is specially designated for EXPERT HUNTS ONLY.

STEP 5 – Safely Disconnect USB/ Removable Disk from Computer

- Close Removable Disk Drive folder and safely disconnect USB by following computers instructions for Safely Remove Hardware and Eject Media.
- Disconnect USB cable from computer and disconnect from Boss Dogg™, Alpha Dogg™, or Turbo Dogg™ Speaker.

STEP 6 – Sync Boss/Alpha/Turbo Dogg Remote with Speaker

- a) With speaker power on, turn ON Boss / Alpha / Turbo Dogg Remote.
- b) Remote will automatically sync with speaker and update new sounds by syncing phase 1 thru 3
- c) Once sync is complete, “Main Menu” will appear on Remote. Remote and speaker are now updated with your purchased sounds and ready for use.
- d) New sounds will be located in “Sounds” and folder you saved them in from **STEP 3**.

Note: This step may take approximately 10 minutes to perform. Keep remote and speaker together during syncing.

For questions email service@primos.com or call customer service at (601) 879-9323 OPTION 3

Visit <http://primos.zendesk.com> to review our Knowledge Base.

Primos Hunting
604 First St., Flora, MS 39071
(601) 879-9323
www.primos.com

PRIMOS[®]
H U N T I N G
SpEAK THE LANGUAGE[®]