

ACCESSORY FITMENT INSTRUCTION

Product

Nissan NP200 Side Bars

Part no.

170018T, BS-170018 TN: 105




60
Minutes

Models : All

Page 1 of 7

Date : 04/04/2018

DIAGRAM



Kit content:

	Qty	Description		Qty	Description
A	8	M8x25 Set Screws	H	8	M6 Hex nuts
B	16	M8x22x1.6 Flat washers	I	4	M10 Hex nuts
C	8	M8 Spring washers	J	4	M10x30x2.5 Flat washers
D	8	M8 hex nuts	K	4	M10 Spring washers
E	8	M6x25 Sets	L	2	Front brackets (PS and DS)
F	16	M6x16x1.6 Flat washers	M	2	Rear brackets (PS and DS)
G	8	M6 Spring washers	N	4	T-bolts

Additional equipment/Material needed for fitment :

	1	Ratchet and spanner set	1	Tectyle
	1	Measuring tape		
	1	Marker		
	1	Drill and 6.5mm Drill bit		
	1	Centre punch and hammer		

Precautions during fitment:

Ensure you have an adequate working space. Requires two people for fitment. Ensure that the correct tools are used with installation

Directions for use:

Read through the fitting instructions before starting fitment.

Fitment Instruction: Nissan NP200 Side Bars

Visual / Graphic Illustration

FIG 1





FIG 2



Step #

Description/Method


FIG 1 shows a basic view of how the brackets mount to the vehicle. Drivers side is shown but do all steps to passengers side as well.

Step 1

Measure the positions for the brackets on the sill of the side of the vehicle. This measurements is taken from the corner of the wheel arch. Shown in FIG 2.

Fitment Instruction: Nissan NP200 Side Bars

Visual / Graphic Illustration



Step #

Description/Method

Step 2


From these measurements you will see plastic covers that need to be removed from the under side of the vehicle for the front and rear brackets. FIG 3.

Step 3


Insert the T-bolts into these holes. FIG 4.

Fitment Instruction: Nissan NP200 Side Bars

Visual / Graphic Illustration




As a double check. Measure from the front of the front bracket to the front of the rear bracket. This measurement must be 1277mm. Adjust brackets to get this measurement.



Step #	Description/Method
Step 4	Mount the brackets to the t-bolts. Make sure the brackets are straight and that the front hole of the bracket lines up with the line that was measured. FIG 5.
Step 5	With the brackets aligned correctly. You will need to mark the centre of the holes, centre punch and drill 6.5mm. FIG 6. Do to the front and back. Apply tectyle to drilled holes.
NOTE - Front brackets	The Drivers side front brackets have a DF cut out in them, passengers side has a PF cut out.
NOTE - Rear brackets	The Drivers side rear brackets have a DB cut out in them, passengers side has a PB cut out.

Fitment Instruction: Nissan NP200 Side Bars

Visual / Graphic Illustration



Step #


Description/Method

Step 6

Mount brackets to the vehicle. Use the kit shown in FIG 7.

Fitment Instruction: Nissan NP200 Side Bars

Visual / Graphic Illustration



Step #

Description/Method

Step 7

Mount the side step to the brackets using the kit shown in fig 8.

Final step

Page 7 of 7

Make sure bar is centralised and tighten all fasteners to specified torque. M8= 22Nm , M10= 42Nm , M6= 9Nm.

