# Technical Information **Proline Promass I 300**

Coriolis flowmeter

**Products** 



## Combines in-line viscosity and flow measurement with a compact, easily accessible transmitter

#### Application

- Measuring principle operates independently of physical fluid properties such as viscosity or density
- Liquid and gas measurement in applications requiring low pressure loss and sensitive handling of the medium

#### Device properties

- Straight, easy-to-clean single-tube system
- TMB® technology
- Titanium measuring tube
- Compact dual-compartment housing with up to 3 I/Os
- Backlit display with touch control and WLAN access
- Remote display available

#### Your benefits

- Energy-saving full bore design enables minimal pressure loss
- Fewer process measuring points multivariable measurement (flow, density, temperature)
- Space-saving installation no inlet/outlet run needs
- Full access to process and diagnostic information numerous, freely combinable I/Os and fieldbuses
- Reduced complexity and variety freely configurable I/O functionality
- Integrated verification Heartbeat Technology



## Table of contents

<b>Document information</b>	I .	Climate class	
<b>Function and system design</b>		Shock resistance	45 45
Measuring system	. 6	Interior cleaning	45 45
Safety	. /		46
Input	. 9	Medium temperature range	
Measured variable		Density	46
Measuring range		Pressure-temperature ratings	46 49
Operable flow range		Flow limit	50
Input signal	10	Pressure loss	50
		System pressure	50
Output	12	Thermal insulation	51
Output and input variants			52
Output signal		Vibrations	52
Ex connection data	18		
Low flow cut off	19	Mechanical construction	53
Galvanic isolation	19		53
Protocol-specific data	19	Dimensions in US units	
		Materials	
Power supply	26	Process connections	
Terminal assignment	26	Surface roughness	75
Device plugs available	26	-	
Pin assignment, device plug $\ldots \ldots \ldots \ldots$		Operability	75
Supply voltage		Operating concept	
Power consumption		Languages	
Current consumption		Local operation	
Power supply failure	27 27	Remote operation	
Potential equalization	34	Service interface	
Terminals	34	Supported operating tools	
Cable entries	35	HistoROM data management	81
Cable specification	35		00
		Certificates and approvals	
Performance characteristics	37	CE mark	
reference operating conditions	37		83
Maximum measured error	I .	Sanitary compatibility	84
Repeatability	39	Functional safety	
Response time	39 39	HART certification	
Influence of ambient temperature		FOUNDATION Fieldbus certification	
Influence of medium pressure		Certification PROFIBUS	
Design fundamentals		Modbus RS485 certification	84
j		Pressure Equipment Directive	85 85
Installation	41	Additional certification	
Mounting location	41		
Orientation	42		-
Inlet and outlet runs	43	Ordering information	86
Special mounting instructions	43	Oracing morniadon	00
Environment	///	Application packages	86
Ambient temperature range	44	Diagnostics functions	
Storage temperature	45	Heartbeat Technology	87

2

Concentration	
Accessories  Device-specific accessories  Communication-specific accessories  Service-specific accessories  System components	87 88 88 89 89
Supplementary documentation	90
Registered trademarks	91

## **Document information**

## Symbols used

## **Electrical symbols**

Symbol	Meaning
===	Direct current
~	Alternating current
$\overline{}$	Direct current and alternating current
<u></u>	Ground connection A grounded terminal which, as far as the operator is concerned, is grounded via a grounding system.
	Protective ground connection A terminal which must be connected to ground prior to establishing any other connections.
\$	<b>Equipotential connection</b> A connection that has to be connected to the plant grounding system: This may be a potential equalization line or a star grounding system depending on national or company codes of practice.

## $Communication\ symbols$

Symbol	Meaning
<b></b>	Wireless Local Area Network (WLAN) Communication via a wireless, local network.
8	Bluetooth Wireless data transmission between devices over a short distance.
•	<b>LED</b> Light emitting diode is off.
举	LED Light emitting diode is on.
	<b>LED</b> Light emitting diode is flashing.

## Symbols for certain types of information

Symbol	Meaning
<b>✓</b>	Permitted Procedures, processes or actions that are permitted.
<b>✓</b> ✓	Preferred Procedures, processes or actions that are preferred.
X	Forbidden Procedures, processes or actions that are forbidden.
i	Tip Indicates additional information.
	Reference to documentation
A=	Reference to page
	Reference to graphic
	Visual inspection

#### Symbols in graphics

Symbol	Meaning
1, 2, 3,	Item numbers
1., 2., 3	Series of steps
A, B, C,	Views
A-A, B-B, C-C,	Sections
EX	Hazardous area
×	Safe area (non-hazardous area)
≋➡	Flow direction

## Function and system design

#### Measuring principle

The measuring principle is based on the controlled generation of Coriolis forces. These forces are always present in a system when both translational and rotational movements are superimposed.

 $F_c = 2 \cdot \Delta m (v \cdot \omega)$ 

 $F_c$  = Coriolis force

 $\Delta m = moving mass$ 


 $\omega$  = rotational velocity

v = radial velocity in rotating or oscillating system

The amplitude of the Coriolis force depends on the moving mass  $\Delta m$ , its velocity v in the system and thus on the mass flow. Instead of a constant rotational velocity  $\omega$ , the sensor uses oscillation.

In the sensor, an oscillation is produced in the measuring tube. The Coriolis forces produced at the measuring tube cause a phase shift in the tube oscillations (see illustration):

- If there is zero flow (i.e. when the fluid stands still), the oscillation measured at points A and B has the same phase (no phase difference) (1).
- Mass flow causes deceleration of the oscillation at the inlet of the tubes (2) and acceleration at the outlet (3).



A002993

The phase difference (A-B) increases with increasing mass flow. Electrodynamic sensors register the tube oscillations at the inlet and outlet. System balance is created by exciting an eccentrically arranged swinging mass to antiphase oscillation. The measuring principle operates independently of temperature, pressure, viscosity, conductivity and flow profile.

#### Density measurement

The measuring tube is continuously excited at its resonance frequency. A change in the mass and thus the density of the oscillating system (comprising measuring tube and fluid) results in a corresponding, automatic adjustment in the oscillation frequency. Resonance frequency is thus a function of medium density. The microprocessor utilizes this relationship to obtain a density signal.

#### Volume measurement

Together with the measured mass flow, this is used to calculate the volume flow.

#### Temperature measurement

The temperature of the measuring tube is determined in order to calculate the compensation factor due to temperature effects. This signal corresponds to the process temperature and is also available as an output signal.


#### Measuring system

The device consists of a transmitter and a sensor.

The device is available as a compact version:

The transmitter and sensor form a mechanical unit.

#### Transmitter




Device versions and materials:

- Transmitter housing
  - Aluminum, coated: aluminum, AlSi10Mg, coated
- Cast, stainless: cast, stainless steel, 1.4409 (CF3M) similar to 316L
- Material of window in transmitter housing:
  - Aluminum, coated: glass
  - Cast, stainless: glass

#### Configuration:


- External operation via 4-line, backlit, graphic local display with touch control and guided menus ("Make-it-run" wizards) for applicationspecific commissioning.
- Via service interface or WLAN interface:
  - Operating tools (e.g. FieldCare, DeviceCare)
  - Web server (access via Web browser, e.g. Microsoft Internet Explorer, Microsoft Edge)

#### Sensor



- Sensitive fluid handling thanks to straight single-tube system
- Simultaneous measurement of viscosity, flow, volume flow, density and temperature (multivariable)
- Immune to process influences
- Nominal diameter range: DN 8 to 80 (3/8 to 3")
- Materials:
  - Sensor: stainless steel, 1.4301/1.4307 (304L)
  - Measuring tubes: titanium Grade 9
  - Process connections: stainless steel, 1.4301 (304), wetted parts: titanium Grade 2

#### **Equipment architecture**



 $\blacksquare$  1 Possibilities for integrating measuring devices into a system

- 1 Control system (e.g. PLC)
- 2 Connecting cable (0/4 to 20 mA HART etc.)
- 3 Fieldbus
- 4 Segment coupler
- 5 Non-hazardous area
- 6 Non-hazardous area and Zone 2/Div. 2
- Hazardous area and Zone 1/Div. 1

#### Safety

#### IT security

We only provide a warranty if the device is installed and used as described in the Operating Instructions. The device is equipped with security mechanisms to protect it against any inadvertent changes to the device settings.

IT security measures in line with operators' security standards and designed to provide additional protection for the device and device data transfer must be implemented by the operators themselves.

#### Device-specific IT security

The device offers a range of specific functions to support protective measures on the operator's side. These functions can be configured by the user and guarantee greater in-operation safety if used correctly. An overview of the most important functions is provided in the following section.

Protecting access via hardware write protection

Write access to the device parameters via the local display, Web browser or operating tool (e.g. FieldCare, DeviceCare) can be disabled via a write protection switch (DIP switch on the motherboard). When hardware write protection is enabled, only read access to the parameters is possible.

Hardware write protection is disabled when the device is delivered.

Protecting access via a password

Different passwords are available to protect write access to the device parameters or access to the device via the WLAN interface.

- User-specific access code
  - Protect write access to the device parameters via the local display, Web browser or operating tool (e.g. FieldCare, DeviceCare). Is equivalent to hardware write protection in terms of functionality.
- WLAN passphrase
- The network key protects a connection between an operating unit (e.g. notebook or tablet) and the device via the WLAN interface which can be ordered as an option.

User-specific access code

Write access to the device parameters via the local display, Web browser or operating tool (e.g. FieldCare, DeviceCare) can be protected by the modifiable, user-specific access code.

When the device is delivered, the device does not have an access code and is equivalent to 0000 (open).

#### WLAN passphrase

A connection between an operating unit (e.g. notebook or tablet) and the device via the WLAN interface which can be ordered as an option is protected by the network key. The WLAN authentication of the network key complies with the IEEE 802.11 standard.

When the device is delivered, the network key is pre-defined depending on the device. It can be changed via the **WLAN settings** submenu in the **WLAN passphrase** parameter.

General notes on the use of passwords

- The access code and network key supplied with the device should be changed during commissioning.
- Follow the general rules for generating a secure password when defining and managing the access code or network key.
- The user is responsible for the management and careful handling of the access code and network key.

#### Access via fieldbus

When communicating via fieldbus, access to the device parameters can be restricted to "Read only" access. The option can be changed in the **Fieldbus writing access** parameter.

This does not affect cyclic measured value transmission to the higher-order system, which is always quaranteed.



Additional information: "Description of Device Parameters" document pertaining to the device  $\rightarrow \implies 90$ .

#### Access via Web server

The device can be operated and configured via a Web browser with the integrated Web server . The connection is via the service interface (CDI-RJ45) or the WLAN interface.

The Web server is enabled when the device is delivered. The Web server can be disabled if necessary (e.g. after commissioning) via the **Web server functionality** parameter.

The device and status information can be hidden on the login page. This prevents unauthorized access to the information.



## Input

#### Measured variable

#### Direct measured variables

- Mass flow
- Density
- Temperature
- Viscosity

#### Calculated measured variables

- Volume flow
- Corrected volume flow
- Reference density

## Measuring range

## Measuring ranges for liquids

DN		Measuring range full scale values $\dot{m}_{min(F)}$ to $\dot{m}_{max(F)}$	
[mm]	[in]	[kg/h]	[lb/min]
8	3/8	0 to 2 000	0 to 73.50
15	1/2	0 to 6 500	0 to 238.9
15 FB	½ FB	0 to 18000	0 to 661.5
25	1	0 to 18 000	0 to 661.5
25 FB	1 FB	0 to 45 000	0 to 1654
40	11/2	0 to 45 000	0 to 1654
40 FB	1½ FB	0 to 70 000	0 to 2 573
50	2	0 to 70 000	0 to 2 573
50 FB	2 FB	0 to 180 000	0 to 6615
80	3	0 to 180 000	0 to 6615
FB = Full bore			

#### Measuring ranges for gases

The full scale values depend on the density of the gas and can be calculated with the formula below:  $\dot{m}_{max(G)} = \dot{m}_{max(F)} \cdot \rho_G : x$ 

m <sub>max(G)</sub>	Maximum full scale value for gas [kg/h]
m <sub>max(F)</sub>	Maximum full scale value for liquid [kg/h]
$\dot{m}_{\max(G)} < \dot{m}_{\max(F)}$	$\dot{m}_{max(G)}$ can never be greater than $\dot{m}_{max(F)}$
$ ho_{G}$	Gas density in [kg/m³] at operating conditions
х	Constant dependent on nominal diameter

DN		х
[mm]	[in]	[kg/m³]
8	3/8	60
15	1/2	80
15 FB	½ FB	90
25	1	90
25 FB	1 FB	90
40	11/2	90

DN		х
[mm]	[in]	[kg/m³]
40 FB	1½ FB	90
50	2	90
50 FB	2 FB	110
80	3	110
FB = Full bore		



To calculate the measuring range, use the *Applicator* sizing tool  $\rightarrow \triangleq 89$ 

#### Calculation example for gas

- Sensor: Promass I, DN 50
- Gas: Air with a density of 60.3 kg/m $^3$  (at 20  $^{\circ}$ C and 50 bar)
- Measuring range (liquid): 70 000 kg/h
- $x = 90 \text{ kg/m}^3 \text{ (for Promass I, DN 50)}$

Maximum possible full scale value:

 $\dot{m}_{~max(G)} = \dot{m}_{~max(F)} \cdot \rho_{G} : x = 70\,000 \; kg/h \cdot 60.3 \; kg/m^{3} : 90 \; kg/m^{3} = 46\,900 \; kg/h$ 

#### Recommended measuring range

"Flow limit" section  $\rightarrow$   $\stackrel{\triangle}{=}$  50

#### Operable flow range

Over 1000: 1.

Flow rates above the preset full scale value do not override the electronics unit, with the result that the totalizer values are registered correctly.

#### Input signal


#### Input and output versions

→ 🖺 12

#### External measured values

To increase the accuracy of certain measured variables or to calculate the corrected volume flow for gases, the automation system can continuously write different measured values to the measuring device:

- Operating pressure to increase accuracy (Endress+Hauser recommends the use of a pressure measuring device for absolute pressure, e.g. Cerabar M or Cerabar S)
- Fluid temperature to increase accuracy (e.g. iTEMP)
- Reference density for calculating the corrected volume flow for gases



It is recommended to read in external measured values to calculate the following measured variables for gases:

- Mass flow
- Corrected volume flow

#### HART protocol

The measured values are written from the automation system to the measuring device via the HART protocol. The pressure transmitter must support the following protocol-specific functions:

- HART protocol
- Burst mode

#### Current input

#### Digital communication

The measured values can be written from the automation system to the measuring via:

- FOUNDATION Fieldbus
- PROFIBUS PA
- Modbus RS485

## Current input 0/4 to 20 mA

Current input	0/4 to 20 mA (active/passive)
Current span	<ul><li>4 to 20 mA (active)</li><li>0/4 to 20 mA (passive)</li></ul>
Resolution	1 μΑ
Voltage drop	Typically: 0.6 to 2 V for 3.6 to 22 mA (passive)
Maximum input voltage	≤ 30 V (passive)
Open-circuit voltage	≤ 28.8 V (active)
Possible input variables	<ul><li>Pressure</li><li>Temperature</li><li>Density</li></ul>

## Status input

Maximum input values	■ DC $-3$ to 30 V ■ If status input is active (ON): $R_i > 3 \text{ k}\Omega$
Response time	Adjustable: 5 to 200 ms
Input signal level	<ul> <li>Low signal: DC -3 to +5 V</li> <li>High signal: DC 12 to 30 V</li> </ul>
Assignable functions	<ul> <li>Off</li> <li>Reset the individual totalizers separately</li> <li>Reset all totalizers</li> <li>Flow override</li> </ul>

## **Output**

#### Output and input variants

Depending on the option selected for output/input 1, different options are available for the other outputs and inputs. Only one option can be selected for each output/input 1 to 3. The table must be read vertically  $(\downarrow)$ .

Example: If the option **BA** (current output 4 to 20 mA HART) was selected for output/input 1, one of the options **A**, **B**, **D**, **E**, **F**, **H**, **I** or **J** is available for output 2 and one of the options **A**, **B**, **D**, **E**, **F**, **H**, **I** or **J** is available for output 3.

Order code for "Output; input 1" (020) →	Possible options						
Current output 4 to 20 mA HART	BA						
Current output 4 to 20 mA HART Ex i	<b>\</b>	CA					
FOUNDATION Fieldbus		4	SA				
FOUNDATION Fieldbus Ex i			<b>\</b>	TA			
PROFIBUS PA				4	GA		
PROFIBUS PA Ex i					<b>\</b>	НА	
Modbus RS485						<b>\</b>	MA
Order code for "Output; input 2" (021) →	<b>\</b>	<b>\</b>	4	4	<b>\</b>	<b>\</b>	<b>\</b>
Not assigned	A	Α	Α	A	Α	Α	A
Current output 0/4 to 20 mA	В		В		В		В
Current output 0/4 to 20 mA (Ex i)		С		С		С	
User configurable input/output 1)	D		D		D		D
Pulse/frequency/switch output	Е		Е		Е		Е
Double pulse output <sup>2)</sup>	F						F
Pulse/frequency/switch output (Ex i)		G		G		G	
Relay output	Н		Н		Н		Н
Current input 0/4 to 20 mA	I		I		I		I
Status input	J		J		J		J
Order code for "Output; input 3" (022) →	4	4	<b>\</b>	4	<b>\</b>	<b>\</b>	<b>\</b>
Not assigned	A	Α	Α	A	A	A	A
Current output 0/4 to 20 mA	В						В
Current output 0/4 to 20 mA (Ex i)		С					
User configurable input/output	D						D
Pulse/frequency/switch output	Е						E
Double pulse output (slave) <sup>2)</sup>	F						F
Pulse/frequency/switch output (Ex i)		G					
Relay output	Н						Н
Current input 0/4 to 20 mA	I						I
Status input	J						J

<sup>2)</sup> If double pulse output (F) is selected for output/input 2 (021), only the double pulse output (F) option is available for selection for output/input 3 (022).

## Output signal

## HART current output

Current output	4 to 20 mA HART
Current span	Can be set to: 4 to 20 mA (active/passive)
Open-circuit voltage	DC 28.8 V (active)
Maximum input voltage	DC 30 V (passive)
Load	250 to 700 Ω
Resolution	0.38 μΑ
Damping	Adjustable: 0.07 to 999 s
Assignable measured variables	<ul> <li>Mass flow</li> <li>Volume flow</li> <li>Corrected volume flow</li> <li>Density</li> <li>Reference density</li> <li>Temperature</li> <li>The range of options increases if the measuring device has one or more application packages.</li> </ul>

## PROFIBUS PA

PROFIBUS PA	In accordance with EN 50170 Volume 2, IEC 61158-2 (MBP), galvanically isolated
Data transfer	31.25 KBit/s
<b>Current consumption</b>	10 mA
Permitted supply voltage	9 to 32 V
Bus connection	With integrated reverse polarity protection

## FOUNDATION Fieldbus

FOUNDATION Fieldbus	H1, IEC 61158-2, galvanically isolated
Data transfer	31.25 KBit/s
Current consumption	10 mA
Permitted supply voltage	9 to 32 V
Bus connection	With integrated reverse polarity protection

#### Modbus RS485

Physical interface	RS485 in accordance with EIA/TIA-485 standard
Terminating resistor	Integrated, can be activated via DIP switches

## Current output 0/4 to 20 mA

Current output	0/4 to 20 mA
Maximum output values	22.5 mA
Current span	Can be set to:
	<ul> <li>4 to 20 mA (active)</li> <li>0/4 to 20 mA (passive)</li> </ul>
Open-circuit voltage	DC 28.8 V (active)
Maximum input voltage	DC 30 V (passive)

Load	$0$ to $700\Omega$
Resolution	0.38 μΑ
Damping	Adjustable: 0.07 to 999 s
Assignable measured variables	<ul> <li>Mass flow</li> <li>Volume flow</li> <li>Corrected volume flow</li> <li>Density</li> <li>Reference density</li> <li>Temperature</li> <li>The range of options increases if the measuring device has one or more application packages.</li> </ul>

## Pulse/frequency/switch output

Function	Can be set to pulse, frequency or switch output
Version	Open collector
	Can be set to:
	<ul><li>Active</li><li>Passive</li></ul>
Maximum input values	DC 30 V, 250 mA (passive)
Open-circuit voltage	DC 28.8 V (active)
Voltage drop	For 22.5 mA: ≤ DC 2 V
Pulse output	
Maximum input values	DC 30 V, 250 mA (passive)
Maximum output current	22.5 mA (active)
Open-circuit voltage	DC 28.8 V (active)
Pulse width	Adjustable: 0.05 to 2 000 ms
Maximum pulse rate	10 000 Impulse/s
Pulse value	Adjustable
Assignable measured variables	<ul> <li>Mass flow</li> <li>Volume flow</li> <li>Corrected volume flow</li> <li>Density</li> <li>Reference density</li> <li>Temperature</li> </ul>
Frequency output	
Maximum input values	DC 30 V, 250 mA (passive)
Maximum output current	22.5 mA (active)
Open-circuit voltage	DC 28.8 V (active)
Output frequency	Adjustable: end value frequency 2 to 10 000 Hz (f $_{\rm max}$ = 12 500 Hz)
Damping	Adjustable: 0 to 999 s
Pulse/pause ratio	1:1
Assignable measured variables	<ul> <li>Mass flow</li> <li>Volume flow</li> <li>Corrected volume flow</li> <li>Density</li> <li>Reference density</li> <li>Temperature</li> <li>The range of options increases if the measuring device has one or more application packages.</li> </ul>
Switch output	
Maximum input values	DC 30 V, 250 mA (passive)

Open-circuit voltage	DC 28.8 V (active)
Switching behavior	Binary, conductive or non-conductive
Switching delay	Adjustable: 0 to 100 s
Number of switching cycles	Unlimited
Assignable functions	■ Off ■ On ■ Diagnostic behavior ■ Limit value — Mass flow — Volume flow — Corrected volume flow — Density — Reference density — Temperature — Totalizer 1-3 ■ Flow direction monitoring ■ Status — Partially filled pipe detection — Low flow cut off  The range of options increases if the measuring device has one or more application packages.

## Double pulse output

Function	Double pulse
Version	Open collector
	Can be set to: Active Passive
Maximum input values	DC 30 V, 250 mA (passive)
Open-circuit voltage	DC 28.8 V (active)
Voltage drop	For 22.5 mA: ≤ DC 2 V
Output frequency	Adjustable: 0 to 1 000 Hz
Damping	Adjustable: 0 to 999 s
Pulse/pause ratio	1:1
Assignable measured variables	<ul> <li>Mass flow</li> <li>Volume flow</li> <li>Corrected volume flow</li> <li>Density</li> <li>Reference density</li> <li>Temperature</li> <li>The range of options increases if the measuring device has one or more application packages.</li> </ul>

## Relay output

Function	Switch output
Version	Relay output, galvanically isolated
Switching behavior	Can be set to: NO (normally open), factory setting NC (normally closed)

Maximum switching capacity (passive)	■ DC 30 V, 0.1 A ■ AC 30 V, 0.5 A
Assignable functions	■ Off ■ On ■ Diagnostic behavior ■ Limit value ■ Mass flow ■ Volume flow ■ Corrected volume flow ■ Density ■ Reference density ■ Temperature ■ Totalizer 1-3 ■ Flow direction monitoring ■ Status ■ Partially filled pipe detection ■ Low flow cut off ■ The range of options increases if the measuring device has one or more
	application packages.

#### User configurable input/output

**One** specific input or output is assigned to a user-configurable input/output (configurable I/O) during device commissioning.

The following inputs and outputs are available for assignment:

- Choice of current output: 4 to 20 mA (active), 0/4 to 20 mA (passive)
- Pulse/frequency/switch output
- Choice of current input: 4 to 20 mA (active), 0/4 to 20 mA (passive)
- Status input

The technical values correspond to those of the inputs and outputs described in this section.

#### Signal on alarm

Depending on the interface, failure information is displayed as follows:

## **HART** current output

Device diagnostics	Device condition can be read out via HART Command 48
--------------------	--

#### PROFIBUS PA

Status and alarm messages	Diagnostics in accordance with PROFIBUS PA Profile 3.02
Error current FDE (Fault Disconnection Electronic)	0 mA

#### FOUNDATION Fieldbus

Status and alarm messages	Diagnostics in accordance with FF-891
Error current FDE (Fault Disconnection Electronic)	0 mA

#### Modbus RS485

Failure mode	Choose from:
	NaN value instead of current value     Last valid value.
	Last valid value

#### Current output 0/4 to 20 mA

#### 4 to 20 mA

<ul> <li>4 to 20 mA in accordance with NAMOR recommendation NE 45</li> <li>4 to 20 mA in accordance with US</li> <li>Min. value: 3.59 mA</li> <li>Max. value: 22.5 mA</li> <li>Freely definable value between: 3.59 to 22.5 mA</li> <li>Actual value</li> <li>Last valid value</li> </ul>	Failure mode	<ul> <li>Min. value: 3.59 mA</li> <li>Max. value: 22.5 mA</li> <li>Freely definable value between: 3.59 to 22.5 mA</li> <li>Actual value</li> </ul>
---	--------------	---

#### 0 to 20 mA

Failure mode	Choose from:
	■ Maximum alarm: 22 mA
	■ Freely definable value between: 0 to 20.5 mA

## Pulse/frequency/switch output

Pulse output	
Failure mode	Choose from:  Actual value  No pulses
Frequency output	
Failure mode	Choose from:  Actual value  O Hz  Defined value (f max 2 to 12 500 Hz)
Switch output	
Failure mode	Choose from:  Current status  Open Closed

## Relay output

Failure mode	Choose from:
	<ul> <li>Current status</li> </ul>
	■ Open
	■ Closed

## Local display

Plain text display	With information on cause and remedial measures
Backlight	Red backlighting indicates a device error.



Status signal as per NAMUR recommendation NE 107

## Interface/protocol

- Via digital communication:
  - HART protocol
  - FOUNDATION Fieldbus
  - PROFIBUS PA
  - Modbus RS485
- Via service interface

Plain text display	With information on cause and remedial measures
--------------------	---



## Web server

Plain text display	With information on cause and remedial measures
--------------------	---

## Light emitting diodes (LED)

Status information	Status indicated by various light emitting diodes
	The following information is displayed depending on the device version:  Supply voltage active
	■ Data transmission active
	Device alarm/error has occurred

## Ex connection data Safety-related values

Order code for "Output; input 1"	Output type	Safety-related values "Output; input 1"	
		26 (+)	27 (-)
Option <b>BA</b>	Current output 4 to 20 mA HART	U <sub>nom</sub> = 30 V U <sub>max</sub> = 250 V	
Option <b>GA</b>	PROFIBUS PA	$U_{\text{nom}} = 32 \text{ V}$ $U_{\text{max}} = 250 \text{ V}$	
Option MA	Modbus RS485	U <sub>nom</sub> = 30 V U <sub>max</sub> = 250 V	
Option <b>SA</b>	FOUNDATION Fieldbus	U <sub>nom</sub> = 32 V U <sub>max</sub> = 250 V	

Order code for	Output type	Safety-related values			
"Output; input 2"; "Output; input 3"		Output;	input 2	Output;	input 3
• / •		24 (+)	25 (-)	22 (+)	23 (-)
Option <b>B</b>	Current output 4 to 20 mA	$U_{\text{nom}} = 30 \text{ V}$ $U_{\text{max}} = 250 \text{ V}$			
Option <b>D</b>	User configurable input/output	$U_{\text{nom}} = 30 \text{ V}$ $U_{\text{max}} = 250 \text{ V}$			
Option <b>E</b>	Pulse/frequency/switch output	$U_{\text{nom}} = 30 \text{ V}$ $U_{\text{max}} = 250 \text{ V}$			
Option <b>F</b>	Double pulse output	$U_{\text{nom}} = 30 \text{ V}$ $U_{\text{max}} = 250 \text{ V}$			
Option <b>H</b>	Relay output	$U_{\text{nom}} = 30 \text{ V}$ $I_{\text{nom}} = 100 \text{ m/s}$ $U_{\text{max}} = 250 \text{ V}$	A DC/500 mA	AC	
Option I	Current input 4 to 20 mA	$U_{\text{nom}} = 30 \text{ V}$ $U_{\text{max}} = 250 \text{ V}$			
Option <b>J</b>	Status input	$U_{\text{nom}} = 30 \text{ V}$ $U_{\text{max}} = 250 \text{ V}$			

#### Intrinsically safe values

Order code for "Output; input 1"	Output type	Intrinsically safe values "Output; input 1"	
		26 (+)	27 (-)
Option CA	Current output 4 to 20 mA HART Ex i	$ \begin{aligned} &U_{i} = 30 \text{ V} \\ &I_{i} = 100 \text{ mA} \\ &P_{i} = 1.25 \text{ W} \\ &L_{i} = 0 \\ &C_{i} = 0 \end{aligned} $	
Option <b>HA</b>	PROFIBUS PA Ex i	$Ex ia ^{1)} \\ U_i = 30 V \\ l_i = 570 mA \\ P_i = 8.5 W \\ L_i = 10 \ \mu H \\ C_i = 5 \ nF$	Ex ic $^{2}$ ) $U_{i} = 32 \text{ V}$ $l_{i} = 570 \text{ mA}$ $P_{i} = 8.5 \text{ W}$ $L_{i} = 10  \mu\text{H}$ $C_{i} = 5 \text{ nF}$
Option TA	FOUNDATION Fieldbus Ex i	$\begin{aligned} &\textbf{Ex ia}^{\ 1)} \\ &\textbf{U}_i = 30 \text{ V} \\ &\textbf{I}_i = 570 \text{ mA} \\ &\textbf{P}_i = 8.5 \text{ W} \\ &\textbf{L}_i = 10  \mu\text{H} \\ &\textbf{C}_i = 5 \text{ nF} \end{aligned}$	Ex ic $^{2}$ ) $U_{i} = 32 \text{ V}$ $l_{i} = 570 \text{ mA}$ $P_{i} = 8.5 \text{ W}$ $L_{i} = 10  \mu\text{H}$ $C_{i} = 5 \text{ nF}$

- 1) Only available for the Zone 1, Class I, Division 1 version
- 2) Only available for the Zone 2, Class I, Division 2 version transmitter

Order code for	Output type	Intrinsically safe values			
"Output; input 2"; "Output; input 3"		Output; input 2 Output; input 3		input 3	
• / •		24 (+)	25 (-)	22 (+)	23 (-)
Option C	Current output 4 to 20 mA Ex i	$\begin{aligned} &U_{i} = 30 \text{ V} \\ &l_{i} = 100 \text{ mA} \\ &P_{i} = 1.25 \text{ W} \\ &L_{i} = 0 \\ &C_{i} = 0 \end{aligned}$			
Option <b>G</b>	Pulse/frequency/switch output Ex i	$\begin{aligned} &U_{i} = 30 \text{ V} \\ &I_{i} = 100 \text{ mA} \\ &P_{i} = 1.25 \text{ W} \\ &L_{i} = 0 \\ &C_{i} = 0 \end{aligned}$			

Low flow cut off

The switch points for low flow cut off are user-selectable.

Galvanic isolation

The outputs are galvanically isolated from one another and from earth (PE).

## Protocol-specific data

#### **HART**

Manufacturer ID	0x11
Device type ID	0x3B
HART protocol revision	7
Device description files (DTM, DD)	Information and files under: www.endress.com
HART load	Min. 250 $\Omega$

Dynamic variables	Read out the dynamic variables: HART command 3 The measured variables can be freely assigned to the dynamic variables.
	Measured variables for PV (primary dynamic variable)  Mass flow Volume flow Corrected volume flow Density Reference density Temperature
	Measured variables for SV, TV, QV (secondary, tertiary and quaternary dynamic variable)  Mass flow  Volume flow  Corrected volume flow  Density  Reference density  Temperature  Totalizer 1  Totalizer 2  Totalizer 3
	The range of options increases if the measuring device has one or more application packages.
	Heartbeat Technology Application Package Additional measured variables are available with the Heartbeat Technology application package: ■ HBSI (Heartbeat Sensor Integrity) ■ Frequency fluctuation 1 ■ Oscillation amplitude 1 ■ Tube damping fluctuation 1 ■ Exciter current 1  Heartbeat Technology Special Documentation → ■ 91
Device variables	Read out the device variables: HART command 9 The device variables are permanently assigned.
	A maximum of 8 device variables can be transmitted:  • 0 = mass flow  • 1 = volume flow  • 2 = corrected volume flow  • 3 = density  • 4 = reference density  • 5 = temperature  • 6 = totalizer 1  • 7 = totalizer 2  • 8 = totalizer 3  • 9 = dynamic viscosity  • 10 = kinematic viscosity  • 11 = temp. compensated dynamic viscosity  • 12 = temp. compensated kinematic viscosity  • 13 = target mass flow  • 14 = carrier mass flow  • 15 = concentration

## PROFIBUS PA

Manufacturer ID	0x11
Ident number	0x156D
Profile version	3.02
Device description files (GSD, DTM, DD)	Information and files under:  www.endress.com www.profibus.org

#### **Output values**

(from measuring device to automation system)


#### Analog input 1 to 8

- Mass flow
- Volume flow
- Corrected volume flow
- Carrier mass flow
- Target mass flow
- Density
- · Reference density
- Concentration
- Dynamic viscosity
- Kinematic viscosity
- Temp. compensated dynamic viscosity
- Temp. compensated kinematic viscosity
- Temperature
- Carrier pipe temperature
- Electronic temperature
- Current input
- The range of options increases if the measuring device has one or more application packages.

#### Heartbeat Technology Application Package

Additional measured variables are available with the Heartbeat Technology application package:

- Oscillation frequency 1
- Carrier pipe temperature
- Frequency fluctuation 1
- Oscillation amplitude 1
- Oscillation damping 1
- Oscillation damping fluctuation 1
- Exciter current 1
- HBSI (Heartbeat Sensor Integrity)



#### Digital input 1 to 2

- Empty pipe detection
- Low flow cut off
- Status verification

#### Totalizer 1 to 3

- Mass flow
- Volume flow
- Corrected volume flow
- Target mass flow
- Carrier mass flow

#### Input values

(from automation system to measuring device)

#### Analog output 1 to 3 (fixed assignment)

- Analog output 1: external pressure
- Analog output 2: external temperature
- Analog output 3: external reference density

#### Digital output 1 to 4: (fixed assignment)

- Digital output 1: switch positive zero return on/off
- Digital output 2: switch zero point adjustment on/off
- Digital output 3: start verification
- Digital output 4: relay output non-conductive/conductive

#### Totalizer 1 to 3

- Totalize
- Reset and hold
- Preset and hold
- Operating mode configuration:
  - Net flow total
  - Forward flow total
  - Reverse flow total
  - Last valid value

Supported functions	Identification & Maintenance     Simplest device identification on the part of the control system and nameplate     PROFIBUS upload/download     Reading and writing parameters is up to ten times faster with PROFIBUS upload/download     Condensed status     Simplest and self-explanatory diagnostic information by categorizing diagnostic messages that occur
Configuration of the device address	<ul> <li>DIP switches on the I/O electronics module</li> <li>Local display</li> <li>Via operating tools (e.g. FieldCare)</li> </ul>
Compatibility with earlier model	If the device is replaced, the Promass 300 measuring device supports the compatibility of the cyclic data with earlier models. It is not necessary to adjust the engineering parameters of the PROFIBUS network with the Promass 300 GSD file.
	Earlier models:  Promass 80 PROFIBUS PA  ID No.: 1528 (hex)  Extended GSD file: EH3x1528.gsd  Standard GSD file: EH3_1528.gsd  Promass 83 PROFIBUS PA  ID No.: 152A (hex)  Extended GSD file: EH3x152A.gsd  Standard GSD file: EH3_152A.gsd
	Description of the function scope of compatibility: Operating Instructions $\rightarrow \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ $

## FOUNDATION Fieldbus

Manufacturer ID	0x452B48
Ident number	0x103B
Device revision	1
DD revision	Information and files under:
CFF revision	<ul><li>www.endress.com</li><li>www.fieldbus.org</li></ul>
Interoperability Test Kit (ITK)	Version 6.1.2
ITK Test Campaign Number	Information:  www.endress.com www.fieldbus.org
Link Master capability (LAS)	Yes
Choice of "Link Master" and "Basic Device"	Yes Factory setting: Basic Device
Node address	Factory setting: 247 (0xF7)
Supported functions	The following methods are supported:  Restart  ENP Restart  Diagnostic
Virtual Communication Relation	onships (VCRs)
Number of VCRs	44
Number of link objects in VFD	50
Permanent entries	1
Client VCRs	0
Server VCRs	10
Source VCRs	43
Sink VCRs	0

Subscriber VCRs	43
Publisher VCRs	43
Device Link Capabilities	
Slot time	4
Min. delay between PDU	8
Max. response delay	20

## Transducer Blocks

Block	Contents	Output values
Setup Transducer Block (TRDSUP)	All parameters for standard commissioning.	No output values
Advanced Setup Transducer Block (TRDASUP)	All parameters for more accurate measurement configuration.	No output values
Display Transducer Block (TRDDISP)	Parameters for configuring the local display.	No output values
HistoROM Transducer Block (TRDHROM)	Parameters for using the HistoROM function.	No output values
Diagnostic Transducer Block (TRDDIAG)	Diagnostics information.	Process variables (AI Channel)  Temperature (7)  Volume flow (9)  Concentration (10)  Mass flow (11)  Corrected volume flow (13)  Density (14)  Reference density (15)  Carrier pipe temperature (51)  Carrier mass flow (57)  Target mass flow (58)  Dynamic viscosity (59)  Kinematic viscosity (60)  Temp. compensated dynamic viscosity (61)  Temp. compensated kinematic viscosity (62)  Electronic temperature (65)  Current input 1 (99)
Expert Configuration Transducer Block (TRDEXP)	Parameters that require the user to have indepth knowledge of the operation of the device in order to configure the parameters appropriately.	No output values
Expert Information Transducer Block (TRDEXPIN)	Parameters that provide information about the state of the device.	No output values
Service Sensor Transducer Block (TRDSRVS)	Parameters that can only be accessed by Endress +Hauser Service.	No output values
Service Information Transducer Block (TRDSRVIF)	Parameters that provide Endress+Hauser Service with information about the state of the device.	No output values
Total Inventory Counter Transducer Block (TRDTIC)	Parameters for configuring all the totalizers and the inventory counter.	Process variables (AI Channel)  Totalizer 1 (16)  Totalizer 2 (17)  Totalizer 3 (18)

Block	Contents	Output values
Heartbeat Technology Transducer Block (TRDHBT)	Parameters for the configuration and comprehensive information about the results of the verification.	No output values
Heartbeat Results 1 Transducer Block (TRDHBTR1)	Information about the results of the verification.	No output values
Heartbeat Results 2 Transducer Block (TRDHBTR2)	Information about the results of the verification.	No output values
Heartbeat Results 3 Transducer Block (TRDHBTR3)	Information about the results of the verification.	No output values
Heartbeat Results 4 Transducer Block (TRDHBTR4)	Information about the results of the verification.	No output values

## Function blocks

Block	Number blocks	Execution times	Process variables (Channel)
Resource Block (RB)	1	This Block (extended functionality) contains all the data that uniquely identify the device; it is the equivalent of an electronic nameplate for the device.	-
Analog Input Block (AI)	8	7 ms	Process variables (AI Channel)  Temperature (7)  Volume flow (9)  Concentration (10)  Mass flow (11)  Corrected volume flow (13)  Density (14)  Reference density (15)  Totalizer 1 (16)  Totalizer 3 (18)  Carrier pipe temperature (51)  Carrier mass flow (57)  Target mass flow (58)  Dynamic viscosity (59)  Kinematic viscosity (60)  Temp. compensated dynamic viscosity (61)  Temp. compensated kinematic viscosity (62)  Electronic temperature (65)  Current input 1 (99)
Discrete Input Block (DI)	2	5 ms	<ul> <li>Switch output state (101)</li> <li>Low flow cut off (103)</li> <li>Empty pipe detection (104)</li> <li>Status verification (105)</li> </ul>
PID Block (PID)	1	6 ms	_

Block	Number blocks	Execution times	Process variables (Channel)
Multiple Analog Output Block (MAO)	1	5 ms	Channel_0 (121)  Value 1: External compensation variable, pressure  Value 2: External compensation variable, temperature  Value 3: External compensation variable, reference density  The compensation variable variables must be transmitted to the device in the SI basic units.
Multiple Digital Output Block (MDO)	1	5 ms	Channel_DO (122)  Value 1: Reset totalizer 1  Value 2: Reset totalizer 2  Value 3: Reset totalizer 3  Value 4: Flow override  Value 5: Start heartbeat verification  Value 6: Status switch output  Value 7: Start zero point adjustment  Value 8: Not assigned
Integrator Block (IT)	1	6 ms	-

## Modbus RS485

Protocol	Modbus Applications Protocol Specification V1.1					
Response times	<ul> <li>Direct data access: typically 25 to 50 ms</li> <li>Auto-scan buffer (data range): typically 3 to 5 ms</li> </ul>					
Device type	Slave					
Slave address range	1 to 247					
Broadcast address range	0					
Function codes	<ul> <li>03: Read holding register</li> <li>04: Read input register</li> <li>06: Write single registers</li> <li>08: Diagnostics</li> <li>16: Write multiple registers</li> <li>23: Read/write multiple registers</li> </ul>					
Broadcast messages	Supported by the following function codes:  O6: Write single registers  16: Write multiple registers  23: Read/write multiple registers					
Supported baud rate	<ul> <li>1200 BAUD</li> <li>2400 BAUD</li> <li>4800 BAUD</li> <li>9600 BAUD</li> <li>19200 BAUD</li> <li>38400 BAUD</li> <li>57600 BAUD</li> <li>115200 BAUD</li> </ul>					
Data transfer mode	ASCII     RTU					

Data access	Each device parameter can be accessed via Modbus RS485.  For Modbus register information
Compatibility with earlier model	If the device is replaced, the Promass 300 measuring device supports the compatibility of the Modbus registers for process variables and diagnostic information with the earlier Promass 83 model. It is not necessary to change the engineering parameters in the automation system.
	Description of the function scope of compatibility:  Operating Instructions $\rightarrow \stackrel{\triangle}{=} 90$ .

## **Power supply**

#### Terminal assignment

#### Transmitter: supply voltage, input/outputs

#### HART

Supply voltage		Input/output 1		Input/output 2		Input/output 3	
1 (+)	2 (-)	26 (+)	27 (-)	24 (+)	25 (-)	22 (+)	23 (-)
		The terminal assignment depends on the specific device version ordered $\rightarrow \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ $					

#### FOUNDATION Fieldbus

Supply	voltage	Input/output 1		Input/output 2		Input/output 3	
1 (+)	2 (-)	26 (A)	27 (B)	24 (+)	25 (-)	22 (+)	23 (-)
		The terminal assignment depends on the specific device version ordered $\rightarrow \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ $					

## PROFIBUS PA

Supply	Supply voltage		Input/output 1		Input/output 2		Input/output 3	
1 (+)	2 (-)	26 (B)	27 (A)	24 (+)	25 (-)	22 (+)	23 (-)	
		The terminal assignment depends on the specific device version ordered $\rightarrow \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ $						

#### Modbus RS485

Supply	Supply voltage		Input/output 1		Input/output 2		Input/output 3	
1 (+)	2 (-)	26 (B)	27 (A)	24 (+)	25 (-)	22 (+)	23 (-)	
		The terminal assignment depends on the specific device version ordered → 🖺 12.						

#### Device plugs available

Povice plugs may not be used in hazardous areas!

#### Device plugs are only available for the following device versions:

Order code for "Input; output 1"

- Option GA "PROFIBUS PA" → 🖺 26
- $\bullet$  Option SA "FOUNDATION Fieldbus"  $\rightarrow~ extstyle exts$

## Order code for "Input; output 1", option GA "PROFIBUS PA"


Order code for	Cable entry	Cable entry
"Electrical connection"	2	3
L, N, P, U	Plug M12 × 1	-

#### Order code for "Input; output 1", option SA "FOUNDATION Fieldbus"

Order code for	Cable entry	Cable entry	
"Electrical connection"	2	3	
M, 3, 4, 5	7/8" plug		

#### Pin assignment, device plug

#### **PROFIBUS PA**



#### **FOUNDATION Fieldbus**

	Pin		Assignment	Coding	Plug/socket
2 / 3	1	+	Signal +	A	Plug
1 4	2	-	Signal –		
	3		Grounding		
	4		Not assigned		

#### Supply voltage

Order code for "Power supply"	terminal voltage		Frequency range
Option <b>D</b>	DC 24 V	±20%	-
Option E	AC100 to 240 V	-15+10%	50/60 Hz
Option I	DC 24 V	±20%	-
Option I	AC100 to 240 V	-15+10%	50/60 Hz

#### Power consumption

#### Transmitter

Max. 10 W (active power)

#### **Current consumption**

#### Transmitter

- Max. 400 mA (24 V)
- Max. 200 mA (110 V, 50/60 Hz; 230 V, 50/60 Hz)

## Power supply failure


- Totalizers stop at the last value measured.
- Configuration is retained in the plug-in memory (HistoROM DAT).
- Error messages (incl. total operated hours) are stored.

#### **Electrical connection**

#### Connecting the transmitter




- Terminal assignment → 🗎 26
- Device plugs available → 🖺 26



- Cable entry for supply voltage
- 2 Cable entry for input/output signal transmission
- Cable entry for input/output signal transmission; Optional: connection of external WLAN antenna, connection of remote display and operating module DKX001 or service plug


#### Connection of remote display and operating module DKX001



- 1 Remote display and operating module DKX001
- Connecting cable
- 3 Measuring device
- Remote display and operating module DKX001  $\rightarrow$   $\blacksquare$  88


#### **Connection examples**

Current output 4 to 20 mA HART




- **₽** 2 Connection example for 4 to 20 mA HART current output (active)
- Automation system with current input (e.g. PLC) 1
- Cable shield: the cable shield must be grounded at both ends to comply with EMC requirements; observe cable specifications → 🖺 35
- 3 Connection for HART operating devices → 🖺 77
- 4
- Transmitter

28



- 3 Connection example for 4 to 20 mA HART current output (passive)
- 1 Automation system with current input (e.g. PLC)
- 2 Power supply
- 3 Cable shield: the cable shield must be grounded at both ends to comply with EMC requirements; observe cable specifications → 35
- 5 Transmitter


#### HART input



A0028763

- 4 Connection example for HART input with a common negative (passive)
- 1 Automation system with HART output (e.g. PLC)
- 2 Active barrier for power supply (e.g. RN221N)
- 3 Cable shield: the cable shield must be grounded at both ends to comply with EMC requirements; observe cable specifications
- 4 Analog display unit: observe maximum load
- Pressure transmitter (e.g. Cerabar M, Cerabar S): see requirements
- 6 Transmitter


#### PROFIBUS-PA



#### **₽** 5 Connection example for PROFIBUS-PA


- 1
- Control system (e.g. PLC) PROFIBUS PA segment coupler
- 3 Cable shield: the cable shield must be grounded at both ends to comply with EMC requirements; observe cable
- 4 T-box
- 5
- Measuring device Local grounding 6
- Bus terminator
- Potential matching line

#### FOUNDATION Fieldbus




- **₽** 6 Connection example for FOUNDATION Fieldbus
- 1
- Control system (e.g. PLC) Power Conditioner (FOUNDATION Fieldbus)
- 3 Cable shield: the cable shield must be grounded at both ends to comply with EMC requirements; observe cable specifications
- T-box
- 5
- Measuring device Local grounding 6
- Bus terminator
- Potential matching line

#### Modbus RS485




- **₽** 7 Connection example for Modbus RS485, non-hazardous area and Zone 2/Div. 2
- Control system (e.g. PLC)
- Cable shield: the cable shield must be grounded at both ends to comply with EMC requirements; observe cable specifications
- Distribution box
- Transmitter

#### Current output 4-20 mA




₽8 Connection example for 4-20 mA current output (active)

- Automation system with current input (e.g. PLC) 1
- 2 Analog display unit: observe maximum load
- 3 Transmitter




- **9** Connection example for 4-20 mA current output (passive)
- Automation system with current input (e.g. PLC) 1
- Active barrier for power supply (e.g. RN221N) 2
- 3 Analog display unit: observe maximum load
- Transmitter

#### Pulse/frequency output




- **■** 10 Connection example for pulse/frequency output (passive)
- Automation system with pulse/frequency input (e.g. PLC)
- Power supply
- 3

#### Switch output




- I1 Connection example for switch output (passive)
- Automation system with switch input (e.g. PLC)
- Power supply
- 3 Transmitter: Observe input values → 🖺 14

#### Double pulse output




A0029280

- 12 Connection example for double pulse output (active)
- 1 Automation system with double pulse input (e.g. PLC)
- 2 Transmitter: Observe input values → 🖺 15
- 3 Double pulse output
- 4 Double pulse output (slave), phase-shifted



- 13 Connection example for double pulse output (passive)
- 1 Automation system with double pulse input (e.g. PLC)
- 2 Power supply
- *3 Transmitter: Observe input values* → 🖺 15
- 4 Double pulse output
- 5 Double pulse output (slave), phase-shifted


#### Relay output



■ 14 Connection example for relay output (passive)

- 1 Automation system with relay input (e.g. PLC)
- 2 Power supply
- 3 Transmitter: Observe input values  $\rightarrow \blacksquare 15$


#### Current input



■ 15 Connection example for 4 to 20 mA current input

- 1 Power supply
- 2 External measuring device (for reading in pressure or temperature, for instance)
- 3 Transmitter: Observe input values

#### Status input



 $\blacksquare$  16 Connection example for status input

- 1 Automation system with status output (e.g. PLC)
- 2 Power supply
- 3 Transmitter: Observe input values

#### Potential equalization

#### Requirements

No special measures for potential equalization are required.

#### **Terminals**

#### Transmitter

Spring terminals for conductor cross-section 0.2 to 2.5  $\text{mm}^2$  (24 to 12 AWG)

#### Cable entries

- Cable gland: M20 × 1.5 with cable Ø 6 to 12 mm (0.24 to 0.47 in)
- Thread for cable entry:
  - NPT 1/2"
  - G ½"
  - M20

#### Cable specification

#### Permitted temperature range

Minimum requirement: cable temperature range ≥ ambient temperature +20 K

#### Power supply cable

Standard installation cable is sufficient.

#### Protective ground cable

Cable: 2.1 mm<sup>2</sup> (14 AWG)

The grounding impedance must be less than 1  $\Omega$ .

#### Signal cable

Current output 4 to 20 mA HART

A shielded cable is recommended. Observe grounding concept of the plant.

#### PROFIBUS PA

Twisted, shielded two-wire cable. Cable type A is recommended.



For further information on planning and installing PROFIBUS PA networks see:

- Operating Instructions "PROFIBUS DP/PA: Guidelines for planning and commissioning" (BA00034S)
- PNO Directive 2.092 "PROFIBUS PA User and Installation Guideline"
- IEC 61158-2 (MBP)

#### FOUNDATION Fieldbus

Twisted, shielded two-wire cable.



For further information on planning and installing FOUNDATION Fieldbus networks see:

- Operating Instructions for "FOUNDATION Fieldbus Overview" (BA00013S)
- FOUNDATION Fieldbus Guideline
- IEC 61158-2 (MBP)

#### Modbus RS485

The EIA/TIA-485 standard specifies two types of cable (A and B) for the bus line which can be used for every transmission rate. Cable type A is recommended.

Cable type	A
Characteristic impedance	135 to 165 $\Omega$ at a measuring frequency of 3 to 20 MHz
Cable capacitance	< 30 pF/m
Wire cross-section	> 0.34 mm <sup>2</sup> (22 AWG)
Cable type	Twisted pairs
Loop resistance	≤110 Ω/km
Signal damping	Max. 9 dB over the entire length of the cable cross-section
Shield	Copper braided shielding or braided shielding with foil shield. When grounding the cable shield, observe the grounding concept of the plant.

Current output 0/4 to 20 mA

Standard installation cable is sufficient.

Pulse/frequency/switch output

Standard installation cable is sufficient.

Double pulse output

Standard installation cable is sufficient.

Relay output

Standard installation cable is sufficient.

Current input 0/4 to 20 mA

Standard installation cable is sufficient.

Status input

Standard installation cable is sufficient.

## Connecting cable for transmitter - remote display and operating module DKX001 $\,$

#### Standard cable

A standard cable can be used as the connecting cable.

Standard cable	4 cores (2 pairs); pair-stranded with common shield
Shielding	Tin-plated copper-braid, optical cover $\geq$ 85 %
Capacitance: core/shield	Maximum 1000 nF for Zone 1, Class I, Division 1
L/R	Maximum 24 $\mu$ H/ $\Omega$ for Zone 1, Class I, Division 1
Cable length	Maximum 300 m (1000 ft), see the following table

Cross-section	Cable length for use in non-hazardous area, Ex Zone 2, Class I, Division 2 Ex Zone 1, Class I, Division 1
0.34 mm <sup>2</sup> (22 AWG)	80 m (270 ft)
0.50 mm <sup>2</sup> (20 AWG)	120 m (400 ft)
0.75 mm <sup>2</sup> (18 AWG)	180 m (600 ft)
1.00 mm <sup>2</sup> (17 AWG)	240 m (800 ft)
1.50 mm <sup>2</sup> (15 AWG)	300 m (1000 ft)


#### Optionally available connecting cable

Standard cable	$2\times2\times0.34~\text{mm}^2$ (22 AWG) PVC cable with common shield (2 pairs, pair-stranded)
Flame resistance	According to DIN EN 60332-1-2
Oil-resistance	According to DIN EN 60811-2-1
Shielding	Tin-plated copper-braid, optical cover ≥ 85 %
Capacitance: core/shield	≤200 pF/m
L/R	<24 μH/Ω
Available cable length	10 m (35 ft)
Operating temperature	When mounted in a fixed position: $-50$ to $+105$ °C ( $-58$ to $+221$ °F); when cable can move freely: $-25$ to $+105$ °C ( $-13$ to $+221$ °F)

# Performance characteristics

#### reference operating conditions

- Error limits based on ISO 11631
- Water with +15 to +45 °C (+59 to +113 °F) at2 to 6 bar (29 to 87 psi)
- Specifications as per calibration protocol
- Accuracy based on accredited calibration rigs that are traced to ISO 17025.



To obtain measured errors, use the *Applicator* sizing tool  $\rightarrow \blacksquare 89$ 

#### Maximum measured error

o.r. = of reading;  $1 \text{ g/cm}^3 = 1 \text{ kg/l}$ ; T = medium temperature

#### Base accuracy

Design fundamentals → 🖺 40

Mass flow and volume flow (liquids)

±0.10 % o.r.

Mass flow (gases)

±0.50 % o.r.

Density (liquids)

Under reference operating conditions	Standard density calibration <sup>1)</sup>	Wide-range Density specification <sup>2) 3)</sup>	
[g/cm³]	[g/cm³]	[g/cm³]	
±0.0005	±0.02	±0.004	

- Valid over the entire temperature and density range 1)
- 2) Valid range for special density calibration: 0 to 2  $g/cm^3$ , +10 to +80 °C (+50 to +176 °F)
- Order code for "Application package", option EF "Special density" or option EH "Special density and viscosity"

#### **Temperature**

 $\pm 0.5 \,^{\circ}\text{C} \pm 0.005 \cdot \text{T} \,^{\circ}\text{C} \, (\pm 0.9 \,^{\circ}\text{F} \pm 0.003 \cdot (\text{T} - 32) \,^{\circ}\text{F})$ 

# Zero point stability

D	N	Zero point stability			
[mm]	[in]	[kg/h]	[lb/min]		
8	3/8	0.150	0.0055		
15	1/2	0.488	0.0179		
15 FB	½ FB	1.350	0.0496		
25	1	1.350	0.0496		
25 FB	1 FB	3.375	0.124		
40	1½	3.375	0.124		
40 FB	1 ½ FB	5.25	0.193		
50	2	5.25	0.193		
50 FB	2 FB	13.5	0.496		
80	3	13.5	0.496		
FB = Full bore					

#### Flow values

Flow values as turndown parameter depending on nominal diameter.

# SI units

DN	1:1	1:10	1:20	1:50	1:100	1:500
[mm]	[kg/h]	[kg/h]	[kg/h]	[kg/h]	[kg/h]	[kg/h]
8	2 000	200	100	40	20	4
15	6500	650	325	130	65	13
15 FB	18000	1800	900	360	180	36
25	18000	1800	900	360	180	36
25 FB	45 000	4500	2 2 5 0	900	450	90
40	45 000	4500	2 2 5 0	900	450	90
40 FB	70000	7 000	3 500	1400	700	140
50	70000	7 000	3 500	1400	700	140
50 FB	180 000	18000	9000	3 600	1800	360
80	180 000	18000	9000	3 600	1800	360
FB = Full bore						

# US units

DN	1:1	1:10	1:20	1:50	1:100	1:500
[inch]	[lb/min]	[lb/min]	[lb/min]	[lb/min]	[lb/min]	[lb/min]
3/8	73.50	7.350	3.675	1.470	0.735	0.147
1/2	238.9	23.89	11.95	4.778	2.389	0.478
½ FB	661.5	66.15	33.08	13.23	6.615	1.323
1	661.5	66.15	33.08	13.23	6.615	1.323
1 FB	1654	165.4	82.70	33.08	16.54	3.308
1½	1654	165.4	82.70	33.08	16.54	3.308
1½ FB	2 573	257.3	128.7	51.46	25.73	5.146
2	2 573	257.3	128.7	51.46	25.73	5.146
2 FB	6 6 1 5	661.5	330.8	132.3	66.15	13.23
3	6615	661.5	330.8	132.3	66.15	13.23
FB = Full bore						

# Accuracy of outputs

The outputs have the following base accuracy specifications.

Current output

Accuracy	±5 μA
----------	-------

Pulse/frequency output

o.r. = of reading

Accuracy Max. ±50 ppm o.r. (across the entire ambient temperature range)	
--	--

#### Repeatability

o.r. = of reading;  $1 \text{ g/cm}^3 = 1 \text{ kg/l}$ ; T = medium temperature

#### Base repeatability

#### Mass flow and volume flow (liquids)

±0.05 % o.r.

#### Mass flow (gases)

±0.25 % o.r.



Design fundamentals → 🖺 40

#### Density (liquids)

 $\pm 0.00025 \text{ g/cm}^3$ 

#### Temperature

 $\pm 0.25 \,^{\circ}\text{C} \pm 0.0025 \cdot \text{T} \,^{\circ}\text{C} \, (\pm 0.45 \,^{\circ}\text{F} \pm 0.0015 \cdot (\text{T}-32) \,^{\circ}\text{F})$ 

#### Response time

The response time depends on the configuration (damping).

#### Influence of ambient temperature

#### **Current output**

o.r. = of reading

Temperature coefficient	Typically 1 uA/°C
remperature coefficient	Typically I m is C

#### Pulse/frequency output

rure coefficient No additional effect. Included in accuracy.
--

# Influence of medium temperature

#### Mass flow and volume flow


When there is a difference between the temperature for zero point adjustment and the process temperature, the typical measured error of the sensor is  $\pm 0.0002~\%$  of the full scale value/°C  $(\pm 0.0001 \% \text{ of the full scale value/°F}).$ 

#### Density

When there is a difference between the density calibration temperature and the process temperature, the typical measured error of the sensor is  $\pm 0.0001$  q/cm<sup>3</sup> /°C ( $\pm 0.00005$  q/cm<sup>3</sup> /°F). Field density calibration is possible.

#### Wide-range density specification (special density calibration)

If the process temperature is outside the valid range ( $\Rightarrow \equiv 37$ ) the measured error is  $\pm 0.0001 \text{ g/cm}^3 \text{ /°C } (\pm 0.00005 \text{ g/cm}^3 \text{ /°F})$ 



- Field density calibration, for example at  $+20 \,^{\circ}\text{C}$  (+68 °F)
- Special density calibration

#### **Temperature**

 $\pm 0.005 \cdot \text{T} \,^{\circ}\text{C} \, (\pm 0.005 \cdot (\text{T} - 32) \,^{\circ}\text{F})$ 

# Influence of medium pressure

The table below shows the effect on accuracy of mass flow due to a difference between calibration pressure and process pressure.

o.r. = of reading

DN		[% o.r./bar]	[% o.r./psi]	
[mm]	[in]			
8	<sup>3</sup> / <sub>8</sub>	No effect	No effect	
15	1/2	No effect	No effect	
15 FB	½ FB	+0.003	+0.0002	
25	1	+0.003	+0.0002	
25 FB	1 FB	No effect	No effect	
40	1½	No effect	No effect	
40 FB	1½ FB	No effect	No effect	
50	2	No effect	No effect	
50 FB	2 FB	No effect	No effect	
80	3	No effect	No effect	
FB = Full bore				

# Design fundamentals

o.r. = of reading, o.f.s. = of full scale value

 $\label{eq:baseAccu} {\tt BaseAccu = base\ accuracy\ in\ \%\ o.r.,\ BaseRepeat = base\ repeatability\ in\ \%\ o.r.}$ 

MeasValue = measured value; ZeroPoint = zero point stability


Calculation of the maximum measured error as a function of the flow rate

Flow rate	Maximum measured error in % o.r.
$\geq \frac{\text{ZeroPoint}}{\text{BaseAccu}} \cdot 100$	± BaseAccu
A0021332	10011333
< ZeroPoint · 100	$\pm \frac{\text{ZeroPoint}}{\text{MeasValue}} \cdot 100$
A0021333	A0021334

Calculation of the maximum repeatability as a function of the flow rate

Flow rate	Maximum repeatability in % o.r.
$\geq \frac{\frac{1}{2} \cdot \text{ZeroPoint}}{\text{BaseRepeat}} \cdot 100$	± BaseRepeat
A0021335	130213.0
$<\frac{1/2 \cdot \text{ZeroPoint}}{\text{BaseRepeat}} \cdot 100$	$\pm \frac{1}{2} \cdot \frac{\text{ZeroPoint}}{\text{MeasValue}} \cdot 100$
A0021336	A0021337

#### Example for max. measured error




- E Error: Maximum measured error as % o.r. (example)
- Q Flow rate as %

# Installation

No special measures such as supports etc. are necessary. External forces are absorbed by the construction of the device.

#### Mounting location




110020772

To prevent measuring errors arising from accumulation of gas bubbles in the measuring tube, avoid the following mounting locations in the pipe:

- Highest point of a pipeline.
- Directly upstream of a free pipe outlet in a down pipe.

#### Installation in down pipes

However, the following installation suggestion allows for installation in an open vertical pipeline. Pipe restrictions or the use of an orifice with a smaller cross-section than the nominal diameter prevent the sensor running empty while measurement is in progress.



A00287

■ 17 Installation in a down pipe (e.g. for batching applications)

- 1 Supply tank
- 2 Sensor
- 3 Orifice plate, pipe restriction
- 4 Valve
- 5 Batching tank

DN		Ø orifice plate,	pipe restriction		
[mm]	[in]	[mm]	[in]		
8	3/8	6	0.24		
15	1/2	10	0.40		
15 FB	½ FB	15	0.60		
25	1	14	0.55		
25 FB	1 FB	24	0.95		
40	1½	22	0.87		
40 FB	1½ FB	35	1.38		
50	2	28	1.10		
50 FB	2 FB	54	2.13		
80	3	50	1.97		
FB = Full bore					

# Orientation

The direction of the arrow on the sensor nameplate helps you to install the sensor according to the flow direction (direction of medium flow through the piping).

	Orientatio	n	Recommendation	
A	Vertical orientation	A0015591		
В	Horizontal orientation, transmitter head up	A0015589	✓ ✓ ¹) Exceptions:	

	Orientatio	Recommendation	
С	Horizontal orientation, transmitter head down	A0015590	Exceptions:
D	Horizontal orientation, transmitter head at side	A0015592	$\mathbf{V}$


- 1) Applications with low process temperatures may decrease the ambient temperature. To maintain the minimum ambient temperature for the transmitter, this orientation is recommended.
- 2) Applications with high process temperatures may increase the ambient temperature. To maintain the maximum ambient temperature for the transmitter, this orientation is recommended.

#### Inlet and outlet runs

# Special mounting instructions

#### Complete drainability guaranteed

When the sensor is installed in a horizontal line, eccentric clamps can be used to ensure complete drainability. When the system is pitched in a specific direction and at a specific slope, gravity can be used to achieve complete drainability. The sensor must be mounted in the correct position to ensure full drainability in the horizontal position. Markings on the sensor show the correct mounting position to optimize drainability.




A0030297

- 1 Eccentric clamp connection
- 2 "This side up" label indicates which side is up
- 3 Slope the device in accordance with the hydiene guidelines. Slope: approx. 2 % or 21 mm/m (0.24 in/feet)
- 4 Line on the underside indicates the lowest point of the eccentric process connection.

# Securing with mounting clamp in the case of hygiene connections

It is not necessary to provide additional support for the sensor for operational performance purposes. If, however, additional support is required for installation purposes, the following dimensions must be observed.

Use mounting clamp with lining between clamp and measuring instrument.



A003029


D	N	A	A	В		С		
[mm]	[in]	[mm]	[in]	[mm]	[in]	[mm]	[in]	
8	8	373	14.69	20	0.79	40	1.57	
15	15	409	16.1	20	0.79	40	1.57	
15 FB	15 FB	539	21.22	30	1.18	44.5	1.75	
25	25	539	21.22	30	1.18	44.5	1.75	
25 FB	25 FB	668	26.3	28	1.1	60	2.36	
40	40	668	26.3	28	1.1	60	2.36	
40 FB	40 FB	780	30.71	35	1.38	80	3.15	
50	50	780	30.71	35	1.38	80	3.15	
50 FB	50 FB	1152	45.35	57	2.24	90	3.54	
80	80	1152	45.35	57	2.24	90	3.54	

# Zero point adjustment

Experience shows that zero point adjustment is advisable only in special cases:

- To achieve maximum measuring accuracy even with low flow rates
- Under extreme process or operating conditions (e.g. very high process temperatures or very high-viscosity fluids).

#### **Protective cover**



# **Environment**

### Ambient temperature range

Measuring device	Non-Ex	-40 to +60 °C (-40 to +140 °F)
	Ex ec, NI version	-40 to +60 °C (-40 to +140 °F)
	Ex ia, IS version	<ul> <li>-40 to +60 °C (-40 to +140 °F)</li> <li>Order code for "Test, certificate", option JP</li> <li>-50 to +60 °C (-58 to +140 °F)</li> </ul>
Readability of the	local display	-20 to $+60$ °C ( $-4$ to $+140$ °F) The readability of the display may be impaired at temperatures outside the temperature range.


► If operating outdoors: Avoid direct sunlight, particularly in warm climatic regions.



Storage temperature	−50 to +80 °C (−58 to +176 °F)
Climate class	DIN EN 60068-2-38 (test Z/AD)
Degree of protection	Transmitter and sensor  ■ As standard: IP66/67, type 4X enclosure  ■ When housing is open: IP20, type 1 enclosure  ■ Display module: IP20, type 1 enclosure
	External WLAN antenna IP67
Vibration resistance	<ul> <li>Vibration, sinusoidal according to IEC 60068-2-6</li> <li>2 to 8.4 Hz, 3.5 mm peak</li> <li>8.4 to 2000 Hz, 1 g peak</li> <li>Vibration broad-band random, according to IEC 60068-2-64</li> <li>10 to 200 Hz, 0.003 g²/Hz</li> <li>200 to 2000 Hz, 0.001 g²/Hz</li> <li>Total: 1.54 g rms</li> </ul>
Shock resistance	Shock, half-sine according to IEC 60068-2-27 6 ms 30 g
Impact resistance	Rough handling shocks according to IEC 60068-2-31
Interior cleaning	<ul> <li>Cleaning in place (CIP)</li> <li>Sterilization in place (SIP)</li> <li>Cleaning with pigs</li> </ul>
	<b>Options</b> Oil- and grease-free version for wetted parts, without inspection certificate Order code for "Service", option <b>HA</b>
Electromagnetic compatibility (EMC)	As per IEC/EN 61326 and NAMUR Recommendation 21 (NE 21)  For details, refer to the Declaration of Conformity.

# **Process**

# Medium temperature range



 $T_A$  Ambient temperature

*T<sub>F</sub>* Medium temperature

A Maximum permitted medium temperature at  $T_{A max}$  = 60 °C (140 °F); higher medium temperatures require a reduction in the ambient temperature  $T_F$  (derating)

*B* Maximum permitted ambient temperature at the maximum specified medium temperature of the sensor

Sensor	1	Noninsulated			Insulated					
		A	I	3		A	В			
	T <sub>A</sub>	$T_{\mathrm{F}}$	T <sub>A</sub>	T <sub>F</sub>	T <sub>A</sub>	$T_{\mathrm{F}}$	T <sub>A</sub>	$T_{\mathrm{F}}$		
Promass I 300	60 °C (140 °F)	150 °C (302 °F)	-	-	60 °C (140 °F)	120 °C (248 °F)	55 ℃ (131 ℉)	150 °C (302 °F)		

#### Seals


No internal seals

Density	0 to $5000\text{kg/m}^3$ (0 to $312\text{lb/cf}$ )
---------	--

# Pressure-temperature ratings


The following pressure/temperature diagrams apply to all pressure-bearing parts of the device and not just the process connection.

# Flange according to EN 1092-1 (DIN 2501)




■ 18 With flange material 1.4301 (304); wetted parts: titanium

# Flange according to ASME B16.5




■ 19 With flange material 1.4301 (304); wetted parts: titanium

#### Flange JIS B2220




₽ 20 With flange material 1.4301 (304). Wetted parts: titanium.

# Flange DIN 11864-2 Form A



€ 21 With titanium flange material


# Threaded hygienic connection DIN 11851



**■** 22 With titanium connection material


DIN 11851 allows for applications up to +140 °C (+284 °F) if suitable sealing materials are used. Please take this into account when selecting seals and counterparts, as these components can limit the pressure and temperature range.

#### Threaded hygienic connection DIN 11864-1 Form A




■ 23 With titanium connection material

### Threaded hygienic connection ISO 2853



■ 24 With titanium connection material

#### Threaded hygienic connection SMS 1145



■ 25 With connection material 1.4404 (316L)

SMS 1145 allows for applications up to 6 bar (87 psi) if suitable sealing materials are used. Please take this into account when selecting seals and counterparts, as these components can limit the pressure and temperature range.

#### Tri-Clamp

The clamp connections are suitable up to a maximum pressure of 16 bar (232 psi). Please observe the operating limits of the clamp and seal used as they can be over 16 bar (232 psi). The clamp and seal are not included in the scope of supply.

Secondary containment pressure rating

The sensor housing is filled with dry inert gas and protects the electronics and mechanics inside.

The following secondary containment pressure rating is only valid for a fully welded sensor housing and/or a device equipped with closed purge connections (never opened/as delivered).

D	N	pressur (designed with	ontainment e rating a safety factor 4)	Secondary containment burst pressure			
[mm]	[in]	[bar]	[psi]	[bar]	[psi]		
8	3/8	40	580	220	3 190		
15	1/2	40	580	220	3 190		
15 FB	½ FB	40	580	235	3 408		
25	1	40	580	235	3 408		
25 FB	1 FB	40	580	220	3 190		
40	1½	40	580	220	3 190		
40 FB	1 ½ FB	40	580	235	3 408		
50	2	40	580	235	3 408		
50 FB	2 FB	40	580	460	6670		
80	3	40	580	460	6670		
FB = Full bore							

If there is a risk of the measuring tube breaking due to process characteristics, e.g. in the case of corrosive fluids, we recommend the use of sensors whose secondary containment is equipped with special "pressure monitoring connections" (order code for "Sensor option", option **CH** "purge connection").

With the help of these connections, the fluid collected in the secondary containment can be bled off in the event of tube failure. This is especially important in high-pressure gas applications. These connections can also be used for gas purging (gas detection).


Do not open the purge connections unless the containment can be filled immediately with a dry, inert gas. Use only low gauge pressure to purge. Maximum pressure: 5 bar (72.5 psi).

If a device fitted with purge connections is connected to the purge system, the maximum nominal pressure is determined by the purge system itself or by the device, depending on which component has the lower nominal pressure.

For information on the dimensions: see the "Mechanical construction -> Accessories" section

### Flow limit

Select the nominal diameter by optimizing between the required flow range and permissible pressure loss.



- The minimum recommended full scale value is approx. 1/20 of the maximum full scale value
- In most applications, 20 to 50 % of the maximum full scale value can be considered ideal
- A low full scale value must be selected for abrasive media (such as liquids with entrained solids): flow velocity < 1 m/s (< 3 ft/s).
- For gas measurement the following rules apply:
  - The flow velocity in the measuring tubes should not exceed half the sound velocity (0.5 Mach).
  - The maximum mass flow depends on the density of the gas: formula  $\rightarrow \triangleq 9$

#### Pressure loss




### System pressure

It is important that cavitation does not occur, or that gases entrained in the liquids do not outgas. This is prevented by means of a sufficiently high system pressure.

For this reason, the following mounting locations are recommended:

- At the lowest point in a vertical pipe
- Downstream from pumps (no danger of vacuum)



#### Thermal insulation

In the case of some fluids, it is important that the heat radiated from the sensor to the transmitter is kept to a minimum. A wide range of materials can be used for the required insulation.

#### NOTICE


#### Danger of overheating with insulation

Ensure that the temperature at the lower end of the transmitter housing does not exceed 80 °C (176 °F)

#### NOTICE

The insulation can also be thicker than the maximum recommended insulation thickness. Prerequisite:


- Ensure that convection takes place on a sufficiently large scale at the transmitter neck.
- Ensure that a sufficiently large area of the housing support remains exposed. The uncovered part serves as a radiator and protects the electronics from overheating and excessive cooling.



- Minimum distance to insulation
- maximum Insulation thickness

The minimum distance a between the transmitter and the insulation is 10 mm (0.39 in). This is to ensure that the transmitter remains completely exposed.

#### Maximum recommended insulation thickness



**2**6 **2**6 Maximum recommended insulation thickness depending on the temperature of the medium and the ambient temperature

Insulation thickness t


 $T_{\rm m}$ Medium temperature

t40<sub>(104)</sub> Maximum recommended insulation thickness at an ambient temperature of  $T_a = 40$  °C (104 °F)

Maximum recommended insulation thickness at an ambient temperature of  $T_a$  = 60 °C (140 °F) t60<sub>(140)</sub>

# $\label{lem:maximum recommended insulation thickness for the extended temperature range or insulation$

For the version extension neck for insulation order code for "Sensor option", option CG:



A0029981

#### Heating

Some fluids require suitable measures to avoid loss of heat at the sensor.

#### Heating options

- Electrical heating, e.g. with electric band heaters
- Via pipes carrying hot water or steam
- Via heating jackets



#### NOTICE

#### Danger of overheating when heating

- ► Ensure that the temperature at the lower end of the transmitter housing does not exceed 80 °C (176 °F).
- ► Ensure that convection takes place on a sufficiently large scale at the transmitter neck.
- ► Ensure that a sufficiently large area of the housing support remains exposed. The uncovered part serves as a radiator and protects the electronics from overheating and excessive cooling.


# Vibrations

The high oscillation frequency of the measuring tubes ensures that the correct operation of the measuring system is not influenced by plant vibrations.

# Mechanical construction

#### Dimensions in SI units

# **Compact version**



# Order code for "Housing", option A "Aluminum, coated"

DN	A 1)	B 1)	С	D 2)	E 2)	F	G	H <sup>3)</sup>	I <sup>3)</sup>	К	L
[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]
8	200	141	59	169	68	101	8.55	282	339.2	57.2	4)
15	200	141	59	169	68	101	11.38	282	339.2	57.2	4)
15 FB	200	141	59	169	68	101	17.07	282	339.2	57.2	4)
25	200	141	59	169	68	101	17.07	292	349.2	57.2	4)
25 FB	200	141	59	169	68	101	26.4	292	362.7	70.7	4)
40	200	141	59	169	68	101	26.4	306	376.7	70.7	4)
40 FB	200	141	59	169	68	101	35.62	306	390.2	84.2	4)
50	200	141	59	169	68	101	35.62	331.5	415.7	84.2	4)
50 FB	200	141	59	169	68	101	54.9	331.5	441.1	109.6	4)
80	200	141	59	169	68	101	54.9	331.5	441.1	109.6	4)

- For version without local display: values  $30\ mm$ 1)
- Depending on the cable gland used: values up to + 30 mm

  If using an extension neck for insulation, order code for "Sensor option", option CG: values +70 mm 2) 3) 4)
- dependent on respective process connection

#### Order code for "Housing", option A "Aluminum, coated"; Ex d

DN	A 1)	B 1)	С	D <sup>2)</sup>	E 2)	F	G	H <sup>3)</sup>	I <sup>3)</sup>	K	L
[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]
8	217	159	58	188	85	103	8.55	312	369.2	57.2	4)
15	217	159	58	188	85	103	11.38	312	369.2	57.2	4)
15 FB	217	159	58	188	85	103	17.07	312	369.2	57.2	4)
25	217	159	58	188	85	103	17.07	322	379.2	57.2	4)
25 FB	217	159	58	188	85	103	26.4	322	392.7	70.7	4)
40	217	159	58	188	85	103	26.4	336	406.7	70.7	4)
40 FB	217	159	58	188	85	103	35.62	336	420.2	84.2	4)

DN	A 1)	B 1)	С	D 2)	E 2)	F	G	H <sup>3)</sup>	I 3)	К	L
[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]
50	217	159	58	188	85	103	35.62	361.5	445.7	84.2	4)
50 FB	217	159	58	188	85	103	54.9	361.5	471.1	109.6	4)
80	217	159	58	188	85	103	54.9	361.5	471.1	109.6	4)

- For version without local display: values 38 mm 1)
- 2) Depending on the cable gland used: values up to + 30 mm
- 3) If using an extension neck for insulation, order code for "Sensor option", option CG: values +70 mm
- dependent on respective process connection


Order code for "Housing", option L "Cast, stainless"

DN	Α	В	С	D 1)	E 1)	F	G	H <sup>2)</sup>	I 2)	К	L
[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]
8	221	158	63	186	85	101	8.55	312	369.2	57.2	3)
15	221	158	63	186	85	101	11.38	312	369.2	57.2	3)
15 FB	221	158	63	186	85	101	17.07	312	369.2	57.2	3)
25	221	158	63	186	85	101	17.07	322	379.2	57.2	3)
25 FB	221	158	63	186	85	101	26.4	322	392.7	70.7	3)
40	221	158	63	186	85	101	26.4	336	406.7	70.7	3)
40 FB	221	158	63	186	85	101	35.62	336	420.2	84.2	3)
50	221	158	63	186	85	101	35.62	361.5	445.7	84.2	3)
50 FB	221	158	63	186	85	101	54.9	361.5	471.1	109.6	3)
80	221	158	63	186	85	101	54.9	361.5	471.1	109.6	3)

- Depending on the cable gland used: values up to  $\pm$  30 mm 1)
- If using an extension neck for insulation, order code for "Sensor option", option CG: values +70~mm
- 2) 3) dependent on respective process connection

# Flange connections

Fixed flange EN 1092-1, ASME B16.5, JIS B2220



Length tolerance for dimension L in mm:  $+1.5\ /\ -2.0$ 

# Flange according to EN 1092-1 (DIN 2501) Form B1 (DIN 2526 Form C): PN 40 1.4301 (304), wetted parts: titanium

Order code for "Process connection", option D2W

DN [mm]	A [mm]	B [mm]	C [mm]	D [mm]	E [mm]	L [mm]
8 <sup>1)</sup>	95	65	4 × Ø14	16	17.30	402
15	95	65	4 × Ø14	16	17.30	438
15 FB	95	65	4 × Ø14	15	17.07	572
25	115	85	4 × Ø14	19	28.50	578
25 FB	115	85	4 × Ø14	18	25.60	700
40	150	110	4 × Ø18	22	43.10	708
40 FB	150	110	4 × Ø18	20	35.62	819
50	165	125	4 × Ø18	24	54.50	827
50 FB	165	125	4 × Ø18	36	54.8	1210
80	200	160	8 × Ø18	33	82.5	1210

FB = Full bore

Surface roughness: Ra 3.2 to 12.5  $\mu m$ 

1) DN 8 with DN 15 flanges as standard

# Flange according to EN 1092-1 (DIN 2501) Form B2 (DIN 2526 Form E): PN 63 1.4301 (304), wetted parts: titanium

Order code for "Process connection", option D3W

Oraci coac joi	nucl code for Trocess connection, option B5.								
DN [mm]	A [mm]	B [mm]	C [mm]	D [mm]	E [mm]	L [mm]			
50	180	135	4 × Ø22	34	54.5	832			
50 FB	180	135	4 × Ø22	45	54.8	1210			
80	215	170	8 × Ø22	41	81.7	1210			

FB = Full bore

Surface roughness (flange): Ra 0.8 to 3.2  $\mu m$ 

# Flange according to EN 1092-1 (DIN 2501) Form B2 (DIN 2526 Form E): PN 100 1.4301 (304), wetted parts: titanium

Order code for "Process connection", option **D4W** 

Order code joi	Order code for Trocess connection, option D4W							
DN [mm]	A [mm]	B [mm]	C [mm]	D [mm]	E [mm]	L [mm]		
8 <sup>1)</sup>	105	75	4 × Ø14	25	17.30	402		
15	105	75	4 × Ø14	25	17.30	438		
15 FB	105	75	4 × Ø14	26	17.07	578		
25	140	100	4 × Ø18	29	28.50	578		
25 FB	140	100	4 × Ø18	31	25.60	706		
40	170	125	4 × Ø22	32	42.50	708		
40 FB	170	125	4 × Ø22	33	35.62	825		
50	195	145	4 × Ø26	36	53.90	832		
50 FB	195	145	4 × Ø26	48	54.8	1210		

# Flange according to EN 1092-1 (DIN 2501) Form B2 (DIN 2526 Form E): PN 100 1.4301 (304), wetted parts: titanium

Order code for "Process connection", option D4W

DN	A	B	C	D	E	L
[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]
80	230	180	8 × Ø26	58	80.9	

FB = Full bore

Surface roughness (flange): Ra 0.8 to 3.2  $\mu m$ 

#### DN 8 with DN 15 flanges as standard

# Flange according to ASME B16.5: Class 150 1.4301 (304), wetted parts: titanium

Order code for "Process connection", option AAW

, , , , , , , , , , , , , , , , , , , ,						
DN [mm]	A [mm]	B [mm]	C [mm]	D [mm]	E [mm]	L [mm]
8 <sup>1)</sup>	90	60.3	4 × Ø15.7	20	15.70	402
15	90	60.3	4 × Ø15.7	20	15.70	438
15 FB	90	60.3	4 × Ø15.7	19	17.07	572
25	110	79.4	4 × Ø15.7	23	26.70	578
25 FB	110	79.4	4 × Ø15.7	22	25.60	700
40	125	98.4	4 × Ø15.7	26	40.90	708
40 FB	125	98.4	4 × Ø15.7	24	35.62	819
50	150	120.7	4 × Ø19.1	28	52.60	827
50 FB	150	120.7	4 × Ø19.1	40	54.8	1210
80	190	152.4	4 × Ø19.1	37	78	1210

FB = Full bore

Surface roughness (flange): Ra 3.2 to 6.3  $\mu m$ 

# DN 8 with DN 15 flanges as standard

### Flange according to ASME B16.5: Class 300 1.4301 (304), wetted parts: titanium

Order code for	Order code for "Process connection", option ABW							
DN [mm]	A [mm]	B [mm]	C [mm]	D [mm]	E [mm]	L [mm]		
8 1)	95	66.7	4 × Ø15.7	20	15.70	402		
15	95	66.7	4 × Ø15.7	20	15.70	438		
15 FB	95	66.7	4 × Ø15.7	19	17.07	572		
25	125	88.9	4 × Ø19.1	23	26.70	578		
25 FB	125	88.9	4 × Ø19.1	22	25.60	700		
40	155	114.3	4 × Ø22.4	26	40.90	708		
40 FB	155	114.3	4 × Ø22.4	24	35.62	819		
50	165	127.0	8 × Ø19.1	28	52.60	827		
50 FB	165	127.0	8 × Ø19.1	43	54.8	1210		
80	210	168.3	8 × Ø22.3	42	78	1210		

FB = Full bore

Surface roughness (flange): Ra 3.2 to 6.3  $\mu m$ 

DN 8 with DN 15 flanges as standard

# Flange according to ASME B16.5: Class 600 1.4301 (304), wetted parts: titanium

Order code for "Process connection", option ACW

DN [mm]	A [mm]	B [mm]	C [mm]	D [mm]	E [mm]	L [mm]
8 <sup>1)</sup>	95	66.7	4 × Ø15.7	20	13.80	402
15	95	66.7	4 × Ø15.7	20	13.80	438
15 FB	95	66.7	4 × Ø15.7	22	17.07	578
25	125	88.9	4 × Ø19.1	23	24.40	578
25 FB	125	88.9	4 × Ø19.1	25	25.60	706
40	155	114.3	4 × Ø22.4	28	38.10	708
40 FB	155	114.3	4 × Ø22.4	29	35.62	825
50	165	127.0	8 × Ø19.1	33	49.30	832
50 FB	165	127.0	8 × Ø19.1	46	54.8	1210
80	210	168.3	8 × Ø22.3	53	73.7	1222

FB = Full bore

Surface roughness (flange): Ra 3.2 to 6.3  $\mu m$ 

1) DN 8 with DN 15 flanges as standard

#### Flange JIS B2220: 10K 1.4301 (304), wetted parts: titanium

Order code for "Process connection", option NDW

Oraci coac joi	oraci code for Process connection, option 11511							
DN [mm]	A [mm]	B [mm]	C [mm]	D [mm]	E [mm]	L [mm]		
50	155	120	4 × Ø19	28	50	827		
50 FB	195	145	4 × Ø26	48	54.8	1210		
80	200	160	8 × Ø18	37	82.5	1210		

FB = Full bore

Surface roughness (flange): Ra 3.2 to 6.3  $\mu m$ 

# Flange JIS B2220: 20K

1.4301 (304), wetted parts: titanium

Order code for "Process connection", option NEW

В С D Ε L Α [mm] [mm] [mm] [mm] [mm] [mm] [mm] 8 1) 95 70  $4 \times Ø15$ 20 15.00 402 15 95 70 4 × Ø15 20 15.00 438 15 FB 95 70  $4 \times Ø15$ 19 17.07 572 25 125 90  $4 \times Ø19$ 23 25.00 578 25 FB 125 90  $4 \times Ø19$ 22 25.60 700 40 140 105 4 × Ø19 26 40.00 708 40 FB 140 105  $4 \times Ø19$ 24 35.62 819 50 155 120 8 × Ø19 28 50.00 827 50 FB 155 120 42 1210 8 × Ø19 54.8

#### Flange JIS B2220: 20K 1.4301 (304), wetted parts: titanium Order code for "Process connection", option **NEW** DN В С D Ε L [mm] [mm] [mm] [mm] [mm] [mm] [mm] 80 200 160 $8 \times \emptyset 23$ 36 80 1210 FB = Full bore Surface roughness (flange): Ra 3.2 to 6.3 $\mu m$

1) DN 8 with DN 15 flanges as standard


Flange JIS B2220: 40K 1.4301 (304), wetted parts: titanium Order code for "Process connection", option NFW								
DN [mm]	A [mm]	B [mm]	C [mm]	D [mm]	E [mm]	L [mm]		
8 <sup>1)</sup>	115	80	4 × Ø19	25	15.00	402		
15	115	80	4 × Ø19	25	15.00	438		
15 FB	115	80	4 × Ø19	26	17.07	578		
25	130	95	4 × Ø19	27	25.00	578		
25 FB	130	95	4 × Ø19	29	25.60	706		
40	160	120	4 × Ø23	30	38.00	708		
40 FB	160	120	4 × Ø23	31	35.62	825		
50	165	130	8 × Ø19	32	50.00	827		
50 FB	165	130	8 × Ø19	43	54.8	1210		
80	210	170	8 × Ø23	46	75	1210		
FB = Full bore Surface roughr	ness (flange): Ra	ι 3.2 to 6.3 μm						

1) DN 8 with DN 15 flanges as standard

Flange JIS B2220: 63K 1.4301 (304), wetted parts: titanium Order code for "Process connection", option NHW								
DN [mm]	A [mm]	B [mm]	C [mm]	D [mm]	E [mm]	L [mm]		
8 1)	120	85	4 × Ø19	28	12.00	402		
15	120	85	4 × Ø19	28	12.80	438		
15 FB	120	85	4 × Ø19	29	17.07	578		
25	140	100	4 × Ø23	30	22.00	578		
25 FB	140	100	4 × Ø23	32	25.60	706		
40	175	130	4 × Ø25	36	35.00	708		
40 FB	175	130	4 × Ø25	37	35.62	825		
50	185	145	8 × Ø23	40	48.00	832		
50 FB	185	145	8 × Ø23	47	54.8	1210		
80	230	185	8 × Ø25	55	73	1226		
FB = Full bore Surface roughr	ness (flange): Ra	a 3.2 to 6.3 µm				,		

1) DN 8 with DN 15 flanges as standard

#### Fixed flange DIN 11864-2



*Detail X: Asymmetrical process connection; the part shown in gray is provided by the supplier.* 

Length tolerance for dimension L in mm: +1.5 / -2.0

Order code for	Order code for "Process connection", option <b>KFW</b>									
DN [mm]	A [mm]	B [mm]	C [mm]	D [mm]	E [mm]	L [mm]				
8 1)	54	37	4 × Ø9	10	10	449				
15	59	42	4 × Ø9	10	16	485				
25	70	53	4 × Ø9	10	26	625				
40	82	65	4 × Ø9	10	38	753				
50	94	77	4 × Ø9	10	50	874				
80	133	112	8 × Ø11	12	81	1268				

FB = Full bore

3A version available: order code for "Additional approval", option LP in conjunction with


Flange DIN11864-2 Form A, for pipe according to DIN11866 series A, flat flange

Ra  $\leq 0.8~\mu m$ : order code for "Measuring tube material", option CB or Ra  $\leq 0.4~\mu m$ : order code for "Measuring tube material", option CD

DN 8 with DN 15 flanges as standard

# **Clamp connections**

# Tri-Clamp



Length tolerance for dimension L in mm: +1.5 / -2.0

Tri-Clamp ( ≥ 1"), DIN 11866 series C  Titanium  Order code for "Process connection", option FTW								
DN [mm]	Clamp [in]	A [mm]	B [mm]	L [mm]				
8	1	50.4	22.1	427				
15	1	50.4	22.1	463				
15 FB	see ¾" Tri-Clamp conn	see ¾" Tri-Clamp connection						
25	1	50.4	22.1	603				
25 FB	1	50.4	22.1	730				
40	1 ½	50.4	34.8	731				
40 FB	1 ½	50.4	34.8	849				
50	2	63.9	47.5	850				
50 FB <sup>1)</sup>	2 1/2	77.4	60.3	1268				
80	3	90.9	72.9	1268				

FB = Full bore

3A version available: order code for "Additional approval", option LP in conjunction with Ra  $\leq 0.8~\mu m$ : order code for "Measuring tube material", option CB or

 $Ra \leq 0.4~\mu m;$  order code for "Measuring tube material", option CD

# Order code for "Process connection", option FRW

3/4" Tri-Clamp, DIN 11866 series C Titanium Order code for "Process connection", option FEW					
DN [mm]	Clamp [in]	A [mm]	B [mm]	L [mm]	
8	3/4	25.0	16.0	426	
15	3/4	25.0	16.0	462	
15 FB	3/4	25.0	16.0	602	

FB = Full bore

3A version available: order code for "Additional approval", option LP in conjunction with

 $Ra \le 0.8 \ \mu m$ : order code for "Measuring tube material", option CB or

 $Ra \le 0.4 \ \mu m$ : order code for "Measuring tube material", option CD

# ½" Tri-Clamp, DIN 11866 series C

Titanium

Order code for "Process connection", option FBW

DN [mm]	Clamp [in]	A [mm]	B [mm]	L [mm]
8	1/2	25.0	9.5	426
15	1/2	25.0	9.5	462

3A version available: order code for "Additional approval", option LP in conjunction with

 $Ra \leq 0.8~\mu m$  order code for "Measuring tube material", option CB or

 $Ra \leq 0.4~\mu m;$  order code for "Measuring tube material", option CD

Eccentric Tri-Cl Titanium	Eccentric Tri-Clamp, DIN 11866 series C Titanium						
DN [mm]	Order Code for "Process connection", Option	Clamp [in]	A [mm]	B [mm]	L [mm]		
8	FEA	1/2	25	9.5	427		
15	FEC	3/4	25	15.75	463		
15 FB	FEE	1	50.5	22.1	603		
25	FEE	1	50.5	22.1	603		
25 FB	FEG	1½	50.5	34.8	730		
40	FEG	1½	50.5	34.8	730		
40 FB	FEJ	2	64	47.5	849		
50	FEJ	2	64	47.5	849		
50 FB	FEL	2 ½	77.5	60.3	1268		
50 FB	FEM	3	91	72.9	1268		
80	FEL	2 ½	77.5	60.3	1268		
80	FEM	3	91	72.9	1268		

FB = Full bore

3A version available: order code for "Additional approval", option LP in conjunction with


 $Ra \leq 0.8~\mu m$ : order code for "Measuring tube material", option CB or

Ra  $\leq 0.4$  µm: order code for "Measuring tube material", option CD

Additional information on "Eccentric clamps

# Cable glands

Threaded hygienic connection DIN 11851



A0015628

Length tolerance for dimension L in mm: +1.5 / -2.0

Threaded hygienic connection DIN 11851, for pipe according to DIN11866, series A
Titanium
Order code for "Process connection", option <b>KCW</b>

DN [mm]	A [in]	B [mm]	L [mm]
8	Rd 34 × 1/8	16	427
15	Rd 34 × 1/8	16	463
15 FB	Rd 34 × 1/8	16	602
25	Rd 52 × 1/6	26	603
25 FB	Rd 52 × 1/6	26	736
40	Rd 65 × 1/6	38	731
40 FB	Rd 65 × 1/6	38	855
50	Rd 78 × 1/6	50	856
50 FB	Rd 78 × 1/6	50	1268
80	Rd 110 × 1/4	81	1268

FB = Full bore

 ${\tt 3A\ version\ available: order\ code\ for\ "Additional\ approval",\ option\ LP\ in\ conjunction\ with}$ 

 $Ra \leq 0.8~\mu m$ : order code for "Measuring tube material", option CB

# Threaded hygienic connection Rd 28 $\times$ 1/8" DIN 11851, for pipe according to DIN11866 series A Titanium

Order code for "Process connection", option KAW

DN [mm]	A [in]	B [mm]	L [mm]
8	Rd 28 × 1/8	10	426
15	Rd 28 × 1/8	10	462

3A version available: order code for "Additional approval", option LP in conjunction with Ra  $\leq$  0.8  $\mu$ m: order code for "Measuring tube material", option CB

# Threaded hygienic connection DIN11864-1 Form A, for pipe according to DIN11866, series A Titanium

Order code for "Process connection", option **KEW** 

order code for Trocess connection, option <b>KEW</b>					
DN [mm]	A [in]	B [mm]	L [mm]		
8 1)	Rd 28 × 1/8	10	428		
15	Rd 34 × 1/8	16	463		
15 FB	Rd 34 × 1/8	16	602		
25	Rd 52 × 1/6	26	603		
25 FB	Rd 52 × 1/6	26	734		
40	Rd 65 × 1/6	38	731		
40 FB	Rd 65 × 1/6	38	855		
50	Rd 78 × 1/6	50	856		
50 FB	Rd 78 × 1/6	50	1268		
80	Rd 110 × 1/4	81	1268		


FB = Full bore

3A version available (order code for "Additional approval", option LP) in combination with Ra  $\leq$  0.8  $\mu$ m, Ra  $\leq$  0.4  $\mu$ m (order code for "Measuring tube material", option CB, CD)


1) DN 8 with DN 10 threaded hygienic connection as standard

Threaded hygienic connection SMS 1145 Titanium Order code for "Process connection", option SCS						
DN [mm]	A [in]	B [mm]	L [mm]			
8	Rd 40 × 1/6	22.5	427			
15	Rd 40 × 1/6	22.5	463			
25	Rd 40 × 1/6	22.5	603			
25 FB	Rd 40 × 1/6	22.5	736			
40	Rd 60 × 1/6	35.5	738			
40 FB	Rd 60 × 1/6	35.5	857			
50	Rd 70 × 1/6	48.5	858			
50 FB	Rd 70 × 1/6	48.5	1258			
80 Rd 98 × 1/6 72 1268						
FB = Full bore 3A version available (Ra $\leq$ 0.8 $\mu$ m) (order code for "Additional approval", option LP)						

# Threaded hygienic connection ISO 2853



A001562



Threaded hygienic connection ISO 2853, for pipe according to ISO 2037  Titanium  Order code for "Process connection", option JSE					
DN [mm]	A [in]	B [mm]	L [mm]		
8 1)	37.13	22.6	435		
15	37.13	22.6	471		
15 FB	37.13	22.6	610		
25 FB	37.13	22.6	744		
40	50.65	35.6	737		
40 FB	50.65	35.6	859		
50	64.16	48.6	856		
50 FB	64.1	48.6	1268		

Threaded hygienic connection ISO 2853, for pipe according to ISO 2037 Titanium Order code for "Process connection", option JSE				
DN [mm]	A [in]	B [mm]	L [mm]	
80	91.19	72.9	1268	


FB = Full bore

3A version available (order code for "Additional approval", option LP) in combination with Ra  $\leq$  0.8  $\mu m$ , Ra  $\leq$  0.4  $\mu m$  (order code for "Measuring tube material", option CB, CD)

1) DN 8 with DN 15 threaded hygienic connection as standard

#### Accessories

Purge connections / secondary containment monitoring




A002996

1 Connection nipple for purge connections/pressure vessel monitoring: order code for "Sensor options", option CH "Purge connection"


DN	A	L
[mm]	[mm]	[mm]
8	90.65	122
15	90.65	158
15 FB	90.65	158
25	90.65	296
25 FB	90.65	296
40	103.35	392
40 FB	103.35	392
50	117.75	488
50 FB	145.5	814
80	145.5	814

# Remote display and operating module DKX001



■ 28 Engineering unit mm (in)


# External WLAN antenna



■ 29 Engineering unit mm (in)

# Dimensions in US units

# **Compact version**



Endress+Hauser 65

A0029789

Order code	for "Housing",	ontion A	"Aluminum.	coated"

DN	A 1)	B 1)	С	D 2)	E 2)	F	G	H <sup>3)</sup>	I 3)	K	L
[in]	[in]	[in]	[in]	[in]	[in]	[in]	[in]	[in]	[in]	[in]	[in]
3/8	7.87	5.55	2.32	6.65	2.68	3.98	0.211	11.1	13.35	2.25	4)
1/2	7.87	5.55	2.32	6.65	2.68	3.98	0.33	11.1	13.35	2.25	4)
½ FB	7.87	5.55	2.32	6.65	2.68	3.98	0.47	11.1	13.35	2.25	4)
1	7.87	5.55	2.32	6.65	2.68	3.98	0.47	11.5	13.75	2.25	4)
1 FB	7.87	5.55	2.32	6.65	2.68	3.98	0.69	11.5	14.28	2.78	4)
1½	7.87	5.55	2.32	6.65	2.68	3.98	0.69	12.05	14.83	2.78	4)
1½ FB	7.87	5.55	2.32	6.65	2.68	3.98	1.02	12.05	15.36	3.31	4)
2	7.87	5.55	2.32	6.65	2.68	3.98	1.02	13.05	16.37	3.31	4)
2 FB	7.87	5.55	2.32	6.65	2.68	3.98	1.02	13.05	17.37	4.31	4)
3	7.87	5.55	2.32	6.65	2.68	3.98	1.02	13.05	17.37	4.31	4)

- 1) For version without local display: values 1.18 in
- 2) Depending on the cable gland used: values up to + 1.18 in
- 3) If using an extension neck for insulation, order code for "Sensor option", option CG: values +70 mm
- 4) dependent on respective process connection

# Order code for "Housing", option A "Aluminum, coated"; Ex d

DN	A 1)	B 1)	С	D 2)	E 2)	F	G	H <sup>3)</sup>	I <sub>3)</sub>	K	L
[in]	[in]	[in]	[in]	[in]	[in]	[in]	[in]	[in]	[in]	[in]	[in]
3/8	8.54	6.26	2.28	7.4	3.35	4.06	0.211	12.28	14.54	2.25	4)
1/2	8.54	6.26	2.28	7.4	3.35	4.06	0.33	12.28	14.54	2.25	4)
½ FB	8.54	6.26	2.28	7.4	3.35	4.06	0.47	12.28	14.54	2.25	4)
1	8.54	6.26	2.28	7.4	3.35	4.06	0.47	12.68	14.93	2.25	4)
1 FB	8.54	6.26	2.28	7.4	3.35	4.06	0.69	12.68	15.46	2.78	4)
11/2	8.54	6.26	2.28	7.4	3.35	4.06	0.69	13.23	16.01	2.78	4)
1½ FB	8.54	6.26	2.28	7.4	3.35	4.06	1.02	13.23	16.54	3.31	4)
2	8.54	6.26	2.28	7.4	3.35	4.06	1.02	14.23	17.55	3.31	4)
2 FB	8.54	6.26	2.28	7.4	3.35	4.06	1.02	14.23	18.55	4.31	4)
3	8.54	6.26	2.28	7.4	3.35	4.06	1.02	14.23	18.55	4.31	4)

- 1) For version without local display: values 1.49 in
- 2) Depending on the cable gland used: values up to + 1.18 in
- 3) If using an extension neck for insulation, order code for "Sensor option", option CG: values +70 mm
- ${\tt 4)} \qquad {\tt dependent} \ {\tt on} \ {\tt respective} \ {\tt process} \ {\tt connection}$

# Order code for "Housing", option L "Cast, stainless"


DN	A	В	С	D 1)	E 1)	F	G	H 2)	I 2)	К	L
[in]	[in]	[in]	[in]	[in]							
3/8	8.7	6.22	2.48	7.32	3.35	3.98	0.211	12.28	14.54	2.25	3)
1/2	8.7	6.22	2.48	7.32	3.35	3.98	0.33	12.28	14.54	2.25	3)
½ FB	8.7	6.22	2.48	7.32	3.35	3.98	0.47	12.28	14.54	2.25	3)
1	8.7	6.22	2.48	7.32	3.35	3.98	0.47	12.68	14.93	2.25	3)
1 FB	8.7	6.22	2.48	7.32	3.35	3.98	0.69	12.68	15.46	2.78	3)
11/2	8.7	6.22	2.48	7.32	3.35	3.98	0.69	13.23	16.01	2.78	3)

DN	A	В	С	D 1)	E 1)	F	G	H <sup>2)</sup>	I 2)	К	L
[in]	[in]	[in]	[in]	[in]	[in]	[in]	[in]	[in]	[in]	[in]	[in]
1½ FB	8.7	6.22	2.48	7.32	3.35	3.98	1.02	13.23	16.54	3.31	3)
2	8.7	6.22	2.48	7.32	3.35	3.98	1.02	14.23	17.55	3.31	3)
2 FB	8.7	6.22	2.48	7.32	3.35	3.98	1.02	14.23	18.55	4.31	3)
3	8.7	6.22	2.48	7.32	3.35	3.98	1.02	14.23	18.55	4.31	3)

- Depending on the cable gland used: values up to + 1.18 in
- 2) 3) If using an extension neck for insulation, order code for "Sensor option", option CG: values +70 mm
- dependent on respective process connection

# Flange connections

Fixed flange ASME B16.5



Length tolerance for dimension  $\boldsymbol{L}$  in inch: +0.06 / -0.08

Flange according 1.4301 (304), we order code for "P	vetted parts: 1	itanium				
DN [in]	A [in]	B [in]	C [in]	D [in]	E [in]	L [in]
3/8 1)	3.54	2.37	4 × Ø0.62	0.79	0.62	15.83
1/2	3.54	2.37	4 × Ø0.62	0.79	0.62	17.24
½ FB	3.54	2.37	4 × Ø0.62	0.75	0.67	22.52
1	4.33	3.13	4 × Ø0.62	0.91	1.05	22.76
1 FB	4.33	3.13	4 × Ø0.62	0.87	1.01	27.56
11/2	4.92	3.87	4 × Ø0.62	1.02	1.61	27.87
1½ FB	4.92	3.87	4 × Ø0.62	0.94	1.4	32.24
2	5.91	4.75	4 × Ø0.75	1.1	2.07	32.56
2 FB	5.91	4.75	4 × Ø0.75	1.57	2.16	47.64
3	7.48	6.00	4 × Ø0.75	1.46	3.07	47.64
FB = Full bore	•					

Surface roughness (flange): Ra 125 to 248  $\mu in$ 

DN 3/8" with DN  $\frac{1}{2}$ " flanges as standard;

Flange according to ASME B16.5: Class 300 1.4301 (304), wetted parts: titanium Order code for "Process connection", option ABW								
DN [in]	A [in]	B [in]	C [in]	D [in]	E [in]	L [in]		
3/8 1)	3.74	2.63	4 × Ø0.62	0.79	0.62	15.83		
1/2	3.74	2.63	4 × Ø0.62	0.79	0.62	17.24		
½ FB	3.74	2.63	4 × Ø0.62	0.75	0.67	22.52		
1	4.92	3.50	4 × Ø0.75	0.91	1.05	22.76		
1 FB	4.92	3.50	4 × Ø0.75	0.87	1.01	27.56		
1½	6.10	4.50	4 × Ø0.88	1.02	1.61	27.87		
1½ FB	6.10	4.50	4 × Ø0.88	0.94	1.4	32.24		
2	6.50	5.00	8 × Ø0.75	1.1	2.07	32.56		
2 FB	6.50	5.00	8 × Ø0.75	1.69	2.16	47.64		
3	8.27	6.63	8 × Ø0.88	1.65	3.07	47.64		
FB = Full bore Surface roughne	ss (flange): Ra	ı 125 to 248 μ	ıin					


1) DN 3/8" with DN  $\frac{1}{2}$ " flanges as standard;

Flange according to ASME B16.5: Class 600 1.4301 (304), wetted parts: titanium Order code for "Process connection", option ACW								
DN [in]	A [in]	B [in]	C [in]	D [in]	E [in]	L [in]		
3/8 1)	3.74	2.63	4 × Ø0.62	0.79	0.54	15.83		
1/2	3.74	2.63	4 × Ø0.62	0.79	0.54	17.24		
½ FB	3.74	2.63	4 × Ø0.62	0.87	0.67	22.76		
1	4.92	3.50	4 × Ø0.75	0.91	0.96	22.76		
1 FB	4.92	3.50	4 × Ø0.75	0.98	1.01	27.8		
1½	6.10	4.50	4 × Ø0.88	1.1	1.5	27.87		
1½ FB	6.10	4.50	4 × Ø0.88	1.14	1.4	32.48		
2	6.50	5.00	8 × Ø0.75	1.3	1.94	32.76		
2 FB	6.50	5.00	8 × Ø0.75	1.81	2.16	47.64		
3	8.27	6.63	8 × Ø0.88	2.09	2.9	48.11		
FB = Full bore Surface roughnes	ss (flange): Ra	125 to 248 µ	ıin					

1) DN 3/8" with DN  $\frac{1}{2}$ " flanges as standard;

# **Clamp connections**

# Tri-Clamp



Length tolerance for dimension L in inch:  $+0.06\ /\ -0.08$ 

Tri-Clamp ( ≥ 1"), DIN 11866 series C  Titanium  Order code for "Process connection", option FTW								
DN [in]	Clamp [in]	A [in]	B [in]	L [in]				
3/8	1	1.98	0.87	16.81				
1/2	1	1.98	0.87	18.23				
½ FB	see ¾" Tri-Clamp connection							
1	1	1.98	0.87	23.74				
1 FB	1	1.98	0.87	28.74				
1½	1 ½	1.98	1.37	28.78				
1½ FB	1 1/2	1.98	1.37	33.43				
2	2	2.52	1.87	33.46				
2 FB 1)	2 1/2	3.05	2.37	49.92				
3	3	3.58	2.87	49.92				

FB = Full bore

3A version available: order code for "Additional approval", option LP in conjunction with Ra  $\leq 32~\mu in$ : order code for "Measuring tube material", option CB or

 $Ra \leq 16~\mu in$ : order code for "Measuring tube material", option CD

# Order code for "Process connection", option FRW

3/4" Tri-Clamp, DIN 11866 series C Titanium Order code for "Process connection", option FEW									
DN [in]	Clamp [in]	A [in]	B [in]	L [in]					
3/8	3/4	0.98	0.63	16.77					
1/2	3/4	0.98	0.63	18.19					
½ FB	½ FB ¾ 0.98 0.63 23.7								

3A version available: order code for "Additional approval", option LP in conjunction with

 $Ra \le 32 \mu in$ : order code for "Measuring tube material", option CB or

 $Ra \le 16~\mu in$ : order code for "Measuring tube material", option CD

1½" Tri-Clamp, DIN 11866 series C Titanium Order code for "Process connection", option FBW							
DN [in]	Clamp [in]	A [in]	B [in]	L [in]			
3/8	1/2	0.98	0.37	16.77			
1/2	1/2	0.98	0.37	18.19			

3A version available: order code for "Additional approval", option LP in conjunction with

Ra  $\leq$  32  $\mu$ in: order code for "Measuring tube material", option CB or Ra  $\leq$  16  $\mu$ in: order code for "Measuring tube material", option CD

Eccentric Tri-Cl	Eccentric Tri-Clamp, DIN 11866 series C Titanium								
DN [in]	Order Code for "Process connection", Option	Clamp [in]	A [in]	B [in]	L [in]				
3/8	FEA	1/2	0.98	0.37	16.81				
1/2	FEC	3/4	0.98	0.62	18.23				
½ FB	FEE	1	1.99	0.87	23.74				
1	FEE	1	1.99	0.87	23.74				
1 FB	FEG	1½	1.99	1.37	28.74				
1½	FEG	1½	1.99	1.37	28.74				
1½ FB	FEJ	2	2.52	1.87	33.43				
2	FEJ	2	2.52	1.87	33.43				
2 FB	FEL	2 ½	3.05	2.37	49.92				
2 FB	FEM	3	3.58	2.87	49.92				
3	FEL	2 ½	3.05	2.37	49.92				
3	FEM	3	3.58	2.87	49.92				


3A version available: order code for "Additional approval", option LP in conjunction with

Ra  $\leq$  32  $\mu$ in: order code for "Measuring tube material", option CB or Ra  $\leq$  16  $\mu$ in: order code for "Measuring tube material", option CD

Additional information on "Eccentric clamps

# Cable glands

Threaded hygienic connection SMS 1145



A0015628


Length tolerance for dimension L in inch:  $+0.06 \ / \ -0.08$ 

Threaded hygienic connection SMS 1145 Titanium Order code for "Process connection", option SCS								
DN [in]	A [in]	B [in]	L [in]					
3/8	Rd 40 × 1/6	0.89	16.81					
1/2	Rd 40 × 1/6	0.89	18.23					
1	Rd 40 × 1/6	0.89	23.74					
1 FB	Rd 40 × 1/6	0.89	28.98					
11/2	Rd 60 × 1/6	1.4	29.06					
1½ FB	Rd 60 × 1/6	1.4	33.74					
2	Rd 70 × 1/6	1.91	33.78					
2 FB	Rd 70 × 1/6	1.91	49.53					
3	Rd 98 × 1/6	2.83	49.92					
FB = Full bore		1						

# Accessories

Purge connections / secondary containment monitoring


 $Ra \leq 32~\mu in$ : order code for "Measuring tube material", option CB or



1 Connection nipple for purge connections/pressure vessel monitoring: order code for "Sensor options", option CH "Purge connection"


DN	A	L
[in]	[in]	[in]
3/8	3.569	4.8
1/2	3.569	6.22
½ FB	3.569	6.22
1	3.569	11.65
1 FB	3.569	11.65
1½	4.069	15.43
1½ FB	4.069	15.43
2	4.636	19.21
2 FB	5.73	32.05
3	5.73	32.05

# Remote display and operating module DKX001



**■** 30 Engineering unit mm (in)

#### External WLAN antenna



■ 31 Engineering unit mm (in)

Weight

Cast transmitter version, stainless: +6 kg (+13 lbs)

Transmitter version for the hazardous area: +2 kg (+4.4 lbs)

All values (weight) refer to devices with EN/DIN PN 40 flanges.

# Weight in SI units

DN [mm]	Weight [kg]
8	11
15	13
15 FB	19
25	20
25 FB	39
40	40
40 FB	65
50	67
50 FB	118

DN [mm]	Weight [kg]
80	122
FB = Full bore	

## Weight in US units

DN [in]	Weight [lbs]
3/8	24
1/2	29
½ FB	42
1	44
1 FB	86
1½	88
1½ FB	143
2	148
2 FB	260
3	269
FB = Full bore	

#### Materials

#### Transmitter housing

Order code for "Housing":


- Option **A** "Aluminum, coated": aluminum, AlSi10Mg, coated
- Option L "Cast, stainless": cast, stainless steel, 1.4409 (CF3M) similar to 316L

## Window material

Order code for "Housing":

- Option A "Aluminum, coated": glass
- Option L "Cast, stainless": glass

## Cable entries/cable glands



VUU3838

## ■ 32 Possible cable entries/cable glands

- 1 Cable entry with M20  $\times$  1.5 internal thread
- 2 Cable gland  $M20 \times 1.5$
- 3 Adapter for cable entry with internal thread  $G \frac{1}{2}$  or NPT  $\frac{1}{2}$ "
- 4 Device plug coupling

Order code for "Housing", option A "Aluminum, coated"

The various cable entries are suitable for hazardous and non-hazardous areas.

Cable entry/cable gland	Material
Cable gland M20 × 1.5	Plastic/nickel-plated brass
Adapter for cable entry with internal thread G ½"	Nickel-plated brass
Adapter for cable entry with internal thread NPT ½"	
Device plug coupling	Plug M12 × 1  Socket: Stainless steel, 1.4404 (316L)  Contact housing: Polyamide  Contacts: Gold-plated brass

Order code for "Housing", option L "Cast, stainless"

The various cable entries are suitable for hazardous and non-hazardous areas.

Cable entry/cable gland	Material
Cable gland M20 × 1.5	Stainless steel, 1.4404 (316L)
Adapter for cable entry with internal thread G ½"	
Adapter for cable entry with internal thread NPT ½"	
Device plug coupling	Plug M12 × 1 Socket: Stainless steel, 1.4404 (316L) Contact housing: Polyamide Contacts: Gold-plated brass

## Device plug

Electrical connection	Material
Plug M12x1	<ul> <li>Socket: Stainless steel, 1.4404 (316L)</li> <li>Contact housing: Polyamide</li> <li>Contacts: Gold-plated brass</li> </ul>

#### Sensor housing


- Acid and alkali-resistant outer surface
- Stainless steel 1.4301 (304)

## Measuring tubes

Grade 9 titanium

#### **Process connections**

- Flanges according to EN 1092-1 (DIN 2501) / according to ASME B16.5/ according to JIS:
  - Stainless steel 1.4301 (304)
  - Wetted parts: Grade 2 titanium
- All other process connections: Grade 2 titanium



#### Seals

Welded process connections without internal seals

## Accessories

Protective cover

Stainless steel, 1.4404 (316L)

#### External WLAN antenna

WLAN antenna:

ASA plastic (acrylic ester-styrene-acrylonitrile) and nickel-plated brass

Adapter:

Stainless steel and copper

#### **Process connections**

- Fixed flange connections:
  - EN 1092-1 (DIN 2501) flange
  - EN 1092-1 (DIN 2512N) flange
  - ASME B16.5 flange
  - JIS B2220 flange
  - DIN 11864-2 Form A flange, DIN11866 series A, flat flange
- Clamp connections

Tri-Clamp (OD tubes), DIN 11866 series C

• Excentric clamp connection:

Excen. Tri-Clamp, DIN 11866 series C

- Threaded hygienic connection:
  - DIN 11851 threaded hygienic connection, DIN11866 series A
  - SMS 1145 threaded hygienic connection
  - ISO 2853 threaded hygienic connection, ISO2037
  - DIN 11864-1 Form A threaded hygienic connection, DIN11866 series A



#### Surface roughness

All data relate to parts in contact with fluid.

- Not polished
- $Ra_{max} = 0.8 \mu m (32 \mu in)$
- $Ra_{max} = 0.4 \mu m (16 \mu in)$

## **Operability**

#### Operating concept

#### Operator-oriented menu structure for user-specific tasks

- Commissioning
- Operation
- Diagnostics
- Expert level

#### Fast and safe commissioning

- Guided menus ("Make-it-run" wizards) for applications
- Menu quidance with brief explanations of the individual parameter functions
- Device access via Web server
- Optional: WLAN access to device via mobile handheld terminal

#### Reliable operation

- Operation in local language → 🖺 75
- Uniform operating philosophy applied to device and operating tools
- If replacing electronic modules, transfer the device configuration via the integrated memory (integrated HistoROM) which contains the process and measuring device data and the event logbook. No need to reconfigure.

#### Efficient diagnostics increase measurement availability

- Troubleshooting measures can be called up via the device and in the operating tools
- Diverse simulation options, logbook for events that occur and optional line recorder functions

#### Languages

Can be operated in the following languages:

- Via local operation
  - English, German, French, Spanish, Italian, Dutch, Portuguese, Polish, Russian, Turkish, Chinese, Japanese, Korean, Arabic, Bahasa (Indonesian), Thai, Vietnamese, Czech, Swedish
- Via Web browser
  - English, German, French, Spanish, Italian, Dutch, Portuguese, Polish, Russian, Turkish, Chinese, Japanese, Korean, Arabic, Bahasa (Indonesian), Thai, Vietnamese, Czech, Swedish
- Via "FieldCare", "DeviceCare" operating tool: English, German, French, Spanish, Italian, Chinese, Japanese

#### Local operation


### Via display module

Two display modules are available:

- Order code for "Display; operation", option **F** "4-line, backlit, graphic display; touch control"
- Order code for "Display; operation", option G "4-line, backlit, graphic display; touch control + WLAN"



Information about WLAN interface → 🖺 80



33 Operation with touch control

## Display elements

- 4-line, illuminated, graphic display
- White background lighting; switches to red in event of device errors
- Format for displaying measured variables and status variables can be individually configured
- Permitted ambient temperature for the display: -20 to +60 °C (-4 to +140 °F)
  The readability of the display may be impaired at temperatures outside the temperature range.

#### Operating elements

- External operation via touch control (3 optical keys) without opening the housing: ±, ⊡, ©
- Operating elements also accessible in various hazardous areas


#### Via remote display and operating module DKX001

The remote display and operating module DKX001 is available as an optional extra: Order code for "Display; operation", option  $\bf 0$  "Separate backlit, 4-line display; 10 m (30 ft) Cable; touch control"



Another device version, e.g. other housing material, other cable length etc., can be ordered via the separate product structure DKX001. The measuring device is ordered with:

Order code for "Display; operation", option **M** "None, prepared for remote display"



A002678

■ 34 Operation via remote display and operating module DKX001

76

#### Display and operating elements



- The measuring device is always supplied with a dummy cover when the remote display and operating module DKX001 is used. Display or operation at the transmitter is not possible in this case.
- If ordered subsequently: The remote display and operating module DKX001 cannot be connected at the same time as the existing display or operation unit. Only one display or operation unit may be connected to the transmitter at any one time.

#### Material

The housing material of the display and operating module DKX001 depends on the choice of transmitter housing material.

Transmitter housing		Remote display and operating module
Order code for "Housing"	Material	Material
Option <b>A</b> "Aluminum, coated"	AlSi10Mg, coated	AlSi10Mg, coated
Option <b>L</b> "Cast, stainless"	Cast stainless steel, 1.4409 (CF3M) similar to 316L	1.4409 (CF3M)

#### Cable entry

Corresponds to the choice of transmitter housing, order code for "Electrical connection".

#### Connecting cable

→ 🖺 36


### Dimensions

→ 🖺 65

#### Remote operation

## Via HART protocol

This communication interface is available in device versions with a HART output.




A002976

■ 35 Options for remote operation via HART protocol (active)

- 1 Control system (e.g. PLC)
- 2 Field Communicator 475
- 3 Computer with Web browser (e.g. Internet Explorer) for accessing the integrated device Web server or computer with operating tool (e.g. FieldCare, DeviceCare, AMS Device Manager, SIMATIC PDM) with COM DTM "CDI Communication TCP/IP"
- 4 Commubox FXA195 (USB)
- 5 Field Xpert SFX350 or SFX370
- 6 VIATOR Bluetooth modem with connecting cable

7 Transmitter




**■** 36 Options for remote operation via HART protocol (passive)

- Control system (e.g. PLC) 1
- 2 Transmitter power supply unit, e.g. RN221N (with communication resistor)
- Connection for Commubox FXA195 and Field Communicator 475 3
- 4 Field Communicator 475 Computer with Web browser (e.g. Internet Explorer) for accessing the integrated device Web server or  $computer\ with\ operating\ tool\ (e.g.\ Field Care,\ Device Care,\ AMS\ Device\ Manager,\ SIMATIC\ PDM)\ with\ COM$
- DTM "CDI Communication TCP/IP" Commubox FXA195 (USB) 6
- Field Xpert SFX350 or SFX370
- 8 VIATOR Bluetooth modem with connecting cable
- Transmitter

#### Via FOUNDATION Fieldbus network

This communication interface is available in device versions with FOUNDATION Fieldbus.




Options for remote operation via FOUNDATION Fieldbus network

- 1 Automation system
- 2 Computer with FOUNDATION Fieldbus network card
- Industry network 3
- 4 High Speed Ethernet FF-HSE network
- Segment coupler FF-HSE/FF-H1 5
- FOUNDATION Fieldbus FF-H1 network 6
- 7 Power supply FF-H1 network
- 8 T-box
- Measuring device

#### Via PROFIBUS PA network

This communication interface is available in device versions with PROFIBUS PA.




A0020020

 $\blacksquare$  38 Options for remote operation via PROFIBUS PA network

- 1 Automation system
- 2 Computer with PROFIBUS network card
- 3 PROFIBUS DP network
- 4 Segment coupler PROFIBUS DP/PA
- 5 PROFIBUS PA network
- 6 T-box
- 7 Measuring device

#### Via Modbus RS485 protocol

This communication interface is available in device versions with a Modbus-RS485 output.




A002943

Options for remote operation via Modbus-RS485 protocol (active)

- 1 Control system (e.g. PLC)
- 2 Computer with Web browser (e.g. Internet Explorer) for accessing the integrated device Web server or with operating tool (e.g. FieldCare, DeviceCare) with COM DTM "CDI Communication TCP/IP" or Modbus DTM
- 3 Transmitter

#### Service interface

#### Via service interface (CDI-RJ45)




■ 40 Connection via service interface (CDI-RJ45)

- 1 Computer with Web browser (e.g. Microsoft Internet Explorer, Microsoft Edge) for accessing the integrated device Web server or with "FieldCare", "DeviceCare" operating tool with COM DTM "CDI Communication TCP/IP" or Modbus DTM
- 2 Standard Ethernet connecting cable with RJ45 connector
- 3 Service interface (CDI-RJ45) of the measuring device with access to the integrated Web server

#### Via WLAN interface

The optional WLAN interface is available on the following device version: Order code for "Display; operation", option  $\mathbf{G}$  "4-line, backlit, graphic display; touch control + WLAN"



A002883

- 1 Transmitter with integrated WLAN antenna
- 2 Transmitter with external WLAN antenna
- ${\it 3} \qquad {\it LED lit constantly: WLAN reception is enabled on measuring device}$
- 4 LED flashing: WLAN connection established between operating unit and measuring device
- 5 Computer with WLAN interface and Web browser (e.g. Microsoft Internet Explorer, Microsoft Edge) for accessing the integrated device Web server or with operating tool (e.g. FieldCare, DeviceCare)
- 6 Mobile handheld terminal with WLAN interface and Web browser (e.g. Microsoft Internet Explorer, Microsoft Edge) for accessing the integrated device Web server or operating tool (e.g. FieldCare, DeviceCare)

Wireless LAN	IEEE 802.11 b/g (2.4 GHz) WLAN
Encryption	WPA2 PSK/TKIP AES-128
Configurable channels	1 to 11
Function	Access point with DHCP
Range with integrated antenna	Max. 10 m (32 ft)
Range with external antenna	Max. 50 m (164 ft)

80

#### Supported operating tools

Different operating tools can be used for local or remote access to the measuring device. Depending on the operating tool used, access is possible with different operating units and via a variety of interfaces.

Supported operating tools	Operating unit	Interface	Additional information
Web browser	Notebook, PC or tablet with Web browser	<ul><li>CDI-RJ45 service interface</li><li>WLAN interface</li></ul>	Special Documentation for the device → 🖺 91
DeviceCare SFE100	Notebook, PC or tablet with Microsoft Windows system	<ul><li>CDI-RJ45 service interface</li><li>WLAN interface</li><li>Fieldbus protocol</li></ul>	→ 🖺 89
FieldCare SFE500	Notebook, PC or tablet with Microsoft Windows system	<ul><li>CDI-RJ45 service interface</li><li>WLAN interface</li><li>Fieldbus protocol</li></ul>	→ 🖺 89
Device Xpert	Field Xpert SFX 100/350/370	HART and FOUNDATION Fieldbus fieldbus protocol	Operating Instructions BA01202S Device description files: Use update function of handheld terminal

- Other operating tools based on FDT technology with a device driver such as DTM/iDTM or DD/EDD can be used for device operation. These operating tools are available from the individual manufacturers. Integration into the following operating tools, among others, is supported:
  - Process Device Manager (PDM) by Siemens → www.siemens.com
  - Asset Management Solutions (AMS) by Emerson → www.emersonprocess.com
  - FieldCommunicator 375/475 by Emerson  $\rightarrow$  www.emersonprocess.com
  - Field Device Manager (FDM) by Honeywell → www.honeywellprocess.com
  - FieldMate by Yokogawa → www.yokogawa.com
  - PACTWare → www.pactware.com

The associated device description files are available at: www.endress.com → Downloads

#### Web server

Thanks to the integrated Web server, the device can be operated and configured via a Web browser and via a service interface (CDI-RJ45) or a WLAN interface. The structure of the operating menu is the same as for the local display. In addition to the measured values, status information on the device is also displayed and allows the user to monitor the status of the device. Furthermore the measuring device data can be managed and the network parameters can be configured. The WLAN connection requires a device that acts as an access point to enable communication via a computer or mobile handheld terminal.

#### Supported functions

Data exchange between the operating unit (such as a notebook for example) and the measuring device:

- Uploading the configuration from the measuring device (XML format, configuration backup)
- Save the configuration to the measuring device (XML format, restore configuration)
- Export event list (.csv file)
- Export parameter settings (.csv file, create documentation of the measuring point configuration)
- Export the Heartbeat verification log (PDF file, only available with the "Heartbeat Verification" application package)
- Flash firmware version for device firmware upgrade, for instance

#### HistoROM data management

The measuring device features HistoROM data management. HistoROM data management comprises both the storage and import/export of key device and process data, making operation and servicing far more reliable, secure and efficient.

i

When the device is delivered, the factory settings of the configuration data are stored as a backup in the device memory. This memory can be overwritten with an updated data record, for example after commissioning.

#### Additional information on the data storage concept

There are different types of data storage units in which device data are stored and used by the device:

	Device memory	T-DAT	S-DAT
Available data	<ul> <li>Event history, such as diagnostic events</li> <li>Parameter data record backup</li> <li>Device firmware package</li> <li>Driver for system integration e.g.:         <ul> <li>DD for HART</li> <li>GSD for PROFIBUS PA</li> <li>DD for FOUNDATION Fieldbus</li> </ul> </li> </ul>	<ul> <li>Measured value memory ("Extended HistoROM" order option)</li> <li>Current parameter data record (used by firmware at run time)</li> <li>Maximum indicators (min/max values)</li> <li>Totalizer values</li> </ul>	<ul> <li>Sensor data: diameter etc.</li> <li>Serial number</li> <li>User-specific access code (to use the "Maintenance" user role)</li> <li>Calibration data</li> <li>Device configuration (e.g. SW options, fixed I/O or multi I/O)</li> </ul>
Storage location	Fixed on the user interface board in the connection compartment	Can be plugged into the user interface board in the connection compartment	In the sensor plug in the transmitter neck part

### Data backup

#### **Automatic**

- The most important device data (sensor and transmitter) are automatically saved in the DAT modules
- If the transmitter or measuring device is replaced: once the T-DAT containing the previous device data has been exchanged, the new measuring device is ready for operation again immediately without any errors
- If the sensor is replaced: once the sensor has been replaced, new sensor data are transferred from the S-DAT in the measuring device and the measuring device is ready for operation again immediately without any errors

#### Manual

Additional parameter data record (complete parameter settings) in the integrated device memory for:

- Data backup function
  - Backup and subsequent restoration of a device configuration in the device memory
- Data comparison function
   Comparison of the current device configuration with the device configuration saved in the device memory

#### Data transfer

#### Manual

Transfer of a device configuration to another device using the export function of the specific operating tool, e.g. with FieldCare, DeviceCare or Web server: to duplicate the configuration or to store in an archive (e.g. for backup purposes)

#### **Event list**

#### Automatic

- Chronological display of up to 20 event messages in the events list
- If the Extended HistoROM application package (order option) is enabled: up to 100 event messages are displayed in the events list along with a time stamp, plain text description and remedial measures
- The events list can be exported and displayed via a variety of interfaces and operating tools e.g. DeviceCare, FieldCare or Web server

#### Data logging

### Manual

If the **Extended HistoROM** application package (order option) is enabled:

- Record up to 1000 measured values via 1 to 4 channels
- User configurable recording interval
- Record up to 250 measured values via each of the 4 memory channels
- Export the measured value log via a variety of interfaces and operating tools e.g. FieldCare, DeviceCare or Web server
- Use the recorded measured value data in the integrated device simulation function in the Diagnostics submenu.

#### Service logbook

#### Manual

- Create up to 20 user-specific events with a date and customized text in a separate logbook for documentation of the measuring point
- Use for calibration or service operations, for example, or for maintenance or revision work that has been performed

## Certificates and approvals

#### **CE** mark

The measuring system is in conformity with the statutory requirements of the applicable EU Directives. These are listed in the corresponding EU Declaration of Conformity along with the standards applied.

Endress+Hauser confirms successful testing of the device by affixing to it the CE mark.

#### C-Tick symbol

The measuring system meets the EMC requirements of the "Australian Communications and Media Authority (ACMA)".

#### Ex approval

The measuring device is certified for use in hazardous areas and the relevant safety instructions are provided in the separate "Safety Instructions" (XA) document. Reference is made to this document on the nameplate.



The separate Ex documentation (XA) containing all the relevant explosion protection data is available from your Endress+Hauser sales center.

#### ATEX/IECEx

Currently, the following versions for use in hazardous areas are available:

#### Ex db eb

Category	Type of protection
II1/2G	Ex db eb ia IIC T6T1 Gb Ex db eb ia IIB T6T1 Gb
II2G	Ex db eb ia IIC T6T1 Gb Ex db eb ia IIB T6T1 Gb

#### Ex db

Category	Type of protection
II1/2G	Ex db ia IIC T6T1 Gb Ex db ia IIB T6T1 Gb
II2G	Ex db ia IIC T6T1 Gb Ex db ia IIB T6T1 Gb

### Ех ес

Category	Type of protection
II3G	Ex ec IIC T5T1 Gc

#### Ex tb

Category	Type of protection
II2D	Ex tb IIIC T** °C Db

### $_{C}CSA_{US}$

Currently, the following versions for use in hazardous areas are available:

#### IS (Ex i) and XP (Ex d)

- Class I, III, III Division 1 Groups A-G
- Class I, III, III Division 1 Groups C-G

#### NI (Ex nA)

Class I Division 2 Groups A - D

#### Ex de

- Class I, Zone 1 AEx/ Ex de ia IIC T6...T1 Gb
  - Class I, Zone 1 AEx/ Ex de ia IIB T6...T1 Gb
- Class I, Zone 1 AEx/ Ex de ia IIC T6...T1 Gb Class I, Zone 1 AEx/ Ex de ia IIB T6...T1 Gb

#### Ex d

- Class I, Zone 1 AEx/ Ex d ia IIC T6...T1 Gb Class I, Zone 1 AEx/ Ex d ia IIB T6...T1 Gb
- Class I, Zone 1 AEx/ Ex d ia IIC T6...T1 Gb Class I, Zone 1 AEx/ Ex d ia IIB T6...T1 Gb

#### Ex nA

Class I, Zone 2 AEx/ Ex nA IIC T5...T1 Gc

#### Fx th

Zone 21 AEx/ Ex tb IIIC T\*\* °C Db

#### Sanitary compatibility

- 3-A approval
- EHEDG-tested

#### **Functional safety**

The measuring device can be used for flow monitoring systems (min., max., range) up to SIL 2 (single-channel architecture; order code for "Additional approval", option LA) and SIL 3 (multichannel architecture with homogeneous redundancy) and is independently evaluated and certified by the  $T\ddot{U}V$  in accordance with IEC 61508.

The following types of monitoring in safety equipment are possible:

- Mass flow
- Volume flow
- Density



#### **HART** certification

#### **HART** interface

The measuring device is certified and registered by the FieldComm Group. The measuring system meets all the requirements of the following specifications:

- Certified according to HART 7
- The device can also be operated with certified devices of other manufacturers (interoperability)

# FOUNDATION Fieldbus certification

#### FOUNDATION Fieldbus interface

The measuring device is certified and registered by the FieldComm Group. The measuring system meets all the requirements of the following specifications:

- Certified in accordance with FOUNDATION Fieldbus H1
- Interoperability Test Kit (ITK), revision version 6.1.2 (certificate available on request)
- Physical Layer Conformance Test
- The device can also be operated with certified devices of other manufacturers (interoperability)

#### **Certification PROFIBUS**

#### **PROFIBUS** interface

The measuring device is certified and registered by the PROFIBUS User Organization (PNO). The measuring system meets all the requirements of the following specifications:

- Certified in accordance with PROFIBUS PA Profile 3.02
- The device can also be operated with certified devices of other manufacturers (interoperability)

#### Modbus RS485 certification

The measuring device meets all the requirements of the MODBUS/TCP conformity test and has the "MODBUS/TCP Conformance Test Policy, Version 2.0". The measuring device has successfully passed all the test procedures carried out.

#### Pressure Equipment Directive

The devices can be ordered with or without a PED approval. If a device with a PED approval is required, this must be explicitly stated in the order. For devices with nominal diameters less than or equal to DN 25 (1"), this is neither possible nor necessary.

- With the identification PED/G1/x (x = category) on the sensor nameplate, Endress+Hauser confirms conformity with the "Essential Safety Requirements" specified in Appendix I of the Pressure Equipment Directive 2014/68/EC.
- Devices bearing this marking (PED) are suitable for the following types of medium:
  - Media in Group 1 and 2 with a vapor pressure greater than, or smaller and equal to 0.5 bar (7.3 psi)
  - Unstable gases
- Devices not bearing this marking (PED) are designed and manufactured according to good engineering practice. They meet the requirements of Art. 4, Par. 3 of the Pressure Equipment Directive 2014/68/EU. The range of application is indicated in tables 6 to 9 in Annex II of the Pressure Equipment Directive 2014/68/EC.

#### Radio approval

Europe:

RED 2014/53/EU

United States of America: CFR Title 47, FCC Part 15.247

Canada:

RSS-247 Issue 1

Japan:

Article 2 clause 1 item 19



Additional country-specific approvals on request.

#### Additional certification

#### CRN approval

Some device versions have CRN approval. A CRN-approved process connection with a CSA approval must be ordered for a CRN-approved device.

#### Tests and certificates

- Pressure test, internal procedure, inspection certificate
- 3.1 Material certificate, wetted parts and secondary containment, EN10204-3.1 inspection certificate
- PMI test (XRF), internal procedure, wetted parts, EN10204-3.1 inspection certificate
- EN10204-2.1 confirmation of compliance with the order and EN10204-2.2 test report

# Other standards and guidelines

■ EN 60529

Degrees of protection provided by enclosures (IP code)

■ IEC/EN 60068-2-6

Environmental influences: Test procedure - Test Fc: vibrate (sinusoidal).

■ IEC/EN 60068-2-31

Environmental influences: Test procedure - Test Ec: shocks due to rough handling, primarily for devices.

■ EN 61010-1

Safety requirements for electrical equipment for measurement, control and laboratory use - general requirements

■ IEC/EN 61326

Emission in accordance with Class A requirements. Electromagnetic compatibility (EMC requirements).

■ NAMUR NE 21

Electromagnetic compatibility (EMC) of industrial process and laboratory control equipment

■ NAMUR NE 32

Data retention in the event of a power failure in field and control instruments with microprocessors

■ NAMUR NE 43

Standardization of the signal level for the breakdown information of digital transmitters with analog output signal.

NAMUR NE 53

Software of field devices and signal-processing devices with digital electronics

■ NAMUR NE 80

The application of the pressure equipment directive to process control devices

- NAMUR NE 105
- Specifications for integrating fieldbus devices in engineering tools for field devices
- NAMUR NE 107
- Self-monitoring and diagnosis of field devices
- NAMUR NE 131
  - Requirements for field devices for standard applications
- NAMUR NE 132
  - Coriolis mass meter
- ETSI EN 300 328
- Guidelines for 2.4 GHz radio components.
- EN 301489

Electromagnetic compatibility and radio spectrum matters (ERM).

## Ordering information

Detailed ordering information is available from the following sources:

- In the Product Configurator on the Endress+Hauser website: www.endress.com -> Click "Corporate" -> Select your country -> Click "Products" -> Select the product using the filters and search field -> Open product page -> The "Configure" button to the right of the product image opens the Product Configurator.
- From your Endress+Hauser Sales Center: www.addresses.endress.com



#### Product Configurator - the tool for individual product configuration

- Up-to-the-minute configuration data
- Depending on the device: Direct input of measuring point-specific information such as measuring range or operating language
- Automatic verification of exclusion criteria
- Automatic creation of the order code and its breakdown in PDF or Excel output format
- Ability to order directly in the Endress+Hauser Online Shop

## Application packages

Many different application packages are available to enhance the functionality of the device. Such packages might be needed to address safety aspects or specific application requirements.

The application packages can be ordered with the device or subsequently from Endress+Hauser. Detailed information on the order code in question is available from your local Endress+Hauser sales center or on the product page of the Endress+Hauser website: <a href="https://www.endress.com">www.endress.com</a>.



Detailed information on the application packages:

Special Documentation for the device

#### **Diagnostics functions**

Package	Description
Extended HistoROM	Comprises extended functions concerning the event log and the activation of the measured value memory.
	Event log: Memory volume is extended from 20 message entries (standard version) to up to 100 entries.
	<ul> <li>Data logging (line recorder):</li> <li>Memory capacity for up to 1000 measured values is activated.</li> <li>250 measured values can be output via each of the 4 memory channels. The recording interval can be defined and configured by the user.</li> <li>Measured value logs can be accessed via the local display or operating tool e.g. FieldCare, DeviceCare or Web server.</li> </ul>

Heartbeat Technology	Package	Description
	Heartbeat Verification +Monitoring	Heartbeat Monitoring Continuously supplies data, which are characteristic of the measuring principle, to an external condition monitoring system for the purpose of preventive maintenance or process analysis. These data enable the operator to:  Draw conclusions - using these data and other information - about the impact process influences (such as corrosion, abrasion, buildup etc.) have on the measuring performance over time.  Schedule servicing in time.  Monitor the process or product quality, e.g. gas pockets.  Heartbeat Verification  Meets the requirement for traceable verification to DIN ISO 9001:2008 Chapter 7.6 a) "Control of monitoring and measuring equipment".  Functional testing in the installed state without interrupting the process.  Traceable verification results on request, including a report.  Simple testing process via local operation or other operating interfaces.
		<ul> <li>Clear measuring point assessment (pass/fail) with high test coverage within the framework of manufacturer specifications.</li> <li>Extension of calibration intervals according to operator's risk assessment.</li> </ul>

#### Concentration

Package	Description
Concentration measurement and special density	Calculation and outputting of fluid concentrations  Many applications use density as a key measured value for monitoring quality or controlling processes. The device measures the density of the fluid as standard and makes this value available to the control system.  The "Special Density" application package offers high-precision density measurement over a wide density and temperature range particularly for applications subject to varying process conditions.
	With the help of the "Concentration Measurement" application package, the measured density is used to calculate other process parameters:  Temperature-compensated density (reference density).  Percentage mass of the individual substances in a two-phase fluid. (Concentration in %).  Fluid concentration is output with special units ("Brix, "Baumé, "API, etc.) for standard applications.

## Viscosity

Package	Description
Viscosity measurement	In-line and real-time viscosity measurement Promass I with the "Viscosity" application package also measures the real-time viscosity of the fluid directly in the process, in addition to measuring the mass flow/volume flow/ temperature and density.
	The following viscosity measurements are performed on liquids:  Dynamic viscosity  Kinematic viscosity  Temperature-compensated viscosity (kinematic and dynamic) in relation to the reference temperature
	Viscosity measurement can be used for Newtonian and non-Newtonian applications and supplies accurate measured data irrespective of the flow, even under difficult conditions.

# Accessories

Various accessories, which can be ordered with the device or subsequently from Endress+Hauser, are available for the device. Detailed information on the order code in question is available from your local Endress+Hauser sales center or on the product page of the Endress+Hauser website: www.endress.com.

## Device-specific accessories

## For the transmitter

Accessories	Description
Promass 300 transmitter	Transmitter for replacement or storage. Use the order code to define the following specifications:  Approvals  Output  Input  Display / operation  Housing  Software  For details, see Installation Instructions EA01150
Remote display and operating module DKX001	The remote display and operating module DKX001 is available as an optional extra: Order code for "Display; operation", option <b>O</b> "Separate backlit, 4-line display; 10 m (30 ft) Cable; touch control"  The remote display and operating module DKX001 can also be ordered separately and subsequently as an accessory without a measuring device .  ■ Further information on display and operating module DKX001 → □ 76.  For details, see Special Documentation SD01763D
WLAN antenna Wide range	External WLAN antenna for a range of up to 50 m (165 ft).  ☐ Further information on the WLAN interface → 🖺 80.
Protective cover	Is used to protect the measuring device from the effects of the weather: e.g. rainwater, excess heating from direct sunlight.  For details, see Installation Instructions EA01160

## For the sensor

Accessories	Description
Heating jacket	Is used to stabilize the temperature of the fluids in the sensor.  Water, water vapor and other non-corrosive liquids are permitted for use as fluids.  If using oil as a heating medium, please consult with Endress+Hauser.  For details, see Operating Instructions BA00099D

# Communication-specific accessories

Accessories	Description
Commubox FXA195 HART	For intrinsically safe HART communication with FieldCare via the USB interface.  For details, see "Technical Information" TI00404F
HART Loop Converter HMX50	Is used to evaluate and convert dynamic HART process variables to analog current signals or limit values.
	For details, see "Technical Information" TI00429F and Operating Instructions BA00371F
Fieldgate FXA320	Gateway for the remote monitoring of connected 4 to 20 mA measuring devices via a Web browser.
	For details, see "Technical Information" TI00025S and Operating Instructions BA00053S
Fieldgate FXA520	Gateway for the remote diagnostics and remote configuration of connected HART measuring devices via a Web browser.
	For details, see "Technical Information" TI00025S and Operating Instructions BA00051S

Field Xpert SFX350	Field Xpert SFX350 is a mobile computer for commissioning and maintenance. It enables efficient device configuration and diagnostics for HART and FOUNDATION Fieldbus devices in the <b>non-Ex area</b> .  For details, see Operating Instructions BA01202S
Field Xpert SFX370	Field Xpert SFX370 is a mobile computer for commissioning and maintenance. It enables efficient device configuration and diagnostics for HART and FOUNDATION Fieldbus devices in the <b>non-Ex area</b> and the <b>Ex area</b> .  For details, see Operating Instructions BA01202S

## Service-specific accessories

Accessories	Description
Applicator	Software for selecting and sizing Endress+Hauser measuring devices:  Choice of measuring devices for industrial requirements  Calculation of all the necessary data for identifying the optimum flowmeter: e.g. nominal diameter, pressure loss, flow velocity and accuracy.  Graphic illustration of the calculation results  Determination of the partial order code, administration, documentation and access to all project-related data and parameters over the entire life cycle of a project.
	Applicator is available:  Via the Internet: <a href="https://wapps.endress.com/applicator">https://wapps.endress.com/applicator</a> As a downloadable DVD for local PC installation.
W@M	W@M Life Cycle Management Improved productivity with information at your fingertips. Data relevant to a plant and its components is generated from the first stages of planning and during the asset's complete life cycle.  W@M Life Cycle Management is an open and flexible information platform with online and on-site tools. Instant access for your staff to current, in-depth data shortens your plant's engineering time, speeds up procurement processes and increases plant uptime.  Combined with the right services, W@M Life Cycle Management boosts productivity in every phase. For more information, visit www.endress.com/lifecyclemanagement
FieldCare	FDT-based plant asset management tool from Endress+Hauser. It can configure all smart field units in your system and helps you manage them. By using the status information, it is also a simple but effective way of checking their status and condition.  For details, see Operating Instructions BA00027S and BA00059S
DeviceCare	Tool for connecting and configuring Endress+Hauser field devices.  For details, see Innovation brochure IN01047S

## System components

Accessories	Description
Memograph M graphic display recorder	The Memograph M graphic display recorder provides information on all relevant measured variables. Measured values are recorded correctly, limit values are monitored and measuring points analyzed. The data are stored in the 256 MB internal memory and also on a SD card or USB stick.
	For details, see "Technical Information" TI00133R and Operating Instructions BA00247R
Cerabar M	The pressure transmitter for measuring the absolute and gauge pressure of gases, steam and liquids. It can be used to read in the operating pressure value.
	For details, see "Technical Information" TI00426P, TI00436P and Operating Instructions BA00200P, BA00382P

Cerabar S	The pressure transmitter for measuring the absolute and gauge pressure of gases, steam and liquids. It can be used to read in the operating pressure value.  For details, see "Technical Information" TI00383P and Operating Instructions BA00271P
iTEMP	The temperature transmitters can be used in all applications and are suitable for the measurement of gases, steam and liquids. They can be used to read in the fluid temperature.  For details, see "Fields of Activity", FA00006T

# Supplementary documentation



For an overview of the scope of the associated Technical Documentation, refer to the following:

- The *W@M Device Viewer*: Enter the serial number from the nameplate (www.endress.com/deviceviewer)
- The *Endress+Hauser Operations App*: Enter the serial number from the nameplate or scan the 2-D matrix code (QR code) on the nameplate.

#### Standard documentation

## **Brief Operating Instructions**

#### Part 1 of 2: Sensor

Measuring device	Documentation code
Proline Promass	KA01212D

#### Part 2 of 2: Transmitter

	Documentation code			
Measuring device	HART	FOUNDATION Fieldbus	PROFIBUS PA	Modbus RS485
Proline 300	KA01226D	KA01229D	KA01227D	KA01228D

## **Operating Instructions**

Measuring device	Documentation			
	HART	FOUNDATION Fieldbus	PROFIBUS PA	Modbus RS485
Promass I 300	BA01487D	BA01520D	BA01509D	BA01498D

### Description of device parameters

	Documentation code			
Measuring device	HART	FOUNDATION Fieldbus	PROFIBUS PA	Modbus RS485
Promass 300	GP01057D	GP01094D	GP01058D	GP01059D

#### Supplementary devicedependent documentation

#### **Safety Instructions**

Contents	Documentation code
ATEX/IECEx Ex d/Ex de	XA01405D
ATEX/IECEx Ex ec	XA01439D
cCSAus XP	XA01373D

Contents	Documentation code
cCSAus Ex d/ Ex de	XA01372D
cCSAus Ex nA	XA01507D
INMETRO Ex d/Ex de	XA01468D
INMETRO Ex ec	XA01470D
NEPSI Ex d/Ex de	XA01469D
NEPSI Ex nA	XA01471D

## Remote display and operating module DKX001

Contents	Documentation code
ATEX/IECEx Ex i	XA01494D
ATEX/IECEx Ex ec	XA01498D
cCSAus IS	XA01499D
cCSAus Ex nA	XA01513D
INMETRO Ex i	XA01500D
INMETRO Ex ec	XA01501D
NEPSI Ex i	XA01502D
NEPSI Ex nA	XA01503D

## Special documentation

Contents	Documentation code
Information on the Pressure Equipment Directive	SD01614D
Functional Safety Manual	SD01727D
Remote display and operating module DKX001	SD01763D

Contents	Documentation			
	HART	FOUNDATION Fieldbus	PROFIBUS PA	Modbus RS485
Web server	SD01662D	SD01665D	SD01664D	SD01663D
Heartbeat Technology	SD01642D	SD01696D	SD01698D	SD01697D
Concentration measurement	SD01644D	SD01706D	SD01708D	SD01707D
Viscosity Measurement	SD01646D	SD01720D	SD01722D	SD01721D

### **Installation Instructions**

Contents	Documentation code
Installation Instructions for spare part sets	Specified for each individual accessory

# Registered trademarks

## HART®

Registered trademark of the FieldComm Group, Austin, Texas, USA  $\,$ 

#### **PROFIBUS®**

Registered trademark of the PROFIBUS User Organization, Karlsruhe, Germany

## FOUNDATION<sup>TM</sup> Fieldbus

Registration-pending trademark of the FieldComm Group, Austin, Texas, USA

#### Modbus<sup>®</sup>

Registered trademark of SCHNEIDER AUTOMATION, INC.

#### TRI-CLAMP®

Registered trademark of Ladish & Co., Inc., Kenosha, USA

# $Applicator^{\circ}, FieldCare^{\circ}, DeviceCare^{\circ}, Field~Xpert^{TM}, HistoROM^{\circ}, TMB^{\circ}, Heartbeat~Technology^{TM}$

Registered or registration-pending trademarks of the Endress+Hauser Group

www.addresses.endress.com

