

# TEXCHARGE TC

## Fujifilm Formulation Guide

### Version 2.1 SMS Base Colors

# Texcharge TC

## Fujifilm Formulation Guide

This document provides the starting formulas to simulate colors from the PANTONE® Color Guide. The formulas used in this guide are starting formulas and simulations of PANTONE®\* references using Texcharge TC screen process printing inks.

Although every care is taken in the color reproduction method used to predict these formulations; variations in fabrics, ink film thickness, and printing conditions/procedures may affect the color achieved.

Fujifilm assumes no responsibility for actual color achieved versus the PANTONE®\* standard print. Pantone LLC assumes no responsibility for formula accuracy. For this reason, all formulations must be proofed prior to a production run and will have to be checked and/or adjusted to ensure color accuracy.

Each Base Color has been carefully selected for its cleanliness of tone, resistance to fading, and suitability for intermixing.

All formulations are percentages “by weight” using the following Texcharge TC Series colors:

DESCRIPTION	
TC-001 Black	TC-217 SMS Blue Red Shade
TC-021 White	TC-218 SMS Blue
TC-046 SMS Yellow Red Shade	TC-316 SMS Green
TC-057 SMS Yellow Green Shade	TC-381 Extender Base
TC-103 SMS Orange	TC-053 Fluorescent Yellow
TC-122 SMS Red Yellow Shade	TC-105 Fluorescent Orange
TC-132 SMS Violet	TC-137 Fluorescent Red
TC-153 SMS Red Blue Shade	TC-139 Fluorescent Magenta
TC-154 SMS Magenta	TC-312 Fluorescent Green

\*PANTONE® is the property of Pantone LLC. Pantone LLC is a wholly owned subsidiary of X-Rite, Incorporated.

# Texcharge TC

Starting Point Yellow C	Formula
<b>TC-046</b> <b>100.00</b>	

Starting Point Yellow 012 C	Formula
<b>TC-046</b> <b>100.00</b>	

Starting Point Orange 021 C	Formula
<b>TC-046</b> <b>84.54</b>	
<b>TC-122</b> <b>15.46</b>	

Starting Point Warm Red C	Formula
<b>TC-046</b> <b>72.60</b>	
<b>TC-153</b> <b>27.40</b>	

Starting Point Red 032 C	Formula
<b>TC-046</b> <b>63.64</b>	
<b>TC-153</b> <b>36.36</b>	

Starting Point Rubine Red C	Formula
<b>TC-046</b> <b>16.77</b>	
<b>TC-103</b> <b>1.33</b>	
<b>TC-154</b> <b>35.98</b>	
<b>TC-139</b> <b>45.92</b>	

Starting Point Rhodamine Red C	Formula
<b>TC-122</b> <b>1.80</b>	
<b>TC-154</b> <b>12.51</b>	
<b>TC-139</b> <b>85.69</b>	

Starting Point Purple C	Formula
<b>TC-139</b> <b>91.47</b>	
<b>TC-132</b> <b>8.53</b>	

Starting Point Violet C	Formula
<b>TC-154</b> <b>70.67</b>	
<b>TC-217</b> <b>29.33</b>	

Starting Point Blue 072 C	Formula
<b>TC-217</b> <b>16.17</b>	
<b>TC-132</b> <b>72.62</b>	
<b>TC-021</b> <b>11.21</b>	

Starting Point Reflex Blue C	Formula
<b>TC-154</b> <b>49.27</b>	
<b>TC-217</b> <b>40.73</b>	
<b>TC-021</b> <b>10.00</b>	

Starting Point Process Blue C	Formula
<b>TC-218</b> <b>35.96</b>	
<b>TC-021</b> <b>64.04</b>	

Starting Point Green C	Formula
<b>TC-316</b> <b>40.16</b>	
<b>TC-021</b> <b>59.84</b>	

Starting Point Black C	Formula
<b>TC-001</b> <b>31.96</b>	
<b>TC-318</b> <b>68.04</b>	

Starting Point Yellow 0131 C	Formula
<b>TC-057</b> <b>6.14</b>	
<b>TC-021</b> <b>93.86</b>	

Starting Point Red 0331 C	Formula
<b>TC-021</b> <b>96.95</b>	
<b>TC-122</b> <b>3.05</b>	

# Texcharge TC

Starting Point Magenta 0521 C <b>TC-021</b> <b>95.10</b> <b>TC-154</b> <b>4.90</b>	Formula	Starting Point Violet 0631 C <b>TC-021</b> <b>92.69</b> <b>TC-132</b> <b>6.18</b> <b>TC-154</b> <b>1.13</b>	Formula	Starting Point Blue 0821 C <b>TC-021</b> <b>95.59</b> <b>TC-218</b> <b>3.88</b> <b>TC-316</b> <b>0.53</b>	Formula	Starting Point Green 0921 C <b>TC-021</b> <b>96.79</b> <b>TC-316</b> <b>2.70</b> <b>TC-057</b> <b>0.51</b>	Formula
Starting Point Black 0961 C <b>TC-021</b> <b>89.82</b> <b>TC-132</b> <b>2.95</b> <b>TC-057</b> <b>4.84</b> <b>TC-001</b> <b>2.39</b>	Formula	Starting Point Medium Yellow C <b>TC-046</b> <b>41.44</b> <b>TC-057</b> <b>29.58</b> <b>TC-021</b> <b>28.98</b>	Formula	Starting Point Bright Orange C <b>TC-103</b> <b>48.30</b> <b>TC-021</b> <b>51.70</b>	Formula	Starting Point Bright Red C <b>TC-103</b> <b>31.20</b> <b>TC-021</b> <b>54.67</b> <b>TC-122</b> <b>14.13</b>	Formula
Starting Point Strong Red C <b>TC-021</b> <b>45.58</b> <b>TC-153</b> <b>42.32</b> <b>TC-154</b> <b>12.10</b>	Formula	Starting Point Pink C <b>TC-021</b> <b>39.91</b> <b>TC-154</b> <b>28.83</b> <b>TC-139</b> <b>31.26</b>	Formula	Starting Point Medium Purple C <b>TC-021</b> <b>45.45</b> <b>TC-154</b> <b>14.03</b> <b>TC-132</b> <b>39.99</b> <b>TC-217</b> <b>0.53</b>	Formula	Starting Point Dark Blue C <b>TC-154</b> <b>29.90</b> <b>TC-217</b> <b>70.10</b>	Formula
Starting Point Medium Blue C <b>TC-218</b> <b>34.75</b> <b>TC-021</b> <b>65.25</b>	Formula	Starting Point Bright Green C <b>TC-021</b> <b>64.74</b> <b>TC-316</b> <b>35.26</b>	Formula	Starting Point Neutral Black C <b>TC-132</b> <b>23.87</b> <b>TC-217</b> <b>18.05</b> <b>TC-046</b> <b>51.66</b> <b>TC-103</b> <b>6.42</b>	Formula	Starting Point Process Yellow C <b>TC-057</b> <b>53.92</b> <b>TC-021</b> <b>41.31</b> <b>TC-046</b> <b>4.77</b>	Formula

# Texcharge TC

Starting Point	Formula
Process Magenta C	
<b>TC-139</b>	<b>55.30</b>
<b>TC-154</b>	<b>30.07</b>
<b>TC-153</b>	<b>14.63</b>

Starting Point	Formula
Process Cyan C	
<b>TC-021</b>	<b>69.48</b>
<b>TC-218</b>	<b>30.52</b>

Starting Point	Formula
Process Black C	
<b>TC-001</b>	<b>40.75</b>
<b>TC-046</b>	<b>38.23</b>
<b>TC-153</b>	<b>11.06</b>
<b>TC-021</b>	<b>9.96</b>

Starting Point	Formula
100 C	
<b>TC-046</b>	<b>6.43</b>
<b>TC-057</b>	<b>19.51</b>
<b>TC-021</b>	<b>74.06</b>

Starting Point	Formula
101 C	
<b>TC-046</b>	<b>6.81</b>
<b>TC-057</b>	<b>26.08</b>
<b>TC-021</b>	<b>67.11</b>

Starting Point	Formula
102 C	
<b>TC-046</b>	<b>12.92</b>
<b>TC-057</b>	<b>64.21</b>
<b>TC-021</b>	<b>22.87</b>

Starting Point	Formula
103 C	
<b>TC-046</b>	<b>47.24</b>
<b>TC-057</b>	<b>21.32</b>
<b>TC-021</b>	<b>30.14</b>
<b>TC-001</b>	<b>1.30</b>

Starting Point	Formula
104 C	
<b>TC-046</b>	<b>44.08</b>
<b>TC-057</b>	<b>21.50</b>
<b>TC-021</b>	<b>32.09</b>
<b>TC-001</b>	<b>2.33</b>

Starting Point	Formula
105 C	
<b>TC-046</b>	<b>41.24</b>
<b>TC-057</b>	<b>12.44</b>
<b>TC-021</b>	<b>41.60</b>
<b>TC-001</b>	<b>4.72</b>

Starting Point	Formula
106 C	
<b>TC-046</b>	<b>17.63</b>
<b>TC-057</b>	<b>20.53</b>
<b>TC-021</b>	<b>61.84</b>

Starting Point	Formula
107 C	
<b>TC-046</b>	<b>23.42</b>
<b>TC-057</b>	<b>25.75</b>
<b>TC-021</b>	<b>50.83</b>

Starting Point	Formula
108 C	
<b>TC-046</b>	<b>35.41</b>
<b>TC-057</b>	<b>29.46</b>
<b>TC-021</b>	<b>35.13</b>

Starting Point	Formula
109 C	
<b>TC-046</b>	<b>68.19</b>
<b>TC-057</b>	<b>7.56</b>
<b>TC-021</b>	<b>24.25</b>

Starting Point	Formula
110 C	
<b>TC-046</b>	<b>81.43</b>
<b>TC-021</b>	<b>17.28</b>
<b>TC-001</b>	<b>0.76</b>
<b>TC-153</b>	<b>0.53</b>

Starting Point	Formula
111 C	
<b>TC-046</b>	<b>76.45</b>
<b>TC-021</b>	<b>20.64</b>
<b>TC-001</b>	<b>2.60</b>
<b>TC-153</b>	<b>0.31</b>

Starting Point	Formula
112 C	
<b>TC-046</b>	<b>67.95</b>
<b>TC-057</b>	<b>2.98</b>
<b>TC-021</b>	<b>25.74</b>
<b>TC-001</b>	<b>3.33</b>

# Texcharge TC

Starting Point	Formula
113 C	
<b>TC-046</b>	<b>26.24</b>
<b>TC-057</b>	<b>10.22</b>
<b>TC-021</b>	<b>63.54</b>

Starting Point	Formula
114 C	
<b>TC-046</b>	<b>31.25</b>
<b>TC-057</b>	<b>11.75</b>
<b>TC-021</b>	<b>57.00</b>

Starting Point	Formula
115 C	
<b>TC-046</b>	<b>41.41</b>
<b>TC-057</b>	<b>14.01</b>
<b>TC-021</b>	<b>44.58</b>

Starting Point	Formula
116 C	
<b>TC-046</b>	<b>71.61</b>
<b>TC-021</b>	<b>28.39</b>

Starting Point	Formula
117 C	
<b>TC-046</b>	<b>79.30</b>
<b>TC-021</b>	<b>18.11</b>
<b>TC-001</b>	<b>1.17</b>
<b>TC-153</b>	<b>1.42</b>

Starting Point	Formula
118 C	
<b>TC-046</b>	<b>74.94</b>
<b>TC-021</b>	<b>21.39</b>
<b>TC-001</b>	<b>2.38</b>
<b>TC-153</b>	<b>1.29</b>

Starting Point	Formula
119 C	
<b>TC-046</b>	<b>65.27</b>
<b>TC-021</b>	<b>30.00</b>
<b>TC-001</b>	<b>4.73</b>

Starting Point	Formula
120 C	
<b>TC-021</b>	<b>79.81</b>
<b>TC-057</b>	<b>18.86</b>
<b>TC-103</b>	<b>1.33</b>

Starting Point	Formula
121 C	
<b>TC-021</b>	<b>76.10</b>
<b>TC-057</b>	<b>22.42</b>
<b>TC-103</b>	<b>1.48</b>

Starting Point	Formula
122 C	
<b>TC-021</b>	<b>69.36</b>
<b>TC-057</b>	<b>28.80</b>
<b>TC-103</b>	<b>1.84</b>

Starting Point	Formula
123 C	
<b>TC-021</b>	<b>64.41</b>
<b>TC-057</b>	<b>32.82</b>
<b>TC-103</b>	<b>2.77</b>

Starting Point	Formula
124 C	
<b>TC-021</b>	<b>51.43</b>
<b>TC-001</b>	<b>0.24</b>
<b>TC-057</b>	<b>44.65</b>
<b>TC-103</b>	<b>2.61</b>
<b>TC-153</b>	<b>1.07</b>

Starting Point	Formula
125 C	
<b>TC-021</b>	<b>47.93</b>
<b>TC-001</b>	<b>2.24</b>
<b>TC-057</b>	<b>44.36</b>
<b>TC-103</b>	<b>5.47</b>

Starting Point	Formula
126 C	
<b>TC-021</b>	<b>48.49</b>
<b>TC-001</b>	<b>3.60</b>
<b>TC-057</b>	<b>43.12</b>
<b>TC-103</b>	<b>4.79</b>

Starting Point	Formula
1205 C	
<b>TC-021</b>	<b>90.40</b>
<b>TC-057</b>	<b>8.64</b>
<b>TC-103</b>	<b>0.96</b>

Starting Point	Formula
1215 C	
<b>TC-021</b>	<b>84.41</b>
<b>TC-057</b>	<b>14.11</b>
<b>TC-103</b>	<b>1.48</b>

# Texcharge TC

Starting Point	Formula
1225 C	
<b>TC-021</b>	<b>68.29</b>
<b>TC-057</b>	<b>28.80</b>
<b>TC-103</b>	<b>2.91</b>

Starting Point	Formula
1235 C	
<b>TC-021</b>	<b>61.04</b>
<b>TC-057</b>	<b>34.31</b>
<b>TC-103</b>	<b>4.65</b>

Starting Point	Formula
1245 C	
<b>TC-021</b>	<b>33.04</b>
<b>TC-001</b>	<b>1.40</b>
<b>TC-046</b>	<b>64.11</b>
<b>TC-122</b>	<b>1.45</b>

Starting Point	Formula
1255 C	
<b>TC-021</b>	<b>56.44</b>
<b>TC-001</b>	<b>2.72</b>
<b>TC-057</b>	<b>36.07</b>
<b>TC103</b>	<b>4.77</b>

Starting Point	Formula
1265 C	
<b>TC-021</b>	<b>56.89</b>
<b>TC-001</b>	<b>5.13</b>
<b>TC-057</b>	<b>33.01</b>
<b>TC-103</b>	<b>4.97</b>

Starting Point	Formula
127 C	
<b>TC-057</b>	<b>16.73</b>
<b>TC-021</b>	<b>82.34</b>
<b>TC-103</b>	<b>0.93</b>

Starting Point	Formula
128 C	
<b>TC-057</b>	<b>27.89</b>
<b>TC-021</b>	<b>71.32</b>
<b>TC-122</b>	<b>0.79</b>

Starting Point	Formula
129 C	
<b>TC-057</b>	<b>34.43</b>
<b>TC-021</b>	<b>64.62</b>
<b>TC-122</b>	<b>0.95</b>

Starting Point	Formula
130 C	
<b>TC-057</b>	<b>29.42</b>
<b>TC-021</b>	<b>37.37</b>
<b>TC-046</b>	<b>30.15</b>
<b>TC-153</b>	<b>3.06</b>

Starting Point	Formula
131 C	
<b>TC-057</b>	<b>53.98</b>
<b>TC-021</b>	<b>40.76</b>
<b>TC-001</b>	<b>0.78</b>
<b>TC-153</b>	<b>4.48</b>

Starting Point	Formula
132 C	
<b>TC-057</b>	<b>50.56</b>
<b>TC-021</b>	<b>41.67</b>
<b>TC-001</b>	<b>2.80</b>
<b>TC-153</b>	<b>4.97</b>

Starting Point	Formula
133 C	
<b>TC-057</b>	<b>46.13</b>
<b>TC-021</b>	<b>41.87</b>
<b>TC-001</b>	<b>7.64</b>
<b>TC-153</b>	<b>4.36</b>

Starting Point	Formula
134 C	
<b>TC-057</b>	<b>14.44</b>
<b>TC-103</b>	<b>2.02</b>
<b>TC-021</b>	<b>83.54</b>

Starting Point	Formula
135 C	
<b>TC-057</b>	<b>20.35</b>
<b>TC-103</b>	<b>3.22</b>
<b>TC-021</b>	<b>76.43</b>

Starting Point	Formula
136 C	
<b>TC-057</b>	<b>27.81</b>
<b>TC-103</b>	<b>4.01</b>
<b>TC-021</b>	<b>68.18</b>

Starting Point	Formula
137 C	
<b>TC-057</b>	<b>95.55</b>
<b>TC-153</b>	<b>4.45</b>

# Texcharge TC

Starting Point	Formula
138 C	
<b>TC-046</b>	<b>91.71</b>
<b>TC-001</b>	<b>0.81</b>
<b>TC-153</b>	<b>7.48</b>

Starting Point	Formula
139 C	
<b>TC-046</b>	<b>89.34</b>
<b>TC-001</b>	<b>3.70</b>
<b>TC-153</b>	<b>6.96</b>

Starting Point	Formula
140 C	
<b>TC-046</b>	<b>86.56</b>
<b>TC-001</b>	<b>9.76</b>
<b>TC-153</b>	<b>3.68</b>

Starting Point	Formula
1345 C	
<b>TC-057</b>	<b>8.97</b>
<b>TC-103</b>	<b>2.44</b>
<b>TC-021</b>	<b>88.59</b>

Starting Point	Formula
1355 C	
<b>TC-057</b>	<b>12.46</b>
<b>TC-103</b>	<b>3.37</b>
<b>TC-021</b>	<b>84.17</b>

Starting Point	Formula
1365 C	
<b>TC-057</b>	<b>22.07</b>
<b>TC-103</b>	<b>5.62</b>
<b>TC-021</b>	<b>72.31</b>

Starting Point	Formula
1375 C	
<b>TC-046</b>	<b>94.31</b>
<b>TC-153</b>	<b>5.69</b>

Starting Point	Formula
1385 C	
<b>TC-046</b>	<b>90.86</b>
<b>TC-001</b>	<b>1.31</b>
<b>TC-153</b>	<b>7.83</b>

Starting Point	Formula
1395 C	
<b>TC-046</b>	<b>87.38</b>
<b>TC-001</b>	<b>5.45</b>
<b>TC-153</b>	<b>7.17</b>

Starting Point	Formula
1405 C	
<b>TC-046</b>	<b>84.98</b>
<b>TC-001</b>	<b>10.65</b>
<b>TC-153</b>	<b>4.37</b>

Starting Point	Formula
141 C	
<b>TC-057</b>	<b>22.64</b>
<b>TC-153</b>	<b>1.86</b>
<b>TC-021</b>	<b>75.50</b>

Starting Point	Formula
142 C	
<b>TC-057</b>	<b>30.51</b>
<b>TC-153</b>	<b>2.40</b>
<b>TC-021</b>	<b>67.09</b>

Starting Point	Formula
143 C	
<b>TC-057</b>	<b>39.25</b>
<b>TC-153</b>	<b>2.97</b>
<b>TC-021</b>	<b>57.78</b>

Starting Point	Formula
144 C	
<b>TC-046</b>	<b>93.08</b>
<b>TC-153</b>	<b>6.92</b>

Starting Point	Formula
145 C	
<b>TC-046</b>	<b>92.60</b>
<b>TC-001</b>	<b>1.67</b>
<b>TC-153</b>	<b>5.73</b>

Starting Point	Formula
146 C	
<b>TC-046</b>	<b>90.46</b>
<b>TC-001</b>	<b>3.98</b>
<b>TC-153</b>	<b>5.56</b>



# Texcharge TC

Starting Point	Formula
147 C	
<b>TC-046</b>	<b>89.04</b>
<b>TC-001</b>	<b>10.96</b>

Starting Point	Formula
148 C	
<b>TC-021</b>	<b>91.44</b>
<b>TC-057</b>	<b>5.95</b>
<b>TC-103</b>	<b>2.61</b>

Starting Point	Formula
149 C	
<b>TC-021</b>	<b>88.48</b>
<b>TC-057</b>	<b>7.89</b>
<b>TC-103</b>	<b>3.63</b>

Starting Point	Formula
150 C	
<b>TC-021</b>	<b>79.45</b>
<b>TC-057</b>	<b>14.29</b>
<b>TC-103</b>	<b>6.26</b>

Starting Point	Formula
151 C	
<b>TC-046</b>	<b>92.71</b>
<b>TC-122</b>	<b>7.29</b>

Starting Point	Formula
152 C	
<b>TC-046</b>	<b>89.23</b>
<b>TC-153</b>	<b>10.77</b>

Starting Point	Formula
153 C	
<b>TC-046</b>	<b>88.37</b>
<b>TC-001</b>	<b>2.44</b>
<b>TC-153</b>	<b>9.19</b>

Starting Point	Formula
154 C	
<b>TC-046</b>	<b>86.06</b>
<b>TC-001</b>	<b>4.69</b>
<b>TC-153</b>	<b>9.25</b>

Starting Point	Formula
1485 C	
<b>TC-046</b>	<b>19.17</b>
<b>TC-103</b>	<b>7.29</b>
<b>TC-021</b>	<b>73.54</b>

Starting Point	Formula
1495 C	
<b>TC-046</b>	<b>39.15</b>
<b>TC-103</b>	<b>16.53</b>
<b>TC-021</b>	<b>44.32</b>

Starting Point	Formula
1505 C	
<b>TC-057</b>	<b>10.64</b>
<b>TC-103</b>	<b>48.70</b>
<b>TC-021</b>	<b>40.66</b>

Starting Point	Formula
1525 C	
<b>TC-046</b>	<b>82.25</b>
<b>TC-001</b>	<b>2.32</b>
<b>TC-153</b>	<b>15.43</b>

Starting Point	Formula
1535 C	
<b>TC-046</b>	<b>81.76</b>
<b>TC-001</b>	<b>5.52</b>
<b>TC-153</b>	<b>12.72</b>

Starting Point	Formula
1545 C	
<b>TC-046</b>	<b>80.29</b>
<b>TC-001</b>	<b>11.49</b>
<b>TC-153</b>	<b>8.22</b>

Starting Point	Formula
155 C	
<b>TC-021</b>	<b>92.01</b>
<b>TC-057</b>	<b>6.48</b>
<b>TC-153</b>	<b>1.51</b>

Starting Point	Formula
156 C	
<b>TC-021</b>	<b>84.42</b>
<b>TC-057</b>	<b>12.84</b>
<b>TC-153</b>	<b>2.74</b>

# Texcharge TC

Starting Point	Formula
157 C	
<b>TC-021</b>	<b>68.29</b>
<b>TC-057</b>	<b>26.51</b>
<b>TC-153</b>	<b>5.20</b>

Starting Point	Formula
158 C	
<b>TC-046</b>	<b>88.68</b>
<b>TC-153</b>	<b>11.32</b>

Starting Point	Formula
159 C	
<b>TC-046</b>	<b>85.04</b>
<b>TC-001</b>	<b>1.74</b>
<b>TC-153</b>	<b>13.22</b>

Starting Point	Formula
160 C	
<b>TC-046</b>	<b>83.46</b>
<b>TC-001</b>	<b>4.46</b>
<b>TC-153</b>	<b>12.08</b>

Starting Point	Formula
161 C	
<b>TC-046</b>	<b>79.73</b>
<b>TC-001</b>	<b>13.44</b>
<b>TC-153</b>	<b>6.83</b>

Starting Point	Formula
1555 C	
<b>TC-021</b>	<b>93.26</b>
<b>TC-057</b>	<b>1.62</b>
<b>TC-103</b>	<b>5.12</b>

Starting Point	Formula
1565 C	
<b>TC-021</b>	<b>85.87</b>
<b>TC-057</b>	<b>4.73</b>
<b>TC-103</b>	<b>8.77</b>
<b>TC-122</b>	<b>0.63</b>

Starting Point	Formula
1575 C	
<b>TC-021</b>	<b>66.70</b>
<b>TC-103</b>	<b>33.30</b>

Starting Point	Formula
1585 C	
<b>TC-046</b>	<b>87.74</b>
<b>TC-153</b>	<b>12.26</b>

Starting Point	Formula
1595 C	
<b>TC-046</b>	<b>86.10</b>
<b>TC-001</b>	<b>1.06</b>
<b>TC-153</b>	<b>12.84</b>

Starting Point	Formula
1605 C	
<b>TC-046</b>	<b>84.52</b>
<b>TC-001</b>	<b>3.83</b>
<b>TC-153</b>	<b>11.65</b>

Starting Point	Formula
1615 C	
<b>TC-046</b>	<b>82.34</b>
<b>TC-001</b>	<b>6.27</b>
<b>TC-153</b>	<b>11.39</b>

Starting Point	Formula
162 C	
<b>TC-021</b>	<b>95.61</b>
<b>TC-103</b>	<b>4.39</b>

Starting Point	Formula
163 C	
<b>TC-021</b>	<b>88.90</b>
<b>TC-103</b>	<b>11.10</b>

Starting Point	Formula
164 C	
<b>TC-021</b>	<b>74.45</b>
<b>TC-057</b>	<b>5.64</b>
<b>TC-103</b>	<b>18.24</b>
<b>TC-122</b>	<b>1.67</b>

Starting Point	Formula
165 C	
<b>TC-046</b>	<b>86.38</b>
<b>TC-153</b>	<b>13.62</b>

# Texcharge TC

Starting Point	Formula
166 C	
<b>TC-046</b>	<b>84.09</b>
<b>TC-153</b>	<b>15.91</b>

Starting Point	Formula
167 C	
<b>TC-046</b>	<b>83.95</b>
<b>TC-001</b>	<b>2.08</b>
<b>TC-153</b>	<b>13.97</b>

Starting Point	Formula
168 C	
<b>TC-046</b>	<b>80.13</b>
<b>TC-001</b>	<b>8.86</b>
<b>TC-153</b>	<b>11.01</b>

Starting Point	Formula
1625 C	
<b>TC-021</b>	<b>92.31</b>
<b>TC-103</b>	<b>6.27</b>
<b>TC-122</b>	<b>1.42</b>

Starting Point	Formula
1635 C	
<b>TC-021</b>	<b>85.55</b>
<b>TC-103</b>	<b>11.84</b>
<b>TC-122</b>	<b>2.61</b>

Starting Point	Formula
1645 C	
<b>TC-021</b>	<b>68.33</b>
<b>TC-103</b>	<b>27.10</b>
<b>TC-122</b>	<b>4.57</b>

Starting Point	Formula
1655 C	
<b>TC-046</b>	<b>83.09</b>
<b>TC-122</b>	<b>1.59</b>
<b>TC-153</b>	<b>15.32</b>

Starting Point	Formula
1665 C	
<b>TC-046</b>	<b>81.35</b>
<b>TC-153</b>	<b>18.65</b>

Starting Point	Formula
1675 C	
<b>TC-046</b>	<b>80.45</b>
<b>TC-001</b>	<b>3.32</b>
<b>TC-153</b>	<b>16.23</b>

Starting Point	Formula
1685 C	
<b>TC-046</b>	<b>79.43</b>
<b>TC-001</b>	<b>6.94</b>
<b>TC-153</b>	<b>13.63</b>

Starting Point	Formula
169 C	
<b>TC-021</b>	<b>95.46</b>
<b>TC-103</b>	<b>2.83</b>
<b>TC-122</b>	<b>1.71</b>

Starting Point	Formula
170 C	
<b>TC-021</b>	<b>86.13</b>
<b>TC-103</b>	<b>8.78</b>
<b>TC-122</b>	<b>5.09</b>

Starting Point	Formula
171 C	
<b>TC-021</b>	<b>67.88</b>
<b>TC-103</b>	<b>23.06</b>
<b>TC-122</b>	<b>9.06</b>

Starting Point	Formula
172 C	
<b>TC-046</b>	<b>80.65</b>
<b>TC-153</b>	<b>19.35</b>

Starting Point	Formula
173 C	
<b>TC-046</b>	<b>79.75</b>
<b>TC-001</b>	<b>1.31</b>
<b>TC-153</b>	<b>18.94</b>

Starting Point	Formula
174 C	
<b>TC-046</b>	<b>78.16</b>
<b>TC-001</b>	<b>4.89</b>
<b>TC-153</b>	<b>16.95</b>

# Texcharge TC

Starting Point	Formula
175 C	
<b>TC-046</b>	<b>77.36</b>
<b>TC-001</b>	<b>10.86</b>
<b>TC-153</b>	<b>11.78</b>

Starting Point	Formula
176 C	
<b>TC-021</b>	<b>95.75</b>
<b>TC-046</b>	<b>1.04</b>
<b>TC-122</b>	<b>3.21</b>

Starting Point	Formula
177 C	
<b>TC-021</b>	<b>88.57</b>
<b>TC-103</b>	<b>1.93</b>
<b>TC-122</b>	<b>9.50</b>

Starting Point	Formula
178 C	
<b>TC-021</b>	<b>75.97</b>
<b>TC-103</b>	<b>7.07</b>
<b>TC-122</b>	<b>16.96</b>

Starting Point	Formula
179 C	
<b>TC-046</b>	<b>70.40</b>
<b>TC-154</b>	<b>29.60</b>

Starting Point	Formula
180 C	
<b>TC-046</b>	<b>68.71</b>
<b>TC-154</b>	<b>30.05</b>
<b>TC-001</b>	<b>1.24</b>

Starting Point	Formula
181 C	
<b>TC-046</b>	<b>67.80</b>
<b>TC-154</b>	<b>26.62</b>
<b>TC-001</b>	<b>5.58</b>

Starting Point	Formula
1765 C	
<b>TC-021</b>	<b>95.54</b>
<b>TC-122</b>	<b>4.46</b>

Starting Point	Formula
1775 C	
<b>TC-021</b>	<b>92.82</b>
<b>TC-122</b>	<b>7.18</b>

Starting Point	Formula
1785 C	
<b>TC-021</b>	<b>72.25</b>
<b>TC-122</b>	<b>27.75</b>

Starting Point	Formula
1788 C	
<b>TC-046</b>	<b>65.27</b>
<b>TC-154</b>	<b>34.73</b>

Starting Point	Formula
1795 C	
<b>TC-046</b>	<b>64.73</b>
<b>TC-154</b>	<b>35.27</b>

Starting Point	Formula
1805 C	
<b>TC-046</b>	<b>64.74</b>
<b>TC-154</b>	<b>33.44</b>
<b>TC-001</b>	<b>1.82</b>

Starting Point	Formula
1815 C	
<b>TC-046</b>	<b>67.59</b>
<b>TC-154</b>	<b>26.20</b>
<b>TC-001</b>	<b>6.21</b>

Starting Point	Formula
1767 C	
<b>TC-021</b>	<b>96.82</b>
<b>TC-122</b>	<b>3.18</b>

Starting Point	Formula
1777 C	
<b>TC-021</b>	<b>81.24</b>
<b>TC-122</b>	<b>15.47</b>
<b>TC-153</b>	<b>3.29</b>

# Texcharge TC

Starting Point	Formula
1787 C	
<b>TC-021</b>	<b>61.32</b>
<b>TC-122</b>	<b>38.68</b>

Starting Point	Formula
1797 C	
<b>TC-046</b>	<b>56.71</b>
<b>TC-154</b>	<b>43.29</b>

Starting Point	Formula
1807 C	
<b>TC-046</b>	<b>58.15</b>
<b>TC-154</b>	<b>39.11</b>
<b>TC-001</b>	<b>2.74</b>

Starting Point	Formula
1817 C	
<b>TC-046</b>	<b>60.43</b>
<b>TC-154</b>	<b>28.84</b>
<b>TC-001</b>	<b>10.73</b>

Starting Point	Formula
182 C	
<b>TC-021</b>	<b>97.89</b>
<b>TC-122</b>	<b>2.11</b>

Starting Point	Formula
183 C	
<b>TC-021</b>	<b>93.73</b>
<b>TC-122</b>	<b>4.55</b>
<b>TC-154</b>	<b>1.72</b>

Starting Point	Formula
184 C	
<b>TC-021</b>	<b>77.78</b>
<b>TC-122</b>	<b>14.56</b>
<b>TC-153</b>	<b>7.66</b>

Starting Point	Formula
185 C	
<b>TC-046</b>	<b>59.12</b>
<b>TC-122</b>	<b>3.48</b>
<b>TC-154</b>	<b>37.40</b>

Starting Point	Formula
186 C	
<b>TC-046</b>	<b>54.71</b>
<b>TC-154</b>	<b>45.29</b>

Starting Point	Formula
187 C	
<b>TC-046</b>	<b>56.79</b>
<b>TC-154</b>	<b>41.03</b>
<b>TC-001</b>	<b>2.18</b>

Starting Point	Formula
188 C	
<b>TC-046</b>	<b>57.85</b>
<b>TC-154</b>	<b>35.10</b>
<b>TC-001</b>	<b>7.05</b>

Starting Point	Formula
189 C	
<b>TC-021</b>	<b>95.48</b>
<b>TC-122</b>	<b>2.87</b>
<b>TC-154</b>	<b>1.65</b>

Starting Point	Formula
190 C	
<b>TC-021</b>	<b>86.89</b>
<b>TC-122</b>	<b>7.19</b>
<b>TC-154</b>	<b>5.92</b>

Starting Point	Formula
191 C	
<b>TC-021</b>	<b>72.98</b>
<b>TC-122</b>	<b>10.29</b>
<b>TC-153</b>	<b>16.73</b>

Starting Point	Formula
192 C	
<b>TC-154</b>	<b>53.82</b>
<b>TC-046</b>	<b>46.18</b>

Starting Point	Formula
193 C	
<b>TC-154</b>	<b>58.16</b>
<b>TC-046</b>	<b>41.84</b>

# Texcharge TC

Starting Point	Formula
194 C	
<b>TC-046</b>	<b>48.68</b>
<b>TC-154</b>	<b>47.87</b>
<b>TC-001</b>	<b>3.45</b>

Starting Point	Formula
195 C	
<b>TC-046</b>	<b>52.46</b>
<b>TC-154</b>	<b>40.24</b>
<b>TC-001</b>	<b>7.30</b>

Starting Point	Formula
1895 C	
<b>TC-021</b>	<b>96.94</b>
<b>TC-122</b>	<b>1.58</b>
<b>TC-154</b>	<b>1.48</b>

Starting Point	Formula
1905 C	
<b>TC-021</b>	<b>93.50</b>
<b>TC-122</b>	<b>2.94</b>
<b>TC-154</b>	<b>3.56</b>

Starting Point	Formula
1915 C	
<b>TC-021</b>	<b>72.12</b>
<b>TC-153</b>	<b>27.88</b>

Starting Point	Formula
1925 C	
<b>TC-154</b>	<b>62.27</b>
<b>TC-046</b>	<b>37.73</b>

Starting Point	Formula
1935 C	
<b>TC-154</b>	<b>59.66</b>
<b>TC-046</b>	<b>40.34</b>

Starting Point	Formula
1945 C	
<b>TC-154</b>	<b>56.26</b>
<b>TC-046</b>	<b>41.53</b>
<b>TC-001</b>	<b>2.21</b>

Starting Point	Formula
1955 C	
<b>TC-154</b>	<b>51.49</b>
<b>TC-046</b>	<b>44.14</b>
<b>TC-001</b>	<b>4.37</b>

Starting Point	Formula
196 C	
<b>TC-021</b>	<b>95.65</b>
<b>TC-057</b>	<b>1.58</b>
<b>TC-154</b>	<b>2.77</b>

Starting Point	Formula
197 C	
<b>TC-021</b>	<b>89.38</b>
<b>TC-057</b>	<b>2.85</b>
<b>TC-154</b>	<b>6.36</b>
<b>TC-153</b>	<b>1.41</b>

Starting Point	Formula
198 C	
<b>TC-021</b>	<b>63.11</b>
<b>TC-057</b>	<b>7.45</b>
<b>TC-153</b>	<b>29.44</b>

Starting Point	Formula
199 C	
<b>TC-154</b>	<b>50.24</b>
<b>TC-046</b>	<b>49.76</b>

Starting Point	Formula
200 C	
<b>TC-154</b>	<b>54.76</b>
<b>TC-046</b>	<b>45.24</b>

Starting Point	Formula
201 C	
<b>TC-046</b>	<b>49.26</b>
<b>TC-154</b>	<b>47.78</b>
<b>TC-001</b>	<b>2.96</b>

Starting Point	Formula
202 C	
<b>TC-046</b>	<b>51.30</b>
<b>TC-154</b>	<b>43.55</b>
<b>TC-001</b>	<b>5.15</b>

# Texcharge TC

Starting Point	Formula
203 C	
<b>TC-021</b>	<b>96.80</b>
<b>TC-153</b>	<b>3.20</b>

Starting Point	Formula
204 C	
<b>TC-021</b>	<b>86.32</b>
<b>TC-057</b>	<b>1.28</b>
<b>TC-153</b>	<b>5.44</b>
<b>TC-154</b>	<b>6.96</b>

Starting Point	Formula
205 C	
<b>TC-021</b>	<b>66.70</b>
<b>TC-122</b>	<b>10.85</b>
<b>TC-154</b>	<b>22.45</b>

Starting Point	Formula
206 C	
<b>TC-046</b>	<b>42.82</b>
<b>TC-154</b>	<b>57.18</b>

Starting Point	Formula
207 C	
<b>TC-046</b>	<b>41.43</b>
<b>TC-154</b>	<b>56.40</b>
<b>TC-001</b>	<b>2.17</b>

Starting Point	Formula
208 C	
<b>TC-046</b>	<b>50.97</b>
<b>TC-154</b>	<b>27.94</b>
<b>TC-132</b>	<b>21.09</b>

Starting Point	Formula
209 C	
<b>TC-046</b>	<b>58.31</b>
<b>TC-122</b>	<b>3.43</b>
<b>TC-132</b>	<b>38.26</b>

Starting Point	Formula
210 C	
<b>TC-021</b>	<b>92.68</b>
<b>TC-122</b>	<b>2.00</b>
<b>TC-154</b>	<b>5.32</b>

Starting Point	Formula
211 C	
<b>TC-021</b>	<b>84.65</b>
<b>TC-122</b>	<b>3.20</b>
<b>TC-154</b>	<b>12.15</b>

Starting Point	Formula
212 C	
<b>TC-021</b>	<b>70.00</b>
<b>TC-122</b>	<b>6.03</b>
<b>TC-154</b>	<b>23.97</b>

Starting Point	Formula
213 C	
<b>TC-021</b>	<b>57.61</b>
<b>TC-153</b>	<b>26.79</b>
<b>TC-154</b>	<b>15.60</b>

Starting Point	Formula
214 C	
<b>TC-154</b>	<b>82.79</b>
<b>TC-046</b>	<b>17.21</b>

Starting Point	Formula
215 C	
<b>TC-154</b>	<b>57.08</b>
<b>TC-046</b>	<b>33.04</b>
<b>TC-132</b>	<b>9.88</b>

Starting Point	Formula
216 C	
<b>TC-046</b>	<b>31.03</b>
<b>TC-154</b>	<b>62.73</b>
<b>TC-001</b>	<b>6.24</b>

Starting Point	Formula
217 C	
<b>TC-021</b>	<b>96.16</b>
<b>TC-154</b>	<b>3.41</b>
<b>TC-057</b>	<b>0.43</b>

Starting Point	Formula
218 C	
<b>TC-021</b>	<b>81.13</b>
<b>TC-153</b>	<b>3.19</b>
<b>TC-154</b>	<b>15.68</b>

# Texcharge TC

Starting Point	Formula
219 C	
<b>TC-021</b>	<b>50.32</b>
<b>TC-154</b>	<b>40.47</b>
<b>TC-153</b>	<b>9.21</b>

Starting Point	Formula
220 C	
<b>TC-154</b>	<b>61.02</b>
<b>TC-046</b>	<b>29.22</b>
<b>TC-132</b>	<b>9.76</b>

Starting Point	Formula
221 C	
<b>TC-154</b>	<b>44.69</b>
<b>TC-046</b>	<b>39.26</b>
<b>TC-132</b>	<b>16.05</b>

Starting Point	Formula
222 C	
<b>TC-154</b>	<b>66.72</b>
<b>TC-046</b>	<b>24.94</b>
<b>TC-001</b>	<b>8.34</b>

Starting Point	Formula
223 C	
<b>TC-021</b>	<b>90.28</b>
<b>TC-122</b>	<b>0.46</b>
<b>TC-154</b>	<b>9.26</b>

Starting Point	Formula
224 C	
<b>TC-021</b>	<b>80.01</b>
<b>TC-154</b>	<b>19.99</b>

Starting Point	Formula
225 C	
<b>TC-021</b>	<b>50.37</b>
<b>TC-154</b>	<b>49.63</b>

Starting Point	Formula
226 C	
<b>TC-154</b>	<b>93.82</b>
<b>TC-046</b>	<b>6.18</b>

Starting Point	Formula
227 C	
<b>TC-154</b>	<b>94.03</b>
<b>TC-046</b>	<b>5.97</b>

Starting Point	Formula
228 C	
<b>TC-046</b>	<b>32.04</b>
<b>TC-132</b>	<b>21.11</b>
<b>TC-154</b>	<b>46.85</b>

Starting Point	Formula
229 C	
<b>TC-046</b>	<b>54.21</b>
<b>TC-132</b>	<b>45.79</b>

Starting Point	Formula
230 C	
<b>TC-021</b>	<b>93.88</b>
<b>TC-154</b>	<b>5.42</b>
<b>TC-122</b>	<b>0.70</b>

Starting Point	Formula
231 C	
<b>TC-021</b>	<b>82.17</b>
<b>TC-154</b>	<b>17.83</b>

Starting Point	Formula
232 C	
<b>TC-021</b>	<b>63.51</b>
<b>TC-154</b>	<b>36.49</b>

Starting Point	Formula
233 C	
<b>TC-021</b>	<b>43.00</b>
<b>TC-154</b>	<b>57.00</b>

Starting Point	Formula
234 C	
<b>TC-154</b>	<b>97.32</b>
<b>TC-001</b>	<b>2.68</b>



# Texcharge TC

Starting Point	Formula
235 C	
<b>TC-154</b>	<b>62.24</b>
<b>TC-046</b>	<b>29.42</b>
<b>TC-217</b>	<b>8.34</b>

Starting Point	Formula
236 C	
<b>TC-021</b>	<b>93.60</b>
<b>TC-154</b>	<b>6.40</b>

Starting Point	Formula
237 C	
<b>TC-021</b>	<b>86.58</b>
<b>TC-154</b>	<b>13.42</b>

Starting Point	Formula
238 C	
<b>TC-021</b>	<b>74.86</b>
<b>TC-154</b>	<b>25.14</b>

Starting Point	Formula
239 C	
<b>TC-021</b>	<b>68.09</b>
<b>TC-154</b>	<b>31.91</b>

Starting Point	Formula
240 C	
<b>TC-021</b>	<b>59.94</b>
<b>TC-154</b>	<b>38.83</b>
<b>TC-132</b>	<b>1.23</b>

Starting Point	Formula
241 C	
<b>TC-021</b>	<b>53.76</b>
<b>TC-154</b>	<b>41.46</b>
<b>TC-132</b>	<b>3.34</b>
<b>TC-122</b>	<b>1.44</b>

Starting Point	Formula
242 C	
<b>TC-021</b>	<b>56.56</b>
<b>TC-132</b>	<b>18.02</b>
<b>TC-122</b>	<b>16.15</b>
<b>TC-154</b>	<b>9.01</b>
<b>TC-001</b>	<b>0.26</b>

Starting Point	Formula
2365 C	
<b>TC-021</b>	<b>96.64</b>
<b>TC-154</b>	<b>3.09</b>
<b>TC-122</b>	<b>0.27</b>

Starting Point	Formula
2375 C	
<b>TC-021</b>	<b>82.89</b>
<b>TC-154</b>	<b>17.11</b>

Starting Point	Formula
2385 C	
<b>TC-021</b>	<b>68.37</b>
<b>TC-154</b>	<b>31.63</b>

Starting Point	Formula
2395 C	
<b>TC-021</b>	<b>57.96</b>
<b>TC-154</b>	<b>42.04</b>

Starting Point	Formula
2405 C	
<b>TC-021</b>	<b>49.62</b>
<b>TC-154</b>	<b>45.85</b>
<b>TC-132</b>	<b>4.53</b>

Starting Point	Formula
2415 C	
<b>TC-021</b>	<b>44.70</b>
<b>TC-154</b>	<b>49.01</b>
<b>TC-132</b>	<b>6.29</b>

Starting Point	Formula
2425 C	
<b>TC-154</b>	<b>45.54</b>
<b>TC-021</b>	<b>37.27</b>
<b>TC-132</b>	<b>12.23</b>
<b>TC-057</b>	<b>4.96</b>

Starting Point	Formula
243 C	
<b>TC-021</b>	<b>96.02</b>
<b>TC-154</b>	<b>3.98</b>

# Texcharge TC

Starting Point	Formula
244 C	
<b>TC-021</b>	<b>91.38</b>
<b>TC-154</b>	<b>8.62</b>

Starting Point	Formula
245 C	
<b>TC-021</b>	<b>84.93</b>
<b>TC-154</b>	<b>15.07</b>

Starting Point	Formula
246 C	
<b>TC-021</b>	<b>61.78</b>
<b>TC-154</b>	<b>34.66</b>
<b>TC-132</b>	<b>3.56</b>

Starting Point	Formula
247 C	
<b>TC-021</b>	<b>53.56</b>
<b>TC-154</b>	<b>41.69</b>
<b>TC-132</b>	<b>4.75</b>

Starting Point	Formula
248 C	
<b>TC-021</b>	<b>50.60</b>
<b>TC-154</b>	<b>42.79</b>
<b>TC-132</b>	<b>6.61</b>

Starting Point	Formula
249 C	
<b>TC-021</b>	<b>52.05</b>
<b>TC-153</b>	<b>29.56</b>
<b>TC-132</b>	<b>17.66</b>
<b>TC-001</b>	<b>0.73</b>

Starting Point	Formula
250 C	
<b>TC-021</b>	<b>96.25</b>
<b>TC-154</b>	<b>3.75</b>

Starting Point	Formula
251 C	
<b>TC-021</b>	<b>91.49</b>
<b>TC-132</b>	<b>2.31</b>
<b>TC-154</b>	<b>6.20</b>

Starting Point	Formula
252 C	
<b>TC-021</b>	<b>75.54</b>
<b>TC-154</b>	<b>17.67</b>
<b>TC-132</b>	<b>6.79</b>

Starting Point	Formula
253 C	
<b>TC-021</b>	<b>54.07</b>
<b>TC-154</b>	<b>35.35</b>
<b>TC-132</b>	<b>10.58</b>

Starting Point	Formula
254 C	
<b>TC-021</b>	<b>50.15</b>
<b>TC-154</b>	<b>37.32</b>
<b>TC-132</b>	<b>12.53</b>

Starting Point	Formula
255 C	
<b>TC-021</b>	<b>42.94</b>
<b>TC-154</b>	<b>22.93</b>
<b>TC-132</b>	<b>27.62</b>
<b>TC-103</b>	<b>6.51</b>

Starting Point	Formula
256 C	
<b>TC-021</b>	<b>96.15</b>
<b>TC-057</b>	<b>0.27</b>
<b>TC-218</b>	<b>0.56</b>
<b>TC-154</b>	<b>3.02</b>

Starting Point	Formula
257 C	
<b>TC-021</b>	<b>91.72</b>
<b>TC-057</b>	<b>0.49</b>
<b>TC-218</b>	<b>1.11</b>
<b>TC-154</b>	<b>6.68</b>

Starting Point	Formula
258 C	
<b>TC-021</b>	<b>60.26</b>
<b>TC-057</b>	<b>0.77</b>
<b>TC-218</b>	<b>4.35</b>
<b>TC-154</b>	<b>34.62</b>

Starting Point	Formula
259 C	
<b>TC-154</b>	<b>87.64</b>
<b>TC-316</b>	<b>12.36</b>

# Texcharge TC

Starting Point	Formula
260 C	
<b>TC-046</b>	<b>26.94</b>
<b>TC-217</b>	<b>16.98</b>
<b>TC-154</b>	<b>56.08</b>

Starting Point	Formula
261 C	
<b>TC-046</b>	<b>31.02</b>
<b>TC-217</b>	<b>17.96</b>
<b>TC-154</b>	<b>51.02</b>

Starting Point	Formula
262 C	
<b>TC-046</b>	<b>38.25</b>
<b>TC-217</b>	<b>18.24</b>
<b>TC-154</b>	<b>43.51</b>

Starting Point	Formula
2562 C	
<b>TC-021</b>	<b>78.30</b>
<b>TC-139</b>	<b>20.73</b>
<b>TC-218</b>	<b>0.97</b>

Starting Point	Formula
2572 C	
<b>TC-021</b>	<b>61.34</b>
<b>TC-139</b>	<b>36.36</b>
<b>TC-217</b>	<b>2.30</b>

Starting Point	Formula
2582 C	
<b>TC-139</b>	<b>96.52</b>
<b>TC-218</b>	<b>3.48</b>

Starting Point	Formula
2592 C	
<b>TC-139</b>	<b>84.73</b>
<b>TC-132</b>	<b>15.27</b>

Starting Point	Formula
2602 C	
<b>TC-139</b>	<b>36.50</b>
<b>TC-021</b>	<b>31.46</b>
<b>TC-132</b>	<b>18.34</b>
<b>TC-154</b>	<b>13.70</b>

Starting Point	Formula
2612 C	
<b>TC-021</b>	<b>52.18</b>
<b>TC-154</b>	<b>19.89</b>
<b>TC-132</b>	<b>23.87</b>
<b>TC-122</b>	<b>4.06</b>

Starting Point	Formula
2622 C	
<b>TC-021</b>	<b>54.76</b>
<b>TC-132</b>	<b>35.11</b>
<b>TC-103</b>	<b>10.13</b>

Starting Point	Formula
2563 C	
<b>TC-021</b>	<b>93.13</b>
<b>TC-154</b>	<b>5.94</b>
<b>TC-218</b>	<b>0.93</b>

Starting Point	Formula
2573 C	
<b>TC-021</b>	<b>89.28</b>
<b>TC-132</b>	<b>5.86</b>
<b>TC-154</b>	<b>4.86</b>

Starting Point	Formula
2583 C	
<b>TC-021</b>	<b>76.87</b>
<b>TC-132</b>	<b>10.97</b>
<b>TC-154</b>	<b>12.16</b>

Starting Point	Formula
2593 C	
<b>TC-154</b>	<b>87.39</b>
<b>TC-217</b>	<b>12.61</b>

Starting Point	Formula
2603 C	
<b>TC-154</b>	<b>88.10</b>
<b>TC-217</b>	<b>11.90</b>

Starting Point	Formula
2613 C	
<b>TC-154</b>	<b>70.15</b>
<b>TC-132</b>	<b>25.15</b>
<b>TC-001</b>	<b>4.70</b>

# Texcharge TC

Starting Point	Formula
2623 C	
<b>TC-153</b>	<b>73.72</b>
<b>TC-217</b>	<b>26.28</b>

Starting Point	Formula
2567 C	
<b>TC-021</b>	<b>94.56</b>
<b>TC-132</b>	<b>4.82</b>
<b>TC-153</b>	<b>0.62</b>

Starting Point	Formula
2577 C	
<b>TC-021</b>	<b>86.62</b>
<b>TC-132</b>	<b>6.94</b>
<b>TC-218</b>	<b>0.75</b>
<b>TC-154</b>	<b>5.69</b>

Starting Point	Formula
2587 C	
<b>TC-021</b>	<b>69.10</b>
<b>TC-132</b>	<b>22.20</b>
<b>TC-154</b>	<b>8.70</b>

Starting Point	Formula
2597 C	
<b>TC-154</b>	<b>80.84</b>
<b>TC-217</b>	<b>19.16</b>

Starting Point	Formula
2607 C	
<b>TC-132</b>	<b>76.78</b>
<b>TC-046</b>	<b>23.22</b>

Starting Point	Formula
2617 C	
<b>TC-154</b>	<b>57.40</b>
<b>TC-217</b>	<b>22.54</b>
<b>TC-046</b>	<b>20.06</b>

Starting Point	Formula
2627 C	
<b>TC-154</b>	<b>48.84</b>
<b>TC-046</b>	<b>29.31</b>
<b>TC-217</b>	<b>21.85</b>

Starting Point	Formula
263 C	
<b>TC-021</b>	<b>97.14</b>
<b>TC-154</b>	<b>2.33</b>
<b>TC-218</b>	<b>0.53</b>

Starting Point	Formula
264 C	
<b>TC-021</b>	<b>94.27</b>
<b>TC-132</b>	<b>5.73</b>

Starting Point	Formula
265 C	
<b>TC-021</b>	<b>76.77</b>
<b>TC-132</b>	<b>23.23</b>

Starting Point	Formula
266 C	
<b>TC-021</b>	<b>60.32</b>
<b>TC-132</b>	<b>39.68</b>

Starting Point	Formula
267 C	
<b>TC-154</b>	<b>77.39</b>
<b>TC-217</b>	<b>22.61</b>

Starting Point	Formula
268 C	
<b>TC-021</b>	<b>54.01</b>
<b>TC-132</b>	<b>36.57</b>
<b>TC-153</b>	<b>8.38</b>
<b>TC-001</b>	<b>1.04</b>

Starting Point	Formula
269 C	
<b>TC-021</b>	<b>55.20</b>
<b>TC-132</b>	<b>29.76</b>
<b>TC-153</b>	<b>11.30</b>
<b>TC-001</b>	<b>3.74</b>

Starting Point	Formula
2635 C	
<b>TC-021</b>	<b>96.40</b>
<b>TC-132</b>	<b>3.21</b>
<b>TC-218</b>	<b>0.28</b>
<b>TC-103</b>	<b>0.11</b>

# Texcharge TC

Starting Point	Formula
2645 C	
<b>TC-021</b>	<b>92.61</b>
<b>TC-132</b>	<b>7.00</b>
<b>TC-218</b>	<b>0.39</b>

Starting Point	Formula
2655 C	
<b>TC-021</b>	<b>85.49</b>
<b>TC-132</b>	<b>13.76</b>
<b>TC-217</b>	<b>0.75</b>

Starting Point	Formula
2665 C	
<b>TC-021</b>	<b>72.58</b>
<b>TC-132</b>	<b>27.42</b>

Starting Point	Formula
2685 C	
<b>TC-132</b>	<b>75.13</b>
<b>TC-046</b>	<b>19.28</b>
<b>TC-217</b>	<b>5.59</b>

Starting Point	Formula
2695 C	
<b>TC-154</b>	<b>43.14</b>
<b>TC-046</b>	<b>33.40</b>
<b>TC-217</b>	<b>23.46</b>

Starting Point	Formula
270 C	
<b>TC-021</b>	<b>95.32</b>
<b>TC-218</b>	<b>1.63</b>
<b>TC-154</b>	<b>3.05</b>

Starting Point	Formula
271 C	
<b>TC-021</b>	<b>89.96</b>
<b>TC-218</b>	<b>3.40</b>
<b>TC-154</b>	<b>6.64</b>

Starting Point	Formula
272 C	
<b>TC-021</b>	<b>79.60</b>
<b>TC-218</b>	<b>6.87</b>
<b>TC-154</b>	<b>13.53</b>

Starting Point	Formula
273 C	
<b>TC-046</b>	<b>23.78</b>
<b>TC-217</b>	<b>24.22</b>
<b>TC-154</b>	<b>52.00</b>

Starting Point	Formula
274 C	
<b>TC-154</b>	<b>44.27</b>
<b>TC-217</b>	<b>36.22</b>
<b>TC-103</b>	<b>19.51</b>

Starting Point	Formula
275 C	
<b>TC-153</b>	<b>79.36</b>
<b>TC-218</b>	<b>20.64</b>

Starting Point	Formula
276 C	
<b>TC-154</b>	<b>77.93</b>
<b>TC-001</b>	<b>22.07</b>

Starting Point	Formula
2705 C	
<b>TC-021</b>	<b>93.56</b>
<b>TC-132</b>	<b>5.18</b>
<b>TC-218</b>	<b>1.26</b>

Starting Point	Formula
2715 C	
<b>TC-021</b>	<b>86.09</b>
<b>TC-132</b>	<b>10.55</b>
<b>TC-217</b>	<b>3.36</b>

Starting Point	Formula
2725 C	
<b>TC-021</b>	<b>67.65</b>
<b>TC-132</b>	<b>25.40</b>
<b>TC-217</b>	<b>6.95</b>

Starting Point	Formula
2735 C	
<b>TC-217</b>	<b>33.57</b>
<b>TC-154</b>	<b>66.43</b>

# Texcharge TC

Starting Point	Formula
2745 C	
<b>TC-153</b>	<b>48.76</b>
<b>TC-217</b>	<b>51.24</b>

Starting Point	Formula
2755 C	
<b>TC-153</b>	<b>57.88</b>
<b>TC-217</b>	<b>42.12</b>

Starting Point	Formula
2765 C	
<b>TC-157</b>	<b>65.07</b>
<b>TC-217</b>	<b>20.39</b>
<b>TC-001</b>	<b>14.54</b>

Starting Point	Formula
2706 C	
<b>TC-021</b>	<b>98.50</b>
<b>TC-218</b>	<b>0.62</b>
<b>TC-132</b>	<b>0.88</b>

Starting Point	Formula
2716 C	
<b>TC-021</b>	<b>94.10</b>
<b>TC-217</b>	<b>2.73</b>
<b>TC-132</b>	<b>3.17</b>

Starting Point	Formula
2726 C	
<b>TC-021</b>	<b>67.10</b>
<b>TC-217</b>	<b>15.04</b>
<b>TC-132</b>	<b>17.86</b>

Starting Point	Formula
2736 C	
<b>TC-217</b>	<b>64.61</b>
<b>TC-154</b>	<b>35.39</b>

Starting Point	Formula
2746 C	
<b>TC-217</b>	<b>76.06</b>
<b>TC-153</b>	<b>23.94</b>

Starting Point	Formula
2756 C	
<b>TC-217</b>	<b>64.56</b>
<b>TC-154</b>	<b>29.21</b>
<b>TC-001</b>	<b>6.23</b>

Starting Point	Formula
2766 C	
<b>TC-154</b>	<b>50.28</b>
<b>TC-217</b>	<b>35.36</b>
<b>TC-001</b>	<b>14.36</b>

Starting Point	Formula
2707 C	
<b>TC-021</b>	<b>98.10</b>
<b>TC-217</b>	<b>1.38</b>
<b>TC-132</b>	<b>0.52</b>

Starting Point	Formula
2717 C	
<b>TC-021</b>	<b>96.05</b>
<b>TC-217</b>	<b>2.72</b>
<b>TC-132</b>	<b>1.23</b>

Starting Point	Formula
2727 C	
<b>TC-021</b>	<b>74.53</b>
<b>TC-217</b>	<b>19.21</b>
<b>TC-132</b>	<b>6.26</b>

Starting Point	Formula
2747 C	
<b>TC-217</b>	<b>61.70</b>
<b>TC-153</b>	<b>38.30</b>

Starting Point	Formula
2757 C	
<b>TC-153</b>	<b>50.76</b>
<b>TC-217</b>	<b>49.24</b>

Starting Point	Formula
2767 C	
<b>TC-154</b>	<b>52.75</b>
<b>TC-217</b>	<b>30.89</b>
<b>TC-001</b>	<b>16.36</b>

# Texcharge TC

Starting Point	Formula
2708 C	
<b>TC-021</b>	<b>97.83</b>
<b>TC-218</b>	<b>1.09</b>
<b>TC-132</b>	<b>1.08</b>

Starting Point	Formula
2718 C	
<b>TC-021</b>	<b>83.51</b>
<b>TC-217</b>	<b>10.24</b>
<b>TC-132</b>	<b>6.25</b>

Starting Point	Formula
2728 C	
<b>TC-021</b>	<b>50.59</b>
<b>TC-217</b>	<b>31.16</b>
<b>TC-132</b>	<b>18.25</b>

Starting Point	Formula
2738 C	
<b>TC-217</b>	<b>50.14</b>
<b>TC-154</b>	<b>49.86</b>

Starting Point	Formula
2748 C	
<b>TC-217</b>	<b>60.11</b>
<b>TC-153</b>	<b>39.89</b>

Starting Point	Formula
2758 C	
<b>TC-217</b>	<b>49.26</b>
<b>TC-153</b>	<b>50.74</b>

Starting Point	Formula
2768 C	
<b>TC-154</b>	<b>61.97</b>
<b>TC-217</b>	<b>23.68</b>
<b>TC-001</b>	<b>14.35</b>

Starting Point	Formula
277 C	
<b>TC-021</b>	<b>97.17</b>
<b>TC-218</b>	<b>1.84</b>
<b>TC-154</b>	<b>0.99</b>

Starting Point	Formula
278 C	
<b>TC-021</b>	<b>93.80</b>
<b>TC-217</b>	<b>4.72</b>
<b>TC-132</b>	<b>1.48</b>

Starting Point	Formula
279 C	
<b>TC-021</b>	<b>81.00</b>
<b>TC-217</b>	<b>15.05</b>
<b>TC-132</b>	<b>3.95</b>

Starting Point	Formula
280 C	
<b>TC-153</b>	<b>56.72</b>
<b>TC-217</b>	<b>43.28</b>

Starting Point	Formula
281 C	
<b>TC-153</b>	<b>56.50</b>
<b>TC-217</b>	<b>43.50</b>

Starting Point	Formula
282 C	
<b>TC-154</b>	<b>57.91</b>
<b>TC-217</b>	<b>25.60</b>
<b>TC-001</b>	<b>16.49</b>

Starting Point	Formula
283 C	
<b>TC-021</b>	<b>95.79</b>
<b>TC-218</b>	<b>2.87</b>
<b>TC-132</b>	<b>1.34</b>

Starting Point	Formula
284 C	
<b>TC-021</b>	<b>90.48</b>
<b>TC-217</b>	<b>7.86</b>
<b>TC-132</b>	<b>1.66</b>

Starting Point	Formula
285 C	
<b>TC-021</b>	<b>63.30</b>
<b>TC-217</b>	<b>32.24</b>
<b>TC-132</b>	<b>4.46</b>

# Texcharge TC

Starting Point	Formula
286 C	
<b>TC-217</b>	<b>79.23</b>
<b>TC-154</b>	<b>20.77</b>

Starting Point	Formula
287 C	
<b>TC-217</b>	<b>76.60</b>
<b>TC-153</b>	<b>23.40</b>

Starting Point	Formula
288 C	
<b>TC-217</b>	<b>65.43</b>
<b>TC-154</b>	<b>27.99</b>
<b>TC-001</b>	<b>6.58</b>

Starting Point	Formula
289 C	
<b>TC-154</b>	<b>63.56</b>
<b>TC-217</b>	<b>17.51</b>
<b>TC001</b>	<b>18.93</b>

Starting Point	Formula
290 C	
<b>TC-021</b>	<b>98.13</b>
<b>TC-217</b>	<b>1.87</b>

Starting Point	Formula
291 C	
<b>TC-021</b>	<b>96.03</b>
<b>TC-217</b>	<b>3.58</b>
<b>TC-132</b>	<b>0.39</b>

Starting Point	Formula
292 C	
<b>TC-021</b>	<b>90.81</b>
<b>TC-217</b>	<b>8.22</b>
<b>TC-132</b>	<b>0.97</b>

Starting Point	Formula
293 C	
<b>TC-217</b>	<b>88.29</b>
<b>TC-154</b>	<b>11.71</b>

Starting Point	Formula
294 C	
<b>TC-217</b>	<b>68.12</b>
<b>TC-154</b>	<b>24.00</b>
<b>TC-001</b>	<b>7.88</b>

Starting Point	Formula
295 C	
<b>TC-217</b>	<b>69.68</b>
<b>TC-154</b>	<b>18.44</b>
<b>TC-001</b>	<b>11.88</b>

Starting Point	Formula
296 C	
<b>TC-154</b>	<b>49.18</b>
<b>TC-001</b>	<b>26.19</b>
<b>TC-217</b>	<b>24.63</b>

Starting Point	Formula
2905 C	
<b>TC-021</b>	<b>96.19</b>
<b>TC-218</b>	<b>3.16</b>
<b>TC-154</b>	<b>0.65</b>

Starting Point	Formula
2915 C	
<b>TC-021</b>	<b>92.61</b>
<b>TC-218</b>	<b>5.99</b>
<b>TC-154</b>	<b>1.40</b>

Starting Point	Formula
2925 C	
<b>TC-021</b>	<b>82.04</b>
<b>TC-217</b>	<b>17.61</b>
<b>TC-153</b>	<b>0.35</b>

Starting Point	Formula
2935 C	
<b>TC-217</b>	<b>100.00</b>

Starting Point	Formula
2945 C	
<b>TC-217</b>	<b>97.90</b>
<b>TC-001</b>	<b>2.10</b>



# Texcharge TC

Starting Point	Formula
2955 C	
<b>TC-217</b>	<b>87.20</b>
<b>TC-001</b>	<b>8.28</b>
<b>TC-154</b>	<b>4.52</b>

Starting Point	Formula
2965 C	
<b>TC-217</b>	<b>71.03</b>
<b>TC-001</b>	<b>18.05</b>
<b>TC-154</b>	<b>10.92</b>

Starting Point	Formula
297 C	
<b>TC-021</b>	<b>95.14</b>
<b>TC-218</b>	<b>4.64</b>
<b>TC-153</b>	<b>0.22</b>

Starting Point	Formula
298 C	
<b>TC-021</b>	<b>91.67</b>
<b>TC-218</b>	<b>7.68</b>
<b>TC-154</b>	<b>0.65</b>

Starting Point	Formula
299 C	
<b>TC-021</b>	<b>84.15</b>
<b>TC-218</b>	<b>14.69</b>
<b>TC-154</b>	<b>1.16</b>

Starting Point	Formula
300 C	
<b>TC-217</b>	<b>40.74</b>
<b>TC-218</b>	<b>59.26</b>

Starting Point	Formula
301 C	
<b>TC-217</b>	<b>95.27</b>
<b>TC-001</b>	<b>4.73</b>

Starting Point	Formula
302 C	
<b>TC-217</b>	<b>87.93</b>
<b>TC-001</b>	<b>12.07</b>

Starting Point	Formula
303 C	
<b>TC-217</b>	<b>76.85</b>
<b>TC-001</b>	<b>23.15</b>

Starting Point	Formula
2975 C	
<b>TC-021</b>	<b>97.30</b>
<b>TC-218</b>	<b>2.50</b>
<b>TC-057</b>	<b>0.20</b>

Starting Point	Formula
2985 C	
<b>TC-021</b>	<b>93.43</b>
<b>TC-218</b>	<b>6.16</b>
<b>TC-154</b>	<b>0.28</b>
<b>TC-057</b>	<b>0.13</b>

Starting Point	Formula
2995 C	
<b>TC-021</b>	<b>85.45</b>
<b>TC-218</b>	<b>14.41</b>
<b>TC-001</b>	<b>0.14</b>

Starting Point	Formula
3005 C	
<b>TC-021</b>	<b>59.18</b>
<b>TC-218</b>	<b>38.63</b>
<b>TC-154</b>	<b>2.19</b>

Starting Point	Formula
3015 C	
<b>TC-021</b>	<b>50.92</b>
<b>TC-218</b>	<b>36.65</b>
<b>TC-154</b>	<b>9.20</b>
<b>TC-057</b>	<b>3.23</b>

Starting Point	Formula
3025 C	
<b>TC-021</b>	<b>37.66</b>
<b>TC-218</b>	<b>30.31</b>
<b>TC-154</b>	<b>15.85</b>
<b>TC-046</b>	<b>16.18</b>

Starting Point	Formula
3035 C	
<b>TC-218</b>	<b>23.69</b>
<b>TC-154</b>	<b>24.07</b>
<b>TC-021</b>	<b>22.90</b>
<b>TC-046</b>	<b>29.34</b>

# Texcharge TC

Starting Point	Formula
304 C	
<b>TC-021</b>	<b>97.29</b>
<b>TC-218</b>	<b>1.73</b>
<b>TC-316</b>	<b>0.98</b>

Starting Point	Formula
305 C	
<b>TC-021</b>	<b>93.86</b>
<b>TC-218</b>	<b>5.36</b>
<b>TC-316</b>	<b>0.78</b>

Starting Point	Formula
306 C	
<b>TC-021</b>	<b>85.97</b>
<b>TC-218</b>	<b>12.72</b>
<b>TC-316</b>	<b>1.31</b>

Starting Point	Formula
307 C	
<b>TC-021</b>	<b>47.42</b>
<b>TC-218</b>	<b>44.92</b>
<b>TC-154</b>	<b>4.78</b>
<b>TC-057</b>	<b>2.88</b>

Starting Point	Formula
308 C	
<b>TC-021</b>	<b>40.00</b>
<b>TC-218</b>	<b>34.65</b>
<b>TC-154</b>	<b>16.67</b>
<b>TC-057</b>	<b>8.68</b>

Starting Point	Formula
309 C	
<b>TC-218</b>	<b>23.10</b>
<b>TC-154</b>	<b>26.40</b>
<b>TC-021</b>	<b>15.45</b>
<b>TC-046</b>	<b>35.05</b>

Starting Point	Formula
310 C	
<b>TC-021</b>	<b>94.88</b>
<b>TC-218</b>	<b>3.64</b>
<b>TC-316</b>	<b>1.48</b>

Starting Point	Formula
311 C	
<b>TC-021</b>	<b>90.93</b>
<b>TC-218</b>	<b>6.88</b>
<b>TC-316</b>	<b>2.19</b>

Starting Point	Formula
312 C	
<b>TC-021</b>	<b>77.83</b>
<b>TC-218</b>	<b>17.44</b>
<b>TC-316</b>	<b>4.73</b>

Starting Point	Formula
313 C	
<b>TC-021</b>	<b>63.77</b>
<b>TC-218</b>	<b>29.73</b>
<b>TC-316</b>	<b>6.50</b>

Starting Point	Formula
314 C	
<b>TC-021</b>	<b>50.99</b>
<b>TC-218</b>	<b>40.42</b>
<b>TC-046</b>	<b>8.59</b>

Starting Point	Formula
315 C	
<b>TC-021</b>	<b>40.88</b>
<b>TC-218</b>	<b>34.94</b>
<b>TC-154</b>	<b>7.18</b>
<b>TC-046</b>	<b>17.00</b>

Starting Point	Formula
316 C	
<b>TC-021</b>	<b>31.08</b>
<b>TC-218</b>	<b>26.25</b>
<b>TC-153</b>	<b>14.50</b>
<b>TC-046</b>	<b>28.17</b>

Starting Point	Formula
3105 C	
<b>TC-021</b>	<b>94.81</b>
<b>TC-316</b>	<b>2.06</b>
<b>TC-218</b>	<b>3.13</b>

Starting Point	Formula
3115 C	
<b>TC-021</b>	<b>88.91</b>
<b>TC-218</b>	<b>7.28</b>
<b>TC-316</b>	<b>3.81</b>

Starting Point	Formula
3125 C	
<b>TC-021</b>	<b>79.21</b>
<b>TC-316</b>	<b>6.56</b>
<b>TC-218</b>	<b>14.23</b>

# Texcharge TC

Starting Point	Formula
3135 C	
<b>TC-021</b>	<b>58.29</b>
<b>TC-316</b>	<b>11.75</b>
<b>TC-218</b>	<b>29.96</b>

Starting Point	Formula
3145 C	
<b>TC-021</b>	<b>45.90</b>
<b>TC-046</b>	<b>15.08</b>
<b>TC-218</b>	<b>37.63</b>
<b>TC-139</b>	<b>1.39</b>

Starting Point	Formula
3155 C	
<b>TC-046</b>	<b>27.56</b>
<b>TC-217</b>	<b>72.44</b>

Starting Point	Formula
3165 C	
<b>TC-217</b>	<b>67.53</b>
<b>TC-046</b>	<b>27.03</b>
<b>TC-001</b>	<b>5.44</b>

Starting Point	Formula
317 C	
<b>TC-021</b>	<b>98.09</b>
<b>TC-316</b>	<b>1.59</b>
<b>TC-218</b>	<b>0.32</b>

Starting Point	Formula
318 C	
<b>TC-021</b>	<b>96.35</b>
<b>TC-316</b>	<b>2.10</b>
<b>TC-218</b>	<b>1.55</b>

Starting Point	Formula
319 C	
<b>TC-021</b>	<b>92.02</b>
<b>TC-316</b>	<b>4.15</b>
<b>TC-218</b>	<b>3.83</b>

Starting Point	Formula
320 C	
<b>TC-021</b>	<b>64.83</b>
<b>TC-316</b>	<b>16.00</b>
<b>TC-218</b>	<b>19.17</b>

Starting Point	Formula
321 C	
<b>TC-021</b>	<b>56.93</b>
<b>TC-218</b>	<b>26.24</b>
<b>TC-046</b>	<b>7.32</b>
<b>TC-316</b>	<b>9.51</b>

Starting Point	Formula
322 C	
<b>TC-021</b>	<b>38.53</b>
<b>TC-217</b>	<b>38.62</b>
<b>TC-046</b>	<b>20.00</b>
<b>TC-316</b>	<b>2.85</b>

Starting Point	Formula
323 C	
<b>TC-012</b>	<b>38.01</b>
<b>TC-217</b>	<b>37.17</b>
<b>TC-046</b>	<b>22.61</b>
<b>TC-001</b>	<b>2.21</b>

Starting Point	Formula
324 C	
<b>TC-021</b>	<b>96.60</b>
<b>TC-217</b>	<b>1.17</b>
<b>TC-216</b>	<b>2.23</b>

Starting Point	Formula
325 C	
<b>TC-021</b>	<b>91.62</b>
<b>TC-046</b>	<b>1.92</b>
<b>TC-218</b>	<b>3.91</b>
<b>TC-316</b>	<b>2.55</b>

Starting Point	Formula
326 C	
<b>TC-021</b>	<b>77.46</b>
<b>TC-046</b>	<b>3.41</b>
<b>TC-218</b>	<b>10.31</b>
<b>TC-316</b>	<b>8.82</b>

Starting Point	Formula
327 C	
<b>TC-217</b>	<b>48.76</b>
<b>TC-316</b>	<b>51.24</b>

Starting Point	Formula
328 C	
<b>TC-046</b>	<b>38.93</b>
<b>TC-218</b>	<b>61.07</b>

# Texcharge TC

Starting Point	Formula
329 C	
<b>TC-217</b>	<b>60.67</b>
<b>TC-046</b>	<b>39.33</b>

Starting Point	Formula
330 C	
<b>TC-217</b>	<b>54.97</b>
<b>TC-046</b>	<b>38.99</b>
<b>TC-001</b>	<b>6.04</b>

Starting Point	Formula
3242 C	
<b>TC-021</b>	<b>94.28</b>
<b>TC-316</b>	<b>4.79</b>
<b>TC-218</b>	<b>0.93</b>

Starting Point	Formula
3252 C	
<b>TC-021</b>	<b>89.70</b>
<b>TC-316</b>	<b>8.05</b>
<b>TC-218</b>	<b>2.25</b>

Starting Point	Formula
3262 C	
<b>TC-021</b>	<b>75.53</b>
<b>TC-316</b>	<b>18.61</b>
<b>TC-218</b>	<b>5.86</b>

Starting Point	Formula
3272 C	
<b>TC-021</b>	<b>50.72</b>
<b>TC-316</b>	<b>35.28</b>
<b>TC-218</b>	<b>14.00</b>

Starting Point	Formula
3282 C	
<b>TC-316</b>	<b>41.18</b>
<b>TC-021</b>	<b>34.95</b>
<b>TC-217</b>	<b>23.87</b>

Starting Point	Formula
3292 C	
<b>TC-217</b>	<b>54.96</b>
<b>TC-046</b>	<b>38.90</b>
<b>TC-316</b>	<b>3.70</b>
<b>TC-001</b>	<b>2.44</b>

Starting Point	Formula
3302 C	
<b>TC-217</b>	<b>52.54</b>
<b>TC-046</b>	<b>40.73</b>
<b>TC-001</b>	<b>6.73</b>

Starting Point	Formula
3245 C	
<b>TC-021</b>	<b>94.74</b>
<b>TC-316</b>	<b>5.26</b>

Starting Point	Formula
3255 C	
<b>TC-021</b>	<b>89.31</b>
<b>TC-316</b>	<b>9.92</b>
<b>TC-218</b>	<b>0.77</b>

Starting Point	Formula
3265 C	
<b>TC-021</b>	<b>78.85</b>
<b>TC-316</b>	<b>19.13</b>
<b>TC-218</b>	<b>2.02</b>

Starting Point	Formula
3275 C	
<b>TC-021</b>	<b>58.72</b>
<b>TC-316</b>	<b>36.89</b>
<b>TC-218</b>	<b>4.39</b>

Starting Point	Formula
3285 C	
<b>TC-021</b>	<b>53.77</b>
<b>TC-316</b>	<b>35.07</b>
<b>TC-217</b>	<b>11.16</b>

Starting Point	Formula
3295 C	
<b>TC-046</b>	<b>40.59</b>
<b>TC-217</b>	<b>48.53</b>
<b>TC-316</b>	<b>10.88</b>

Starting Point	Formula
3305 C	
<b>TC-046</b>	<b>44.30</b>
<b>TC-217</b>	<b>48.54</b>
<b>TC-001</b>	<b>7.16</b>

# Texcharge TC

Starting Point	Formula
3248 C	
<b>TC-021</b>	<b>90.48</b>
<b>TC-218</b>	<b>5.11</b>
<b>TC-057</b>	<b>4.41</b>

Starting Point	Formula
3258 C	
<b>TC-021</b>	<b>87.21</b>
<b>TC-218</b>	<b>7.51</b>
<b>TC-057</b>	<b>5.28</b>

Starting Point	Formula
3268 C	
<b>TC-021</b>	<b>66.94</b>
<b>TC-316</b>	<b>16.19</b>
<b>TC-218</b>	<b>8.87</b>
<b>TC-046</b>	<b>8.00</b>

Starting Point	Formula
3278 C	
<b>TC-021</b>	<b>49.25</b>
<b>TC-316</b>	<b>28.43</b>
<b>TC-218</b>	<b>12.39</b>
<b>TC-046</b>	<b>9.93</b>

Starting Point	Formula
3288 C	
<b>TC-021</b>	<b>29.43</b>
<b>TC-046</b>	<b>30.86</b>
<b>TC-218</b>	<b>29.15</b>
<b>TC-316</b>	<b>10.56</b>

Starting Point	Formula
3298 C	
<b>TC-046</b>	<b>49.72</b>
<b>TC-217</b>	<b>50.28</b>

Starting Point	Formula
3308 C	
<b>TC-046</b>	<b>45.83</b>
<b>TC-217</b>	<b>43.87</b>
<b>TC-001</b>	<b>10.30</b>

Starting Point	Formula
331 C	
<b>TC-021</b>	<b>96.83</b>
<b>TC-316</b>	<b>2.38</b>
<b>TC-057</b>	<b>0.79</b>

Starting Point	Formula
332 C	
<b>TC-021</b>	<b>95.48</b>
<b>TC-316</b>	<b>3.75</b>
<b>TC-057</b>	<b>0.77</b>

Starting Point	Formula
333 C	
<b>TC-021</b>	<b>90.25</b>
<b>TC-316</b>	<b>9.25</b>
<b>TC-057</b>	<b>0.50</b>

Starting Point	Formula
334 C	
<b>TC-057</b>	<b>39.82</b>
<b>TC-217</b>	<b>60.18</b>

Starting Point	Formula
335 C	
<b>TC-046</b>	<b>47.78</b>
<b>TC-217</b>	<b>41.62</b>
<b>TC-316</b>	<b>10.60</b>

Starting Point	Formula
336 C	
<b>TC-046</b>	<b>52.60</b>
<b>TC-217</b>	<b>46.50</b>
<b>TC-001</b>	<b>0.90</b>

Starting Point	Formula
337 C	
<b>TC-021</b>	<b>92.98</b>
<b>TC-057</b>	<b>3.96</b>
<b>TC-218</b>	<b>3.06</b>

Starting Point	Formula
338 C	
<b>TC-021</b>	<b>89.94</b>
<b>TC-057</b>	<b>5.11</b>
<b>TC-218</b>	<b>4.95</b>

Starting Point	Formula
339 C	
<b>TC-021</b>	<b>71.80</b>
<b>TC-057</b>	<b>13.74</b>
<b>TC-218</b>	<b>13.09</b>
<b>TC-316</b>	<b>1.37</b>

# Texcharge TC

Starting Point	Formula
340 C	
<b>TC-021</b>	<b>45.49</b>
<b>TC-057</b>	<b>29.45</b>
<b>TC-218</b>	<b>25.06</b>

Starting Point	Formula
341 C	
<b>TC-046</b>	<b>52.10</b>
<b>TC-218</b>	<b>28.52</b>
<b>TC-021</b>	<b>18.62</b>
<b>TC-001</b>	<b>0.76</b>

Starting Point	Formula
342 C	
<b>TC-046</b>	<b>53.35</b>
<b>TC-218</b>	<b>28.29</b>
<b>TC-021</b>	<b>14.99</b>
<b>TC-001</b>	<b>3.37</b>

Starting Point	Formula
343 C	
<b>TC-046</b>	<b>56.30</b>
<b>TC-217</b>	<b>37.12</b>
<b>TC-001</b>	<b>6.58</b>

Starting Point	Formula
3375 C	
<b>TC-021</b>	<b>93.28</b>
<b>TC-316</b>	<b>4.79</b>
<b>TC-057</b>	<b>1.93</b>

Starting Point	Formula
3385 C	
<b>TC-021</b>	<b>88.40</b>
<b>TC-316</b>	<b>8.61</b>
<b>TC-057</b>	<b>2.99</b>

Starting Point	Formula
3395 C	
<b>TC-021</b>	<b>69.70</b>
<b>TC-316</b>	<b>22.75</b>
<b>TC-057</b>	<b>7.55</b>

Starting Point	Formula
3405 C	
<b>TC-021</b>	<b>44.00</b>
<b>TC-316</b>	<b>40.89</b>
<b>TC-057</b>	<b>15.11</b>

Starting Point	Formula
3415 C	
<b>TC-316</b>	<b>52.82</b>
<b>TC-021</b>	<b>24.54</b>
<b>TC-046</b>	<b>19.70</b>
<b>TC-001</b>	<b>2.94</b>

Starting Point	Formula
3425 C	
<b>TC-046</b>	<b>58.23</b>
<b>TC-217</b>	<b>37.92</b>
<b>TC-001</b>	<b>2.08</b>
<b>TC-316</b>	<b>1.77</b>

Starting Point	Formula
3435 C	
<b>TC-046</b>	<b>54.16</b>
<b>TC-217</b>	<b>36.48</b>
<b>TC-001</b>	<b>9.36</b>

Starting Point	Formula
344 C	
<b>TC-021</b>	<b>92.95</b>
<b>TC-057</b>	<b>4.87</b>
<b>TC-218</b>	<b>2.18</b>

Starting Point	Formula
345 C	
<b>TC-021</b>	<b>90.89</b>
<b>TC-057</b>	<b>6.04</b>
<b>TC-218</b>	<b>3.07</b>

Starting Point	Formula
346 C	
<b>TC-021</b>	<b>85.87</b>
<b>TC-057</b>	<b>9.45</b>
<b>TC-218</b>	<b>4.68</b>

Starting Point	Formula
347 C	
<b>TC-046</b>	<b>52.81</b>
<b>TC-316</b>	<b>47.19</b>

Starting Point	Formula
348 C	
<b>TC-046</b>	<b>76.99</b>
<b>TC-218</b>	<b>23.01</b>

# Texcharge TC

Starting Point	Formula
349 C	
<b>TC-046</b>	<b>69.06</b>
<b>TC-217</b>	<b>29.07</b>
<b>TC-001</b>	<b>1.87</b>

Starting Point	Formula
350 C	
<b>TC-046</b>	<b>66.94</b>
<b>TC-217</b>	<b>24.43</b>
<b>TC-001</b>	<b>8.63</b>

Starting Point	Formula
351 C	
<b>TC-021</b>	<b>94.09</b>
<b>TC-057</b>	<b>3.40</b>
<b>TC-316</b>	<b>2.51</b>

Starting Point	Formula
352 C	
<b>TC-021</b>	<b>92.31</b>
<b>TC-057</b>	<b>4.09</b>
<b>TC-316</b>	<b>3.60</b>

Starting Point	Formula
353 C	
<b>TC-021</b>	<b>90.29</b>
<b>TC-057</b>	<b>5.07</b>
<b>TC-316</b>	<b>4.64</b>

Starting Point	Formula
354 C	
<b>TC-046</b>	<b>62.70</b>
<b>TC-316</b>	<b>37.30</b>

Starting Point	Formula
355 C	
<b>TC-046</b>	<b>56.12</b>
<b>TC-316</b>	<b>43.88</b>

Starting Point	Formula
356 C	
<b>TC-046</b>	<b>68.18</b>
<b>TC-217</b>	<b>19.00</b>
<b>TC-316</b>	<b>12.40</b>
<b>TC-001</b>	<b>0.42</b>

Starting Point	Formula
357 C	
<b>TC-046</b>	<b>66.48</b>
<b>TC-217</b>	<b>27.83</b>
<b>TC-001</b>	<b>5.69</b>

Starting Point	Formula
358 C	
<b>TC-021</b>	<b>88.91</b>
<b>TC-057</b>	<b>9.53</b>
<b>TC-218</b>	<b>1.56</b>

Starting Point	Formula
359 C	
<b>TC-021</b>	<b>85.56</b>
<b>TC-057</b>	<b>12.46</b>
<b>TC-218</b>	<b>1.98</b>

Starting Point	Formula
360 C	
<b>TC-021</b>	<b>53.83</b>
<b>TC-057</b>	<b>36.42</b>
<b>TC-046</b>	<b>4.87</b>
<b>TC-218</b>	<b>4.88</b>

Starting Point	Formula
361 C	
<b>TC-057</b>	<b>54.77</b>
<b>TC-021</b>	<b>27.88</b>
<b>TC-046</b>	<b>9.42</b>
<b>TC-218</b>	<b>7.93</b>

Starting Point	Formula
362 C	
<b>TC-046</b>	<b>22.84</b>
<b>TC-057</b>	<b>39.47</b>
<b>TC-217</b>	<b>12.19</b>
<b>TC-021</b>	<b>25.50</b>

Starting Point	Formula
363 C	
<b>TC-046</b>	<b>22.22</b>
<b>TC-057</b>	<b>42.32</b>
<b>TC-021</b>	<b>25.49</b>
<b>TC-218</b>	<b>8.33</b>
<b>TC-001</b>	<b>1.64</b>

Starting Point	Formula
364 C	
<b>TC-046</b>	<b>29.31</b>
<b>TC-057</b>	<b>37.77</b>
<b>TC-021</b>	<b>21.04</b>
<b>TC-218</b>	<b>8.35</b>
<b>TC-001</b>	<b>3.53</b>

# Texcharge TC

Starting Point	Formula
365 C	
<b>TC-021</b>	<b>86.47</b>
<b>TC-057</b>	<b>12.50</b>
<b>TC-218</b>	<b>1.03</b>

Starting Point	Formula
366 C	
<b>TC-021</b>	<b>82.07</b>
<b>TC-057</b>	<b>16.62</b>
<b>TC-218</b>	<b>1.31</b>

Starting Point	Formula
367 C	
<b>TC-021</b>	<b>71.17</b>
<b>TC-057</b>	<b>26.89</b>
<b>TC-218</b>	<b>1.94</b>

Starting Point	Formula
368 C	
<b>TC-046</b>	<b>90.51</b>
<b>TC-316</b>	<b>9.49</b>

Starting Point	Formula
369 C	
<b>TC-046</b>	<b>90.81</b>
<b>TC-316</b>	<b>6.63</b>
<b>TC-218</b>	<b>2.56</b>

Starting Point	Formula
370 C	
<b>TC-046</b>	<b>74.62</b>
<b>TC-057</b>	<b>13.19</b>
<b>TC-217</b>	<b>11.38</b>
<b>TC-001</b>	<b>0.81</b>

Starting Point	Formula
371 C	
<b>TC-046</b>	<b>84.70</b>
<b>TC-217</b>	<b>9.79</b>
<b>TC-001</b>	<b>5.51</b>

Starting Point	Formula
372 C	
<b>TC-021</b>	<b>86.33</b>
<b>TC-057</b>	<b>12.96</b>
<b>TC-316</b>	<b>0.71</b>

Starting Point	Formula
373 C	
<b>TC-021</b>	<b>82.00</b>
<b>TC-057</b>	<b>17.04</b>
<b>TC-316</b>	<b>0.96</b>

Starting Point	Formula
374 C	
<b>TC-021</b>	<b>73.97</b>
<b>TC-057</b>	<b>24.75</b>
<b>TC-316</b>	<b>1.28</b>

Starting Point	Formula
375 C	
<b>TC-021</b>	<b>30.50</b>
<b>TC-057</b>	<b>66.21</b>
<b>TC-316</b>	<b>3.29</b>

Starting Point	Formula
376 C	
<b>TC-057</b>	<b>50.52</b>
<b>TC-046</b>	<b>29.37</b>
<b>TC-021</b>	<b>14.22</b>
<b>TC-316</b>	<b>3.39</b>
<b>TC-217</b>	<b>2.5</b>

Starting Point	Formula
377 C	
<b>TC-057</b>	<b>50.74</b>
<b>TC-046</b>	<b>25.68</b>
<b>TC-021</b>	<b>16.50</b>
<b>TC-316</b>	<b>4.87</b>
<b>TC-001</b>	<b>2.21</b>

Starting Point	Formula
378 C	
<b>TC-057</b>	<b>41.85</b>
<b>TC-046</b>	<b>29.78</b>
<b>TC-021</b>	<b>15.19</b>
<b>TC-001</b>	<b>8.59</b>
<b>TC-316</b>	<b>4.59</b>

Starting Point	Formula
379 C	
<b>TC-021</b>	<b>77.70</b>
<b>TC-057</b>	<b>22.11</b>
<b>TC-316</b>	<b>0.19</b>

Starting Point	Formula
380 C	
<b>TC-021</b>	<b>62.03</b>
<b>TC-057</b>	<b>37.55</b>
<b>TC-316</b>	<b>0.42</b>



# Texcharge TC

Starting Point	Formula
381 C	
<b>TC-057</b>	<b>68.85</b>
<b>TC-021</b>	<b>30.38</b>
<b>TC-218</b>	<b>0.77</b>

Starting Point	Formula
382 C	
<b>TC-046</b>	<b>97.46</b>
<b>TC-316</b>	<b>2.54</b>

Starting Point	Formula
383 C	
<b>TC-046</b>	<b>90.36</b>
<b>TC-057</b>	<b>5.59</b>
<b>TC-217</b>	<b>4.05</b>

Starting Point	Formula
384 C	
<b>TC-046</b>	<b>81.87</b>
<b>TC-057</b>	<b>12.69</b>
<b>TC-217</b>	<b>3.84</b>
<b>TC-001</b>	<b>1.60</b>

Starting Point	Formula
385 C	
<b>TC-046</b>	<b>91.11</b>
<b>TC-001</b>	<b>4.92</b>
<b>TC-217</b>	<b>3.97</b>

Starting Point	Formula
386 C	
<b>TC-021</b>	<b>76.81</b>
<b>TC-057</b>	<b>23.19</b>

Starting Point	Formula
387 C	
<b>TC-021</b>	<b>55.14</b>
<b>TC-057</b>	<b>44.59</b>
<b>TC-316</b>	<b>0.27</b>

Starting Point	Formula
388 C	
<b>TC-057</b>	<b>58.59</b>
<b>TC-021</b>	<b>40.97</b>
<b>TC-316</b>	<b>0.44</b>

Starting Point	Formula
389 C	
<b>TC-057</b>	<b>76.92</b>
<b>TC-021</b>	<b>22.28</b>
<b>TC-316</b>	<b>0.80</b>

Starting Point	Formula
390 C	
<b>TC-046</b>	<b>70.52</b>
<b>TC-057</b>	<b>27.25</b>
<b>TC-218</b>	<b>2.23</b>

Starting Point	Formula
391 C	
<b>TC-046</b>	<b>76.96</b>
<b>TC-057</b>	<b>18.12</b>
<b>TC-217</b>	<b>3.14</b>
<b>TC-001</b>	<b>1.78</b>

Starting Point	Formula
392 C	
<b>TC-046</b>	<b>83.50</b>
<b>TC-057</b>	<b>9.43</b>
<b>TC-217</b>	<b>3.17</b>
<b>TC-001</b>	<b>3.90</b>

Starting Point	Formula
393 C	
<b>TC-021</b>	<b>80.51</b>
<b>TC-057</b>	<b>19.49</b>

Starting Point	Formula
394 C	
<b>TC-021</b>	<b>55.17</b>
<b>TC-057</b>	<b>44.83</b>

Starting Point	Formula
395 C	
<b>TC-057</b>	<b>53.35</b>
<b>TC-021</b>	<b>46.65</b>

Starting Point	Formula
396 C	
<b>TC-057</b>	<b>84.62</b>
<b>TC-021</b>	<b>15.01</b>
<b>TC-316</b>	<b>0.37</b>

# Texcharge TC

Starting Point	Formula
397 C	
<b>TC-046</b>	<b>41.94</b>
<b>TC-057</b>	<b>39.76</b>
<b>TC-021</b>	<b>16.64</b>
<b>TC-218</b>	<b>1.08</b>
<b>TC-001</b>	<b>0.58</b>

Starting Point	Formula
398 C	
<b>TC-046</b>	<b>88.90</b>
<b>TC-057</b>	<b>7.33</b>
<b>TC-217</b>	<b>2.74</b>
<b>TC-001</b>	<b>1.03</b>

Starting Point	Formula
399 C	
<b>TC-046</b>	<b>69.77</b>
<b>TC-057</b>	<b>25.89</b>
<b>TC-001</b>	<b>2.53</b>
<b>TC-217</b>	<b>1.81</b>

Starting Point	Formula
3935 C	
<b>TC-057</b>	<b>30.17</b>
<b>TC-021</b>	<b>65.24</b>
<b>TC-046</b>	<b>4.59</b>

Starting Point	Formula
3945 C	
<b>TC-057</b>	<b>75.65</b>
<b>TC-021</b>	<b>24.35</b>

Starting Point	Formula
3955 C	
<b>TC-057</b>	<b>100.00</b>

Starting Point	Formula
3965 C	
<b>TC-057</b>	<b>75.04</b>
<b>TC-046</b>	<b>24.60</b>
<b>TC-218</b>	<b>0.36</b>

Starting Point	Formula
3975 C	
<b>TC-046</b>	<b>75.29</b>
<b>TC-057</b>	<b>22.30</b>
<b>TC-001</b>	<b>1.35</b>
<b>TC-217</b>	<b>1.06</b>

Starting Point	Formula
3985 C	
<b>TC-046</b>	<b>83.34</b>
<b>TC-057</b>	<b>12.11</b>
<b>TC-001</b>	<b>3.34</b>
<b>TC-217</b>	<b>1.21</b>

Starting Point	Formula
3995 C	
<b>TC-046</b>	<b>88.19</b>
<b>TC-001</b>	<b>8.54</b>
<b>TC-217</b>	<b>3.27</b>

Starting Point	Formula
400 C	
<b>TC-021</b>	<b>97.00</b>
<b>TC-001</b>	<b>1.38</b>
<b>TC-057</b>	<b>1.43</b>
<b>TC-122</b>	<b>0.19</b>

Starting Point	Formula
401 C	
<b>TC-021</b>	<b>92.57</b>
<b>TC-046</b>	<b>4.47</b>
<b>TC-001</b>	<b>2.68</b>
<b>TC-153</b>	<b>0.28</b>

Starting Point	Formula
402 C	
<b>TC-021</b>	<b>89.56</b>
<b>TC-046</b>	<b>5.80</b>
<b>TC-001</b>	<b>3.93</b>
<b>TC-153</b>	<b>0.71</b>

Starting Point	Formula
403 C	
<b>TC-021</b>	<b>82.39</b>
<b>TC-046</b>	<b>10.35</b>
<b>TC-001</b>	<b>6.18</b>
<b>TC-153</b>	<b>1.08</b>

Starting Point	Formula
404 C	
<b>TC-021</b>	<b>70.54</b>
<b>TC-046</b>	<b>17.76</b>
<b>TC-001</b>	<b>9.44</b>
<b>TC-153</b>	<b>2.26</b>

Starting Point	Formula
405 C	
<b>TC-021</b>	<b>57.60</b>
<b>TC-046</b>	<b>27.12</b>
<b>TC-001</b>	<b>12.08</b>
<b>TC-153</b>	<b>3.20</b>

# Texcharge TC

Starting Point	Formula
406 C	
<b>TC-021</b>	<b>97.17</b>
<b>TC-001</b>	<b>1.28</b>
<b>TC-057</b>	<b>1.07</b>
<b>TC-153</b>	<b>0.48</b>

Starting Point	Formula
407 C	
<b>TC-021</b>	<b>93.98</b>
<b>TC-001</b>	<b>2.59</b>
<b>TC-057</b>	<b>2.36</b>
<b>TC-153</b>	<b>1.07</b>

Starting Point	Formula
408 C	
<b>TC-021</b>	<b>89.68</b>
<b>TC-001</b>	<b>4.86</b>
<b>TC-057</b>	<b>3.27</b>
<b>TC-153</b>	<b>2.19</b>

Starting Point	Formula
409 C	
<b>TC-021</b>	<b>82.92</b>
<b>TC-001</b>	<b>6.75</b>
<b>TC-057</b>	<b>6.39</b>
<b>TC-153</b>	<b>3.94</b>

Starting Point	Formula
410 C	
<b>TC-021</b>	<b>74.44</b>
<b>TC-001</b>	<b>9.65</b>
<b>TC-057</b>	<b>9.78</b>
<b>TC-153</b>	<b>6.13</b>

Starting Point	Formula
411 C	
<b>TC-021</b>	<b>48.54</b>
<b>TC-046</b>	<b>28.15</b>
<b>TC-001</b>	<b>14.31</b>
<b>TC-153</b>	<b>9.00</b>

Starting Point	Formula
412 C	
<b>TC-153</b>	<b>41.71</b>
<b>TC-046</b>	<b>34.05</b>
<b>TC-316</b>	<b>24.24</b>

Starting Point	Formula
413 C	
<b>TC-021</b>	<b>94.34</b>
<b>TC-046</b>	<b>3.62</b>
<b>TC-001</b>	<b>1.77</b>
<b>TC-316</b>	<b>0.27</b>

Starting Point	Formula
414 C	
<b>TC-021</b>	<b>91.10</b>
<b>TC-046</b>	<b>5.52</b>
<b>TC-001</b>	<b>3.02</b>
<b>TC-316</b>	<b>0.36</b>

Starting Point	Formula
415 C	
<b>TC-021</b>	<b>86.80</b>
<b>TC-046</b>	<b>7.64</b>
<b>TC-001</b>	<b>4.91</b>
<b>TC-316</b>	<b>0.65</b>

Starting Point	Formula
416 C	
<b>TC-021</b>	<b>84.31</b>
<b>TC-001</b>	<b>8.21</b>
<b>TC-057</b>	<b>7.48</b>

Starting Point	Formula
417 C	
<b>TC-021</b>	<b>64.86</b>
<b>TC-046</b>	<b>21.00</b>
<b>TC-001</b>	<b>12.92</b>
<b>TC-316</b>	<b>1.22</b>

Starting Point	Formula
418 C	
<b>TC-021</b>	<b>51.62</b>
<b>TC-046</b>	<b>28.58</b>
<b>TC-001</b>	<b>18.21</b>
<b>TC-316</b>	<b>1.59</b>

Starting Point	Formula
419 C	
<b>TC-153</b>	<b>38.85</b>
<b>TC-316</b>	<b>30.35</b>
<b>TC-046</b>	<b>19.67</b>
<b>TC-001</b>	<b>11.13</b>

Starting Point	Formula
420 C	
<b>TC-021</b>	<b>93.41</b>
<b>TC-046</b>	<b>4.24</b>
<b>TC-132</b>	<b>1.74</b>
<b>TC-218</b>	<b>0.61</b>

Starting Point	Formula
421 C	
<b>TC-021</b>	<b>86.15</b>
<b>TC-046</b>	<b>8.65</b>
<b>TC-132</b>	<b>3.37</b>
<b>TC-217</b>	<b>1.83</b>

# Texcharge TC

Starting Point	Formula
422 C	
<b>TC-021</b>	<b>81.72</b>
<b>TC-046</b>	<b>11.29</b>
<b>TC-132</b>	<b>5.22</b>
<b>TC-218</b>	<b>1.77</b>

Starting Point	Formula
423 C	
<b>TC-021</b>	<b>69.34</b>
<b>TC-046</b>	<b>18.89</b>
<b>TC-132</b>	<b>8.88</b>
<b>TC-218</b>	<b>2.89</b>

Starting Point	Formula
424 C	
<b>TC-021</b>	<b>51.30</b>
<b>TC-046</b>	<b>30.60</b>
<b>TC-132</b>	<b>13.89</b>
<b>TC-218</b>	<b>4.21</b>

Starting Point	Formula
425 C	
<b>TC-021</b>	<b>82.35</b>
<b>TC-001</b>	<b>17.65</b>

Starting Point	Formula
426 C	
<b>TC-046</b>	<b>42.23</b>
<b>TC-132</b>	<b>27.81</b>
<b>TC-001</b>	<b>20.37</b>
<b>TC-021</b>	<b>9.59</b>

Starting Point	Formula
427 C	
<b>TC-021</b>	<b>98.79</b>
<b>TC-001</b>	<b>0.43</b>
<b>TC-217</b>	<b>0.39</b>
<b>TC-046</b>	<b>0.39</b>

Starting Point	Formula
428 C	
<b>TC-021</b>	<b>98.90</b>
<b>TC-001</b>	<b>1.10</b>

Starting Point	Formula
429 C	
<b>TC-021</b>	<b>95.81</b>
<b>TC-001</b>	<b>2.65</b>
<b>TC-217</b>	<b>1.27</b>
<b>TC-057</b>	<b>0.27</b>

Starting Point	Formula
430 C	
<b>TC-021</b>	<b>89.26</b>
<b>TC-001</b>	<b>6.55</b>
<b>TC-217</b>	<b>3.70</b>
<b>TC-046</b>	<b>0.49</b>

Starting Point	Formula
431 C	
<b>TC-021</b>	<b>85.51</b>
<b>TC-001</b>	<b>14.49</b>

Starting Point	Formula
432 C	
<b>TC-046</b>	<b>50.72</b>
<b>TC-217</b>	<b>18.30</b>
<b>TC-132</b>	<b>30.98</b>

Starting Point	Formula
433 C	
<b>TC-046</b>	<b>44.90</b>
<b>TC-132</b>	<b>35.87</b>
<b>TC-001</b>	<b>10.58</b>
<b>TC-217</b>	<b>8.65</b>

Starting Point	Formula
434 C	
<b>TC-021</b>	<b>96.10</b>
<b>TC-046</b>	<b>1.17</b>
<b>TC-316</b>	<b>1.21</b>
<b>TC-122</b>	<b>1.52</b>

Starting Point	Formula
435 C	
<b>TC-021</b>	<b>94.32</b>
<b>TC-122</b>	<b>2.58</b>
<b>TC-046</b>	<b>1.11</b>
<b>TC-316</b>	<b>1.99</b>

Starting Point	Formula
436 C	
<b>TC-021</b>	<b>89.32</b>
<b>TC-122</b>	<b>5.18</b>
<b>TC-316</b>	<b>3.77</b>
<b>TC-046</b>	<b>1.73</b>

Starting Point	Formula
437 C	
<b>TC-021</b>	<b>66.89</b>
<b>TC-122</b>	<b>16.28</b>
<b>TC-316</b>	<b>10.66</b>
<b>TC-046</b>	<b>6.17</b>

# Texcharge TC

Starting Point	Formula
438 C	
<b>TC-046</b>	<b>45.60</b>
<b>TC-153</b>	<b>35.95</b>
<b>TC-316</b>	<b>18.45</b>

Starting Point	Formula
439 C	
<b>TC-046</b>	<b>39.23</b>
<b>TC-316</b>	<b>21.78</b>
<b>TC-153</b>	<b>38.99</b>

Starting Point	Formula
440 C	
<b>TC-046</b>	<b>36.49</b>
<b>TC-316</b>	<b>25.08</b>
<b>TC-153</b>	<b>38.43</b>

Starting Point	Formula
441 C	
<b>TC-021</b>	<b>97.37</b>
<b>TC-001</b>	<b>1.12</b>
<b>TC-046</b>	<b>1.00</b>
<b>TC-316</b>	<b>0.51</b>

Starting Point	Formula
442 C	
<b>TC-021</b>	<b>95.25</b>
<b>TC-001</b>	<b>2.55</b>
<b>TC-046</b>	<b>1.31</b>
<b>TC-316</b>	<b>0.89</b>

Starting Point	Formula
443 C	
<b>TC-021</b>	<b>94.22</b>
<b>TC-001</b>	<b>3.53</b>
<b>TC-046</b>	<b>0.99</b>
<b>TC-316</b>	<b>1.26</b>

Starting Point	Formula
444 C	
<b>TC-021</b>	<b>88.28</b>
<b>TC-001</b>	<b>7.45</b>
<b>TC-046</b>	<b>2.17</b>
<b>TC-316</b>	<b>2.10</b>

Starting Point	Formula
445 C	
<b>TC-021</b>	<b>50.39</b>
<b>TC-046</b>	<b>6.56</b>
<b>TC-316</b>	<b>25.13</b>
<b>TC-122</b>	<b>17.92</b>

Starting Point	Formula
446 C	
<b>TC-021</b>	<b>30.82</b>
<b>TC-046</b>	<b>10.53</b>
<b>TC-316</b>	<b>34.85</b>
<b>TC-122</b>	<b>23.80</b>

Starting Point	Formula
447 C	
<b>TC-316</b>	<b>40.10</b>
<b>TC-122</b>	<b>27.82</b>
<b>TC-021</b>	<b>19.57</b>
<b>TC-046</b>	<b>12.51</b>

Starting Point	Formula
WARM GRAY 1 C	
<b>TC-021</b>	<b>98.35</b>
<b>TC-001</b>	<b>0.67</b>
<b>TC-057</b>	<b>0.85</b>
<b>TC-122</b>	<b>0.13</b>

Starting Point	Formula
WARM GRAY 2 C	
<b>TC-021</b>	<b>97.40</b>
<b>TC-001</b>	<b>1.12</b>
<b>TC-057</b>	<b>1.27</b>
<b>TC-122</b>	<b>0.21</b>

Starting Point	Formula
WARM GRAY 3 C	
<b>TC-021</b>	<b>94.92</b>
<b>TC-001</b>	<b>1.69</b>
<b>TC-046</b>	<b>3.11</b>
<b>TC-153</b>	<b>0.28</b>

Starting Point	Formula
WARM GRAY 4 C	
<b>TC-021</b>	<b>93.38</b>
<b>TC-001</b>	<b>2.25</b>
<b>TC-046</b>	<b>3.95</b>
<b>TC-153</b>	<b>0.42</b>

Starting Point	Formula
WARM GRAY 5 C	
<b>TC-021</b>	<b>91.36</b>
<b>TC-001</b>	<b>2.89</b>
<b>TC-046</b>	<b>5.08</b>
<b>TC-153</b>	<b>0.67</b>

Starting Point	Formula
WARM GRAY 6 C	
<b>TC-021</b>	<b>90.00</b>
<b>TC-001</b>	<b>3.41</b>
<b>TC-046</b>	<b>5.62</b>
<b>TC-153</b>	<b>0.97</b>

# Texcharge TC

Starting Point WARM GRAY 7 C TC-021 85.25 TC-001 4.96 TC-046 8.45 TC-153 1.34	Formula	Starting Point WARM GRAY 8 C TC-021 80.41 TC-001 6.17 TC-046 11.48 TC-153 1.94	Formula	Starting Point WARM GRAY 9 C TC-021 75.33 TC-001 7.56 TC-046 14.21 TC-153 2.90	Formula	Starting Point WARM GRAY 10 C TC-021 69.45 TC-001 9.11 TC-046 17.87 TC-153 3.57	Formula
Starting Point WARM GRAY 11 C TC-021 61.51 TC-001 10.76 TC-046 23.25 TC-153 4.48	Formula	Starting Point COOL GRAY 1 C TC-021 97.30 TC-046 1.71 TC-153 0.51 TC-218 0.48	Formula	Starting Point COOL GRAY 2 C TC-021 95.54 TC-046 2.62 TC-153 0.99 TC-218 0.85	Formula	Starting Point COOL GRAY 3 C TC-021 94.25 TC-046 3.31 TC-153 1.33 TC-218 1.11	Formula
Starting Point COOL GRAY 4 C TC-021 91.20 TC-046 4.91 TC-153 2.12 TC-218 1.77	Formula	Starting Point COOL GRAY 5 C TC-021 88.85 TC-046 6.14 TC-153 2.74 TC-218 2.27	Formula	Starting Point COOL GRAY 6 C TC-021 87.57 TC-046 6.07 TC-122 2.04 TC-217 4.32	Formula	Starting Point COOL GRAY 7 C TC-021 79.71 TC-046 10.82 TC-153 5.25 TC-218 4.22	Formula
Starting Point COOL GRAY 8 C TC-021 72.87 TC-046 14.22 TC-153 7.18 TC-218 5.73	Formula	Starting Point COOL GRAY 9 C TC-021 59.94 TC-046 20.88 TC-153 10.67 TC-218 8.51	Formula	Starting Point COOL GRAY 10 C TC-021 47.58 TC-046 26.89 TC-153 14.13 TC-218 11.40	Formula	Starting Point COOL GRAY 11 C TC-021 75.79 TC-001 19.47 TC-316 2.74 TC-153 2.00	Formula

# Texcharge TC

Starting Point	Formula
448 C	
<b>TC-046</b>	<b>42.24</b>
<b>TC-057</b>	<b>17.78</b>
<b>TC-153</b>	<b>19.50</b>
<b>TC-217</b>	<b>20.48</b>

Starting Point	Formula
449 C	
<b>TC-057</b>	<b>41.33</b>
<b>TC-154</b>	<b>16.53</b>
<b>TC-218</b>	<b>12.61</b>
<b>TC-046</b>	<b>19.77</b>
<b>TC-153</b>	<b>9.76</b>

Starting Point	Formula
450 C	
<b>TC-057</b>	<b>59.34</b>
<b>TC-154</b>	<b>29.56</b>
<b>TC-218</b>	<b>10.25</b>
<b>TC-001</b>	<b>0.85</b>

Starting Point	Formula
451 C	
<b>TC-021</b>	<b>56.78</b>
<b>TC-057</b>	<b>31.03</b>
<b>TC-154</b>	<b>8.89</b>
<b>TC-218</b>	<b>3.30</b>

Starting Point	Formula
452 C	
<b>TC-021</b>	<b>74.92</b>
<b>TC-057</b>	<b>17.00</b>
<b>TC-154</b>	<b>5.93</b>
<b>TC-218</b>	<b>2.15</b>

Starting Point	Formula
453 C	
<b>TC-021</b>	<b>85.80</b>
<b>TC-057</b>	<b>9.20</b>
<b>TC-154</b>	<b>3.66</b>
<b>TC-218</b>	<b>1.34</b>

Starting Point	Formula
454 C	
<b>TC-021</b>	<b>90.15</b>
<b>TC-057</b>	<b>6.59</b>
<b>TC-154</b>	<b>2.36</b>
<b>TC-218</b>	<b>0.90</b>

Starting Point	Formula
4485 C	
<b>TC-057</b>	<b>59.15</b>
<b>TC-021</b>	<b>26.62</b>
<b>TC-001</b>	<b>9.90</b>
<b>TC-153</b>	<b>4.33</b>

Starting Point	Formula
4495 C	
<b>TC-057</b>	<b>57.56</b>
<b>TC-021</b>	<b>35.13</b>
<b>TC-001</b>	<b>4.48</b>
<b>TC-153</b>	<b>2.83</b>

Starting Point	Formula
4505 C	
<b>TC-057</b>	<b>46.83</b>
<b>TC-021</b>	<b>46.74</b>
<b>TC-001</b>	<b>3.77</b>
<b>TC-153</b>	<b>2.66</b>

Starting Point	Formula
4515 C	
<b>TC-021</b>	<b>76.98</b>
<b>TC-057</b>	<b>19.46</b>
<b>TC-001</b>	<b>1.99</b>
<b>TC-153</b>	<b>1.57</b>

Starting Point	Formula
4525 C	
<b>TC-021</b>	<b>85.72</b>
<b>TC-057</b>	<b>11.95</b>
<b>TC-001</b>	<b>1.25</b>
<b>TC-153</b>	<b>1.08</b>

Starting Point	Formula
4535 C	
<b>TC-021</b>	<b>90.18</b>
<b>TC-057</b>	<b>8.25</b>
<b>TC-001</b>	<b>0.88</b>
<b>TC-153</b>	<b>0.69</b>

Starting Point	Formula
4545 C	
<b>TC-021</b>	<b>92.08</b>
<b>TC-057</b>	<b>6.63</b>
<b>TC-001</b>	<b>0.69</b>
<b>TC-153</b>	<b>0.60</b>

Starting Point	Formula
455 C	
<b>TC-046</b>	<b>82.94</b>
<b>TC-218</b>	<b>9.57</b>
<b>TC-122</b>	<b>7.49</b>

Starting Point	Formula
456 C	
<b>TC-046</b>	<b>91.61</b>
<b>TC-217</b>	<b>5.90</b>
<b>TC-122</b>	<b>2.49</b>

# Texcharge TC

Starting Point	Formula
457 C	
<b>TC-046</b>	<b>94.76</b>
<b>TC-217</b>	<b>3.75</b>
<b>TC-122</b>	<b>1.49</b>

Starting Point	Formula
458 C	
<b>TC-021</b>	<b>68.65</b>
<b>TC-057</b>	<b>30.28</b>
<b>TC-122</b>	<b>0.47</b>
<b>TC-001</b>	<b>0.60</b>

Starting Point	Formula
459 C	
<b>TC-021</b>	<b>74.64</b>
<b>TC-057</b>	<b>24.42</b>
<b>TC-122</b>	<b>0.51</b>
<b>TC-001</b>	<b>0.43</b>

Starting Point	Formula
460 C	
<b>TC-021</b>	<b>85.38</b>
<b>TC-057</b>	<b>14.01</b>
<b>TC-122</b>	<b>0.40</b>
<b>TC-001</b>	<b>0.21</b>

Starting Point	Formula
461 C	
<b>TC-021</b>	<b>88.29</b>
<b>TC-057</b>	<b>2.94</b>
<b>TC-046</b>	<b>8.65</b>
<b>TC-001</b>	<b>0.12</b>

Starting Point	Formula
462 C	
<b>TC-046</b>	<b>51.23</b>
<b>TC-057</b>	<b>14.41</b>
<b>TC-153</b>	<b>18.80</b>
<b>TC-217</b>	<b>15.56</b>

Starting Point	Formula
463 C	
<b>TC-046</b>	<b>25.87</b>
<b>TC-057</b>	<b>39.79</b>
<b>TC-154</b>	<b>27.33</b>
<b>TC-218</b>	<b>7.01</b>

Starting Point	Formula
464 C	
<b>TC-046</b>	<b>46.71</b>
<b>TC-057</b>	<b>26.28</b>
<b>TC-154</b>	<b>20.48</b>
<b>TC-218</b>	<b>6.53</b>

Starting Point	Formula
465 C	
<b>TC-021</b>	<b>57.43</b>
<b>TC-057</b>	<b>32.28</b>
<b>TC-154</b>	<b>8.75</b>
<b>TC-218</b>	<b>1.54</b>

Starting Point	Formula
466 C	
<b>TC-021</b>	<b>72.96</b>
<b>TC-057</b>	<b>19.84</b>
<b>TC-154</b>	<b>6.13</b>
<b>TC-218</b>	<b>1.07</b>

Starting Point	Formula
467 C	
<b>TC-021</b>	<b>83.81</b>
<b>TC-057</b>	<b>11.79</b>
<b>TC-154</b>	<b>3.75</b>
<b>TC-218</b>	<b>0.65</b>

Starting Point	Formula
468 C	
<b>TC-021</b>	<b>90.09</b>
<b>TC-057</b>	<b>7.23</b>
<b>TC-154</b>	<b>2.33</b>
<b>TC-218</b>	<b>0.35</b>

Starting Point	Formula
4625 C	
<b>TC-046</b>	<b>77.18</b>
<b>TC-001</b>	<b>14.00</b>
<b>TC-154</b>	<b>8.82</b>

Starting Point	Formula
4635 C	
<b>TC-046</b>	<b>64.95</b>
<b>TC-021</b>	<b>24.72</b>
<b>TC-122</b>	<b>6.02</b>
<b>TC-001</b>	<b>4.31</b>

Starting Point	Formula
4645 C	
<b>TC-021</b>	<b>56.47</b>
<b>TC-046</b>	<b>36.28</b>
<b>TC-122</b>	<b>4.44</b>
<b>TC-001</b>	<b>2.81</b>

Starting Point	Formula
4655 C	
<b>TC-021</b>	<b>74.94</b>
<b>TC-046</b>	<b>20.30</b>
<b>TC-122</b>	<b>2.90</b>
<b>TC-001</b>	<b>1.86</b>



# Texcharge TC

Starting Point	Formula
4665 C	
<b>TC-021</b>	<b>82.58</b>
<b>TC-046</b>	<b>14.38</b>
<b>TC-001</b>	<b>1.23</b>
<b>TC-122</b>	<b>1.81</b>

Starting Point	Formula
4675 C	
<b>TC-021</b>	<b>91.68</b>
<b>TC-046</b>	<b>6.73</b>
<b>TC-122</b>	<b>0.95</b>
<b>TC-001</b>	<b>0.64</b>

Starting Point	Formula
4685 C	
<b>TC-021</b>	<b>92.77</b>
<b>TC-046</b>	<b>6.06</b>
<b>TC-001</b>	<b>0.45</b>
<b>TC-122</b>	<b>0.72</b>

Starting Point	Formula
469 C	
<b>TC-046</b>	<b>81.32</b>
<b>TC-122</b>	<b>8.17</b>
<b>TC-217</b>	<b>3.66</b>
<b>TC-001</b>	<b>6.85</b>

Starting Point	Formula
470 C	
<b>TC-046</b>	<b>82.86</b>
<b>TC-122</b>	<b>11.16</b>
<b>TC-217</b>	<b>5.98</b>

Starting Point	Formula
471 C	
<b>TC-046</b>	<b>86.17</b>
<b>TC-122</b>	<b>10.04</b>
<b>TC-217</b>	<b>3.79</b>

Starting Point	Formula
472 C	
<b>TC-021</b>	<b>67.67</b>
<b>TC-046</b>	<b>28.43</b>
<b>TC-122</b>	<b>3.41</b>
<b>TC-001</b>	<b>0.49</b>

Starting Point	Formula
473 C	
<b>TC-021</b>	<b>88.74</b>
<b>TC-046</b>	<b>9.66</b>
<b>TC-122</b>	<b>1.53</b>
<b>TC-001</b>	<b>0.07</b>

Starting Point	Formula
474 C	
<b>TC-021</b>	<b>91.17</b>
<b>TC-046</b>	<b>7.59</b>
<b>TC-122</b>	<b>1.24</b>

Starting Point	Formula
475 C	
<b>TC-021</b>	<b>93.08</b>
<b>TC-046</b>	<b>5.99</b>
<b>TC-122</b>	<b>0.93</b>

Starting Point	Formula
4695 C	
<b>TC-057</b>	<b>50.46</b>
<b>TC-154</b>	<b>24.11</b>
<b>TC-021</b>	<b>15.77</b>
<b>TC-001</b>	<b>9.66</b>

Starting Point	Formula
4705 C	
<b>TC-021</b>	<b>32.41</b>
<b>TC-057</b>	<b>39.37</b>
<b>TC-154</b>	<b>22.95</b>
<b>TC-001</b>	<b>5.27</b>

Starting Point	Formula
4715 C	
<b>TC-021</b>	<b>57.32</b>
<b>TC-057</b>	<b>24.43</b>
<b>TC-154</b>	<b>14.71</b>
<b>TC-001</b>	<b>3.54</b>

Starting Point	Formula
4725 C	
<b>TC-021</b>	<b>78.39</b>
<b>TC-057</b>	<b>11.45</b>
<b>TC-154</b>	<b>8.02</b>
<b>TC-001</b>	<b>2.14</b>

Starting Point	Formula
4735 C	
<b>TC-021</b>	<b>87.30</b>
<b>TC-057</b>	<b>6.89</b>
<b>TC-154</b>	<b>4.44</b>
<b>TC-001</b>	<b>1.37</b>

Starting Point	Formula
4745 C	
<b>TC-021</b>	<b>92.88</b>
<b>TC-057</b>	<b>3.71</b>
<b>TC-154</b>	<b>2.57</b>
<b>TC-001</b>	<b>0.84</b>

# Texcharge TC

Starting Point	Formula
4755 C	
<b>TC-021</b>	<b>95.58</b>
<b>TC-057</b>	<b>2.35</b>
<b>TC-154</b>	<b>1.55</b>
<b>TC-001</b>	<b>0.52</b>

Starting Point	Formula
476 C	
<b>TC-057</b>	<b>50.63</b>
<b>TC-153</b>	<b>34.29</b>
<b>TC-218</b>	<b>15.08</b>

Starting Point	Formula
477 C	
<b>TC-057</b>	<b>53.89</b>
<b>TC-153</b>	<b>22.35</b>
<b>TC-154</b>	<b>13.00</b>
<b>TC-218</b>	<b>10.76</b>

Starting Point	Formula
478 C	
<b>TC-057</b>	<b>53.86</b>
<b>TC-154</b>	<b>39.05</b>
<b>TC-218</b>	<b>7.09</b>

Starting Point	Formula
479 C	
<b>TC-021</b>	<b>57.15</b>
<b>TC-057</b>	<b>24.53</b>
<b>TC-154</b>	<b>15.08</b>
<b>TC-217</b>	<b>3.24</b>

Starting Point	Formula
480 C	
<b>TC-021</b>	<b>82.48</b>
<b>TC-057</b>	<b>10.00</b>
<b>TC-154</b>	<b>6.48</b>
<b>TC-218</b>	<b>1.04</b>

Starting Point	Formula
481 C	
<b>TC-021</b>	<b>89.78</b>
<b>TC-057</b>	<b>5.66</b>
<b>TC-154</b>	<b>3.92</b>
<b>TC-218</b>	<b>0.64</b>

Starting Point	Formula
482 C	
<b>TC-021</b>	<b>92.85</b>
<b>TC-057</b>	<b>4.15</b>
<b>TC-154</b>	<b>2.61</b>
<b>TC-218</b>	<b>0.39</b>

Starting Point	Formula
483 C	
<b>TC-046</b>	<b>66.85</b>
<b>TC-154</b>	<b>23.03</b>
<b>TC-001</b>	<b>10.12</b>

Starting Point	Formula
484 C	
<b>TC-046</b>	<b>66.49</b>
<b>TC-001</b>	<b>3.33</b>
<b>TC-154</b>	<b>30.18</b>

Starting Point	Formula
485 C	
<b>TC-046</b>	<b>66.69</b>
<b>TC-154</b>	<b>33.31</b>

Starting Point	Formula
486 C	
<b>TC-021</b>	<b>82.95</b>
<b>TC-057</b>	<b>9.59</b>
<b>TC-154</b>	<b>7.46</b>

Starting Point	Formula
487 C	
<b>TC-021</b>	<b>84.72</b>
<b>TC-057</b>	<b>8.31</b>
<b>TC-154</b>	<b>6.97</b>

Starting Point	Formula
488 C	
<b>TC-021</b>	<b>90.08</b>
<b>TC-057</b>	<b>5.42</b>
<b>TC-154</b>	<b>4.50</b>

Starting Point	Formula
489 C	
<b>TC-021</b>	<b>91.51</b>
<b>TC-057</b>	<b>4.86</b>
<b>TC-154</b>	<b>3.63</b>

Starting Point	Formula
490 C	
<b>TC-046</b>	<b>59.90</b>
<b>TC-154</b>	<b>27.95</b>
<b>TC-217</b>	<b>12.15</b>

# Texcharge TC

Starting Point	Formula
491 C	
<b>TC-046</b>	<b>61.23</b>
<b>TC-154</b>	<b>30.54</b>
<b>TC-217</b>	<b>8.23</b>

Starting Point	Formula
492 C	
<b>TC-046</b>	<b>61.71</b>
<b>TC-154</b>	<b>32.02</b>
<b>TC-217</b>	<b>6.27</b>

Starting Point	Formula
493 C	
<b>TC-021</b>	<b>90.95</b>
<b>TC-132</b>	<b>2.71</b>
<b>TC-122</b>	<b>4.37</b>
<b>TC-103</b>	<b>1.97</b>

Starting Point	Formula
494 C	
<b>TC-021</b>	<b>96.24</b>
<b>TC-122</b>	<b>3.44</b>
<b>TC-001</b>	<b>0.32</b>

Starting Point	Formula
495 C	
<b>TC-021</b>	<b>98.20</b>
<b>TC-122</b>	<b>1.80</b>

Starting Point	Formula
496 C	
<b>TC-021</b>	<b>98.31</b>
<b>TC-122</b>	<b>1.32</b>
<b>TC-046</b>	<b>0.37</b>

Starting Point	Formula
497 C	
<b>TC-046</b>	<b>58.91</b>
<b>TC-154</b>	<b>26.48</b>
<b>TC-217</b>	<b>14.61</b>

Starting Point	Formula
498 C	
<b>TC-046</b>	<b>61.38</b>
<b>TC-154</b>	<b>26.96</b>
<b>TC-217</b>	<b>11.66</b>

Starting Point	Formula
499 C	
<b>TC-021</b>	<b>59.17</b>
<b>TC-103</b>	<b>14.56</b>
<b>TC-122</b>	<b>16.77</b>
<b>TC-316</b>	<b>9.50</b>

Starting Point	Formula
500 C	
<b>TC-021</b>	<b>89.30</b>
<b>TC-122</b>	<b>7.53</b>
<b>TC-103</b>	<b>1.14</b>
<b>TC-316</b>	<b>2.03</b>

Starting Point	Formula
501 C	
<b>TC-021</b>	<b>95.06</b>
<b>TC-122</b>	<b>3.33</b>
<b>TC-103</b>	<b>0.64</b>
<b>TC-316</b>	<b>0.97</b>

Starting Point	Formula
502 C	
<b>TC-021</b>	<b>97.38</b>
<b>TC-103</b>	<b>0.48</b>
<b>TC-122</b>	<b>1.69</b>
<b>TC-316</b>	<b>0.45</b>

Starting Point	Formula
503 C	
<b>TC-021</b>	<b>97.91</b>
<b>TC-103</b>	<b>0.80</b>
<b>TC-122</b>	<b>0.96</b>
<b>TC-316</b>	<b>0.33</b>

Starting Point	Formula
4975 C	
<b>TC-021</b>	<b>54.86</b>
<b>TC-001</b>	<b>17.30</b>
<b>TC-057</b>	<b>14.25</b>
<b>TC-103</b>	<b>13.59</b>

Starting Point	Formula
4985 C	
<b>TC-021</b>	<b>65.02</b>
<b>TC-103</b>	<b>12.61</b>
<b>TC-122</b>	<b>12.51</b>
<b>TC-217</b>	<b>9.86</b>

Starting Point	Formula
4995 C	
<b>TC-021</b>	<b>75.03</b>
<b>TC-103</b>	<b>7.90</b>
<b>TC-122</b>	<b>9.88</b>
<b>TC-217</b>	<b>7.19</b>

# Texcharge TC

Starting Point	Formula
5005 C	
<b>TC-021</b>	<b>85.24</b>
<b>TC-103</b>	<b>5.40</b>
<b>TC-122</b>	<b>5.89</b>
<b>TC-218</b>	<b>3.47</b>

Starting Point	Formula
5015 C	
<b>TC-021</b>	<b>93.22</b>
<b>TC-103</b>	<b>2.73</b>
<b>TC-122</b>	<b>2.37</b>
<b>TC-218</b>	<b>1.68</b>

Starting Point	Formula
5025 C	
<b>TC-021</b>	<b>96.35</b>
<b>TC-103</b>	<b>1.42</b>
<b>TC-122</b>	<b>1.07</b>
<b>TC-217</b>	<b>1.16</b>

Starting Point	Formula
5035 C	
<b>TC-021</b>	<b>98.24</b>
<b>TC-001</b>	<b>0.54</b>
<b>TC-103</b>	<b>0.72</b>
<b>TC-122</b>	<b>0.50</b>

Starting Point	Formula
504 C	
<b>TC-046</b>	<b>55.72</b>
<b>TC-154</b>	<b>31.48</b>
<b>TC-217</b>	<b>12.80</b>

Starting Point	Formula
505 C	
<b>TC-046</b>	<b>55.20</b>
<b>TC-154</b>	<b>34.16</b>
<b>TC-217</b>	<b>10.64</b>

Starting Point	Formula
506 C	
<b>TC-046</b>	<b>52.25</b>
<b>TC-154</b>	<b>38.66</b>
<b>TC-217</b>	<b>9.09</b>

Starting Point	Formula
507 C	
<b>TC-021</b>	<b>92.85</b>
<b>TC-122</b>	<b>2.62</b>
<b>TC-103</b>	<b>1.30</b>
<b>TC-132</b>	<b>3.23</b>

Starting Point	Formula
508 C	
<b>TC-021</b>	<b>96.27</b>
<b>TC-122</b>	<b>3.23</b>
<b>TC-218</b>	<b>0.50</b>

Starting Point	Formula
509 C	
<b>TC-021</b>	<b>96.96</b>
<b>TC-122</b>	<b>2.55</b>
<b>TC-217</b>	<b>0.49</b>

Starting Point	Formula
510 C	
<b>TC-021</b>	<b>98.25</b>
<b>TC-122</b>	<b>1.58</b>
<b>TC-001</b>	<b>0.17</b>

Starting Point	Formula
511 C	
<b>TC-154</b>	<b>45.92</b>
<b>TC-046</b>	<b>39.57</b>
<b>TC-217</b>	<b>14.51</b>

Starting Point	Formula
512 C	
<b>TC-154</b>	<b>74.28</b>
<b>TC-046</b>	<b>16.92</b>
<b>TC-316</b>	<b>8.80</b>

Starting Point	Formula
513 C	
<b>TC154</b>	<b>93.17</b>
<b>TC-316</b>	<b>6.83</b>

Starting Point	Formula
514 C	
<b>TC-021</b>	<b>88.69</b>
<b>TC-154</b>	<b>10.91</b>
<b>TC-316</b>	<b>0.40</b>

Starting Point	Formula
515 C	
<b>TC-021</b>	<b>95.14</b>
<b>TC-154</b>	<b>4.86</b>

# Texcharge TC

Starting Point	Formula
516 C	
<b>TC-021</b>	<b>96.88</b>
<b>TC-154</b>	<b>3.00</b>
<b>TC-103</b>	<b>0.12</b>

Starting Point	Formula
517 C	
<b>TC-021</b>	<b>97.97</b>
<b>TC-154</b>	<b>1.65</b>
<b>TC-122</b>	<b>0.38</b>

Starting Point	Formula
5115 C	
<b>TC-046</b>	<b>46.12</b>
<b>TC-217</b>	<b>15.64</b>
<b>TC-154</b>	<b>38.24</b>

Starting Point	Formula
5125 C	
<b>TC-021</b>	<b>45.02</b>
<b>TC-057</b>	<b>11.95</b>
<b>TC-218</b>	<b>6.31</b>
<b>TC-154</b>	<b>36.72</b>

Starting Point	Formula
5135 C	
<b>TC-021</b>	<b>58.66</b>
<b>TC-057</b>	<b>9.03</b>
<b>TC-218</b>	<b>5.00</b>
<b>TC-154</b>	<b>27.31</b>

Starting Point	Formula
5145 C	
<b>TC-021</b>	<b>75.02</b>
<b>TC-057</b>	<b>6.01</b>
<b>TC-218</b>	<b>3.09</b>
<b>TC-154</b>	<b>15.88</b>

Starting Point	Formula
5155 C	
<b>TC-021</b>	<b>90.49</b>
<b>TC-057</b>	<b>2.46</b>
<b>TC-218</b>	<b>1.21</b>
<b>TC-154</b>	<b>5.84</b>

Starting Point	Formula
5165 C	
<b>TC-021</b>	<b>94.92</b>
<b>TC-057</b>	<b>1.46</b>
<b>TC-218</b>	<b>0.64</b>
<b>TC-154</b>	<b>2.98</b>

Starting Point	Formula
5175 C	
<b>TC-021</b>	<b>95.91</b>
<b>TC-057</b>	<b>1.37</b>
<b>TC-218</b>	<b>0.47</b>
<b>TC-154</b>	<b>2.25</b>

Starting Point	Formula
518 C	
<b>TC-139</b>	<b>62.14</b>
<b>TC-057</b>	<b>11.50</b>
<b>TC-218</b>	<b>10.61</b>
<b>TC-103</b>	<b>7.43</b>
<b>TC-132</b>	<b>8.32</b>

Starting Point	Formula
519 C	
<b>TC-139</b>	<b>57.07</b>
<b>TC-046</b>	<b>17.76</b>
<b>TC-153</b>	<b>11.38</b>
<b>TC-217</b>	<b>13.79</b>

Starting Point	Formula
520 C	
<b>TC-139</b>	<b>68.77</b>
<b>TC-046</b>	<b>11.59</b>
<b>TC-153</b>	<b>11.14</b>
<b>TC-218</b>	<b>8.50</b>

Starting Point	Formula
521 C	
<b>TC-021</b>	<b>82.47</b>
<b>TC-154</b>	<b>14.59</b>
<b>TC-316</b>	<b>2.94</b>

Starting Point	Formula
522 C	
<b>TC-021</b>	<b>89.97</b>
<b>TC-154</b>	<b>7.23</b>
<b>TC-057</b>	<b>1.25</b>
<b>TC-218</b>	<b>1.55</b>

Starting Point	Formula
523 C	
<b>TC-021</b>	<b>93.83</b>
<b>TC-057</b>	<b>0.78</b>
<b>TC-154</b>	<b>4.12</b>
<b>TC-217</b>	<b>1.07</b>
<b>TC-316</b>	<b>0.2</b>

Starting Point	Formula
524 C	
<b>TC-021</b>	<b>96.02</b>
<b>TC-154</b>	<b>2.53</b>
<b>TC-057</b>	<b>0.88</b>
<b>TC-218</b>	<b>0.57</b>

# Texcharge TC

Starting Point	Formula
5185 C	
<b>TC-021</b>	<b>48.23</b>
<b>TC-103</b>	<b>22.04</b>
<b>TC-153</b>	<b>14.91</b>
<b>TC-218</b>	<b>14.82</b>

Starting Point	Formula
5195 C	
<b>TC-021</b>	<b>57.61</b>
<b>TC-103</b>	<b>13.99</b>
<b>TC-154</b>	<b>15.49</b>
<b>TC-217</b>	<b>12.91</b>

Starting Point	Formula
5205 C	
<b>TC-021</b>	<b>90.49</b>
<b>TC-103</b>	<b>2.51</b>
<b>TC-153</b>	<b>3.44</b>
<b>TC-217</b>	<b>3.56</b>

Starting Point	Formula
5215 C	
<b>TC-021</b>	<b>90.46</b>
<b>TC-103</b>	<b>2.52</b>
<b>TC-153</b>	<b>3.45</b>
<b>TC-217</b>	<b>3.57</b>

Starting Point	Formula
5225 C	
<b>TC-021</b>	<b>96.71</b>
<b>TC-001</b>	<b>0.73</b>
<b>TC-103</b>	<b>0.79</b>
<b>TC-132</b>	<b>1.77</b>

Starting Point	Formula
5235 C	
<b>TC-021</b>	<b>97.81</b>
<b>TC-001</b>	<b>0.55</b>
<b>TC-103</b>	<b>0.51</b>
<b>TC-132</b>	<b>1.13</b>

Starting Point	Formula
5245 C	
<b>TC-021</b>	<b>98.75</b>
<b>TC-001</b>	<b>0.28</b>
<b>TC-103</b>	<b>0.35</b>
<b>TC-132</b>	<b>0.62</b>

Starting Point	Formula
525 C	
<b>TC-046</b>	<b>33.16</b>
<b>TC-217</b>	<b>18.29</b>
<b>TC-154</b>	<b>48.55</b>

Starting Point	Formula
526 C	
<b>TC-154</b>	<b>87.50</b>
<b>TC-316</b>	<b>12.50</b>

Starting Point	Formula
527 C	
<b>TC-021</b>	<b>62.30</b>
<b>TC-132</b>	<b>21.41</b>
<b>TC-154</b>	<b>16.29</b>

Starting Point	Formula
528 C	
<b>TC-021</b>	<b>88.10</b>
<b>TC-132</b>	<b>7.29</b>
<b>TC-154</b>	<b>4.61</b>

Starting Point	Formula
529 C	
<b>TC-021</b>	<b>94.23</b>
<b>TC-132</b>	<b>3.53</b>
<b>TC-154</b>	<b>2.24</b>

Starting Point	Formula
530 C	
<b>TC-021</b>	<b>96.76</b>
<b>TC-132</b>	<b>1.90</b>
<b>TC-154</b>	<b>1.34</b>

Starting Point	Formula
531 C	
<b>TC-021</b>	<b>98.12</b>
<b>TC-132</b>	<b>0.89</b>
<b>TC-154</b>	<b>0.99</b>

Starting Point	Formula
5255 C	
<b>TC-021</b>	<b>50.78</b>
<b>TC-132</b>	<b>19.93</b>
<b>TC-001</b>	<b>19.60</b>
<b>TC-153</b>	<b>9.69</b>

Starting Point	Formula
5265 C	
<b>TC-021</b>	<b>59.13</b>
<b>TC-153</b>	<b>22.69</b>
<b>TC-001</b>	<b>5.14</b>
<b>TC-218</b>	<b>13.04</b>

# Texcharge TC

Starting Point	Formula
5275 C	
<b>TC-021</b>	<b>73.65</b>
<b>TC-153</b>	<b>13.41</b>
<b>TC-001</b>	<b>4.21</b>
<b>TC-218</b>	<b>8.73</b>

Starting Point	Formula
5285 C	
<b>TC-021</b>	<b>90.59</b>
<b>TC-218</b>	<b>3.09</b>
<b>TC-001</b>	<b>1.89</b>
<b>TC-153</b>	<b>4.43</b>

Starting Point	Formula
5295 C	
<b>TC-021</b>	<b>97.03</b>
<b>TC-132</b>	<b>1.84</b>
<b>TC-001</b>	<b>1.13</b>

Starting Point	Formula
5305 C	
<b>TC-021</b>	<b>98.36</b>
<b>TC-132</b>	<b>0.97</b>
<b>TC-001</b>	<b>0.67</b>

Starting Point	Formula
5315 C	
<b>TC-021</b>	<b>99.38</b>
<b>TC-132</b>	<b>0.37</b>
<b>TC-001</b>	<b>0.25</b>

Starting Point	Formula
532 C	
<b>TC-001</b>	<b>30.46</b>
<b>TC-217</b>	<b>16.17</b>
<b>TC-154</b>	<b>53.37</b>

Starting Point	Formula
533 C	
<b>TC-217</b>	<b>75.65</b>
<b>TC-001</b>	<b>22.49</b>
<b>TC-132</b>	<b>1.86</b>

Starting Point	Formula
534 C	
<b>TC-021</b>	<b>56.51</b>
<b>TC-218</b>	<b>15.42</b>
<b>TC-154</b>	<b>18.50</b>
<b>TC-001</b>	<b>9.57</b>

Starting Point	Formula
535 C	
<b>TC-021</b>	<b>93.11</b>
<b>TC-001</b>	<b>1.34</b>
<b>TC-218</b>	<b>2.83</b>
<b>TC-154</b>	<b>2.72</b>

Starting Point	Formula
536 C	
<b>TC-021</b>	<b>95.91</b>
<b>TC-154</b>	<b>1.34</b>
<b>TC-218</b>	<b>1.79</b>
<b>TC-001</b>	<b>0.96</b>

Starting Point	Formula
537 C	
<b>TC-021</b>	<b>98.09</b>
<b>TC-218</b>	<b>1.08</b>
<b>TC-153</b>	<b>0.83</b>

Starting Point	Formula
538 C	
<b>TC-021</b>	<b>98.90</b>
<b>TC-218</b>	<b>0.71</b>
<b>TC-153</b>	<b>0.39</b>

Starting Point	Formula
539 C	
<b>TC-046</b>	<b>40.82</b>
<b>TC-217</b>	<b>26.05</b>
<b>TC-154</b>	<b>33.13</b>

Starting Point	Formula
540 C	
<b>TC-046</b>	<b>32.32</b>
<b>TC-217</b>	<b>32.60</b>
<b>TC-154</b>	<b>35.08</b>

Starting Point	Formula
541 C	
<b>TC-217</b>	<b>43.42</b>
<b>TC-154</b>	<b>32.24</b>
<b>TC-046</b>	<b>24.34</b>

Starting Point	Formula
542 C	
<b>TC021</b>	<b>93.32</b>
<b>TC-218</b>	<b>3.86</b>
<b>TC-154</b>	<b>2.32</b>
<b>TC-057</b>	<b>0.50</b>

# Texcharge TC

Starting Point	Formula
543 C	
<b>TC-021</b>	<b>96.74</b>
<b>TC-217</b>	<b>2.76</b>
<b>TC-153</b>	<b>0.50</b>

Starting Point	Formula
544 C	
<b>TC-021</b>	<b>98.47</b>
<b>TC-218</b>	<b>1.10</b>
<b>TC-154</b>	<b>0.43</b>

Starting Point	Formula
545 C	
<b>TC-021</b>	<b>99.01</b>
<b>TC-218</b>	<b>0.78</b>
<b>TC-154</b>	<b>0.21</b>

Starting Point	Formula
5395 C	
<b>TC-046</b>	<b>53.09</b>
<b>TC-217</b>	<b>10.38</b>
<b>TC-132</b>	<b>34.73</b>
<b>TC-001</b>	<b>1.80</b>

Starting Point	Formula
5405 C	
<b>TC-021</b>	<b>65.39</b>
<b>TC-046</b>	<b>13.15</b>
<b>TC-218</b>	<b>9.97</b>
<b>TC-154</b>	<b>11.49</b>

Starting Point	Formula
5415 C	
<b>TC-021</b>	<b>69.88</b>
<b>TC-046</b>	<b>11.15</b>
<b>TC-218</b>	<b>9.25</b>
<b>TC-154</b>	<b>9.72</b>

Starting Point	Formula
5425 C	
<b>TC-021</b>	<b>82.05</b>
<b>TC-046</b>	<b>6.85</b>
<b>TC-218</b>	<b>5.47</b>
<b>TC-154</b>	<b>5.63</b>

Starting Point	Formula
5435 C	
<b>TC-021</b>	<b>92.65</b>
<b>TC-046</b>	<b>2.85</b>
<b>TC-218</b>	<b>2.26</b>
<b>TC-154</b>	<b>2.24</b>

Starting Point	Formula
5445 C	
<b>TC-021</b>	<b>95.32</b>
<b>TC-046</b>	<b>1.84</b>
<b>TC-218</b>	<b>1.45</b>
<b>TC-154</b>	<b>1.39</b>

Starting Point	Formula
5455 C	
<b>TC-021</b>	<b>96.97</b>
<b>TC-057</b>	<b>0.88</b>
<b>TC-218</b>	<b>1.07</b>
<b>TC-154</b>	<b>1.08</b>

Starting Point	Formula
546 C	
<b>TC-046</b>	<b>56.75</b>
<b>TC-217</b>	<b>13.02</b>
<b>TC-132</b>	<b>30.23</b>

Starting Point	Formula
547 C	
<b>TC-046</b>	<b>45.50</b>
<b>TC-217</b>	<b>26.26</b>
<b>TC-154</b>	<b>28.24</b>

Starting Point	Formula
548 C	
<b>TC-046</b>	<b>43.00</b>
<b>TC-217</b>	<b>30.44</b>
<b>TC-154</b>	<b>26.56</b>

Starting Point	Formula
549 C	
<b>TC-021</b>	<b>91.37</b>
<b>TC-217</b>	<b>7.17</b>
<b>TC-001</b>	<b>1.46</b>

Starting Point	Formula
550 C	
<b>TC-021</b>	<b>95.26</b>
<b>TC-217</b>	<b>3.94</b>
<b>TC-001</b>	<b>0.80</b>

Starting Point	Formula
551 C	
<b>TC-021</b>	<b>95.25</b>
<b>TC-057</b>	<b>1.18</b>
<b>TC-218</b>	<b>2.23</b>
<b>TC-154</b>	<b>1.34</b>



# Texcharge TC

Starting Point	Formula
552 C	
<b>TC-021</b>	<b>97.40</b>
<b>TC-057</b>	<b>0.62</b>
<b>TC-218</b>	<b>1.28</b>
<b>TC-154</b>	<b>0.70</b>

Starting Point	Formula
5463 C	
<b>TC-046</b>	<b>54.67</b>
<b>TC-218</b>	<b>11.93</b>
<b>TC-132</b>	<b>33.40</b>

Starting Point	Formula
5473 C	
<b>TC-021</b>	<b>66.54</b>
<b>TC-218</b>	<b>18.25</b>
<b>TC-001</b>	<b>7.78</b>
<b>TC-046</b>	<b>7.43</b>

Starting Point	Formula
5483 C	
<b>TC-021</b>	<b>84.64</b>
<b>TC-218</b>	<b>7.98</b>
<b>TC-001</b>	<b>3.64</b>
<b>TC-046</b>	<b>3.74</b>

Starting Point	Formula
5493 C	
<b>TC-021</b>	<b>92.86</b>
<b>TC-218</b>	<b>3.52</b>
<b>TC-001</b>	<b>1.67</b>
<b>TC-046</b>	<b>1.95</b>

Starting Point	Formula
5503 C	
<b>TC-021</b>	<b>95.81</b>
<b>TC-001</b>	<b>1.16</b>
<b>TC-057</b>	<b>0.80</b>
<b>TC-218</b>	<b>2.23</b>

Starting Point	Formula
5513 C	
<b>TC-021</b>	<b>97.43</b>
<b>TC-001</b>	<b>0.67</b>
<b>TC-057</b>	<b>0.58</b>
<b>TC-218</b>	<b>1.32</b>

Starting Point	Formula
5523 C	
<b>TC-021</b>	<b>95.12</b>
<b>TC-046</b>	<b>2.80</b>
<b>TC-218</b>	<b>1.25</b>
<b>TC-132</b>	<b>0.83</b>

Starting Point	Formula
5467 C	
<b>TC-001</b>	<b>36.80</b>
<b>TC-057</b>	<b>25.31</b>
<b>TC-021</b>	<b>37.89</b>

Starting Point	Formula
5477 C	
<b>TC-021</b>	<b>58.04</b>
<b>TC-001</b>	<b>11.68</b>
<b>TC-057</b>	<b>12.77</b>
<b>TC-217</b>	<b>17.51</b>

Starting Point	Formula
5487 C	
<b>TC-021</b>	<b>76.43</b>
<b>TC-001</b>	<b>6.98</b>
<b>TC-057</b>	<b>6.66</b>
<b>TC-217</b>	<b>9.93</b>

Starting Point	Formula
5497 C	
<b>TC-021</b>	<b>89.18</b>
<b>TC-001</b>	<b>3.57</b>
<b>TC-057</b>	<b>2.83</b>
<b>TC-217</b>	<b>4.42</b>

Starting Point	Formula
5507 C	
<b>TC-021</b>	<b>94.93</b>
<b>TC-001</b>	<b>2.07</b>
<b>TC-057</b>	<b>1.41</b>
<b>TC-218</b>	<b>1.59</b>

Starting Point	Formula
5517 C	
<b>TC-021</b>	<b>96.25</b>
<b>TC-001</b>	<b>1.18</b>
<b>TC-057</b>	<b>1.06</b>
<b>TC-217</b>	<b>1.51</b>

Starting Point	Formula
5527 C	
<b>TC-021</b>	<b>97.18</b>
<b>TC-217</b>	<b>1.09</b>
<b>TC-001</b>	<b>0.83</b>
<b>TC-057</b>	<b>0.90</b>

Starting Point	Formula
553 C	
<b>TC-046</b>	<b>67.53</b>
<b>TC-217</b>	<b>20.02</b>
<b>TC-001</b>	<b>12.45</b>

# Texcharge TC

Starting Point	Formula
554 C	
<b>TC-046</b>	<b>66.51</b>
<b>TC-217</b>	<b>27.63</b>
<b>TC-001</b>	<b>5.86</b>

Starting Point	Formula
555 C	
<b>TC-046</b>	<b>68.14</b>
<b>TC-217</b>	<b>28.91</b>
<b>TC-001</b>	<b>2.95</b>

Starting Point	Formula
556 C	
<b>TC-021</b>	<b>80.62</b>
<b>TC-057</b>	<b>9.88</b>
<b>TC-217</b>	<b>7.75</b>
<b>TC-001</b>	<b>1.75</b>

Starting Point	Formula
557 C	
<b>TC-021</b>	<b>86.03</b>
<b>TC-057</b>	<b>6.85</b>
<b>TC-217</b>	<b>5.70</b>
<b>TC-001</b>	<b>1.42</b>

Starting Point	Formula
558 C	
<b>TC-021</b>	<b>91.56</b>
<b>TC-057</b>	<b>4.23</b>
<b>TC-217</b>	<b>3.34</b>
<b>TC-001</b>	<b>0.87</b>

Starting Point	Formula
559 C	
<b>TC-021</b>	<b>94.20</b>
<b>TC-057</b>	<b>3.00</b>
<b>TC-217</b>	<b>2.20</b>
<b>TC-001</b>	<b>0.60</b>

Starting Point	Formula
5535 C	
<b>TC-217</b>	<b>62.45</b>
<b>TC-103</b>	<b>20.25</b>
<b>TC-057</b>	<b>13.18</b>
<b>TC-001</b>	<b>4.12</b>

Starting Point	Formula
5545 C	
<b>TC-021</b>	<b>63.22</b>
<b>TC-316</b>	<b>20.16</b>
<b>TC-001</b>	<b>8.03</b>
<b>TC-057</b>	<b>4.63</b>
<b>TC-103</b>	<b>3.96</b>

Starting Point	Formula
5555 C	
<b>TC-021</b>	<b>74.80</b>
<b>TC-046</b>	<b>10.20</b>
<b>TC-316</b>	<b>8.73</b>
<b>TC-001</b>	<b>6.27</b>

Starting Point	Formula
5565 C	
<b>TC-021</b>	<b>87.87</b>
<b>TC-046</b>	<b>4.90</b>
<b>TC-001</b>	<b>3.32</b>
<b>TC-316</b>	<b>3.91</b>

Starting Point	Formula
5575 C	
<b>TC-021</b>	<b>91.37</b>
<b>TC-001</b>	<b>2.31</b>
<b>TC-046</b>	<b>3.69</b>
<b>TC-316</b>	<b>2.63</b>

Starting Point	Formula
5585 C	
<b>TC-021</b>	<b>94.08</b>
<b>TC-046</b>	<b>2.92</b>
<b>TC-316</b>	<b>1.59</b>
<b>TC-001</b>	<b>1.41</b>

Starting Point	Formula
5595 C	
<b>TC-021</b>	<b>95.80</b>
<b>TC-046</b>	<b>2.53</b>
<b>TC-001</b>	<b>0.82</b>
<b>TC-316</b>	<b>0.85</b>

Starting Point	Formula
560 C	
<b>TC-046</b>	<b>21.46</b>
<b>TC-217</b>	<b>44.49</b>
<b>TC-316</b>	<b>13.97</b>
<b>TC-122</b>	<b>5.78</b>
<b>TC-103</b>	<b>14.3</b>

Starting Point	Formula
561 C	
<b>TC-046</b>	<b>51.28</b>
<b>TC-217</b>	<b>44.14</b>
<b>TC-122</b>	<b>4.58</b>

Starting Point	Formula
562 C	
<b>TC-046</b>	<b>50.64</b>
<b>TC-217</b>	<b>49.36</b>

# Texcharge TC

Starting Point	Formula
563 C	
<b>TC-021</b>	<b>89.20</b>
<b>TC-316</b>	<b>9.30</b>
<b>TC-103</b>	<b>0.66</b>
<b>TC-122</b>	<b>0.84</b>

Starting Point	Formula
564 C	
<b>TC-021</b>	<b>93.28</b>
<b>TC-316</b>	<b>5.71</b>
<b>TC-103</b>	<b>0.63</b>
<b>TC-122</b>	<b>0.38</b>

Starting Point	Formula
565 C	
<b>TC-021</b>	<b>96.05</b>
<b>TC-316</b>	<b>3.23</b>
<b>TC-103</b>	<b>0.72</b>

Starting Point	Formula
566 C	
<b>TC-021</b>	<b>97.22</b>
<b>TC-316</b>	<b>1.99</b>
<b>TC-103</b>	<b>0.54</b>
<b>TC-057</b>	<b>0.25</b>

Starting Point	Formula
5605 C	
<b>TC-046</b>	<b>65.99</b>
<b>TC-001</b>	<b>17.75</b>
<b>TC-217</b>	<b>16.26</b>

Starting Point	Formula
5615 C	
<b>TC-021</b>	<b>69.76</b>
<b>TC-057</b>	<b>16.29</b>
<b>TC-001</b>	<b>7.49</b>
<b>TC-217</b>	<b>6.46</b>

Starting Point	Formula
5625 C	
<b>TC-021</b>	<b>79.81</b>
<b>TC-057</b>	<b>10.09</b>
<b>TC-001</b>	<b>5.26</b>
<b>TC-217</b>	<b>4.84</b>

Starting Point	Formula
5635 C	
<b>TC-021</b>	<b>90.86</b>
<b>TC-057</b>	<b>4.22</b>
<b>TC-001</b>	<b>2.55</b>
<b>TC-217</b>	<b>2.37</b>

Starting Point	Formula
5645 C	
<b>TC-021</b>	<b>93.70</b>
<b>TC-057</b>	<b>2.88</b>
<b>TC-001</b>	<b>1.78</b>
<b>TC-217</b>	<b>1.64</b>

Starting Point	Formula
5655 C	
<b>TC-021</b>	<b>95.18</b>
<b>TC-057</b>	<b>2.29</b>
<b>TC-217</b>	<b>1.22</b>
<b>TC-001</b>	<b>1.31</b>

Starting Point	Formula
5665 C	
<b>TC-021</b>	<b>96.28</b>
<b>TC-057</b>	<b>1.86</b>
<b>TC-001</b>	<b>0.93</b>
<b>TC-217</b>	<b>0.93</b>

Starting Point	Formula
567 C	
<b>TC-046</b>	<b>28.51</b>
<b>TC-217</b>	<b>55.17</b>
<b>TC-103</b>	<b>16.32</b>

Starting Point	Formula
568 C	
<b>TC-021</b>	<b>42.82</b>
<b>TC-316</b>	<b>37.95</b>
<b>TC-217</b>	<b>12.32</b>
<b>TC-103</b>	<b>6.91</b>

Starting Point	Formula
569 C	
<b>TC-021</b>	<b>49.78</b>
<b>TC-316</b>	<b>39.75</b>
<b>TC-218</b>	<b>7.18</b>
<b>TC-103</b>	<b>3.29</b>

Starting Point	Formula
570 C	
<b>TC-021</b>	<b>92.64</b>
<b>TC-316</b>	<b>6.76</b>
<b>TC-001</b>	<b>0.28</b>
<b>TC-103</b>	<b>0.32</b>

Starting Point	Formula
571 C	
<b>TC-021</b>	<b>96.26</b>
<b>TC-316</b>	<b>3.39</b>
<b>TC-057</b>	<b>0.11</b>
<b>TC-103</b>	<b>0.24</b>

# Texcharge TC

Starting Point	Formula
572 C	
<b>TC-021</b>	<b>97.03</b>
<b>TC-316</b>	<b>2.55</b>
<b>TC-057</b>	<b>0.29</b>
<b>TC-103</b>	<b>0.13</b>

Starting Point	Formula
573 C	
<b>TC-021</b>	<b>97.90</b>
<b>TC-316</b>	<b>1.64</b>
<b>TC-057</b>	<b>0.46</b>

Starting Point	Formula
574 C	
<b>TC-057</b>	<b>57.32</b>
<b>TC-021</b>	<b>27.43</b>
<b>TC-001</b>	<b>9.39</b>
<b>TC-217</b>	<b>5.86</b>

Starting Point	Formula
575 C	
<b>TC-057</b>	<b>50.82</b>
<b>TC-021</b>	<b>39.73</b>
<b>TC-217</b>	<b>5.56</b>
<b>TC-001</b>	<b>3.89</b>

Starting Point	Formula
576 C	
<b>TC-021</b>	<b>51.36</b>
<b>TC-057</b>	<b>41.42</b>
<b>TC-217</b>	<b>5.26</b>
<b>TC-001</b>	<b>1.96</b>

Starting Point	Formula
577 C	
<b>TC-021</b>	<b>82.42</b>
<b>TC-057</b>	<b>14.66</b>
<b>TC-217</b>	<b>2.13</b>
<b>TC-001</b>	<b>0.79</b>

Starting Point	Formula
578 C	
<b>TC-021</b>	<b>89.54</b>
<b>TC-057</b>	<b>8.49</b>
<b>TC-217</b>	<b>1.39</b>
<b>TC-001</b>	<b>0.58</b>

Starting Point	Formula
579 C	
<b>TC-021</b>	<b>91.74</b>
<b>TC-057</b>	<b>6.95</b>
<b>TC-218</b>	<b>0.75</b>
<b>TC-001</b>	<b>0.56</b>

Starting Point	Formula
580 C	
<b>TC-021</b>	<b>93.21</b>
<b>TC-057</b>	<b>5.74</b>
<b>TC-218</b>	<b>0.64</b>
<b>TC-001</b>	<b>0.41</b>

Starting Point	Formula
5743 C	
<b>TC-046</b>	<b>78.03</b>
<b>TC-001</b>	<b>11.46</b>
<b>TC-217</b>	<b>10.51</b>

Starting Point	Formula
5753 C	
<b>TC-057</b>	<b>53.36</b>
<b>TC-021</b>	<b>35.33</b>
<b>TC-001</b>	<b>9.01</b>
<b>TC-218</b>	<b>2.30</b>

Starting Point	Formula
5763 C	
<b>TC-021</b>	<b>55.19</b>
<b>TC-057</b>	<b>36.22</b>
<b>TC-001</b>	<b>6.45</b>
<b>TC-217</b>	<b>2.14</b>

Starting Point	Formula
5773 C	
<b>TC-021</b>	<b>56.62</b>
<b>TC-046</b>	<b>36.76</b>
<b>TC-001</b>	<b>3.42</b>
<b>TC-217</b>	<b>3.20</b>

Starting Point	Formula
5783 C	
<b>TC-021</b>	<b>86.05</b>
<b>TC-057</b>	<b>10.79</b>
<b>TC-001</b>	<b>2.69</b>
<b>TC-218</b>	<b>0.47</b>

Starting Point	Formula
5793 C	
<b>TC-021</b>	<b>91.08</b>
<b>TC-057</b>	<b>6.82</b>
<b>TC-001</b>	<b>1.70</b>
<b>TC-217</b>	<b>0.40</b>

Starting Point	Formula
5803 C	
<b>TC-021</b>	<b>88.99</b>
<b>TC-046</b>	<b>9.33</b>
<b>TC-001</b>	<b>0.85</b>
<b>TC-217</b>	<b>0.83</b>

# Texcharge TC

Starting Point	Formula
5747 C	
<b>TC-046</b>	<b>71.50</b>
<b>TC-001</b>	<b>12.15</b>
<b>TC-217</b>	<b>10.54</b>
<b>TC-057</b>	<b>5.81</b>

Starting Point	Formula
5757 C	
<b>TC-057</b>	<b>42.13</b>
<b>TC-046</b>	<b>27.46</b>
<b>TC-021</b>	<b>20.98</b>
<b>TC-001</b>	<b>5.93</b>
<b>TC-217</b>	<b>3.5</b>

Starting Point	Formula
5767 C	
<b>TC-021</b>	<b>46.66</b>
<b>TC-057</b>	<b>27.49</b>
<b>TC-046</b>	<b>19.89</b>
<b>TC-001</b>	<b>3.90</b>
<b>TC-217</b>	<b>2.06</b>

Starting Point	Formula
5777 C	
<b>TC-021</b>	<b>71.79</b>
<b>TC-057</b>	<b>15.24</b>
<b>TC-046</b>	<b>9.73</b>
<b>TC-001</b>	<b>2.62</b>
<b>TC-218</b>	<b>0.62</b>

Starting Point	Formula
5787 C	
<b>TC-021</b>	<b>88.38</b>
<b>TC-057</b>	<b>9.89</b>
<b>TC-001</b>	<b>1.58</b>
<b>TC-218</b>	<b>0.15</b>

Starting Point	Formula
5797 C	
<b>TC-021</b>	<b>91.68</b>
<b>TC-057</b>	<b>7.13</b>
<b>TC-001</b>	<b>1.19</b>

Starting Point	Formula
5807 C	
<b>TC-021</b>	<b>94.41</b>
<b>TC-057</b>	<b>4.78</b>
<b>TC-001</b>	<b>0.81</b>

Starting Point	Formula
581 C	
<b>TC-046</b>	<b>89.20</b>
<b>TC-001</b>	<b>7.86</b>
<b>TC-218</b>	<b>2.94</b>

Starting Point	Formula
582 C	
<b>TC-046</b>	<b>90.15</b>
<b>TC-217</b>	<b>4.09</b>
<b>TC-057</b>	<b>3.86</b>
<b>TC-001</b>	<b>1.90</b>

Starting Point	Formula
583 C	
<b>TC-057</b>	<b>64.99</b>
<b>TC-021</b>	<b>33.48</b>
<b>TC-001</b>	<b>0.79</b>
<b>TC-218</b>	<b>0.74</b>

Starting Point	Formula
584 C	
<b>TC-021</b>	<b>67.14</b>
<b>TC-057</b>	<b>32.17</b>
<b>TC-218</b>	<b>0.35</b>
<b>TC-001</b>	<b>0.34</b>

Starting Point	Formula
585 C	
<b>TC-021</b>	<b>77.98</b>
<b>TC-057</b>	<b>13.94</b>
<b>TC-046</b>	<b>7.47</b>
<b>TC-217</b>	<b>0.61</b>

Starting Point	Formula
586 C	
<b>TC-021</b>	<b>80.33</b>
<b>TC-057</b>	<b>12.25</b>
<b>TC-046</b>	<b>6.96</b>
<b>TC-217</b>	<b>0.46</b>

Starting Point	Formula
587 C	
<b>TC-021</b>	<b>87.61</b>
<b>TC-057</b>	<b>12.21</b>
<b>TC-001</b>	<b>0.18</b>

Starting Point	Formula
5815 C	
<b>TC-046</b>	<b>83.61</b>
<b>TC-001</b>	<b>10.52</b>
<b>TC-217</b>	<b>5.87</b>

Starting Point	Formula
5825 C	
<b>TC-021</b>	<b>41.65</b>
<b>TC-057</b>	<b>39.10</b>
<b>TC-046</b>	<b>14.09</b>
<b>TC-001</b>	<b>5.16</b>

# Texcharge TC

Starting Point	Formula
5835 C	
<b>TC-021</b>	<b>63.13</b>
<b>TC-057</b>	<b>18.29</b>
<b>TC-046</b>	<b>15.20</b>
<b>TC-001</b>	<b>3.38</b>

Starting Point	Formula
5845 C	
<b>TC-021</b>	<b>76.75</b>
<b>TC-057</b>	<b>10.80</b>
<b>TC-046</b>	<b>10.08</b>
<b>TC-001</b>	<b>2.37</b>

Starting Point	Formula
5855 C	
<b>TC-021</b>	<b>85.73</b>
<b>TC-057</b>	<b>5.45</b>
<b>TC-046</b>	<b>7.32</b>
<b>TC-001</b>	<b>1.50</b>

Starting Point	Formula
5865 C	
<b>TC-021</b>	<b>88.69</b>
<b>TC-057</b>	<b>5.01</b>
<b>TC-046</b>	<b>5.28</b>
<b>TC-001</b>	<b>1.02</b>

Starting Point	Formula
5875 C	
<b>TC-021</b>	<b>91.26</b>
<b>TC-057</b>	<b>3.11</b>
<b>TC-046</b>	<b>4.88</b>
<b>TC-001</b>	<b>0.75</b>

Starting Point	Formula
600 C	
<b>TC-021</b>	<b>88.48</b>
<b>TC-046</b>	<b>5.87</b>
<b>TC-057</b>	<b>5.65</b>

Starting Point	Formula
601 C	
<b>TC-021</b>	<b>86.27</b>
<b>TC-057</b>	<b>7.26</b>
<b>TC-046</b>	<b>6.47</b>

Starting Point	Formula
602 C	
<b>TC-021</b>	<b>80.15</b>
<b>TC-057</b>	<b>12.27</b>
<b>TC-046</b>	<b>7.58</b>

Starting Point	Formula
603 C	
<b>TC-021</b>	<b>61.88</b>
<b>TC-057</b>	<b>26.94</b>
<b>TC-046</b>	<b>11.18</b>

Starting Point	Formula
604 C	
<b>TC-021</b>	<b>43.44</b>
<b>TC-057</b>	<b>46.14</b>
<b>TC-046</b>	<b>10.30</b>
<b>TC-001</b>	<b>0.12</b>

Starting Point	Formula
605 C	
<b>TC-057</b>	<b>65.14</b>
<b>TC-021</b>	<b>20.40</b>
<b>TC-046</b>	<b>14.07</b>
<b>TC-001</b>	<b>0.39</b>

Starting Point	Formula
606 C	
<b>TC-057</b>	<b>59.99</b>
<b>TC-046</b>	<b>38.91</b>
<b>TC-001</b>	<b>1.10</b>

Starting Point	Formula
607 C	
<b>TC-021</b>	<b>87.72</b>
<b>TC-046</b>	<b>7.67</b>
<b>TC-057</b>	<b>4.56</b>
<b>TC-001</b>	<b>0.05</b>

Starting Point	Formula
608 C	
<b>TC-021</b>	<b>83.33</b>
<b>TC-046</b>	<b>8.47</b>
<b>TC-057</b>	<b>8.07</b>
<b>TC-001</b>	<b>0.13</b>

Starting Point	Formula
609 C	
<b>TC-021</b>	<b>79.41</b>
<b>TC-057</b>	<b>11.21</b>
<b>TC-046</b>	<b>9.19</b>
<b>TC-001</b>	<b>0.19</b>

Starting Point	Formula
610 C	
<b>TC-021</b>	<b>65.83</b>
<b>TC-057</b>	<b>22.67</b>
<b>TC-064</b>	<b>11.12</b>
<b>TC-001</b>	<b>0.38</b>

# Texcharge TC

Starting Point	Formula
611 C	
<b>TC-021</b>	<b>40.48</b>
<b>TC-057</b>	<b>45.31</b>
<b>TC-046</b>	<b>13.48</b>
<b>TC-001</b>	<b>0.73</b>

Starting Point	Formula
612 C	
<b>TC-057</b>	<b>66.62</b>
<b>TC-046</b>	<b>20.30</b>
<b>TC-021</b>	<b>11.78</b>
<b>TC-001</b>	<b>1.30</b>

Starting Point	Formula
613 C	
<b>TC-057</b>	<b>53.34</b>
<b>TC-046</b>	<b>37.87</b>
<b>TC-021</b>	<b>6.55</b>
<b>TC-001</b>	<b>2.24</b>

Starting Point	Formula
614 C	
<b>TC-021</b>	<b>89.38</b>
<b>TC-046</b>	<b>7.05</b>
<b>TC-057</b>	<b>3.11</b>
<b>TC-001</b>	<b>0.46</b>

Starting Point	Formula
615 C	
<b>TC-021</b>	<b>85.62</b>
<b>TC-046</b>	<b>9.65</b>
<b>TC-057</b>	<b>4.03</b>
<b>TC-001</b>	<b>0.70</b>

Starting Point	Formula
616 C	
<b>TC-021</b>	<b>83.72</b>
<b>TC-046</b>	<b>9.83</b>
<b>TC-057</b>	<b>5.57</b>
<b>TC-001</b>	<b>0.88</b>

Starting Point	Formula
617 C	
<b>TC-021</b>	<b>68.44</b>
<b>TC-046</b>	<b>17.04</b>
<b>TC-057</b>	<b>12.95</b>
<b>TC-001</b>	<b>1.57</b>

Starting Point	Formula
618 C	
<b>TC-046</b>	<b>21.83</b>
<b>TC-057</b>	<b>30.01</b>
<b>TC-021</b>	<b>45.63</b>
<b>TC-001</b>	<b>2.53</b>

Starting Point	Formula
619 C	
<b>TC-057</b>	<b>44.40</b>
<b>TC-021</b>	<b>27.97</b>
<b>TC-046</b>	<b>24.21</b>
<b>TC-001</b>	<b>3.42</b>

Starting Point	Formula
620 C	
<b>TC-057</b>	<b>48.55</b>
<b>TC-021</b>	<b>19.63</b>
<b>TC-046</b>	<b>26.73</b>
<b>TC-001</b>	<b>5.09</b>

Starting Point	Formula
621 C	
<b>TC-021</b>	<b>97.93</b>
<b>TC-046</b>	<b>1.31</b>
<b>TC-001</b>	<b>0.15</b>
<b>TC-316</b>	<b>0.61</b>

Starting Point	Formula
622 C	
<b>TC-021</b>	<b>97.42</b>
<b>TC-001</b>	<b>0.77</b>
<b>TC-057</b>	<b>0.82</b>
<b>TC-316</b>	<b>0.99</b>

Starting Point	Formula
623 C	
<b>TC-021</b>	<b>93.77</b>
<b>TC-001</b>	<b>1.50</b>
<b>TC-046</b>	<b>2.41</b>
<b>TC-316</b>	<b>2.32</b>

Starting Point	Formula
624 C	
<b>TC-021</b>	<b>87.10</b>
<b>TC-001</b>	<b>3.09</b>
<b>TC-046</b>	<b>4.79</b>
<b>TC-316</b>	<b>5.02</b>

Starting Point	Formula
625 C	
<b>TC-021</b>	<b>71.87</b>
<b>TC-001</b>	<b>5.91</b>
<b>TC-046</b>	<b>10.02</b>
<b>TC-316</b>	<b>12.20</b>

Starting Point	Formula
626 C	
<b>TC-021</b>	<b>40.51</b>
<b>TC-001</b>	<b>11.08</b>
<b>TC-046</b>	<b>15.80</b>
<b>TC-316</b>	<b>32.61</b>

# Texcharge TC

Starting Point	Formula
627 C	
<b>TC-001</b>	<b>17.88</b>
<b>TC-046</b>	<b>30.16</b>
<b>TC-217</b>	<b>37.98</b>
<b>TC-316</b>	<b>13.98</b>

Starting Point	Formula
628 C	
<b>TC-021</b>	<b>97.97</b>
<b>TC-218</b>	<b>1.28</b>
<b>TC-057</b>	<b>0.75</b>

Starting Point	Formula
629 C	
<b>TC-021</b>	<b>96.88</b>
<b>TC-218</b>	<b>2.28</b>
<b>TC-057</b>	<b>0.72</b>
<b>TC-001</b>	<b>0.12</b>

Starting Point	Formula
630 C	
<b>TC-021</b>	<b>92.70</b>
<b>TC-217</b>	<b>5.89</b>
<b>TC-057</b>	<b>1.41</b>

Starting Point	Formula
631 C	
<b>TC-021</b>	<b>89.09</b>
<b>TC-218</b>	<b>8.10</b>
<b>TC-046</b>	<b>2.35</b>
<b>TC-001</b>	<b>0.46</b>

Starting Point	Formula
632 C	
<b>TC-021</b>	<b>70.03</b>
<b>TC-217</b>	<b>26.04</b>
<b>TC-057</b>	<b>3.93</b>

Starting Point	Formula
633 C	
<b>TC-021</b>	<b>45.00</b>
<b>TC-217</b>	<b>43.73</b>
<b>TC-046</b>	<b>11.27</b>

Starting Point	Formula
634 C	
<b>TC-021</b>	<b>47.69</b>
<b>TC-218</b>	<b>38.44</b>
<b>TC-057</b>	<b>6.11</b>
<b>TC-153</b>	<b>7.76</b>

Starting Point	Formula
635 C	
<b>TC-021</b>	<b>97.81</b>
<b>TC-218</b>	<b>1.49</b>
<b>TC-316</b>	<b>0.70</b>

Starting Point	Formula
636 C	
<b>TC-021</b>	<b>96.58</b>
<b>TC-218</b>	<b>2.73</b>
<b>TC-316</b>	<b>0.69</b>

Starting Point	Formula
637 C	
<b>TC-021</b>	<b>92.66</b>
<b>TC-218</b>	<b>6.69</b>
<b>TC-316</b>	<b>0.65</b>

Starting Point	Formula
638 C	
<b>TC-021</b>	<b>85.56</b>
<b>TC-218</b>	<b>13.52</b>
<b>TC-057</b>	<b>0.92</b>

Starting Point	Formula
639 C	
<b>TC-021</b>	<b>71.25</b>
<b>TC-218</b>	<b>27.33</b>
<b>TC-057</b>	<b>1.42</b>

Starting Point	Formula
640 C	
<b>TC-021</b>	<b>58.92</b>
<b>TC-218</b>	<b>37.96</b>
<b>TC-001</b>	<b>0.28</b>
<b>TC-046</b>	<b>2.84</b>

Starting Point	Formula
641 C	
<b>TC-021</b>	<b>45.68</b>
<b>TC-218</b>	<b>44.53</b>
<b>TC-154</b>	<b>6.11</b>
<b>TC-057</b>	<b>3.68</b>

Starting Point	Formula
642 C	
<b>TC-021</b>	<b>98.73</b>
<b>TC-057</b>	<b>0.17</b>
<b>TC-218</b>	<b>0.71</b>
<b>TC-154</b>	<b>0.39</b>



# Texcharge TC

Starting Point	Formula
643 C	
<b>TC-021</b>	<b>97.73</b>
<b>TC-057</b>	<b>0.27</b>
<b>TC-218</b>	<b>1.12</b>
<b>TC-154</b>	<b>0.88</b>

Starting Point	Formula
644 C	
<b>TC-021</b>	<b>93.13</b>
<b>TC-057</b>	<b>1.00</b>
<b>TC-218</b>	<b>3.01</b>
<b>TC-154</b>	<b>2.86</b>

Starting Point	Formula
645 C	
<b>TC-021</b>	<b>87.24</b>
<b>TC-057</b>	<b>1.77</b>
<b>TC-218</b>	<b>5.60</b>
<b>TC-154</b>	<b>5.39</b>

Starting Point	Formula
646 C	
<b>TC-021</b>	<b>78.55</b>
<b>TC-057</b>	<b>2.67</b>
<b>TC-218</b>	<b>9.58</b>
<b>TC-154</b>	<b>9.20</b>

Starting Point	Formula
647 C	
<b>TC-021</b>	<b>55.35</b>
<b>TC-057</b>	<b>5.06</b>
<b>TC-218</b>	<b>19.33</b>
<b>TC-154</b>	<b>20.26</b>

Starting Point	Formula
648 C	
<b>TC-046</b>	<b>29.24</b>
<b>TC-217</b>	<b>33.02</b>
<b>TC-154</b>	<b>37.74</b>

Starting Point	Formula
649 C	
<b>TC-021</b>	<b>99.33</b>
<b>TC-218</b>	<b>0.45</b>
<b>TC-154</b>	<b>0.22</b>

Starting Point	Formula
650 C	
<b>TC-021</b>	<b>98.12</b>
<b>TC-057</b>	<b>0.20</b>
<b>TC-218</b>	<b>0.91</b>
<b>TC-154</b>	<b>0.77</b>

Starting Point	Formula
651 C	
<b>TC-021</b>	<b>93.88</b>
<b>TC-057</b>	<b>0.88</b>
<b>TC-218</b>	<b>2.48</b>
<b>TC-154</b>	<b>2.76</b>

Starting Point	Formula
652 C	
<b>TC-021</b>	<b>86.33</b>
<b>TC-057</b>	<b>1.87</b>
<b>TC-218</b>	<b>5.53</b>
<b>TC-154</b>	<b>6.27</b>

Starting Point	Formula
653 C	
<b>TC-021</b>	<b>60.43</b>
<b>TC-057</b>	<b>4.77</b>
<b>TC-218</b>	<b>16.63</b>
<b>TC-154</b>	<b>18.17</b>

Starting Point	Formula
654 C	
<b>TC-021</b>	<b>33.01</b>
<b>TC-057</b>	<b>8.52</b>
<b>TC-218</b>	<b>23.04</b>
<b>TC-154</b>	<b>35.43</b>

Starting Point	Formula
655 C	
<b>TC-154</b>	<b>41.10</b>
<b>TC-021</b>	<b>12.54</b>
<b>TC-046</b>	<b>25.71</b>
<b>TC-218</b>	<b>20.65</b>

Starting Point	Formula
656 C	
<b>TC-021</b>	<b>99.43</b>
<b>TC-218</b>	<b>0.40</b>
<b>TC-132</b>	<b>0.17</b>

Starting Point	Formula
657 C	
<b>TC-021</b>	<b>98.40</b>
<b>TC-218</b>	<b>0.89</b>
<b>TC-132</b>	<b>0.71</b>

Starting Point	Formula
658 C	
<b>TC-021</b>	<b>97.00</b>
<b>TC-218</b>	<b>1.60</b>
<b>TC-132</b>	<b>1.40</b>

# Texcharge TC

Starting Point	Formula
659 C	
<b>TC-021</b>	<b>90.38</b>
<b>TC-218</b>	<b>5.54</b>
<b>TC-154</b>	<b>4.08</b>

Starting Point	Formula
660 C	
<b>TC-021</b>	<b>76.04</b>
<b>TC-218</b>	<b>14.51</b>
<b>TC-154</b>	<b>9.45</b>

Starting Point	Formula
661 C	
<b>TC-217</b>	<b>84.24</b>
<b>TC-153</b>	<b>15.76</b>

Starting Point	Formula
662 C	
<b>TC-217</b>	<b>41.94</b>
<b>TC-154</b>	<b>42.48</b>
<b>TC-046</b>	<b>15.58</b>

Starting Point	Formula
663 C	
<b>TC-021</b>	<b>99.71</b>
<b>TC-153</b>	<b>0.29</b>

Starting Point	Formula
664 C	
<b>TC-021</b>	<b>99.43</b>
<b>TC-132</b>	<b>0.41</b>
<b>TC-001</b>	<b>0.16</b>

Starting Point	Formula
665 C	
<b>TC-021</b>	<b>97.51</b>
<b>TC-132</b>	<b>1.78</b>
<b>TC-001</b>	<b>0.71</b>

Starting Point	Formula
666 C	
<b>TC-021</b>	<b>92.65</b>
<b>TC-132</b>	<b>5.40</b>
<b>TC-001</b>	<b>1.95</b>

Starting Point	Formula
667 C	
<b>TC-021</b>	<b>83.20</b>
<b>TC-132</b>	<b>12.95</b>
<b>TC-001</b>	<b>3.85</b>

Starting Point	Formula
668 C	
<b>TC-021</b>	<b>71.62</b>
<b>TC-132</b>	<b>19.93</b>
<b>TC-153</b>	<b>3.11</b>
<b>TC-001</b>	<b>5.34</b>

Starting Point	Formula
669 C	
<b>TC-021</b>	<b>52.65</b>
<b>TC-132</b>	<b>29.83</b>
<b>TC-153</b>	<b>7.98</b>
<b>TC-001</b>	<b>9.54</b>

Starting Point	Formula
670 C	
<b>TC-021</b>	<b>97.98</b>
<b>TC-154</b>	<b>1.66</b>
<b>TC-057</b>	<b>0.36</b>

Starting Point	Formula
671 C	
<b>TC-021</b>	<b>97.08</b>
<b>TC-153</b>	<b>2.26</b>
<b>TC-132</b>	<b>0.66</b>

Starting Point	Formula
672 C	
<b>TC-021</b>	<b>90.74</b>
<b>TC-154</b>	<b>7.95</b>
<b>TC-057</b>	<b>1.05</b>
<b>TC-218</b>	<b>0.26</b>

Starting Point	Formula
673 C	
<b>TC-021</b>	<b>85.17</b>
<b>TC-154</b>	<b>13.24</b>
<b>TC-057</b>	<b>1.23</b>
<b>TC-218</b>	<b>0.36</b>

Starting Point	Formula
674 C	
<b>TC-021</b>	<b>67.12</b>
<b>TC-154</b>	<b>29.82</b>
<b>TC-057</b>	<b>2.17</b>
<b>TC-217</b>	<b>0.89</b>

# Texcharge TC

Starting Point	Formula
675 C	
<b>TC-154</b>	<b>77.75</b>
<b>TC-046</b>	<b>17.79</b>
<b>TC-217</b>	<b>4.46</b>

Starting Point	Formula
676 C	
<b>TC-154</b>	<b>64.47</b>
<b>TC-046</b>	<b>30.18</b>
<b>TC-217</b>	<b>5.35</b>

Starting Point	Formula
677 C	
<b>TC-021</b>	<b>97.17</b>
<b>TC-046</b>	<b>1.04</b>
<b>TC-154</b>	<b>1.67</b>
<b>TC-218</b>	<b>0.12</b>

Starting Point	Formula
678 C	
<b>TC-021</b>	<b>96.87</b>
<b>TC-057</b>	<b>0.66</b>
<b>TC-154</b>	<b>2.29</b>
<b>TC-218</b>	<b>0.18</b>

Starting Point	Formula
679 C	
<b>TC-021</b>	<b>95.73</b>
<b>TC-154</b>	<b>3.21</b>
<b>TC-057</b>	<b>0.77</b>
<b>TC-218</b>	<b>0.29</b>

Starting Point	Formula
680 C	
<b>TC-021</b>	<b>88.59</b>
<b>TC-154</b>	<b>8.50</b>
<b>TC-057</b>	<b>2.06</b>
<b>TC-218</b>	<b>0.85</b>

Starting Point	Formula
681 C	
<b>TC-021</b>	<b>74.18</b>
<b>TC-154</b>	<b>19.84</b>
<b>TC-057</b>	<b>4.28</b>
<b>TC-218</b>	<b>1.70</b>

Starting Point	Formula
682 C	
<b>TC-021</b>	<b>58.30</b>
<b>TC-154</b>	<b>31.77</b>
<b>TC-057</b>	<b>6.53</b>
<b>TC-218</b>	<b>3.40</b>

Starting Point	Formula
683 C	
<b>TC-154</b>	<b>43.08</b>
<b>TC-021</b>	<b>28.90</b>
<b>TC-046</b>	<b>22.04</b>
<b>TC-217</b>	<b>5.98</b>

Starting Point	Formula
684 C	
<b>TC-021</b>	<b>98.74</b>
<b>TC-153</b>	<b>0.68</b>
<b>TC-001</b>	<b>0.21</b>
<b>TC-122</b>	<b>0.37</b>

Starting Point	Formula
685 C	
<b>TC-021</b>	<b>97.56</b>
<b>TC-153</b>	<b>2.05</b>
<b>TC-001</b>	<b>0.39</b>

Starting Point	Formula
686 C	
<b>TC-021</b>	<b>95.89</b>
<b>TC-001</b>	<b>0.55</b>
<b>TC-122</b>	<b>1.96</b>
<b>TC-132</b>	<b>1.60</b>

Starting Point	Formula
687 C	
<b>TC-021</b>	<b>87.18</b>
<b>TC-046</b>	<b>3.78</b>
<b>TC-122</b>	<b>2.94</b>
<b>TC-132</b>	<b>6.10</b>

Starting Point	Formula
688 C	
<b>TC-021</b>	<b>84.35</b>
<b>TC-001</b>	<b>1.03</b>
<b>TC-122</b>	<b>7.48</b>
<b>TC-132</b>	<b>7.14</b>

Starting Point	Formula
689 C	
<b>TC-021</b>	<b>66.67</b>
<b>TC-122</b>	<b>19.13</b>
<b>TC-132</b>	<b>10.58</b>
<b>TC-217</b>	<b>3.62</b>

Starting Point	Formula
690 C	
<b>TC-021</b>	<b>42.98</b>
<b>TC-103</b>	<b>21.25</b>
<b>TC-154</b>	<b>23.43</b>
<b>TC-217</b>	<b>12.34</b>

# Texcharge TC

Starting Point	Formula
691 C	
<b>TC-021</b>	<b>95.60</b>
<b>TC-046</b>	<b>2.41</b>
<b>TC-154</b>	<b>1.99</b>

Starting Point	Formula
692 C	
<b>TC-021</b>	<b>95.85</b>
<b>TC-057</b>	<b>1.64</b>
<b>TC-122</b>	<b>1.16</b>
<b>TC-132</b>	<b>1.35</b>

Starting Point	Formula
693 C	
<b>TC-021</b>	<b>92.16</b>
<b>TC-057</b>	<b>2.85</b>
<b>TC-122</b>	<b>2.15</b>
<b>TC-132</b>	<b>2.84</b>

Starting Point	Formula
694 C	
<b>TC-021</b>	<b>85.20</b>
<b>TC-057</b>	<b>3.93</b>
<b>TC-122</b>	<b>4.87</b>
<b>TC-154</b>	<b>3.87</b>
<b>TC-217</b>	<b>2.13</b>

Starting Point	Formula
695 C	
<b>TC-021</b>	<b>86.56</b>
<b>TC-001</b>	<b>2.56</b>
<b>TC-122</b>	<b>10.22</b>
<b>TC-153</b>	<b>0.66</b>

Starting Point	Formula
696 C	
<b>TC-021</b>	<b>73.40</b>
<b>TC-122</b>	<b>22.12</b>
<b>TC-001</b>	<b>4.48</b>

Starting Point	Formula
697 C	
<b>TC-021</b>	<b>65.77</b>
<b>TC-122</b>	<b>22.66</b>
<b>TC-001</b>	<b>5.76</b>
<b>TC-103</b>	<b>5.81</b>

Starting Point	Formula
698 C	
<b>TC-021</b>	<b>98.71</b>
<b>TC-057</b>	<b>0.51</b>
<b>TC-122</b>	<b>0.78</b>

Starting Point	Formula
699 C	
<b>TC-021</b>	<b>98.20</b>
<b>TC-057</b>	<b>0.25</b>
<b>TC-122</b>	<b>1.55</b>

Starting Point	Formula
700 C	
<b>TC-021</b>	<b>95.18</b>
<b>TC-057</b>	<b>1.08</b>
<b>TC-122</b>	<b>2.20</b>
<b>TC-154</b>	<b>1.54</b>

Starting Point	Formula
701 C	
<b>TC-021</b>	<b>92.10</b>
<b>TC-122</b>	<b>6.38</b>
<b>TC-153</b>	<b>1.04</b>
<b>TC-001</b>	<b>0.48</b>

Starting Point	Formula
702 C	
<b>TC-021</b>	<b>79.75</b>
<b>TC-122</b>	<b>15.58</b>
<b>TC-154</b>	<b>3.72</b>
<b>TC-001</b>	<b>0.95</b>

Starting Point	Formula
703 C	
<b>TC-021</b>	<b>64.96</b>
<b>TC-122</b>	<b>28.60</b>
<b>TC-153</b>	<b>4.58</b>
<b>TC-001</b>	<b>1.86</b>

Starting Point	Formula
704 C	
<b>TC-046</b>	<b>52.57</b>
<b>TC-154</b>	<b>44.62</b>
<b>TC-001</b>	<b>2.81</b>

Starting Point	Formula
705 C	
<b>TC-021</b>	<b>99.23</b>
<b>TC-057</b>	<b>0.19</b>
<b>TC-122</b>	<b>0.58</b>

Starting Point	Formula
706 C	
<b>TC-021</b>	<b>98.81</b>
<b>TC-057</b>	<b>0.13</b>
<b>TC-122</b>	<b>1.06</b>

# Texcharge TC

Starting Point	Formula
707 C	
<b>TC-021</b>	<b>97.53</b>
<b>TC-122</b>	<b>2.47</b>

Starting Point	Formula
708 C	
<b>TC-021</b>	<b>93.42</b>
<b>TC-122</b>	<b>5.81</b>
<b>TC-153</b>	<b>0.77</b>

Starting Point	Formula
709 C	
<b>TC-021</b>	<b>81.36</b>
<b>TC-122</b>	<b>14.76</b>
<b>TC-154</b>	<b>3.88</b>

Starting Point	Formula
710 C	
<b>TC-021</b>	<b>65.65</b>
<b>TC-122</b>	<b>30.75</b>
<b>TC-154</b>	<b>3.25</b>
<b>TC001</b>	<b>0.35</b>

Starting Point	Formula
711 C	
<b>TC-046</b>	<b>58.25</b>
<b>TC-154</b>	<b>41.75</b>

Starting Point	Formula
712 C	
<b>TC-021</b>	<b>91.32</b>
<b>TC-046</b>	<b>6.19</b>
<b>TC-103</b>	<b>2.49</b>

Starting Point	Formula
713 C	
<b>TC-021</b>	<b>87.99</b>
<b>TC-046</b>	<b>8.48</b>
<b>TC-103</b>	<b>3.53</b>

Starting Point	Formula
714 C	
<b>TC-021</b>	<b>78.52</b>
<b>TC-046</b>	<b>15.04</b>
<b>TC-103</b>	<b>6.34</b>
<b>TC-001</b>	<b>0.10</b>

Starting Point	Formula
715 C	
<b>TC-021</b>	<b>56.19</b>
<b>TC-046</b>	<b>30.37</b>
<b>TC-103</b>	<b>13.09</b>
<b>TC-001</b>	<b>0.35</b>

Starting Point	Formula
716 C	
<b>TC-021</b>	<b>41.65</b>
<b>TC-046</b>	<b>37.21</b>
<b>TC-103</b>	<b>20.48</b>
<b>TC-001</b>	<b>0.66</b>

Starting Point	Formula
717 C	
<b>TC-046</b>	<b>87.10</b>
<b>TC-001</b>	<b>0.84</b>
<b>TC-153</b>	<b>12.06</b>

Starting Point	Formula
718 C	
<b>TC-046</b>	<b>84.80</b>
<b>TC-001</b>	<b>1.32</b>
<b>TC-153</b>	<b>13.88</b>

Starting Point	Formula
719 C	
<b>TC-021</b>	<b>95.65</b>
<b>TC-001</b>	<b>0.18</b>
<b>TC-057</b>	<b>2.28</b>
<b>TC-103</b>	<b>1.89</b>

Starting Point	Formula
720 C	
<b>TC-021</b>	<b>91.20</b>
<b>TC-057</b>	<b>4.70</b>
<b>TC-103</b>	<b>3.60</b>
<b>TC-001</b>	<b>0.50</b>

Starting Point	Formula
721 C	
<b>TC-021</b>	<b>77.58</b>
<b>TC-146</b>	<b>16.21</b>
<b>TC-103</b>	<b>5.31</b>
<b>TC-001</b>	<b>0.90</b>

Starting Point	Formula
722 C	
<b>TC-021</b>	<b>44.83</b>
<b>TC-046</b>	<b>41.22</b>
<b>TC-103</b>	<b>12.07</b>
<b>TC-001</b>	<b>1.88</b>

# Texcharge TC

Starting Point	Formula
723 C	
<b>TC-046</b>	<b>62.44</b>
<b>TC-021</b>	<b>15.38</b>
<b>TC-103</b>	<b>19.09</b>
<b>TC-001</b>	<b>3.09</b>

Starting Point	Formula
724 C	
<b>TC-057</b>	<b>46.53</b>
<b>TC-021</b>	<b>14.52</b>
<b>TC-103</b>	<b>33.35</b>
<b>TC-001</b>	<b>5.60</b>

Starting Point	Formula
725 C	
<b>TC-046</b>	<b>69.11</b>
<b>TC-103</b>	<b>21.49</b>
<b>TC-001</b>	<b>9.40</b>

Starting Point	Formula
726 C	
<b>TC-021</b>	<b>94.15</b>
<b>TC-057</b>	<b>3.11</b>
<b>TC-103</b>	<b>2.12</b>
<b>TC-001</b>	<b>0.62</b>

Starting Point	Formula
727 C	
<b>TC-021</b>	<b>87.43</b>
<b>TC-046</b>	<b>8.86</b>
<b>TC-103</b>	<b>2.73</b>
<b>TC-001</b>	<b>0.98</b>

Starting Point	Formula
728 C	
<b>TC-021</b>	<b>79.60</b>
<b>TC-046</b>	<b>14.28</b>
<b>TC-103</b>	<b>4.62</b>
<b>TC-001</b>	<b>1.50</b>

Starting Point	Formula
729 C	
<b>TC-021</b>	<b>56.89</b>
<b>TC-046</b>	<b>30.47</b>
<b>TC-103</b>	<b>9.82</b>
<b>TC-001</b>	<b>2.82</b>

Starting Point	Formula
730 C	
<b>TC-046</b>	<b>54.71</b>
<b>TC-021</b>	<b>26.18</b>
<b>TC-103</b>	<b>14.89</b>
<b>TC-001</b>	<b>4.22</b>

Starting Point	Formula
731 C	
<b>TC-046</b>	<b>42.59</b>
<b>TC-057</b>	<b>20.37</b>
<b>TC-103</b>	<b>27.80</b>
<b>TC-001</b>	<b>9.24</b>

Starting Point	Formula
732 C	
<b>TC-057</b>	<b>54.66</b>
<b>TC-103</b>	<b>24.57</b>
<b>TC-001</b>	<b>12.23</b>
<b>TC-021</b>	<b>8.54</b>

Starting Point	Formula
7401 C	
<b>TC-046</b>	<b>10.43</b>
<b>TC-021</b>	<b>89.40</b>
<b>TC-122</b>	<b>0.17</b>

Starting Point	Formula
7402 C	
<b>TC-057</b>	<b>7.37</b>
<b>TC-021</b>	<b>92.01</b>
<b>TC-122</b>	<b>0.62</b>

Starting Point	Formula
7403 C	
<b>TC-057</b>	<b>12.27</b>
<b>TC-021</b>	<b>86.47</b>
<b>TC-153</b>	<b>1.26</b>

Starting Point	Formula
7404 C	
<b>TC-057</b>	<b>31.63</b>
<b>TC-021</b>	<b>67.42</b>
<b>TC-103</b>	<b>0.95</b>

Starting Point	Formula
7405 C	
<b>TC-046</b>	<b>32.78</b>
<b>TC-021</b>	<b>42.49</b>
<b>TC-057</b>	<b>24.37</b>
<b>TC-153</b>	<b>0.36</b>

Starting Point	Formula
7406 C	
<b>TC-046</b>	<b>36.75</b>
<b>TC-057</b>	<b>26.20</b>
<b>TC-021</b>	<b>36.21</b>
<b>TC-153</b>	<b>0.84</b>

# Texcharge TC

Starting Point	Formula
7407 C	
<b>TC-046</b>	<b>41.92</b>
<b>TC-021</b>	<b>54.89</b>
<b>TC-001</b>	<b>1.07</b>
<b>TC-153</b>	<b>2.12</b>

Starting Point	Formula
7408 C	
<b>TC-046</b>	<b>99.01</b>
<b>TC-001</b>	<b>0.99</b>

Starting Point	Formula
7409 C	
<b>TC-046</b>	<b>98.32</b>
<b>TC-001</b>	<b>1.68</b>

Starting Point	Formula
7410 C	
<b>TC-046</b>	<b>10.43</b>
<b>TC-103</b>	<b>5.58</b>
<b>TC-153</b>	<b>0.54</b>
<b>TC-021</b>	<b>83.45</b>

Starting Point	Formula
7411 C	
<b>TC-001</b>	<b>0.20</b>
<b>TC-057</b>	<b>23.01</b>
<b>TC-153</b>	<b>4.64</b>
<b>TC-021</b>	<b>72.15</b>

Starting Point	Formula
7412 C	
<b>TC-001</b>	<b>1.39</b>
<b>TC-046</b>	<b>33.08</b>
<b>TC-103</b>	<b>12.30</b>
<b>TC-021</b>	<b>53.23</b>

Starting Point	Formula
7413 C	
<b>TC-001</b>	<b>0.43</b>
<b>TC-057</b>	<b>40.55</b>
<b>TC-153</b>	<b>7.76</b>
<b>TC-021</b>	<b>51.26</b>

Starting Point	Formula
7414 C	
<b>TC-001</b>	<b>2.16</b>
<b>TC-046</b>	<b>42.86</b>
<b>TC-103</b>	<b>17.05</b>
<b>TC-021</b>	<b>37.93</b>

Starting Point	Formula
7415 C	
<b>TC-021</b>	<b>91.25</b>
<b>TC-057</b>	<b>4.84</b>
<b>TC-154</b>	<b>3.91</b>

Starting Point	Formula
7416 C	
<b>TC-021</b>	<b>65.72</b>
<b>TC-057</b>	<b>19.35</b>
<b>TC-153</b>	<b>14.93</b>

Starting Point	Formula
7417 C	
<b>TC-046</b>	<b>66.80</b>
<b>TC-154</b>	<b>33.20</b>

Starting Point	Formula
7418 C	
<b>TC-021</b>	<b>74.95</b>
<b>TC-122</b>	<b>19.75</b>
<b>TC-001</b>	<b>1.16</b>
<b>TC-057</b>	<b>4.14</b>

Starting Point	Formula
7419 C	
<b>TC-021</b>	<b>76.86</b>
<b>TC-122</b>	<b>19.16</b>
<b>TC-001</b>	<b>2.52</b>
<b>TC-103</b>	<b>1.46</b>

Starting Point	Formula
7420 C	
<b>TC-021</b>	<b>47.88</b>
<b>TC-154</b>	<b>35.31</b>
<b>TC-103</b>	<b>14.44</b>
<b>TC-001</b>	<b>2.37</b>

Starting Point	Formula
7421 C	
<b>TC-154</b>	<b>51.05</b>
<b>TC-046</b>	<b>40.30</b>
<b>TC-001</b>	<b>8.65</b>

Starting Point	Formula
7422 C	
<b>TC-021</b>	<b>98.49</b>
<b>TC-122</b>	<b>1.08</b>
<b>TC-057</b>	<b>0.43</b>

# Texcharge TC

Starting Point	Formula
7423 C	
<b>TC-021</b>	<b>81.33</b>
<b>TC-122</b>	<b>9.95</b>
<b>TC-154</b>	<b>7.36</b>
<b>TC-132</b>	<b>1.36</b>

Starting Point	Formula
7424 C	
<b>TC-021</b>	<b>71.85</b>
<b>TC-154</b>	<b>20.01</b>
<b>TC-122</b>	<b>8.14</b>

Starting Point	Formula
7425 C	
<b>TC-021</b>	<b>58.44</b>
<b>TC-122</b>	<b>17.67</b>
<b>TC-153</b>	<b>17.19</b>
<b>TC-132</b>	<b>6.70</b>

Starting Point	Formula
7426 C	
<b>TC-046</b>	<b>47.40</b>
<b>TC-154</b>	<b>42.53</b>
<b>TC-132</b>	<b>10.07</b>

Starting Point	Formula
7427 C	
<b>TC-046</b>	<b>59.84</b>
<b>TC-154</b>	<b>27.92</b>
<b>TC-132</b>	<b>12.24</b>

Starting Point	Formula
7428 C	
<b>TC-046</b>	<b>60.46</b>
<b>TC-132</b>	<b>39.54</b>

Starting Point	Formula
7429 C	
<b>TC-021</b>	<b>95.02</b>
<b>TC-057</b>	<b>1.29</b>
<b>TC-154</b>	<b>3.52</b>
<b>TC-218</b>	<b>0.17</b>

Starting Point	Formula
7430 C	
<b>TC-021</b>	<b>91.71</b>
<b>TC-057</b>	<b>1.92</b>
<b>TC-154</b>	<b>6.03</b>
<b>TC-218</b>	<b>0.34</b>

Starting Point	Formula
7431 C	
<b>TC-021</b>	<b>80.25</b>
<b>TC-154</b>	<b>14.70</b>
<b>TC-057</b>	<b>4.25</b>
<b>TC-218</b>	<b>0.80</b>

Starting Point	Formula
7432 C	
<b>TC-021</b>	<b>65.66</b>
<b>TC-154</b>	<b>25.66</b>
<b>TC-057</b>	<b>6.92</b>
<b>TC-217</b>	<b>1.76</b>

Starting Point	Formula
7433 C	
<b>TC-021</b>	<b>46.69</b>
<b>TC-154</b>	<b>40.50</b>
<b>TC-057</b>	<b>10.58</b>
<b>TC-217</b>	<b>2.23</b>

Starting Point	Formula
7434 C	
<b>TC-021</b>	<b>41.88</b>
<b>TC-154</b>	<b>42.18</b>
<b>TC-057</b>	<b>12.95</b>
<b>TC-217</b>	<b>2.99</b>

Starting Point	Formula
7435 C	
<b>TC-154</b>	<b>48.00</b>
<b>TC-021</b>	<b>33.88</b>
<b>TC-057</b>	<b>13.64</b>
<b>TC-217</b>	<b>4.48</b>

Starting Point	Formula
7436 C	
<b>TC-021</b>	<b>99.03</b>
<b>TC-154</b>	<b>0.97</b>

Starting Point	Formula
7437 C	
<b>TC-021</b>	<b>93.30</b>
<b>TC-154</b>	<b>4.86</b>
<b>TC-057</b>	<b>0.93</b>
<b>TC-218</b>	<b>0.91</b>

Starting Point	Formula
7438 C	
<b>TC-021</b>	<b>93.18</b>
<b>TC-154</b>	<b>4.38</b>
<b>TC-132</b>	<b>2.44</b>



# Texcharge TC

Starting Point	Formula
7439 C	
<b>TC-021</b>	<b>86.57</b>
<b>TC-154</b>	<b>11.36</b>
<b>TC-316</b>	<b>2.07</b>

Starting Point	Formula
7440 C	
<b>TC-021</b>	<b>85.29</b>
<b>TC-153</b>	<b>11.39</b>
<b>TC-218</b>	<b>3.32</b>

Starting Point	Formula
7441 C	
<b>TC-021</b>	<b>77.07</b>
<b>TC-132</b>	<b>14.01</b>
<b>TC-154</b>	<b>8.92</b>

Starting Point	Formula
7442 C	
<b>TC-021</b>	<b>65.43</b>
<b>TC-132</b>	<b>34.57</b>

Starting Point	Formula
7443 C	
<b>TC-021</b>	<b>99.07</b>
<b>TC-154</b>	<b>0.62</b>
<b>TC-218</b>	<b>0.31</b>

Starting Point	Formula
7444 C	
<b>TC-021</b>	<b>95.80</b>
<b>TC-154</b>	<b>2.51</b>
<b>TC-218</b>	<b>1.48</b>
<b>TC-001</b>	<b>0.21</b>

Starting Point	Formula
7445 C	
<b>TC-021</b>	<b>94.36</b>
<b>TC-218</b>	<b>2.14</b>
<b>TC-153</b>	<b>3.07</b>
<b>TC-001</b>	<b>0.43</b>

Starting Point	Formula
7446 C	
<b>TC-021</b>	<b>86.71</b>
<b>TC-154</b>	<b>8.92</b>
<b>TC-218</b>	<b>4.37</b>

Starting Point	Formula
7447 C	
<b>TC-021</b>	<b>72.66</b>
<b>TC-132</b>	<b>21.47</b>
<b>TC-001</b>	<b>5.87</b>

Starting Point	Formula
7448 C	
<b>TC-021</b>	<b>69.52</b>
<b>TC-001</b>	<b>13.48</b>
<b>TC-132</b>	<b>7.04</b>
<b>TC-153</b>	<b>9.96</b>

Starting Point	Formula
7449 C	
<b>TC-021</b>	<b>63.86</b>
<b>TC-001</b>	<b>14.42</b>
<b>TC-153</b>	<b>21.72</b>

Starting Point	Formula
7450 C	
<b>TC-021</b>	<b>96.84</b>
<b>TC-046</b>	<b>0.56</b>
<b>TC-218</b>	<b>1.36</b>
<b>TC-153</b>	<b>1.24</b>

Starting Point	Formula
7451 C	
<b>TC-021</b>	<b>91.63</b>
<b>TC-217</b>	<b>5.65</b>
<b>TC-154</b>	<b>2.72</b>

Starting Point	Formula
7452 C	
<b>TC-021</b>	<b>88.96</b>
<b>TC-217</b>	<b>5.35</b>
<b>TC-132</b>	<b>5.69</b>

Starting Point	Formula
7453 C	
<b>TC-021</b>	<b>91.05</b>
<b>TC-218</b>	<b>5.20</b>
<b>TC-154</b>	<b>3.75</b>

Starting Point	Formula
7454 C	
<b>TC-021</b>	<b>82.14</b>
<b>TC-057</b>	<b>2.65</b>
<b>TC-218</b>	<b>8.03</b>
<b>TC-154</b>	<b>7.18</b>

# Texcharge TC

Starting Point	Formula
7455 C	
<b>TC-021</b>	<b>65.37</b>
<b>TC-057</b>	<b>0.72</b>
<b>TC-218</b>	<b>16.00</b>
<b>TC-154</b>	<b>17.91</b>

Starting Point	Formula
7456 C	
<b>TC-021</b>	<b>77.66</b>
<b>TC-001</b>	<b>0.86</b>
<b>TC-218</b>	<b>9.14</b>
<b>TC-154</b>	<b>12.34</b>

Starting Point	Formula
7457 C	
<b>TC-021</b>	<b>98.10</b>
<b>TC-218</b>	<b>1.26</b>
<b>TC-046</b>	<b>0.64</b>

Starting Point	Formula
7458 C	
<b>TC-021</b>	<b>89.54</b>
<b>TC-218</b>	<b>5.37</b>
<b>TC-154</b>	<b>2.03</b>
<b>TC-046</b>	<b>3.06</b>

Starting Point	Formula
7459 C	
<b>TC-021</b>	<b>82.11</b>
<b>TC-218</b>	<b>10.82</b>
<b>TC-154</b>	<b>2.77</b>
<b>TC-046</b>	<b>4.30</b>

Starting Point	Formula
7460 C	
<b>TC-021</b>	<b>56.48</b>
<b>TC-218</b>	<b>39.18</b>
<b>TC-318</b>	<b>4.34</b>

Starting Point	Formula
7461 C	
<b>TC-021</b>	<b>69.85</b>
<b>TC-154</b>	<b>5.81</b>
<b>TC-218</b>	<b>22.60</b>
<b>TC-057</b>	<b>1.74</b>

Starting Point	Formula
7462 C	
<b>TC-021</b>	<b>52.77</b>
<b>TC-218</b>	<b>24.03</b>
<b>TC-154</b>	<b>18.58</b>
<b>TC-057</b>	<b>4.62</b>

Starting Point	Formula
7463 C	
<b>TC-218</b>	<b>19.28</b>
<b>TC-154</b>	<b>35.90</b>
<b>TC-021</b>	<b>13.77</b>
<b>TC-046</b>	<b>31.05</b>

Starting Point	Formula
7464 C	
<b>TC-021</b>	<b>96.26</b>
<b>TC-057</b>	<b>1.65</b>
<b>TC-218</b>	<b>1.88</b>
<b>TC-001</b>	<b>0.21</b>

Starting Point	Formula
7465 C	
<b>TC-021</b>	<b>88.71</b>
<b>TC-218</b>	<b>6.37</b>
<b>TC-057</b>	<b>4.92</b>

Starting Point	Formula
7466 C	
<b>TC-021</b>	<b>80.24</b>
<b>TC-316</b>	<b>9.83</b>
<b>TC-218</b>	<b>9.93</b>

Starting Point	Formula
7467 C	
<b>TC-021</b>	<b>72.35</b>
<b>TC-316</b>	<b>13.23</b>
<b>TC-218</b>	<b>14.42</b>

Starting Point	Formula
7468 C	
<b>TC-021</b>	<b>76.12</b>
<b>TC-218</b>	<b>20.21</b>
<b>TC-001</b>	<b>2.86</b>
<b>TC-132</b>	<b>0.81</b>

Starting Point	Formula
7469 C	
<b>TC-021</b>	<b>66.25</b>
<b>TC-218</b>	<b>27.76</b>
<b>TC-001</b>	<b>3.86</b>
<b>TC-132</b>	<b>2.13</b>

Starting Point	Formula
7470 C	
<b>TC-021</b>	<b>68.77</b>
<b>TC-218</b>	<b>24.00</b>
<b>TC-001</b>	<b>7.23</b>

# Texcharge TC

Starting Point	Formula
7471 C	
<b>TC-021</b>	<b>95.79</b>
<b>TC-316</b>	<b>3.93</b>
<b>TC-218</b>	<b>0.28</b>

Starting Point	Formula
7472 C	
<b>TC-021</b>	<b>84.94</b>
<b>TC-046</b>	<b>7.95</b>
<b>TC-218</b>	<b>6.51</b>
<b>TC-132</b>	<b>0.60</b>

Starting Point	Formula
7473 C	
<b>TC-021</b>	<b>66.32</b>
<b>TC-046</b>	<b>17.16</b>
<b>TC-217</b>	<b>16.52</b>

Starting Point	Formula
7474 C	
<b>TC-021</b>	<b>63.06</b>
<b>TC-218</b>	<b>23.34</b>
<b>TC-046</b>	<b>11.17</b>
<b>TC-001</b>	<b>2.43</b>

Starting Point	Formula
7475 C	
<b>TC-021</b>	<b>78.46</b>
<b>TC-218</b>	<b>9.02</b>
<b>TC-001</b>	<b>4.69</b>
<b>TC-046</b>	<b>7.83</b>

Starting Point	Formula
7476 C	
<b>TC-021</b>	<b>62.16</b>
<b>TC-218</b>	<b>18.29</b>
<b>TC-001</b>	<b>10.09</b>
<b>TC-046</b>	<b>9.46</b>

Starting Point	Formula
7477 C	
<b>TC-021</b>	<b>39.40</b>
<b>TC-218</b>	<b>20.29</b>
<b>TC-046</b>	<b>24.81</b>
<b>TC-153</b>	<b>15.50</b>

Starting Point	Formula
7478 C	
<b>TC-021</b>	<b>94.20</b>
<b>TC-316</b>	<b>3.08</b>
<b>TC-057</b>	<b>2.72</b>

Starting Point	Formula
7479 C	
<b>TC-021</b>	<b>74.26</b>
<b>TC-057</b>	<b>14.75</b>
<b>TC-316</b>	<b>10.99</b>

Starting Point	Formula
7480 C	
<b>TC-021</b>	<b>60.27</b>
<b>TC-057</b>	<b>17.83</b>
<b>TC-316</b>	<b>21.90</b>

Starting Point	Formula
7481 C	
<b>TC-057</b>	<b>34.80</b>
<b>TC-316</b>	<b>23.64</b>
<b>TC-021</b>	<b>41.56</b>

Starting Point	Formula
7482 C	
<b>TC-057</b>	<b>43.23</b>
<b>TC-218</b>	<b>18.22</b>
<b>TC-021</b>	<b>38.55</b>

Starting Point	Formula
7483 C	
<b>TC-046</b>	<b>67.19</b>
<b>TC-217</b>	<b>27.80</b>
<b>TC-001</b>	<b>5.01</b>

Starting Point	Formula
7484 C	
<b>TC-046</b>	<b>51.20</b>
<b>TC-217</b>	<b>34.70</b>
<b>TC-316</b>	<b>8.03</b>
<b>TC-001</b>	<b>6.07</b>

Starting Point	Formula
7485 C	
<b>TC-021</b>	<b>92.50</b>
<b>TC-046</b>	<b>6.68</b>
<b>TC-218</b>	<b>0.82</b>

Starting Point	Formula
7486 C	
<b>TC-021</b>	<b>88.38</b>
<b>TC-057</b>	<b>10.37</b>
<b>TC-218</b>	<b>1.25</b>

# Texcharge TC

Starting Point	Formula
7487 C	
<b>TC-021</b>	<b>71.53</b>
<b>TC-057</b>	<b>24.74</b>
<b>TC-316</b>	<b>3.73</b>

Starting Point	Formula
7488 C	
<b>TC-021</b>	<b>58.04</b>
<b>TC-057</b>	<b>36.90</b>
<b>TC-316</b>	<b>5.06</b>

Starting Point	Formula
7489 C	
<b>TC-021</b>	<b>50.98</b>
<b>TC-057</b>	<b>29.68</b>
<b>TC-046</b>	<b>13.24</b>
<b>TC-218</b>	<b>5.08</b>
<b>TC-001</b>	<b>1.02</b>

Starting Point	Formula
7490 C	
<b>TC-021</b>	<b>46.61</b>
<b>TC-057</b>	<b>46.47</b>
<b>TC-218</b>	<b>4.39</b>
<b>TC-001</b>	<b>2.53</b>

Starting Point	Formula
7491 C	
<b>TC-057</b>	<b>38.71</b>
<b>TC-021</b>	<b>35.25</b>
<b>TC-046</b>	<b>19.18</b>
<b>TC-001</b>	<b>4.04</b>
<b>TC-218</b>	<b>2.82</b>

Starting Point	Formula
7492 C	
<b>TC-021</b>	<b>85.13</b>
<b>TC-057</b>	<b>13.56</b>
<b>TC-001</b>	<b>0.83</b>
<b>TC-218</b>	<b>0.48</b>

Starting Point	Formula
7493 C	
<b>TC-021</b>	<b>89.72</b>
<b>TC-057</b>	<b>8.57</b>
<b>TC-001</b>	<b>1.20</b>
<b>TC-218</b>	<b>0.51</b>

Starting Point	Formula
7494 C	
<b>TC-021</b>	<b>87.65</b>
<b>TC-057</b>	<b>8.53</b>
<b>TC-001</b>	<b>2.35</b>
<b>TC-316</b>	<b>1.47</b>

Starting Point	Formula
7495 C	
<b>TC-021</b>	<b>37.49</b>
<b>TC-057</b>	<b>41.82</b>
<b>TC-046</b>	<b>15.83</b>
<b>TC-001</b>	<b>2.95</b>
<b>TC-218</b>	<b>1.91</b>

Starting Point	Formula
7496 C	
<b>TC-057</b>	<b>44.63</b>
<b>TC-046</b>	<b>25.82</b>
<b>TC-021</b>	<b>21.36</b>
<b>TC-001</b>	<b>4.08</b>
<b>TC-316</b>	<b>4.11</b>

Starting Point	Formula
7497 C	
<b>TC-046</b>	<b>43.43</b>
<b>TC-021</b>	<b>47.21</b>
<b>TC-001</b>	<b>9.36</b>

Starting Point	Formula
7498 C	
<b>TC-057</b>	<b>58.77</b>
<b>TC-021</b>	<b>28.09</b>
<b>TC-001</b>	<b>10.49</b>
<b>TC-218</b>	<b>2.65</b>

Starting Point	Formula
7499 C	
<b>TC-021</b>	<b>91.71</b>
<b>TC-046</b>	<b>8.29</b>

Starting Point	Formula
7500 C	
<b>TC-021</b>	<b>90.09</b>
<b>TC-046</b>	<b>9.03</b>
<b>TC-001</b>	<b>0.39</b>
<b>TC-154</b>	<b>0.49</b>

Starting Point	Formula
7501 C	
<b>TC-021</b>	<b>87.37</b>
<b>TC-046</b>	<b>11.33</b>
<b>TC-001</b>	<b>0.65</b>
<b>TC-154</b>	<b>0.65</b>

Starting Point	Formula
7502 C	
<b>TC-021</b>	<b>79.32</b>
<b>TC-046</b>	<b>18.41</b>
<b>TC-154</b>	<b>1.28</b>
<b>TC-001</b>	<b>0.99</b>

# Texcharge TC

Starting Point	Formula
7503 C	
<b>TC-021</b>	<b>72.91</b>
<b>TC-154</b>	<b>3.11</b>
<b>TC-057</b>	<b>21.10</b>
<b>TC-001</b>	<b>2.88</b>

Starting Point	Formula
7504 C	
<b>TC-021</b>	<b>60.37</b>
<b>TC-057</b>	<b>25.34</b>
<b>TC-154</b>	<b>9.89</b>
<b>TC-001</b>	<b>4.40</b>

Starting Point	Formula
7505 C	
<b>TC-046</b>	<b>61.12</b>
<b>TC-021</b>	<b>25.44</b>
<b>TC-153</b>	<b>7.05</b>
<b>TC-001</b>	<b>6.39</b>

Starting Point	Formula
7506 C	
<b>TC-021</b>	<b>95.31</b>
<b>TC-057</b>	<b>4.10</b>
<b>TC-122</b>	<b>0.59</b>

Starting Point	Formula
7507 C	
<b>TC-021</b>	<b>92.29</b>
<b>TC-057</b>	<b>5.61</b>
<b>TC-103</b>	<b>2.10</b>

Starting Point	Formula
7508 C	
<b>TC-021</b>	<b>74.82</b>
<b>TC-046</b>	<b>23.38</b>
<b>TC-122</b>	<b>1.20</b>
<b>TC-001</b>	<b>0.60</b>

Starting Point	Formula
7509 C	
<b>TC-021</b>	<b>55.71</b>
<b>TC-046</b>	<b>41.38</b>
<b>TC-122</b>	<b>1.91</b>
<b>TC-001</b>	<b>1.00</b>

Starting Point	Formula
7510 C	
<b>TC-046</b>	<b>71.16</b>
<b>TC-021</b>	<b>23.82</b>
<b>TC-122</b>	<b>3.36</b>
<b>TC-001</b>	<b>1.66</b>

Starting Point	Formula
7511 C	
<b>TC-046</b>	<b>88.49</b>
<b>TC-021</b>	<b>4.96</b>
<b>TC-122</b>	<b>4.25</b>
<b>TC-001</b>	<b>2.30</b>

Starting Point	Formula
7512 C	
<b>TC-046</b>	<b>71.62</b>
<b>TC-057</b>	<b>18.21</b>
<b>TC-122</b>	<b>6.69</b>
<b>TC-001</b>	<b>3.48</b>

Starting Point	Formula
7513 C	
<b>TC-021</b>	<b>91.87</b>
<b>TC-046</b>	<b>5.86</b>
<b>TC-122</b>	<b>1.71</b>
<b>TC-001</b>	<b>0.56</b>

Starting Point	Formula
7514 C	
<b>TC-021</b>	<b>80.71</b>
<b>TC-046</b>	<b>15.48</b>
<b>TC-122</b>	<b>2.80</b>
<b>TC-001</b>	<b>1.01</b>

Starting Point	Formula
7515 C	
<b>TC-021</b>	<b>61.54</b>
<b>TC-046</b>	<b>31.78</b>
<b>TC-122</b>	<b>4.87</b>
<b>TC-001</b>	<b>1.81</b>

Starting Point	Formula
7516 C	
<b>TC-046</b>	<b>78.02</b>
<b>TC-122</b>	<b>9.91</b>
<b>TC-021</b>	<b>7.70</b>
<b>TC-001</b>	<b>4.37</b>

Starting Point	Formula
7517 C	
<b>TC-046</b>	<b>75.92</b>
<b>TC-122</b>	<b>11.64</b>
<b>TC-001</b>	<b>6.13</b>
<b>TC-057</b>	<b>6.31</b>

Starting Point	Formula
7518 C	
<b>TC-021</b>	<b>40.27</b>
<b>TC-046</b>	<b>36.42</b>
<b>TC-153</b>	<b>13.60</b>
<b>TC-001</b>	<b>9.71</b>

# Texcharge TC

Starting Point	Formula
7519 C	
<b>TC-057</b>	<b>39.42</b>
<b>TC-021</b>	<b>33.55</b>
<b>TC-001</b>	<b>14.41</b>
<b>TC-153</b>	<b>12.62</b>

Starting Point	Formula
7520 C	
<b>TC-021</b>	<b>94.21</b>
<b>TC-046</b>	<b>4.20</b>
<b>TC-001</b>	<b>0.19</b>
<b>TC-122</b>	<b>1.40</b>

Starting Point	Formula
7521 C	
<b>TC-021</b>	<b>79.47</b>
<b>TC-057</b>	<b>11.53</b>
<b>TC-154</b>	<b>7.87</b>
<b>TC-218</b>	<b>1.13</b>

Starting Point	Formula
7522 C	
<b>TC-021</b>	<b>60.14</b>
<b>TC-001</b>	<b>1.42</b>
<b>TC-057</b>	<b>21.47</b>
<b>TC-154</b>	<b>16.97</b>

Starting Point	Formula
7523 C	
<b>TC-021</b>	<b>73.99</b>
<b>TC-001</b>	<b>3.10</b>
<b>TC-057</b>	<b>9.14</b>
<b>TC-122</b>	<b>13.77</b>

Starting Point	Formula
7524 C	
<b>TC-021</b>	<b>65.76</b>
<b>TC-001</b>	<b>3.40</b>
<b>TC-057</b>	<b>13.91</b>
<b>TC-122</b>	<b>16.93</b>

Starting Point	Formula
7525 C	
<b>TC-021</b>	<b>60.18</b>
<b>TC-001</b>	<b>3.09</b>
<b>TC-057</b>	<b>22.77</b>
<b>TC-154</b>	<b>13.96</b>

Starting Point	Formula
7526 C	
<b>TC-046</b>	<b>72.05</b>
<b>TC-001</b>	<b>4.63</b>
<b>TC-154</b>	<b>23.32</b>

Starting Point	Formula
7527 C	
<b>TC-021</b>	<b>97.28</b>
<b>TC-046</b>	<b>2.14</b>
<b>TC-001</b>	<b>0.58</b>

Starting Point	Formula
7528 C	
<b>TC-021</b>	<b>94.43</b>
<b>TC-046</b>	<b>3.89</b>
<b>TC-001</b>	<b>1.32</b>
<b>TC-122</b>	<b>0.36</b>

Starting Point	Formula
7529 C	
<b>TC-021</b>	<b>94.46</b>
<b>TC--001</b>	<b>2.22</b>
<b>TC-057</b>	<b>2.14</b>
<b>TC-103</b>	<b>1.18</b>

Starting Point	Formula
7530 C	
<b>TC-021</b>	<b>90.11</b>
<b>TC-001</b>	<b>3.74</b>
<b>TC-057</b>	<b>3.70</b>
<b>TC-103</b>	<b>2.45</b>

Starting Point	Formula
7531 C	
<b>TC-021</b>	<b>72.24</b>
<b>TC-057</b>	<b>11.43</b>
<b>TC-001</b>	<b>8.83</b>
<b>TC-103</b>	<b>7.50</b>

Starting Point	Formula
7532 C	
<b>TC-021</b>	<b>51.02</b>
<b>TC-057</b>	<b>23.71</b>
<b>TC-001</b>	<b>13.01</b>
<b>TC-103</b>	<b>12.26</b>

Starting Point	Formula
7533 C	
<b>TC-021</b>	<b>21.15</b>
<b>TC-057</b>	<b>37.07</b>
<b>TC-001</b>	<b>20.79</b>
<b>TC-103</b>	<b>20.99</b>

Starting Point	Formula
7534 C	
<b>TC-021</b>	<b>96.82</b>
<b>TC-046</b>	<b>2.42</b>
<b>TC-001</b>	<b>0.76</b>

# Texcharge TC

Starting Point	Formula
7535 C	
<b>TC-021</b>	<b>94.37</b>
<b>TC-057</b>	<b>3.17</b>
<b>TC-001</b>	<b>2.00</b>
<b>TC-103</b>	<b>0.46</b>

Starting Point	Formula
7536 C	
<b>TC-021</b>	<b>85.24</b>
<b>TC-046</b>	<b>11.31</b>
<b>TC-001</b>	<b>3.09</b>
<b>TC-154</b>	<b>0.36</b>

Starting Point	Formula
7537 C	
<b>TC-021</b>	<b>94.62</b>
<b>TC-001</b>	<b>2.55</b>
<b>TC-057</b>	<b>2.36</b>
<b>TC-316</b>	<b>0.47</b>

Starting Point	Formula
7538 C	
<b>TC-021</b>	<b>90.31</b>
<b>TC-001</b>	<b>3.90</b>
<b>TC-046</b>	<b>4.77</b>
<b>TC-316</b>	<b>1.02</b>

Starting Point	Formula
7539 C	
<b>TC-021</b>	<b>88.14</b>
<b>TC-001</b>	<b>5.27</b>
<b>TC-046</b>	<b>6.02</b>
<b>TC-316</b>	<b>0.57</b>

Starting Point	Formula
7540 C	
<b>TC-021</b>	<b>67.13</b>
<b>TC-001</b>	<b>23.36</b>
<b>TC-316</b>	<b>4.71</b>
<b>TC-154</b>	<b>4.80</b>

Starting Point	Formula
7541 C	
<b>TC-021</b>	<b>98.96</b>
<b>TC-218</b>	<b>0.40</b>
<b>TC-154</b>	<b>0.25</b>
<b>TC-057</b>	<b>0.39</b>

Starting Point	Formula
7542 C	
<b>TC-021</b>	<b>94.15</b>
<b>TC-218</b>	<b>2.34</b>
<b>TC-153</b>	<b>1.69</b>
<b>TC-057</b>	<b>1.82</b>

Starting Point	Formula
7543 C	
<b>TC-021</b>	<b>87.67</b>
<b>TC-218</b>	<b>3.49</b>
<b>TC-153</b>	<b>3.34</b>
<b>TC-057</b>	<b>5.50</b>

Starting Point	Formula
7544 C	
<b>TC-021</b>	<b>77.53</b>
<b>TC-218</b>	<b>6.39</b>
<b>TC-153</b>	<b>6.31</b>
<b>TC-046</b>	<b>9.77</b>

Starting Point	Formula
7545 C	
<b>TC-021</b>	<b>76.18</b>
<b>TC-218</b>	<b>7.70</b>
<b>TC-154</b>	<b>4.65</b>
<b>TC-001</b>	<b>11.47</b>

Starting Point	Formula
7546 C	
<b>TC-021</b>	<b>64.40</b>
<b>TC-001</b>	<b>17.18</b>
<b>TC-218</b>	<b>8.46</b>
<b>TC-154</b>	<b>9.96</b>

Starting Point	Formula
7547 C	
<b>TC-021</b>	<b>53.24</b>
<b>TC-001</b>	<b>33.47</b>
<b>TC-132</b>	<b>13.29</b>

Starting Point	Formula
7548 C	
<b>TC-046</b>	<b>100.00</b>

Starting Point	Formula
7549 C	
<b>TC-046</b>	<b>74.94</b>
<b>TC-103</b>	<b>2.49</b>
<b>TC-021</b>	<b>22.57</b>

Starting Point	Formula
7550 C	
<b>TC-046</b>	<b>94.93</b>
<b>TC-001</b>	<b>1.66</b>
<b>TC-153</b>	<b>3.41</b>

# Texcharge TC

Starting Point	Formula
7551 C	
<b>TC-046</b>	<b>93.32</b>
<b>TC-001</b>	<b>3.12</b>
<b>TC-153</b>	<b>3.56</b>

Starting Point	Formula
7552 C	
<b>TC-046</b>	<b>85.93</b>
<b>TC-001</b>	<b>10.24</b>
<b>TC-153</b>	<b>3.83</b>

Starting Point	Formula
7553 C	
<b>TC-046</b>	<b>83.45</b>
<b>TC-001</b>	<b>16.55</b>

Starting Point	Formula
7554 C	
<b>TC-046</b>	<b>80.13</b>
<b>TC-001</b>	<b>19.87</b>

Starting Point	Formula
7555 C	
<b>TC-046</b>	<b>21.55</b>
<b>TC-001</b>	<b>1.05</b>
<b>TC-057</b>	<b>25.57</b>
<b>TC-103</b>	<b>3.36</b>
<b>TC-021</b>	<b>48.47</b>

Starting Point	Formula
7556 C	
<b>TC-046</b>	<b>62.38</b>
<b>TC-001</b>	<b>2.19</b>
<b>TC-103</b>	<b>2.51</b>
<b>TC-021</b>	<b>32.92</b>

Starting Point	Formula
7557 C	
<b>TC-046</b>	<b>63.63</b>
<b>TC-001</b>	<b>3.13</b>
<b>TC-122</b>	<b>1.05</b>
<b>TC-021</b>	<b>32.19</b>

Starting Point	Formula
7558 C	
<b>TC-046</b>	<b>56.13</b>
<b>TC-001</b>	<b>4.06</b>
<b>TC-103</b>	<b>3.82</b>
<b>TC-021</b>	<b>35.99</b>

Starting Point	Formula
7559 C	
<b>TC-046</b>	<b>50.26</b>
<b>TC-001</b>	<b>4.49</b>
<b>TC-103</b>	<b>4.83</b>
<b>TC-021</b>	<b>40.42</b>

Starting Point	Formula
7560 C	
<b>TC-046</b>	<b>48.35</b>
<b>TC-001</b>	<b>6.11</b>
<b>TC-103</b>	<b>3.51</b>
<b>TC-021</b>	<b>42.03</b>

Starting Point	Formula
7561 C	
<b>TC-046</b>	<b>52.18</b>
<b>TC-001</b>	<b>8.47</b>
<b>TC-122</b>	<b>0.97</b>
<b>TC-021</b>	<b>38.38</b>

Starting Point	Formula
7562 C	
<b>TC-046</b>	<b>25.43</b>
<b>TC-001</b>	<b>1.89</b>
<b>TC-103</b>	<b>2.26</b>
<b>TC-021</b>	<b>70.42</b>

Starting Point	Formula
7563 C	
<b>TC-046</b>	<b>51.96</b>
<b>TC-001</b>	<b>1.06</b>
<b>TC-103</b>	<b>3.89</b>
<b>TC-021</b>	<b>43.09</b>

Starting Point	Formula
7564 C	
<b>TC-046</b>	<b>55.67</b>
<b>TC-001</b>	<b>0.98</b>
<b>TC-103</b>	<b>7.48</b>
<b>TC-021</b>	<b>35.87</b>

Starting Point	Formula
7565 C	
<b>TC-046</b>	<b>38.42</b>
<b>TC-001</b>	<b>1.50</b>
<b>TC-103</b>	<b>12.48</b>
<b>TC-021</b>	<b>47.60</b>

Starting Point	Formula
7566 C	
<b>TC-046</b>	<b>32.80</b>
<b>TC-001</b>	<b>2.51</b>
<b>TC-122</b>	<b>8.47</b>
<b>TC-021</b>	<b>56.22</b>



# Texcharge TC

Starting Point	Formula
7567 C	
<b>TC-001</b>	<b>5.09</b>
<b>TC-057</b>	<b>32.40</b>
<b>TC-122</b>	<b>9.17</b>
<b>TC-021</b>	<b>53.34</b>

Starting Point	Formula
7568 C	
<b>TC-001</b>	<b>6.95</b>
<b>TC-057</b>	<b>28.98</b>
<b>TC-122</b>	<b>8.33</b>
<b>TC-021</b>	<b>55.74</b>

Starting Point	Formula
7569C	
<b>TC-057</b>	<b>41.52</b>
<b>TC-001</b>	<b>0.84</b>
<b>TC-122</b>	<b>4.65</b>
<b>TC-021</b>	<b>52.99</b>

Starting Point	Formula
7570 C	
<b>TC-057</b>	<b>40.12</b>
<b>TC-001</b>	<b>0.97</b>
<b>TC-122</b>	<b>5.48</b>
<b>TC-021</b>	<b>53.43</b>

Starting Point	Formula
7571 C	
<b>TC-057</b>	<b>39.32</b>
<b>TC-001</b>	<b>1.45</b>
<b>TC-122</b>	<b>5.56</b>
<b>TC-021</b>	<b>53.67</b>

Starting Point	Formula
7572 C	
<b>TC-057</b>	<b>37.31</b>
<b>TC-001</b>	<b>2.23</b>
<b>TC-122</b>	<b>6.75</b>
<b>TC-021</b>	<b>53.71</b>

Starting Point	Formula
7573 C	
<b>TC-057</b>	<b>39.19</b>
<b>TC-001</b>	<b>3.00</b>
<b>TC-122</b>	<b>7.63</b>
<b>TC-021</b>	<b>50.18</b>

Starting Point	Formula
7574 C	
<b>TC-057</b>	<b>35.03</b>
<b>TC-001</b>	<b>3.58</b>
<b>TC-122</b>	<b>6.33</b>
<b>TC-021</b>	<b>55.06</b>

Starting Point	Formula
7575 C	
<b>TC-057</b>	<b>36.66</b>
<b>TC-001</b>	<b>6.02</b>
<b>TC-122</b>	<b>6.23</b>
<b>TC-021</b>	<b>51.09</b>

Starting Point	Formula
7576 C	
<b>TC-021</b>	<b>70.24</b>
<b>TC-057</b>	<b>22.86</b>
<b>TC-001</b>	<b>0.78</b>
<b>TC-122</b>	<b>6.12</b>

Starting Point	Formula
7577 C	
<b>TC-021</b>	<b>61.15</b>
<b>TC-057</b>	<b>30.85</b>
<b>TC-001</b>	<b>0.65</b>
<b>TC-122</b>	<b>7.35</b>

Starting Point	Formula
7578 C	
<b>TC-021</b>	<b>51.95</b>
<b>TC-057</b>	<b>36.32</b>
<b>TC-001</b>	<b>0.77</b>
<b>TC-122</b>	<b>10.96</b>

Starting Point	Formula
5779 C	
<b>TC-021</b>	<b>50.88</b>
<b>TC-057</b>	<b>32.27</b>
<b>TC-001</b>	<b>0.71</b>
<b>TC-122</b>	<b>16.14</b>

Starting Point	Formula
7580 C	
<b>TC-021</b>	<b>52.38</b>
<b>TC-057</b>	<b>28.82</b>
<b>TC-001</b>	<b>1.72</b>
<b>TC-122</b>	<b>17.08</b>

Starting Point	Formula
7581 C	
<b>TC-021</b>	<b>54.63</b>
<b>TC-057</b>	<b>26.56</b>
<b>TC-001</b>	<b>5.64</b>
<b>TC-122</b>	<b>13.17</b>

Starting Point	Formula
7582 C	
<b>TC-021</b>	<b>46.66</b>
<b>TC-046</b>	<b>37.42</b>
<b>TC-001</b>	<b>9.38</b>
<b>TC-122</b>	<b>6.54</b>

# Texcharge TC

Starting Point	Formula
7583 C	
<b>TC-021</b>	<b>40.85</b>
<b>TC-001</b>	<b>0.66</b>
<b>TC-057</b>	<b>40.45</b>
<b>TC-154</b>	<b>18.04</b>

Starting Point	Formula
7584 C	
<b>TC-021</b>	<b>35.25</b>
<b>TC-001</b>	<b>0.95</b>
<b>TC-057</b>	<b>43.07</b>
<b>TC-154</b>	<b>20.73</b>

Starting Point	Formula
7585 C	
<b>TC-021</b>	<b>40.08</b>
<b>TC-001</b>	<b>2.35</b>
<b>TC-057</b>	<b>37.20</b>
<b>TC-154</b>	<b>20.37</b>

Starting Point	Formula
7586 C	
<b>TC-021</b>	<b>40.02</b>
<b>TC-001</b>	<b>2.35</b>
<b>TC-057</b>	<b>37.24</b>
<b>TC-154</b>	<b>20.39</b>

Starting Point	Formula
7587 C	
<b>TC-021</b>	<b>37.82</b>
<b>TC-001</b>	<b>3.11</b>
<b>TC-057</b>	<b>37.25</b>
<b>TC-154</b>	<b>21.82</b>

Starting Point	Formula
7588 C	
<b>TC-021</b>	<b>46.79</b>
<b>TC-001</b>	<b>5.06</b>
<b>TC-057</b>	<b>30.64</b>
<b>TC-154</b>	<b>17.51</b>

Starting Point	Formula
7589 C	
<b>TC-021</b>	<b>57.26</b>
<b>TC-001</b>	<b>10.70</b>
<b>TC-057</b>	<b>22.51</b>
<b>TC-153</b>	<b>9.53</b>

Starting Point	Formula
7590 C	
<b>TC-021</b>	<b>91.13</b>
<b>TC-001</b>	<b>0.60</b>
<b>TC-057</b>	<b>5.26</b>
<b>TC-154</b>	<b>3.01</b>

Starting Point	Formula
7591 C	
<b>TC-021</b>	<b>64.30</b>
<b>TC-001</b>	<b>0.99</b>
<b>TC-057</b>	<b>22.64</b>
<b>TC-154</b>	<b>12.07</b>

Starting Point	Formula
7592 C	
<b>TC-021</b>	<b>41.58</b>
<b>TC-001</b>	<b>1.32</b>
<b>TC-057</b>	<b>35.59</b>
<b>TC-154</b>	<b>21.51</b>

Starting Point	Formula
7593 C	
<b>TC-021</b>	<b>36.80</b>
<b>TC-001</b>	<b>2.14</b>
<b>TC-057</b>	<b>34.99</b>
<b>TC-154</b>	<b>26.07</b>

Starting Point	Formula
7594 C	
<b>TC-021</b>	<b>39.18</b>
<b>TC-001</b>	<b>4.48</b>
<b>TC-057</b>	<b>31.17</b>
<b>TC-154</b>	<b>25.17</b>

Starting Point	Formula
7595 C	
<b>TC-021</b>	<b>42.62</b>
<b>TC-001</b>	<b>6.60</b>
<b>TC-057</b>	<b>29.51</b>
<b>TC-154</b>	<b>21.27</b>

Starting Point	Formula
7596 C	
<b>TC-021</b>	<b>46.06</b>
<b>TC-001</b>	<b>9.35</b>
<b>TC-057</b>	<b>26.25</b>
<b>TC-154</b>	<b>18.34</b>

Starting Point	Formula
7597 C	
<b>TC-046</b>	<b>69.95</b>
<b>TC-154</b>	<b>30.05</b>

Starting Point	Formula
7598 C	
<b>TC-046</b>	<b>70.86</b>
<b>TC-001</b>	<b>1.45</b>
<b>TC-154</b>	<b>27.69</b>

# Texcharge TC

Starting Point	Formula
7599 C	
<b>TC-046</b>	<b>68.38</b>
<b>TC-001</b>	<b>1.81</b>
<b>TC-154</b>	<b>29.81</b>

Starting Point	Formula
7600 C	
<b>TC-021</b>	<b>29.08</b>
<b>TC-046</b>	<b>43.43</b>
<b>TC-103</b>	<b>5.73</b>
<b>TC-154</b>	<b>17.66</b>
<b>TC-001</b>	<b>4.1</b>

Starting Point	Formula
7601 C	
<b>TC-021</b>	<b>32.44</b>
<b>TC-001</b>	<b>5.22</b>
<b>TC-046</b>	<b>41.61</b>
<b>TC-103</b>	<b>6.40</b>
<b>TC-154</b>	<b>14.33</b>

Starting Point	Formula
7602 C	
<b>TC-021</b>	<b>61.27</b>
<b>TC-001</b>	<b>8.43</b>
<b>TC-103</b>	<b>30.30</b>

Starting Point	Formula
7603 C	
<b>TC-021</b>	<b>61.64</b>
<b>TC-001</b>	<b>11.55</b>
<b>TC-103</b>	<b>26.81</b>

Starting Point	Formula
7604 C	
<b>TC-021</b>	<b>97.87</b>
<b>TC-001</b>	<b>0.13</b>
<b>TC-057</b>	<b>1.02</b>
<b>TC-154</b>	<b>0.98</b>

Starting Point	Formula
7605 C	
<b>TC-021</b>	<b>93.23</b>
<b>TC-001</b>	<b>0.19</b>
<b>TC-057</b>	<b>3.19</b>
<b>TC-154</b>	<b>3.39</b>

Starting Point	Formula
7606 C	
<b>TC-021</b>	<b>81.75</b>
<b>TC-001</b>	<b>0.42</b>
<b>TC-057</b>	<b>8.55</b>
<b>TC-154</b>	<b>9.28</b>

Starting Point	Formula
7607 C	
<b>TC-021</b>	<b>63.12</b>
<b>TC-001</b>	<b>0.83</b>
<b>TC-057</b>	<b>18.62</b>
<b>TC-154</b>	<b>17.43</b>

Starting Point	Formula
7608 C	
<b>TC-046</b>	<b>65.84</b>
<b>TC-001</b>	<b>3.63</b>
<b>TC-154</b>	<b>30.53</b>

Starting Point	Formula
7609 C	
<b>TC-046</b>	<b>62.26</b>
<b>TC-001</b>	<b>6.27</b>
<b>TC-154</b>	<b>31.47</b>

Starting Point	Formula
7610 C	
<b>TC-046</b>	<b>61.23</b>
<b>TC-001</b>	<b>9.96</b>
<b>TC-154</b>	<b>28.81</b>

Starting Point	Formula
7611 C	
<b>TC-021</b>	<b>93.68</b>
<b>TC-001</b>	<b>0.37</b>
<b>TC-046</b>	<b>4.38</b>
<b>TC-153</b>	<b>1.57</b>

Starting Point	Formula
7612 C	
<b>TC-021</b>	<b>91.29</b>
<b>TC001</b>	<b>1.28</b>
<b>TC-057</b>	<b>4.30</b>
<b>TC-122</b>	<b>3.13</b>

Starting Point	Formula
7613 C	
<b>TC-021</b>	<b>88.27</b>
<b>TC-001</b>	<b>1.93</b>
<b>TC-057</b>	<b>5.47</b>
<b>TC-122</b>	<b>4.33</b>

Starting Point	Formula
7614 C	
<b>TC-021</b>	<b>86.04</b>
<b>TC-001</b>	<b>3.38</b>
<b>TC-057</b>	<b>6.49</b>
<b>TC-122</b>	<b>4.09</b>

# Texcharge TC

Starting Point	Formula
7615 C	
<b>TC-021</b>	<b>80.82</b>
<b>TC-001</b>	<b>6.11</b>
<b>TC-057</b>	<b>7.35</b>
<b>TC-122</b>	<b>5.72</b>

Starting Point	Formula
7616 C	
<b>TC-021</b>	<b>67.77</b>
<b>TC-001</b>	<b>9.94</b>
<b>TC-046</b>	<b>13.72</b>
<b>TC-122</b>	<b>8.57</b>

Starting Point	Formula
7617 C	
<b>TC-021</b>	<b>52.46</b>
<b>TC-001</b>	<b>12.04</b>
<b>TC-046</b>	<b>21.67</b>
<b>TC-153</b>	<b>13.83</b>

Starting Point	Formula
7618 C	
<b>TC-021</b>	<b>56.34</b>
<b>TC-057</b>	<b>26.75</b>
<b>TC-154</b>	<b>16.20</b>
<b>TC-001</b>	<b>0.71</b>

Starting Point	Formula
7619 C	
<b>TC-021</b>	<b>39.45</b>
<b>TC-057</b>	<b>33.92</b>
<b>TC-154</b>	<b>26.02</b>
<b>TC-001</b>	<b>0.61</b>

Starting Point	Formula
7620 C	
<b>TC-021</b>	<b>31.39</b>
<b>TC-057</b>	<b>33.94</b>
<b>TC-154</b>	<b>33.94</b>
<b>TC-001</b>	<b>0.73</b>

Starting Point	Formula
7621 C	
<b>TC-046</b>	<b>60.03</b>
<b>TC-154</b>	<b>38.04</b>
<b>TC-001</b>	<b>1.93</b>

Starting Point	Formula
7622 C	
<b>TC-046</b>	<b>59.59</b>
<b>TC-154</b>	<b>36.51</b>
<b>TC-001</b>	<b>3.90</b>

Starting Point	Formula
7623 C	
<b>TC-046</b>	<b>61.21</b>
<b>TC-154</b>	<b>33.99</b>
<b>TC-001</b>	<b>4.80</b>

Starting Point	Formula
7624 C	
<b>TC-046</b>	<b>61.73</b>
<b>TC-154</b>	<b>32.26</b>
<b>TC-001</b>	<b>6.01</b>

Starting Point	Formula
7625 C	
<b>TC-021</b>	<b>53.24</b>
<b>TC-057</b>	<b>26.84</b>
<b>TC-153</b>	<b>19.92</b>

Starting Point	Formula
7626 C	
<b>TC-021</b>	<b>54.54</b>
<b>TC-103</b>	<b>32.02</b>
<b>TC-153</b>	<b>12.35</b>
<b>TC-001</b>	<b>1.09</b>

Starting Point	Formula
7627 C	
<b>TC-021</b>	<b>53.26</b>
<b>TC-103</b>	<b>30.66</b>
<b>TC-153</b>	<b>13.42</b>
<b>TC-001</b>	<b>2.66</b>

Starting Point	Formula
7628 C	
<b>TC-046</b>	<b>64.39</b>
<b>TC-154</b>	<b>32.68</b>
<b>TC-001</b>	<b>2.93</b>

Starting Point	Formula
7629 C	
<b>TC-046</b>	<b>63.98</b>
<b>TC-154</b>	<b>26.78</b>
<b>TC-001</b>	<b>9.24</b>

Starting Point	Formula
7630C	
<b>TC-046</b>	<b>65.76</b>
<b>TC-154</b>	<b>22.95</b>
<b>TC-001</b>	<b>11.29</b>

# Texcharge TC

Starting Point	Formula
7631 C	
<b>TC-046</b>	<b>63.09</b>
<b>TC-154</b>	<b>23.89</b>
<b>TC-001</b>	<b>13.02</b>

Starting Point	Formula
7632 C	
<b>TC-021</b>	<b>95.94</b>
<b>TC-057</b>	<b>2.06</b>
<b>TC-132</b>	<b>2.00</b>

Starting Point	Formula
7633 C	
<b>TC-021</b>	<b>92.45</b>
<b>TC-001</b>	<b>1.14</b>
<b>TC-057</b>	<b>2.43</b>
<b>TC-154</b>	<b>3.98</b>

Starting Point	Formula
7634 C	
<b>TC-021</b>	<b>73.14</b>
<b>TC-001</b>	<b>0.88</b>
<b>TC-057</b>	<b>5.91</b>
<b>TC-154</b>	<b>20.07</b>

Starting Point	Formula
7635 C	
<b>TC-021</b>	<b>49.42</b>
<b>TC-001</b>	<b>0.19</b>
<b>TC-154</b>	<b>39.61</b>
<b>TC-057</b>	<b>10.78</b>

Starting Point	Formula
7636 C	
<b>TC-021</b>	<b>37.30</b>
<b>TC-154</b>	<b>45.10</b>
<b>TC-057</b>	<b>17.22</b>
<b>TC-001</b>	<b>0.38</b>

Starting Point	Formula
7637 C	
<b>TC-021</b>	<b>41.56</b>
<b>TC-154</b>	<b>38.00</b>
<b>TC-057</b>	<b>17.91</b>
<b>TC-001</b>	<b>2.53</b>

Starting Point	Formula
7638 C	
<b>TC-021</b>	<b>38.60</b>
<b>TC-154</b>	<b>39.35</b>
<b>TC-057</b>	<b>18.05</b>
<b>TC-001</b>	<b>4.00</b>

Starting Point	Formula
7639 C	
<b>TC-021</b>	<b>75.80</b>
<b>TC-154</b>	<b>12.73</b>
<b>TC-001</b>	<b>4.08</b>
<b>TC-057</b>	<b>7.39</b>

Starting Point	Formula
7640 C	
<b>TC-021</b>	<b>48.57</b>
<b>TC-154</b>	<b>34.33</b>
<b>TC-057</b>	<b>14.11</b>
<b>TC-001</b>	<b>2.99</b>

Starting Point	Formula
7641 C	
<b>TC-021</b>	<b>39.14</b>
<b>TC-154</b>	<b>41.23</b>
<b>TC-057</b>	<b>16.66</b>
<b>TC-001</b>	<b>2.97</b>

Starting Point	Formula
7642 C	
<b>TC-021</b>	<b>38.67</b>
<b>TC-154</b>	<b>34.45</b>
<b>TC-046</b>	<b>21.08</b>
<b>TC-001</b>	<b>5.80</b>

Starting Point	Formula
7643 C	
<b>TC-021</b>	<b>38.18</b>
<b>TC-154</b>	<b>33.02</b>
<b>TC-046</b>	<b>21.18</b>
<b>TC-001</b>	<b>7.62</b>

Starting Point	Formula
7644 C	
<b>TC-021</b>	<b>41.24</b>
<b>TC-154</b>	<b>28.20</b>
<b>TC-046</b>	<b>20.99</b>
<b>TC-001</b>	<b>9.57</b>

Starting Point	Formula
7645 C	
<b>TC-021</b>	<b>40.13</b>
<b>TC-154</b>	<b>26.96</b>
<b>TC-046</b>	<b>21.72</b>
<b>TC-001</b>	<b>11.19</b>

Starting Point	Formula
7646 C	
<b>TC-021</b>	<b>73.26</b>
<b>TC-154</b>	<b>17.61</b>
<b>TC-057</b>	<b>6.93</b>
<b>TC-218</b>	<b>2.20</b>

# Texcharge TC

Starting Point	Formula
7647 C	
<b>TC-021</b>	<b>54.92</b>
<b>TC-154</b>	<b>37.04</b>
<b>TC-057</b>	<b>6.51</b>
<b>TC-218</b>	<b>1.53</b>

Starting Point	Formula
7648 C	
<b>TC-154</b>	<b>50.70</b>
<b>TC-021</b>	<b>42.85</b>
<b>TC-057</b>	<b>4.64</b>
<b>TC-316</b>	<b>1.81</b>

Starting Point	Formula
7649 C	
<b>TC-021</b>	<b>53.38</b>
<b>TC-153</b>	<b>33.18</b>
<b>TC-132</b>	<b>13.44</b>

Starting Point	Formula
7650 C	
<b>TC-021</b>	<b>53.86</b>
<b>TC-154</b>	<b>30.38</b>
<b>TC-153</b>	<b>10.81</b>
<b>TC-001</b>	<b>4.95</b>

Starting Point	Formula
7651 C	
<b>TC-021</b>	<b>34.00</b>
<b>TC-154</b>	<b>41.44</b>
<b>TC-046</b>	<b>18.52</b>
<b>TC-218</b>	<b>6.04</b>

Starting Point	Formula
7652 C	
<b>TC-154</b>	<b>41.53</b>
<b>TC-021</b>	<b>27.14</b>
<b>TC-046</b>	<b>21.35</b>
<b>TC-217</b>	<b>9.98</b>

Starting Point	Formula
7653 C	
<b>TC-021</b>	<b>75.42</b>
<b>TC-046</b>	<b>11.57</b>
<b>TC-154</b>	<b>9.49</b>
<b>TC-218</b>	<b>3.52</b>

Starting Point	Formula
7654 C	
<b>TC-021</b>	<b>77.72</b>
<b>TC-154</b>	<b>15.41</b>
<b>TC-057</b>	<b>4.25</b>
<b>TC-218</b>	<b>2.62</b>

Starting Point	Formula
7655 C	
<b>TC-021</b>	<b>67.80</b>
<b>TC-154</b>	<b>26.49</b>
<b>TC-057</b>	<b>3.13</b>
<b>TC-218</b>	<b>2.58</b>

Starting Point	Formula
7656 C	
<b>TC-021</b>	<b>52.14</b>
<b>TC-154</b>	<b>40.75</b>
<b>TC-057</b>	<b>3.68</b>
<b>TC-218</b>	<b>3.43</b>

Starting Point	Formula
7657 C	
<b>TC-021</b>	<b>52.56</b>
<b>TC-153</b>	<b>40.23</b>
<b>TC-218</b>	<b>7.21</b>

Starting Point	Formula
7658 C	
<b>TC-021</b>	<b>34.11</b>
<b>TC-154</b>	<b>35.94</b>
<b>TC-046</b>	<b>20.79</b>
<b>TC-217</b>	<b>9.16</b>

Starting Point	Formula
7659 C	
<b>TC-021</b>	<b>35.23</b>
<b>TC-154</b>	<b>41.08</b>
<b>TC-057</b>	<b>15.26</b>
<b>TC-218</b>	<b>8.43</b>

Starting Point	Formula
7660 C	
<b>TC-021</b>	<b>82.41</b>
<b>TC-218</b>	<b>3.34</b>
<b>TC-154</b>	<b>9.57</b>
<b>TC-057</b>	<b>4.68</b>

Starting Point	Formula
7661 C	
<b>TC-021</b>	<b>72.38</b>
<b>TC-218</b>	<b>4.25</b>
<b>TC-154</b>	<b>18.84</b>
<b>TC-057</b>	<b>4.53</b>

Starting Point	Formula
7662 C	
<b>TC-021</b>	<b>53.89</b>
<b>TC-154</b>	<b>40.22</b>
<b>TC-316</b>	<b>5.89</b>

# Texcharge TC

Starting Point	Formula
7663 C	
<b>TC-154</b>	<b>42.88</b>
<b>TC-021</b>	<b>43.25</b>
<b>TC-217</b>	<b>9.40</b>
<b>TC-057</b>	<b>4.47</b>

Starting Point	Formula
7664 C	
<b>TC-021</b>	<b>44.05</b>
<b>TC-154</b>	<b>41.06</b>
<b>TC-217</b>	<b>10.48</b>
<b>TC-057</b>	<b>4.41</b>

Starting Point	Formula
7665 C	
<b>TC-021</b>	<b>44.66</b>
<b>TC-154</b>	<b>40.23</b>
<b>TC-218</b>	<b>8.09</b>
<b>TC-057</b>	<b>7.02</b>

Starting Point	Formula
7666 C	
<b>TC-021</b>	<b>40.62</b>
<b>TC-154</b>	<b>25.34</b>
<b>TC-046</b>	<b>24.75</b>
<b>TC-218</b>	<b>9.29</b>

Starting Point	Formula
7667 C	
<b>TC-021</b>	<b>83.99</b>
<b>TC-001</b>	<b>2.47</b>
<b>TC-218</b>	<b>5.83</b>
<b>TC-154</b>	<b>7.71</b>

Starting Point	Formula
7668 C	
<b>TC-021</b>	<b>78.29</b>
<b>TC-153</b>	<b>12.06</b>
<b>TC-218</b>	<b>9.65</b>

Starting Point	Formula
7669 C	
<b>TC-021</b>	<b>70.16</b>
<b>TC-154</b>	<b>19.49</b>
<b>TC-218</b>	<b>8.78</b>
<b>TC-001</b>	<b>1.57</b>

Starting Point	Formula
7670 C	
<b>TC-021</b>	<b>63.64</b>
<b>TC-154</b>	<b>24.37</b>
<b>TC-218</b>	<b>10.40</b>
<b>TC-001</b>	<b>1.59</b>

Starting Point	Formula
7671 C	
<b>TC-021</b>	<b>57.06</b>
<b>TC-154</b>	<b>30.16</b>
<b>TC-218</b>	<b>10.82</b>
<b>TC-001</b>	<b>1.96</b>

Starting Point	Formula
7672 C	
<b>TC-021</b>	<b>55.25</b>
<b>TC-154</b>	<b>31.54</b>
<b>TC-218</b>	<b>11.07</b>
<b>TC-001</b>	<b>2.14</b>

Starting Point	Formula
7673 C	
<b>TC-021</b>	<b>67.32</b>
<b>TC-154</b>	<b>20.08</b>
<b>TC-218</b>	<b>9.31</b>
<b>TC-001</b>	<b>3.29</b>

Starting Point	Formula
7674 C	
<b>TC-021</b>	<b>88.19</b>
<b>TC-154</b>	<b>6.56</b>
<b>TC-218</b>	<b>3.88</b>
<b>TC-001</b>	<b>1.37</b>

Starting Point	Formula
7675 C	
<b>TC-021</b>	<b>84.02</b>
<b>TC-154</b>	<b>9.28</b>
<b>TC-218</b>	<b>5.02</b>
<b>TC-001</b>	<b>1.68</b>

Starting Point	Formula
7676 C	
<b>TC-021</b>	<b>74.19</b>
<b>TC-154</b>	<b>18.16</b>
<b>TC-218</b>	<b>6.12</b>
<b>TC-001</b>	<b>1.53</b>

Starting Point	Formula
7677 C	
<b>TC-021</b>	<b>66.74</b>
<b>TC-154</b>	<b>25.42</b>
<b>TC-218</b>	<b>6.16</b>
<b>TC-001</b>	<b>1.68</b>

Starting Point	Formula
7678 C	
<b>TC-021</b>	<b>60.62</b>
<b>TC-154</b>	<b>30.85</b>
<b>TC-218</b>	<b>6.96</b>
<b>TC-001</b>	<b>1.57</b>

# Texcharge TC

Starting Point	Formula
7679 C	
<b>TC-021</b>	<b>53.58</b>
<b>TC-154</b>	<b>35.07</b>
<b>TC-218</b>	<b>9.17</b>
<b>TC-001</b>	<b>2.18</b>

Starting Point	Formula
7680 C	
<b>TC-021</b>	<b>44.93</b>
<b>TC-154</b>	<b>43.05</b>
<b>TC-218</b>	<b>9.80</b>
<b>TC-001</b>	<b>2.22</b>

Starting Point	Formula
7681 C	
<b>TC-021</b>	<b>93.54</b>
<b>TC-001</b>	<b>0.69</b>
<b>TC-218</b>	<b>2.95</b>
<b>TC-154</b>	<b>2.82</b>

Starting Point	Formula
7682 C	
<b>TC-021</b>	<b>85.01</b>
<b>TC-001</b>	<b>1.09</b>
<b>TC-218</b>	<b>7.26</b>
<b>TC-154</b>	<b>6.64</b>

Starting Point	Formula
7683 C	
<b>TC-021</b>	<b>71.36</b>
<b>TC-217</b>	<b>20.47</b>
<b>TC-153</b>	<b>8.17</b>

Starting Point	Formula
7684 C	
<b>TC-021</b>	<b>63.50</b>
<b>TC-217</b>	<b>25.15</b>
<b>TC-153</b>	<b>11.35</b>

Starting Point	Formula
7685 C	
<b>TC-021</b>	<b>60.23</b>
<b>TC-217</b>	<b>27.25</b>
<b>TC-153</b>	<b>12.52</b>

Starting Point	Formula
7686 C	
<b>TC-021</b>	<b>55.49</b>
<b>TC-217</b>	<b>30.62</b>
<b>TC-153</b>	<b>13.89</b>

Starting Point	Formula
7687 C	
<b>TC-021</b>	<b>51.95</b>
<b>TC-154</b>	<b>27.02</b>
<b>TC-218</b>	<b>19.16</b>
<b>TC-001</b>	<b>1.87</b>

Starting Point	Formula
7688 C	
<b>TC-021</b>	<b>86.66</b>
<b>TC-001</b>	<b>0.64</b>
<b>TC-218</b>	<b>9.85</b>
<b>TC-154</b>	<b>2.85</b>

Starting Point	Formula
7689 C	
<b>TC-021</b>	<b>82.73</b>
<b>TC-218</b>	<b>13.31</b>
<b>TC-154</b>	<b>3.07</b>
<b>TC-001</b>	<b>0.89</b>

Starting Point	Formula
7690 C	
<b>TC-021</b>	<b>72.53</b>
<b>TC-218</b>	<b>20.94</b>
<b>TC-154</b>	<b>4.73</b>
<b>TC-001</b>	<b>1.80</b>

Starting Point	Formula
7691 C	
<b>TC-021</b>	<b>63.17</b>
<b>TC-218</b>	<b>26.10</b>
<b>TC-154</b>	<b>8.45</b>
<b>TC-001</b>	<b>2.28</b>

Starting Point	Formula
7692 C	
<b>TC-021</b>	<b>61.27</b>
<b>TC-218</b>	<b>23.03</b>
<b>TC-154</b>	<b>12.29</b>
<b>TC-001</b>	<b>3.41</b>

Starting Point	Formula
7693 C	
<b>TC-021</b>	<b>57.78</b>
<b>TC-218</b>	<b>20.95</b>
<b>TC-154</b>	<b>16.37</b>
<b>TC-001</b>	<b>4.90</b>

Starting Point	Formula
7694 C	
<b>TC-021</b>	<b>54.29</b>
<b>TC-218</b>	<b>21.25</b>
<b>TC-154</b>	<b>17.84</b>
<b>TC-001</b>	<b>6.62</b>



# Texcharge TC

Starting Point	Formula
7695 C	
<b>TC-021</b>	<b>92.86</b>
<b>TC-217</b>	<b>5.67</b>
<b>TC-001</b>	<b>1.47</b>

Starting Point	Formula
7696 C	
<b>TC-021</b>	<b>91.41</b>
<b>TC-218</b>	<b>6.05</b>
<b>TC-001</b>	<b>2.18</b>
<b>TC-132</b>	<b>0.36</b>

Starting Point	Formula
7697 C	
<b>TC-021</b>	<b>77.64</b>
<b>TC-218</b>	<b>10.86</b>
<b>TC-153</b>	<b>5.01</b>
<b>TC-046</b>	<b>6.49</b>

Starting Point	Formula
7698 C	
<b>TC-021</b>	<b>63.37</b>
<b>TC-218</b>	<b>12.66</b>
<b>TC-154</b>	<b>11.07</b>
<b>TC-046</b>	<b>12.90</b>

Starting Point	Formula
7699 C	
<b>TC-021</b>	<b>56.18</b>
<b>TC-218</b>	<b>14.47</b>
<b>TC-154</b>	<b>13.87</b>
<b>TC-046</b>	<b>15.48</b>

Starting Point	Formula
7700 C	
<b>TC-021</b>	<b>56.42</b>
<b>TC-218</b>	<b>16.89</b>
<b>TC-154</b>	<b>18.44</b>
<b>TC-057</b>	<b>8.25</b>

Starting Point	Formula
7701 C	
<b>TC-021</b>	<b>42.67</b>
<b>TC-218</b>	<b>22.89</b>
<b>TC-154</b>	<b>17.27</b>
<b>TC-046</b>	<b>17.17</b>

Starting Point	Formula
7702 C	
<b>TC-021</b>	<b>86.47</b>
<b>TC-218</b>	<b>8.84</b>
<b>TC-154</b>	<b>2.62</b>
<b>TC-057</b>	<b>2.07</b>

Starting Point	Formula
7703 C	
<b>TC-021</b>	<b>78.51</b>
<b>TC-218</b>	<b>14.60</b>
<b>TC-154</b>	<b>2.31</b>
<b>TC-046</b>	<b>4.58</b>

Starting Point	Formula
7704 C	
<b>TC-021</b>	<b>65.35</b>
<b>TC-218</b>	<b>24.23</b>
<b>TC-154</b>	<b>3.87</b>
<b>TC-046</b>	<b>6.55</b>

Starting Point	Formula
7705 C	
<b>TC-021</b>	<b>58.21</b>
<b>TC-218</b>	<b>25.91</b>
<b>TC-154</b>	<b>10.19</b>
<b>TC-057</b>	<b>5.69</b>

Starting Point	Formula
7706 C	
<b>TC-021</b>	<b>56.06</b>
<b>TC-218</b>	<b>24.49</b>
<b>TC-154</b>	<b>12.62</b>
<b>TC-057</b>	<b>6.83</b>

Starting Point	Formula
7707 C	
<b>TC-021</b>	<b>46.25</b>
<b>TC-218</b>	<b>24.28</b>
<b>TC-154</b>	<b>13.67</b>
<b>TC-046</b>	<b>15.80</b>

Starting Point	Formula
7708 C	
<b>TC-021</b>	<b>37.49</b>
<b>TC-218</b>	<b>24.74</b>
<b>TC-154</b>	<b>17.27</b>
<b>TC-046</b>	<b>20.50</b>

Starting Point	Formula
7709 C	
<b>TC-021</b>	<b>90.08</b>
<b>TC-218</b>	<b>6.13</b>
<b>TC-046</b>	<b>2.99</b>
<b>TC-001</b>	<b>0.80</b>

Starting Point	Formula
7710 C	
<b>TC-021</b>	<b>81.91</b>
<b>TC-218</b>	<b>14.26</b>
<b>TC-057</b>	<b>3.02</b>
<b>TC-103</b>	<b>0.81</b>

# Texcharge TC

Starting Point	Formula
7711 C	
<b>TC-021</b>	<b>67.55</b>
<b>TC-218</b>	<b>23.38</b>
<b>TC-046</b>	<b>9.07</b>

Starting Point	Formula
7712 C	
<b>TC-021</b>	<b>57.96</b>
<b>TC-217</b>	<b>35.69</b>
<b>TC-057</b>	<b>6.35</b>

Starting Point	Formula
7713 C	
<b>TC-217</b>	<b>71.34</b>
<b>TC-046</b>	<b>28.66</b>

Starting Point	Formula
7714 C	
<b>TC-217</b>	<b>69.29</b>
<b>TC-046</b>	<b>30.71</b>

Starting Point	Formula
7715 C	
<b>TC-218</b>	<b>33.15</b>
<b>TC-046</b>	<b>47.36</b>
<b>TC-154</b>	<b>19.49</b>

Starting Point	Formula
7716 C	
<b>TC-021</b>	<b>62.75</b>
<b>TC-001</b>	<b>0.50</b>
<b>TC-046</b>	<b>17.02</b>
<b>TC-218</b>	<b>19.73</b>

Starting Point	Formula
7717 C	
<b>TC-021</b>	<b>45.46</b>
<b>TC-001</b>	<b>0.39</b>
<b>TC-046</b>	<b>23.97</b>
<b>TC-218</b>	<b>30.18</b>

Starting Point	Formula
7718 C	
<b>TC-021</b>	<b>29.10</b>
<b>TC-046</b>	<b>27.58</b>
<b>TC-217</b>	<b>23.35</b>
<b>TC-218</b>	<b>19.97</b>

Starting Point	Formula
7719 C	
<b>TC-021</b>	<b>21.45</b>
<b>TC-046</b>	<b>31.01</b>
<b>TC-217</b>	<b>47.54</b>

Starting Point	Formula
7720 C	
<b>TC-021</b>	<b>30.20</b>
<b>TC-001</b>	<b>3.98</b>
<b>TC-046</b>	<b>29.85</b>
<b>TC-218</b>	<b>35.97</b>

Starting Point	Formula
7721 C	
<b>TC-021</b>	<b>34.44</b>
<b>TC-001</b>	<b>5.32</b>
<b>TC-046</b>	<b>23.33</b>
<b>TC-218</b>	<b>36.91</b>

Starting Point	Formula
7722 C	
<b>TC-021</b>	<b>24.95</b>
<b>TC-001</b>	<b>8.20</b>
<b>TC-046</b>	<b>24.05</b>
<b>TC-218</b>	<b>42.80</b>

Starting Point	Formula
7723 C	
<b>TC-021</b>	<b>63.23</b>
<b>TC-046</b>	<b>18.02</b>
<b>TC-217</b>	<b>14.41</b>
<b>TC-057</b>	<b>4.34</b>

Starting Point	Formula
7724 C	
<b>TC-021</b>	<b>40.81</b>
<b>TC-046</b>	<b>40.70</b>
<b>TC-218</b>	<b>18.49</b>

Starting Point	Formula
7725 C	
<b>TC-046</b>	<b>35.78</b>
<b>TC-057</b>	<b>11.58</b>
<b>TC-218</b>	<b>27.12</b>
<b>TC-021</b>	<b>25.52</b>

Starting Point	Formula
7726 C	
<b>TC-046</b>	<b>67.33</b>
<b>TC-218</b>	<b>32.67</b>

# Texcharge TC

Starting Point	Formula
7727 C	
<b>TC-046</b>	<b>55.95</b>
<b>TC-217</b>	<b>40.07</b>
<b>TC-057</b>	<b>3.36</b>
<b>TC-001</b>	<b>0.62</b>

Starting Point	Formula
7728 C	
<b>TC-046</b>	<b>59.18</b>
<b>TC-217</b>	<b>38.77</b>
<b>TC-001</b>	<b>2.05</b>

Starting Point	Formula
7729 C	
<b>TC-046</b>	<b>49.77</b>
<b>TC-217</b>	<b>45.44</b>
<b>TC-001</b>	<b>4.79</b>

Starting Point	Formula
7730 C	
<b>TC-021</b>	<b>51.19</b>
<b>TC-046</b>	<b>23.25</b>
<b>TC-057</b>	<b>13.45</b>
<b>TC-218</b>	<b>10.58</b>
<b>TC-001</b>	<b>1.53</b>

Starting Point	Formula
7731 C	
<b>TC-046</b>	<b>75.00</b>
<b>TC-217</b>	<b>21.85</b>
<b>TC-218</b>	<b>3.15</b>

Starting Point	Formula
7732 C	
<b>TC-046</b>	<b>63.08</b>
<b>TC-217</b>	<b>32.10</b>
<b>TC-057</b>	<b>4.82</b>

Starting Point	Formula
7733 C	
<b>TC-046</b>	<b>66.04</b>
<b>TC-217</b>	<b>32.59</b>
<b>TC-001</b>	<b>1.37</b>

Starting Point	Formula
7734 C	
<b>TC-046</b>	<b>65.40</b>
<b>TC-217</b>	<b>29.47</b>
<b>TC-001</b>	<b>5.13</b>

Starting Point	Formula
7735 C	
<b>TC-046</b>	<b>66.49</b>
<b>TC-217</b>	<b>24.83</b>
<b>TC-001</b>	<b>8.68</b>

Starting Point	Formula
7736 C	
<b>TC-046</b>	<b>62.94</b>
<b>TC-217</b>	<b>27.28</b>
<b>TC-001</b>	<b>9.78</b>

Starting Point	Formula
7737 C	
<b>TC-046</b>	<b>25.65</b>
<b>TC-057</b>	<b>35.28</b>
<b>TC-218</b>	<b>7.50</b>
<b>TC-103</b>	<b>1.30</b>
<b>TC-021</b>	<b>30.27</b>

Starting Point	Formula
7738 C	
<b>TC-046</b>	<b>33.60</b>
<b>TC-057</b>	<b>26.84</b>
<b>TC-218</b>	<b>10.00</b>
<b>TC-021</b>	<b>29.33</b>
<b>TC-001</b>	<b>0.23</b>

Starting Point	Formula
7739 C	
<b>TC-046</b>	<b>35.13</b>
<b>TC-057</b>	<b>24.49</b>
<b>TC-218</b>	<b>13.06</b>
<b>TC-021</b>	<b>26.86</b>
<b>TC-103</b>	<b>0.46</b>

Starting Point	Formula
7740 C	
<b>TC-046</b>	<b>41.56</b>
<b>TC-057</b>	<b>19.97</b>
<b>TC-218</b>	<b>13.95</b>
<b>TC-021</b>	<b>23.06</b>
<b>TC-103</b>	<b>1.46</b>

Starting Point	Formula
7741 C	
<b>TC-046</b>	<b>75.83</b>
<b>TC-218</b>	<b>12.54</b>
<b>TC-021</b>	<b>10.36</b>
<b>TC-001</b>	<b>1.27</b>

Starting Point	Formula
7742 C	
<b>TC-046</b>	<b>67.48</b>
<b>TC-218</b>	<b>16.04</b>
<b>TC-021</b>	<b>10.91</b>
<b>TC-103</b>	<b>5.57</b>

# Texcharge TC

Starting Point	Formula
7743 C	
<b>TC-046</b>	<b>57.31</b>
<b>TC-218</b>	<b>19.08</b>
<b>TC-021</b>	<b>14.71</b>
<b>TC-103</b>	<b>8.90</b>

Starting Point	Formula
7744 C	
<b>TC-057</b>	<b>55.92</b>
<b>TC-021</b>	<b>27.37</b>
<b>TC-046</b>	<b>15.00</b>
<b>TC-001</b>	<b>0.78</b>
<b>TC-218</b>	<b>0.93</b>

Starting Point	Formula
7745 C	
<b>TC-057</b>	<b>53.63</b>
<b>TC-021</b>	<b>27.67</b>
<b>TC-046</b>	<b>16.18</b>
<b>TC-001</b>	<b>1.44</b>
<b>TC-218</b>	<b>1.08</b>

Starting Point	Formula
7746 C	
<b>TC-057</b>	<b>47.71</b>
<b>TC-021</b>	<b>33.36</b>
<b>TC-046</b>	<b>15.36</b>
<b>TC-001</b>	<b>2.44</b>
<b>TC-218</b>	<b>1.13</b>

Starting Point	Formula
7747 C	
<b>TC-057</b>	<b>46.48</b>
<b>TC-021</b>	<b>29.50</b>
<b>TC-046</b>	<b>18.95</b>
<b>TC-001</b>	<b>3.41</b>
<b>TC-218</b>	<b>1.66</b>

Starting Point	Formula
7748 C	
<b>TC-057</b>	<b>42.32</b>
<b>TC-021</b>	<b>30.53</b>
<b>TC-046</b>	<b>20.70</b>
<b>TC-001</b>	<b>4.55</b>
<b>TC-218</b>	<b>1.9</b>

Starting Point	Formula
7749 C	
<b>TC-057</b>	<b>38.80</b>
<b>TC-021</b>	<b>30.48</b>
<b>TC-046</b>	<b>22.64</b>
<b>TC-001</b>	<b>6.33</b>
<b>TC-218</b>	<b>1.75</b>

Starting Point	Formula
7750 C	
<b>TC-057</b>	<b>35.91</b>
<b>TC-021</b>	<b>27.10</b>
<b>TC-046</b>	<b>26.53</b>
<b>TC-001</b>	<b>8.38</b>
<b>TC-218</b>	<b>2.08</b>

Starting Point	Formula
7751 C	
<b>TC-021</b>	<b>61.01</b>
<b>TC-057</b>	<b>36.51</b>
<b>TC-103</b>	<b>1.31</b>
<b>TC-001</b>	<b>1.17</b>

Starting Point	Formula
7752 C	
<b>TC-057</b>	<b>44.85</b>
<b>TC-021</b>	<b>36.71</b>
<b>TC-046</b>	<b>16.09</b>
<b>TC-001</b>	<b>1.06</b>
<b>TC-103</b>	<b>1.29</b>

Starting Point	Formula
7753 C	
<b>TC-057</b>	<b>48.04</b>
<b>TC-021</b>	<b>30.99</b>
<b>TC-046</b>	<b>17.51</b>
<b>TC-001</b>	<b>1.65</b>
<b>TC-103</b>	<b>1.81</b>

Starting Point	Formula
7754 C	
<b>TC-057</b>	<b>61.06</b>
<b>TC-021</b>	<b>32.36</b>
<b>TC-001</b>	<b>3.50</b>
<b>TC-103</b>	<b>3.08</b>

Starting Point	Formula
7755 C	
<b>TC-057</b>	<b>58.85</b>
<b>TC-021</b>	<b>32.74</b>
<b>TC-001</b>	<b>5.51</b>
<b>TC-103</b>	<b>2.90</b>

Starting Point	Formula
7756 C	
<b>TC-057</b>	<b>53.74</b>
<b>TC-021</b>	<b>34.91</b>
<b>TC-001</b>	<b>8.62</b>
<b>TC-103</b>	<b>2.73</b>

Starting Point	Formula
7757 C	
<b>TC-057</b>	<b>55.68</b>
<b>TC-021</b>	<b>31.37</b>
<b>TC-001</b>	<b>10.64</b>
<b>TC-103</b>	<b>2.31</b>

Starting Point	Formula
7758 C	
<b>TC-057</b>	<b>54.46</b>
<b>TC-021</b>	<b>30.88</b>
<b>TC-046</b>	<b>13.86</b>
<b>TC-001</b>	<b>0.80</b>

# Texcharge TC

Starting Point	Formula
7759 C	
<b>TC-057</b>	<b>59.26</b>
<b>TC-021</b>	<b>22.05</b>
<b>TC-046</b>	<b>17.37</b>
<b>TC-001</b>	<b>1.32</b>

Starting Point	Formula
7760 C	
<b>TC-057</b>	<b>41.93</b>
<b>TC-021</b>	<b>28.35</b>
<b>TC-046</b>	<b>25.30</b>
<b>TC-001</b>	<b>4.42</b>

Starting Point	Formula
7761 C	
<b>TC-057</b>	<b>37.51</b>
<b>TC-021</b>	<b>32.08</b>
<b>TC-046</b>	<b>22.60</b>
<b>TC-001</b>	<b>6.89</b>
<b>TC-218</b>	<b>0.92</b>

Starting Point	Formula
7762 C	
<b>TC-057</b>	<b>28.01</b>
<b>TC-021</b>	<b>29.25</b>
<b>TC-046</b>	<b>29.15</b>
<b>TC-001</b>	<b>8.55</b>
<b>TC-217</b>	<b>5.04</b>

Starting Point	Formula
7763 C	
<b>TC-057</b>	<b>21.33</b>
<b>TC-021</b>	<b>31.70</b>
<b>TC-046</b>	<b>31.96</b>
<b>TC-001</b>	<b>10.95</b>
<b>TC-217</b>	<b>4.06</b>

Starting Point	Formula
7764 C	
<b>TC-046</b>	<b>34.93</b>
<b>TC-057</b>	<b>22.76</b>
<b>TC-021</b>	<b>26.16</b>
<b>TC-001</b>	<b>12.46</b>
<b>TC-217</b>	<b>3.69</b>

Starting Point	Formula
7765 C	
<b>TC-057</b>	<b>50.73</b>
<b>TC-021</b>	<b>33.64</b>
<b>TC-046</b>	<b>13.97</b>
<b>TC-001</b>	<b>1.30</b>
<b>TC-218</b>	<b>0.36</b>

Starting Point	Formula
7766 C	
<b>TC-057</b>	<b>51.95</b>
<b>TC-021</b>	<b>30.21</b>
<b>TC-046</b>	<b>15.88</b>
<b>TC-001</b>	<b>1.72</b>
<b>TC-218</b>	<b>0.24</b>

Starting Point	Formula
7767 C	
<b>TC-057</b>	<b>45.42</b>
<b>TC-021</b>	<b>35.92</b>
<b>TC-046</b>	<b>16.06</b>
<b>TC-001</b>	<b>2.60</b>

Starting Point	Formula
7768 C	
<b>TC-046</b>	<b>75.52</b>
<b>TC-021</b>	<b>19.61</b>
<b>TC-001</b>	<b>4.46</b>
<b>TC-316</b>	<b>0.41</b>

Starting Point	Formula
7769 C	
<b>TC-046</b>	<b>71.10</b>
<b>TC-021</b>	<b>20.22</b>
<b>TC-001</b>	<b>8.68</b>

Starting Point	Formula
7770 C	
<b>TC-046</b>	<b>70.11</b>
<b>TC-021</b>	<b>17.89</b>
<b>TC-001</b>	<b>12.00</b>

Starting Point	Formula
7771 C	
<b>TC-046</b>	<b>60.72</b>
<b>TC-021</b>	<b>22.57</b>
<b>TC-001</b>	<b>15.86</b>
<b>TC-316</b>	<b>0.85</b>

Starting Point	Formula
Black 2 C	
<b>TC-046</b>	<b>68.98</b>
<b>TC-001</b>	<b>18.83</b>
<b>TC-153</b>	<b>5.94</b>
<b>TC-218</b>	<b>6.25</b>

Starting Point	Formula
Black 3 C	
<b>TC-046</b>	<b>45.37</b>
<b>TC-001</b>	<b>16.15</b>
<b>TC-217</b>	<b>30.49</b>
<b>TC-122</b>	<b>7.99</b>

Starting Point	Formula
Black 4 C	
<b>TC-046</b>	<b>65.57</b>
<b>TC-001</b>	<b>15.41</b>
<b>TC-122</b>	<b>9.57</b>
<b>TC-218</b>	<b>9.45</b>

# Texcharge TC

Starting Point	Formula
Black 5 C	
<b>TC-046</b>	<b>48.82</b>
<b>TC-153</b>	<b>19.86</b>
<b>TC-218</b>	<b>16.96</b>
<b>TC-001</b>	<b>4.09</b>
<b>TC-122</b>	<b>10.27</b>

Starting Point	Formula
Black 6 C	
<b>TC-153</b>	<b>58.25</b>
<b>TC-218</b>	<b>22.27</b>
<b>TC-001</b>	<b>14.69</b>
<b>TC-057</b>	<b>4.79</b>

Starting Point	Formula
Black 7 C	
<b>TC-046</b>	<b>54.08</b>
<b>TC-217</b>	<b>24.34</b>
<b>TC-153</b>	<b>21.58</b>

Starting Point	Formula
801 C	
<b>TC-312</b>	<b>4.95</b>
<b>TC-021</b>	<b>67.76</b>
<b>TC-218</b>	<b>27.29</b>

Starting Point	Formula
802 C	
<b>TC-053</b>	<b>31.79</b>
<b>TC-312</b>	<b>68.21</b>

Starting Point	Formula
803 C	
<b>TC-053</b>	<b>99.67</b>
<b>TC-105</b>	<b>0.33</b>

Starting Point	Formula
804 C	
<b>TC-105</b>	<b>100.00</b>

Starting Point	Formula
805 C	
<b>TC-137</b>	<b>100.00</b>

Starting Point	Formula
806 C	
<b>TC-137</b>	<b>7.92</b>
<b>TC-139</b>	<b>92.08</b>

Starting Point	Formula
807 C	
<b>TC-139</b>	<b>87.57</b>
<b>TC-154</b>	<b>12.43</b>

Starting Point	Formula
808 C	
<b>TC-021</b>	<b>51.43</b>
<b>TC-312</b>	<b>29.51</b>
<b>TC-218</b>	<b>12.91</b>
<b>TC-316</b>	<b>6.15</b>

Starting Point	Formula
809 C	
<b>TC-053</b>	<b>59.84</b>
<b>TC-057</b>	<b>37.28</b>
<b>TC-312</b>	<b>2.88</b>

Starting Point	Formula
810 C	
<b>TC-057</b>	<b>74.77</b>
<b>TC-105</b>	<b>25.23</b>

Starting Point	Formula
811 C	
<b>TC-103</b>	<b>28.37</b>
<b>TC-137</b>	<b>38.44</b>
<b>TC-381</b>	<b>33.19</b>

Starting Point	Formula
812 C	
<b>TC-139</b>	<b>85.89</b>
<b>TC-122</b>	<b>14.11</b>

Starting Point	Formula
813 C	
<b>TC-139</b>	<b>79.52</b>
<b>TC-154</b>	<b>20.48</b>

# Texcharge TC

Starting Point	Formula
814 C	
<b>TC-139</b> <b>88.29</b>	
<b>TC-217</b> <b>11.71</b>	